OMRON

Machine Automation Controller

NJ/NX-series

CPU Unit Software

User's Manual

NX701-1□□□

NX102-1□□□

NX102-90□□

NX1P2-1

NX1P2-90□□□□

NJ501-□□□□

NJ301-1□□□

NJ101-10□□

NJ101-90□□

CPU Unit





NOTE -

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks -

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD and SDHC logos are trademarks of SD-3C, LLC.





Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

Introduction

Thank you for purchasing an NJ/NX-series CPU Unit.

This manual contains information that is necessary to use the NJ/NX-series CPU Unit. Please read this manual and make sure you understand the functionality and performance of the NJ/NX-series CPU Unit before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

Intended Audience

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- · Personnel in charge of introducing FA systems.
- · Personnel in charge of designing FA systems.
- · Personnel in charge of installing and maintaining FA systems.
- · Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B 3503.

Applicable Products

This manual	covers	the	following	products
THIS IIIGHUAL	COVCIS	uic	TOHOWHING	products.

- NX-series CPU Units
 NX701-17□□
 - NX701-16□□
 - NX102-12□□
 - NX102-11□□
 - NX102-10□□
 - NX102-90□□
 -
 - NX1P2-11□□□□
 - NX1P2-11□□□□1
 - NX1P2-10□□□□
 - NX1P2-10□□□□1
 - NX1P2-90□□□□
 - NX1P2-90□□□□1
- NJ-series CPU Units
 - NJ501-□5□□
 - NJ501-□4□□
 - NJ501-□3□□
 - NJ301-12□□
 - NJ301-11□□
 - NJ101-10□□
 - NJ101-90□□

Part of the specifications and restrictions for the CPU Units are given in other manuals. Refer to *Relevant Manuals* on page 2 and *Related Manuals* on page 28.

Relevant Manuals

The following table provides the relevant manuals for the NJ/NX-series CPU Units. Read all of the manuals that are relevant to your system configuration and application before you use the NJ/NX-series CPU Unit.

Most operations are performed from the Sysmac Studio Automation Software. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Sysmac Studio.

									Maı	nual								
		Basic information]								
Purpose of use	NX-series CPU Unit Hardware User's Manual	NX-series NX102 CPU Unit Hardware User's Manual	NX-series NX1P2 CPU Unit Hardware User's Manual	NJ-series CPU Unit Hardware User's Manual	NJ/NX-series CPU Unit Software User's Manual	NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual	NJ/NX-series Instructions Reference Manual	NJ/NX-series CPU Unit Motion Control User's Manual	NJ/NX-series Motion Control Instructions Reference Manual	NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual	NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual	NJ/NX-series CPU Unit OPC UA User's Manual	NX-series CPU Unit FINS User's Manual	NJ/NX-series Database Connection CPU Units User's Manual	NJ-series SECS/GEM CPU Units User's Manual	NJ-series NJ Robotics CPU Unit User's Manual	NJ/NY-series NC Integrated Controller User's Manual	NJ/NX-series Troubleshooting Manual
Introduction to NX701 CPU Units	•																	
Introduction to NX102 CPU Units		•																
Introduction to NX1P2 CPU Units			•															
Introduction to NJ-series Controllers				•														
Setting devices and hardware	•	•	•	•														
Using motion control								•										
Using EtherCAT										•								
Using EtherNet/IP											•							
Software settings					•													
Using motion control					1			•										
Using EtherCAT					1					•								
Using EtherNet/IP		1			1			1			•				1		1	
Using OPC UA					1							•						
Using FINS					1								•					
Using the database connection service					1									•				
Using the GEM Services					1										•			
Using robot control		1			1			1							1	•	1	
Using numerical control					1												•	
Using the NX1P2 CPU Unit functions					1	•												


								1	Maı	nual								
		E	Basic	infor	matio	n	1		ı	1	1	1			1	ı	1	
Purpose of use	NX-series CPU Unit Hardware User's Manual	NX-series NX102 CPU Unit Hardware User's Manual	NX-series NX1P2 CPU Unit Hardware User's Manual	NJ-series CPU Unit Hardware User's Manual	NJ/NX-series CPU Unit Software User's Manual	NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual	NJ/NX-series Instructions Reference Manual	NJ/NX-series CPU Unit Motion Control User's Manual	NJ/NX-series Motion Control Instructions Reference Manual	NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual	NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual	NJ/NX-series CPU Unit OPC UA User's Manual	NX-series CPU Unit FINS User's Manual	NJ/NX-series Database Connection CPU Units User's Manual	NJ-series SECS/GEM CPU Units User's Manual	NJ-series NJ Robotics CPU Unit User's Manual	NJ/NY-series NC Integrated Controller User's Manual	NJ/NX-series Troubleshooting Manual
Writing the user program					•		•		_									
Using motion control								•	•									
Using EtherCAT										•								
Using EtherNet/IP											•							
Using OPC UA												•						
Using FINS													•					
Using the database connection service	1													•				
Using the GEM Services	1														•			
Using robot control																•		
Using numerical control																	•	
Programming error processing																		•
Using the NX1P2 CPU Unit functions						•												
Testing operation and debugging					•													
Using motion control	-				`			•										
Using EtherCAT										•								
Using EtherNet/IP					1					Ť								
Using OPC UA					1						–	•						
Using FINS					1							–	•					
Using the database connection service	+				ł								_					
Using the GEM Services		1			1										•			
Using robot control					ł											•		
Using numerical control		-			ł													
Using the NX1P2 CPU Unit functions		-			ł													
Learning about error management and corrections *1												A	•	•	A	A	A	•
Maintenance	+																	
Using motion control	•	•	•	•				•				-						
Using EtherCAT	4									•	_							
Using EtherNet/IP											•							

^{*1} Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the error management concepts and the error items. However, refer to the manuals that are indicated with triangles for details on errors corresponding to the products with the manuals that are indicated with triangles.

Manual Structure

Page Structure

The following page structure is used in this manual.



This illustration is provided only as a sample. It may not literally appear in this manual.

Special Information

Special information in this manual is classified as follows:



Precautions for Safe Use

Precautions on what to do and what not to do to ensure safe usage of the product.



Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.



Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.



Version Information

Information on differences in specifications and functionality for Controller with different unit versions and for different versions of the Sysmac Studio is given.

Note References are provided to more detailed or related information.

Precaution on Terminology

In this manual, "download" refers to transferring data from the Sysmac Studio to the physical Controller and "upload" refers to transferring data from the physical Controller to the Sysmac Studio.

For the Sysmac Studio, synchronization is used to both upload and download data. Here, "synchronize" means to automatically compare the data for the Sysmac Studio on the computer with the data in the physical Controller and transfer the data in the direction that is specified by the user.

Manual Structure

Sections in this Manual

					1	10
1	Introduction to NJ/NX-series Controllers	10	Communications Setup		2	11
2	CPU Unit Operation	11	Example of Actual Application Procedures		3	12
3	I/O Ports, Slave Configuration, and Unit Configuration	12	Troubleshooting		4 5	A
4	Controller Setup	Α	Appendices		3	
5	Designing Tasks	П	Index		7	7
6	Programming					3
7	Checking Operation and Actual Operation			_///	()
8	CPU Unit Functions					
9	Backup Functions					

CONTENTS

I	ntroducti	on	1
F	Relevant I	Manuals	2
ľ	Manual St	tructure	4
Ş	Sections i	in this Manual	7
7	Terms and	d Conditions Agreement	17
		ecautions	
	-	ns for Safe Use	
		ns for Correct Use	
F	Regulatio	ns and Standards	22
\	versions .		24
F	Related M	lanuals	28
٦	Гerminolo	ogy	32
F	Revision I	History	37
Section	n 1	Introduction to NJ/NX-series Controllers	
1	I-1 The No.	J/NX-series Controllers	
	1-1-2	Introduction to the System Configurations	1-5
		Specifications	
1	1-3 Overal 1-3-1 1-3-2	Il Operating Procedure for the NJ/NX-series Controller Overall Procedure	1-16
Section	n 2	CPU Unit Operation	
2	2-1 Overvi	iew of CPU Unit Operation Introduction to CPU Unit	
	2-1-1	Overview of Operation According to CPU Unit Status	
2	2-2 Softwa 2-2-1 2-2-2	Software Configuration Operation of Software	2-4
2	2-3 Access 2-3-1 2-3-2	Sing I/O	2-13
2	2-4 I/O Ref 2-4-1 2-4-2	freshing of NX Bus Function Module	2-25

	2-5-1 Overview of Control	
	2-5-2 Sequence Control System	
	2-5-3 Motion Control System	
0.0	, , , , , , , , , , , , , , , , , , , ,	
2-6	Overview of CPU Unit Data	
2-7	Operation for CPU Unit Status	
	2-7-1 CPU Unit Status	
	_ · _ · · · · · · · · · · · · · · · · ·	
	2-7-3 Operating Modes	2-40
Section 3	I/O Ports, Slave Configuration, and Unit Configuration	ation
3-1	Procedure to Create the Slave and Unit Configurations	
3-2	Creating and Comparing the Slave and Unit Configurations	
	3-2-1 Creating the EtherCAT Slave Configuration	
	3-2-2 Creating the Unit Configuration	
	3-2-3 Verifying the Unit Configuration	3-7
3-3	I/O Ports and Device Variables	3-8
	3-3-1 I/O Ports	3-8
	3-3-2 I/O Port Names	3-9
	3-3-3 Device Variables	3-10
3-4	Allocating Variables to Units	3-14
•	3-4-1 Procedure to Assign Variables to Units	
	3-4-2 Using Variables Assigned to Units	
3-5	Creating the Axes and Assigning Them to the Servo Drives/Encoder Input Slaves	s/NX Units
	3-5-1 Introduction	
	3-5-2 Axis Variables and Axes Group Variables	
Section 4	Controller Setup	
4-1	Overview of the Controller Setup	4-2
4-2	Initial Settings for the PLC Function Module	4-4
	4-2-1 Introduction	
	4-2-2 Controller Setup	
	4-2-3 Task Settings	
	4-2-4 Unit Configuration and Unit Setup for NX102 CPU Units and NX1P2 CPU Units	
	4-2-5 Unit Configuration and Unit Setup for NJ-series CPU Units	
4-3	Initial Settings for NX Units	
	4-3-1 NX Unit Settings	
	4-3-2 I/O Allocation Settings	
	4-3-3 Unit Operation Settings	4-19
4-4	Initial Settings for Special Units	4-20
4-5	Initial Settings for the Motion Control Function Module	4-22
	4-5-1 Introduction	4-22
	4-5-2 Setting Methods	4-23
4-6	Initial Settings for the EtherCAT Master Function Module	
4-7	Initial Settings for the EtherNet/IP Function Module	
4-8	Initial Settings for Built-in I/O	4-26
4-9	Initial Settings for Option Boards	4-27
4-10	Memory Settings for CJ-series Units	4-28
	4-10-1 Setting Procedure	

	4-10-2 4-10-3	Setting ScreenSettings	
Section &	5	Designing Tasks	
5-1	Overvi	ew of Task Designing Procedure	5-3
5-2	Overvi	ew of Tasks	5-6
	5-2-1	Tasks	
	5-2-2	Instructions Related to Tasks	
	5-2-3	System-defined Variables Related to Tasks	
5-3		ications and Basic Operation of Tasks for NX701 CPU Units	
	5-3-1	Specifications of Tasks for NX701 CPU Units	
	5-3-2	Guidelines for Separating Tasks for NX701 CPU Units	
	5-3-3 5-3-4	Basic Operation of Tasks for NX701 CPU Units Event Task Execution Conditions for NX701 CPU Units	
	5-3- 4 5-3-5	Event Task Execution Timing for NX701 CPU Units	
	5-3-6	Operation When Execution Condition Is Met Again before Execution of the Event Task Is Completed	
5-4	•	ications and Basic Operation of Tasks for NX102 CPU Units and NX1P2 CPU I	
	5-4-1	Specifications of Tasks for NX102 CPU Units and NX1P2 CPU Units	
	5-4-2	Guidelines for Separating Tasks for NX102 CPU Units and NX1P2 CPU Units	
	5-4-3	Basic Operation of Tasks for NX102 CPU Units and NX1P2 CPU Units	
	5-4-4	Event Task Execution Conditions for NX102 CPU Units and NX1P2 CPU Units	
	5-4-5	Event Task Execution Timing for NX102 CPU Units and NX1P2 CPU Units	5-45
	5-4-6	Operation When Execution Condition Is Met Again before Execution of the Event Task Is Completed	5-49
5-5	Specif	ications and Basic Operation of Tasks for NJ-series Controllers	5-50
	5-5-1	Specifications of Tasks for NJ-series Controllers	
	5-5-2	Guidelines for Separating Tasks for NJ-series Controllers	5-51
	5-5-3	Basic Operation of Tasks for NJ-series Controllers	
	5-5-4	Event Task Execution Conditions for NJ-series Controllers	
	5-5-5	Event Task Execution Timing for NJ-series Controllers	5-65
	5-5-6	Operation When Execution Condition Is Met Again before Execution of the Event Task Is Completed	5-69
5-6	Servic	es Other Than Tasks	
	5-6-1	Execution Priorities and Execution Orders of Services Other Than Tasks	
	5-6-2	Processing Performed in and Execution Timing of the Tag Data Link Service	
	5-6-3	Processing Performed in and Execution Timing of the Option Board Service	
	5-6-4	Processing Performed in and Execution Timing of the Communications Bridge Service	
	5-6-5	Processing Performed in and Execution Timing of the System Services	
5-7	Assigr	nment and Settings Related to Tasks	
	5-7-1	Assigning I/O Refreshing to Tasks	
	5-7-2	Assigning Tasks to Programs	
	5-7-3	Parameters for Primary Periodic Task and Periodic Tasks	5-94
5-8	Ensuri	ing Concurrency of Variable Values	5-97
	5-8-1	Ensuring Concurrency of Variable Values between Tasks	
	5-8-2	Variable Access from Outside the Controller	5-103
5-9		Related to Tasks	
5-10) Monito	oring Task Execution Status and Task Execution Times	. 5-110
5-11	Task D	esign Methods and I/O Response Times	. 5-114
	5-11-1	Checking the Task Execution Time	5-114
	5-11-2	Examples of Task Design	
	5-11-3	System Input and Output Response Times	5-118

Section 6 Programming

	0-1	Overview of Programming Procedures	დ-ა					
	6-2	POUs (Program Organization Units)	6-5					
		6-2-1 What Are POUs?						
		6-2-2 Overview of the Three Types of POUs						
		6-2-3 Differences between Programs, Functions, and Function Blocks						
		6-2-4 Details on Programs						
		6-2-5 Details on Function Blocks						
		6-2-6 Details on Functions						
		6-2-7 Operation That Applies to Both Functions and Function Blocks						
	6-3	Variables						
		6-3-1 Variables						
		6-3-2 Types of Variables						
		6-3-4 Attributes of Variables						
		6-3-5 Data Types						
		6-3-6 Derivative Data Types						
		6-3-7 Array Specifications and Range Specifications for Data Types						
		6-3-8 Variable Attributes						
		6-3-9 Changes to Variables for Status Changes						
		6-3-10 Function Block Instances						
		6-3-11 Monitoring Variable Values						
		6-3-12 Restrictions on Variable Names and Other Program-related Names						
	6-4	Constants (Literals)						
	0-4	6-4-1 Constants						
		6-4-2 Notation for Different Data Types						
		21						
	6-5	Programming Languages						
		6-5-1 Programming Languages						
		6-5-2 Ladder Diagram Language						
		6-5-3 Structured Text Language	6-96					
	6-6	Instructions	6-133					
		6-6-1 Instructions	6-133					
		6-6-2 Basic Understanding of Instructions	6-133					
		6-6-3 Instruction Errors	6-136					
	6-7	Namespaces	6-142					
		6-7-1 Namespaces	6-142					
		6-7-2 Namespace Specifications	6-143					
		6-7-3 Procedure for Using Namespaces	6-146					
	6-8	Libraries	6-147					
		6-8-1 Introduction to Libraries						
		6-8-2 Specifications of Libraries						
		6-8-3 Library Object Specifications						
		6-8-4 Procedure to Use Libraries						
	6-9	Programming Precautions						
		6-9-1 Array Specifications for Input Variables, Output Variables, In-Out Variables						
		6-9-2 Structure Variables for Input Variables, Output Variables, In-Out Variables						
		0-9-3 Waster Control	0-132					
	_							
Sect	ion 7	Checking Operation and Actual Operation						
	7-1	Overview of Steps in Checking Operation and Actual Operation						
	7-2	Offline Debugging	7-3					
	_	7-2-1 Features of Simulation						
		7-2-2 Simulation Execution						
		7-2-3 Setting Up Simulations						

7-3	Checking Operation on the Actual System and Actual Operation	
	7-3-1 Procedures	
	7-3-2 Downloading the Project	
	7-3-3 Checking I/O Wiring	
	7-3-4 MC Test Run	
	7-3-5 Checking the Operation of the Oser Program	
Section 8	CPU Unit Functions	
8-1	Data Management, Clock, and Operating Functions	
	8-1-1 Clearing All Memory	
	8-1-2 Clock	
	8-1-3 RUN Output	8-6
8-2	Management Functions for NX Units	8-7
	8-2-1 NX Bus Function Module	
	8-2-2 Mounting Settings of NX Units on the CPU Unit	
	8-2-3 Restarting NX Units on the CPU Unit	
	8-2-4 Checking Wiring for NX Units on the CPU Unit	
	8-2-5 Fail-soft Operation for NX Units on the CPU Unit	
	8-2-6 Monitoring Total Power-ON Time for NX Units on the CPU Unit	8-21
8-3	Management Functions for CJ-series Units	8-22
	8-3-1 Basic I/O Units	8-22
	8-3-2 Special Units	8-23
8-4	SD Memory Card Operations	8-25
•	8-4-1 SD Memory Card Operations	
	8-4-2 Specifications of Supported SD Memory Cards, Folders, and Files	
	8-4-3 SD Memory Card Operation Instructions	
	8-4-4 FTP Client Communications Instructions	
	8-4-5 FTP Server	
	8-4-6 File Operations from the Sysmac Studio	
	8-4-7 SD Memory Card Life Expiration Detection	
	8-4-8 List of System-defined Variables Related to SD Memory Cards	
	8-4-9 SD Memory Card Self-diagnostic Functions	
	8-4-10 Exclusive Control of File Access in SD Memory Cards	
8-5	Security	
	8-5-1 Authentication of User Program Execution IDs	8-35
	8-5-2 User Program Transfer with No Restoration Information	8-38
	8-5-3 Overall Project File Protection	
	8-5-4 Data Protection	
	8-5-5 Operation Authority Verification	
	8-5-6 CPU Unit Write Protection	
	8-5-7 CPU Unit Names and Serial IDs	
8-6	Debugging	
	8-6-1 Forced Refreshing	
	8-6-2 Changing Present Values	
	8-6-3 Online Editing	
	8-6-4 Data Tracing	
	8-6-5 Differential Monitoring	8-63
8-7	Event Logs	8-68
	8-7-1 Introduction	
	8-7-2 Detailed Information on Event Logs	
	8-7-3 Controller Events (Controller Errors and Information)	
	8-7-4 User-defined Events (User-defined Errors and Information)	8-77
8-8	Changing Event Levels	8-84
	8-8-1 Applications of Changing Event Levels	
	8-8-2 Events for Which the Event Level Can Be Changed	
	8-8-3 Procedure to Change an Event Level	

Section 9 Backup Functions

9-1	The Bac	kup Functions	9-3
	9-1-1	Applications of Backup Functions	
	9-1-2	Examples of Operating Procedures for the Backup Functions	
	9-1-3	Data That Is Backed Up	
	9-1-4 9-1-5	Types of Backup FunctionsRelation Between the Different Types of Backup Functions and Data Groups	9-9
	9-1-5	Applicable Range of the Backup Functions	
9-2	SD Men	nory Card Backups	
. .	9-2-1	Backup (Controller to SD Memory Card)	
	9-2-2	Restore (SD Memory Card to Controller)	
	9-2-3	Verify (between Controller and SD Memory Card)	
9-3	Disablir	ng Backups to SD Memory Cards	9-33
9-4	Automa	tic Transfers from SD Memory Cards	9-34
9-5	Progran	n Transfer from SD Memory Card	9-36
9-6	Sysmac	Studio Controller Backups	9-43
	9-6-1	Backup (Controller to Computer)	
	9-6-2	Restore (Computer to Controller)	
	9-6-3	Verify (between Controller and Computer)	9-47
9-7	Importi	ng and Exporting Sysmac Studio Backup File Data	9-48
9-8	Sysmac	Studio Variable and Memory Backup Functions	9-49
	9-8-1	Applicable Data for Sysmac Studio Variable and Memory Backup Functions	
	9-8-2	Using Sysmac Studio Variable and Memory Backup Functions	
	9-8-3	Compatibility between CPU Unit Models	9-50
9-9	Backup	Functions When EtherCAT Slaves Are Connected	
	9-9-1	Backed Up EtherCAT Slave Data	
	9-9-2	Backup Support Depending on the Controller Status	
	9-9-3	Conditions for Restoring EtherCAT Slave Data	
	9-9-4	EtherCAT Slaves for Which You Can Back Up Data	
9-10		Functions When EtherCAT Slave Terminals Are Connected	
	9-10-1 9-10-2	Backing Up Data in an EtherCAT Slave Terminal	
	9-10-2	Conditions for Restoring EtherCAT Slave Terminal Data	
Q_11		Functions When NX Units Are Connected	
3-11	9-11-1	Backing Up Data in NX Units on the CPU Unit	
	9-11-2	Backup Support Depending on the Controller Status	
	9-11-3	Conditions for Restoring NX Unit Data on the CPU Unit	
9-12	Backup	Functions When CJ-series Units Are Connected	9-61
•	9-12-1	Backed Up CJ-series Unit Data	
	9-12-2	Backup Support Depending on the Controller Status	
	9-12-3	Conditions for Restoring CJ-series Unit Data	9-61
9-13	Backup	-related Files	9-63
	9-13-1	Types of Backup-related Files	9-63
	9-13-2	Specifications of a Backup File	
	9-13-3	Specifications of a Restore Command File	
	9-13-4	Specifications of an Automatic Transfer Command File	
	9-13-5 9-13-6	Specifications of a Controller Verification Results File	
	9-13-0	Specifications of an EtherCAT Slave Terminal Verification Results File	
	9-13-8	Specifications of an NX Unit Verification Results File	
	9-13-9	Specifications of CJ-series Unit Verification Results File	
9-14	Compat	ibility between Backup-related Files	9-76
	9-14-1	Compatibility between Backup Functions	9-76
	9-14-2	Compatibility between CPU Unit Models	
	9-14-3	Compatibility between Unit Versions of CPU Units	9-78

9-1	5 Funct	ions That Cannot Be Executed during Backup Functions	9-80
Section	10	Communications Setup	
10-	1 Comn 10-1-1	nunications System OverviewIntroduction	
10-	2 Conne 10-2-1 10-2-2	Configurations That Allow Online Connections	10-7
10-	3 Conne 10-3-1 10-3-2	Connection Configurations between Controllers and Slaves	10-10
10-	4 Conne 10-4-1 10-4-2	Connection with HMIs or Serial Communications Devices	10-14
Section	11	Example of Actual Application Procedures	
11-	1 Exam 11-1-1 11-1-2	ple Application	11-2
11-	2 Overv 11-2-1 11-2-2 11-2-3 11-2-4 11-2-5 11-2-6	iew of the Example Procedure Wiring and Settings Software Design Software Settings from the Sysmac Studio Programming with the Sysmac Studio Simulation with the Sysmac Studio Checking Operation and Starting Operation on the Actual System	11-3 11-4 11-8 11-9
Section	12	Troubleshooting	
12-	1 Overv	iew of Troubleshooting	12-2
Appendi	ces		
A- 1	Speci A-1-1 A-1-2 A-1-3	Fications General Specifications Performance Specifications Function Specifications	A-3
A-2	2 Calcu A-2-1 A-2-2	lating Guidelines for the Real Processing Times of Tasks for the NX701 Calculating the Average Real Processing Times of Tasks Example of Calculating the Average Real Processing Time of a Task and Setting the	A-22 ne Task Period
A -3	A-3-1 A-3-2	lating Guidelines for the Real Processing Times of Tasks for the NX102 Calculating the Average Real Processing Times of Tasks Example of Calculating the Average Real Processing Time of a Task and Setting the	System A-32 A-32 ne Task Period
A -4	A-4-1 A-4-2	lating Guidelines for the Real Processing Times of Tasks for the NX1P2 Calculating the Average Real Processing Times of Tasks Example of Calculating the Average Real Processing Time of a Task and Setting the	System A-42 A-43
A-5		lating Guidelines for the Real Processing Times of Tasks for the NJ-seri	A-49 i es System

	A-5-1	Calculating the Average Real Processing Times of Tasks	A-53
	A-5-2	Example of Calculating the Average Real Processing Time of a Task and Setting the Ta	
A-6	System	-defined Variables	
	A-6-1	System-defined Variables for the Overall NJ/NX-series Controller (No Category)	
	A-6-2	PLC Function Module, Category Name: PLC	
	A-6-3	PLC Function Module, Category Name: CJB	
	A-6-4	NX Bus Function Module, Category Name: _NXB	
	A-6-5	Motion Control Function Module, Category Name: MC	
	A-6-6	EtherCAT Master Function Module, Category Name: _EC	
	A-6-7	EtherNet/IP Function Module, Category Name: _EIP	
	A-6-8	Meanings of Error Status Bits	A-123
A-7	Specific	cations for Individual System-defined Variables	
	A-7-1	System-defined Variables for the Overall NJ/NX-series Controller (No Category)	
	A-7-2	PLC Function Module, Category Name: _PLC	
	A-7-3	PLC Function Module, Category Name: _CJB	
	A-7-4	NX Bus Function Module, Category Name: _NXB	
	A-7-5	Motion Control Function Module, Category Name: _MC	A-157
	A-7-6	EtherCAT Master Function Module, Category Name: _EC	
	A-7-7	EtherNet/IP Function Module, Category Name: _EIP	A-170
A-8	Attribut	es of CPU Unit Data	A-195
A-9	Conten	ts of Memory Used for CJ-series Units	
	A-9-1	CIO Area	
	A-9-2	Internal I/O Area	
	A-9-3	Holding Area	
	A-9-4	DM Area	
	A-9-5	EM Area	
A-10		Memory Allocation Methods	
	A-10-1	Variable Memory Allocation Rules	
	A-10-2	Important Case Examples	
A-11	Registe	ring a Symbol Table on the CX-Designer	A-218
A-12		Disable EtherCAT Slaves and Axes	
	A-12-1	Project Settings When Using EtherCAT Slaves and Axes	
	A-12-2	Using Instructions to Enable/Disable EtherCAT Slaves and Axes	
	A-12-3	System-defined Variables That Indicate EtherCAT Slave or Axis Status	
	A-12-4	Enabling/Disabling Execution of Program	
	A-12-5	Checking Enabled/Disabled Program	
	A-12-6 A-12-7	Settings with the Sysmac Studio Examples of Applications of Enabling/Disabling EtherCAT Slaves and Axes	
A 12		strictions for the User Program	
A-13	A-13-1	-	
	A-13-1 A-13-2	User Program Object Restrictions	
A 44			
A-14	_	ng CPU Units with Unit Version 1.02 or Earlier	
	A-14-1	Uploading the Data from the CPU Unit	
	A-14-2 A-14-3	Connecting the New CPU Unit	
A 15	_	•	
A-15		Information for NX-series Controllers	
	A-15-1 A-15-2	Relationship Between Unit Versions of CPU Units and Sysmac Studio Versions Functions That Were Added or Changed for Each Unit Version	
A-16	Version	Information for NJ-series Controllers	
	A-16-1	Relationship between Unit Versions of CPU Units and Sysmac Studio Versions	
	A-16-2	Relationship between Hardware Revisions of CPU Units and Sysmac Studio Versions	
	A-16-2 A-16-3 A-16-4	Relationship between Hardware Revisions of CPU Units and Sysmac Studio Versions Functions That Were Added or Changed for Each Unit Version Performance Improvements for Unit Version Upgrades	A-248

Index

Terms and Conditions Agreement

Warranty, Limitations of Liability

Warranties

Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Disclaimers

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Safety Precautions

Refer to the following manuals for safety precautions.

- NX-series CPU Unit Hardware User's Manual (Cat. No. W535)
- NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593)
- NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)

Precautions for Safe Use

Refer to the following manuals for precautions for safe use.

- NX-series CPU Unit Hardware User's Manual (Cat. No. W535)
- NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593)
- NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)

Precautions for Correct Use

Refer to the following manuals for precautions for correct use.

- NX-series CPU Unit Hardware User's Manual (Cat. No. W535)
- NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593)
- NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)

Regulations and Standards

Conformance to EU Directives

Applicable Directives

- EMC Directives
- · Low Voltage Directive

Concepts

EMC Directive

OMRON devices that comply with EU Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards.*

Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer. EMC-related performance of the OMRON devices that comply with EU Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

* Applicable EMC (Electromagnetic Compatibility) standards are as follows: EMS (Electromagnetic Susceptibility): EN 61131-2 EMI (Electromagnetic Interference): EN 61131-2 (Radiated emission: 10-m regulations)

Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 VAC and 75 to 1,500 VDC meet the required safety standards. The applicable directive is EN 61010-2-201.

Conformance to EU Directives

The NJ/NX-series Controllers comply with EU Directives. To ensure that the machine or device in which the NJ/NX-series Controller is used complies with EU Directives, the Controller must be installed as follows:

- The NJ/NX-series Controller must be installed within a control panel.
- You must use the power supply in SELV specifications for the DC power supplies connected to DC Power Supply Units and I/O Units.
- NJ/NX-series Controllers that comply with EU Directives also conform to the Common Emission Standard (EN 61000-6-4). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions.

You must therefore confirm that the overall machine or equipment complies with EU Directives.

Conformance to KC Certification

Observe the following precaution if you use NX-series Units in Korea.

A급 기기 (업무용 방송통신기자재) 이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Class A Device (Broadcasting Communications Device for Office Use)

This device obtained EMC registration for office use (Class A), and it is intended to be used in places other than homes.

Sellers and/or users need to take note of this.

Conformance to Shipbuilding Standards

The NJ/NX-series Controllers comply with the following shipbuilding standards. Applicability to the shipbuilding standards is based on certain usage conditions. It may not be possible to use the product in some locations. Contact your OMRON representative before attempting to use a Controller on a ship.

Usage Conditions for NK and LR Shipbuilding Standards

- The NJ/NX-series Controller must be installed within a control panel.
- Gaps in the door to the control panel must be completely filled or covered with gaskets or other material.
- The following noise filter must be connected to the power supply line.

Noise Filter

Manufacturer	Model	
Cosel Co., Ltd.	TAH-06-683	

Software Licenses and Copyrights

This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj_info_e/.

Versions

Hardware revisions and unit versions are used to manage the hardware and software in NJ/NX-series Units and EtherCAT slaves. The hardware revision or unit version is updated each time there is a change in hardware or software specifications. Even when two Units or EtherCAT slaves have the same model number, they will have functional or performance differences if they have different hardware revisions or unit versions.


Checking Versions

You can check versions on the ID information indications or with the Sysmac Studio.

Checking Unit Versions on ID Information Indications


The unit version is given on the ID information indication on the side of the product.

The ID information on an NX-series NX701-□□□□ CPU Unit is shown below.



Note The hardware revision is not displayed for the Unit that the hardware revision is in blank.

The ID information on an NX-series NX102-□□□□ CPU Unit is shown below.



Note The hardware revision is not displayed for the Unit that the hardware revision is in blank.

MAC address


PORT1: PORT2: POR

Lot number Serial number

The ID information on an NX-series NX1P2-

Note The hardware revision is not displayed for the Unit that the hardware revision is in blank.

The ID information on an NJ-series NJ501- CPU Unit is shown below.



Note The hardware revision is not displayed for the Unit that the hardware revision is in blank.

Checking Unit Versions with the Sysmac Studio

You can use the Sysmac Studio to check unit versions. The procedure is different for Units and for EtherCAT slaves.

Checking the Unit Version of an NX-series CPU Unit

You can use the Production Information while the Sysmac Studio is online to check the unit version of a Unit. You can do this for the following Units.

Model	Unit for which unit version can be checked		
NX701-□□□□	CPU Unit		
NX102-□□□□	CPU Unit and NX Unit on CPU Rack		
NX1P2-□□□□	CPU Unit, NX Unit on CPU Rack, and Option Boards		

1 Right-click CPU Rack under Configurations and Setup - CPU/Expansion Racks in the Multiview Explorer and select *Production Information*.

The Production Information Dialog Box is displayed.

Checking the Unit Version of an NJ-series CPU Unit

You can use the Production Information while the Sysmac Studio is online to check the unit version of a Unit. You can do this for the CPU Unit, CJ-series Special I/O Units, and CJ-series CPU Bus Units. You cannot check the unit versions of CJ-series Basic I/O Units with the Sysmac Studio.

Use the following procedure to check the unit version.

1 Double-click CPU/Expansion Racks under Configurations and Setup in the Multiview Explorer. Or, right-click CPU/Expansion Racks under Configurations and Setup and select *Edit* from the menu.


The Unit Editor is displayed.

2 Right-click any open space in the Unit Editor and select **Production Information**. The Production Information Dialog Box is displayed.

Changing Information Displayed in Production Information Dialog Box

1 Click the **Show Detail** or **Show Outline** Button at the lower right of the Production Information Dialog Box.

The view will change between the production information details and outline.



Outline View Detail View

The information that is displayed is different for the Outline View and Detail View. The Detail View displays the unit version, hardware version, and software versions. The Outline View displays only the unit version.

Note The hardware revision is separated by "/" and displayed on the right of the hardware version. The hardware revision is not displayed for the Unit that the hardware revision is in blank.

Checking the Unit Version of an EtherCAT Slave

You can use the Production Information while the Sysmac Studio is online to check the unit version of an EtherCAT slave. Use the following procedure to check the unit version.

1 Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit* from the menu.

The EtherCAT Tab Page is displayed.


2 Right-click the master on the EtherCAT Tab Page and select **Display Production Information**.


The Production Information Dialog Box is displayed. The unit version is displayed after "Rev."

Changing Information Displayed in Production Information Dialog Box

1 Click the Show Detail or Show Outline Button at the lower right of the Production Information Dialog Box.

The view will change between the production information details and outline.





Outline View

Detail View

Unit Versions of CPU Units and Sysmac Studio Versions

The functions that are supported depend on the unit version of the NJ/NX-series CPU Unit. The version of Sysmac Studio that supports the functions that were added for an upgrade is also required to use those functions.

Refer to A-15 Version Information for NX-series Controllers and A-16 Version Information for NJ-series Controllers for the relationship between the unit versions of the CPU Units and the Sysmac Studio versions, and for the functions that are supported by each unit version.

Related Manuals

The followings are the manuals related to this manual. Use these manuals for reference.

Manual name	Cat. No.	Model numbers	Application	Description
NX-series CPU Unit Hardware User's Manual	W535	NX701-□□□□	Learning the basic specifications of the NX701 CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NX701 system is provided along with the following information on the CPU Unit. • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection
NX-series NX102 CPU Unit Hardware User's Manual	W593	NX102-□□□	Learning the basic specifications of the NX102 CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NX102 system is provided along with the following information on the CPU Unit. • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection
NX-series NX1P2 CPU Unit Hardware User's Manual	W578	NX1P2-□□□	Learning the basic specifications of the NX1P2 CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NX1P2 system is provided along with the following information on the CPU Unit. • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection
NJ-series CPU Unit Hardware User's Manual	W500	NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning the basic specifications of the NJ-series CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NJ-series system is provided along with the following information on the CPU Unit. • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection
NJ/NX-series CPU Unit Software User's Manual	W501	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning how to pro- gram and set up an NJ/NX-series CPU Unit. Mainly software infor- mation is provided.	The following information is provided on a Controller built with an NJ/NX-series CPU Unit. CPU Unit operation CPU Unit features Initial settings Programming based on IEC 61131-3 language specifications

Manual name	Cat. No.	Model numbers	Application	Description
NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual	W579	NX1P2-□□□□	Learning about the details of functions only for an NX-series NX1P2 CPU Unit and an introduction of functions for an NJ/NX-series CPU Unit.	Of the functions for an NX1P2 CPU Unit, the following information is provided. • Built-in I/O • Serial Communications Option Boards • Analog I/O Option Boards An introduction of following functions for an NJ/NX-series CPU Unit is also provided. • Motion control functions • EtherNet/IP communications functions • EtherCAT communications functions
NJ/NX-series Instructions Reference Manual	W502	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning detailed specifications on the basic instructions of an NJ/NX-series CPU Unit.	The instructions in the instruction set (IEC 61131-3 specifications) are described.
NJ/NX-series CPU Unit Motion Control User's Manual	W507	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning about motion control set- tings and program- ming concepts.	The settings and operation of the CPU Unit and programming concepts for motion control are described.
NJ/NX-series Motion Control Instructions Reference Manual	W508	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning about the specifications of the motion control instructions.	The motion control instructions are described.
NJ/NX-series CPU Unit Built-in EtherCAT® Port User's Manual	W505	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Using the built-in EtherCAT port on an NJ/NX-series CPU Unit.	Information on the built-in EtherCAT port is provided. This manual provides an introduction and provides information on the configuration, features, and setup.
NJ/NX-series CPU Unit Built-in EtherNet/IP [™] Port User's Manual	W506	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Using the built-in EtherNet/IP port on an NJ/NX-series CPU Unit.	Information on the built-in EtherNet/IP port is provided. Information is provided on the basic setup, tag data links, and other features.
NJ/NX-series CPU Unit OPC UA User's Manual	W588	NX102-□□□□ NJ501-1□00	Using the OPC UA.	Information on the OPC UA is provided.
NX-series CPU Unit FINS User's Manual	W596	NX701-□□20 NX102-□□□□	Using the FINS function on the NX-series CPU Unit.	An introduction to the FINS function on the NX-series CPU Unit is provided.
NJ/NX-series Database Connection CPU Units User's Manual	W527	NX701-□□20 NX102-□□20 NJ501-□□20 NJ101-□□20	Using the database connection service with NJ/NX-series Controllers.	Describes the database connection service.
NJ-series SECS/GEM CPU Units User's Manual	W528	NJ501-1340	Using the GEM Services with NJ-series Controllers.	Provides information on the GEM Services.
NJ-series NJ Robotics CPU Unit User's Manual	W539	NJ501-4□□□	Controlling robots with NJ-series CPU Units.	Describes the functionality to control robots.
NJ/NY-series NC Integrated Controller User's Manual	O030	NJ501-5300 NY532-5400	Performing numerical control with NJ/NY-series Controllers.	Describes the functionality to perform the numerical control.
NJ/NY-series G code Instructions Reference Manual	O031	NJ501-5300 NY532-5400	Learning about the specifications of the G code/M code instructions.	The G code/M code instructions are described.

Manual name	Cat. No.	Model numbers	Application	Description
NJ/NX-series Troubleshooting Manual	W503	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning about the errors that may be detected in an NJ/NX-series Controller.	Concepts on managing errors that may be detected in an NJ/NX-series Controller and information on individual errors are described.
Sysmac Studio Version 1 Operation Manual	W504	SYSMAC -SE2□□□	Learning about the operating procedures and functions of the Sysmac Studio.	Describes the operating procedures of the Sysmac Studio.
CNC Operator Operation Manual	O032	SYSMAC -RTNC0□□□D	Learning an introduc- tion of the CNC Oper- ator and how to use it.	An introduction of the CNC Operator, installation procedures, basic operations, connection operations, and operating procedures for main functions are described.
NX-series EtherCAT® Coupler Unit User's Manual	W519	NX-ECC	Learning how to use an NX-series Ether- CAT Coupler Unit and EtherCAT Slave Ter- minals.	The following items are described: the overall system and configuration methods of an EtherCAT Slave Terminal (which consists of an NX-series EtherCAT Coupler Unit and NX Units), and information on hardware, setup, and functions to set up, control, and monitor NX Units through EtherCAT.
NX-series Data Reference Manual	W525	NX	Referencing lists of the data that is required to configure systems with NX- series Units.	Lists of the power consumptions, weights, and other NX Unit data that is required to configure systems with NX-series Units are provided.
NX-series NX Units User's Manuals	W521	NX-ID	Learning how to use NX Units.	Describes the hardware, setup methods, and functions of the NX Units. Manuals are available for the following Units. Digital I/O Units, Analog I/O Units, System Units, Position Interface Units, Communications Interface Units, Load Cell Input Units, and IO-Link Master Units.
	W522	NX-AD		
	W592 W566	NX-HAD□□□ NX-TS□□□□ NX-HB□□□□		
	NX-RDL□□□			
	W524	NX-ECS□□□ NX-PG0□□□		
	W540	NX-CIF□□□		
	W565	NX-RS 🗆 🗆 🗆		
NX-series Safety Control Unit User's Manual	W567 Z930	NX-ILM	Learning how to use NX-series Safety Control Units	Describes the hardware, setup methods, and functions of the NX-series Safety Control Units.
Vision System FH/FZ5 Series Vision System User's Manual	Z340	FH-1□□□ FH-3□□□ FZ5-L35□ FZ5-6□□ FZ5-11□□	Learning how to use the FH/FZ5-series Vision Systems.	Describes the software functions, setup and operating methods required for using the FH/FZ5-series system.
Vision Sensor FQ-M series Specialized Vision Sensor for Positioning User's Manual	Z314	FQ-MS12□	Learning how to use the Specialized Vision Sensors for Positioning.	Describes the hardware, setup methods and functions of the Specialized Vision Sensors for Positioning.
Vision Sensor FZ3 Series User's Manual	Z290	FZ3-□□□	Learning how to use the FZ3-series Vision Sensors.	Describes the software functions, setup and operating methods of the FZ3-series Vision Sensors.
Displacement Sensor ZW series Confocal Fiber Type Displace- ment Sensor User's Manual	Z332	ZW-CE1□	Learning how to use the ZW-series Displacement Sensors.	Describes the hardware, setup methods and functions of the ZW-series Displacement Sensors.

Manual name	Cat. No.	Model numbers	Application	Description
CJ-series Special Unit	W490	CJ1W-AD□□□	Learning how to use	The methods and precautions for using CJ-
Manuals		CJ1W-DA□□□	CJ-series Units with	series Units with an NJ501 CPU Unit are
for NJ-series CPU Unit		CJ1W-MAD42	an NJ-series CPU	described, including access methods and pro-
	W491	CJ1W-TC□□□	Unit.	gramming interfaces.
	W492	CJ1W-CT021		Manuals are available for the following Units. Analog I/O Units, Insulated-type Analog I/O
	W498	CJ1W-PDC15		Units, Temperature Control Units, ID Sensor
		CJ1W-PH41U		Units, High-speed Counter Units, Serial Com-
		CJ1W-AD04U		munications Units. DeviceNet Units, Ether-
	W493	CJ1W-CRM21		Net/IP Units and CompoNet Master Units.
	W494	CJ1W-SCU□□		·
	W495	CJ1W-EIP21		
	W497	CJ1W-DRM21		
	Z317	CJ1W-V680□□□		
NA-series Programmable Ter-	V118	NA5-□W□□□□	Learning about NA-	Describes the pages and object functions of
minal			series PT pages and	the NA-series Programmable Terminals.
Software User's Manual			object functions.	
NS-series Programmable Ter-	V073	NS15-□□□□□	Learning how to use	Describes the setup methods, functions, etc. of
minals		NS12-□□□□□	the NS-series Pro-	the NS-series Programmable Terminals.
Programming Manual		NS10-□□□□□	grammable Termi-	
		NS8-□□□□□	nals.	
		NS5-□□□□□		
CX-Designer	V099		Learning to create	Describes operating procedures for the CX-
User's Manual			screen data for NS-	Designer.
			series Programma-	
			ble Terminals.	

Terminology

Term	Description
absolute encoder home offset	This data is used to restore in the CPU Unit the actual position of a Servo Drive with an absolute encoder. The offset is the difference between the command position after homing and the absolute data that is read from the absolute encoder.
array specification	One of the variable specifications. An array variable contains multiple elements of the same data type. The elements in the array are specified by serial numbers called subscripts that start from the beginning of the array.
AT	One of the attributes of a variable. This attribute allows the user to specify what is assigned to a variable. An I/O port or an address in memory used for CJ-series Units can be specified.
axes group	A functional unit that groups together axes within the Motion Control Function Module.
Axes Group Variable	A system-defined variable that is defined as a structure and provides status information and some of the axes parameters for an individual axes group. An Axes Group Variable is used to specify an axes group for motion control instructions and to monitor the command interpolation velocity, error information, and other information for the axes group.
axis	A functional unit within the Motion Control Function Module. An axis is assigned to the drive mechanism in an external Servo Drive or the sensing mechanism in an external Encoder Input Slave Unit.
Axis Variable	A system-defined variable that is defined as a structure and provides status information and some of the axis parameters for an individual axis. An Axis Variable is used to specify an axis for motion control instructions and to monitor the command position, error information, and other information for the axis.
basic data type	Any of the data types that are defined by IEC 61131-3. They include Boolean, bit string, integer, real, duration, date, time of day, date and time, and text string data types. "Basic data type" is used as opposed to derivative data types, which are defined by the user.
cam data variable	A variable that represents the cam data as a structure array. A cam data variable is an array structure that consists of phases and displacements.
CJ-series Unit	Any of the CJ-series Units that can be used with an NJ-series Controller.
Communications Coupler Unit	The generic name of an interface unit for remote I/O communications on a network between NX Units and a host network master. For example, an EtherCAT Coupler Unit is a Communications Coupler Unit for an EtherCAT network.
Constant	One of the attributes of a variable. If you specify the Constant attribute for a variable, the value of the variable cannot be written by any instructions, ST operators, or CIP message communications.
Controller	The range of devices that are directly controlled by the CPU Unit. In the NX-series System, the Controller includes the CPU Rack and EtherCAT slaves (including general-purpose slaves and Servo Drives).
	In the NJ-series System, the Controller includes the CPU Rack, Expansion Racks, and EtherCAT slaves (including general-purpose slaves and Servo Drives).
Controller error	Errors that are defined by the NJ/NX-series System. "Controller error" is a collective term for major fault level, partial fault level, minor fault level, and observation Controller events.
Controller event	One of the events in the NJ/NX-series System. Controller events are errors and information that are defined by the system for user notification. A Controller event occurs when the system detects a factor that is defined as a Controller event.
Controller information	Information that is defined by the NJ/NX-series System that is not an error. It represents an information Controller event.
CPU Unit	The Unit that serves as the center of control for a Machine Automation Controller. The CPU Unit executes tasks, refreshes I/O for other Units and slaves, etc. The NJ/NX-series CPU Units include the NX701-□□□□, NX1P2-□□□□, NJ501-□□□□ and NJ301-□□□□.

Term	Description
derivative data type	A data type that is defined by the user. Structures, unions, and enumerations are
	derivative data types.
device	A general term for any Unit or slave that is refreshed by the I/O refreshing that is performed by the CPU Unit. Specifically, it refers to EtherCAT slaves, NX Units on the CPU Unit, built-in I/O, Option Boards, and CJ-series Units.
device output	An output for any Unit or slave that is refreshed by the I/O refreshing that is performed by the CPU Unit.
device variable	A variable that is used to access a specific device through an I/O port.
download	To transfer data from the Sysmac Studio to the Controller with the synchronization operation of the Sysmac Studio.
edge	One of the attributes of a variable. This attribute makes a BOOL variable pass TRUE to a function block when the variable changes from FALSE to TRUE or when it changes from TRUE to FALSE.
enumeration	One of the derivative data types. This data type takes one item from a prepared name list of enumerators as its value.
enumerator	One of the values that an enumeration can take expressed as a character string. The value of an enumeration is one of the enumerators.
EtherCAT Master Function Module	One of the function modules. This function module controls the EtherCAT slaves as the EtherCAT master.
EtherNet/IP Function Module	One of the function modules. This function module controls the built-in EtherNet/IP port.
event log	A function that recognizes and records errors and other events.
Event Setup	Settings that define user-defined errors and user-defined information.
event task	A task that executes a user program only once when the task execution conditions are met.
FB	An acronym for "function block."
forced refreshing	Forcing the refreshing of an input from an external device or an output to an external device, e.g., when the user debugs a program. Addresses that are subject to forced refreshing can still be overwritten from the user program.
FUN	An abbreviation for "function."
function	A POU that is used to create an object that determines a unique output for the same input, such as for data processing.
function block	A POU that is used to create an object that can have a different output for the same input, such as for a timer or counter.
function module	One of the functional units of the software configuration of the CPU Unit.
general-purpose slave	Any of the EtherCAT slaves that cannot be assigned to an axis.
global variable	A variable that can be read or written from all POUs (programs, functions, and function blocks).
I/O map settings	Settings that assign variables to I/O ports. Assignment information between I/O ports and variables.
I/O port	A logical interface that is used by the CPU Unit to exchange data with an external device (slave or Unit).
I/O refreshing	Cyclic data exchange with external devices that is performed with predetermined memory addresses.
information	One of the event levels for Controller events or user-defined events. These are not errors, but appear in the event log to notify the user of specific information.
Initial Value	One of the attributes of a variable. The variable is set to the initial value in the following situations.
	When power is turned ON When the CRILLInit changes to BLIN mode.
	When the CPU Unit changes to RUN mode When you specify to initialize the values when the user program is transferred.
	 When you specify to initialize the values when the user program is transferred When a major fault level Controller error occurs
inline ST	ST programming that is included within a ladder diagram program.
instruction	The smallest unit of the processing elements that are provided by OMRON for use in POU algorithms. There are ladder diagram instructions (program inputs and outputs), function instructions, function block instructions, and ST statements.


Term	Description		
literal	A constant expression that is used in a user program.		
local variable	A variable that can be accessed only from inside the POU in which it is defined. "Local variable" is used as opposed to "global variable." Local variables include internal variables, input variables, output variables, in-out variables, and external variables.		
main memory	The memory inside the CPU Unit that is used by the CPU Unit to execute the OS and user program.		
major fault level Controller error	An error for which all NJ/NX-series Controller control operations stop. The CPU Unit immediately stops user program execution and turns OFF the loads for all slaves and Units (including remote I/O).		
MC Test Run	A function to check motor operation and wiring from the Sysmac Studio.		
memory used for CJ-series Units	A type of I/O memory specified as the assignment destination of variables when accessing a CJ-series Unit and CJ-series network. It can be accessed only with variables with an AT attribute.		
minor fault level Controller error	An error for which part of the control operations for one of the function modules in the NJ/NX-series Controller stop. An NJ/NX-series CPU Unit continues operation even after a minor fault level Controller error occurs.		
Motion Control Function Module	One of the function modules. The MC Function Module performs motion control based on commands from the motion control instructions that are executed in the user program.		
motion control instruction	A function block instruction that executes motion control. The Motion Control Function Module supports instructions that are based on function blocks for PLCopen [®] motion control as well as instructions developed specifically for the Motion Control Function Module.		
namespace	A system that is used to group and nest the names of functions, function block definitions, and data types.		
Network Publish	One of the attributes of a variable. This attribute allows you to use CIP message communications or tag data links to read/write variables from another Controller or from a host computer.		
NX bus	The NX-series internal bus. An NX1P2 CPU Unit has the NX bus.		
NX Units	Any of the NX-series Units that perform I/O processing with connected external devices. The Communications Coupler Units are not included with the NX Units.		
observation	One of the event levels for Controller events or user-defined events. These are minor errors that do not affect control operations, but appear in the event log to notify the user of specific information.		
partial fault level Controller error	An error for which all of the control operations for one of the function modules in the NJ/NX-series Controller stop. An NJ/NX-series CPU Unit continues operation even after a partial fault level Controller error.		
PDO communications	An abbreviation for process data communications. Data is exchanged between the master and slaves on a process data communications cycle. (The process data communications cycle is the same as the task period of the primary periodic task.)		
periodic task	A task for which user program execution and I/O refreshing are performed each period.		
PLC Function Module	One of the function modules. This function module executes the user program, sends commands to the Motion Control Function Module, and provides an interface to the USB and SD Memory Card.		
POU	An acronym for "program organization unit." A POU is a unit in a program execution model that is defined in IEC 61131-3. A POU contains an algorithm and a local variable table and forms the basic unit used to build a user program. There are three types of POUs: programs, functions, and function blocks.		
primary periodic task	The task with the highest priority.		
process data communications	One type of EtherCAT communications in which process data objects (PDOs) are used to exchange information cyclically and in realtime. Process data communications are also called PDO communications.		

Term	Description
program	Along with functions and function blocks, one of the three types of POUs.
Daniel Consideration	Programs are assigned to tasks to execute them.
Range Specification	One of the variable specifications. You can specify a range for a variable in advance. The variable can take only values that are in the specified range.
Retain	One of the attributes of a variable. The values of variables with a Retain attribute
	are held at the following times. (Variables without a Retain attribute are set to their initial values.)
	When power is turned ON after a power interruption
	When the CPU Unit changes to RUN mode
	When you specify to not initialize the values when the user program is transferred
SDO communications	One type of EtherCAT communications in which service data objects (SDOs) are used to transmit information whenever required.
Servo Drive/encoder input slave	Any of the EtherCAT slaves that is assigned to an axis. In the NJ/NX-series System, it would be a Servo Drive or Encoder Input Slave Unit.
slave	A device that performs remote I/O for a master.
slave and Unit configurations	A generic term for the EtherCAT configuration and Unit configuration.
Slave Terminal	A building-block remote I/O terminal to which a Communications Coupler Unit and
	NX Units are mounted. A Slave Terminal is one type of slave.
Special Unit Setup	A generic term for the settings for a Special Unit, including the settings in allocated DM Area words.
structure	One of the derivative data types. It consists of multiple data types placed together
synchronization	into a layered structure. A function that automatically compares the information in the NJ/NX-series Control-
Synchronization	ler with the information in the Sysmac Studio, displays any differences and locations in a hierarchical form, and can be used to synchronize the information.
Sysmac Studio	A computer software application for setting, programming, debugging, and trouble- shooting NJ/NX-series Controllers. It also provides operations for motion control
	and a Simulator.
system common processing	System processing that is performed by the CPU Unit to perform I/O refreshing and
	the user program execution within a task. Exclusive control of variables between tasks, data trace processing, and other processing is performed.
system service	Processing that is performed by the CPU Unit in unused time between task pro-
•	cessing. The system service includes communications processing, SD Memory Card access processing, self-diagnosis processing, and other processing.
system-defined variable	A variable for which all attributes are defined by the system and cannot be changed by the user.
task	An attribute that defines when a program is executed.
task period	The interval at which the primary periodic task or a periodic task is executed.
union	One of the derivative data types. It allows you to handle the same data as different data types.
Unit	A device that mounts to the CPU Rack or an Expansion Rack. In NJ/NX-series manuals, it refers to CJ-series Units.
Unit configuration	The configuration information for the Units that are set on the Sysmac Studio. This information tells what Unit models are connected to the CPU Unit and where they are connected.
upload	To transfer data from the Controller to the Sysmac Studio with the synchronization operation of the Sysmac Studio.
user program	All of the programs in one project.
user-defined event	One of the events in the NJ/NX-series System. These events are defined by the user. "User-defined events" is a generic term for user-defined errors and user-defined information.
user-defined variable	A variable for which all of the attributes are defined by the user and can be changed by the user.
variable	A representation of data, such as a numeric value or character string, that is used in a user program. You can change the value of a variable by assigned the required value. "Variable" is used as opposed to "constant," for which the value does not change.

Term	Description
variable memory	A memory area that contains the present values of variables that do not have AT
	specifications. It can be accessed only with variables without an AT attribute.

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content
01	July 2011	Original production
02	March 2012	Added information on the NJ301-□□□□.
		Added information on the functions supported by unit version 1.01 of the CPU Units.
		Corrected mistakes.
03	May 2012	Added information on the functions supported by unit ver-
03	Way 2012	sion 1.02 of the CPU Units.
		Corrected mistakes.
04	August 2012	 Added information on the functions supported by unit version 1.03 of the CPU Units.
		Corrected mistakes.
05	February 2013	 Added information on the functions supported by unit version 1.04 of the CPU Units.
		Corrected mistakes.
06	April 2013	 Added information on the functions supported by unit version 1.05 of the CPU Units.
		Added information on the NX Series.
		Corrected mistakes.
07	June 2013	Added information on the functions supported by unit ver-
		sion 1.06 of the CPU Units.
		Corrected mistakes.
08	September 2013	 Added information on the functions supported by unit version 1.07 of the CPU Units.
		Corrected mistakes.
09	December 2013	 Added information on the functions supported by unit version 1.08 of the CPU Units.
		Corrected mistakes.
10	July 2014	Corrected mistakes.
11	January 2015	 Added information on the functions supported by unit version 1.10 of the CPU Units.
		Corrected mistakes.
12	April 2015	Added information on the NX701-□□□□ and NJ101-□□□□.
		Corrected mistakes.
13	October 2015	Added information on the hardware revision.
		Corrected mistakes.
14	April 2016	 Added information on the functions supported by unit version 1.11 of the CPU Units.
		Corrected mistakes.
15	July 2016	 Added information on the functions supported by unit version 1.12 of the CPU Units.
16	October 2016	Added information on the NX1P2-□□□□□.
		Added information on the functions supported by unit version 1.13 of the CPU Units.
17	January 2017	Corrected mistakes.
	•	,

Revision code	Date	Revised content
18	April 2017	Added information on the functions supported by unit version 1.14 of the CPU Units.
		Corrected mistakes.
19	June 2017	Corrected mistakes.
20	June 2017	Added information on the functions supported by unit version 1.15 of the CPU Units.
21	October 2017	Added information on the functions supported by unit version 1.16 of the CPU Units.
		Corrected mistakes.
22	January 2018	Added information on the functions supported by unit version 1.17 of the CPU Units.
23	April 2018	Added information on the functions supported by unit version 1.18 of the CPU Units.
		Corrected mistakes.
24	April 2018	Added information on the NX102-□□□.
		Added information on the functions supported by unit version 1.30 of the CPU Units.
		Made changes accompanying the transfer of explanation for event codes and errors to the NJ/NX-series Troubleshooting Manual.
25	July 2018	Added information on the hardware revision.
		Added information on the functions supported by unit version 1.19 of the NJ-series CPU Units.
		Added information on the functions supported by unit version 1.31 of the NX102-□□□□.
		Corrected mistakes.
26	January 2019	Added information on the functions supported by unit version 1.20 of the NJ-series CPU Units.
		Corrected mistakes.



Introduction to NJ/NX-series Controllers

This section describes the features, basic system configuration, specifications, and overall operating procedure of an NJ/NX-series Controller.

1-1	The N	J/NX-series Controllers
	1-1-1	Features
	1-1-2	Introduction to the System Configurations
1-2	Main S	Specifications
1-3	Overa	II Operating Procedure for the NJ/NX-series Controller 1-16
	1-3-1	Overall Procedure
	1-3-2	Procedure Details


1-1 The NJ/NX-series Controllers

The SYSMAC NJ/NX-series Controllers are next-generation machine automation controllers that provide the functionality and high-speed performance that are required for machine control.

They provide the safety, reliability, and maintainability that are required of industrial controllers.

The NJ/NX-series Controllers provide the functionality of previous OMRON PLCs, and they also provide the functionality that is required for motion control. Synchronized control of I/O devices on high-speed EtherCAT can be applied to safety devices, vision systems, motion equipment, discrete I/O, and more.

OMRON offers the new Sysmac Series of control devices designed with unified communications specifications and user interface specifications. The NJ/NX-series Machine Automation Controllers are part of the Sysmac Series. You can use them together with EtherCAT slaves, other Sysmac products, and the Sysmac Studio Automation Software to achieve optimum functionality and ease of operation. With a system that is created from Sysmac products, you can connect components and operate the system through unified concepts and usability.



1-1-1 Features

Hardware Features

Standard-feature EtherCAT Control Network Support

All CPU Units provide an EtherCAT master port for EtherCAT communications. EtherCAT is an advanced industrial network system that achieves faster, more-efficient communications. It is based on Ethernet. Each node achieves a short fixed communications cycle time by transmitting Ethernet frames at high speed. The standard-feature EtherCAT control network allows you to connect all of the devices required for machine control (e.g., I/O systems, Servo Drives, Inverters, and machine vision) to the same network.

Support for EtherCAT Slave Terminals

You can use EtherCAT Slave Terminals to save space. You can also flexibly build systems with the wide variety of NX Units.

Achieving a Safety Subsystem

You can use NX-series Safety Control Units to integrate safety controls in a sequence and motion control system.



Version Information

A CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher are required to use the NX-series Safety Control Units.

NX Units (Only for the NX102 and NX1P2)

The NX102 CPU Units and NX1P2 CPU Units allow you to mount NX-series Digital I/O Units, Analog I/O Units and other Units to the CPU Unit, in addition to EtherCAT network slaves.



Precautions for Correct Use

You cannot mount NX-series Safety Control Units on the NX1P2 CPU Units. You cannot
mount NX-series Safety Control Units on the CPU Unit and use them. Use NX-series Safety
Control Units as a subsystem on EtherCAT.

CJ-series Units (Only for the NJ□01)

NJ-series CPU Units allow you to mount CJ-series Basic I/O Units and Special Units on the I/O bus, in addition to EtherCAT network slaves.

Standard-feature EtherNet/IP Communications Port

All CPU Units provide an EtherNet/IP port for EtherNet/IP communications. EtherNet/IP is a multi-vendor industrial network that uses Ethernet. You can use it for networks between Controllers or as a field network. The use of standard Ethernet technology allows you to connect to many different types of general-purpose Ethernet devices.

Standard-feature USB Port (Only for the NX701 and NJ□01)

You can connect a computer that runs the Support Software directly to the CPU Unit with a USB connection.



Precautions for Correct Use

The NX102 CPU Units and NX1P2 CPU Units do not provide a USB port.

Standard-feature SD Memory Card Slot

You can access an SD Memory Card that is mounted in the CPU Unit from the user program.

Highly Reliable Hardware

The NJ/NX-series Controllers provide the hardware reliability and RAS functions that you expect of a PLC

Parallel Execution of Tasks with a Multi-core Processor (NX701, NX102, and NX1P2)

The NX701- $\square\square\square\square$ CPU Unit has a multi-core processor that can execute more than one task in parallel. This enables high-speed control of even large-scale devices including an improvement of communications performance for large capacity data.

The NX102- $\square\square\square\square$ CPU Unit and NX1P2- $\square\square\square\square\square$ CPU Unit have a multi-core processor that can execute the tasks, tag data link service, and system services in parallel. This secures communications performance with the Sysmac Studio, an HMI, or other devices.

Software Features

Integrated Sequence Control and Motion Control

An NJ/NX-series CPU Unit can perform both sequence control and motion control. You can simultaneously achieve both sequence control and multi-axes synchronized control. Sequence control, motion control, and I/O refreshing are all executed in the same control period. The same control period is also used for the process data communications cycle for EtherCAT. This enables precise sequence and motion control in a fixed period with very little deviation.

Multitasking

You assign I/O refreshing and programs to tasks and then specify execution conditions and execution order for them to flexibly combine controls that suit the application.

Programming Languages Based on the IEC 61131-3 International Standard

The NJ/NX-series Controllers support language specifications that are based on IEC 61131-3. To these, OMRON has added our own improvements. Motion control instructions that are based on PLCopen® standards and an instruction set (POUs) that follows IEC rules are provided.

Programming with Variables to Eliminate Worrying about the Memory Map

You access all data through variables in the same way as for the advanced programming languages that are used on computers. Memory in the CPU Unit is automatically assigned to the variables that you create so that you do not have to remember the physical addresses.

A Wealth of Security Features

The many security features of the NJ/NX-series Controllers include operation authority settings and restriction of program execution with IDs.

Complete Controller Monitoring

The CPU Unit monitors events in all parts of the Controller, including mounted Units and EtherCAT slaves. Troubleshooting information for errors is displayed on the Sysmac Studio or on an NS-series PT. Events are also recorded in logs.

Sysmac Studio Automation Software

The Sysmac Studio provides an integrated development environment that covers not only the Controller, but also covers peripheral devices and devices on EtherCAT. You can use consistent procedures for all devices regardless of the differences in the devices. The Sysmac Studio supports all phases of Controller application, from designing through debugging, simulations, commissioning, and changes during operation.

A Wealth of Simulation Features

The many simulation features include execution, debugging, and task execution time estimates on a virtual controller.

1-1-2 Introduction to the System Configurations

This section describes the system configurations of the NX-series and NJ-series Controllers.

Introduction to the System Configurations of the NX701 CPU Units

The NX701 CPU Unit supports the following system configurations.

Basic System Configurations

The NX701 basic configurations include the EtherCAT network configuration and the Support Software.

• EtherCAT Network Configuration


You can use the built-in EtherCAT port to connect to EtherCAT Slave Terminals, to general-purpose slaves for analog and digital I/O, and to Servo Drives and encoder input slaves. An EtherCAT network configuration enables precise sequence and motion control in a fixed cycle with very little deviation.

· Support Software

The Support Software is connected to the peripheral USB port on the CPU Unit with a commercially available USB cable. You can also connect it through an Ethernet cable that is connected to the built-in EtherNet/IP port.

Refer to 10-2 Connection with Sysmac Studio for details on the connection configuration of the Support Software.

Support Software





Precautions for Correct Use

NX Units should be connected to Slave Terminals. The NX bus connector of the CPU Unit is provided for future expansion so that it cannot be used to connect any NX Unit.




Additional Information

You can connect the Sysmac Studio directly to the Communications Coupler Unit to set up the Slave Terminal. Refer to the *NX-series EtherCAT Coupler Units User's Manual* (Cat. No. W519) for details.

Network Configurations

- Host computers, HMIs, and other NJ/NX-series Controllers are connected to the built-in Ether-Net/IP port.
- An NX701 CPU Unit has two EtherNet/IP ports.



Refer to Section 10 Communications Setup for details on the network configuration.

Support Software

You can use the following Support Software to set up, monitor, and debug an NX701 CPU Unit.

· Sysmac Studio

The Sysmac Studio is the main Support Software that you use for an NX701 CPU Unit. On it, you can set up the Controller configurations, parameters, and programs, and you can debug and simulate operation.

· Other Support Software

The following Support Software is also included in the Sysmac Studio Software Package Standard Edition.

Configuration software	Application
Sysmac Studio	The Sysmac Studio is used for sequence control, motion control, and all other operations except those described below.
Network Configurator	The Network Configurator is used for tag data links on EtherNet/IP ports.*1

If the NJ/NX-series Controller is a target device, you may also use Sysmac Studio version 1.10 or higher. Use the Network Configurator if a CS/CJ-series PLC operates as the originator device.

Introduction to the System Configurations of the NX102 CPU Units

The NX102 CPU Unit supports the following system configurations.

Basic System Configurations

The NX102 basic configurations include the EtherCAT network configuration, NX Unit configuration, and the Support Software.

• EtherCAT Network Configuration

You can use the built-in EtherCAT port to connect to EtherCAT Slave Terminals, to general-purpose slaves for analog and digital I/O, and to Servo Drives and encoder input slaves. An EtherCAT network configuration enables precise sequence and motion control in a fixed cycle with very little deviation.


· NX Unit Configuration

In addition to the EtherCAT network, you can mount NX-series Digital I/O Units, Analog I/O Units and other Units.

· Support Software

You can connect the Support Software through an Ethernet cable that is connected to the built-in EtherNet/IP port.

Refer to 10-2 Connection with Sysmac Studio on page 10-7 for details on the connection configuration of the Support Software.



d

Precautions for Correct Use

An NX102 CPU Unit does not provide a USB port.




Additional Information

You can connect the Sysmac Studio directly to the Communications Coupler Unit to set up the Slave Terminal. Refer to the *NX-series EtherCAT Coupler Units User's Manual* (Cat. No. W519) for details.

Network Configurations

- Host computers, HMIs, and other NJ/NX-series Controllers are connected to the built-in Ether-Net/IP port.
- An NX102 CPU Unit has two built-in EtherNet/IP ports.



Refer to Section 10 Communications Setup for details on the network configuration.

Support Software

You can use the following Support Software to set up, monitor, and debug an NX102 CPU Unit.

· Sysmac Studio

The Sysmac Studio is the main Support Software that you use for an NX102 CPU Unit. On it, you can set up the Controller configurations, parameters, and programs, and you can debug and simulate operation.

• Other Support Software

The following Support Software is also included in the Sysmac Studio Software Package Standard Edition.

Configuration software	Application
Sysmac Studio	The Sysmac Studio is used for sequence control, motion control, and all other operations except those described below.
Network Configurator	The Network Configurator is used for tag data links on EtherNet/IP ports.*1

If the NJ/NX-series Controller is a target device, you may also use Sysmac Studio version 1.10 or higher. Use the Network Configurator if a CS/CJ-series PLC operates as the originator device.

Introduction to the System Configurations of the NX1P2 CPU Units

The NX1P2 CPU Unit supports the following system configurations.

Basic System Configurations

The NX1P2 basic configurations include the EtherCAT network configuration, NX Unit configuration, and the Support Software.

EtherCAT Network Configuration

You can use the built-in EtherCAT port to connect to EtherCAT Slave Terminals, to general-purpose slaves for analog and digital I/O, and to Servo Drives and encoder input slaves. An EtherCAT network configuration enables precise sequence and motion control in a fixed cycle with very little deviation.


· NX Unit Configuration

In addition to the EtherCAT network, you can mount NX-series Digital I/O Units, Analog I/O Units and other Units.

Support Software

You can connect the Support Software through an Ethernet cable that is connected to the built-in EtherNet/IP port.

Refer to 10-2 Connection with Sysmac Studio for details on the connection configuration of the Support Software.





Precautions for Correct Use

An NX1P2 CPU Unit does not provide a USB port.




Additional Information

You can connect the Sysmac Studio directly to the Communications Coupler Unit to set up the Slave Terminal. Refer to the NX-series EtherCAT Coupler Units User's Manual (Cat. No. W519) for details.

Network Configurations

· Host computers, HMIs, and other NJ/NX-series Controllers are connected to the built-in Ether-Net/IP port.



Refer to Section 10 Communications Setup for details on the network configuration.

Support Software

You can use the following Support Software to set up, monitor, and debug an NX1P2 CPU Unit.

· Sysmac Studio

The Sysmac Studio is the main Support Software that you use for an NX1P2 CPU Unit. On it, you can set up the Controller configurations, parameters, and programs, and you can debug and simulate operation.

· Other Support Software

The following Support Software is also included in the Sysmac Studio Software Package Standard Edition.

Configuration software Application					
Sysmac Studio	The Sysmac Studio is used for sequence control, motion control, and all other operations except those described below.				
Network Configurator	The Network Configurator is used for tag data links on EtherNet/IP ports.*1				

If the NJ/NX-series Controller is a target device, you may also use Sysmac Studio version 1.10 or higher. Use the Network Configurator if a CS/CJ-series PLC operates as the originator device.

Introduction to the System Configurations of the NJ-series Controllers

The NJ Series supports the following system configurations.

Basic System Configurations

The NJ-series basic configurations include the EtherCAT network configuration, CJ-series Unit configuration, and the Support Software.

EtherCAT Network Configuration

You can use the built-in EtherCAT port to connect to EtherCAT Slave Terminals, to general-purpose slaves for analog and digital I/O, and to Servo Drives and encoder input slaves. An EtherCAT network configuration enables precise sequence and motion control in a fixed cycle with very little deviation.


CJ-series Unit Configuration

In addition to the EtherCAT network, you can mount CJ-series Basic I/O Units and Special Units. CJ-series Units can be mounted both to the CPU Rack where the CPU Unit is mounted and to Expansion Racks.

Support Software

The Support Software is connected to the peripheral USB port on the CPU Unit with a commercially available USB cable. You can also connect it through an Ethernet cable that is connected to the built-in EtherNet/IP port.

Refer to 10-2 Connection with Sysmac Studio for details on the connection configuration of the Support Software.






Additional Information

You can connect the Sysmac Studio directly to the Communications Coupler Unit to set up the Slave Terminal. Refer to the *NX-series EtherCAT Coupler Units User's Manual* (Cat. No. W519) for details.

Network Configurations

- Host computers, HMIs, and other NJ-series Controllers are connected to the built-in EtherNet/IP port or to a CJ1W-EIP21 EtherNet/IP Unit.
- A DeviceNet network is connected to a DeviceNet Unit. A CompoNet network is connected to a CompNet Unit. A serial communications network is connected to a Serial Communications Unit.



Refer to Section 10 Communications Setup for details on the network configuration.

Support Software

You can use the following Support Software to set up, monitor, and debug an NJ-series Controller.

· Sysmac Studio

The Sysmac Studio is the main Support Software that you use for an NJ-series Controller. On it, you can set up the Controller configurations, parameters, and programs, and you can debug and simulate operation.

· Other Support Software

The following Support Software is also included in the Sysmac Studio Software Package Standard Edition.

Configuration software	Application
Sysmac Studio	The Sysmac Studio is used for sequence control, motion control, and all other operations except those described below.
Network Configurator	The Network Configurator is used for tag data links on EtherNet/IP ports or Units.*1
CX-Integrator	The CX-Integrator is used for remote I/O communications with a DeviceNet Unit or CompoNet Master Unit.
CX-Protocol	The CX-Protocol is used for protocol macros with Serial Communications Units.
CX-Designer	The CX-Designer is used to create screens for NS-series PTs.

^{*1} If the NJ/NX-series Controller is a target device, you may also use Sysmac Studio version 1.10 or higher. Use the Network Configurator if a CS/CJ-series PLC operates as the originator device.

1-2 Main Specifications

This section gives the main specifications of the NJ/NX-series Controllers. Refer to *A-1 Specifications* for general specifications, performance specifications, and function specifications.

Item		NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-		
		Size		80 MB	5 MB	1.5 MB	20 MB	5 MB	3 MB
	Program capacity*1	Oversity	Number of POU definitions	6,000	3,000	450	3,000	750	450
	сарасну	Quantity	Number of POU Instances	48,000	9,000	1,800	9,000 (*)	3,000 (*)	1,800
		Retain attri-	Size	4 MB	1.5 MB	32 KB* ³	2 MB	0.5 MB	
	Memory capacity for	butes*2	Number of variables	40,000	10,000	5,000	10,000	5,000 (*)	
	variables	No Retain	Size	256 MB	32 MB	2 MB	4 MB	2 MB	
Program-		attributes*4	Number of variables	360,000	90,000	90,000	180,000 (*)	90,000 (*)	22,500
ming	Data types	Number of da	ta types	8,000	1,000	1,000	2,000	1,000	
		CIO Area			6,144 words (CI 6143)* ⁵	O 0 to CIO	6,144 words (0	CIO 0 to CIO 6	143)
		Work Area			512 words (W0	to W511)* ⁵	512 words (W	512 words (W0 to W511)	
	Memory for	Holding Area			1,536 words (H0	0 to H1535)* ⁶	1,536 words (H	H0 to H1535)	
	CJ-series Units (Can be specified with AT specifica- tions for vari- ables.)	n be with DM Area			32,768 words (D0 to D32767)	16,0000 words (D0 to D15999)*6	32,768 words (D0 to D32767)		7)
		EM Area			32,768 words × 25 banks (E0_00000 to E18_32767)*6 *7		32,768 words × 25 banks (E0_00000 to E18_32767)	32,768 word (E0_00000 t	s × 4 banks o E3_32767)
Motion co	ntrol			Refer to Perforn	nance Specification	ons of Motion Con	trol for Each Typ	e of CPU Unit	s on page A-9.
	Supported serv	rices		Sysmac Stu- dio connection			Sysmac Studio connection		
Periph- eral USB port	Physical layer			USB 2.0-com- pliant B-type connector			USB 2.0-comp	oliant B-type co	onnector
	Transmission distance			5 m max.			5 m max.		
	Number of port	s		2	2	1			
	Physical layer			10BASE- T/100BASE- TX/ 1000BASE-T					
	Frame length			1,514 bytes max.					
Built-in	Media access n	nethod		CSMA/CD					
Ether- Net/IP	Modulation			Baseband					
port	Topology	Topology		Star					
	Baud rate			1 Gbps (100BASE-TX) (1000BASE-T)					
	Transmission n	nedia		STP (shielded, t	wisted-pair) cable	e of Ethernet cate	gory 5, 5e or hig	her	
	Maximum trans Ethernet switch		ce between	100 m					
	Maximum number of cascade connections			There are no restrictions if an Ethernet switch is used.					

ltem			NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-	
		Maximum number of con- nections	256 per port 512 total	32 per port 64 total	32				
		Packet interval*8	Can be set for each connection. 0.5 to 10,000	Can be set for each connection. 1 to 10,000 ms	Can be set for each connection. 2 to 10,000 ms	-	Can be set for each connection. 1 to 10,000 ms in 1.0-ms increments (*)		
			ms in 0.5-ms increments 40,000 pps*9	in 1-ms increments 12,000 pps*9	in 1.0-ms increments	luding boorthoo	+\ /*\		
		Permissible communications band	(including heartbeat)	(including heartbeat, CIP Safety routing)		3,000 pps* ⁹ (including heartbeat) (*)			
		Maximum number of tag sets	256 per port 512 total	32 per port 40*10 total	32				
Built-in	CIP service:	Tag types	Network vari- ables	Network variable Holding and DM		Network varial DM, and EM A	oles, CIO, Wor treas	k, Holding,	
Ether- Net/IP	Tag data links	Number of tags per connection (i.e., per tag set)	, ,	roller status is inc	luded in the tag s	et.)			
port	munications)	Maximum number of tags	256 per port 512 total	T	256				
		Maximum link data size per node (total size for all tags)	369,664 bytes	19,200 bytes					
		Maximum data size per connection	1,444 bytes	600 bytes	l aa //				
		Maximum number of registrable tag sets	256 per port 512 total (1 connection = 1 tag set)	32 per port 40*10 total (1 connection = 1 tag set)	32 (1 connection = 1 tag set)				
		Maximum tag set size	1,444 bytes (Two bytes are used if Con- troller status is included in the		o bytes are used if Controller status is included in the tag s			the tag set.)	
		Multi-cast packet filter*11	tag set.) Supported						
	Communication	ns standard	IEC 61158 Type						
		EtherCAT master specifications		e Pack Motion Co	ntrol compliant)				
	Physical layer Modulation		100BASE-TX Baseband						
Built-in	Baud rate		100 Mbps (100BASE-TX)						
Ether-	Duplex mode		Auto Line, daisy chain, and branching						
CAT port	Transmission media				or higher (double-s	shielded straight	t cable with alu	minum tape	
	Maximum trans	smission distance between	100 m						
	Maximum numl	ber of slaves	512	64	16	192		64	
	Communications method Synchronization method				Half duplex (when con- nected to the Serial Commu- nications Option Board)				
Serial commu- nications					Start-stop syn- chronization (when con- nected to the Serial Commu- nications Option Board)				
	Baud rate				1.2/2.4/4.8/9.6/ 19.2/38.4/57.6/ 115.2 kbps (when con- nected to the Serial Commu- nications Option Board)				

ltem			NX701-	NX102- □□□□	NX1P2-	NJ501-	NJ301-	NJ101-		
		Maximum number of CJ Units per CPU Rack or Expansion Rack					10			
	Maximum number of connectable Units	umber of Units per CPU Rack			32	8				
		Maximum number of CJ Units for entire controller					40			
		Maximum number of NX Units for entire controller		4,096	432	24	4,096		400	
Unit con-	Maximum number of Expansion Racks		0			3				
figura- tion	I/O capacity	Maximum num points on CJ-s					2,560			
	Power Supply Unit for CPU Rack and Expansion	Model		NX-PA9001 NX-PD7001	A non-isolated p DC input is built Unit.	oower supply for into the CPU	NJ-P□3001			
		cpansion Power OFF detection time	AC power supply	30 to 45 ms			30 to 45 ms			
	Racks		DC power supply	5 to 20 ms	2 to 8 ms	2 to 8 ms	22 to 25 ms			
	Maximum NV D	M : NVP 1/0 1 / :			Input: 8,192 bytes					
Maximum NX Bus I/O data size				Output: 8,192 bytes						

^{*1} Execution objects and variable tables (including variable names)

Note Items that are marked with asterisks in the table are improvements that were made during version upgrades. Refer to *A-15 Version Information for NX-series Controllers* and *A-16 Version Information for NJ-series Controllers* for information on version upgrades.

^{*2} Does not include Holding, DM, and EM Area memory for CJ-series Units.

^{*3} Memory for CJ-series Units is included.

^{*4} Does not include CIO and Work Area memory for CJ-series Units.

^{*5} Variables without a Retain attribute are used. The value can be set in 1-word increments.

^{*6} Variables with a Retain attribute are used. The value can be set in 1-word increments.

^{*7} For the NX102 CPU Unit, creating all banks simultaneously at the maximum number of words is not possible, because the capacity of the retain variable memory is limited to 1.5 MB.

^{*8} Data will be refreshed at the set interval, regardless of the number of nodes.

^{*9 &}quot;pps" means packets per second, i.e., the number of communications packets that can be sent or received in one second.

^{*10} If more than 40 tag sets are registered in total, the Number of Tag Sets for Tag Data Links Exceeded (840E0000 hex) event will occur.

^{*11} As the EtherNet/IP port implements the IGMP client, unnecessary multi-cast packets can be filtered by using an Ethernet switch that supports IGMP Snooping.

1-3 **Overall Operating Procedure for the NJ/NX-series Controller**

This section gives the overall operating procedure of the NJ/NX-series Controllers and then describes it in more detail.

1-3-1 **Overall Procedure**

The overall procedure to use an NJ/NX-series Controller is given below.

Step 1. Software Design

Design the overall system configuration, task configuration, programs, and variables.

Step 1-1 Designing I/O and Processing

Step 1-2 Designing Tasks

Step 1-3 Designing Programs



Step 2. Software Setups and Programming

Create the system configurations that you designed in step 1 on the Support Software and assign the variables. Create the tasks and programs, and debug them, e.g., with simulations.

Step 2-1 Slave and Unit Configurations

Step 2-2 Controller Setup

Step 2-3 Programming

Step 2-4 Offline Debugging



Step 3. Mounting and Setting Hardware

Mount the Units and make the required hardware settings.



Step 4. Wiring

Connect the network cables and wire the I/O.



Step 5. Checking Operation and Starting Actual Operation on the Actual System

Connect the Support Software to the physical system and download the project. Check operation on the physical system and then start actual system operation.

1-3-2 Procedure Details

Step 1. Software Design		
Step	Description	Reference
Step 1-1 Designing I/O and Processing	 External I/O devices and Unit configuration Refresh periods for external devices Program contents 	NX-series CPU Unit Hard- ware User's Manual (Cat. No. W535)
G		NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593) NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
		NJ-series CPU Unit Hard- ware User's Manual (Cat. No. W500)



Step 1-2 Designing Tasks	 Task configuration Relationship between tasks and programs Task periods Slave and Unit refresh times Exclusive control methods for variables between tasks 	4-2-3 Task Settings
-----------------------------	--	---------------------



Step 1-3 Designing Pro- grams		
POU (Program Organization Unit) Design	ProgramsFunctions and function blocksDetermining the algorithm languages	Section 6 Programming
Variable Design	 Defining variables that you can use in more than one POU and variables that you use in only specific POUs Defining the variables names for the device variables that you use to access slaves and Units Defining the attributes of variables, such as the Name and Retain attributes Designing the data types of variables 	6-3 Variables



Step 2. Software Setups and Programming			
Step	Description	Sysmac Studio Operations	Reference
Project Creation	 Create a project in the Sysmac Studio. Insert a Controller. 	New Project Button Insert – Controller	Sysmac Studio Version 1 Operation Manual (Cat. No. W504)



The following Controller Configurations and Setup and the Programming and Task Settings can be performed in either order.

Step 2-1 Slave and Unit Configurations			
Creating the Slave and Unit Configurations	 Creating the slave configuration and Unit configuration either offline or online. (For online configuration, make the online connection that is described in step 5.) Setting up any Slave Terminals that are used. 	EtherCAT Slave Set- ting Editor Unit Editor	3-2-1 Creating the EtherCAT Slave Configuration 3-2-2 Creating the Unit Con- figuration NX-series EtherCAT Cou- pler Unit User's Manual (Cat. No. W519)



, ,	Registering device variables in variable tables (Variable names are user defined or automatically created.)	І/О Мар	3-3 I/O Ports and Device Variables
	· · · · · · · · · · · · · · · · · · ·		



(The following step is for motion control.)

3) Creating the Axes and Assigning Them to the Servo Drive/Encoder Input Slaves	Creating the axes and setting them as real axes or virtual axes. Creating axes groups to perform interpolated axes control.	Configurations and Setup – Motion Con- trol Setup	3-5 Creating the Axes and Assigning Them to the Servo Drives/Encoder Input Slaves/NX Units
---	---	---	---



Step 2-2 Controller Setup	Setting the following parameters from the Sysmac Studio		Section 4 Controller Setup
	Setting the initial values for the PLC Function Module	Configurations and Setup – Controller Setup – Operation Settings	4-2 Initial Settings for the PLC Function Module
	 (For NX1P2 CPU Units) Setting the clock data with clock function when a Battery is mounted Initial settings for the NX Bus Function Module Initial settings for NX Units Initial settings for built-in I/O Initial settings for Option Boards Memory settings for CJ-series Units 	Each setting is given below. Controller – Controller Clock Configurations and Setup – CPU Rack Configurations and Setup – Built-in I/O Settings Configurations and Setup – Option Board Settings Configurations and Setup – Memory Settings for CJseries Units	8-1-2 Clock 4-2-4 Unit Configuration and Unit Setup for NX102 CPU Units and NX1P2 CPU Units 4-3 Initial Settings for NX Units NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual (Cat. No. W579)
	(For NJ-series CPU Units) Initial settings for Special Units	Configurations and Setup – CPU/Expan- sion Racks	4-4 Initial Settings for Spe- cial Units
	(To use motion control) Setting the initial settings for the Motion Control Function Module	Configurations and Setup – Motion Con- trol Setup	4-5 Initial Settings for the Motion Control Function Module
	Setting the initial values for the Ether-CAT Function Module	Configurations and Setup – EtherCAT	4-6 Initial Settings for the EtherCAT Master Function Module
	Setting the initial values for the Ether- Net/IP Function Module	Configurations and Setup – Controller Setup – Built-in Ether- Net/IP Port Settings	4-7 Initial Settings for the EtherNet/IP Function Mod- ule



Step 2-3 Programming			
1) Registering Variables	 Registering the variables used by more than one POU in the global variable table with Sysmac Studio Registering the local variable table for each program Registering the local variable table for each function block and function 	Global Variable Table Editor Local Variable Table Editor	Sysmac Studio Version 1 Operation Manual (Cat. No. W504) 6-3 Variables
2) Writing Algorithms for POUs	Writing the algorithms for the POUs (programs, function blocks, and functions) in the required languages	Programming Editor	Section 6 Programming NJ/NX-series Instructions Reference Manual (Cat. No. W502) and NJ/NX-series Motion Control Instructions Reference Manual (Cat. No. W508)
3) Setting the Tasks	Making task settings	Configurations and Setup – Task Settings	4-2-3 Task Settings
•			
Step 2-4 Offline Debugging	Checking the algorithms and task execution times on the Simulator (virtual control-		Section 7 Checking Operation and Actual Operation



ler)

Step 3. Mounting and Setting Hardware			
Step	Description	Reference	
1. Mounting	Connecting adjacent Units Mounting to DIN Track	NX-series CPU Unit Hard- ware User's Manual (Cat. No. W535)	
		NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593) NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)	
		NJ-series CPU Unit Hard- ware User's Manual (Cat. No. W500)	
2. Setting Hard- ware	Setting the node addresses of the EtherCAT slaves Setting unit numbers on the rotary switches on the front of the Special Units	Operation manuals for the EtherCAT slaves and Spe- cial Units	



Step 4. Wiring		
Step	Description	Reference
1. Connecting Ethernet Cable	Connecting the built-in EtherCAT port Connecting the built-in EtherNet/IP port	NX-series CPU Unit Hard- ware User's Manual (Cat. No. W535)
		NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593) NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
		NJ-series CPU Unit Hard- ware User's Manual (Cat. No. W500)
2. Wiring I/O	Wiring I/O to EtherCAT slaves Wiring Basic I/O Units and Special Units	Operation manuals for the EtherCAT slaves
		NX-series CPU Unit Hard- ware User's Manual (Cat. No. W535)
		NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593) NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578) NJ-series CPU Unit Hard- ware User's Manual (Cat. No. W500)
	Checking wiring	Sysmac Studio Version 1 Operation Manual (Cat. No. W504)
3. Connecting the Computer That Runs the Sysmac Studio	Connecting USB Cable*1 Connecting the built-in EtherNet/IP port	Sysmac Studio Version 1 Operation Manual (Cat. No. W504)



Step 5. Checking Operation and Starting Operation on the Actual System

Step	Description	Sysmac Studio Operations	Reference
Online Connection to Sysmac Studio and Project Download	Turn ON the power supply to the Controller and place the Sysmac Studio online. Then, download the project.* (Perform this step before you create the slave configuration or Unit configuration from the mounted Units in step 2-1.)	Controller – Communications Setup Controller – Synchronization	Section 7 Checking Opera- tion and Actual Operation



^{*1} An NX1P2 CPU Unit does not provide a USB port.

2. Operation Check on Controller	 Check the wiring by using forced refreshing of real I/O from the I/O Map or Watch Tab Page. For motion control, use the MC Test Run operations in PROGRAM mode to check the wiring. Then check the motor rotation directions for jogging, travel distances for relative positioning (e.g., for electronic gear settings), and homing operation. Change the Controller to RUN mode and check the operation of the user program. 	Section 7 Checking Operation and Actual Operation
1		
3. Actual Controller Operation	Start actual operation.	

^{*} Use the Synchronize Menu of the Sysmac Studio to download the project.



CPU Unit Operation

This section provides information that is necessary to use the CPU Unit, including how the CPU Unit works and the operations that it performs depending on the status of the CPU Unit.

2-1	Overv	iew of CPU Unit Operation	2-2
	2-1-1	Introduction to CPU Unit	
	2-1-2	Overview of Operation According to CPU Unit Status	2-3
2-2	Softwa	are	2-4
	2-2-1	Software Configuration	
	2-2-2	Operation of Software	
2-3	Acces	ssing I/O	2-13
	2-3-1	Types of Variables	
	2-3-2	Accessing I/O with Variables	
2-4	I/O Re	freshing of NX Bus Function Module	
	2-4-1	I/O Refreshing Methods	
	2-4-2	I/O Refreshing Method Operation	
2-5	Seque	ence Control and Motion Control	2-29
	2-5-1	Overview of Control	
	2-5-2	Sequence Control System	
	2-5-3	Motion Control System	
	2-5-4	Synchronizing Sequence Control and Motion Control	2-35
2-6	Overv	iew of CPU Unit Data	2-36
2-7	Opera	tion for CPU Unit Status	2-37
	2-7-1	CPU Unit Status	2-37
	2-7-2	Operation for CPU Unit Status	
	2-7-3	Operating Modes	2-40

Overview of CPU Unit Operation 2-1


This section describes the operation of the CPU Unit and gives an overview of how it operates depending on the status of the CPU Unit.

2-1-1 Introduction to CPU Unit

The NJ/NX-series CPU Unit executes the user program for sequence control and motion control. It also performs other processing, such as I/O refreshing and external communications. These processes are performed by the software in the CPU Unit.

The CPU Unit also contains settings, the user program, variables, and other data. The CPU Unit uses this data to perform processing. Of this data, variables are used to access the CPU Unit and I/O, and for external communications.

The internal software and the use of variables for I/O access enable the CPU Unit to execute both sequence control and motion control.



Note You can use CJ-series Units only with NJ-series CPU Units.

Note You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units. You can use the built-in I/Os and Analog I/O Option Boards only with the NX1P2 CPU Units.

This section describes the following items to provide you with a basic understanding of how the CPU Unit performs sequence control and motion control.

Item	Reference
Software	P.2-4
Accessing I/O	P.2-13
Sequence control and motion control	P.2-29
Overview of CPU Unit data	P.2-36
Operation for CPU Unit status	P.2-37



Additional Information

Refer to the following manuals for details on the use of variables for external communications.

Communications	Manual
EtherNet/IP	For information on using variables with the built-in EtherNet/IP port, refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual (Cat. No. W506).
	• For information on using variables with an EtherNet/IP Unit, refer to the CJ-series EtherNet/IP Units Operation Manual for NJ-series CPU Unit (Cat. No. W495).
Serial communica- tions	CJ-series Serial Communications Units Operation Manual for NJ-series CPU Unit (Cat. No. W494)

2-1-2 Overview of Operation According to CPU Unit Status

The status of the CPU Unit changes when an error occurs or when you change the operating mode. Changes in the status of the CPU Unit affect user program execution, I/O refreshing, and the processing of external communications.

The CPU Unit operation according to the status of the CPU Unit is described in 2-7 Operation for CPU Unit Status.

2-2 **Software**

This section describes the software configuration of the CPU Unit, and how the software components operate.

Software Configuration 2-2-1

The software in the CPU Unit is divided into five modules. These functional units are called function modules.

The function modules and the processing that they perform are described in the following table.

Function module name	Processing	
PLC Function Module	Performs the following services: task scheduling, commands for other function modules, event logging, execution of the user program, I/O refreshing*1 for the CJ-series Units, USB port services*2, SD Memory Card services, and data trace processing.	
NX Bus Function Module*3	Performs processing such as event logging and I/O refreshing for the NX Units that are connected to the NX bus of the CPU Unit.	
Motion Control Function Module	Performs motion control processing.*4	
EtherCAT Master Function Module	Performs communications with EtherCAT slaves as the EtherCAT master, including I/O refreshing*5 for the EtherCAT slaves, EtherCAT message communications*6, etc.	
EtherNet/IP Function Module	Performs processing for EtherNet/IP communications, including tag data link processing, built-in EtherNet/IP port servicing, etc.	

^{*1} Some CJ-series Units can also be connected to an NJ-series CPU Unit.

^{*2} The NX102 CPU Units and NX1P2 CPU Units do not provide a USB port.

^{*3} Only the NX102 CPU Units and NX1P2 CPU Units have the NX Bus Function Module.

^{*4} This function module executes motion processing based on target values (such as the position or velocity target value) from the motion control instructions. It outputs command values, controls status, and obtains information through the EtherCAT Master Function Module.

^{*5} I/O refreshing for EtherCAT slaves is performed by using process data communications (also called PDO communications). In PDO communications, the master and slaves exchange data cyclically at regular intervals.

^{*6} This module communicates with the EtherCAT slaves as the EtherCAT master.

2-2-2 Operation of Software

The software in the CPU Unit performs the following four processes. Which process is performed depends on the status of the CPU Unit and the execution conditions of the process itself.

Type of CPU Unit processing	Status of CPU Unit	Execution conditions	Processing example
Initialization	Startup state	Initialization is performed only when the power supply is turned ON.	Self diagnosis at startup
Processing executed with tasks	Normal operation and error states	The processing is executed within the assigned task. These tasks are executed either periodically or only once when the specified condition is met.	User program execution and I/O refreshing
Tag data link service		These services are performed only	Tag data links
Option board service*1		upon requests from the hardware or other external devices.	I/O refreshing for Analog I/O Option Boards
System services			USB port service*2, SD Memory Card service, and communications process- ing for Serial Communica- tions Option Boards*3

^{*1} The option board service is executed only by an NX1P2 CPU Unit.

Refer to 2-7-1 CPU Unit Status for information on the CPU Unit status.

This section describes the operation of the processes.

Initialization

Initialization is performed only when the power supply is turned ON.

The following processing is performed for initialization.

Processing	Description
Self diagnosis at startup	Operation is monitored for the following errors: Power Supply Error, CPU Unit Reset, CPU Unit Watchdog Timer Error, and Incorrect Power Supply Unit Connected.*1
Data check	The _RetainFail (Retention Failure Flag) system-defined variable changes to TRUE at the following time: when the values of variables for which the Retain attribute was set to retain the values and the values in DM, EM, and HR Areas in the memory used for CJ-series Units*2 were not retained after a power interruption.
Detecting NX Units*3	The NX Units mounted in the Controller are detected.
Detecting CJ-series Units*4	The CJ-series Units mounted in the Controller are detected.
Recording Power Turned ON and Power Interrupted events	The Power Turned ON and Power Interrupted events are recorded.

^{*1} Refer to *Types of Fatal Errors* in the *NJ/NX- series Troubleshooting Manual* (Cat. No. W503) for information on the following errors: Power Supply Error, CPU Unit Reset, CPU Unit Watchdog Timer Error, and Incorrect Power Supply Unit Connected.

^{*2} The NX102 CPU Units and NX1P2 CPU Units do not provide a USB port.

^{*3} Only the NX1P2 CPU Units support Serial Communications Option Boards.

^{*2} You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

^{*3} You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

*4 You can use CJ-series Units only with NJ-series CPU Units.

Processing Executed with Tasks

Types of Processing That Are Executed with Tasks

The following processing is performed with tasks.

Processing	Description
I/O refreshing	Data I/O for EtherCAT slaves, NX Units on the CPU Unit*1, I/O built in the CPU Unit*2, Analog I/O Option Boards in the CPU Unit*3, CJ-series*4 Basic I/O Units, and CJ-series Special Units is performed.
User program execution	The user programming for sequence control is executed. It also sends commands to the motion control process.
Motion control	Motion control is executed based on commands from the user program.
System common processing	System common processing, such as data trace processing and tag data link processing, is performed.

^{*1} You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

Refer to 5-3-3 Basic Operation of Tasks for NX701 CPU Units, 5-4-3 Basic Operation of Tasks for NX102 CPU Units and NX1P2 CPU Units, and 5-5-3 Basic Operation of Tasks for NJ-series Controllers for details on the processing that is executed with tasks.

Task Operation

Processing is assigned to tasks. There are three kinds of tasks, as shown in the following table. They are defined by their execution priorities and execution conditions.

Type of peri- odic task	Execution priority (smaller values indicate higher priority)	Execution condition	Main processing content
Primary periodic task	This task has the highest execution priority.	The primary periodic task is periodically executed.	I/O refreshing, user program execution, and motion control
Periodic tasks	5*1 This task has the next highest execution priority after the primary periodic task.	The periodic task is periodically executed. The task period is an integer multiple of the task period of the primary periodic task.	I/O refreshing, user program execution, and motion control
	16 ^{*2} , 17, or 18	The periodic task is periodically executed. The task period is an integer multiple of the task period of the primary periodic task.	The processing that can be performed depends on the task execution priority. Execution priority 16: I/O refreshing and user program execution Execution priority 17 or 18: User program execution
Event tasks	8 or 48	An event task is executed only once when the specified condition is met.	User program execution

^{*1} You can use the priority-5 periodic task only with the NX701 CPU Units.


^{*2} You can use the built-in I/O only with the NX1P2 CPU Units.

^{*3} You can use Analog I/O Option Boards only with the NX1P2 CPU Units.

^{*4} You can use CJ-series Units only with NJ-series CPU Units.

^{*2} You cannot use the priority-16 periodic task with the NX102 CPU Unit or NX1P2 CPU Unit.


The CPU Unit executes the task with the highest execution priority first. The following operation example is for the primary periodic task and a periodic task. If the primary periodic task is ready for execution while a periodic task is in execution, execution of the primary periodic task is prioritized.



The operation of tasks with lower priority when a task with higher priority is in execution differs between the NX701 CPU Units, NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units. Refer to 5-2 Overview of Tasks for details on task operation.

Operation of Processing with Tasks

Processing that is assigned to a task is executed within the task in the order shown in the following diagram. If the program contains a motion control instruction, the execution process for the program in the task will send a command to the motion control process. The motion control process is executed based on commands.



Note The CPU Unit executes motion control in the primary periodic task and in the priority-5 periodic task. Refer to 5-11-3 System Input and Output Response Times for details.



Additional Information

With an NX701 CPU Unit, you can execute motion control in the primary periodic task and in the priority-5 periodic task. If these two motion controls need to be identified, the motion control in the primary periodic task is called motion control 1, while the motion control in the priority-5 periodic task is called motion control 2.

Tag Data Link Service

Processing Performed by the Tag Data Link Service


The tag data link service processes communications that use tags with other controllers or devices on an EtherNet/IP network. You can use the built-in EtherNet/IP port in the CPU Unit or a CJ-series CJ1W-EIP21 EtherNet/IP Unit to connect to an HMI.

Note You can use the CJ1W-EIP21 EtherNet/IP Unit only with NJ-series CPU Units.

Operation of the Tag Data Link Service

The tag data link service is executed periodically. The period and the time that is required for each execution depend on the model of the CPU Unit and on the tag data link settings.

The execution priority of the tag data link service for an NJ-series CPU Unit is between the execution priorities of the priority-16 periodic task and the priority-17 periodic task. Therefore, the tag data link service will be given priority over execution of the priority-17 periodic task, but if the primary periodic task or the priority-16 periodic task is executed, the execution of the primary periodic task or the priority-16 periodic task is prioritized.



The tag data link service is executed with a priority that is between the execution priorities of the priority-16 periodic task and the priority-17 periodic task.

The tag data link service for an NX-series CPU Unit is executed in parallel with the execution of tasks.

For details on the tag data link service, refer to 5-6 Services Other Than Tasks.

Option Board Service


Processing Performed by the Option Board Service

The option board service processes the I/O refreshing for an Analog I/O Option Board that is mounted on the NX1P2 CPU Unit.

Note The option board service is executed only by an NX1P2 CPU Unit.

Operation of the Option Board Service

The option board service for an NX1P2 CPU Unit is executed in parallel with the execution of tasks. However, during execution of the tag data link service, the option board service is not executed.



The option board service is executed in parallel with the execution of tasks.

Refer to 5-6 Services Other Than Tasks for details on the option board service.

Communications Bridge Service

Processing Performed by the Communications Bridge Service


The communications bridge service performs processing to relay CIP Safety communications between CIP Safety on EtherNet/IP devices and the NX-SL5□□□ Safety CPU Unit that is mounted to the NX102 CPU Unit.

Refer to the NX-series Safety Control Unit User's Manual (Cat. No. Z930-E1-12 or later) for information on the CIP Safety communications.

Note The communications bridge service is executed by an NX102 CPU Unit with unit version 1.31 or later.

Operation of the Communications Bridge Service

The communications bridge service for an NX102 CPU Unit is executed in parallel with the execution of tasks. The tag data link service is not executed during execution of the communications bridge service.



The communications bridge service is executed in parallel with the execution of tasks.

Refer to 5-6 Services Other Than Tasks for details on the communications bridge service.

System Services

System Services

System services include the following processing.

Processing	Contents
USB port service*1	Processing of service requests from the Sysmac Studio or host computers
Built-in EtherNet/IP port service	 Processing of message service requests, such as CIP commands, from the Sysmac Studio, an HMI, host computers, or other Controllers Execution of communications instructions for CIP and socket communications
Built-in EtherCAT port service	Execution of EtherCAT message communications
Communications processing for a Serial Communications Option Board*2	Execution of communications processing for a Serial Communications Option Board
CJ-series Special Unit service	Event servicing for CJ-series Special Units
*3	Execution of communications instructions (CIP)
SD Memory Card service	Access from FTP client
	SD Memory Card operations from the Sysmac Studio
	Execution of SD Memory Card instructions
Self-diagnosis	Hardware error detection

^{*1} The NX102 CPU Units and NX1P2 CPU Units do not provide a USB port.

System Service Operations

For the NX701 CPU Units, if a request comes from the hardware or from outside of the CPU Unit, system services are executed in parallel with other processes. System services are executed at the required time without being affected by the execution of tasks.

For the NX102 CPU Units, if a request comes from the hardware or from outside of the CPU Unit, system services are executed in parallel with other processes. System services are executed at the required time without being affected by the execution of tasks. However, during execution of the tag data link service, system services are not executed.


For the NX1P2 CPU Units, if a request comes from the hardware or from outside of the CPU Unit, system services are executed in parallel with other processes. System services are executed at the required time without being affected by the execution of tasks. However, during execution of the tag data link service or option board service, system services are not executed.

^{*2} The communications processing for a Serial Communications Option Board is executed only by an NX1P2 CPU Unit.

^{*3} The CPU Unit exchanges data between CJ-series Special Units and the memory words that are allocated to them during I/O refreshing. You can use CJ-series Special Units only with NJ-series CPU Units.

For NJ-series CPU Units, if a request comes from the hardware or from outside of the CPU Unit, system services are executed during the unused time between the execution of all tasks.

the execution of all tasks.



Refer to 5-6 Services Other Than Tasks for details on the system services.

2-3 Accessing I/O

The CPU Unit uses variables to access I/O. This section describes how variables are used to access I/O.

In this manual, I/O on EtherCAT slaves, NX Units on the CPU Unit, built-in I/O, Analog I/O Option Boards, and CJ-series Units are treated as I/O. Refer to the *NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual* (Cat. No. W506) for details on how to access data in other Controllers with tag data links.

2-3-1 Types of Variables

In an NJ/NX-series CPU Unit, you use variables in the user program to access I/O and memory in the CPU Unit.

The type of a variable depends on whether it has attributes that are set by the user, and what it can access

Variables		Attribute set- tings	Accessed data	
User-defined variables		All attributes can be set.	CPU Unit	
Semi-user-defined variables	Device variables	Device variables for EtherCAT slaves	Some attributes can be set.*1	EtherCAT slaves*2*3
		Device variables for NX Units*4		NX Units on the CPU Unit
		Device variables for built-in I/O*5		Built-in I/O
		Device variables for Option Boards*5		Analog I/O Option Boards
		Device variables for CJ-series Units*6		CJ-series Basic I/O Units and CJ-series Special Units
	Cam data variable	es		Servo Drives, encoder input slaves, and CPU Unit
System-defined variables	System-defined variables for PLC Function Module		No attributes can be set.	CPU Unit
	System-defined variables for motion control	MC Common Variable		Servo Drives, encoder input slaves, and CPU Unit
		Axis Variables		
		Axes Group Variables		
System-defined varia		rariables for Ether-		Built-in EtherNet/IP port
	System-defined v CAT master System-defined v bus* ⁷			Built-in EtherCAT master port
				CPU Unit

^{*1} Refer to Device Variable Attributes on page 3-12 for the attributes that can be set.

^{*2 &}quot;EtherCAT slaves" includes any NX Units on EtherCAT Slave Terminals.

- *3 With the Sysmac Studio version 1.08 or lower, the EtherCAT slaves to which axes are assigned cannot be accessed via EtherCAT slave device variables.
- *4 You can use system-defined variables for NX Units only with the NX102 CPU Units and NX1P2 CPU Units.
- *5 You can use device variables for built-in I/Os and Option Boards only with the NX1P2 CPU Units.
- *6 You can use CJ-series Units only with NJ-series CPU Units.
- *7 You can use system-defined variables for NX bus only with the NX102 CPU Units and NX1P2 CPU Units.

User-defined Variables

The user defines all of the attributes of a user-defined variable. Refer to 6-3 Variables for details on user-defined variables.

Semi-user-defined Variables

Semi-user-defined variables have some attributes that you can set. These variables are used to access specific data. A semi-user-defined variable can either be a device variable or a cam data variable, depending on what it can access.

Device Variables

Device variables are used to access data in devices. A device is a general term for any Unit or slave that is refreshed by the I/O refreshing that is performed by the CPU Unit. Specifically, it refers to EtherCAT slaves, NX Units on the CPU Unit, built-in I/O, Analog I/O Option Boards, and CJ-series

The device and the data to access in that device determine the type of device variable, as shown below.

Type of device variable	Device	Accessed data
Device variables for EtherCAT slaves	EtherCAT slaves*1	Process data for EtherCAT slaves*2
Device variables for NX Units*3	NX Units on the CPU Unit	I/O data for NX Units
Device variables for built-in I/O*4	Built-in I/O	I/O data for built-in I/O
Device variables for Option Boards*4	Analog I/O Option Boards	I/O data for Analog I/O Option Boards
Device variables for CJ-series	CJ-series Basic I/O Units	Real I/O data in Basic I/O Units
Units ^{*5}	CJ-series Special Units	Operating data ^{*6} and setup data for Special Units ^{*7}

^{*1} With the Sysmac Studio version 1.08 or lower, the EtherCAT slaves to which axes are assigned cannot be accessed via EtherCAT slave device variables.

^{*2} This refers to I/O data that is exchanged during the process data communications cycle between the master and slaves.

^{*3} You can use system-defined variables for NX Units only with the NX102 CPU Units and NX1P2 CPU Units.


^{*4} You can use device variables for built-in I/Os and Option Boards only with the NX1P2 CPU Units.

^{*5} You can use CJ-series Units only with NJ-series CPU Units.

^{*6} This data is used in the operation of CJ-series Units. The CIO Area portion of the memory used for CJseries Units is used.

^{*7} This data is used to set up the CJ-series Units. The DM Area portion of the memory used for CJ-series Units is used.

Device variables are used to access data for EtherCAT slaves, NX Units on the CPU Unit, built-in I/O, Analog I/O Option Boards, and CJ-series Units through the I/O ports. The I/O ports are logical ports that are used to access devices.



Refer to 3-3-1 I/O Ports for details on I/O ports and device variables.

Cam Data Variables

Cam data variables are used to access data in cam tables, which are used for motion control. For details, refer to the *NJ/NX-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

System-defined Variables

System-defined variables are defined in advance in an NJ/NX-series Controller. The names and all attributes are defined by the system. They have specific functions. You cannot change the variable names or any other attributes.

The system-defined variables are specific to a function module. There are system-defined variables for each function module. The types of system-defined variables are listed in the following table.

Function module	Type of system-defined variable
PLC Function Module	System-defined variables for PLC Function Module
NX Bus Function Module*1	System-defined variables for NX bus
Motion Control Function Module	System-defined variables for motion control
EtherNet/IP Function Module	System-defined variables for EtherNet/IP
EtherCAT Master Function Module	System-defined variables for EtherCAT master

^{*1} Only the NX102 CPU Units and NX1P2 CPU Units have the NX Bus Function Module.

The system-defined variables for motion control are classified according to what the Motion Control Function Module does, as listed in the following table.

System-defined variables for motion control	Description
MC Common Variable	Common processing for the entire Motion Control Function Module
Axis variables	Control of individual axes
Axes Group variables	Control of axes groups*1

^{*1} An axes group consists of multiple axes. An axes group is used for interpolation.

Refer to A-6 System-defined Variables for details on system-defined variables.


Accessing I/O with Variables 2-3-2

In the CPU Unit, variables are used in the user program. Variables access the data of the assigned I/O. The following table shows how I/O and variables are assigned in the CPU Unit. The type of variable that is used by a CJ-series Special Unit depends on the data to access.

I/O		Data	Variables
EtherCAT slaves	EtherCAT slaves to which axes are not assigned		Device variables for EtherCAT slaves
	EtherCAT slaves to which axes are assigned		Device variables for EtherCAT slaves*1 Axis variables
NX Units on the CPU Unit*2	NX Units to which axes are not assigned		Device variables for NX Units
	NX Units to which axes are assigned		Device variables for NX Units Axis variables
Built-in I/O*3			Device variables for built-in I/O
Analog I/O Option	Boards ^{*4}		Device variables for Option Boards
CJ-series Units*5	Basic I/O Units		Device variables for CJ-series Units
	Special Units	Operating data Setup data	Device variables for CJ-series Units
		Assigned memory area data*6	User-defined variables

^{*1} With the Sysmac Studio version 1.08 or lower, the EtherCAT slaves to which axes are assigned cannot be accessed via EtherCAT slave device variables.

- *2 You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.
- *3 You can use the built-in I/O only with the NX1P2 CPU Units.
- *4 You can use Analog I/O Option Boards only with the NX1P2 CPU Units.
- *5 You can use CJ-series Units only with NJ-series CPU Units.
- *6 This data is for extended functions and slave I/O that you assign by specifying addresses in memory. You cannot access assigned memory area data with device variables.



Accessing EtherCAT Slaves

The method that is used to access an EtherCAT slave depends on the type of EtherCAT slave.


Type of EtherCAT slave	Access method
 Servo Drive and encoder input slaves*1 General-purpose slaves 	These slaves are accessed through I/O ports by using device variables for EtherCAT slaves.
Servo Drive and encoder input slaves that are assigned to axes	These slaves are accessed directly with Axis variables.*2

- *1 With the Sysmac Studio version 1.08 or lower, the EtherCAT slaves to which axes are assigned cannot be accessed via EtherCAT slave device variables.
- *2 For a Servo Drive, one Servomotor is assigned as one axis to one Axis variable. For an encoder input slave, one counter is assigned as one axis to one Axis variable.

Note EtherCAT slaves that cannot be assigned to axes are called general-purpose slaves. EtherCAT slaves that can be assigned to axes are called Servo Drive and encoder input slaves. Refer to the *NJ/NX-series CPU Unit Motion Control User's Manual* (Cat. No. W507) for details on Servo Drive and encoder input slaves.

Accessing Servo Drive, Encoder Input, and General-purpose Slaves That Are Not Assigned to Axes


These slaves are accessed through I/O ports for device variables for EtherCAT slaves. PDO communications are used to access data from I/O ports.



Accessing Servo Drive and Encoder Input Slaves That Are Assigned to Axes

Servo Drive and encode input slaves that are assigned to axes are accessed directly through the Axis variable. PDO communications are used to access data from Axis variables.

For example, if a Servomotor is controlled with a Servo Drive, the control commands for the Servomotor that is assigned to an Axis variable are sent to the Servo Drive. The feedback from the Servomotor is sent from the Servo Drive to the CPU Unit by using the Axis variable.



Refer to 3-5-2 Axis Variables and Axes Group Variables for details on Axis variables.



Version Information

With the Sysmac Studio version 1.09 or higher, device variables can be assigned to the I/O ports of Servo Drive and encoder input slaves to which axes are assigned.

The I/O port to which a device variable can be assigned must meet either of the following conditions.

- The value of the R/W attribute is R (Read only).
- The value of the R/W attribute is W (Write only), and <Not assigned> is set for the process data field under **Detailed Settings** on the Axis Basic Settings Display in the Sysmac Studio.



Precautions for Correct Use

If you perform the following steps, the system will clear the assignment of the device variable to the I/O port of a Servo Drive and encoder input slave to which an axis is assigned.

- (1) With the Sysmac Studio version 1.09 or higher, assign device variables to the I/O ports of Servo Drive and encoder input slaves to which axes are assigned.
- (2) Save the project data.
- (3) Open the saved project data with the Sysmac Studio version 1.08 or lower.



Additional Information

There are two types of EtherCAT communications, PDO communications and SDO communications. PDO communications are used for commands to refresh I/O data, such as data for Servomotor position control, on a fixed control period. SDO communications are used for commands to read and write data at specified times, such as for parameter transfers.

Refer to the NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual (Cat. No. W505) for details.

Accessing NX Units on the CPU Unit


The method that is used to access an NX Unit on the NX102 CPU Unit and NX1P2 CPU Unit depends on the type of NX Unit.

Type of NX Unit on the CPU Unit*1	Access method
NX Units that are not assigned to axes	These Units are accessed through I/O ports by using device variables for NX Units.
NX Units that are assigned to axes	These Units are accessed directly with axis variables.
	These Units are accessed through I/O ports by using device variables for NX Units.

^{*1} You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.


Accessing NX Units That Are Not Assigned to Axes

These Units are accessed through I/O ports for device variables for NX Units.



Accessing NX Units That Are Assigned to Axes

NX Units that are assigned to axes are accessed directly through the Axis variable. You can also assign the device variables to the I/O ports of NX Units that are assigned to axes.



Refer to 3-5-2 Axis Variables and Axes Group Variables for details on Axis variables.




Precautions for Correct Use

The I/O port to which a device variable can be assigned in the NX Unit that is assigned to an axis must meet either of the following conditions.

- The value of the R/W attribute is R (Read only).
- The value of the R/W attribute is W (Write only), and <Not assigned> is set for the process data field under **Detailed Settings** on the Axis Basic Settings Display in the Sysmac Studio.

Accessing Built-in I/O


You access I/O that is built in an NX1P2 CPU Unit through the I/O ports for device variables for built-in I/O.



Refer to 3-3-1 I/O Ports for details.

Accessing Analog I/O Option Boards


You access Analog I/O Option Boards in an NX1P2 CPU Unit through the I/O ports for device variables for Option Boards.



Refer to 3-3-1 I/O Ports for details.

Accessing Basic I/O Units

With an NJ-series CPU Unit, you access Basic I/O Units through the I/O ports for device variables for the CJ-series Unit.



Refer to 3-3-1 I/O Ports for details.


Accessing Special Units

With an NJ-series CPU Unit, there are two methods that you can use to access Special I/O Units. Which method is used depends on the data to access.

Access method	Data
Accessing Special Units through I/O ports by using device variables for CJ-series Units	 Operating data Setup data
Accessing Special Units by using user-defined variables with AT specifications	Assigned memory area data

Accessing Special Units through I/O ports by Using Device Variables for CJseries Units


The operating data and setup data are accessed through the I/O ports for the device variables for the CJ-series Unit. The data is exchanged during I/O refreshing.



Refer to 3-3-1 I/O Ports for details.

Accessing Special Units by Using User-defined Variables with AT **Specifications**

The assigned memory area addresses are accessed by using AT specifications for user-defined variables to the memory addresses that are used for the CJ-series Units. The data in the memory used for CJ-series Units is exchanged with the data in the CJ-series Units during I/O refreshing.



The assigned memory addresses including the following addresses.

- · Addresses in fixed allocations for DeviceNet Units
- · Addresses in user-specified allocations for DeviceNet Units or CompoNet Master Units from the CX-Integrator (A CompoNet Master Unit must be set to communications mode 8 to use the CX-Integrator.)
- · Addresses in expansion memory for High-speed Counter Units
- · Addresses in expansion memory for Process I/O Units

Refer to A-9 Contents of Memory Used for CJ-series Units for information on the memory used for CJ-series Units. Refer to 6-3-8 Variable Attributes for information on AT specifications.

2-4 I/O Refreshing of NX Bus Function Module

This section describes I/O refreshing of the NX Bus Function Module for the NX102 CPU Units and NX1P2 CPU Units.

The NX Bus Function Module of the NX102 CPU Unit and NX1P2 CPU Unit performs the data exchange cyclically with the NX Units on the CPU Unit.

The data exchange is executed by I/O refreshing in the primary periodic task. Therefore, the period of I/O refreshing is the task period of the primary periodic task.



Precautions for Correct Use

Only the NX102 CPU Units and NX1P2 CPU Units have the NX Bus Function Module.

2-4-1 I/O Refreshing Methods

The I/O refreshing methods of NX Units that are mounted on the NX1P2 CPU Unit are listed below.

I/O refreshing method for NX Units	Actual operation
NX Units that support both Free-Run refreshing and synchronous	Operates with synchronous I/O refreshing.
I/O refreshing	
NX Units that support Free-Run refreshing, synchronous I/O	
refreshing, and task period prioritized refreshing	
NX Units that support only time stamp refreshing	Operates with time stamp refreshing.
NX Units that support only Free-Run refreshing	Operates with Free-Run refreshing.

Note NX Units with different I/O refreshing methods can be mixed on the NX102 CPU Unit and NX1P2 CPU Unit.

Note You cannot change the I/O refreshing methods for NX Units on the NX102 CPU Unit or NX1P2 CPU Unit.

An outline of the I/O refreshing methods that are actually operated in the NX102 CPU Unit and NX1P2 CPU Unit is listed below.

I/O refreshing method	Outline
Synchronous I/O refreshing	With this I/O refreshing method, the timing to read inputs or to refresh
	outputs is synchronized on a fixed interval between more than one NX Units.
Time stamp refreshing	With this I/O refreshing method, the NX Units record the DC times ^{*1} when inputs change or perform outputs at specified DC times. Data exchange between the NX Units and CPU Unit are performed cyclically on the NX bus refresh cycles.
Input refreshing with input	With this I/O refreshing method, the Input Units record the DC times when
changed times	the inputs change.
Output refreshing with	With this I/O refreshing method, the Output Units change outputs at specified
specified time stamps	DC times.
Free-Run refreshing	With this I/O refreshing method, the refresh cycle of the NX bus and the I/O refresh cycles of the NX Units are asynchronous.

^{*1} The slaves or Units that support distributed clock synchronization have a clock that is shared by the slaves or Units. The time that is based on this distributed clock is called the DC time.

The I/O refreshing methods that you can use depend on the model of the NX Unit. Select the NX Units according to the I/O refreshing method to use.

Refer to the manuals for the specific Units for the I/O refreshing methods that are supported by individual NX Units.

2-4-2 I/O Refreshing Method Operation

This section describes the operation of each I/O refreshing method in the NX102 CPU Unit and NX1P2 CPU Unit.

The detailed operation of the I/O refreshing methods depends on the NX Units. Refer to the manuals for the NX Units.

Operation of Synchronous I/O Refreshing

All NX Units that support synchronous I/O refreshing on the NX102 CPU Unit and NX1P2 CPU Unit read their inputs at the same time that is synchronized with the I/O refreshing in the primary periodic task. Outputs are also refreshed simultaneously, but at a separately set timing from inputs.




Precautions for Correct Use

The NX Units on the CPU Unit, EtherCAT slaves, and EtherCAT Slave Terminals do not read inputs or refresh outputs simultaneously.

Operation Example of Synchronous I/O Refreshing

All NX Units that support synchronous I/O refreshing read their inputs at the same time.

All NX Units that support synchronous I/O refreshing refresh their outputs at the same time.



Operation of Time Stamp Refreshing

The following describes the operation of time stamp refreshing.

Operation of Input Refreshing with Input Changed Times

All NX Units that support input refreshing with input changed times on the NX102 CPU Unit and NX1P2 CPU Unit record the DC times when inputs change (called input changed times). Then, the input changed times are read at the time that is synchronized with the I/O refreshing in the primary periodic task. The most recent values are always read as the input values.



Additional Information

The timing when the input changed times are read is the same as that for reading the inputs for NX Units that support synchronous input refreshing.


Operation of Output Refreshing with Specified Time Stamps

All NX Units that support output refreshing with specified time stamps on the NX102 CPU Unit and NX1P2 CPU Unit change the outputs at the specified DC times for each NX Unit.

Operation Example of Time Stamp Refreshing

All NX Units that support input refreshing with input changed times record the DC times when inputs change for each NX Unit and read the input changed times at the same time.

All NX Units that support output refreshing with specified time stamps change the outputs at the specified DC times for each NX Unit.




Operation of Free-Run Refreshing

With Free-Run refreshing, the refresh cycle of the NX bus and the I/O refresh cycle of the NX Units operate asynchronously.

Operation Example of Free-Run Refreshing

An example of operation for Free-Run refreshing method in the NX102 CPU Unit and NX1P2 CPU Unit is provided in the following figure.

The NX Units that support Free-Run refreshing perform I/O processing based on their own unique timings that is asynchronous with the I/O refreshing in the primary periodic task.



2-5 Sequence Control and Motion Control


This section describes the sequence control and motion control systems that are used by the CPU Unit.

2-5-1 Overview of Control

The NJ/NX-series CPU Unit can perform both sequence control and motion control.

You execute sequence control with instructions other than motion control instructions in the user program. Sequence control is for EtherCAT slaves, NX Units on the CPU Unit, built-in I/O, Option Boards, and CJ-series Units that are not assigned to axes. Control is performed by the PLC Function Module, NX Bus Function Module, and the EtherCAT Master Function Module.

You perform motion control with motion control instructions in the user program for EtherCAT Servo Drive and encoder input slaves that are assigned to axes. Control is performed by the PLC Function Module, Motion Control Function Module, NX Bus Function Module, and the EtherCAT Master Function Module.



Note You can use CJ-series Units only with NJ-series CPU Units.

Note You can use the NX Bus Function Module only with the NX102 CPU Units and NX1P2 CPU Units.

Note You can use the built-in I/Os and Option Boards only with the NX1P2 CPU Units.



Additional Information

Instruction Types in Terms of Control Systems

In terms of the controls, the instructions can be broadly separated into the following two types of instructions.

Definition
These instructions are executed in the user program in the PLC Function Module and processing for them is completed there.
These instructions are executed in the user program in the PLC Function Module to send commands to the Motion Control Function Module. MC_Home (Homing), MC_Move (Positioning), MC_CamIn (Start Cam Operation), and other instructions for motion control operations

For details on motion control instructions, refer to the NJ/NX-series Motion Control Instructions Reference Manual (Cat. No. W508). For details on other instructions, refer to the NJ/NX-series Instructions Reference Manual (Cat. No. W502).



Version Information

With the Sysmac Studio version 1.09 or higher, device variables can be assigned to the I/O ports of Servo Drive and encoder input slaves to which axes are assigned.

The I/O port to which a device variable can be assigned must meet either of the following conditions.

- The value of the R/W attribute is R (Read only).
- The value of the R/W attribute is W (Write only), and <Not assigned> is set for the process data field under **Detailed Settings** on the Axis Basic Settings Display in the Sysmac Studio.



Precautions for Correct Use

If you perform the following steps, the system will clear the assignment of the device variable to the I/O port of a Servo Drive and encoder input slave to which an axis is assigned.

- (1) With the Sysmac Studio version 1.09 or higher, assign device variables to the I/O ports of Servo Drive and encoder input slaves to which axes are assigned.
- (2) Save the project data.
- (3) Open the saved project data with the Sysmac Studio version 1.08 or lower.

2-5-2 Sequence Control System

The way that the sequence control works depends on the device to control. This section describes the operation of the function modules and the control period as part of the sequence control system.


Device	Sequence Control System			
Device	Operation of the function module	Control period		
Servo Drive, encoder input*1, and general-purpose slaves	 The PLC Function Module executes the user program and refreshes the device variables. The EtherCAT Master Function Module exchanges data with the slaves through the I/O ports for device variables. 	The task period of the task to which the program is assigned (i.e., the task period of the primary periodic task or a periodic task)*2		
NX Units on the CPU Unit that are not assigned to axes*3	 The PLC Function Module executes the user program and refreshes the device variables. The NX Bus Function Module exchanges data with the NX Units on the CPU Unit through the I/O ports for device variables. 	Primary periodic task*4		
Built-in I/O*5	The PLC Function Module executes the user program, refreshes the device variables, and exchanges data with the built-in I/O.	Primary periodic task		
Option Boards*6	The PLC Function Module executes the user program, refreshes the device variables, and exchanges data with the Option Boards.	Primary periodic task*7		
CJ-series Units*8	The PLC Function Module executes the user program, refreshes the device variables, and exchanges data with the CJ-series Units.	The task period of the task to which the program is assigned (i.e., the task period of the primary periodic task or a periodic task)*9		

- *1 With the Sysmac Studio version 1.09 or higher, a Servo Drive and encoder input slave to which an axis is assigned can also be a part of sequence controls if you assign the device variable to the I/O port of the slave.
- *2 The data refresh period in the slave depends on settings in the slave.
- *3 You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units. An NX Unit on the CPU Unit to which an axis is assigned can also be a part of sequence controls if you assign the device variable to the I/O port of the NX Unit.
- *4 The I/O refresh cycles of the NX Units that operate with Free-Run refreshing and the control period of the CPU Unit are asynchronous.
- *5 You can use the built-in I/O only with the NX1P2 CPU Units.
- *6 You can use Option Boards only with the NX1P2 CPU Units.
- *7 The primary periodic task and the data exchange period of Option Boards are asynchronous.
- *8 You can use CJ-series Units only with NJ-series CPU Units.
- *9 The data exchange period with a CJ-series Unit is the task period to which I/O refreshing for the CJ-series Unit is assigned.

Servo Drive, encoder input, and general-purpose slaves that are not assigned to axes are refreshed in the process data communications cycle. This means that I/O refreshing takes place in the task period of the primary periodic task or the priority-5 periodic task. However, execution of the programs and refreshing of the device variables take place in the task period of the task to which the programs are assigned. Therefore, the slave values are not reflected and not controlled by the device variables until the task period of the task to which the programs are assigned.

If it is necessary to control a slave in the process data communications cycle, assign the program that controls the slave to the primary periodic task or the priority-5 periodic task.

For details, refer to 5-11-3 System Input and Output Response Times.





Additional Information

- You can use the priority-5 periodic task only with the NX701 CPU Units.
- With an NX701 CPU Unit, you can perform process data communications in the primary periodic task and the priority-5 periodic task. If these two process data communications cycles need to be identified, the communications cycle for the primary periodic task is called process data communications cycle 1, while the communications cycle for the priority-5 periodic task is called process data communications cycle 2.
- The NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units perform process data communications only in the primary periodic task.
- You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.
- You can use the built-in I/Os and Option Boards only with the NX1P2 CPU Units.
- You can use CJ-series Units only with NJ-series CPU Units.

2-5-3 Motion Control System

This section describes the operation of the function modules and the control period as part of the motion control system.

Operation of Function Modules

- The PLC Function Module executes motion control instructions in the user program and sends commands for motion control to the Motion Control Function Module. Axis variables are used for these commands.
- The Motion Control Function Module performs motion control processing based on commands from the PLC Function Module. It then reflects the results of this processing in the Axis variables.
- The EtherCAT Master Function Module sends the command values of the Axis variable to the Servo Drive or other slave by using EtherCAT communications.
- The NX Bus Function Module outputs the command values of the Axis variable to the NX-series Pulse Output Unit or other Unit on the CPU Unit.

Control Period

The motion control period is the task period of the primary periodic task or the priority-5 periodic task.


Motion control processing in the Motion Control Function Module is executed in the task period of the primary periodic task or the priority-5 periodic task. The Motion Control Function Module also exchanges data with Servo Drive and encoder input slaves that are assigned to the axes to control in the process data communications cycle of the primary periodic task or the priority-5 periodic task. The process data communications cycle is synchronized with the primary periodic task or the priority-5 periodic task.

Furthermore, in the NX102 CPU Units and NX1P2 CPU Units, the Motion Control Function Module exchanges data with NX Units on the CPU Unit that are assigned to the axes to control in the primary periodic task.

This makes the motion control period the same as the task period of the primary periodic task or the priority-5 periodic task, which allows complete synchronization of multiple axes.

However, the following restrictions apply:

- The motion control instruction is executed and the command for motion control is sent in the sequence control period.
- The data refresh period in the EtherCAT slave depends on settings in the slave.



2-33



Precautions for Correct Use

- You can use the priority-5 periodic task only with the NX701 CPU Units.
- With an NX701 CPU Unit, you can execute motion control in the primary periodic task and in the priority-5 periodic task. If these two motion controls need to be identified, the motion control in the primary periodic task is called motion control 1, while the motion control in the priority-5 periodic task is called motion control 2.
- The NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units perform motion control only in the primary periodic task.



Additional Information

- · Use the Sysmac Studio to assign an axis to an EtherCAT slave and NX Unit mounted on the NX102 and NX1P2 CPU Units, which are controlled by the Motion Control Function Module. This allows the PLC Function Module to send commands to the Motion Control Function Module for motion control instructions that are executed in the user program. It also allows the PLC Function Module to obtain information from the Motion Control Function Module through the Axis variables.
- · The task to which the program that contains the motion control instructions is assigned determines the I/O response time of the motion control system. For details, refer to 5-11-3 System Input and Output Response Times.

2-5-4 Synchronizing Sequence Control and Motion Control


The sequence control period is the task period of the task to which the program and I/O refreshing are assigned. However, motion control is always executed in the task period of the primary periodic task or the priority-5 periodic task. The process data communications cycle for the EtherCAT slave to use for motion control is synchronized with the primary periodic task or the priority-5 periodic task.

With an NX701 CPU Unit, you can set motion control to execute motion processing for each axis and each axes group. For axes or axes groups for which you set motion control 1, motion control and process data communications are executed in the task period of the primary periodic task. For axes or axes groups for which you set motion control 2, motion control and process data communications are executed in the task period of the priority-5 periodic task.

The NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units perform motion control and process data communications for axes and axes groups in the task period of the primary periodic task.

If you assign the sequence control program to the task that motion control is executed, you can synchronize the sequence and motion control periods with the process data communications cycle for EtherCAT.

The following diagram shows a program assigned to the primary periodic task. In the following diagram, the period of sequence control, motion control, and process data communications on EtherCAT are all synchronized.





Additional Information

 Relationship among motion controls, tasks, and process data communications cycles for the NX701 CPU Units

Motion control	Task to execute	Process data communications cycle
Motion control 1	Primary periodic task	Process data communications cycle 1
Motion control 2	Priority-5 periodic task	Process data communications cycle 2

 Relationship among motion controls, tasks, and process data communications cycles for the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units

Motion control	Task to execute	Process data communications cycle
Motion control	Primary periodic task	Process data communications cycle

Overview of CPU Unit Data 2-6

The CPU Unit also contains settings, the user program, present values, and other data. The main data is described in the following table.

Refer to A-8 Attributes of CPU Unit Data for information on all of the data in the CPU Unit.

Type of data		data	Description
	EtherCAT Slave Configuration		This is information on the EtherCAT slave configuration.
	ration	EtherCAT Mas- ter Settings	The EtherCAT Master Settings contain parameter settings for the Ether-CAT Master Function Module, such as the communications cycle.
	Unit Configuration and Unit Setup		The Unit Configuration and Unit Setup contain information on the Unit configuration that enables the CPU Unit to recognize the Units, and the initial settings of Units.
	I/O Map		The I/O Map contains assignment information between the variables and the I/O ports that are automatically created based on the Unit Configuration.
	Control	Operation Set- tings	The Operation Settings include the Startup Mode setting, Security Settings, and System Service Monitoring Settings.
	Control- ler Setup Built-in Ether- Net/IP Port Set- tings		The Built-in EtherNet/IP Port Settings contain the following settings: TCP/IP settings, Ethernet settings, DHCP settings, DNS settings, FTP settings, NTP settings, and SNMP settings
Set- tings	Maties Control Octor		The Motion Control Setup consists of settings for Axis variables and Axes Group variables for axis and axes groups, and motion control parameter settings.
	Cam Data S	ettings	The cam data includes cam tables that consist of phase/displacement data for use in cam operation for motion control instructions.
	Event Setup		These settings are for user-defined errors and user-defined information.
	Task Setup		The Task Setup contain settings for the task types, number of tasks, task execution conditions, task names, programs executed in the task, and other task settings.
	Data Trace	Settings	The Data Trace Settings include settings for trigger conditions.
	Tag Data Link Tables		The Tag Data Link Tables contain the tag data link settings for EtherNet/IP.
	Controller N	lame	The Controller name is the name of the CPU Unit.
	Operation A	Authority Verifica-	This data contains the operation authority passwords to perform Sysmac Studio operations for the CPU Unit.
	Built-in	Set Time	This is the time information that is used inside the CPU Unit.
	Clock	Time Zone Set- ting	This is the time zone that is set for the clock in the CPU Unit.
User	POUs (prog tion units)	ram organiza-	These are the definitions of the programs, functions, and function blocks. The local variable tables and the initial values of the variables are also included.
Pro- gram		Data Types	This data contains the definitions of the data types.
gram	Data	Global Variables	This data gives the attribute information of the global variables. It includes the Initial Value and Retain attributes.
Present	Values of Variables		This data contains the values of the variables.
Values	I Contents of Memory Used		These are the values of the CIO, Working, Holding, DM, and EM Areas in the memory for CJ-series Units.
Other	Event Logs Other		The event logs include the error log for the Controller, and logs of events other than errors, such as when the power supply was turned ON and OFF and when operation started.
Data			This data is used to restore the actual position of a Servo Drive with an absolute encoder in motion control. The offset is the difference between the command position after homing and the absolute data that is read from the absolute encoder.

You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

2-7 Operation for CPU Unit Status

This section describes the processing that is performed for user program execution, I/O refreshing, and external communications according to the status of the CPU Unit. It also describes the operating modes that change the execution status of the user program when the CPU Unit is in the normal operation state

2-7-1 CPU Unit Status

The CPU Unit can be in any of three states: startup state, normal operation state, or error state. These states are defined as follows:

State	Definition
Startup state	The software is initializing the system.
Normal operation	The software is executing processing for instructions that are executed in a task or it is executing a system service. A Controller error has not occurred.
Error state	A Controller error occurred when the software was executing processing for instructions that are executed in a task or it was executing a system service.

The normal operation state has these three states for operation: PROGRAM mode, RUN mode, and downloading. A CPU Unit in the normal operation state changes to the other states due to user interaction. This status is defined as follows:


State	Definition
PROGRAM mode	The operating mode is PROGRAM mode.
RUN mode	The operating mode is RUN mode.
Downloading	Data is being downloaded from the Sysmac Studio.

Note Refer to 2-7-3 Operating Modes for details on PROGRAM mode and RUN mode.

CPU Unit Status

The CPU Unit enters the startup state after the power supply is turned ON. About 10 to 20 seconds after the CPU Unit enters the startup state, software processing begins and the CPU Unit changes to normal operation. If a Controller error occurs during normal operation, the CPU Unit changes to the error state. When you reset the Controller error, the CPU Unit returns to normal operation.

When the CPU Unit changes from startup state to normal operation, it will change to the operating mode that you specify in the Controller Setup. You can set the operating mode at startup to PRO-GRAM mode or RUN mode. Thereafter, changing the operating mode causes the CPU Unit to change between PROGRAM mode and RUN mode. If you download data from the Sysmac Studio during PROGRAM mode, the CPU Unit will change to the downloading state. The CPU Unit will return to PROGRAM mode when the download is completed.





Additional Information

- You can check the operating status of the CPU Unit with the status indicators on the front panel of the CPU Unit. Refer to 12-1 Overview of Troubleshooting for troubleshooting procedures using the status indicators.
- Refer to A-8 Attributes of CPU Unit Data for information on data operations when the CPU Unit status changes.
- Refer to 6-3-9 Changes to Variables for Status Changes for the values that variables take when the status of the CPU Unit changes.

2-7-2 Operation for CPU Unit Status

Changes in the status of the CPU Unit affect user program execution, I/O refreshing, and the operation of external communications. The following table shows how each process operates in startup state and during normal operation.

Refer to *Non-fatal Errors* in the *NJ/NX- series Troubleshooting Manual* (Cat. No. W503) for information on the error state.

CPIL Unit process	Operation	Operation during r		ormal operation	
CPU Unit process- ing	during execu- tion	PROGRAM mode	RUN mode	Downloading	
User program	Stopped.	Stopped.	Executed.	Stopped.	
I/O Refreshing for EtherCAT slaves	Stopped.	Executed.		EtherCAT communications changes to safe-operational state. *1*2	
I/O refreshing for NX Units on the CPU Unit, built-in I/O, or Analog I/O Option Boards	Stopped.	Executed.		Stopped.*2	
I/O Refreshing for CJ- series Units*2	Stopped.	Executed.			
External communica- tions	Stopped.	Executed.		Executed. *3	

^{*1} Only the input values are refreshed.

Values of Outputs in I/O Refreshing

The following table shows the values of the outputs in each state after I/O refresh processing.

	Operation	Operation during		normal operation	
Outputs	Operation during startup	PROGRAM mode	RUN mode	Downloading	
Outputs from Ether- CAT slaves	Controlled by the slave settings.*1	The outputs have the values of the device variables for EtherCAT slaves.		Controlled by the slave settings.*2*3	
Outputs from NX Units on the CPU Unit	Changed to the initial values of Units.	The outputs have the values of the device variables for NX Units.		Controlled by the Unit settings.*3	
Outputs from built-in I/O	Turned OFF.	The outputs have the values of the device variables for built-in I/O.		Turned OFF.*3	
Outputs from Analog I/O Option Boards	Turned OFF.	The outputs have the values of the device variables for Option Boards.		Turned OFF.*3	
Outputs from CJ- series Basic Output Units	Turned OFF.	The output have the values of the device variables for CJ-serie Units. *3*4			

^{*2} I/O refreshing is executed when the device output hold configuration is set to enable (16#A5A5) in the _DeviceOutHoldCfg (Device Output Hold Configuration) system-defined variable. Refer to Device Output Hold Configurations on page 6-70 for the device output hold configurations. A CPU Unit with unit version 1.13 or later and Sysmac Studio version 1.17 or higher are required to use the _DeviceOutHoldCfg (Device Output Hold Configuration) system-defined variable.

^{*3} The tag data links remain in effect, but the values of those links are not refreshed. The output tags retain the values from before the download was started. The values in the input tags are not reflected in the variables.

- *1 Refer to the manual for each slave for information on the slave settings that apply until EtherCAT communications starts after the power supply is turned ON.
- *2 When the download is completed, initialization of the EtherCAT slaves starts. When initialization is in progress, the outputs reflect the settings for the slave.
- *3 Device outputs are retained even when the operating mode changes or when downloading if the device output hold configuration is set to enable (16#A5A5) in the DeviceOutHoldCfg (Device Output Hold Configuration) system-defined variables. Refer to 6-3-9 Changes to Variables for Status Changes for details. A CPU Unit with unit version 1.13 or later and Sysmac Studio version 1.17 or higher are required to use the _DeviceOutHoldCfg (Device Output Hold Configuration) system-defined variable.
- *4 When the download is completed and when the operating mode is changed: the values in the device variables for CJ-series Units are initialized to the values of the Initial Value attributes.

Refer to 6-3-8 Variable Attributes for information on the Initial Value attribute for variables.

Refer to Device Output Hold Configurations on page 6-70 for details on the device output hold configurations.



Precautions for Correct Use

- You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.
- You can use the built-in I/Os and Analog I/O Option Boards only with the NX1P2 CPU Units.
- · You can use CJ-series Units only with NJ-series CPU Units.



Additional Information

Servo Drive Response to Changes in Operating Mode

If the operating mode changes from RUN to PROGRAM mode during a motion control operation, the axes will decelerate to a stop at the maximum deceleration rate.

Changing the Operating Mode during Initialization of EtherCAT Slaves

You can change the operating mode of the CPU Unit to RUN mode while EtherCAT slaves initialization is in progress. If you do, provide programming to confirm that communications are established before you attempt to use slave data in control operations. Your program can use the EC_PDSlavTbl (Process Data Communicating Slave Table) system-defined variable to see if the process data inputs and outputs are valid for all of the slaves.

2-7-3 **Operating Modes**

You can change the operating mode according to the purpose of operation, such as functional testing or actual operation. You can set the operating mode to RUN mode or PROGRAM mode, depending on the purpose. The execution status of the user program is different in each operating mode. The following table gives the purpose for each operating mode and the execution status of the user program.

Operating mode	Application	User program execution status
RUN mode*1	RUN mode is for trial operation or actual operation.	Executed.
PROGRAM mode	PROGRAM mode is for checking I/O wiring and other functional testing without executing the user program.	Not executed.

^{*1} For the default setting, the CPU Unit will enter RUN mode when the CPU Unit changes from startup state to normal operation.



Additional Information

The CPU Unit performs various operations when the operating mode is changed, i.e., the axes are stopped, and motion control instructions are aborted. For details on how the Motion Control Function Module operates when the operating mode is changed, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Operations Allowed from the Sysmac Studio or an HMI in Each Operating Mode

The major operations that you can perform from the Sysmac Studio or an HMI in each operating mode are listed in the following table.

	Operation	RUN mode	PROGRAM mode
Sysmac Studio	Synchronization	Not possible.	Possible.
	Online editing	Possible.	_
	Forced refreshing	Possible.	
	Changing the values of variables or memory used for CJ-series Units*1	Possible.	
НМІ	Changing the values of variables or memory used for CJ-series Units*1	Possible.	

^{*1} You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

Retention of Variable Values during Changes in Operating Mode

The following table shows how the Retain attribute affects the variable values when the operating mode is changed between RUN mode and PROGRAM mode.

Retain attribute of variable	Values of variables
Non-retain	If initial values are set, the variables change to the initial values.
	If no initial values are set, the variables change to the system-defined initial values.*1
Retain	The values before the operating mode changed are retained.

^{*1} The system-defined initial values of variables depend on the data types of the variables. Refer to *When the Initial Value Specification Is Left Blank* on page 6-64.

Refer to 6-3-9 Changes to Variables for Status Changes for the values that variables take when the status of the CPU Unit changes.

Setting and Changing the Operating Mode

When operation starts after the power supply is turned ON, the CPU Unit operates in the operating mode that you specify in the Controller Setup. During normal operation, you change the operating mode for different purposes. You use the Sysmac Studio to set and change the operating mode.

Operating Mode Setting after the Power Supply Is Turned ON

When the CPU Unit starts operating after the power supply is turned ON, the CPU Unit operates in the operating mode that you set as the Startup Mode. Specify RUN mode or PROGRAM mode in the *Startup Mode* setting in the **Operation Settings** in the Controller Setup. Refer to *4-2-2 Controller Setup* for details on the Startup Mode setting.

Changing the Operating Mode during Operation

You can change the operating mode from the Sysmac Studio. Select the RUN mode or PROGRAM mode from Controller - Operating Mode on the menu bar.



Precautions for Safe Use

Always confirm the safety of the controlled system before you change the setting of the Startup Mode or the current operating mode.

Checking the Operating Mode

You can check the operating mode with the RUN indicator on the CPU Unit or the Sysmac Studio.


Checking the RUN Indicator

The RUN indicator on the CPU Unit indicates the operating mode as given below.

RUN indicator status	Operating mode
Not lit	PROGRAM mode
Lit	RUN mode

Checking the Operating Mode from the Sysmac Studio

You can check the operating mode from the Controller Status Pane of the Sysmac Studio. The following Controller Status Pane indicates that the CPU Unit is in RUN mode.





Additional Information

With an NX701 CPU Unit or NJ-series CPU Unit, if you want to output a signal when the CPU Unit is in RUN mode, use the RUN output on the Power Supply Unit. Refer to the NX-series CPU Unit Hardware User's Manual (Cat. No. W535) and the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) for details on the RUN output on the Power Supply Unit.



I/O Ports, Slave Configuration, and Unit Configuration

This section describes how to use I/O ports, how to create the slave and Unit configurations, and how to assign functions.

3-1	Proced	dure to Create the Slave and Unit Configurations 3-2
3-2	Creating and Comparing the Slave and Unit Configurations	
	3-2-1	Creating the EtherCAT Slave Configuration
	3-2-2	Creating the Unit Configuration
	3-2-3	Verifying the Unit Configuration
3-3	I/O Ports and Device Variables	
	3-3-1	I/O Ports
	3-3-2	I/O Port Names
	3-3-3	Device Variables
3-4	Allocating Variables to Units	
	3-4-1	Procedure to Assign Variables to Units
	3-4-2	Using Variables Assigned to Units
3-5		
	Drives/Encoder Input Slaves/NX Units	
	3-5-1	Introduction
	3-5-2	Axis Variables and Axes Group Variables
	3-5-3	Creating and Using Axes and Axis Variables

Procedure to Create the Slave and 3-1 **Unit Configurations**

This section provides the procedures for the slave and Unit configurations.

The shaded steps in the overall procedure that is given below are for the slave and Unit configurations.

Step 1. Software Design

Step 1-1 Designing I/O and Processing

Step 1-2 Designing Tasks

Step 1-3 Designing Programs



Step 2. Software Setups and Programming

Step 2-1 Slave and Unit Configurations

Step 2-2 Controller Setup

Step 2-3 Programming

Step 2-4 Offline Debugging



Step 3. Mounting and Setting Hardware





Step 4. Wiring



Step 5. Checking Operation and Starting Operation on the **Actual System**

For details, refer to 1-3 Overall Operating Procedure for the NJ/NX-series Controller.





Assigned in the Axis Setup



Step 3 Reference Create the axes and assigning them to the slaves or Units (if motion control is used). 1. Create the axes. 3-5 Creating 2. Assign the axes to the slaves or Units in the EtherCAT configuration or Unit configuration. the Axes and EtherCAT slave configuration/Unit configuration Assigning Them to the Servo CPU Unit Drives/Encoder Sysmac Studio Input Slaves/NX Units Servo Drives/encoder input slaves


From EtherCAT configuration/Unit configuration

3-2 Creating and Comparing the Slave and Unit Configurations

To enable accessing the slaves and Units in the Controller, you create a slave configuration and a Unit configuration on the Sysmac Studio. You can also compare the Unit configuration that was created on the Sysmac Studio with the physical Unit configuration.

3-2-1 Creating the EtherCAT Slave Configuration

In the EtherCAT Tab Page of the Sysmac Studio, create the EtherCAT slave configuration that is detected as "correct" by the CPU Unit.



The I/O ports are automatically registered for the slaves in the configuration. Later, the user assigns device variables to the I/O ports. You can specify device variables in the user program to access the slaves.

Refer to *EtherCAT Configuration and Settings* in the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for specific procedures to create the EtherCAT slave configuration.



Additional Information

- If you connect EtherCAT Slave Terminals, create the EtherCAT slave configuration, create the Slave Terminal configuration, and set the operation settings. Refer to the NX-series EtherCAT Coupler Unit User's Manual (Cat. No. W519) for information on the Slave Terminal configuration and operation settings.
- If you use the built-in I/O or Option Boards with an NX1P2 CPU Unit, make the configuration settings and other settings in the Controller Setup.



Version Information

A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use EtherCAT Slave Terminals.




Additional Information

If the EtherCAT slaves are Servo Drives or encoder input slaves, after they are registered in the EtherCAT slave configuration, Axis Variables are registered automatically by creating the axes. Refer to 3-5 Creating the Axes and Assigning Them to the Servo Drives/Encoder Input Slaves/NX Units for details.

3-2-2 **Creating the Unit Configuration**

Use the Unit Editor in the Unit Configuration and Setup Tab Page of the Sysmac Studio to create the Unit configuration that is recognized as correct by the CPU Unit.

Create the Unit Configuration with the Unit Editor of the Sysmac Studio.



When the power is turned ON, an automatic check is performed to determine whether the "correct" Unit configuration matches the physical Unit configuration. The I/O ports are automatically registered for Units that are specified in the Unit configuration. Later, the user assigns device variables to the I/O ports. The device variables are used in the user program to access the Units in the Unit configuration.

Refer to CPU/Expansion Rack Configuration and Setup in the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures to create the Unit configuration.



Precautions for Correct Use


- You can start the Controller without creating the Unit configuration. However, if you do so, the I/O ports and device variables will not be registered automatically, so you will not be able to access the Units from the user program.
- Create the Unit Configuration to use NX Units with an NX102 CPU Unit and NX1P2 CPU Unit, or to use CJ-series Units with an NJ-series CPU Unit. The NX701 CPU Units do not have the Unit configuration because Units are not used.

3-2-3 Verifying the Unit Configuration

You can use either of the following two methods to compare the Unit configuration.


Comparison between the Unit Configuration on the Sysmac Studio and the Physical Unit Configuration

You can verify if the Unit configuration on the Sysmac Studio and the physical Unit configuration are the same. You can compare the Unit configuration on the Sysmac Studio with the physical Unit configuration to see if they are the same before the first time you download the Unit configuration to the CPU Unit from the Sysmac Studio.



Comparison between the Unit Configuration on the Sysmac Studio and the Unit Configuration in the CPU Unit

You can verify if the Unit configuration on the Sysmac Studio and the Unit configuration that is saved in the CPU Unit are the same. You can compare the Unit configuration on the Sysmac Studio with the Unit configuration information that is stored in the CPU Unit to see if they match before you download the Unit configuration to the CPU Unit from the Sysmac Studio.



I/O Ports and Device Variables

This section describes the I/O ports and device variables that you use to access the EtherCAT slaves, NX Units on the CPU Unit, built-in I/O, Option Boards, and CJ-series Units of an NJ/NX-series Controller.




Precautions for Correct Use

- You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.
- You can use the built-in I/Os and Analog I/O Option Boards only with the NX1P2 CPU Units.
- · You can use CJ-series Units only with NJ-series CPU Units.


3-3-1 I/O Ports

An I/O port is a logical interface that is used by the CPU Unit to exchange data with external devices (slaves and Units), built-in I/O, and Analog I/O Option Boards. I/O ports are automatically created when you create the Slave and Unit configurations and other configurations on the Sysmac Studio. You assign device variables to I/O ports to enable accessing the slaves and Units from the user program.



I/O ports are automatically registered in the I/O Map when you create the EtherCAT slave configuration, Unit configuration, and other configurations on the Sysmac Studio, or when you read either of these configurations from the physical Controller from the Sysmac Studio. You can check the I/O ports that were registered in the I/O Map of the Sysmac Studio.

I/O Map



3-3-2 I/O Port Names

The I/O port names are registered automatically. The I/O port names differ as given below depending on whether the device is an EtherCAT slave, NX Unit on the CPU Unit, built-in I/O, Analog I/O Option Board, CJ-series Basic I/O Unit, or CJ-series Special Unit.

EtherCAT Slave Devices

The following I/O port names are used for Remote I/O Terminals that are EtherCAT slave devices.

Example for a 16-point Remote I/O Terminal: Bit00 to Bit15

For other slaves, all or part of the object names that are defined in the EtherCAT object dictionary are used.

Example for Analog Input Unit: CH0_input16-bit

Examples for the R88D-KN50H-ECT: Position actual value and Digital inputs

NX Unit Devices on the CPU Units

If the device is an NX Unit on the CPU Unit, I/O port names are determined by the model number of the NX Unit and the functionality.

Example for an Digital Input Unit: Input Bit 00

Example for an Analog Output Unit: Ch1 Analog Output Value

Built-in I/O Devices

If the device is a built-in I/O, I/O port names are created only for the number of bits for the model number of the NX1P2 CPU Unit.

Example for an NX1P2-9024DT CPU Unit:

Input bits: Input Bit 00 to Input Bit 13
Output bits: Output Bit 00 to Output Bit 09

Option Board Devices

If the device is an Option Board, I/O port names are determined by the model number of the Option Board and the functionality.


Example for an Analog Input Option Board: Ch1 Analog Input Value

Example for an Analog Output Option Board: Ch1 Analog Output Value

CJ-series Basic I/O Unit Devices

If the device is a CJ-series Basic I/O Unit, I/O port names are created according to the following rules.

Rules for I/O Port Names for Basic I/O Units



Example of I/O Port Names for Specific Numbers of I/O Points

Number of input points Number of output points	I/O port names				
	Inputs	Data type	Outputs	Data type	
32 points	Ch1_In	WORD	Ch1_Out	WORD	
	Ch1_In00 to Ch1_In15	BOOL	Ch1_Out00 to Ch1_Out15	BOOL	
	Ch2_In	WORD	Ch2_Out	WORD	
	Ch2_In00 to Ch2_In15	BOOL	Ch2_Out00 to Ch2_Out15	BOOL	


CJ-series Special Unit Devices

If the device is a CJ-series Special Unit, I/O port names are determined by the model number of the Unit and the functionality.


Examples for a CJ1W-AD041-V1 Analog Input Unit: Ch1 PkHdCmd, Ch1 AveCfg, etc.

3-3-3 **Device Variables**

In an NJ/NX-series Controller, external devices are not assigned to specific memory addresses in the CPU Unit. Rather, variables are assigned to the I/O ports. These variables are called device variables.



You can specify device variables in the user program or in external communications to access the devices (slaves or Units).



Refer to 2-3-1 Types of Variables for the relationship of device variables to other variables.

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details on registering device variables with the Sysmac Studio.

Device Variable Attributes

The attributes of the device variables are described in the following table. You can change the settings of some of the attributes, but not all of them.

Attribute	Setting	Changes to settings
Variable Name	Automatically generated variables: [device_name] + [I/O_port_name]	Allowed.
	The default device names are as follows:	
	 For EtherCAT slaves, an E followed by a sequential number starting from 001. 	
	• For CJ-series Units, the device names start with a J followed by a sequential number starting from 01.	
	Refer to 3-3-2 I/O Port Names for more information on I/O port names.	
	If entered manually, the variable name is the string you enter.	
Data Type	According to the data type of the I/O port.	Allowed.
AT Specification	NX Units connected through an EtherCAT Coupler Unit: ECAT://node#[EtherCAT_Coupler_Unit_node_ad-dress.NX_Unit_number]/[I/O_port_name]	Not allowed.
	 NX Units on the CPU Unit: IOBus://unit#[NX_Unit_num- ber]/[I/O_port_name] 	
	Built-in I/O: BuiltInIO://cpu/#0/[I/O_port_name]	
	 Option Boards: BuiltInIO://opt/#[physical_port_num- ber]/[I/O_port_name] 	
	 EtherCAT slaves: ECAT://node#[node_ad- dress]/[I/O_port_name] 	
	 CJ-series Units: IOBus://rack#[rack_num- ber]/slot#[slot_number]/[l/O_port_name] 	
Retain	Device variables for EtherCAT slaves: Not retained.Device variables for NX Units: Not retained.	Not allowed.
	Device variables for built-in I/O: Not retained.	
	Device variables for Option Boards: Not retained.	
	 Device variables for CJ-series Units assigned to the Operating Data (CIO Area): Not retained 	
	Device variables for CJ-series Units assigned to the Setup Data (DM Area): Retained	
Initial Value	None	Allowed.
Constant	None	Allowed.
Network Publish	Do not publish.	Allowed.
Edge	None	Not allowed.

Note You can use CJ-series Units only with NJ-series CPU Units.

Note You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

Note You can use the built-in I/Os and Option Boards only with the NX1P2 CPU Units.

Note You can use system-defined variables for NX Units only with the NX102 CPU Units and NX1P2 CPU Units.

Note You can use device variables for built-in I/Os and Option Boards only with the NX1P2 CPU Units.

Note The physical port number indicates a physical location for an I/O port. 0 is given for the option board slot 1 and 1 is given for the option board slot 2.

Refer to 6-3-4 Attributes of Variables for the meanings of the attributes.



Additional Information

- You can specify forced refreshing for I/O ports in the I/O Map. You can force real I/O to turn ON or OFF to check the wiring.
- You can choose the variable table (global variable table or local variable table for one POU) in which to register a device variable in the I/O Map.

Allocating Variables to Units

For some instructions, the Units on EtherCAT Slave Terminals, NX Units on the NX102 CPU Units and NX1P2 CPU Units are specified by using variables. Therefore, you must assign variables to the Units in advance. After you assign variables to the Units, the connection locations of the Units are automatically updated in the variables even if you change the locations. This means that you do not have to assign variables again every time you change the Unit connection locations.



Version Information

A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to assign variables to Units.



Additional Information

You can assign variables to EtherCAT slaves other than Slave Terminals. This applies to Ether-CAT slaves from other manufacturers. The variables are assigned to the EtherCAT slaves in the same way as they are assigned to EtherCAT Coupler Units and NX Units.

3-4-1 Procedure to Assign Variables to Units

The variables assigned to the Units are not created automatically when you make configuration settings for an EtherCAT Slave Terminal or Unit on the Sysmac Studio. You must make the following settings to assign the variables to the Units.

- On the Sysmac Studio, select Configurations and Setup EtherCAT or Configurations and Setup - CPU/Expansion Racks - CPU Rack and make configuration settings for EtherCAT Slave Terminals or NX Units on the CPU Unit.
- Select Configurations and Setup I/O Map to display the I/O Map. The I/O Map is displayed for the Units of the set EtherCAT Slave Terminals.
- Right-click the model of Unit to which you want to assign variables and select Display Node Location Port from the menu.

The **Node location information** port will be added on the I/O Map.

Right-click the Node location information and select Create Device Variable.

The variable name will be written automatically to the Variable Field of the Node location information port.

The data type of variables assigned to the Units is _sNXUNIT_ID structure. The details on the _sNX-UNIT_ID structure data type are given in the following table.

	Variable	Name	Meaning	Data type
Us	er specified	Specified Unit	Specified Unit	_sNXUNIT_ID
	NodeAdr	Node address	Node address of the Communications Coupler Unit*1	UINT
	IPAdr IP address*2		IP address of the Communications Coupler Unit*1	BYTE[5]
	UnitNo Unit number U		Unit number of the specified Unit	UDINT
	Path Path*2		Path information to the specified Unit	BYTE[64]
	PathLength	Valid path length	Valid path length	USINT

^{*1} This address is not used for an NX Unit on the CPU Unit.

² This information is used only inside the Controller. You cannot access or change it.



Precautions for Correct Use

The values of variables assigned to the Units will be set automatically when you register the variables. Do not change the values of the variables. If you change the value, the Controller may not perform the intended operation.



Additional Information

The data type of variables assigned to EtherCAT slaves other than Slave Terminals is _sECAT_ID structure. The details are given in the following table.

	Variable Name		Meaning	Data type
Us	ser specified	Specified slave	Specified slave	_sECAT_ID
	NodeAdr	Node address	Node address of the EtherCAT Coupler Unit	UINT

3-4-2 Using Variables Assigned to Units


This section describes how to use the variables assigned to the Units in the user program. In any cases, the variable with the same name as the variable assigned to the Unit on the I/O Map must be registered in the variable table in advance. The data type of the variable is _sNXUNIT_ID structure.

Designating Units

The variables assigned to the Units are passed as parameters to the instructions for which specify the Units.

Example: Executing the NX_SaveParam Instruction

In the following example, the NX Unit to which the *NX1* variable is assigned is specified when the NX SaveParam instruction is executed. *NX1* is passed to the *UnitProxy* variable.



Designating Unit Attributes

You can specify members of the variables that you assign to Units to specify some of the Unit attributes.

Example: Executing an Instruction with the Unit Number of an NX Unit

The following programming example reads a data object from an NX Unit if the NX Unit number of the NX Unit to which the NX1 variable is assigned is 2. The NX1. UnitNo member gives the NX Unit number.

```
IF (NX1.UnitNo = UINT#2) THEN
 NX_ReadObj_instance(Execute:=TRUE, UnitProxy:=NX1, Obj:=S_Obj, ReadDat:=Rdat);
END_IF;
```

Designating More Than One Unit

To designate more than one Unit, you can specify the elements of an array of the variables that are assigned to the Units. This allows you to use loop processing to perform the same process for more than one Unit.

Example: The following programming example changes multiple NX Units to the mode that enables writing data.

NX0, NX1, and NX2 are the variables that were assigned to the NX Units. The variables are assigned to the elements of the NXTable[0..2] and then the NX ChangeWriteMode instruction is executed in order for each.

Variable Table

Variable	Data type
NXTable	ARRAY[02] OF_sNXUNIT_ID

```
    ST Program
```

FOR i:= 0 TO 2 DO

NX ChangeWriteMode instance[i](Execute:=FALSE);

END FOR;

NXTable[0] := NX0;

NXTable[1] := NX1;

NXTable[2] := NX2;

FOR i:= 0 TO 2 DO

NX_ChangeWriteMode_instance[i](Execute:=TRUE, UnitProxy:=NXTable[i]);


END_FOR;

3-5 Creating the Axes and Assigning Them to the Servo Drives/Encoder Input Slaves/NX Units

This section describes how to create axes in the NJ/NX-series Controller and how to assign the axes to the Servo Drive, encoder input slaves, and NX Units.

3-5-1 Introduction

When you use the Motion Control Function Module for operation with EtherCAT Servo Drive, encoder input slaves, or NX Units, create axes in the Sysmac Studio and define them as EtherCAT servo Drive, encoder input slaves, or NX Units. At a result, Axis Variables are automatically created as system-defined variables.



You can specify an Axis Variable in a motion control instruction in the user program to easily access and perform operations with Servo Drive, encoder input slaves, and NX Units.

Axis Variables and Axes Group Variables 3-5-2

The following table lists the types of Axis Variables and Axes Group Variables.

Type of	variable	Application	Device to access	Creation method
Axis Variables	System-defined axis variables	An Axis Variable is used to control a sin-	The EtherCAT slave (Servo Drive or	Provided by the system.
	Axis Variables auto- matically created when axes are cre- ated with the Sys- mac Studio	gle axis.	encoder input slave) or NX Unit that is assigned to the axis	You must create an axis with Sysmac Studio and assign the device to the axis.
Axes Group Variables	System-defined axes group variables	An Axes Group Variable is used for	The EtherCAT slaves (Servo Drive	Provided by the system.
	Axes Group Variables automatically created when axes groups are created with the Sysmac Studio	multi-axes coordi- nated control.	or encoder input slaves) or NX Units that are assigned to the axes group	You must create an axes group with the Sysmac Studio.

Refer to the NJ/NX-series Motion Control Instructions Reference Manual (Cat. No. W508) for details on Axis Variables and Axes Group Variables.

Specifying Axis and Axes Group Variables

The variables can be specified with variable names that are created with the Sysmac Studio or with system-defined variable names.

Type	Names		
Туре	Axis Variables	Axes Group Variables	
Variable names created with the Sysmac Studio	MC_Axis*** ("***" is assigned in ascending order from 000 in the order the variables are created.)	MC_Group*** ("***" is assigned in ascending order from 000 in the order the variables are created.)	
	You can change the names as required.	You can change the names as required.	
System-defined variable names	_MC_AX[***]*1 (The array element numbers are assigned in ascending order from 0 in the order the variables are created.)	_MC_GRP[***]*1 (The array element numbers are assigned in ascending order from 0 in the order the variables are created.)	

^{*1} With the NX701 CPU Unit, you can also use _MC1_AX[***], _MC2_AX[***], _MC1_GRP[***], and _MC2_GRP[***]. For details, refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507).

Application

There are two ways to use Axis Variables and Axes Group Variables.


- 1) Specifying Axes and Axes Groups in Motion Control Instructions: If you specify an axis or axes group for an I/O variable for a motion control instruction, you can perform operations for the OMRON Servo Drive, encoder input slave, or NX Unit.
- 2) Monitoring Axis Variable Members: You can use instructions to monitor the actual position, error information, or other information on the Servo Drive, encoder input slaves, and NX Units.



Additional Information

Details on Axis Variables

- 1. Assume that you create an axis with an axis name of A on the Sysmac Studio. An Axis Variable with a variable name of A is created automatically based on the system-defined axis variable. The Axis Variable consists of Axis Basic Settings, Unit Conversion Settings, I/O, operating status, current values, error status, and warning status.
- 2. You specify the axis variable name A for the in-out variable of a motion control instruction. With the axis variable name, you can access the OMRON Servo Drive or encoder input slave, supported Servo Drive or encoder input slave from another company, or NX Unit and perform operations for it.
- 3. You can specify the Axis Variable to use instructions as required to monitor the actual position, error information, or other information on the Servo Drive, encoder input slave, or NX Unit.



3-5-3 **Creating and Using Axes and Axis Variables**

You can create and use axes and Axis Variables as described below.

Right-click Axis Settings under Configurations and Setup - Motion Control Setup in the Multiview Explorer and select *Add* – *Axis Settings* from the menu.


If necessary, you can change the axis variable names from the default names of MC Axis***. ("***" is incremented from 000 in the order that the axis variables are created.)

Assign the axes that you created to Servo Drives or encoder input slaves in the EtherCAT slave configuration of the Sysmac Studio.

Set the Axis Basic Settings from the Sysmac Studio.

Classification	Parameter name	Setting
Axis Basic Settings	Axis Number	Axis numbers are automatically set in the order that the axes are created.
	Motion Control*1	Select Primary periodic task.
	Axis Use	Select Used axis.
	Axis Type	Select a servo axis or encoder axis.
	Input Device/ Output Device	Specify the node address of the EtherCAT slave that is assigned to the axis.


*1 You can select this parameter for NX701 CPU Units.



- Use the Sysmac Studio to specify the settings required for Test Mode operation (Unit Conversion, Count Mode, Limits, etc.) and the settings required for actual system operation. Then transfer the settings to the CPU Unit with the project.
- In the user program, an axis variable name is specified for the in-out variable Axis in motion control instructions.

For the axis variable name, specify the axis name (axis variable name) that was specified in the Motion Control Setup or a system-defined variable. You can execute motion control for the assigned Servo Drive, encoder input slave, or NX Unit. An example that specifies the axis variable name MyAxis1 is shown below.

Example:



Refer to 3-5-2 Axis Variables and Axes Group Variables for information on Axis Variables.



Precautions for Correct Use

For an NX701 CPU Unit, use the system-defined variables that correspond to the Motion Control parameter for Axis Settings or Axes Group Settings. A building error will occur if you use the system-defined variables that do not correspond.

Motion Control setting	Corresponding system-defined variable
MC1: Primary periodic task	_MC_AX[***], _MC1_AX[***], _MC_GRP[***], _MC1_GRP[***]
MC2: Priority-5 periodic task	_MC2_AX[***], _MC2_GRP[***]



Controller Setup

This section describes the initial settings of the function modules.

4-1	Overvi	ew of the Controller Setup	4-2
4-2	Initial S	Settings for the PLC Function Module	4-4
	4-2-1	Introduction	
	4-2-2	Controller Setup	4-4
	4-2-3	Task Settings	4-7
	4-2-4	Unit Configuration and Unit Setup for NX102 CPU Units and NX1P2 CPU Units	4-12
	4-2-5	Unit Configuration and Unit Setup for NJ-series CPU Units	4-15
4-3	Initial S	Settings for NX Units	4-16
	4-3-1	NX Unit Settings	
	4-3-2	I/O Allocation Settings	
	4-3-3	Unit Operation Settings	
4-4	Initial	Settings for Special Units	4-20
4-5	Initial S	Settings for the Motion Control Function Module	4-22
	4-5-1	Introduction	
	4-5-2	Setting Methods	4-23
4-6	Initial S	Settings for the EtherCAT Master Function Module	4-24
4-7	Initial	Settings for the EtherNet/IP Function Module	4-25
4-8	Initial	Settings for Built-in I/O	4-26
4-9	Initial S	Settings for Option Boards	4-27
4-10	Memoi	ry Settings for CJ-series Units	4-28
	4-10-1	Setting Procedure	
	4-10-2	Setting Screen	
	4-10-3	Settings	4-30

Overview of the Controller Setup

This section provides an overview of the Controller Setup.

The shaded steps in the overall procedure that is shown below are related to the Controller Setup.

Step 1. Software Design

Step 1-1 Designing I/O and Processing

Step 1-2 Designing Tasks

Step 1-3 Designing Programs



Step 2. Software Setups and Programming

Step 2-1 Slave and Unit Configurations

Step 2-2 Controller Setup

Step 2-3 Programming

Step 2-4 Offline Debugging



Step 3. Mounting and Setting Hardware



Step 4. Wiring



Step 5. Checking Operation and Starting Operation on the **Actual System**

Refer to 1-3 Overall Operating Procedure for the NJ/NX-series Controller for details.

Controller Setup	Reference
Initial Settings Related to the PLC Function Module:	4-2 Initial Set-
Controller Setup: Startup Mode, Write Protection, System Service Monitoring Settings, and other settings	tings for the PLC Function Module
Initial Settings for NX Units:	4-3 Initial Set-
Unit Configuration and Setup: Initial settings for the NX Units	tings for NX Units
Initial Settings for Special Units:	4-4 Initial Set-
Unit Configuration and Setup: Initial settings for the Special Units	tings for Special Units
Initial Settings for the Motion Control Function Module:	4-5 Initial Set-
Axis Parameters: Motion control parameters for single-axis operation	tings for the Motion Control
 Axes Group Parameters: Motion control parameters for multi-axes coordinated operation 	Function Mod- ule
 Cam data: Phase and displacement setting tables for cam motions 	
Initial Settings for the EtherCAT Master Function Module:	4-6 Initial Set-
EtherCAT Master Parameters in the EtherCAT Configuration: Parameter settings for the EtherCAT master process data communications cycle, and other settings	tings for the EtherCAT Mas- ter Function Module
Initial Settings for the EtherNet/IP Function Module:	4-7 Initial Set-
Ethernet Port Setup: EtherNet/IP Port TCP/IP Settings, Ethernet Settings, and other settings	tings for the EtherNet/IP Function Mod- ule

Initial Settings for the PLC Function 4-2 **Module**

This section describes the initial settings that are required for the PLC Function Module.

4-2-1 Introduction

The initial settings for the PLC Function Module are listed below.

- Controller Setup
- · Task Settings


Select Configurations and Setup - Controller Setup and Configurations and Setup - Task Settings on the Sysmac Studio to make these settings

4-2-2 **Controller Setup**

Operation Settings Tab Page

Basic Settings

The Operation Settings are for functions supported by the CPU Unit, such as the definitions of operations when the power is turned ON or when the operating mode changes.



Parameter	Setting group	Description	Set value	Default	Update tim- ing	Changes in RUN mode
Operation Settings	Startup Mode	Sets the CPU Unit's operating mode at startup.	RUN or PRO- GRAM mode	RUN mode	When down- loaded to CPU Unit	Not allowed.
	Start delay time at startup*1	Sets the time to wait for an NS-series PT to per- form the tag verifications with priority during startup after the power supply is turned ON.*2	0 to 10 s	0 s	When down- loaded to CPU Unit	Not allowed.
	Battery- related error detection*3	Sets whether to use battery-related error detection.	Do not use. Use.	Do not use.	When down- loaded to CPU Unit	Not allowed.
SD Memory Card Setting	Memory Card Diagnosis at Startup	Sets whether to execute self-diagnosis (file system check and recovery) on the inserted SD Memory Card when the power is turned ON.	Do not check. Check.	Do not check.	When down- loaded to CPU Unit	Not allowed.
System Service Monitoring Settings*4	System Service Execution Interval [ms]	Sets the interval of system service execution.	10 ms to 1 s	10 ms	When down- loaded to CPU Unit	Not allowed.
	System Service Execution Time Ratio [%]	Sets the ratio of execution for monitoring system services in relation to overall processing of the CPU Unit.	5% to 50%	10%	When down- loaded to CPU Unit	Not allowed.
SD Memory Card Pro- gram Trans- fer Setting*5	Program transfer by system- defined vari- able	Sets whether to use the program transfer from SD Memory Card.	Use. Do not use.	Do not use.	When trans- ferred to CPU Unit	Not allowed.
	Password	Sets the password that is used for verification when you execute the program transfer from the SD Memory Card.	8 to 32 single- byte alphanu- meric charac- ters (case sensitive)	None	When trans- ferred to CPU Unit	Not allowed.
SD Memory Card Restore Setting*6	Restore by system- defined vari- able	Set whether to use the restore of SD Memory Card backups by the system-defined variable.	Use. Do not use.	Do not use.	When trans- ferred to CPU Unit	Not allowed.
	Password	Sets the password that is used for verification when you execute the restore of SD Memory Card backups by the system-defined variable.	8 to 32 single- byte alphanu- meric charac- ters (case sensitive)	None	When trans- ferred to CPU Unit	Not allowed.
Event Log Settings*7	Instruction Error Output	Sets whether to output events to an event log when instruction errors occur.	Do not use. Use.	Do not use.	When trans- ferred to CPU Unit	Not allowed.

Parameter	Setting group	Description	Set value	Default	Update tim- ing	Changes in RUN mode
Security Setting	Write Protection at Startup	Sets whether to automatically enable or disable write protection when you turn ON the power supply to the Controller.	Do not use. Use.	Do not use.	When power is turned ON	Supported.
	Prohibit data backup to the SD Memory Card ^{*8}	Sets whether to enable or disable SD Memory Card backups.	Do not use. Use.	Do not use.	When down- loaded to CPU Unit	Supported.

- *1 This setting is enabled when an NS-series PT is connected to the built-in EtherNet/IP port on the CPU Unit, and the power supplies for these devices are turned ON simultaneously.
 - A CPU Unit with unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to set the NS start wait time at startup.
- *2 The processing time for verifying tags of an NS-series PT can be reduced with this setting. Set the value to 10 if you want to give priority to the tag verifications. Otherwise, set the value to 0.
 - If you set the value to 10, after the power supply is turned ON, the CPU Unit gives priority to the tag verifications of the NS-series PT for approximately 10 seconds during startup before the Unit changes the startup state to the normal operation state. The time to complete the tag verifications can be reduced by performing a part of processing of the tag verifications with priority during startup.
 - If you specify the value between 1 and 10, the time until the CPU Unit changes the state to the normal operation state is increased because the Unit gives priority to the tag verifications for the specified time regardless of whether an NS-series PT is used. Set the value to 0 if an NS-series PT is not connected, or if you do not turn ON the power supplies for the NSseries PT and the CPU Unit simultaneously.
- *3 These settings are only provided for the NX102 CPU Units and NX1P2 CPU Units.
- *4 For NX-series CPU Units, the System Service Monitoring Settings are not provided.
- *5 A CPU Unit with unit version 1.11 or later and Sysmac Studio version 1.15 or higher are required to use the SD Memory Card Program Transfer Setting.
- *6 A CPU Unit with unit version 1.14 or later and Sysmac Studio version 1.18 or higher are required to use the SD Memory Card Restore Setting.
- *7 A CPU Unit with unit version 1.02 or later and Sysmac Studio version 1.03 or higher are required to use the Event Log Settings.
- *8 A CPU Unit with unit version 1.03 or later and Sysmac Studio version 1.04 or higher are required to disable backups.

Operation item		Description		
Setting Change	You can cha	ou can change the set values of parameters that can be changed during RUN mode.		
during RUN Mode	Refer to the	Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the operations.		
	Start:	Enables writing set values.		
	Transfer:	Transfers set values to the Controller. The set values are overwritten.		
	Cancel:	Prohibits writing set values.		




Precautions for Correct Use

If Use is selected for Event Log Settings – Instruction Error Output, an instruction error is output each time an error occurs when an instruction with an error is executed repetitively. This may cause the event log to exceed the maximum number of events. If this occurs, older events are overwritten.

4-2-3 Task Settings

Task Settings

The Task Settings are used to add and set up tasks.



Parameter	Setting group	Description	Set value	Default	Update timing	Changes in RUN mode
Task Type		Sets the task type.	Primary periodic task Priority-5 periodic task*1	Primary peri- odic task	When down- loaded to CPU Unit	Not allowed.
			Priority-16 periodic task*2			
			Priority-17 periodic task			
			Priority-18 periodic task			
			Priority-8 event task			
			Priority-48 event task			
	Execution Priority	Sets the task execution priority.	Automatically set according to the task type.	Primary periodic task: 4	When down- loaded to CPU Unit	Not allowed.
Task Name		Sets the task name.	Text string	Primary peri- odic task: Pri- maryTask	When down- loaded to CPU Unit	Not allowed.
				Periodic tasks: Period- icTask0		
				Event tasks: EventTask0		

Parameter	Setting group	Description	Set value	Default	Update timing	Changes in RUN mode
Period/Exe- cution Con- ditions		Sets the task period.	Primary periodic task/Periodic task/Periodic tasks: Refer to 5-3-1 Specifications of Tasks for NX701 CPU Units. Refer to 5-4-1 Specifications of Tasks for NX102 CPU Units and NX1P2 CPU Units. Refer to 5-5-1 Specifications of Tasks for NJ-series Controllers. Event tasks: Executed with an instruction or when a variable expression is satisfied.	Primary periodic task: 1 ms*3 Periodic tasks: 2 ms (Priority 5) 10 ms (Priority 16, 17, and 18) Event tasks: Execution with an instruction	When downloaded to CPU Unit	Not allowed.
Task Period Exceeded Detection		Sets whether to detect an error when the task period is exceeded.	Detect. (Minor fault level Controller error generated.) Do not detect. (Store an observation level log record.)	Primary periodic task and periodic tasks: Detect Event tasks: Do not detect (cannot be changed).	When down- loaded to CPU Unit	Not allowed.
Task Time- out Detec- tion Time		Sets the task execution timeout time. A Task Execution Timeout occurs when the timeout time is exceeded.	Primary periodic task and periodic tasks: Task period × 1 to Task period × 5 Event tasks: Execution priority of 8: 1 to 500 ms Execution priority of 48: 1 ms to 10 s	Primary periodic task and periodic tasks: Task period × 5 Event tasks: Execution priority of 8: 200 ms Execution priority of 48: 1 s	When down- loaded to CPU Unit	Not allowed.
Variable Access Time [%]		Sets the percentage of the task period to assign to variable access from outside the Controller.	Primary periodic task and periodic tasks: 1% to 50% Event tasks: None	3%	When down- loaded to CPU Unit	Not allowed.


^{*1} You can use the priority-5 periodic task only with the NX701 CPU Units.

^{*2} You cannot use the priority-16 periodic task with the NX102 CPU Unit or NX1P2 CPU Unit.

^{*3} For the NX102 CPU Unit, NX1P2-□□□□ CPU Unit, and NJ101-□□□□ CPU Unit, the default of the primary periodic task is 2 ms.

● I/O Control Task Settings


The I/O Control Task Settings are used to set the timing of refresh execution of inputs and outputs.



Parameter	Description	Set value	Default	Update timing	Changes in RUN mode
Task Name	Sets the task to use to refresh the specified Units or slaves.	PrimaryTask or PeriodicTask	PrimaryTask	When down- loaded to CPU Unit	Not allowed.

Program Assignment Settings

The Program Assignments Settings are used to assign the programs to tasks, set the program execution order, and set the operation of the programs at the start of operation.



Parameter	Description	Set value	Default	Update timing	Changes in RUN mode
Program Execution Order	Assigns the programs to the specified tasks and sets the order of program execution within the tasks.	Assign the programs in the order to execute them from top to bottom.	Program0	When down- loaded to CPU Unit	Not allowed.
Initial Status of Program*1	Set whether to run the program at the start of operation.	Run Stop	Run	When down- loaded to CPU Unit	Not allowed.

^{*1} A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required.



Precautions for Correct Use


- · A program that contains the device variables used to access slaves and Units must be assigned to the same task as the one to which the slaves and Units that are set in the I/O Control Task Settings are assigned. A building error will occur if you assign the program to other tasks.
- The default task set in the I/O Control Task Settings is the primary periodic task. If you want to assign the program to a task other than the primary periodic task, change the setting in the I/O Control Task Settings in advance to prevent a building error.
- For an NX-series CPU Unit, a program used to control slaves and Units that are assigned to axes must be assigned to the tasks that correspond to the Motion Control parameter for Axis Settings or Axes Group Settings. A building error will occur if you assign the program to the tasks that do not correspond.

Use the system-defined variables that correspond to the setting values of the Motion Control parameter when you specify axes or axes groups in programs.

Motion Control setting	Corresponding task to program assignment	Corresponding system- defined variable
MC1: Primary periodic task	Primary periodic task Priority-16 periodic task	_MC_AX[], _MC1_AX[], _MC_GRP[], _MC1_GRP[]
MC2: Priority-5 periodic task	Priority-5 periodic task	_MC2_AX[], _MC2_GRP[]

Settings for Exclusive Control of Variables in Tasks


The Settings for Exclusive Control of Variables in Tasks are used to set the tasks that refresh specified global variables and the tasks that access specified global variables.



Item	Parameter	Description	Set value	Default	Update tim- ing	Changes in RUN mode
Each Task	Variables to be refreshed	Sets the variables to refresh in the primary periodic task or periodic task.		None	When down- loaded to CPU Unit	Not allowed.
	Data Type	Sets the data type of variable.	None			
	Variable Comment	Sets a comment for the variable.	None			
	Accessing Task	Sets the tasks that access the variable.				


Task Execution Status Monitor

The Task Execution Status Monitor displays the execution status of the programs.



● Task Execution Time Monitor

The Task Execution Time Monitor displays the execution times of the tasks.



4-2-4 Unit Configuration and Unit Setup for NX102 CPU Units and **NX1P2 CPU Units**


This section describes the Unit configurations and settings for the NX102 CPU Units and NX1P2 CPU Units. These settings are not provided for the NX701 CPU Units and NJ-series CPU Units.

Create the NX Unit configuration on the CPU Unit, and set up each Unit.

Make the settings on the CPU and Expansion Racks Tab Page on the Sysmac Studio.

Unit Configuration Information

The Unit configuration information describes the configuration of the NX Bus Function Module: the number and order of NX Units connected to the NX bus of the NX102 CPU Unit and NX1P2 CPU Unit, individual Unit information, and information about the CPU Unit itself.



The settable items for the selected CPU Unit are listed below.

Item	Description	Set values	Default
Serial Number Check Method	Set this setting to Setting = Actual device to	No check.	No check.
	compare the serial numbers of the NX Units at	Setting =	
	these times: when the power is turned ON and	Actual device	
	after the CPU Unit is restarted. The serial		
	numbers of the NX Units saved in the Unit		
	configuration information are compared with		
	the actual serial numbers of the NX Units.*1		
	If differences are found, a Unit Configuration		
	Verification Error will occur.		
Fail-soft Operation Setting	Set whether to use fail-soft operation for the NX	Fail-soft	Fail-soft
	Bus Function Module. Select Fail-soft operation	operation	operation
	to perform fail-soft operation.	Stop	
	Refer to 8-2-5 Fail-soft Operation for NX Units		
	on the CPU Unit.		

^{*1} If this setting is set to Setting = Actual device and you replace an NX Unit on the CPU Unit, a Unit Configuration Verification Error will occur. A Unit Configuration Verification Error will also occur if you swap the mounting position of two Units of the same model. If it becomes necessary to replace an NX Unit, or swap the mounting positions of two Units of the same model while this setting is set to Setting = Actual device, you must correct the Unit configuration information and download it to the CPU Unit. Set this parameter to Setting = Actual device if strict management of the equipment configuration is required.

Precautions in Changing the Unit Configuration

This section provides precautions that apply when you change the NX Unit configuration on an NX102 CPU Unit and NX1P2 CPU Unit.


● I/O Data That Require Specification of NX Unit Numbers

You must specify the NX Unit number to access some system-defined variables in I/O data. If you change the Unit configuration on the CPU Unit, you must correct the specified NX Unit numbers, such as those in programs.

_NXB_UnitRegTbl (NX Unit Registration Status) and _NXB_UnitErrFlagTbl (NX Unit Error Status) are examples of the system-defined variables to specify the NX Unit number.

The system-defined variable for this status information uses BOOL arrays, and the NX Unit number is specified as the subscript.

For example, if an NX Unit D is added to the CPU Unit, the NX Unit numbers of all NX Units to the right of the new NX Unit will change.



If you specify the subscripts of arrays directly with numbers, the subscripts in the program must be corrected to specify the same NX Unit as before the addition.

If you use _sNXUNIT_ID data type variables that are assigned to the Units to specify the array subscripts, you do not need to correct the program even if the Unit configuration changes. The NX Unit number of a Unit is stored in the *UnitNo* member of the _sNXUNIT_ID structure variable.

For example, if the _sNXUNIT_ID variable NXUnitB is assigned to NX Unit B in the above figure, the program would not need to be corrected even if the Unit configuration changed as long s the array subscript is specified with _NXB_UnitRegTbl[NXUnitB.UnitNo].



Additional Information

NX Unit Mounting Settings


If an NX Unit is removed or if you know in advance that an NX Unit is planned to be added, you can use the NX Unit mounting settings to prevent the NX Unit numbers from changing.

Refer to 8-2-2 Mounting Settings of NX Units on the CPU Unit.

4-2-5 Unit Configuration and Unit Setup for NJ-series CPU Units

This section describes the Unit settings for NJ-series CPU Units. These settings are not provided for NX-series CPU Units.

Unit Information



Settings for All Units

Set the device names.

Device names are automatically created when Units are added in the Unit Editor.

Default names: "J" followed by serial numbers that start from 01

We recommend that you change the name to one that is suitable to the device.



Additional Information

The device names that are set here are placed before the I/O port name when device variables are automatically created.

Special Units

Set the unit numbers of the Special Units.



Precautions for Correct Use

Make sure you set the same unit numbers as the unit numbers that are set on the rotary switches on the front of the Special Units. If they are not the same, operation will be according to the unit numbers that are set on the front-panel rotary switches.

Basic I/O Units

The following settings are made in the Unit Information of the Basic I/O Units.


Access point	Setting group	Description	Set values	Default	Update tim- ing	Changes in RUN mode
Unit Information Note Set the information for each slot.	Basic Input Unit Input Response Time	Sets the input response time (ON response time = OFF response time) of the Basic Input Unit. You can set no filter or you can set the value in increments from 0 to 32 ms. You can increase the value to reduce chattering and the effects of external noise. If you decrease the value, shorter input pulses are received (but the pulses must be longer than the task period).	No filter 0.5 ms, 1 ms, 2 ms, 4 ms, 8 ms, 16 ms, or 32 ms	8 ms	When power is turned ON or the CPU Unit is reset	Not allowed.

Initial Settings for NX Units

This section describes the initial settings that are required for NX Units on the NX102 CPU Units and NX1P2 CPU Units. These settings are not provided for the NX701 CPU Units and NJ-series CPU Units.

4-3-1 **NX Unit Settings**

Select an NX Unit to set and make the settings on the CPU and Expansion Racks Tab Page on the Sysmac Studio.



The settable items for the selected NX Unit are listed below.

Item	Description	Set values	Default
Device name	The name of the NX Unit.	Any value*1	*2
NX Unit Mounting Setting	This setting enables or disables the mounting of an NX Unit. Refer to 8-2-2 Mounting Settings of NX Units on the CPU Unit for details on this setting.	Enabled or Disabled	Enabled
I/O allocation settings	These are the settings for which I/O data in the NX Unit to exchange.*3 Click the Edit I/O Allocation Settings Button to edit these settings. You cannot change this setting for System Units. Refer to <i>4-3-2 I/O Allocation Settings</i> for an overview of I/O allocation settings and how to edit the settings.		Refer to the manual for the specific NX Unit.
Unit operation settings	These are the Unit operation settings for the NX Unit.*4 Click the Edit Unit Operation Settings Button to edit these settings. You cannot change this setting for System Units. Refer to <i>4-3-3 Unit Operation Settings</i> for the Unit operation settings.		Refer to the manual for the specific NX Unit.
Unit application data	This data controls the functionality that is specific to each NX Unit. Not all NX Units have Unit application data.		Refer to the manual for the specific NX Unit.

^{*1} The device name that is set here is placed before the I/O port name when device variables are automatically created.

^{*2 &}quot;N" followed by serial numbers that start from 1.

^{*3} The NX Units contain default values for the I/O settings. You do not need to edit the default values for a standard exchange. Change the settings as necessary.

^{*4} The settings are available depend on the type of the NX Unit. For example, Digital Input Units have a setting for the input filter value, and Digital Output Units have a setting for the output value at load rejection. Refer to the manual for the specific NX Unit for the settings and their meanings.

4-3-2 I/O Allocation Settings

This section provides an overview of I/O allocation settings and how to edit the settings.

An Overview of I/O Allocation Settings

To allocate I/O, select an I/O entry mapping and register an I/O entry to the I/O entry mapping.

Selecting I/O Entry Mappings


An I/O entry mapping defines a set of I/O data. Each Unit has its I/O entry mapping.

The data for each I/O entry included in the selected I/O entry mappings are exchanged. Default values are assigned to the I/O entry mapping selections. Change the I/O entry mapping selections as necessary. If an I/O entry mapping must be selected, the option to deselect it will not be available.

Registering I/O Entries

The I/O data assigned to an I/O entry mapping is called an I/O entry.

Default values are assigned to the I/O entries in each I/O entry mapping. Some I/O entry mappings allow you to add or delete I/O entries. Also, the I/O data that you can assign to an I/O entry mapping is predetermined. Change the I/O entries as necessary.




*The shaded I/O data is not exchanged with process data communications.

Editing the I/O Allocation Settings

You can edit the I/O allocation settings for the NX Units as necessary.

When you click the Edit I/O Allocation Settings Button in the CPU and Expansion Racks Tab Page on the Sysmac Studio, the Edit I/O Allocation Settings Pane is displayed.



Name/Label	Description
I/O Allocation	The usage of I/O allocation for the entire CPU Unit is displayed here.
Status	(1)I/O data size: The size of the I/O data that is allocated for the entire CPU Unit is given. The denominator is the maximum allocatable size.
	The I/O data size gives the amount of memory that is used by the I/O data. This value will
	not necessarily be the same as the total sum of all I/O entry sizes.
	(2)Number of I/O entry mappings: The number of I/O entry mappings that are allocated to the entire CPU Unit is given. The denominator is the maximum number of allocatable I/O data.
I/O Entry	This is a mapping list of the I/O entries in the corresponding Unit.
Mapping List	The I/O entry mapping list shows up to four inputs and outputs respectively.
	The I/O entry mapping list shows the following items.
	Selection: This column is used to select the I/O entry mappings that you wish to allocate. Select the I/O entry mapping that you wish to allocate.
	If you do not want to allocate the I/O entry mapping as part of the I/O allocation information, select <i>No</i>
	option.
	Input/Output: This column shows whether the data is an input or an output in terms of the CPU Unit.
	I/O entry mapping name: This column gives the name of the I/O entry mapping.
	• Flag: If the I/O entry is editable, this column says "Editable."
1/0 t	• If the I/O entry is not editable, this column says ""
I/O entries	This pane allows you to view and edit the I/O entries for the I/O entry mappings that are selected in the I/O Entry Mapping List.
	Each I/O entry contains the following information.
	Index: This is the index number for the NX object.
	The index is displayed after "0x" as index_number: subindex_number.
	Size: This column gives the size of the I/O entry data.
	Data Type: This column gives the data type of the I/O entry. I/O entry pages. This polymore rives the pages of the I/O entry.
	 I/O entry name: This column gives the name of the I/O entry. Comment: This column gives a description of the I/O entry.
Control buttons	Add I/O Entry Button: This button adds an I/O entry to the selected I/O entry mapping.
for the Edit I/O	Delete I/O Entry Button: This button deletes the selected I/O entry from the selected I/O entry mapping.
Allocation	OK Button: This button confirms the settings in the Edit I/O Allocation Settings Pane, and returns the
Settings Pane	display to the CPU and Expansion Racks Tab Page.
	Cancel Button: This button cancels the settings in the Edit I/O Allocation Settings Pane, and returns the
	display to the CPU and Expansion Racks Tab Page.
	Apply Button: This button confirms the settings in the Edit I/O Allocation Settings Pane, and allows you to edit other I/O entries.

4-3-3 Unit Operation Settings


The settings that are available depend on the type of the NX Unit. For example, Digital Input Units have a setting for the input filter value, and Digital Output Units have a setting for the output value at load rejection.

Refer to the manual for the specific NX Unit for the settings and their meanings.

Editing the Unit Operation Settings

You can edit the Unit operation settings for the NX Units as necessary.

When you click the **Edit Unit Operation Settings** Button in the CPU and Expansion Racks Tab Page on the Sysmac Studio, the Edit Unit Operation Settings Tab Page is displayed.





Precautions for Correct Use

If the connected position of an NX Unit is changed, the Unit operation settings return to initial values. Transfer the Unit operation settings again as necessary.


Initial Settings for Special Units

This section describes the initial settings that are required for the Special Units used with NJ-series CPU Units. These settings are not provided for NX-series CPU Units.

You can use any of the following methods to set the initial settings of the Special Units.

Method 1: Setting from the Unit Setting Pane of the Sysmac Studio

- Select the Unit in the Unit Configuration and Setup.
- Specify the settings in the Unit Settings Tab Page shown below.



Connect the CPU Unit online and transfer the settings to the CPU Unit.

Method 2: Using the Sysmac Studio to Specify Initial Settings for the I/O Ports in the I/O Map

- Use the I/O Map in the Sysmac Studio to set values for the I/O ports.
- Restart the Unit, reset the Controller, or cycle the power supply to the Controller.


Method 3: Using the Sysmac Studio to Specify Initial Settings for the Device Variables of the CJ-series Units

- 1 Use the Sysmac Studio to specify the initial values for the device variables of the CJ-series Units.
- 2 Download the variable table from the Sysmac Studio to the CPU Unit.
 Select the Clear the present values of variables with Retain attribute Check Box.
- **3** Restart the Unit, reset the Controller, or cycle the power supply to the Controller.

Method 4: Using Instructions to Set the Device Variables for the CJseries Units

1 Set the values for the device variables for the CJ-series Unit at the start of operation from the user program (e.g., use the MOVE instruction) and then restart the Unit.

Example:



Precautions for Safe Use

When you restart a Special Unit after you change the settings, confirm the safety of the devices at the connection target before you restart the Unit.


Initial Settings for the Motion Control Function Module

This section describes the initial settings that are required for the MC Function Module.

4-5-1 Introduction

The initial settings for the Motion Control Function Module are called motion control parameters. Motion control parameters include the following parameters.

- Axis Parameters: Settings for single-axis control
- Axes Group Parameters: Settings for multi-axes coordinated control




4-5-2 Setting Methods

You can use either of the following methods to set motion control parameters.

Method 1: Setting the Motion Control Setup in the Sysmac Studio

Right-click *Axis Settings* from under **Configurations and Setup - Motion Control Setup** in the Sysmac Studio and make the settings in the Axis Setting Table.



Download the motion control parameters to the CPU Unit to save them in the non-volatile memory in the CPU Unit. The downloaded settings are enabled when the power is turned ON or a download is performed.

Method 2: Setting with the MC_Write Instruction

You can temporarily overwrite some motion control parameters with the MC_Write instruction.

Refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for details.


4-6 **Initial Settings for the EtherCAT Master Function Module**

This section describes the initial settings that are required for the EtherCAT Master Function Module.

The initial settings for the EtherCAT Master Function Module include the following and other items.

- · Device names
- · Total Cable Length
- · Fail-soft Operation Settings
- Wait Time for Slave Startup
- PDO Communications Timeout Detection Count
- · Revision Check Method
- · Serial Number Check Method

Double-click EtherCAT under Configurations and Setup and then select the master on the Sysmac Studio. The Initial Setting Tab Page for the EtherCAT Master Function Module is displayed.



Refer to the NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual (Cat. No. W505) for details.

4-7 Initial Settings for the EtherNet/IP Function Module

This section describes the initial settings that are required for the EtherNet/IP Function Module.

The initial settings for the EtherNet/IP Function Module are listed below.

- TCP/IP Settings
- Link Settings
- FTP Settings
- NTP Settings
- SNMP Settings
- · SNMP Trap Settings
- · FINS Settings

Select Configurations and Setup – Controller Setup – Built-in EtherNet/IP Port Settings on the Sysmac Studio to make these settings.

Refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP User's Manual (Cat. No. W506) for details.



Precautions for Correct Use

For the NX701-□□00, FINS Settings are not provided.

Initial Settings for Built-in I/O

This section describes the initial settings that are required for I/O built in the NX1P2 CPU Units.

The initial settings for the built-in I/O are listed below.

- · Input Filter Setting
- · Load Rejection Output Setting

Select Configurations and Setup - Controller Setup - Built-in I/O Settings on the Sysmac Studio to make these settings.

Refer to the NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual (Cat. No. W579) for details.

4-9 Initial Settings for Option Boards

This section describes the initial settings that are required for Option Boards in the NX1P2 CPU Units.

The initial settings for the Option Boards are listed below.

- Configuration
- Option Board 1 Serial Communications Settings
- Option Board 2 Serial Communications Settings

Select Configurations and Setup – Controller Setup – Option Board Settings on the Sysmac Studio to make these settings.

Refer to the NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual (Cat. No. W579) for details.

4-10 **Memory Settings for CJ-series Units**

This section describes the initial settings that are required for memory used for CJ-series Units in the NX102 CPU Units and NX1P2 CPU Units.

The initial settings for memory for CJ-series Units are listed below. Set whether to enable or disable memory for CJ-series Units and set the memory size when it is enabled.

- CIO
- WR
- HR
- DM
- EM



Additional Information

You cannot use the EM Area for the NX1P2 CPU Units.

Select Configurations and Setup - Controller Setup - Memory Settings on the Sysmac Studio to make these settings.

4-10-1 Setting Procedure


The procedure to make the memory settings for CJ-series Units is described below.

No.	Step	Description	Reference
1	Determining the usable memory	Determine the area type and the number of words of memory used for CJ-series Units to make available for data exchange with connected devices.	Manuals and technical materials for connected devices
2	Memory settings for CJ-series Units	In the Sysmac Studio, set the area type and the number of words of memory used for CJ-series Units to make available for connected devices.	4-10-2 Setting Screen
3	Programming	Create the user program that uses the memory used for CJ-series Units. If the set memory size is not sufficient, return to step 2 and increase the number of words.	Section 6 Programming
4	Downloading the project	Download the project from the Sysmac Studio.	Sysmac Studio Version 1 Operation Manual (Cat. No. W504)
5	Checking operation and actual operation	Check the operation of the user program and connected devices.	Section 7 Checking Operation and Actual Operation

4-10-2 Setting Screen

Specify the memory used for CJ-series Units in the Memory Settings for CJ-series Units Tab Page, which is displayed by selecting **Memory Settings** under **Configurations and Setup - Controller Setup**.

The tab page used to make settings when an NX1P2 CPU Unit is used is shown below.



4-10-3 Settings

For the NX102 CPU Units, the settings are as follows.

Item	Setting group	Setting	Description	Set value	Default	Update timing	Changes in RUN mode
Memory Settings for CJ-series Units	CIO*1	Enable	Enable or disable the generation of CIO area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Num- ber of Words)	Specify the size of memory of area type CIO.	1 to 6,144	6,144	When down- loaded to CPU Unit	Not allowed.
	WR*1	Enable	Enable or disable the generation of WR area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Num- ber of Words)	Specify the size of memory of area type WR.	1 to 512	512	When down- loaded to CPU Unit	Not allowed.
	HR*2	Enable	Enable or disable the generation of HR area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Num- ber of Words)	Specify the size of memory of area type HR.	1 to 1,536	512	When down- loaded to CPU Unit	Not allowed.
	DM*2	Enable	Enable or disable the generation of DM area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Num- ber of Words)	Specify the size of memory of area type DM.	1 to 32,768	4,096	When down- loaded to CPU Unit	Not allowed.
	EM0- EM18*2	Enable	Enable or disable the generation of EM area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Number of Words)	Specify the size of memory of area type EM.	1 to 32,768	32,768	When down-loaded to CPU Unit	Not allowed.

^{*1.} Variables without a Retain attribute are used. The value can be set in 1-word increments.

^{*2.} Variables with a Retain attribute are used. The value can be set in 1-word increments.

For the NX1P2 CPU Units, the settings are as follows.

Item	Setting group	Setting	Description	Set value	Default	Update timing	Changes in RUN mode
Memory Settings for CJ-series Units	CIO*1	Enable	Enable or disable the generation of CIO area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Num- ber of Words)	Specify the size of memory of area type CIO.	1 to 6,144	6,144	When down- loaded to CPU Unit	Not allowed.
	WR*1	Enable	Enable or disable the generation of WR area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Num- ber of Words)	Specify the size of memory of area type WR.	1 to 512	512	When down- loaded to CPU Unit	Not allowed.
	HR*2	Enable	Enable or disable the generation of HR area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Num- ber of Words)	Specify the size of memory of area type HR.	1 to 1,536	512	When down- loaded to CPU Unit	Not allowed.
	DM*2	Enable	Enable or disable the generation of DM area type memory used for CJ-series Units.	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Num- ber of Words)	Specify the size of memory of area type DM.	1 to 16,000	4,096	When down- loaded to CPU Unit	Not allowed.

^{*1.} Variables without a Retain attribute are used. The value can be set in 1-word increments.

^{*2.} Variables with a Retain attribute are used. The value can be set in 1-word increments.



Additional Information

The setting for memory used for CJ-series Units can also be made when you use the NX701-□□20 Units. The settings for memory used for CJ-series Units for an NX701-□□20 Unit are as follows.

Item	Setting group	Setting	Set value	Default	Update timing	Changes in RUN mode
Memory Set- tings for CJ- series Units	CIO*1	Enable	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Number of Words)	1 to 6,144	6,144	When down- loaded to CPU Unit	Not allowed.
	WR*1	Enable	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Number of Words)	1 to 512	512	When down- loaded to CPU Unit	Not allowed.
	HR*2	Enable	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Number of Words)	1 to 1,536	512	When down- loaded to CPU Unit	Not allowed.
	DM*2	Enable	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Number of Words)	1 to 32,768	32,768	When down- loaded to CPU Unit	Not allowed.
	EM0- EM18*2	Enable	Enable Disable	Disable	When down- loaded to CPU Unit	Not allowed.
		Size (Number of Words)	1 to 32,768	32,768	When down- loaded to CPU Unit	Not allowed.

^{*1.} Variables without a Retain attribute are used. The value can be set in 1-word increments.

^{*2.} Variables with a Retain attribute are used. The value can be set in 1-word increments.



Designing Tasks

This section describes the task system and types of tasks.

5-1	Overvi	ew of Task Designing Procedure	. 5-3
5-2	Overvi	ew of Tasks	. 5-6
	5-2-1	Tasks	. 5-6
	5-2-2	Instructions Related to Tasks	. 5-8
	5-2-3	System-defined Variables Related to Tasks	. 5-8
5-3	Specifi	cations and Basic Operation of Tasks for NX701 CPU Units	5-11
	5-3-1	Specifications of Tasks for NX701 CPU Units	.5-11
	5-3-2	Guidelines for Separating Tasks for NX701 CPU Units	5-12
	5-3-3	Basic Operation of Tasks for NX701 CPU Units	
	5-3-4	Event Task Execution Conditions for NX701 CPU Units	5-22
	5-3-5	Event Task Execution Timing for NX701 CPU Units	5-27
	5-3-6	Operation When Execution Condition Is Met Again before Execution of	
		the Event Task Is Completed	5-31
5-4	Specifi	cations and Basic Operation of Tasks for NX102 CPU Units and	
	NX1P2	CPU Units	5-32
	5-4-1	Specifications of Tasks for NX102 CPU Units and NX1P2 CPU Units	5-32
	5-4-2	Guidelines for Separating Tasks for NX102 CPU Units and NX1P2 CPU Units	5-33
	5-4-3	Basic Operation of Tasks for NX102 CPU Units and NX1P2 CPU Units	
	5-4-4	Event Task Execution Conditions for NX102 CPU Units and NX1P2 CPU Units	
	5-4-5	Event Task Execution Timing for NX102 CPU Units and NX1P2 CPU Units	
	5-4-6	Operation When Execution Condition Is Met Again before Execution of	0 40
	0.0	the Event Task Is Completed	5-49
5-5	Specifi	cations and Basic Operation of Tasks for NJ-series Controllers	5-50
	5-5-1	Specifications of Tasks for NJ-series Controllers	5-50
	5-5-2	Guidelines for Separating Tasks for NJ-series Controllers	5-51
	5-5-3	Basic Operation of Tasks for NJ-series Controllers	5-51
	5-5-4	Event Task Execution Conditions for NJ-series Controllers	5-60
	5-5-5	Event Task Execution Timing for NJ-series Controllers	5-65
	5-5-6	Operation When Execution Condition Is Met Again before Execution of the Event Task Is Completed	5-69

5-6	Service	es Other Than Tasks5-70
	5-6-1	Execution Priorities and Execution Orders of Services Other Than Tasks
	5-6-2	Processing Performed in and Execution Timing of the Tag Data Link Service
	5-6-3	Processing Performed in and Execution Timing of the Option Board Service
	5-6-4	Processing Performed in and Execution Timing of the Communications Bridge Service
	5-6-5	Processing Performed in and Execution Timing of the System Services5-82
5-7	Assign	ment and Settings Related to Tasks5-85
	5-7-1	Assigning I/O Refreshing to Tasks5-85
	5-7-2	Assigning Tasks to Programs5-93
	5-7-3	Parameters for Primary Periodic Task and Periodic Tasks
5-8	Ensuri	ng Concurrency of Variable Values5-97
	5-8-1	Ensuring Concurrency of Variable Values between Tasks5-97
	5-8-2	Variable Access from Outside the Controller
5-9	Errors	Related to Tasks5-107
5-10) Monito	ring Task Execution Status and Task Execution Times 5-110
5-11	Task D	esign Methods and I/O Response Times
	5-11-1	Checking the Task Execution Time
	5-11-2	Examples of Task Design
	5-11-3	System Input and Output Response Times

5-1 Overview of Task Designing Procedure

This section provides an overview of the task designing procedure.

The shaded steps in the overall procedure that is shown below are related to the task designing procedure.

Step 1. Software Design

Step 1-1 I/O Processing Design

Step 1-2 Designing Tasks

Step 1-3 Designing Programs



Step 2. Software Setups and Programming

Step 2-1 Slave and Unit Configurations

Step 2-2 Controller Setup

Step 2-3 Programming

Step 2-4 Offline Debugging



Step 3. Mounting and Setting Hardware



Step 4. Wiring



Step 5. Checking Operation and Starting Operation on the Actual System

Refer to 1-3 Overall Operating Procedure for the NJ/NX-series Controller for details.

Designing the Tasks	Reference
Design the task configuration. Design the task configuration based on the I/O response perfor-	5-3-3 Basic Operation of Tasks for NX701 CPU Units
mance that is required by the controlled devices.	5-4-3 Basic Operation of Tasks for NX102 CPU Units and NX1P2 CPU Units
	5-5-3 Basic Operation of Tasks for NJ-series Controllers
	5-11 Task Design Methods and I/O Response Times
 Determine whether to use the primary periodic task, or the priority-5 or priority-16 periodic task for the I/O refreshing of each Unit and slave. 	5-7-1 Assigning I/O Refreshing to Tasks
Devices (slaves/Units) Primary periodic task	
Assign the slaves and Units to the task for I/O refreshing.	
 Determine which programs to assign to the primary periodic task, to the priority-5, priority-16, priority-17, and priority-18 periodic tasks, and to the priority-8 and priority-48 event tasks. 	5-7-2 Assigning Tasks to Programs
 Design the exclusive control methods for variables between tasks. 	5-8-1 Ensuring Con- currency of Variable Values between Tasks
Design the exclusive control methods for variables between tasks when the same global variables are used in different tasks.	
Design the tasks to access variables from outside of the Controller.	5-8-2 Variable Access from Outside the Con- troller
Design the tasks to enable synchronization of accessing variables in the CPU Unit from outside of the Controller with the execution of a program in a specific task. EtherNet/IP tag data links are included in accessing variables.	

Task Settings on the Sysmac Studio

Setting the Tasks	Reference
 Initial Settings for the PLC Function Module: Task Settings: Task Periods, I/O Settings, Program Assignments, Task Interface Settings, and other settings 	4-2 Initial Settings for the PLC Function Mod- ule

Offline Debugging with the Sysmac Studio

Desktop Operation Check	Reference
 Perform desktop debugging of sequence control and motion control with the Simulator (virtual controller). 	Section 7 Checking Operation and Actual Operation
 Monitor the task execution times in the Task Execution Time Monitor Display. 	5-10 Monitoring Task Execution Status and Task Execution Times

Overview of Tasks 5-2

This section provides an overview of tasks.

5-2-1 **Tasks**

Tasks are used to assign an execution condition and execution order to a series of processes, such as I/O refreshing and user program execution.

There are three kinds of tasks, as shown in the following table. They are defined by their execution conditions and execution priorities.

Type of task	Number of tasks	Task execu- tion priority	Definition	Main processing content
Primary periodic task	1	4	The primary periodic task is executed once every task period. It has the highest execution priority.	I/O refreshing, user program execution, and motion control
			Motion control instructions and Ether-CAT communications of the primary periodic task are executed on the primary periodic task period.	
Periodic tasks	0 to 1	5*1	The priority-5 periodic task is executed once every task period. It has the second highest execution priority after the primary periodic task.	I/O refreshing, user pro- gram execution, and motion control
			Motion control instructions and Ether-CAT communications of the priority-5 periodic task are executed on the priority-5 periodic task period.	
	0 to 3	16 ^{*2} , 17, or 18	The priority-16, priority-17, and priority-18 periodic tasks are executed once every task period.	The processing that can be performed depends on the task execution priority.
			Motion control instructions and Ether- CAT communications of the priority-16 periodic task are executed on the pri-	Execution priority 16: I/O refreshing and user program execution
			mary periodic task period.	Execution priority 17 or 18: User program exe- cution
Event tasks	0 to 32	8 or 48	An event task is executed only once when the specified execution condition is met.	User program execution

^{*1} You can use the priority-5 periodic task only with the NX701 CPU Units.

^{*2} You cannot use the priority-16 periodic task with the NX102 CPU Unit or NX1P2 CPU Unit.



Version Information

A CPU Unit with unit version 1.03 or later and Sysmac Studio version 1.04 or higher are required to use event tasks.




Additional Information

With an NX701 CPU Unit, you can execute motion control in the primary periodic task and in the priority-5 periodic task. If these two motion controls need to be identified, the motion control in the primary periodic task is called motion control 1, while the motion control in the priority-5 periodic task is called motion control 2.

Primary Periodic Task and Periodic Tasks

The CPU Unit periodically executes both the primary periodic task and periodic tasks. (The interval in which the CPU Unit executes the primary periodic task or a periodic task is called the task period.)



From 1 to 128 programs can be assigned to one task. The programs that are assigned to a task are executed in the order that they are assigned. Execution of the all of the programs assigned to each task is called user program execution.

Exchanging data with CJ-series Units or EtherCAT slaves is called I/O refreshing.

You can assign I/O refreshing for each slave and Unit to the primary periodic task or the priority-5 or priority-16 periodic task. By default, I/O refreshing for all slaves and Units is assigned to the primary periodic task.

Event Tasks

An event task is executed only once when the specified execution condition is met. There are the following two types of execution conditions for event tasks.

Execution condition	Specification
Execution with an instruction	The event task is executed when the ActEventTask (Execute Event Task) instruction is executed.
Execution when a condition for a variable is met	The event task is executed when the specified variable matches a predefined condition.

From 1 to 128 programs can be assigned to one task. The programs that are assigned to a task are executed in the order that they are assigned.



Precautions for Correct Use

- I/O refreshing and motion control are not executed in event tasks. This means that you cannot
 assign programs to event tasks if the program performs I/O control or executes motion control
 instructions.
- Event tasks are not executed repeatedly every task period. Therefore, you cannot assign a
 program to an event task if that program contains an instruction whose execution is not
 completed within one task period. Instructions that are executed over more than one task
 period include some of the basic instructions, such as instructions for SD Memory Cards and
 communications, all motion control instructions, and all simulation instructions. Refer to the
 NJ/NX-series Instructions Reference Manual (Cat. No. W502) for details on the basic instructions that cannot be used in event tasks.



Additional Information

Tasks operate differently between the NX701 CPU Units, NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units. Refer to 5-3 Specifications and Basic Operation of Tasks for NX701 CPU Units, 5-4 Specifications and Basic Operation of Tasks for NX102 CPU Units and NX1P2 CPU Units, and 5-5 Specifications and Basic Operation of Tasks for NJ-series Controllers for details.

5-2-2 **Instructions Related to Tasks**

The following instructions are supported to read the status of the current task, to determine if execution is in progress for other tasks, and to perform exclusive control for regional concurrency between tasks.

Instruction	Instruction name	Introduction			
GetMyTaskStatus	Read Current Task	Reads the following status of the c	urrent task.		
	Status	Last Task Execution Time, Maximu Task Execution Time, Task Executi Flag, and Task Period Exceeded C	•		
GetMyTaskInterval	Read Current Task Period	Reads the task period of the current task.			
Task_IsActive	Determine Task Status	Determines if the specified task is currently in execution.			
Lock	Lock Tasks	Starts a lock between tasks.	Execution of any other task with a		
Unlock	Unlock Tasks	Stops a lock between tasks.	lock region with the same lock number is disabled.		
ActEventTask	Activate Event Task	Activates the specified event task.			

5-2-3 System-defined Variables Related to Tasks

The following system-defined variables are provided for each task to show task status.

Do not use these variables in the user program. There may be a delay in updating them and concurrency problems in relation to the error status of the Function Module. It is used only to sample the task status for data tracing from the Sysmac Studio.

You can also use the GetMyTaskStatus and Task IsActive instructions to read task status from the user program. You cannot access the following variables directly through system-defined variables.


Variable name	Meaning	Description	Data type	R/W
_TaskName_Active	Task Active Flag	TRUE during task execution.	BOOL	R
		FALSE from the completion of task execution until the end of the task period.		
_ <i>TaskName</i> _LastExecTime	Last Task Execu- tion Time	Gives the last execution time of the task.	TIME	R
_ <i>TaskName</i> _MaxExecTime	Maximum Task Execution Time	Gives the maximum value of the task execution time.	TIME	R
_TaskName_MinExecTime	Minimum Task Execution Time	Gives the minimum value of the task execution time.	TIME	R

Variable name	Meaning	Description	Data type	R/W
_TaskName_ExecCount	Task Execution Count	Contains the number of executions of the task.	UDINT	R
		If the present value exceeds the maximum value of the data type, the present value returns to 0 and the count is continued.		
_TaskName_Exceeded	Task Period Exceeded Flag	TRUE when task execution is completed if the task period is exceeded.	BOOL	R
		FALSE if task execution was completed within the task period.		
_TaskName_ExceedCount	Task Period Exceeded Count	Contains the number of times that the task period was exceeded.	UDINT	R
		If the present value exceeds the maximum value of the data type, the present value returns to 0 and the count is continued.		

Note Example: The Task Period Exceeded Flag for the task named MainTask is _MainTask_Exceeded.


Flag Operation

Task Active Flag (_TaskName_Active)



^{*} When the ActEventTask instruction is used to execute an event task, the Task Active Flag changes to TRUE.

• Task Period Exceeded Flag (_TaskName_Exceeded)



5-3 Specifications and Basic Operation of Tasks for NX701 CPU Units

This section describes the specifications and basic operation of tasks for the NX701 CPU Units with a multi-core processor.

5-3-1 Specifications of Tasks for NX701 CPU Units

The specifications of tasks are given in the following table.

Item	Specification
Type of task	Primary periodic task
	Periodic task (priority 5, 16, 17, or 18)
	Event task (priority 8 or 48)
Numbers of tasks	Primary periodic task: 1
	Periodic tasks: 0 to 4 tasks*1
	Event tasks: 0 to 32 tasks*2
Number of programs per task	128 max.
Task period of the primary periodic task	125 μs
	250 μs to 8 ms (in 250-μs increments)
Task periods of periodic tasks	• Priority 5 125 μs 250 μs to 100 ms (in 250 μs increments)
	250 μs to 100 ms (in 250-μs increments)
	• Priority 16, 17, or 18 1 ms to 100 ms (in 250-μs increments)
	Set the task period of each periodic task to an integer multiple of the task period of the primary periodic task.
	You cannot select any combination of task periods whose least common multiple exceeds 600 ms.

^{*1} There can be no more than one task with each of the following execution priorities: 5, 16, 17, and 18.

^{*2} There can be up to 32 tasks with each of the following priorities as long as there are no more than a total of 32 tasks with these priorities: 8 and 48.



Precautions for Correct Use

Do not set the task period of primary periodic task to 4 ms or more when you use the priority-5 periodic task. If you set the task period to 4 ms or more, a Slave Application Error may occur.

Guidelines for Separating Tasks for NX701 CPU Units 5-3-2

All programs must be assigned to one of the tasks. Use the guidelines in the following table to determine which tasks to assign your programs to based on the requirements of the programs.

Task	Programs that are suitable for this task
Primary periodic task	Programs that require periodic I/O refreshing, user program execution, motion control, or system common processing at an exact execution period.
	Programs that require the highest execution priority and contain controls that need high-speed response.
	Programs that contain motion control instructions with the highest execution priority.
Priority-5 periodic task	Programs that require periodic I/O refreshing, user program execution, motion control, or system common processing at an exact execution period.
	Programs that require the second highest execution priority after the primary periodic task and contain controls that need high-speed response.
	Programs that contain motion control instructions with a relatively high execution priority.
	Programs used for applications where the processes that require the highest-speed processing are controlled with the primary periodic task and the rest is controlled separately with the priority-5 periodic task.
Priority-16 periodic task	Programs with a relatively low execution priority that require periodic user program execution or system common processing.
	Programs that contain controls for some slaves and Units whose I/O refreshing is assigned to the primary periodic task.
	Programs that contain motion control instructions with a relatively low execution priority.
	Programs used for applications where, among the processes for slaves and Units controlled with the primary periodic task, those with a relatively low execution priority are controlled separately with the priority-16 periodic task.
Priority-17 or priority-18 periodic task	Programs with a relatively low execution priority that require periodic user program execution or system common processing.
	Programs that contain data processing and communications processing controls that do not need high-speed response.
Event task	Programs that are executed only when specified conditions are met.

5-3-3 **Basic Operation of Tasks for NX701 CPU Units**

With a multi-core processor, the NX701 CPU Units can execute the primary periodic task and the priority-5 periodic task in parallel. The order in which tasks are executed depends on the execution priority that is set for each task.



Additional Information

With an NX701 CPU Unit, you can execute multiple tasks, the tag data link service, and system services in parallel.


Task Execution Priority

The type of the task determines its execution priority. The CPU Unit executes the task with the highest execution priority first.

If the execution condition is met for another task, Tb, that has a higher execution priority while task Ta execution is in progress, the NX-series CPU Unit will assign Tb to the available core for processing on a priority basis.

The execution priority for each task type is given in the following table. The smaller the value of the execution priority, the higher the priority.

Task	Execution pri- ority	Tasks with the same execution priority
Primary periodic task	4	
Periodic task	5, 16, 17, or 18	You cannot set the same execution priority for more than one task.
Event task	8 or 48	You can set the same execution priority for more than one event task. Refer to 5-3-5 Event Task Execution Timing for NX701 CPU Units for the order of execution.



Task Periods for the Primary Periodic Task and Periodic Tasks

The CPU Unit repeatedly and cyclically executes the primary periodic task and periodic tasks. The task periods for periodic tasks must be assigned as integer multiples of the task period of the primary periodic task (called the primary period). Therefore, execution of both tasks will start at the same time every few cycles.

For example, if the primary period is set to 1 ms and the task period of the priority-16 periodic task is set to 4 ms, the execution timing of the primary periodic task and the priority-16 periodic task is synchronized after each four executions of the primary periodic task.



Additional Information


An event task is not executed periodically. Instead, it is executed only once when the specified execution condition is met. Therefore, execution of an event task depends on when its execution condition is met and on its execution priority.

Examples of Execution Order for Tasks

This section gives a few examples of the execution order for the primary periodic task and periodic tasks. Refer to 5-3-5 Event Task Execution Timing for NX701 CPU Units for the order of execution of event tasks.

Projects with Only the Primary Periodic Task

The primary periodic task is executed every primary period. The system service shown in this figure refers to non-task related processing, such as communications processing, that is performed by the CPU Unit. System services are executed in the unused time between execution of the tasks. Refer to Processing Performed in System Services on page 5-82 for details on the system services.




Project with the Primary Periodic Task, Priority-5 Periodic Task, Priority-16 Periodic Task, and Priority-17 Periodic Task

• The tasks are classified into the following two groups and executed.

Group	Type of task
Group 1	Primary periodic task
	Priority-16 periodic task
Group 2	Periodic task (priority 5, 17, or 18)
	Event task (priority 8 or 48)

- Each task in the same group is preferentially executed in descending order of execution priority.
- The primary periodic task has the highest execution priority, so it is always executed in the primary period.
- The priority-5 periodic task is executed in parallel with the primary periodic task.
- The priority-16 periodic task is executed after completion of the primary periodic task.
- The priority-17 periodic task has a lower execution priority than the priority-5 periodic task, so it is executed when the priority-5 periodic task is not being executed.
- In this example, the task period for the priority-5 periodic task is set to twice the primary period.
 Also, the task period for the priority-16 periodic task is set to four times the primary period. This
 means that the timing at which execution of a task starts coincides with that of the primary periodic
 task once every two primary periods for the priority-5 periodic task and once every four primary
 periods for the priority-16 periodic task.
- The system services are executed at the required time without being affected by the tasks.





Precautions for Correct Use

If you have multiple tasks that read and write to the same variables, make sure to use exclusive control of variables between the tasks. Otherwise, a task other than the one currently in execution may change the variable values. Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details.

Tasks and Operating Modes

The relationship between CPU Unit operating modes and tasks is given in the following table.

Task	Specification
Primary periodic task	These tasks are executed in both RUN mode and PROGRAM mode.
Periodic tasks	The user program is executed only in RUN mode.
Event tasks	Event tasks are executed only in RUN mode.



Precautions for Correct Use


- · Even if the execution condition for an event task is already met when you change the operating mode to RUN mode, the event task will not be executed. An event task is executed only when its execution condition changes from not met to met during RUN mode.
- Even in RUN mode, an event task is not executed if there is a major fault level error.

The Processing Performed in Each Task

Primary Periodic Task

The primary periodic task has the highest execution priority. It executes processes with high speed and high precision.

In the specified period, this task performs system common processing, I/O refreshing, user program execution, and motion control.



- *1: Task period
- *2: Task execution time

The CPU Unit executes tasks in this fixed period. This is a preset, fixed time.


This is the actual time it takes from the point that the execution condition is met until execution is completed.

Proc	essing	Processing contents
I/O refresh- ing	Output data processing	 Output refresh data is created for Output Units that refresh I/O. If forced refreshing is set, the forced refreshing values are reflected in the output refresh data.
	Refreshing	This process exchanges data with I/O.
	Input data processing	 Whether the condition expression for event task execution is met or not is determined Input refresh data is loaded from Input Units that refresh I/O. If forced refreshing is set, the forced refreshing values are reflected in the input refresh data that was read.
System common processing 1		Processing for exclusive control of variables in tasks is performed (when access ing tasks are set).
		Motion input processing is performed.*1
		Data trace processing (sampling and trigger checking) is performed.
User progran	n execution	Programs assigned to tasks are executed in the order that they are assigned.
Motion control*2		The motion control commands from the motion control instructions in the user program assigned to the primary periodic task and the priority-16 periodic task are executed.
		Processing the motion outputs for I/O refreshing in the next primary periodic task
System common processing 2		Processing for exclusive control of variables in tasks is performed (when refresh ing tasks are set).
		Processing for variables accessed from outside of the Controller is performed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
		If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.

^{*1} The Axis Current Values (Position, Velocity, and Torque) and Drive Status in the system-defined variables for motion control are updated.

Note The processes in each cell in the above table are executed in the order of description.

^{*2} When there are motion control instructions in user program execution in the primary periodic task, the CPU Unit executes the results from those instructions immediately afterward in motion control processing as shown below. The CPU Unit outputs the results to the Servo Drives during I/O refreshing in the next primary periodic task.



When there is a motion control instruction in user program execution in the priority-16 periodic task, the CPU Unit executes the result from that instruction in the motion control processing (MC) of the next primary periodic task.


Refer to 5-11-3 System Input and Output Response Times for details.

Priority-5 Periodic Task

The priority-5 periodic task has the next highest execution priority after the primary periodic task. It executes processes with high speed and high precision.

In every period, this task performs system common processing, I/O refreshing, user program execution, and motion control.

The priority-5 periodic task is available only for the NX701 CPU Units.




F	Processing	Processing contents
I/O	Output data pro-	Output refresh data is created for Output Units that refresh I/O.
refreshing	cessing	If forced refreshing is set, the forced refreshing values are reflected in the output refresh data.
	Refreshing	This process exchanges data with I/O.
	Input data process-	Input refresh data is loaded from Input Units that refresh I/O.
	ing	If forced refreshing is set, the forced refreshing values are reflected in the input refresh data that was read.
System common processing 1		Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).
		Motion input processing is performed.*1
		Data tracing processing (sampling and trigger checking) is performed.
User progr	am execution	Programs assigned to tasks are executed in the order that they are assigned.
Motion control*2		The motion control commands from the motion control instructions in the user program assigned to the priority-5 periodic task are executed.
		Processing the motion outputs for I/O refreshing in the next priority-5 periodic task.

Processing	Processing contents
System common processing 2	Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).
	 Processing for variables accessed from outside of the Controller is per- formed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
	 If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.

- *1 The Axis Current Values (Position, Velocity, and Torque) and Drive Status in the system-defined variables for motion control is updated.
- *2 When there are motion control instructions in user program execution in the priority-5 periodic task, the CPU Unit executes the results from those instructions immediately afterward in motion control processing as shown below. The CPU Unit outputs the results to the Servo Drives during I/O refreshing in the next priority-5 periodic task.

Note The processes in each cell in the above table are executed in the order of description.




Priority-16, Priority-17, or Priority-18 Periodic Task

A periodic task executes its programs every task period. The task period is specified as an integer multiple of the primary period. You can use 0 to 3 periodic tasks.

The priority-16 periodic task allows you to write control programs for the slaves and Units for which you set the priority-16 periodic task in the I/O Control Task Settings.

Processing for periodic tasks that do not control I/O is different from processing for periodic tasks that do control I/O.


Periodic Tasks That Do Not Control I/O



Processing	Processing contents
System common processing 1	 Processing for exclusive control of variables in tasks is performed (when accessing tasks are set). Data trace processing (sampling and trigger checking) is performed.
User program execution	Programs assigned to tasks are executed in the order that they are assigned.
System common processing 2	Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).
	 Processing for variables accessed from outside of the Controller is per- formed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
	If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.

Note The processes in each cell in the above table are executed in the order of description.

Priority-16 Periodic Task That Controls I/O



Processing	Processing contents
System common processing 1	Reflecting the input refresh data.*1
	Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).
	Data tracing processing (sampling and trigger checking) is performed.
User program execution	Programs assigned to tasks are executed in the order that they are assigned.
System common processing 2	Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).
	Processing for variables accessed from outside of the Controller is performed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
	If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.
	Reflecting the execution results in the output refresh data.*2


^{*1} This loads the input refresh data from the EtherCAT slaves for which you set the priority-16 periodic task in the I/O Control Task Settings. Input refresh data refers to the data that is input in process data communications during I/O refreshing in the primary periodic task.

Note The processes in each cell in the above table are executed in the order of description.

^{*2} This reflects the execution results of the user program for the EtherCAT slaves for which you set the priority-16 periodic task in the I/O Control Task Settings in the output refresh data. The output refresh data will be output in process data communications during I/O refreshing in the primary periodic task.

Event Tasks

An event task is executed only once when the specified execution condition is met. You can use 0 to 32 event tasks. The processing details for event tasks are shown in the following figure.



The Controller may pause the execution of a task in order to execute a task with a higher execution priority.

In the rest of this manual, description of tasks in the NX-series CPU Unit will not refer to the pausing task scenario.

Processing	Processing contents	
System common processing 1	 Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).*1 	
User program execution	Programs assigned to tasks are executed in the order that they are assigned.	
System common processing 2	 Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).*1 	

^{*1} Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details on exclusive control.

5-3-4 **Event Task Execution Conditions for NX701 CPU Units**

An event task is executed only once when the specified execution condition is met. There are the following two types of execution conditions for event tasks.

Execution condition	Event task execution timing	Reason for use
Execution with the ActEvent- Task instruction	When ActEventTask instruction is executed	When you need to explicitly specify which event tasks to execute in the user program When the execution condition for the event task may change before meeting the condition expression for the variable is determined
Execution when a condition expression for a variable is met	When the specified variable value matches the specified condition expression*	When you want to simplify the user program by executing event tasks without user programming

Refer to Execution Timing When the Execution Condition Is a Condition Expression for a Variable on page 5-28 for the timing of when the value of the specified variable is checked to see if the specified condition expression is met.



Precautions for Safe Use

If the following variables are specified for a condition expression when the execution condition is a condition expression for a variable, event tasks may not be executed when conditions are met or event tasks may be executed when conditions are not met.

- Structure members whose data size is 16 bits or more, except for system-defined variables for motion control
- Array elements whose data size is 16 bits or more

When the above variables are specified and the match evaluation is performed, perform either of the followings.

- Copy the above variables to the internal variables with a basic data type other than a data size of 64 bits, and access the copied internal variables.
- Use the settings for exclusive control of variables in tasks, and set the primary periodic task as a refreshing task.


Executing Event Tasks for the ActEventTask Instruction

When the ActEventTask (Execute Event Task) instruction is executed in the user program, the specified event task is executed once. Refer to the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for the detailed specifications of the ActEventTask instruction.

Using the ActEventTask instruction to execute event tasks makes it easy to see which event tasks are executed. Also, this method is also effective when the execution condition for the event task may change before meeting the condition expression for the variable is determined.


Example of User Programming Using the ActEventTask Instruction


Example 1: Executing an Event Task Only Once When the Value of a Variable Changes In the following example, the upward differentiation option is used for the ActEventTask instruction. This causes the Task1 event task to be executed only once when the BoolVar BOOL variable changes to TRUE.



Example 2: Executing an Event Task Repeatedly While the Value of a Variable Matches a Specified Value

In the following example, the upward differentiation option is not used for the ActEventTask instruction. This causes the Task1 event task to be executed as long as the *BoolVar* BOOL variable is TRUE. Any ActEventTask instructions that specify Task1 will be ignored if Task1 is already in execution. After the execution of the event task has started, it is executed to the end even if the value of *BoolVar* changes to FALSE during execution.





Executing Event Tasks When Condition Expressions for Variables Are Met

This method executes the event task once when the specified condition expression is met for the value of a variable that was specified on the Sysmac Studio. The event task is not executed repeatedly while the value of the variable matches the condition expression. It is executed only once when the value of the variable first changes so that it meets the condition expression. This method of execution does not require user programming to execute the event task.

Variables for Which You Can Specify Condition Expressions

The following table lists the variables that you can specify for condition expressions.

Type of variables		Specification
System-defined variables		Possible.*1
Semi-user-defined variables		Possible.
User-defined variables	Global variables	Possible.
	Variables used in a program	Possible.
	Variables used in a function block	Possible.*2
	Variables used in a function	Not possible.

^{*1} The following variables cannot be used. EN, ENO, P Off, P CY, P First RunMode, P First Run and P PRGER

Data Types of Variables for Condition Expressions

The following table lists the data types of variables that you can specify for condition expressions.

Classification of data type	Data type		Specification
	Boolean, bit string, in	teger, and real	Possible.
Basic data types	Duration, date, time of day, date and time, or text string data		Not possible.
Data type specifica-	Array specification	Arrays	Not possible.
tions		Elements	Possible.*1
Derivative data type	Structures	Structures	Not possible.
		Members	Possible.*2
	Unions	Unions	Not possible.
		Members	Possible.*2
	Enumerations		Possible.

^{*1} The elements of the array must be Boolean variables, bit strings, integer data, or real data.

^{*2} In-out variables cannot be used.

^{*2} The members must be Boolean, bit strings, integer data, or real data.

Condition Expressions That You Can Specify

The condition expressions that you can specify depend on the data type of the variable that you specify for the condition expression. If the variable that you specify for a condition expression is bit string data, integer data, or real data, you must set a comparison constant to compare to the value of the variable.

Data type	Possible condition expressions
Boolean, Boolean array elements, Boolean structure members,	Change to TRUE
and Boolean union members	Change to FALSE
Bit string, real number, integer, as well as array element, struc-	Variable = {Comparison constant}
ture member, or union member with one of those data types	Variable ≠ {Comparison constant}
	Variable > {Comparison constant}
	Variable ≥ {Comparison constant}
	Variable < {Comparison constant}
	Variable ≤ {Comparison constant}

Valid Range of Comparison Constants


If the variable that you specify for a condition expression is bit string data, integer data, or real data, you must set a comparison constant to compare to the value of the variable. The valid range of comparison constants is the same as the valid range of the data type of the variable that you specify for the condition expression.

Refer to *Basic Data Types and Derivative Data Types* on page 6-30 for the valid range of values for each data type. For example, if the variable that you specify for the condition expression is a BYTE variable, the valid range of comparison constant values is from BYTE#16#00 to BYTE#16#FF.


Example of Executing Event Tasks When Condition Expressions for Variables Are Met

Example 1: Execution Condition for Event Task Set to a Change to TRUE of the *Program1.trigger1*Boolean Variable

When the value of *Program1.trigger1* changes to TRUE, the event task is executed only once.



Example 2: Execution Condition for an Event Task Set to When *Program1.curVal* (INIT variable) ≥ 10 The event task is executed only once when the value of Program1.curVal changes from less than 10 to 10 or higher.





Precautions for Correct Use

If the value of a specified variable changes in the primary periodic task, the CPU Unit evaluates whether the condition expression is met in the next primary periodic task. This means that the event task will be executed on completion of this evaluation against the condition expression in the next primary periodic task after the CPU Unit evaluates that the condition expression is met.

5-3-5 Event Task Execution Timing for NX701 CPU Units

The execution priority of event tasks is 8 or 48. With a multi-core processor, the NX701 CPU Units execute event tasks for which the execution condition is met according to the task execution priority. Depending on the user program, however, the CPU Unit may execute an event task in parallel with the primary periodic task, periodic tasks, or other event tasks with different execution priorities.

If you have multiple tasks that read and write to the same variables, make sure to use the following functions to control how an event task is executed with the primary periodic task, periodic tasks, or other event tasks with different execution priorities.

Purpose	Function to use
Accessing the same global variable from an event task	Exclusive control of variables in tasks
and from another task	Settings for exclusive control of variables in tasks
	Lock (Lock Tasks) instruction
	Unlock (Unlock Tasks) instruction
Checking the execution status of other tasks	Task_IsActive (Determine Task Status) instruction

Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details.

The execution of an event task also depends on its execution conditions. You can also set the same execution priority for more than one event task. You must be careful when the execution conditions are met for more than one event task that has the same execution priority.


Differences in Execution Timing Based on the Execution Conditions of Event Tasks

The execution timing for event tasks depends on whether the execution condition is triggered by an ActEventTask instruction or by when a condition expression for a variable is met.


Execution Timing When the Execution Condition Is an ActEventTask Instruction

If the execution condition for an event task is triggered by an ActEventTask instruction, the event task execution condition will be met immediately after the ActEventTask instruction is executed. The NX-series CPU Unit executes event tasks for which the execution condition is met according to the task execution priority.

Example 1: Executing an Event Task with an Execution Priority Higher Than the Task That Executes an Instruction



Example 2: Executing an Event Task with an Execution Priority Lower Than the Task That Executes an Instruction




The event task execution condition is met immediately after the ActEventTask instruction is executed.


Execution Timing When the Execution Condition Is a Condition Expression for a Variable

The condition expression is evaluated for a match inside the primary periodic task. The execution condition for an event task is met when it is evaluated to match the condition expression. The NXseries CPU Unit executes event tasks for which the execution condition is met according to the task execution priority.

Example 1: Project with a Priority-16 Periodic Task and an Event Task Execution with a Priority of 8



Example 2: Project with a Priority-16 Periodic Task and an Event Task Execution with a Priority of 48





Precautions for Correct Use

• For the NX701 CPU Units, the timing at which the execution condition for an event task is met is the same regardless of whether the condition expression match is triggered by I/O refreshing in the primary periodic task, or by execution of a program that is assigned to the primary periodic task. This difference is described in the following table.

Trigger for condition expression to match	Timing at which the execution condition for an event task is met
I/O refreshing in the primary periodic task	Evaluation in the next primary periodic task
Execution of the programs in the primary periodic task	Evaluation in the next primary periodic task


- In order for an event task to be executed, the condition expression must be met in the evaluation after the previous evaluation where the condition expression was not met. This means that even if the status of the condition expression changes from not met to met, if the condition returns to not met before the next evaluation, the event task will not be executed.
- For an NX701 CPU Unit, specify an internal variable defined in the program that is assigned to
 the primary periodic task if you specify an internal variable with a data size of 64 bits or more
 to the condition expression. If an internal variable that is not defined in the primary periodic
 task is specified, the concurrency of variable values may not be ensured. As the result, the
 match evaluation may not be correctly performed.

Execution Timing for Event Tasks with the Same Execution Priority

You can also set the same execution priority for more than one event task. If the execution conditions for more than one event task with the same execution priority are triggered by an ActEventTask instruction, the event tasks will be executed in the order that the instruction is executed.

Example 1: When Two ActEventTask Instructions Are Executed

In the example given below, two ActEventTask instructions are used to execute two event tasks. The T1 event task is executed before the T2 event task because the ActEventTask instruction that triggered T1 was executed first.




Example 2: When Both Condition Expressions for Variables and the ActEventTask Instruction Are Used In this example, the execution conditions of the T1, T2, and T3 event tasks are set as given below.

- T1: Condition expression for the VarA variable
- T2: Condition expression for the VarB variable
- T3: ActEventTask instruction


The operation would proceed as described below if the condition expression for VarA was met during I/O refreshing, the ActEventTask instruction was executed in the user program, and the condition expression for VarB was met during execution of the user program all in the same primary period.


- (1) The condition expression for VarA is met during I/O refreshing.
- (2) The condition expression for *VarB* is met during execution of the user program.
- (3) At this point, T1 and T2 are not executed because the condition expressions are not yet evaluated.
- (4) The ActEventTask instruction is executed in the user program, so T3 is executed.
- (5) When I/O refreshing is executed in the primary periodic task, the match is detected that the condition expressions for VarA and VarB are met, so T1 and T2 are executed. If the match is detected that more than one condition expression is met in the same execution period, the order of execution of event tasks is undefined. The following figure shows an example when T1 is executed first.



5-3-6 Operation When Execution Condition Is Met Again before Execution of the Event Task Is Completed

If the execution condition for an event task is met again before the execution of that event task is completed, the second match of the execution condition is ignored. "Before an event task is completed" includes the duration of execution of the event task and the time waiting for execution. After the execution of the event task has started, it is executed to the end even if the condition expression is no longer met.





Specifications and Basic Operation of Tasks for NX102 CPU Units and **NX1P2 CPU Units**

This section describes the specifications and basic operation of tasks for the NX102 CPU Units and NX1P2 CPU Units with a multi-core processor.

Specifications of Tasks for NX102 CPU Units and NX1P2 CPU 5-4-1 **Units**

The specifications of tasks are given in the following table.

Item	Specification
Type of task	Primary periodic task
	Periodic task (priority 17 or 18)
	Event task (priority 8 or 48)
Numbers of tasks	Primary periodic task: 1
	Periodic tasks: 0 to 2 tasks*1
	Event tasks: 0 to 32 tasks*2
Number of programs per task	128 max.
Task period of the primary periodic task	NX102 CPU Units: 1 ms to 32 ms (in 250-µs increments)
	NX1P2 CPU Units: 2 ms to 8 ms (in 250-µs increments)
Task periods of periodic tasks	Priority 17 or 18 NX102 CPU Units: 1 ms to 100 ms (in 250-µs increments) NX1P2 CPU Units: 2 ms to 100 ms (in 250-µs increments)
	Set the task period of each periodic task to an integer multiple of the task period of the primary periodic task. You cannot select any combination of task periods whose least common multiple exceeds 600 ms.

^{*1} There can be no more than one task with each of the following execution priorities: 17and 18.

^{*2} There can be up to 32 tasks with each of the following priorities as long as there are no more than a total of 32 tasks with these priorities: 8 and 48.

5-4-2 Guidelines for Separating Tasks for NX102 CPU Units and NX1P2 CPU Units

All programs must be assigned to one of the tasks. Use the guidelines in the following table to determine which tasks to assign your programs to based on the requirements of the programs.

Task	Programs that are suitable for this task
Primary periodic task	Programs that require periodic I/O refreshing, user program execution, motion control, or system common processing at an exact execution period.
	Programs that require the highest execution priority and contain controls that need high-speed response.
	Programs that contain motion control instructions with the highest execution priority.
Priority-17 or priority-18 periodic task	Programs with a relatively low execution priority that require periodic user program execution or system common processing.
	Programs that contain data processing and communications processing controls that do not need high-speed response.
Event task	Programs that are executed only when specified conditions are met.

5-4-3 Basic Operation of Tasks for NX102 CPU Units and NX1P2 CPU Units

The NX102 CPU Units and NX1P2 CPU Units cannot execute more than one task at the same time. The order in which tasks are executed depends on the execution priority that is set for each task.




Additional Information

- With an NX102 CPU Unit, you can execute the communications bridge service, tag data link service and system services without being affected by the task execution.
- With an NX1P2 CPU Unit, you can execute the tag data link service, option board service, and system services without being affected by the task execution.

Task Execution Priority

The type of the task determines its execution priority. If the execution condition is met for another task, Tb, that has a higher execution priority while task Ta execution is in progress, execution of Ta will be interrupted to allow execution of Tb. Processing for Ta will resume when processing for Tb is completed. The execution priority for each task type is given in the following table. The smaller the value of the execution priority, the higher the priority.

Task	Execution priority	Tasks with the same execution priority
Primary periodic task	4	
Periodic task	17 or 18	You cannot set the same execution priority for more than one task.
Event task	8 or 48	You can set the same execution priority for more than one event task. Refer to 5-4-5 Event Task Execution Timing for NX102 CPU Units and NX1P2 CPU Units for the order of execution.



Task Periods for the Primary Periodic Task and Periodic Tasks

The CPU Unit repeatedly and cyclically executes the primary periodic task and periodic tasks. The task periods for periodic tasks must be assigned as integer multiples of the task period of the primary periodic task (called the primary period). Therefore, execution of both tasks will start at the same time every few cycles.

For example, if the primary period is set to 2 ms and the task period of the priority-17 periodic task is set to 8 ms, the execution timing of the primary periodic task and the priority-17 periodic task is synchronized after each four executions of the primary periodic task.



Additional Information


An event task is not executed periodically. Instead, it is executed only once when the specified execution condition is met. Therefore, execution of an event task depends on when its execution condition is met and on its execution priority.

Examples of Execution Order for Tasks

This section gives a few examples of the execution order for the primary periodic task and periodic tasks. Refer to 5-4-5 Event Task Execution Timing for NX102 CPU Units and NX1P2 CPU Units for the order of execution of event tasks.


Projects with Only the Primary Periodic Task

The primary periodic task is executed every primary period. The system service shown in this figure refers to non-task related processing, such as communications processing, that is performed by the CPU Unit. Refer to *Processing Performed in System Services* on page 5-82 for details on the system services.



Project with the Primary Periodic Task and Priority-17 Periodic Task

- The primary periodic task has the highest execution priority, so it is always executed in the primary period.
- The priority-17 periodic task has a lower execution priority than the primary periodic task, so it is executed when the primary periodic task is not being executed.
- In this example, the task period for the priority-17 periodic task is set to four times the primary period. This means that execution of the priority-17 periodic task will start at the same time once every four primary periods.
- The system services are executed at the required time without being affected by the tasks.





Precautions for Correct Use

If you have multiple tasks that read and write to the same variables, make sure to use exclusive control of variables between the tasks. Otherwise, a task other than the one currently in execution may change the variable values. Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details.

Tasks and Operating Modes

The relationship between CPU Unit operating modes and tasks is given in the following table.

Task	Specification
Primary periodic task	These tasks are executed in both RUN mode and PROGRAM mode.
Periodic tasks	The user program is executed only in RUN mode.
Event tasks	Event tasks are executed only in RUN mode.



Precautions for Correct Use


- Even if the execution condition for an event task is already met when you change the operating mode to RUN mode, the event task will not be executed. An event task is executed only when its execution condition changes from not met to met during RUN mode.
- Even in RUN mode, an event task is not executed if there is a major fault level error.

The Processing Performed in Each Task

Primary Periodic Task

The primary periodic task has the highest execution priority. It executes processes with high speed and high precision.

In the specified period, this task performs system common processing, I/O refreshing, user program execution, and motion control.



- *1: Task period
- *2: Task execution time


The CPU Unit executes tasks in this fixed period. This is a preset, fixed time.

This is the actual time it takes from the point that the execution condition is met until execution is completed.

Processing		Processing contents
I/O refresh- ing	Output data processing	 Output refresh data is created for Output Units that refresh I/O. If forced refreshing is set, the forced refreshing values are reflected in the output
ing processing	refresh data.	
	Refreshing	This process exchanges data with I/O.
	Input data	Whether the condition expression for event task execution is met or not is determined.
	processing	Input refresh data is loaded from Input Units that refresh I/O.
		If forced refreshing is set, the forced refreshing values are reflected in the input refresh data that was read.
System comr	non process-	Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).
		Motion input processing is performed.*1
		Data trace processing (sampling and trigger checking) is performed.
User progran	n execution	Programs assigned to tasks are executed in the order that they are assigned.
Motion control*2		The motion control commands from the motion control instructions in the user program assigned to the primary periodic task are executed.
		Processing the motion outputs for I/O refreshing in the next primary periodic task.
System common processing 2		Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).
		Processing for variables accessed from outside of the Controller is performed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
		If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.


^{*1} The Axis Current Values (Position, Velocity, and Torque) and Drive Status in the system-defined variables for motion control are updated.

^{*2} When there are motion control instructions in user program execution in the primary periodic task, the CPU Unit executes the results from those instructions immediately afterward in motion control processing as shown below. The CPU Unit outputs the results to the Servo Drives during I/O refreshing in the next primary periodic task.



Priority-17 or Priority-18 Periodic Task


A periodic task executes its programs every task period. The task period is specified as an integer multiple of the primary period. You can use 0 to 2 periodic tasks.



Processing	Processing contents
System common processing 1	Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).
	Data trace processing (sampling and trigger checking) is performed.
User program execution	Programs assigned to tasks are executed in the order that they are assigned.
System common processing 2	Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).
	 Processing for variables accessed from outside of the Controller is per- formed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
	If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.

Event Tasks

An event task is executed only once when the specified execution condition is met. You can use 0 to 32 event tasks. The processing details for event tasks are shown in the following figure.



^{*} The CPU Unit will temporarily interrupt the execution of a task in order to execute a task with a higher execution priority.

Task execution condition is met.

Processing	Processing contents
System common processing 1	 Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).*1
User program execution	Programs assigned to tasks are executed in the order that they are assigned.
System common processing 2	 Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).*1

^{*1} Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details on exclusive control.

5-4-4 Event Task Execution Conditions for NX102 CPU Units and NX1P2 CPU Units

An event task is executed only once when the specified execution condition is met. There are the following two types of execution conditions for event tasks.

Execution condition	Event task execution timing	Reason for use	
Execution with the ActEvent- Task instruction	When ActEventTask instruction is executed	 When you need to explicitly specify which event tasks to execute in the user program When the execution condition for the event task may change before meeting the condition expression for the variable is determined 	
Execution when a condition expression for a variable is met	When the specified variable value matches the specified condition expression*	When you want to simplify the user program by executing event tasks without user programming	

^{*} Refer to Execution Timing When the Execution Condition Is a Condition Expression for a Variable on page 5-28 for the timing of when the value of the specified variable is checked to see if the specified condition expression is met.



Precautions for Safe Use

If the following variables are specified for a condition expression when the execution condition is a condition expression for a variable, event tasks may not be executed when conditions are met or event tasks may be executed when conditions are not met.

- · Structure members whose data size is 16 bits or more, except for system-defined variables for motion control
- · Array elements whose data size is 16 bits or more

When the above variables are specified and the match evaluation is performed, perform either of the followings.

- · Copy the above variables to the internal variables with a basic data type other than a data size of 64 bits, and access the copied internal variables.
- Use the settings for exclusive control of variables in tasks, and set the primary periodic task as a refreshing task.


Executing Event Tasks for the ActEventTask Instruction

When the ActEventTask (Execute Event Task) instruction is executed in the user program, the specified event task is executed once. Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for the detailed specifications of the ActEventTask instruction.

Using the ActEventTask instruction to execute event tasks makes it easy to see which event tasks are executed. Also, this method is also effective when the execution condition for the event task may change before meeting the condition expression for the variable is determined.


Example of User Programming Using the ActEventTask Instruction


Example 1: Executing an Event Task Only Once When the Value of a Variable Changes In the following example, the upward differentiation option is used for the ActEventTask instruction. This causes the Task1 event task to be executed only once when the *BoolVar* BOOL variable changes to TRUE.



Example 2: Executing an Event Task Repeatedly While the Value of a Variable Matches a Specified Value

In the following example, the upward differentiation option is not used for the ActEventTask instruction. This causes the Task1 event task to be executed as long as the BoolVar BOOL variable is TRUE. Any ActEventTask instructions that specify Task1 will be ignored if Task1 is already in execution. After the execution of the event task has started, it is executed to the end even if the value of BoolVar changes to FALSE during execution.





Executing Event Tasks When Condition Expressions for Variables Are Met

This method executes the event task once when the specified condition expression is met for the value of a variable that was specified on the Sysmac Studio. The event task is not executed repeatedly while the value of the variable matches the condition expression. It is executed only once when the value of the variable first changes so that it meets the condition expression. This method of execution does not require user programming to execute the event task.

Variables for Which You Can Specify Condition Expressions

The following table lists the variables that you can specify for condition expressions.

	Type of variables	Specification
System-defined variables		Possible.*1
Semi-user-defined variables		Possible.
User-defined variables	Global variables	Possible.
	Variables used in a program	Possible.
	Variables used in a function block	Possible.*2
	Variables used in a function	Not possible.

The following variables cannot be used. EN, ENO, P_Off, P_CY, P_First_RunMode, P_First_Run and P PRGER

^{*2} In-out variables cannot be used.

• Data Types of Variables for Condition Expressions

The following table lists the data types of variables that you can specify for condition expressions.

Classification of data type	Data type		Specification
	Boolean, bit string, integer, and real		Possible.
Basic data types	Duration, date, time of day, date and time, or text string data		Not possible.
Data type specifica-	Array specification	Arrays	Not possible.
tions		Elements	Possible.*1
Derivative data type	Structures	Structures	Not possible.
		Members	Possible.*2
	Unions	Unions	Not possible.
		Members	Possible.*2
	Enumerations		Possible.

^{*1} The elements of the array must be Boolean variables, bit strings, integer data, or real data.

Condition Expressions That You Can Specify

The condition expressions that you can specify depend on the data type of the variable that you specify for the condition expression. If the variable that you specify for a condition expression is bit string data, integer data, or real data, you must set a comparison constant to compare to the value of the variable.

Data type	Possible condition expressions
Boolean, Boolean array elements, Boolean structure members,	Change to TRUE
and Boolean union members	Change to FALSE
Bit string, real number, integer, as well as array element, struc-	Variable = {Comparison constant}
ture member, or union member with one of those data types	Variable ≠ {Comparison constant}
	Variable > {Comparison constant}
	Variable ≥ {Comparison constant}
	Variable < {Comparison constant}
	Variable ≤ {Comparison constant}

Valid Range of Comparison Constants

If the variable that you specify for a condition expression is bit string data, integer data, or real data, you must set a comparison constant to compare to the value of the variable. The valid range of comparison constants is the same as the valid range of the data type of the variable that you specify for the condition expression.


Refer to *Basic Data Types and Derivative Data Types* on page 6-30 for the valid range of values for each data type. For example, if the variable that you specify for the condition expression is a BYTE variable, the valid range of comparison constant values is from BYTE#16#00 to BYTE#16#FF.

^{*2} The members must be Boolean, bit strings, integer data, or real data.


Example of Executing Event Tasks When Condition Expressions for Variables Are Met

Example 1: Execution Condition for Event Task Set to a Change to TRUE of the Program1.trigger1 Boolean Variable

When the value of *Program1.trigger1* changes to TRUE, the event task is executed only once.



Example 2: Execution Condition for an Event Task Set to When *Program1.curVal* (INIT variable) ≥ 10 The event task is executed only once when the value of Program1.curVal changes from less than 10 to 10 or higher.





Precautions for Correct Use

If the value of a specified variable changes in the primary periodic task, the CPU Unit evaluates whether the condition expression is met in the next primary periodic task. This means that the event task will be executed on completion of this evaluation against the condition expression in the next primary periodic task after the CPU Unit evaluates that the condition expression is met.

5-4-5 Event Task Execution Timing for NX102 CPU Units and NX1P2 CPU Units

The execution priority of event tasks is 8 or 48. If the execution conditions for an event task are met while another task is in execution, the task with the higher execution priority is given priority. The task with the lower execution priority is interrupted. This is the same as with the primary periodic task and periodic tasks.

If you have multiple tasks that read and write to the same variables, make sure to use the following functions to control how an event task is executed with the primary periodic task, periodic tasks, or other event tasks with different execution priorities.

Purpose	Function to use
Accessing the same global variable from an event task	Exclusive control of variables in tasks
and from another task	Settings for exclusive control of variables in tasks
	Lock (Lock Tasks) instruction
	Unlock (Unlock Tasks) instruction
Checking the execution status of other tasks	Task_IsActive (Determine Task Status) instruction

Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details.

The execution of an event task also depends on its execution conditions. You can also set the same execution priority for more than one event task. You must be careful when the execution conditions are met for more than one event task that has the same execution priority.


Differences in Execution Timing Based on the Execution Conditions of Event Tasks

The execution timing for event tasks depends on whether the execution condition is triggered by an ActEventTask instruction or by when a condition expression for a variable is met.


Execution Timing When the Execution Condition Is an ActEventTask Instruction

If the execution condition for an event task is triggered by an ActEventTask instruction, the event task execution condition will be met immediately after the ActEventTask instruction is executed. The NX1P2 CPU Units execute event tasks for which the execution condition is met according to the task execution priority.

Example 1: Executing an Event Task with an Execution Priority Higher Than the Task That Executes an Instruction



Example 2: Executing an Event Task with an Execution Priority Lower Than the Task That Executes an Instruction




Event task is executed when the primary periodic task is completed.

• Execution Timing When the Execution Condition Is a Condition Expression for a Variable

The condition expression is evaluated for a match inside the primary periodic task. The execution condition for an event task is met when it is evaluated to match the condition expression. The NX1P2 CPU Unit executes event tasks for which the execution condition is met according to the task execution priority.


Example 1: Project with a Priority-17 Periodic Task and an Event Task Execution with a Priority of 8 The execution priority of the event task (execution priority of 8) is higher than the execution priority of the priority-17 periodic task. The priority-17 periodic task is therefore executed after the event task is executed.



Example 2: Project with a Priority-17 Periodic Task and an Event Task Execution with a Priority of 48

The execution priority of the event task is lower than the execution priority of the priority-17

periodic task. The event task is therefore executed after the priority-17 periodic task is executed.





Precautions for Correct Use

For the NX102 CPU Units and NX1P2 CPU Units, the timing at which the execution condition
for an event task is met is the same regardless of whether the condition expression match is
triggered by I/O refreshing in the primary periodic task, or by execution of a program that is
assigned to the primary periodic task.

Trigger for condition expression to match	Timing at which the execution condition for an event task is met
I/O refreshing in the primary periodic task	Evaluation in the next primary periodic task
Execution of the programs in the primary periodic task	Evaluation in the next primary periodic task


• In order for an event task to be executed, the condition expression must be met in the evaluation after the previous evaluation where the condition expression was not met. This means that even if the status of the condition expression changes from not met to met, if the condition returns to not met before the next evaluation, the event task will not be executed.

Execution Timing for Event Tasks with the Same Execution Priority

You can also set the same execution priority for more than one event task. If the execution conditions for more than one event task with the same execution priority are triggered by an ActEventTask instruction, the event tasks will be executed in the order that the instruction is executed.

Example 1: When Two ActEventTask Instructions Are Executed

In the example given below, two ActEventTask instructions are used to execute two event tasks. The T1 event task is executed before the T2 event task because the ActEventTask instruction that triggered T1 was executed first.




Example 2: When Both Condition Expressions for Variables and the ActEventTask Instruction Are Used In this example, the execution conditions of the T1, T2, and T3 event tasks are set as given below.

- T1: Condition expression for the VarA variable
- T2: Condition expression for the VarB variable
- T3: ActEventTask instruction


The operation would proceed as described below if the condition expression for VarA was met during I/O refreshing, the ActEventTask instruction was executed in the user program, and the condition expression for VarB was met during execution of the user program all in the same primary period.


- (1) The condition expression for VarA is met during I/O refreshing.
- (2) The condition expression for *VarB* is met during execution of the user program.
- (3) At this point, T1 and T2 are not executed because the condition expressions are not yet evaluated.
- (4) The ActEventTask instruction is executed in the user program, so T3 is executed.
- (5) When I/O refreshing is executed in the primary periodic task, the match is detected that the condition expressions for VarA and VarB are met, so T1 and T2 are executed. If the match is detected that more than one condition expression is met in the same execution period, the order of execution of event tasks is undefined. The following figure shows an example when T1 is executed first.



5-4-6 Operation When Execution Condition Is Met Again before Execution of the Event Task Is Completed

If the execution condition for an event task is met again before the execution of that event task is completed, the second match of the execution condition is ignored. "Before an event task is completed" includes the duration of execution of the event task and the time waiting for execution. After the execution of the event task has started, it is executed to the end even if the condition expression is no longer met.





Specifications and Basic Operation 5-5 of Tasks for NJ-series Controllers

This section describes the specifications and basic operation of tasks for NJ-series CPU Units.

5-5-1 **Specifications of Tasks for NJ-series Controllers**

The specifications of tasks are given in the following table.

Item	Specification
Type of task	Primary periodic task
	Periodic task (priority 16, 17, or 18)
	Event task (priority 8 or 48)
Numbers of tasks	Primary periodic task: 1
	Periodic tasks: 0 to 3 tasks*1
	Event tasks: 0 to 32 tasks*2
Number of programs per task	128 max.
Task period of the primary periodic task	500 μs ^{*3} , 1 ms, 2 ms, or 4 ms
Task periods of periodic tasks	Set the task period of each periodic task to an integer multiple of the task period of the primary periodic task. Refer to the table of valid task periods for periodic tasks that is given below.

^{*1} There can be no more than one task with each of the following execution priorities: 16, 17, and 18.

Valid Task Periods for Periodic Tasks

Task period of the primary periodic task	Task periods that you can set for periodic tasks
500 μs*1	1 ms, 2 ms, 3 ms, 4 ms, 5 ms, 8 ms, 10 ms, 15 ms, 20 ms, 25 ms, 30 ms, 40 ms, 50 ms, 60 ms, 75 ms, or 100 ms
1 ms	1 ms, 2 ms, 3 ms, 4 ms, 5 ms, 8 ms, 10 ms, 15 ms, 20 ms, 25 ms, 30 ms, 40 ms, 50 ms, 60 ms, 75 ms, or 100 ms
2 ms	2 ms, 4 ms, 8 ms, 10 ms, 20 ms, 30 ms, 40 ms, 50 ms, 60 ms, or 100 ms
4 ms	4 ms, 8 ms, 20 ms, 40 ms, 60 ms, or 100 ms

^{*1} With the NJ301- , you can use this setting with unit version 1.03 or later. You cannot use this setting with the NJ101-□□□.

^{*2} There can be up to 32 tasks with each of the following priorities as long as there are no more than a total of 32 tasks with these priorities: 8 and 48.

^{*3} With the NJ301- , you can use this setting with unit version 1.03 or later. You cannot use this setting with the NJ101-□□□.

5-5-2 Guidelines for Separating Tasks for NJ-series Controllers

All programs must be assigned to one of the tasks. Use the guidelines in the following table to determine which tasks to assign your programs to based on the requirements of the programs.

Task	Programs that are suitable for this task
Primary periodic task	Programs that require I/O refreshing at an exact execution period.
	Programs that require the highest execution priority.
	Programs that contain motion control instructions with a high execution priority.
Priority-16 periodic task	Programs that require I/O refreshing.
	Programs with a relatively low execution priority that must be executed periodically.
	Programs that contain motion control instructions with a relatively low execution priority.
Priority-17 or priority-18 periodic task	Programs with a relatively low execution priority that must be executed periodically.
Event task	Programs that are executed only when specified conditions are met.


5-5-3 Basic Operation of Tasks for NJ-series Controllers

The CPU Unit cannot execute more than one task at the same time. The order in which tasks are executed depends on the execution priority that is set for each task.

Task Execution Priority

The type of the task determines its execution priority. If the execution condition is met for another task, Tb, that has a higher execution priority while task Ta execution is in progress, execution of Ta will be interrupted to allow execution of Tb. Processing for Ta will resume when processing for Tb is completed. The execution priority for each task type is given in the following table. The smaller the value of the execution priority, the higher the priority.

Task	Execution priority	Tasks with the same execution priority
Primary periodic task	4	
Periodic task	16, 17, or 18	You cannot set the same execution priority for more than one task.
Event task	8 or 48	You can set the same execution priority for more than one event task. Refer to 5-5-5 Event Task Execution Timing for NJ-series Controllers for the order of execution.



Task Periods for the Primary Periodic Task and Periodic Tasks

The CPU Unit repeatedly and cyclically executes the primary periodic task and periodic tasks. The task periods for periodic tasks must be assigned as integer multiples of the task period of the primary periodic task (called the primary period). Therefore, execution of both tasks will start at the same time every few cycles.

For example, if the primary period is set to 1 ms and the task period of the priority-16 periodic task is set to 4 ms, the execution timing of the primary periodic task and the priority-16 periodic task is synchronized after each four executions of the primary periodic task.



Additional Information


An event task is not executed periodically. Instead, it is executed only once when the specified execution condition is met. Therefore, execution of an event task depends on when its execution condition is met and on its execution priority.

Examples of Execution Order for Tasks

This section gives a few examples of the execution order for the primary periodic task and periodic tasks. Refer to 5-5-5 Event Task Execution Timing for NJ-series Controllers for the order of execution of event tasks.

Projects with Only the Primary Periodic Task

The primary periodic task is executed every primary period. The system service shown in this figure refers to non-task related processing, such as communications processing, that is performed by the CPU Unit. System services are executed in the unused time between execution of the tasks. Refer to *Processing Performed in System Services* on page 5-82 for details on the system services.




IO: Indicates I/O refreshing (data outputs and then data inputs). UPG: User program execution.

MC: Indicates motion control.

SS: Indicates system services

Project with the Primary Periodic Task, Priority-16 Periodic Task, and Priority-17 Periodic Task

- · The primary periodic task has the highest execution priority, so it is always executed in the primary period.
- The priority-16 periodic task has a lower execution priority than the primary periodic task, so it is executed when the primary periodic task is not being executed.
- The priority-17 periodic task has an even lower execution priority, so it is executed when the above two tasks are not under execution.
- In this example, the task period for the priority-16 periodic task is set to four times the primary period. This means that once every four primary periods, execution of the primary periodic task and the priority-16 periodic task will start at the same time.
- System services are executed in the unused time between execution of the tasks.






Precautions for Correct Use

If you have multiple tasks that read and write to the same variables, make sure to use exclusive control of variables between the tasks. Otherwise, a task other than the one currently in execution may change the variable values. Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details.

Executing Other Tasks during the Unused Time of a Task

A task with a higher execution priority is never interrupted to start execution of a task with a lower execution priority. However, for NJ-series CPU Units, if unused time occurs during a task with higher priority, that time may be used to start execution of a task with lower priority. An example of this is the time spent waiting for a data transfer to be completed in an I/O refresh process. As soon as processing resumes for the task with higher priority, the task with lower priority will be interrupted. This processing order is illustrated in the following figure.





Precautions for Correct Use

Even if unused time occurs in the primary periodic task, the priority-16 periodic task is always executed after the primary periodic task is completed. However, for NJ-series CPU Units, this restriction does not apply to the priority-17 or priority-18 periodic tasks. This restriction also does not apply to I/O refreshing in the priority-16 periodic task. I/O refreshing for the priority-16 periodic task may be executed during the unused time of the primary periodic task.

Tasks and Operating Modes

The relationship between CPU Unit operating modes and tasks is given in the following table.

Task	Specification
Primary periodic task	These tasks are executed in both RUN mode and PROGRAM mode.
Periodic tasks	The user program is executed only in RUN mode.
Event tasks	Event tasks are executed only in RUN mode.



Precautions for Correct Use


- Even if the execution condition for an event task is already met when you change the operating mode to RUN mode, the event task will not be executed. An event task is executed only when its execution condition changes from not met to met during RUN mode.
- Even in RUN mode, an event task is not executed if there is a major fault level error.

The Processing Performed in Each Task

Primary Periodic Task

The primary periodic task has the highest execution priority. It executes processes with high speed and high precision.

In every period, this task performs system common processing, I/O refreshing, user program execution, and motion control. The primary periodic task performs motion control processing (MC).



*1: Task period

*2: Task execution time


The CPU Unit executes tasks in this fixed period. This is a preset, fixed time.

This is the actual time it takes from the point that the execution condition is met until execution is completed.

Processing		Processing contents
I/O refresh- ing	Output data processing	 Output refresh data is created for Output Units that refresh I/O. If forced refreshing is set, the forced refreshing values are reflected in the output refresh data.
	Refreshing	This process exchanges data with I/O.
	Input data processing	 Input refresh data is loaded from Input Units that refresh I/O. If forced refreshing is set, the forced refreshing values are reflected in the input refresh data that was read.
System comr	mon process-	Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).
		Motion input processing is performed.*1
		 Data trace processing (sampling and trigger checking) is performed. Whether the condition expression for event task execution is met or not is determined.
User program	n execution	Programs assigned to tasks are executed in the order that they are assigned.
Motion control*2		The motion control commands from the motion control instructions in the user program execution are executed.
		Processing the motion outputs for I/O refreshing in the next primary periodic task.
System common processing 2		Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).
		Processing for variables accessed from outside of the Controller is performed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
		If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.

^{*1} The Axis Current Values (Position, Velocity, and Torque) and Drive Status in the system-defined variables for motion control are updated.

^{*2} When there are motion control instructions in user program execution in the primary periodic task, the CPU Unit executes the results from those instructions immediately afterward in motion control processing. The CPU Unit outputs the results to the Servo Drives during I/O refreshing in the next primary periodic task.



When there is a motion control instruction in user program execution in the periodic task, the CPU Unit executes the result from that instruction in the motion control processing (MC) of the next primary periodic task.

Refer to 5-11-3 System Input and Output Response Times for details.


Periodic Tasks

A periodic task executes its programs every task period. The task period is specified as an integer multiple of the primary period. You can use 0 to 3 periodic tasks.

The priority-16 periodic task can also refresh I/O.


Processing for periodic tasks that do not control I/O is different from processing for periodic tasks that do control I/O.

Periodic Tasks That Do Not Control I/O



Processing	Processing contents
System common processing 1	Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).
	Data trace processing (sampling and trigger checking) is performed.
User program execution	Programs assigned to tasks are executed in the order that they are assigned.
System common processing 2	Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).
	 Processing for variables accessed from outside of the Controller is performed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
	If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.

Periodic Tasks That Control I/O




Processing		Processing contents
I/O refresh- ing*1	Output data processing	 Output refresh data is created for Output Units that refresh I/O. If forced refreshing is set, the forced refreshing values are reflected in the output refresh data.
	Refreshing	This process exchanges data with I/O.
	Input data processing	 Input refresh data is loaded from Input Units that refresh I/O.*2 If forced refreshing is set, the forced refreshing values are reflected in the input refresh data that was read.
System common processing 1		 Processing for exclusive control of variables in tasks is performed (when accessing tasks are set). Data trace processing (sampling and trigger checking) is performed.
User program execution		Programs assigned to tasks are executed in the order that they are assigned.
System common processing 2		Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).
		Processing for variables accessed from outside of the Controller is performed to maintain concurrency with task execution (executed for the variable access time that is set in the Task Settings).
		If there is processing for EtherNet/IP tag data links and refreshing tasks are set for the tags (i.e., variables with a Network Publish attribute), variable access processing is performed.

^{*1} I/O refreshing of CJ-series Units is executed.

^{*2} If the input refresh data loaded in the priority-16 periodic task is accessed in the primary periodic task for the NJ-series CPU Unit, copy the input refresh data to access in the priority-16 periodic task to a global variable and access the values of the copied global variable in the primary periodic task. Ensure concurrency of variable values for the global variable. Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details. If you do not perform the above processing, when an execution of the primary periodic task is started during I/O refreshing in the priority-16 periodic task, the concurrency of values of the input refresh data accessed in the primary periodic task may not be ensured.

Event Tasks

An event task is executed only once when the specified execution condition is met. You can use 0 to 32 event tasks. The processing details for event tasks are shown in the following figure.



 The CPU Unit will temporarily interrupt the execution of a task in order to execute a task with a higher execution priority.

Processing	Processing contents
System common processing 1	 Processing for exclusive control of variables in tasks is performed (when accessing tasks are set).*1
User program execution	Programs assigned to tasks are executed in the order that they are assigned.
System common processing 2	 Processing for exclusive control of variables in tasks is performed (when refreshing tasks are set).*1

^{*1} Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details on exclusive control.

5-5-4 **Event Task Execution Conditions for NJ-series Controllers**

An event task is executed only once when the specified execution condition is met. There are the following two types of execution conditions for event tasks.

Execution condition	Event task execution timing	Reason for use
Execution with the ActEvent- Task instruction	When ActEventTask instruction is executed	When you need to explicitly specify which event tasks to execute in the user program When the execution condition for the event task may change before meeting the condition expression for the variable is determined
Execution when a condition expression for a variable is met	When the specified variable value matches the specified condition expression*	When you want to simplify the user program by executing event tasks without user programming

Refer to Execution Timing When the Execution Condition Is a Condition Expression for a Variable on page 5-28 for the timing of when the value of the specified variable is checked to see if the specified condition expression is



Precautions for Safe Use

If the following variables are specified for a condition expression when the execution condition is a condition expression for a variable, event tasks may not be executed when conditions are met or event tasks may be executed when conditions are not met.

- Structure members whose data size is 16 bits or more, except for system-defined variables for motion control
- Array elements whose data size is 16 bits or more

When the above variables are specified and the match evaluation is performed, perform either of the followings.

- Copy the above variables to the internal variables with a basic data type other than a data size of 64 bits, and access the copied internal variables.
- Use the settings for exclusive control of variables in tasks, and set the primary periodic task as a refreshing task.


Executing Event Tasks for the ActEventTask Instruction

When the ActEventTask (Execute Event Task) instruction is executed in the user program, the specified event task is executed once. Refer to the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for the detailed specifications of the ActEventTask instruction.

Using the ActEventTask instruction to execute event tasks makes it easy to see which event tasks are executed. Also, this method is also effective when the execution condition for the event task may change before meeting the condition expression for the variable is determined.


• Example of User Programming Using the ActEventTask Instruction

Example 1: Executing an Event Task Only Once When the Value of a Variable Changes In the following example, the upward differentiation option is used for the ActEventTask instruction. This causes the Task1 event task to be executed only once when the *BoolVar* BOOL variable changes to TRUE.



Example 2: Executing an Event Task Repeatedly While the Value of a Variable Matches a Specified Value

In the following example, the upward differentiation option is not used for the ActEventTask instruction. This causes the Task1 event task to be executed as long as the *BoolVar* BOOL variable is TRUE. Any ActEventTask instructions that specify Task1 will be ignored if Task1 is already in execution. After the execution of the event task has started, it is executed to the end even if the value of *BoolVar* changes to FALSE during execution.



Executing Event Tasks When Condition Expressions for Variables Are Met

This method executes the event task once when the specified condition expression is met for the value of a variable that was specified on the Sysmac Studio. The event task is not executed repeatedly while the value of the variable matches the condition expression. It is executed only once when the value of the variable first changes so that it meets the condition expression. This method of execution does not require user programming to execute the event task.

Variables for Which You Can Specify Condition Expressions

The following table lists the variables that you can specify for condition expressions.

	Type of variables	Specification
System-defined variables		Possible.*1
Semi-user-defined va	ariables	Possible.
User-defined variables	Global variables	Possible.
	Variables used in a program	Possible.
	Variables used in a function block	Possible.*2
	Variables used in a function	Not possible.

The following variables cannot be used. EN, ENO, P Off, P CY, P First RunMode, P First Run and P PRGER

Data Types of Variables for Condition Expressions

The following table lists the data types of variables that you can specify for condition expressions.

Classification of data type	Data	ı type	Specification
	Boolean, bit string, integer, and real		Possible.
Basic data types	Duration, date, time of day, date and time, or text string data		Not possible.
Data type specifica-	Array specification	Arrays	Not possible.
tions		Elements	Possible.*1
	Structures	Structures	Not possible.
		Members	Possible.*2
Derivative data type	Unions	Unions	Not possible.
	Unions	Members	Possible.*2
	Enumerations		Possible.

^{*1} The elements of the array must be Boolean variables, bit strings, integer data, or real data.

^{*2} In-out variables cannot be used.

^{*2} The members must be Boolean, bit strings, integer data, or real data.

Condition Expressions That You Can Specify

The condition expressions that you can specify depend on the data type of the variable that you specify for the condition expression. If the variable that you specify for a condition expression is bit string data, integer data, or real data, you must set a comparison constant to compare to the value of the variable.

Data type	Possible condition expressions	
Boolean, Boolean array elements, Boolean structure members,	Change to TRUE	
and Boolean union members	Change to FALSE	
Bit string, real number, integer, as well as array element, struc-	Variable = {Comparison constant}	
ture member, or union member with one of those data types	Variable ≠ {Comparison constant}	
	Variable > {Comparison constant}	
	Variable ≥ {Comparison constant}	
	Variable < {Comparison constant}	
	Variable ≤ {Comparison constant}	

Valid Range of Comparison Constants


If the variable that you specify for a condition expression is bit string data, integer data, or real data, you must set a comparison constant to compare to the value of the variable. The valid range of comparison constants is the same as the valid range of the data type of the variable that you specify for the condition expression.

Refer to *Basic Data Types and Derivative Data Types* on page 6-30 for the valid range of values for each data type. For example, if the variable that you specify for the condition expression is a BYTE variable, the valid range of comparison constant values is from BYTE#16#00 to BYTE#16#FF.


Example of Executing Event Tasks When Condition Expressions for Variables Are Met

Example 1: Execution Condition for Event Task Set to a Change to TRUE of the *Program1.trigger1*Boolean Variable

When the value of *Program1.trigger1* changes to TRUE, the event task is executed only once.



Example 2: Execution Condition for an Event Task Set to When *Program1.curVal* (INIT variable) ≥ 10 The event task is executed only once when the value of Program1.curVal changes from less than 10 to 10 or higher.





Precautions for Correct Use

The CPU Unit evaluates whether the condition expression is met before the programs that are assigned to the primary periodic task are executed. Even if the specified value of the variable matches the condition expression during execution of the program in the primary periodic task, the condition is not evaluated until just before the next execution of the primary periodic task. This means that the event task will be executed after the end of the execution of the primary periodic task that follows the execution of the primary periodic task in which the value of the variable meets the condition expression.

5-5-5 Event Task Execution Timing for NJ-series Controllers

The execution priority of event tasks is 8 or 48. If the execution conditions for an event task are met while another task is in execution, the task with the higher execution priority is given priority. The task with the lower execution priority is interrupted. This is the same as with the primary periodic task and periodic tasks. The execution of an event task also depends on its execution conditions.

You can also set the same execution priority for more than one event task. You must be careful when the execution conditions are met for more than one event task that has the same execution priority.

Differences in Execution Timing Based on the Execution Conditions of Event Tasks


The execution of event tasks depends on whether the execution condition is triggered by an ActEvent-Task instruction or by when an condition expression for a variable is met.

Execution Timing When the Execution Condition Is an ActEventTask Instruction

If the execution condition for an event task is triggered by an ActEventTask instruction, the event task will be executed immediately after the ActEventTask instruction is executed.


Example 1: ActEventTask Instruction Executed in Priority-16 Periodic Task and an Event Task with an Execution Priority of 8

The execution priority of the event task (execution priority of 8) is higher than the execution priority of the priority-16 periodic task. Execution of the priority-16 periodic task is therefore interrupted and the event task is executed.



Example 2: Executing an ActEventTask Instruction within the Primary Periodic Task

The event task has a lower execution priority than the primary periodic task, so the event task is executed after execution of the primary periodic task is completed.




Event task is executed when the primary periodic task is completed.


Execution Timing When the Execution Condition Is a Condition Expression for a Variable

The condition expression is evaluated for a match inside the primary periodic task. This means that the event task will be executed immediately after the first execution of the primary periodic task after the specified value of the variable meets the condition expression. However, if there are tasks with a higher execution priority than the event task, those tasks will be executed first.

Example 1: Project with a Priority-16 Periodic Task and an Event Task Execution with a Priority of 8 The event task is executed immediately after the first execution of the primary periodic task after the condition expression is met. The execution priority of the event task (execution priority of 8) is higher than the execution priority of the priority-16 periodic task. The priority-16 periodic task is therefore executed after the event task is executed.



Example 2: Project with a Priority-16 Periodic Task and an Event Task Execution with a Priority of 48 The execution priority of the event task is lower than the execution priority of the priority-16 periodic task. The event task is therefore executed after the priority-16 periodic task is executed.





Precautions for Correct Use

• The execution timing of an event task depends on how the condition expression is met. The match can be triggered by I/O refreshing in the primary periodic task, or by execution of a program that is assigned to the primary periodic task. This difference is described in the following table. This difference occurs because the condition expression is evaluated for a match by system common processing 1 inside the primary periodic task. Processing in the primary periodic task takes place in this order: I/O refreshing, system common processing 1, and user program execution.

Trigger for condition expression to match	Event task execution timing
I/O refreshing in the primary periodic task	After completion of the primary periodic task
Execution of the programs in the primary periodic task	After completion of the next execution of the primary periodic task


- In order for an event task to be executed, the condition expression must be met in the evaluation after the previous evaluation where the condition expression was not met. This means that even if the status of the condition expression changes from not met to met, if the condition returns to not met before the next evaluation, the event task will not be executed.
- For an NJ-series CPU Unit, specify an internal variable defined in the program that is assigned
 to the primary periodic task if you specify an internal variable with a data size of 64 bits or
 more to the condition expression. If an internal variable that is not defined in the primary periodic task is specified, the concurrency of variable values may not be ensured. As the result,
 the match evaluation may not be correctly performed.

Execution Timing for Event Tasks with the Same Execution Priority

You can also set the same execution priority for more than one event task. If the execution conditions are met for more than one event task that has the same execution priority, the event tasks will be executed in the order that their execution conditions are met.

Example 1: When Two ActEventTask instructions Are Executed

In the example given below, two ActEventTask instructions are used to execute two event tasks. The T1 event task is executed before the T2 event task because the ActEventTask instruction that triggered T1 was executed first.




Example 2: When Both Condition Expressions for Variables and the ActEventTask Instruction Are Used In this example, the execution conditions of the T1, T2, and T3 event tasks are set as given below.

- T1: Condition expression for the VarA variable
- T2: Condition expression for the VarB variable
- T3: ActEventTask instruction


The operation would proceed as described below if the condition expression for VarA was met during I/O refreshing, the ActEventTask instruction was executed in the user program, and the condition expression for VarB was met during execution of the user program all in the same primary period.


- (1) The condition expression for VarA is met during I/O refreshing.
- (2) In system common processing 1, the match is detected for the condition expression for VarA and T1 is executed. The condition expression for VarB is not yet met, so T2 is not executed.
- (3) The condition expression for VarB is met during execution of the user program.
- (4) The ActEventTask instruction is executed in the user program, so T3 is executed.
- (5) In system common processing 1 in the next primary period, the match is detected for the condition expression for VarB and T2 is executed.



5-5-6 Operation When Execution Condition Is Met Again before Execution of the Event Task Is Completed

If the execution condition for an event task is met again before the execution of that event task is completed, the second match of the execution condition is ignored. "Before an event task is completed" includes the duration of execution of the event task and the time waiting for execution. After the execution of the event task has started, it is executed to the end even if the condition expression is no longer met.





Services Other Than Tasks 5-6

The CPU Unit performs processing other than the primary periodic task, periodic tasks, and event tasks. This section describes the services other than tasks for the NX701 CPU Units, NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units.

NX701 CPU Units

For the NX701 CPU Unit, the processing includes the tag data link service and system services. The processing that is performed, the execution priority, and the execution timing for these two services are given in the following table.

Item	Tag data link service	System services
Execution prior- ity	The tag data link service is executed in parallel with the task execution and system services.	System services are executed in parallel with the task execution and tag data link service.
Processing	Data is exchanged by using tags with other controllers and devices on an EtherNet/IP network. You can use the built-in EtherNet/IP port in the CPU Unit.*1	System services include services with low execution priority, such as the USB port service and SD Memory Card service.
Execution timing	The execution interval and the time that is required for each execution depend on the model of the CPU Unit and on the tag data link settings.*2	System services are executed at the required time if a request comes from the hardware or from outside of the CPU Unit.

^{*1} For details on the processing that is performed for tag data links, refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual (Cat. No. W506).

NX102 CPU Units

For the NX102 CPU Units, the following two services are provided: the tag data link service and system service. The processing, execution priority, and execution timing for these two services are given in the following table.

Item	Communications bridge service*1	Tag data link service	System service
Execution priority	The communications bridge service is executed in parallel with the task execution and system services. It is prioritized than the tag data link service and system services.	The tag data link service is executed in parallel with the task execution. However, during execution of the communications bridge service, the tag data link service is not executed. It is prioritized than system services.	System services are executed in parallel with the task execution. However, during execution of the communications bridge service and tag data link service, system services are not executed.
Processing	The processing to relay CIP Safety communications between CIP Safety on EtherNet/IP devices and the Safety CPU Unit that is mounted to the CPU Unit, is executed in the communications bridge service.	Data is exchanged by using tags with other controllers and devices on an EtherNet/IP network. You can use the built-in EtherNet/IP port in the CPU Unit.*2	System services include services with low execu- tion priority, such as the USB port service and SD Memory Card service.
Execution timing	Executed when the frames of the CIP Safety communications are sent and received by the built-in EtherNet/IP port.	The execution interval and the time that is required for each execution depend on the model of the CPU Unit and on the tag data link settings.*3	Executed according to the execution priority if a request comes from the hardware or from outside of the CPU Unit.

^{*1} The service is executed by an NX102 CPU Unit with unit version 1.31 or later.

^{*2} Refer to 5-6-2 Processing Performed in and Execution Timing of the Tag Data Link Service for details on the execution interval and the time that is required for execution of tag data links.

- *2 For details on the processing that is performed for tag data links, refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual (Cat. No. W506).
- *3 Refer to 5-6-2 Processing Performed in and Execution Timing of the Tag Data Link Service for details on the execution interval and the time that is required for execution of tag data links.

NX1P2 CPU Units

For the NX1P2 CPU Unit, the processing includes the tag data link service, option board service, and system services. The processing that is performed, the execution priority, and the execution timing for these three services are given in the following table.

Item	Tag data link service	Option board service	System services
Execution prior- ity	The tag data link service is executed in parallel with the task execution. It is prioritized than the option board service and system services.	The option board service is executed in parallel with the task execution. However, during execution of the tag data link service, the option board service is not executed. It is prioritized than system services.	System services are executed in parallel with the task execution. However, during execution of the tag data link service or option board service, system services are not executed.
Processing	Data is exchanged by using tags with other controllers and devices on an EtherNet/IP network. You can use the built-in EtherNet/IP port in the CPU Unit.*1	I/O refreshing for Analog I/O Option Boards is executed.	System services include services with low execution priority, such as the USB port service and SD Memory Card service.
Execution timing	The execution interval and the time that is required for each execution depend on the model of the CPU Unit and on the tag data link settings.*2	The option board service is executed depends the execution priority if a request comes from the Option Board.	System services are executed depend on the execution priority if a request comes from the hardware or from outside of the CPU Unit.

^{*1} For details on the processing that is performed for tag data links, refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual (Cat. No. W506).

NJ-series CPU Units

For the NJ-series CPU Unit, the processing includes the tag data link service and system services. The processing that is performed, the execution priority, and the execution timing for these two services are given in the following table.

Item	Tag data link service	System services
Execution prior- ity	The execution priority is between the execution priorities of the priority-16 periodic task and the priority-17 periodic task.	The execution priority is lower than that of any of the tasks.
Processing	Data is exchanged by using tags with other controllers and devices on an EtherNet/IP network. You can use the built-in EtherNet/IP port in the CPU Unit or a CJ-series CJ1W-EIP21 EtherNet/IP Unit to connect to an HMI.*1	System services include services with low execution priority, such as the USB port service and SD Memory Card service.
Execution timing	The execution interval and the time that is required for each execution depend on the model of the CPU Unit and on the tag data link settings.*2	System services are executed in the unused time between execution of the tasks and tag data link service.*3

^{*1} For details on the processing that is performed for tag data links, refer to the *NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual* (Cat. No. W506).

^{*2} Refer to 5-6-2 Processing Performed in and Execution Timing of the Tag Data Link Service for details on the execution interval and the time that is required for execution of tag data links.

^{*2} Refer to 5-6-2 Processing Performed in and Execution Timing of the Tag Data Link Service for details on the execution interval and the time that is required for execution of tag data links.

*3 If sufficient time cannot be obtained to execute the system services with an NJ-series CPU Unit, the processing of tasks with an execution priority of 17 or higher will be interrupted to allocate sufficient time. You can set the time for execution of the system services in the System Service Monitoring Settings on the Sysmac Studio.

5-6-1 Execution Priorities and Execution Orders of Services Other Than **Tasks**

This section provides examples of the execution priorities and execution orders of the communications bridge service, tag data link service, option board service, and system services.

Execution Priorities of Services Other Than Tasks

NX701 CPU Units

The tag data link service is not affected by the task execution priority and system services. System services are not affected by the task execution priority and tag data link service.

NX102 CPU Units

The communications bridge service, tag data link service and system services are not affected by the task execution priority. The communications bridge service, tag data link service and system services are executed in descending order of execution priority.

Note The communications bridge service is executed by an NX102 CPU Unit with unit version 1.31 or later.


NX1P2 CPU Units

The tag data link service, option board service and system services are not affected by the task execution priority. The tag data link service, option board service and system services are executed in descending order of execution priority.

NJ-series CPU Units

The execution priorities of the tag data link service and system services are shown below.

The execution priority of the tag data link service is between the execution priorities of the priority-16 periodic task and the priority-17 periodic task. The execution priority of the system services is lower than the execution priority of any of the tasks.




Examples of the Order of Execution for Services Other Than Tasks

As an example, the order of execution for the primary periodic task, priority-16 periodic task, priority-17 periodic task, tag data link service, option board service, and system services is shown below.


NX701 CPU Units

- The tag data link service is executed without being affected by the tasks and system services.
- The system services are executed at the required time without being affected by the tasks and tag data link service.




NX102 CPU Units

- You can execute the communications bridge service, tag data link service and system services in parallel with the execution of tasks.
- · The order of execution priority is communications bridge service, tag data link service and then system services.




NX1P2 CPU Units

- · You can execute the tag data link service, option board service or system services in parallel with the execution of tasks.
- The order of execution priority is tag data link service, option board service and then system services.



NJ-series CPU Units

- Execution of the tag data link service is given priority over execution of the priority-17 periodic task. However, execution of the primary periodic task and priority-16 periodic task is given even higher priority.
- The system services are executed in the unused time between execution of all of the tasks and tag data link service.



The execution interval and the execution time for one execution depend on the model of the CPU Unit and on the tag data link settings. Refer to 5-6-2 Processing Performed in and Execution Timing of the Tag Data Link Service for details.

tasks and tag data link service.


5-6-2 Processing Performed in and Execution Timing of the Tag Data **Link Service**

Processing Performed in Tag Data Link Service

The processing for tag data links is separated in multiple processes. This processing is performed in the tag data link service, the system services, and the tasks. The following example shows the processing that is performed for the tag data links when the built-in EtherNet/IP port on the CPU Unit is used.


Flow of Tag Data Reception Processing

- The tag data link service reads the tag data from the received tag sets.
- · If a refreshing task is set, the task writes the values of the tag data to the variables that are assigned to the tags.
- If a refreshing task is not set, a system service writes the values of the tag data to the variables that are assigned to the tags.



Flow of Tag Data Transmission Processing

- If a refreshing task is set, the task reads the values of the tag data from the variables that are assigned to the tags.
- If a refreshing task is not set, a system service reads the values of the tag data from the variables that are assigned to the tags.
- Then, in the tag data link service, the tag set is created from the tag data and the tag set is sent.





Additional Information

Differences in the Timing of Processing Tag Data Links Depending on Whether a Refreshing Task Is Set

The process to write values to and read values from variables is different depending on whether a refreshing task is set. If a refreshing task is set, the values are read and written in that task. If a refreshing task is not set, the values are read and written in a system service. This means there is a difference in the execution timing of processing tag data links.


The difference in the execution timing when data is received for tag data links with an NJ-series CPU Unit is shown below.

When a Refreshing Task Is Specified
In this example, the primary periodic task is set as the refreshing task. Values are written to the
variables in the next primary periodic task after the tag data links service.

periodic task after the tag data links service. Execution priority High Primary periodic task Task period Priority-16 periodic task Tag data link service Task period Priority-17 UPG Interrupted periodic task Tag data is read from the tag set. System

Values are written to the variables in the next primary


When a Refreshing Task Is Not Specified
 The values are written to the variables in a system service.



Low

Execution Timing of the Tag Data Link Service

The execution interval and the execution time depend on the model of the CPU Unit and on the tag data link settings. Guidelines are provided below. For an NJ-series CPU Unit, however, if a task with a higher execution priority than the tag data link service is executed, the execution interval and the execution time will be longer than the following values.



Using the Built-in EtherNet/IP Port on the CPU Unit

	Tag	data link setting	Execution	Execution	
CPU Unit	Number of tags	Number of connections	RPI [ms]	interval (ms)	time (ms)
NJ501-□□□□	8	1	1	1	0.02 to 0.04
		4	2	1	0.02 to 0.10
		32	50	1	0.02 to 0.10
NJ301-□□□□	8	1	1	1	0.03 to 0.06
		4	2	1	0.03 to 0.15
		32	50	1	0.03 to 0.15
NJ101-□□□□	8	1	1	1	0.04 to 0.09
		4	2	1	0.04 to 0.28
		32	50	1	0.04 to 0.28



Additional Information

For an NX-series CPU Unit, the priority-17 and priority-18 periodic tasks and the system service are not affected by execution of the tag data link service.

Using the CJ1W-EIP21 EtherNet/IP Unit

		Tag data link s	ettings		Execution	Execution
CPU Unit	Number of tags	Number of connections	RPI [ms]	Send/re ceive	interval (ms)	time (ms)
NJ501-□□□□	8	1	1	Send	3	0.10
				Receive	3	0.10
		4	2	Send	4	0.22
				Receive	4	0.13
		32	50	Send	12	0.68
				Receive	6 to 35	0.23 to 0.66
NJ301-□□□□	8	1	1	Send	3	0.16
				Receive	3	0.16
		4	4 2	Send	3	0.21
				Receive	4	0.33
		32	50	Send	15	1.05
				Receive	8 to 35	0.29 to 1.85
NJ101-□□□□	8	1 1	Send	3	0.21	
				Receive	3	0.21
	-	4	4 2	Send	6	0.46
				Receive	13	0.80
		32	50	Send	12 to 50	2.97 to 4.09
				Receive	25	2.36



Version Information

Execution of processing for tag data links depends on the unit version of the CPU Unit and the Sysmac Studio version as given below.

Unit version of CPU Unit	Sysmac Studio version			
Offic version of CPO Offic	1.03 or lower	1.04 or higher		
1.03 or later	Built-in EtherNet/IP port ser- vice in system services	Tag data link service*		
1.02 or earlier	Built-in EtherNet/IP port service in system services			

^{*} If a unit version of 1.02 or earlier is set on the Sysmac Studio, the tag data links are processed in the built-in EtherNet/IP port service in the system services.

5-6-3 Processing Performed in and Execution Timing of the Option **Board Service**

Processing Performed in Option Board Service


For the NX1P2 CPU Units, I/O refreshing for Analog I/O Option Boards is executed in the processing performed in the option board service.

Execution Timing of the Option Board Service


For the NX1P2 CPU Units, the option board service is executed without being affected by the tasks. However, the tag data link service, option board service and system services are not executed in parallel.

The option board service is executed depends on the execution priority if a request comes from the Option Board. The internal processing of an Option Board, the option board service for an NX1P2 CPU Unit, and the task execution are performed asynchronously.

When you input the data, the input data is read in the internal processing of an Option Board and processed in the option board service for an NX1P2 CPU Unit. When the processing in the option board service is completed, you can use the input data in user program execution in the next primary periodic task.



When you output data, the output data is processed in the option board service after user program execution is completed. When the processing in the option board service is completed, the output data is output in the next internal processing of the Option Board.



5-6-4 Processing Performed in and Execution Timing of the Communications Bridge Service

Processing Performed in Communications Bridge Service


For the NX102 CPU Units, the processing to relay CIP Safety communications between CIP Safety on EtherNet/IP devices and the Safety CPU Unit that is mounted to the CPU Unit, is executed in the communications bridge service.

Note The communications bridge service is executed by an NX102 CPU Unit with unit version 1.31 or later.

Execution Timing of the Communications Bridge Service

For the NX102 CPU Units, the communications bridge service is executed without being affected by the tasks. However, the communications bridge service, tag data link service and system services are not executed in parallel.

The communications bridge service is executed when the frames of the CIP Safety communications are sent and received by the built-in EtherNet/IP port.



The execution interval and execution time for the communications bridge service depend on the settings of CIP Safety communications.

Refer to the *NX-series Safety Control Unit User's Manual* (Cat. No. Z930-E1-12 or later) for information on the CIP Safety communications.

5-6-5 Processing Performed in and Execution Timing of the System Services

Processing Performed in System Services

System services include the following processing.

System service	Description
USB port service*1	Processing of service requests from the Sysmac Studio or host computers.
Built-in EtherNet/IP port service	Processing of message service requests, such as CIP commands, from the Sysmac Studio, an HMI, host computers, or other Controllers
	 Execution of communications instructions for CIP and socket communications
Built-in EtherCAT port service	Execution of EtherCAT message communications
Communications processing for a Serial Communications Option Board*2	Execution of communications processing for a Serial Communications Option Board
Service for CJ-series Special	Event servicing for CJ-series Special Units
Units ^{*3}	Execution of communications instructions (CIP)
SD Memory Card service	Access from FTP client
	SD Memory Card operations from the Sysmac Studio
	Execution of SD Memory Card instructions
Self-diagnosis	Hardware error detection

^{*1} The NX102 CPU Units and NX1P2 CPU Units do not provide a USB port.

Execution Timing of the System Services

For the NX701 CPU Units, the system services are executed at the required time without being affected by the tasks and tag data link service. It is designed to always secure sufficient time for system service execution.

For the NX102 CPU Units, the system services are executed without being affected by the tasks. However, during execution of the communications bridge service or tag data link service, system services are not executed.

For the NX1P2 CPU Units, the system services are executed without being affected by the tasks. However, during execution of the tag data link service or option board service, system services are not executed.

For NJ-series CPU Units, the system services are executed in the unused time between execution of the tasks and tag data link service.

If sufficient time cannot be obtained to execute the system services, the processing of tasks with an execution priority of 17 or higher will be interrupted to allocate sufficient time.

^{*2} The communications processing for a Serial Communications Option Board is executed only by an NX1P2 CPU Unit.

^{*3} You can use CJ-series Units only with NJ-series CPU Units.The CPU Unit exchanges data between CJseries Special Units and the memory words that are allocated to them during I/O refreshing. You can use CJ-series Special Units only with NJ-series CPU Units.

You can set the time for execution of the system services in the System Service Monitoring Settings on the Sysmac Studio.


There is no priority in the processing of system services. All of the processing is executed in parallel with time slicing.

Execution Timing When Sufficient Execution Time for the System Services Cannot Be Obtained

With an NJ-series CPU Unit, if there is not enough unused time between execution of the tasks and tag data link service to execute the system services, the execution of tasks with an execution priority of 17 or higher will be interrupted to allocate sufficient time.

If the system service execution time cannot be obtained even if execution of tasks with an execution priority of 17 or higher is temporarily interrupted, an Insufficient System Service Time Error occurs and user program execution stops.

You can set the time for execution of the system services in the System Service Monitoring Settings on the Sysmac Studio.



System Service Monitoring Settings

The System Service Monitoring Settings are used to monitor whether sufficient system service execution time can be secured with NJ-series CPU Units. If the execution of all tasks cannot be completed within the system service execution interval, execution is monitored to see if at least the ratio of execution that is set for the System Service Execution Time Ratio is completed. You can set the System Service Monitoring Settings in the Basic Settings Display of the Operation Settings Tab Page on the Sysmac Studio.

Access point	Setting group	Setting [unit]	Description	Set val- ues	Default	Update timing	Changes in RUN mode
Operation Settings, Operation Settings	System Service Monitoring Settings	System Service Execution Interval [ms]	Sets the interval of system service execution.	10 ms to 1 s	10 ms	When down- loaded to CPU Unit	Not allowed.
Tab, Basic Settings		System Service Execution Time Ratio [%]	Sets the ratio for monitoring system service execution.	5% to 50%	10%	When down- loaded to CPU Unit	Not allowed.



Additional Information

NX-series CPU Units are designed to always secure sufficient time for system service execution, so the System Service Monitoring Settings are not provided. Also an Insufficient System Service Time Error will not occur.



Precautions for Correct Use

- For NJ-series CPU Units, set the System Service Monitoring Settings to the minimum values that are required to meet the response performance of the system services so that sufficient time can be allocated to the system services and task execution. The System Service Monitoring Settings are used to monitor whether the specified system service execution time can be obtained. System services will not necessarily be executed for the specified time.
- For NJ-series CPU Units, design the tasks so that sufficient time can be allocated to execution of the system services. Refer to 5-11 Task Design Methods and I/O Response Times for the setting procedures for tasks.
- To increase the system service execution time with an NJ-series CPU Unit, increase the task period or take other steps to increase the unused time between task execution.
- With an NJ-series CPU Unit, if the time that is specified in the System Service Monitoring Settings cannot be allocated to the system service execution time even if execution of tasks with an execution priority of 17 or higher is interrupted, an Insufficient System Service Time Error occurs and user program execution stops.
- With an NJ-series CPU Unit, if sufficient system service execution time cannot be allocated and execution of tasks with an execution priority of 17 or higher is interrupted, a Task Period Exceeded error will occur for the tasks that are interrupted. Design the tasks so that the execution of tasks with an execution priority of 17 or higher is completed within the task periods even if the execution time of the system services satisfies the System Service Monitoring Settings.

5-7 Assignment and Settings Related to Tasks

This section describes the assignment and settings related to tasks.

5-7-1 Assigning I/O Refreshing to Tasks

I/O refreshing of the EtherCAT slaves, NX Units on the CPU Unit, I/O built in the CPU Unit, Option Boards in the CPU Unit, and the CJ-series Units is assigned to the tasks.

Tasks to which assignment is possible and unit of assignment are different depending on the target for I/O refreshing. Unit of assignment refers to a target or a group of targets for I/O refreshing assigned to one task. For example, when the unit of assignment is Slave Terminal, you can assign I/O refreshing to only one task even if more than one NX Unit is connected to a Communications Coupler Unit.

If you want to perform input and output operations in tasks to which I/O refreshing is not assigned, refer to *Input and Output Operations in Tasks to Which I/O Refreshing Is Not Assigned* on page 5-87.

The following table shows the relationship among the target for I/O refreshing, the assignable task, and the unit of assignment.

I/O refreshing target	Assignable task	Unit of assign- ment
Communications Coupler Unit with an NX-series Safety Control Unit on the Slave Terminal	Primary periodic task or priority-5 and priority-16 periodic tasks*1*2*3	By Slave Termi- nal
Communications Coupler Unit with an NX Unit assigned to an axis on the Slave Terminal	Primary periodic task or priority-5 periodic task*3	
Communications Coupler Unit without an NX Unit assigned to an axis on the Slave Terminal	Primary periodic task or priority-5 and priority-16 periodic tasks*2*3	
EtherCAT slaves to which axes are assigned	Primary periodic task or priority-5 periodic task*2*3	By slave
Other EtherCAT slaves	Primary periodic task or priority-5 and priority-16 periodic tasks*2*3	
NX Units on the CPU Unit*4 and I/O built in the CPU Unit*5	Primary periodic task	
CJ-series Basic I/O Units*6	Primary periodic task and priority-	By Unit
CJ-series Special I/O Units*6	16 periodic task	
CJ-series CPU Bus Units*6		

^{*1} If multiple Slave Terminals with mounted NX-series Safety Control Units exist, you cannot assign Slave Terminals to a combination of the periodic tasks other than priority-5 periodic task and priority-5 periodic task.

^{*2} You can use the priority-5 periodic task only with the NX701 CPU Units.

^{*3} You can only use the primary periodic task with the NX102 CPU Units or NX1P2 CPU Units.

^{*4} You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

^{*5} You can use I/Os built in the CPU Unit only with the NX1P2 CPU Units.

^{*6} You can use various CJ-series Units only with NJ-series CPU Units.



Precautions for Safe Use

If two different function modules are used together, such as when you use CJ-series Basic Units and EtherCAT slaves, take suitable measures in the user program and external controls to ensure that safety is maintained in the controlled system if one of the function modules stops.

The relevant outputs will behave according to the slave or Unit specifications if a partial fault level error occurs in one of the function modules.

Refer to Non-fatal Errors in the NJ/NX- series Troubleshooting Manual (Cat. No. W503) for information on the partial fault level Controller error.



Additional Information

When using both EtherCAT slaves and CJ-series Units, you can shorten the task execution time of the primary periodic task by assigning the I/O refreshing for EtherCAT slaves to a different task than the I/O refreshing for CJ-series Units. Assign I/O refreshing for EtherCAT slaves to the primary periodic task and assign I/O refreshing for CJ-series Units to the priority-16 periodic task.

Sysmac Studio Setting Procedure

For the slaves and Units that are not assigned to axes, set the tasks in which to perform I/O refreshing in I/O Control Task Settings under Configurations and Setup - Task Settings of the Sysmac Studio.

Refer to I/O Control Task Settings on page 4-9 for details.

For the slaves and Units that are assigned to axes, specify the motion controls to use in Motion Control Setup under Configurations and Setup of the Sysmac Studio. The tasks to perform I/O refreshing are set.

Refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507) for details.

Timing of I/O Refreshing

The table below shows when I/O is refreshed for EtherCAT slaves, NX Units on the CPU Unit, I/O built in the CPU Unit, Option Boards in the CPU Unit, and CJ-series Units.

I/O refreshing target	I/O refreshing task	Period of I/O refreshing
EtherCAT slaves	Primary periodic task	Task period of the primary periodic task
	Priority-5 periodic task*1	Task period of the priority-5 periodic task
	Priority-16 periodic task	Task period of the primary periodic task*2
NX Units on the CPU Unit*3	Primary periodic task	Task period of the primary periodic task
I/O built in the CPU Unit*4	Primary periodic task	Task period of the primary periodic task
CJ-series Units*5	Primary periodic task	Task period of the primary periodic task
	Priority-16 periodic task	Task period of the priority-16 periodic task

^{*1} You can use the priority-5 periodic task only with the NX701 CPU Units.

^{*2} EtherCAT communications is executed during I/O refreshing in the primary periodic task. If the priority-16 periodic task is used to control EtherCAT slaves, the data refresh period during I/O refreshing will be the task period of the priority-16 periodic task.

^{*3} You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

^{*4} You can use the built-in I/O only with the NX1P2 CPU Units.

^{*5} You can use CJ-series Units only with NJ-series CPU Units.

Priorities in Process Data Communications

EtherCAT process data communications is executed during I/O refreshing. With an NX701 CPU Unit, you can perform process data communications in the primary periodic task and the priority-5 periodic task.

When process data communications is executed in the primary periodic task or the priority-5 periodic task, process data communications in the primary periodic task is prioritized. Therefore, the I/O refresh time of the priority-5 task is longer even if the process data communications cycle and process data size of two tasks are the same.

Accessing I/O from the User Program

You use device variables to access I/O ports from the user program. Access the device variables from a program in the task that is set in the I/O Control Task Settings.

Input and Output Operations in Tasks to Which I/O Refreshing Is Not Assigned

If you attempt to output data directly from a task to which I/O refreshing is not assigned, an error will occur when you check the program on the Sysmac Studio. For example, if the processes for NX Units are assigned to different tasks on the Slave Terminal, data can be output only from the task to which I/O refreshing is assigned. In this case, you need to create the program to pass the data from the task to which I/O refreshing is not assigned to the task to which I/O refreshing is assigned and output data from the task to which I/O refreshing is assigned.

The following sample programming shows how to pass the data from the task to which I/O refreshing is not assigned to the task to which I/O refreshing is assigned and output data from the task to which I/O refreshing is assigned.

In this sample programming, the external data input processing is performed in a task to which I/O refreshing is not assigned. Usually, this kind of processing causes a warning to occur when you check the program on the Sysmac Studio. However, the execution of processing is possible.

Unit Configuration

A Slave Terminal is used. The following table shows the Unit configuration of the Slave Terminal.

Model number	Product name
NX-ECC20□	EtherCAT Coupler Unit
NX-ID3317	DC Input Unit
NX-OD3256	Transistor Output Unit

I/O Map

The following I/O map is used. The table below shows the bits that are used in the sample programming.


Position	Port	Description	R/W	Data type	Variable	Variable comment	Variable type
Unit1	NX-ID3317						
	Input Bit 00	Input bit 00	R	BOOL	ComIn	Common input value	Global variable
Unit2	NX-OD3256						
	Output Bit 00	Output bit 00	W	BOOL	OutA1	Output value A1	Global variable
	Output Bit 01	Output bit 01	W	BOOL	OutA2	Output value A2	Global variable
	Output Bit 02	Output bit 02	W	BOOL	OutB1	Output value B1	Global variable
	Output Bit 03	Output bit 03	W	BOOL	OutB2	Output value B2	Global variable

I/O Specifications

The I/O specifications are as follows:

- OutA1 changes from FALSE to TRUE one second after the value of ComIn changes from FALSE to TRUE. In the same way, OutA2 changes to TRUE two seconds, OutB1 three seconds and OutB2 four seconds after the value of ComIn changes to TRUE.
- When the value of ComIn changes from TRUE to FALSE, the values of OutA1, OutA2, OutB1 and OutB2 change from TRUE to FALSE.

The following figure shows the timing chart.



Task Processing


The primary periodic task and priority-16 periodic task are used. The I/O refreshing is assigned to the primary periodic task.

OutA1 and OutA2 are controlled in the primary periodic task. A series of processing, i.e., input of ComIn, calculations and outputs of OutA1 and OutA2, is performed in the primary periodic task.

For controls of OutB1 and OutB2, the processing from input of ComIn to calculations is performed in the periodic task. The calculation results of the periodic task are assigned to the temporary global variables tmp_OutB1 and tmp_OutB2. In the primary periodic task, the values of tmp_OutB1 and tmp_OutB2 are assigned to OutB1 and OutB2. Then, OutB1 and OutB2 are output.

The Controller may pause the periodic task in order to execute the primary periodic task. The assignment of calculation results to tmp_OutB1 and tmp_OutB2 may be performed before or after the pause of the periodic task. And the timing of assignment determines the timing of output of calculation results in the primary periodic task.

The following figure shows an example of processing flow. The task period of the periodic task is set to twice as long as that of the primary periodic task.



If the values are assigned to *tmp_OutB1* and *tmp_OutB2* in step (4), they are output in step (8).

If the values are assigned to *tmp_OutB1* and *tmp_OutB2* in step (7), they are output in step (10).

- (1) ComIn is input during I/O refreshing in the primary periodic task.
- (2) The calculation is performed during the user program execution in the primary periodic task and the values are assigned to OutA1 and OutA2. Also, the values of tmp_OutB1 and tmp_OutB2 are assigned to OutB1 and OutB2. However, the values of tmp_OutB1 and tmp_OutB2 are the initial values because the values are not assigned to tmp_OutB1 and tmp_OutB2 in the periodic task. Therefore, the values of OutB1 and OutB2 are also the initial values.
- (3) ComIn is input during I/O refreshing in the periodic task.
- (4) The calculation is performed during the user program execution in the periodic task. If the primary periodic task is executed while the periodic task execution is in progress, the periodic task is paused. Depending on the timing of processing in the periodic task, the assignment of the values to *tmp_OutB1* and *tmp_OutB2* may be performed before or after the pause of the periodic task.
- (5) OutA1, OutA2, OutB1 and OutB2 are output during I/O refreshing in the primary periodic task.
 - Also, ComIn is input again.
- (6) The calculation is performed during the user program execution in the primary periodic task and the values are assigned to *OutA1* and *OutA2*.
 - Also, the values of tmp_OutB1 and tmp_OutB2 are assigned to OutB1 and OutB2. If the values are assigned to tmp_OutB1 and tmp_OutB2 in step (4), the calculation results of the periodic task are reflected in OutB1 and OutB2. If the values are not assigned to tmp_OutB1 and tmp_OutB2 in step (4), the values of tmp_OutB1 and tmp_OutB2 are the initial values. Therefore, the values of tmp_OutB1 and tmp_OutB2 are also the initial values.
- (7) The calculation is performed during the user program execution in the periodic task that follows step (4).
 - If the values are not assigned to *tmp_OutB1* and *tmp_OutB2* in step (4), they are assigned here
- (8) OutA1, OutA2, OutB1 and OutB2 are output during I/O refreshing in the primary periodic task.
 - If the values are assigned to *tmp_OutB1* and *tmp_OutB2* in step (4), the calculation results of the periodic task are output as *OutB1* and *OutB2*.
 - If the values are assigned to *tmp_OutB1* and *tmp_OutB2* in step (7), the initial values of *OutB1* and *OutB2* are output.
- (9) The calculation is performed during the user program execution in the primary periodic task and the values are assigned to *OutA1* and *OutA2*.
 - Also, the values of *tmp_OutB1* and *tmp_OutB2* are assigned to *OutB1* and *OutB2*. If the values are assigned to *tmp_OutB1* and *tmp_OutB2* in step (7), the calculation results of the periodic task are reflected in *OutB1* and *OutB2*.

(10) OutA1, OutA2, OutB1 and OutB2 are output during I/O refreshing in the primary periodic task.

If the values are assigned to tmp_OutB1 and tmp_OutB2 in step (7), the calculation results of the periodic task are output as OutB1 and OutB2.

You can use the Lock and Unlock instructions to perform the task exclusive controls to prevent the values of tmp_OutB1 and tmp_OutB2 from being overwritten by the periodic task before they are accessed by the primary periodic task. Refer to 5-8-1 Ensuring Concurrency of Variable Values between Tasks for details on task exclusive controls.

Global Variable Table

The global variables are shown below.

Global variable table

Name	Data type	Initial value	AT specification	Comment
ComIn	BOOL	FALSE	ECAT://node#[1,1]/Input Bit 00	Common input value
OutA1	BOOL	FALSE	ECAT://node#[1,2]/Output Bit 00	Output value A1
OutA2	BOOL	FALSE	ECAT://node#[1,2]/Output Bit 01	Output value A2
OutB1	BOOL	FALSE	ECAT://node#[1,2]/Output Bit 02	Output value B1
OutB2	BOOL	FALSE	ECAT://node#[1,2]/Output Bit 03	Output value B2
tmp_OutB1	BOOL	FALSE		Temporary variable for B1
tmp_OutB2	BOOL	FALSE		Temporary variable for B2

Ladder Diagram for Primary Periodic Task

The ladder diagram for the primary periodic task is shown below.


Internal variable table

Name	Data type
A1_Wait	TON
A2_Wait	TON

External variable table

Name	Data type	Comment
ComIn	BOOL	Common input value
OutA1	BOOL	Output value A1
OutA2	BOOL	Output value A2
OutB1	BOOL	Output value B1
OutB2	BOOL	Output value B2
tmp_OutB1	BOOL	Temporary variable for B1
tmp_OutB2	BOOL	Temporary variable for B2

Algorithm



Ladder Diagram for Periodic Task


The ladder diagram for the periodic task is shown below. Internal variable table

Name	Data type
B1_Wait	TON
B2_Wait	TON

External variable table

Name	Data type	Comment
ComIn	BOOL	Common input value
tmp_OutB1	BOOL	Temporary variable for B1
tmp_OutB2	BOOL	Temporary variable for B2

Algorithm for periodic task



5-7-2 Assigning Tasks to Programs

You assign the programs to execute to tasks. (You can assign up to 128 programs to one task.) Also, you set the operation of the programs at the start of operation.

Order of Program Execution

The order of execution of the programs in a task is set with the Sysmac Studio.

Initial Status for Programs at the Start of Operation

Set the operation of the programs at the start of operation. The *Initial Status* at the start of operation is used to set whether to execute the program when the task to which the program is assigned is executed for the first time after the operating mode of the CPU Unit is changed from PROGRAM mode to RUN mode. You have a setting option between *Run* or *Stop*.

If the *Initial Status* is *Stop*, when enabling the execution of the specified program with the PrgStart instruction, it is executed from the next time the timing for executing the program occurs. If the *Initial Status* is *Run*, when disabling the execution of the specified program with the PrgStop instruction, it is disabled from the next time the timing for executing the program occurs.

Sysmac Studio Setting Procedure

Assign programs to tasks, set the order of program execution within the task, and set the *Initial Status* for each program in **Program Assignment Settings** under **Configurations and Setup – Task Settings** of the Sysmac Studio.

Refer to Program Assignment Settings on page 4-9 for details.



Version Information

The CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the *Initial Status* setting for programs at the start of operation, the PrgStart instruction and the PrgStop instruction.

POUs That You Can Assign to Tasks

From 0 to 128 programs can be assigned to one task.

You can assign only program POUs. You cannot assign function block instances or functions directly to tasks. You cannot assign the same program to more than one task.

Parameters for Primary Periodic Task and Periodic Tasks 5-7-3

The parameters for primary periodic task and periodic tasks are given below.

Parameters for Primary Periodic Tasks

Parameter		Setting range	Default	Update timing	Changes in RUN mode
Task Type		Specify the primary periodic task.		When	Not
	Execution priority	Always 4.		down- loaded to	allowed.
Task Name		Text string	Primary- Task	CPU Unit	
Period/ Execu- tion Con- ditions	Task period*1	NX701 CPU Units	1 ms*3		
		125 μs, 250 μs to 8 ms (in 250-μs increments)			
		NX102 CPU Units			
		1 ms to 32 ms (in 250-ms increments)			
		NX1P2 CPU Units			
		2 ms to 8 ms (in 250-μs increments)			
		NJ-series CPU Units			
		500 μs ^{*2} , 1 ms, 2 ms, or 4 ms			
Task Period Exceeded Detection		Specify whether to detect an error if the task execution time exceeds the specified task period.	Detect.		
		Detect (a minor fault level Controller error is generated).			
		Do not detect (an observation is recorded in event log).			
		Refer to <i>Task Period Exceeded</i> on page 5-107 for details.			
Task Timeout Detection Time		Set the time to detect timeouts if task execution does not end, e.g., if there is an infinite loop. Set a multiple of the task period. 1 to 5 Refer to <i>Task Execution Timeout</i> on page 5-108 for details.	5		
Variable Access Time [%]		Set the percentage of the task period to assign to variable access. 1% to 50% Refer to Settings for Variable Access Time on page 5-105 for details.	3%		

^{*1} The process data communications cycle (process data communications cycle 1) in the EtherCAT settings will be the same as this period.

^{*2} With the NJ301- $\square\square\square\square$, you can use this setting with unit version 1.03 or later. You cannot use this setting with the NJ101-□□□.

^{*3} For the NX102- CPU Units, NX1P2- CPU Units, and NJ101- CPU Units, the default of the primary periodic task is 2 ms.

Parameters for Priority-5 Periodic Task

Parameter		Setting range	Default	Update timing	Changes in RUN mode
Task Type		Specify the priority-5 periodic task.*1		When	Not
	Execution pri- ority	Automatically set to 5.		loaded to	allowed.
Task Name		Text string	Periodic Task0	CPU Unit	
Period/	Task period*2	NX701 CPU Units	2 ms		
Execution Conditions		125 μs, 250 μs to 100 ms (in 250-μs increments)			
Task Period Exceeded		The same as for the primary periodic task.	The same		
Detection			as for the		
Task Timeout Detection			primary		
Time			periodic		
Variable Acc	cess Time [%]		task.		

^{*1} You can use the priority-5 periodic task only with the NX701 CPU Units.

● Parameters for Priority-16, Priority-17, and Priority-18 Periodic Tasks

Parameter		Setting range	Default	Update timing	Change s in RUN mode
Task Type		You can set any of the following. Priority-16 periodic task*1 Priority-17 periodic task Priority-18 periodic task		When down- loaded to CPU Unit	Not allowed.
	Execution priority	Automatically set to 16, 17, or 18.			
Task Name		Text string	Periodic- Task0		
Period/ Execution Conditions	Task period	NX701 CPU Units Refer to 5-3-1 Specifications of Tasks for NX701 CPU Units.	10 ms		
		NX102 CPU Units and NX1P2 CPU Units			
		Refer to 5-4-1 Specifications of Tasks for NX102 CPU Units and NX1P2 CPU Units.			
		NJ-series CPU Units			
		Refer to 5-5-1 Specifications of Tasks for NJ-series Controllers.			
Task Period Exceeded Detection		The same as for the primary periodic task.	The same as for the		
Task Timeout Detection Time			primary periodic		
Variable Acce	ess Time [%]		task.		

^{*1} You cannot use the priority-16 periodic task with the NX102 CPU Units or NX1P2 CPU Units.

^{*2} The process data communications cycle 2 in the EtherCAT settings will be the same as this period.

Event Task Parameters

Parameter	Setting range	Default	Update timing	Changes in RUN mode
Task Type	Priority-8 event task Priority-48 event task		When down-loaded to	Not allowed.
Task Name	Text string	EventTask0	CPU Unit	
Execution Condition	Select either Execution by instructions or When a variable expression is satisfied.	Execution with an instruction		
Task Execution Timeout Time Set the time to detect a timeout if task execution does not end, e.g., if there is an infinite loop. The setting unit is milliseconds.		• Execution priority of 8: 200 ms		
	 Execution priority of 8: 1 to 500 ms Execution priority of 48: 1 ms to 10 s 	• Execution priority of 48:		

• Sysmac Studio Setting Procedure

Add and set the tasks in the Task Settings under Configurations and Setup on the Sysmac Stu-

Refer to Task Settings on page 4-7 for details.

5-8 Ensuring Concurrency of Variable Values

This section describes how to ensure concurrency of variable values between tasks and provides an overview of variable access from outside the Controller.

5-8-1 Ensuring Concurrency of Variable Values between Tasks

If more than one task reads or writes the same global variable, you can use either of the following two methods to ensure the concurrency of the value of the global variable between the tasks.

Method 1: Write the global variable from only one task and read the variable from the other tasks.

Use the settings for exclusive control of variables in tasks.


Method 2: With this method, you can write the global variable from more than one task. Use the task exclusive control instructions.

Method 1: Settings for Exclusive Control of Variables in Tasks

Introduction


You can specify the task that refreshes a global variable and the tasks that access the global variable. This ensures the concurrency of the value of the global variable from the point of view of the tasks that access the variable.

A single task is set to read and write the value of a specified global variable. That task is called the refreshing task. Tasks that only read the value of the global variable are also specified. These tasks are called accessing tasks. This ensures the concurrency of the value of the global variable.




Application Example

The refreshing task specification is used to ensure the concurrency of the value of a global variable within a periodic task when the variable is written in the primary periodic task.



System

If a refreshing task is set for a global variable, the accessing task, at the start of accessing task execution, always reads the most recent value of the variable that was written at the completion of refreshing task execution.




This will allow you to maintain the concurrency of the values of global variables within the tasks without performing any special programming.

If an instruction that writes the value to a global variable is used in the accessing task, an error will occur when you check the program on the Sysmac Studio.



Precautions for Correct Use

If you are using the ActEventTask instruction between two tasks, you must keep in mind when the global variables are accessed, and when they are refreshed. For example, in the following diagram, the value of the *GVarA* global variable that is accessed from the event task is the value that was current at the end of task period 1. Therefore, even if the periodic task in task period 2 writes the value of *GVarA*, that value will not be reflected in the event task. The value that the event task writes to the *GVarB* global variable is not passed to the periodic task until the start of task period 3. Even if the periodic task in task period 2 accesses the value of *GVarB*, the value that the event task writes will not be accessed.



Because of this, do not use exclusive control of variables in tasks to pass the values of global variable if you are using the ActEventTask instruction to execute event tasks. To ensure the concurrency of global variables when using the ActEventTask instruction, you should use the Task_IsActive (Determine Task Status) instruction. The Task_IsActive instruction determines whether the specified task is in execution or waiting to be executed. Use this instruction to prevent other tasks from accessing variables that the event task writes to while it is in execution. Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for details on the Task_IsActive instruction.

Restrictions

- Only one refreshing task can be set for each global variable. If it is necessary to write a global variable from more than one task, use the task exclusive control instructions described below to ensure concurrency.
- If you specify a refreshing task for a structure or union variable, you must specify only one refreshing task for the entire structure or union variable. You cannot specify a different refreshing task for different structure or union members.
- If you specify a refreshing task for an array variable, you must specify only one refreshing task for the entire array variable. You cannot specify a different refreshing task for different array elements.



Precautions for Correct Use

Do not write the value of a variable for which concurrency is required from any task that is not the refreshing task, e.g., do not write the value from the accessing task. If you read or write the value of a variable for which a refreshing task is set from any task that is not a refreshing or accessing task, the concurrency of the global variable may be lost. If you write such a program, a warning is given when the program is checked.



Additional Information

You can use a data trace to sample an external variable for a global variable for which settings for exclusive control of variables in tasks are used. This allows you to sample the values of the global variable in the refreshing and accessing tasks in a data trace. Refer to 8-6-4 Data Tracing for information on data tracing.

Sysmac Studio Setting Procedure

Set the global variables for which to specify refreshing tasks, and set the accessing tasks in the Settings for Exclusive Control of Variables in Tasks on the Task Settings Tab Page on the Sysmac Studio.

For details, refer to Settings for Exclusive Control of Variables in Tasks on page 4-10.


Method 2: Task Exclusive Control Instructions

Use the task exclusive control instructions (i.e., the Lock and Unlock instructions) when it is necessary to write the value of a global variable from more than one task while maintaining concurrency in the value of the variable. The task exclusive control instructions create a lock region from one Lock instruction to the next Unlock instruction. If a lock region in one task is being executed, the lock regions with the same lock number in other tasks are not executed. If you place the instructions that write to the global variable in lock regions, the concurrency of the value is maintained even if you write the value of the variable from more than one task.


Refer to information on the Lock and Unlock instructions in the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for details.

Example:

In this example, task A and task B both have lock region 1. The priority of task B is higher than the priority of task A. If the execution condition for task B is met during execution of lock region 1 in task A, execution of task A is paused during lock region 1 and task B is executed. However, in this case, lock region 1 in task A is not completed, so task B is paused before it processes lock region 1. When task B is paused, execution of lock region 1 in task A is started again.



When execution of lock region 1 in task A is completed, task A is paused again and the remainder of lock region 1 in task B is executed. The concurrency of the value of the global variable is maintained by implementing exclusive control of the write processing of the global variable between the tasks.





Precautions for Correct Use

- Do not make the locked regions any longer than necessary. If the lock regions are too long, the task execution period may be exceeded.
- Always use the Lock and Unlock instructions in a pair in the same section of the same POU.

Example of Accessing the Same Global Variable Between Tasks

This section describes how to request processing to another task with multiple global variables.

The following sample programming uses one global variable *gReq* as an exclusive flag for processing to perform exclusive control in the user program. Even in this case, exclusive control of variables in tasks is required for the access logic to the *gPar1*, *gPar2*, and *gReq* global variables that are used between tasks.

A sample programming that uses the task exclusive control instructions (i.e., the Lock and Unlock instructions) to perform exclusive control is shown.

Global Variables

Name	Data type	Comment
gReq	BOOL	Request flag
gPar1	ULINT	Parameter 1
gPar2	DATA_AND_TIME	Parameter 2

Task That Makes Processing Requests (MainTask)

· Internal Variables

Name	Data type	Comment
ReqTrg	BOOL	Request trigger
cCnt	ULINT	100-ms counter value
cTime	DATA_AND_TIME	Current time

ST Program

(* Get the 100-ms counter value. *) cCnt:=Get100msCnt(); (* Get the current time. *) cTime:=GetTime(); (* Start an exclusive lock between tasks. *) Lock(1); IF ReqTrg=TRUE AND gReq=FALSE THEN (* Access the exclusive flag. *) gPar1:=cCnt; (* Set the parameter to process in SubTask. *) gPar2:=cTime; (* Set the parameter to process in SubTask. *) gReq:=TRUE; ReqTrg:=FALSE;

Task That Receives Processing Requests (SubTask)

· Internal Variables

END_IF; Unlock(1);

Name	Data type	Comment
ReqBusy	BOOL	
UserDefFB_ins	UserDefFB	User-defined function block instance that executes processing

ReqBusy:=FALSE;

END_IF;

• ST Program (* Start an exclusive lock between tasks. *) Lock(1); IF gReq=TRUE AND ReqBusy=FALSE THEN (* Access the exclusive flag. *) ReqBusy:=TRUE; UserDefFB_ins.PutData:=gPar1; (* Read the parameter from MainTask. *) UserDefFB_ins.PutDate:=gPar2; (* Read the parameter from MainTask. *) gReq:=FALSE; (* Reset the exclusive flag. *) UserDefFB_ins.Execute:=TRUE; END_IF; Unlock(1); (* Stop an exclusive lock between tasks. *) UserDefFB_ins(); IF UserDefFB_ins.Done:=TRUE THEN UserDefFB_ins.Execute:=FALSE;

(* Stop an exclusive lock between tasks. *)

5-8-2 Variable Access from Outside the Controller


A variable access from outside the Controller is executed during the system service. The system service has a lower execution priority than tasks. This means, if multiple variables are accessed from outside the Controller, refreshing all variable values may not be completed in a task period. If refreshed variables and not-refreshed variables are mixed in the user program, the Controller may perform unintended operation.

To avoid this, make the variable access from outside the Controller be executed during the system common processing 2 of the task. By making this, multiple variable values can be securely refreshed in the same task period.


Accessing Variables from Outside the Controller during the System Service

Whether you use an NX-series CPU Unit or an NJ-series CPU Unit, access to multiple variables may not be completed in the same task period.

NX-series CPU Unit




NJ-series CPU Unit



Accessing Variables from Outside the Controller during the System Common Processing 2

Whether you use an NX-series CPU Unit or an NJ-series CPU Unit, access to multiple variables is executed in the same period.



This section particularly describes how to execute the variable access from outside the Controller during the system common processing 2 of the task.

Methods to Access Variables From Outside the Controller

There are the following four methods to access variables from outside the Controller.

- Sysmac Studio
- NA/NS-series PT
- · EtherNet/IP tag data links
- CIP communications instruction from the host computer

If the Sysmac Studio is used to access variables, it can only refresh the variable values during the system common processing 2 of the task. Values are accessed during the system services.

Tasks that Execute Variable Access during the System Common **Processing 2**

The tasks that execute variable access from outside the Controller during the system common processing 2 are predetermined as follows according to the variable types.

Variable	Tasks that refresh values
Global variables specified in the settings for exclusive control of variables in tasks	The refreshing task specified in Settings for Exclusive Control of Variable in Tasks under Configurations and Setup – Task Settings on the Sysmac Studio.
Device variables for EtherCAT slaves	Tasks specified in I/O Control Task Settings under
Device variables for CJ-series Basic I/O Units	Configurations and Setup – Task Settings on the Sysmac Studio.
Device variables for CJ-series Special Units	Primary periodic task
Variables with AT specifications in memory used for CJ-series Units	

Note You can use CJ-series Units only with NJ-series CPU Units.

Note You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

Settings for Executing Variable Access during the System Common **Processing 2**

To access variables from outside the Controller during the system common processing 2, it is necessary to make the following two settings on the Sysmac Studio.

- Settings for exclusive control of variables in tasks (when the target variables are the global variables)
- · Settings for Variable Access Time

Settings for Exclusive Control of Variables in Tasks

If global variables are accessed from outside the Controller during the system common processing 2 of the task, it is necessary to make setting for exclusive control of variables in tasks. The Exclusive Control of Variables in Tasks refers to the function that specifies the task that can refresh the target global variable. This function prevents the target variable from being updated by other tasks or by other methods to access variables from outside the Controller.

For the details on the exclusive control of variables in tasks, refer to Settings for Exclusive Control of Variables in Tasks on page 4-10.



Precautions for Correct Use

When you use EtherNet/IP tag data links, always specify the same task as the refreshing task for all tags (variables that have Network Publish attribute) in the same tag set. Otherwise, multiple tags in a tag set may be refreshed in separate task periods.

Settings for Variable Access Time

When variable access from outside the Controller is executed during the system common processing 2 of the task, the task execution time may be longer. The user must set the upper limit of the processing time for accessing variables on the Sysmac Studio. The Variable Access Time refers to the upper limit of the processing time for accessing variables.

Calculating Variable Access Time

Use the following equation for calculating the variable access time.

Variable access time [μ s] = total size of variables [bytes] * a + number of variables * b + number of accesses * c + d

The values of the constants a to d in above equation vary depending on the type of the CPU Unit.

CPU Unit model		Constant value [μs]			
GF 6 Gillt illodei	а	b	С	d	
NX701-□□□□	0.0005	0.033	2.67	7.22	
NX102-□□□□	0.0040	0.240	3.27	25.21	
NX1P2-□□□	0.0040	0.240	3.27	25.21	
NJ501-□□□□	0.0010	0.490*1	1.41	6.68	
NJ301-□□□□	0.0015*2	0.560*3	2.15	7.52	
NJ101-□□□□	0.0015	1.070	3.83	10.29	

^{*1} The constant value is 0.58 for a CPU Unit with unit version 1.02 or earlier.

Setting Variable Access Time

Set the variable access time in the **Task Settings** Display under **Configurations and Setup** – **Task Settings** on the Sysmac Studio. The setting must be made for each task by entering the ratio to the task period. The default value is 3%. For the details on the settings, refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504).

Example of Variable Access Time Setting

The following is an example of variable access time setting.

In this example, it is assumed that there are the following three variable accesses from outside the Controller to the task that operates in the NJ501- $\square\square\square\square$ CPU Units.

Access No.	Source of variable access	Total size of variables to access [bytes]	Number of variables to access	Number of accesses
1	EtherNet/IP tag data link	600	8	1
2	EtherNet/IP tag data link	200	4	1
3	CIP communications instruction	1,000	1	1

^{*2} The constant value is 0.0009 for a CPU Unit with unit version 1.02 or earlier.

^{*3} The constant value is 1.03 for a CPU Unit with unit version 1.02 or earlier.

Using the equation, the variable access time for Access No.1 is calculated as follows.

Variable access time for Access No.1 =
$$600 * 0.001 + 8 * 0.49 + 1 * 1.41 + 6.68$$

= $12.61 [\mu s]$

In the same way, you can calculate the access time for the other accesses and get the following values.

Access No.	Variable Access Time [µs]
1	12.61
2	10.25
3	9.58

If only one of these accesses occurs in one task period, you set the Variable Access Time to the one for Access No.1, which requires the longest access time.

The variable access time for Access No.1 is 12.61 µs. Therefore, when the task period is 500 µs, the Variable Access Time is set to $12.61/500 \approx 3\%$.

If every access occurs once in one task period, the Variable Access Time is calculated with the equation as follows.

Variable access time =
$$(600 + 200 + 1000) * 0.001 + (8 + 4 + 1) * 0.49 + (1 + 1 + 1) * 1.41 + 6.68$$

= 19.08 [µs]

When the task period is 500 μ s, the Variable Access Time is set to $19.08/500 \approx 4\%$.

Processing in the case that actual variable access time became longer than set value

If actual variable access time became longer than the set value, the following processing is performed depending on the number of variable accesses in one task period.

Set a sufficiently long access time so that multiple variable accesses can be completed within a task period.

Number of vari- able accesses in one task period	Processing
Multiple times	Variable accesses are executed for the number of times that can be completed within the set variable access time. The rest of accesses that could not be done will be executed in the next task period.
	This means, the multiple variable accesses cannot be completed within the same task period.
Once	Variable accesses continue even after the set variable access time is exceeded. This means, the task execution time gets longer.

5-9 Errors Related to Tasks

This section describes the following errors.

- · Task Period Exceeded
- · Motion Control Period Exceeded
- · Task Execution Timeout
- I/O Refreshing Timeout Error
- · Insufficient System Service Time Error


Task Period Exceeded

A Task Period Exceeded error occurs if the task execution time exceeds the specified task period.

This is a minor fault level Controller error. Operation continues even when this error occurs.

It can occur for the primary periodic task and periodic tasks.

You can also disable the Task Period Exceeded errors with a setting. Use the Task Period Exceeded Detection setting in the Task Settings of the Sysmac Studio. The default setting is to detect the error.



Error name	Error level	Correction
Task Period Exceeded	Minor fault	Review the task settings and programs and download the project again.
		Reset the error from the Sysmac Studio.

Even if the Task Period Exceeded Detection setting is disabled, information will be output to the following system-defined variables if task processing is not completed within the period: Task Period Exceeded Flag (_TaskName_Exceeded), Task Period Exceeded Count (_TaskName_ExceedCount), Controller Error Status (_ErrSta), and the event log.

I/O is refreshed as follows according to what the I/O is for if task processing is not completed within the task period.

I/O is for	I/O refresh operation if task processing is not completed within the task period
EtherCAT slave*1	Outputs: The values from the previous period are output.
NX Units on the CPU Unit*2	Inputs: Inputs are refreshed, but the input data is not updated in the executed user program.
Built-in I/O*3	
CJ-series Unit	I/O is not refreshed until execution of the task is completed.

^{*1} This includes NX Units on EtherCAT Slave Terminals.

^{*2} You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

^{*3} You can use the built-in I/O only with the NX1P2 CPU Units.



Precautions for Correct Use

If the Task Period Exceeded error occurs, shorten the programs to fit in the task period or increase the setting of the task period.

Motion Control Period Exceeded

A Motion Control Period Exceeded error occurs if the motion control processing (MC) is not completed within the primary period (i.e., the motion control period) twice or more in a row. A partial fault level Controller error will occur in the Motion Control Function Module. A Task Period Exceeded error will occur at the same time.


Error name	Error level	Correction
Motion Control Period Exceeded	Partial fault	Reduce the amount of processing in the programs or increase the control period within the range that does not adversely affect operation.

Task Execution Timeout

A Task Execution Timeout error occurs if task processing is not completed within the specified Task **Execution Timeout Time.**

This is a major fault level Controller error. Execution of the user program stops when the error occurs.

This error also occurs when normal task operation is not possible due to errors in program logic, such as infinite loops.




Error name	Error level	Correction
Task Execution	Major fault	Review the task settings and download the user program again.
Timeout		The power supply must be cycled or the CPU Unit reset.

I/O Refreshing Timeout Error

An I/O Refreshing Timeout Error occurs when I/O refreshing for the primary periodic task or a priority-16 periodic task is not completed within the period twice or more in a row.

This is a major fault level Controller error. Execution of the user program stops when the error occurs.



Error name	Error level	Correction
I/O Refreshing	Major fault	Review the task settings and download the project again.
Timeout Error		The power supply must be cycled or the CPU Unit reset.

Insufficient System Service Time Error

With an NJ-series CPU Unit, an Insufficient System Service Time Error occurs if the system service execution time that is specified in the System Service Monitoring Settings cannot be obtained. This is a major fault level Controller error. Execution of the user program stops when the error occurs.

Error name	Error level	Correction
Insufficient Sys- tem Service Time	Major fault	Review the task settings and the system service monitoring settings and download the project again.
Error		The power supply must be cycled or the CPU Unit reset.



Additional Information

NX-series CPU Units are designed to always secure sufficient time for system service execution, so the System Service Monitoring Settings are not provided. Also an Insufficient System Service Time Error will not occur.

Monitoring Task Execution Status 5-10 and Task Execution Times


You can use online operations from the Sysmac Studio to monitor the task execution status and task execution times.

Monitoring Task Execution Status

You can monitor the execution status of the programs in all of the tasks (started/stopped) from the Sysmac Studio.

Sysmac Studio Operation

Place the Sysmac Studio online with the CPU Unit and select Configurations and Setup - Task Settings. Click the Task Execution Status Monitor Button to display the following window.




Task Execution Time Monitor

You can monitor the execution time of each task from the Sysmac Studio.


Values You Can Monitor from the Sysmac Studio

The display depends on whether you connect to the physical Controller or to the Simulator.

Connected to the Controller



Connected to the Simulator






Additional Information

To check or estimate the system service execution time, the task execution time ratio, system service execution ratio, estimated CPU usage rate, tag data service execution ratio, expanded number of I/O points for CJ-series Unit, and built-in EtherNet/IP are displayed for NJ-series CPU Units.

The above information are not displayed for NX-series CPU Units because the system services are executed at the required time without being affected by the tasks.

Built-in EtherNet/IP Dialog Box for Simulator Connection



The parameters are listed in the following table.

Port or Unit that is used	Parameter	Description	Set values	Default
CPU Unit Built-in Eth- erNet/IP Port	Number of con- nections	This is the number of tag data link connections.	0 to 32	0
	Minimum RPI	This is the lowest packet interval (RPI) that is set for all of the tag data link connections.	1 ms to 10 s in 1-ms incre- ments	
CJ-series EtherNet/IP Unit (CJ1W-EIP21)*1	Number of tags	This is the number of tags in the tag data links.	0 to 256	0

^{*1} Entries are made on the Expanded number of I/O points for CJ-series Unit Dialog Box.

You can monitor the following items.


Mor	nitor item	Description	Connected to the Con- troller	Connected to the Sim- ulator
Task exe- cution	Min.	The minimum value of the task execution time.	Displayed.	Not dis- played.
time ^{*1}	Average	The maximum value of the task execution time.		Displayed.
	Max.	The maximum value of the task execution time.		
Set period		The specified task period.*2		
Period exce	eded	If the task execution time exceeds the task period (i.e., if the Task Period Exceeded Flag system-defined variable is TRUE), the amount by which the time was exceeded is displayed in the bar.*2		
Task execution count		Displays the number of executions of the task. The value of the Task Execution Count system-defined variable is displayed.		
Real proces tasks*3	sing time of	The time ratios are displayed with bars for the system common processing, I/O refreshing, user program execution, and motion control processing. (Specific time values are not displayed.)	Not dis- played.	Displayed.
	Average esti- mation	The estimated average value of the real processing time of task is displayed.		
	Max estimation	The estimated maximum value of the real processing time of task is displayed.		
Task execution time ratio*4		The percentage of the total task execution time per unit time.	Displayed.	Not dis- played.

^{*1} This is the actual time required from the point that task execution was started until it was completed. This interval includes both the time to execute other tasks and the time for system services that were executed from when task execution was started until it was completed.

Only the primary periodic task is displayed when a Simulator for an NX701 CPU Unit is connected.

^{*2} This item is not displayed for event tasks.

*3 This interval is the time required to execute only the task itself. It is the same as the task execution time for the primary periodic task. For periodic tasks, this is the task execution time minus the time to execute other tasks and the time for system services that were executed between the point that the execution condition is met until execution is completed.



*4 This item was added for version 1.12 of the Sysmac Studio. It is not displayed for an NX-series CPU Unit.




Precautions for Correct Use

The above values when connected to the Simulator of the Sysmac Studio may contain more error in comparison to the times when connected to the physical Controller. Use them as guidelines. Always confirm operation while connected to the physical Controller to study the designs and before starting actual system operation.

Meaning of the Task Execution Time and the Real Processing Time of the Task

The Task Execution Time and Real Processing Time of Tasks that are displayed in the Monitor View for the execution time of tasks are described in the following table. The Real Processing Time of Tasks shows only the time the Simulator was connected.

Displayed time	Meaning
Task execution time	This is the time from when the task period starts until task processing ends. However, this includes the time when the periodic task is interrupted for execution of tasks with higher execution priorities.
Real processing time of task	This is the time from when the task period starts until task processing ends. However, this does not include the time when the periodic task is interrupted for execution of tasks with higher execution priorities.



- a: Task execution time of primary periodic task
- b: Task execution time of periodic task

c+d: Real processing time of periodic tasks (only when the Simulator is connected).

5-11 Task Design Methods and I/O **Response Times**

This section provides guidelines for designing tasks, information on estimating task execution times, information on confirming system service monitoring settings, an example of task designing, and information on I/O response times.

The primary periodic task and periodic tasks of an NJ/NX-series Controller operate according to the specified task periods. If the actual execution time exceeds the task period, an error occurs.

This section uses an example that consists of one primary periodic task to describe estimation and appraisal methods.



Precautions for Safe Use

The task execution times in the physical Controller depends on the logic operations that are performed in the user program, the presence of communications commands and data links, on whether data tracing is performed, and on other factors. Before starting actual operation, you must test performance under all foreseeable conditions on the actual system and make sure that the task periods are not exceeded and that suitable communications performance is achieved.

5-11-1 **Checking the Task Execution Time**

Always design your system so that the average and maximum task execution times that are estimated with the methods that are described in this section sufficiently fit within the specified task periods.

Desktop Calculations

First, refer to A-2 Calculating Guidelines for the Real Processing Times of Tasks for the NX701 System, A-3 Calculating Guidelines for the Real Processing Times of Tasks for the NX102 System, A-4 Calculating Guidelines for the Real Processing Times of Tasks for the NX1P2 System and A-5 Calculating Guidelines for the Real Processing Times of Tasks for the NJ-series System to make a rough estimate of the average task execution time on paper. You cannot estimate the maximum value on paper.

Estimating with the Simulator on the Sysmac Studio

Use the Task Execution Time Monitor of the Simulator on the Sysmac Studio to estimate the average and maximum task execution times. Use the following procedure to check operation on the Simulator.

- 1 Create the Unit and slave configurations, create the global variables and device variables, and create the axes (to create the Axis Variables).
- **2** Create the programs to check.
- **3** Set up the tasks and build the project.
- **4** Start the Simulator in Execution Time Estimation Mode.
- **5** Select the relevant hardware revision in the Unit that the hardware revision is displayed.
- With an NJ-series CPU Unit, set the Expanded number of I/O points in the CJ-series Unit parameters in the Task Execution Time Monitor to create user-defined variables for specified CJ-series Special Units. Also set the sizes of the expansion areas (e.g., fixed I/O allocation areas for the DeviceNet Unit) for AT specifications (i.e., the number of output words and the number of input words). These sizes are used to calculate the I/O refresh time for the specific Special Units.
- **7** Estimate the task execution times in the Task Execution Time Monitor.

You can check the following values in the Task Execution Time Monitor when you start the Simulator in Execution Time Estimation Mode.

- The average and maximum values of the task execution time
- The average and maximum values of the real processing times of the tasks
- Bar graph that shows the system common processing time, I/O refreshing time, user program execution time, and motion control time
- · CPU usage

Note Only the primary periodic task is displayed for an NX-series CPU Unit.



Additional Information

You can check the following values when connected to the Simulator of the Sysmac Studio. You cannot check these values when connected to the physical Controller.

- CPU usage: Displays how much of the task period is used by the total of the maximum estimated task processing time, the tag data link service execution time ratio, and the system service processing time of an NJ-series CPU Unit (as specified in the system service monitoring settings). If CPU usage exceeds 100%, it means that there is not sufficient time for task processing and the system service monitoring settings.
 - This information is not displayed for an NX-series CPU Unit.
- Real processing time of tasks: This is the time that was required for the task from when task
 execution is started until it is completed. The time to execute other tasks that were executed
 from when task execution was started until it was completed is not included.

Calculating Times on the Physical Controller

You can check the following values in the Task Execution Time Monitor when you are connected to the physical Controller.

- · The minimum, average, and maximum values of the task execution time
- Set period
- Number of times a task is executed (Task Execution Count)
- Number of times the task period was exceeded (Task Period Exceeded Count)
- Task execution time ratio

The maximum values that are displayed on the Sysmac Studio are the results of operation on the physical Controller. As described previously, the maximum value of the task execution time varies depending on the internal status of the physical Controller. As a result, the maximum values obtained here may be exceeded in actual operation. Use the obtained values or the larger values in the following calculating results as guidelines of maximum values.

NX-series CPU Units

(Average value of task execution time + (Average value of task execution time - Minimum value of task execution time)) \times 1.2 + 25 μ s

NJ-series CPU Units

- Task period of 500 μs: Average value of task execution time + (Average value of task execution time – Minimum value of task execution time) + 100 μ s
- Task period of 1, 2, or 4 ms: Average value of task execution time + (Average value of task execution time – Minimum value of task execution time) + 120 μs

For NJ-series CPU Units, you can also check whether sufficient system service execution time is obtained.

Insufficient system service execution time may decrease the online operations of the Sysmac Studio or the communications response performance with external devices such as an HMI. For NJ-series CPU Units, system services are executed during the unused time between execution of the tasks. Use the following guideline for the task execution time ratio.

CPU Unit model	Guideline for task execution time ratio
NJ501-□□□□	90% or less
NJ301-□□□□	80% or less
NJ101-□□□□	70% or less



Version Information

- The task execution time ratio is displayed when an NJ-series CPU Unit is used with Sysmac Studio version 1.12 or higher.
- Use an NJ101-□□□□ CPU Unit with Sysmac Studio version 1.13 or higher. You cannot use an NJ101-□□□□ CPU Unit with Sysmac Studio version 1.12 or lower.



Precautions for Correct Use

NX-series CPU Units are designed to always secure sufficient time for system service execution. Therefore, the task execution time ratio is not displayed.



Additional Information

The average values of the task execution times that are displayed for task execution time monitoring are the averages for 10 task execution times.

5-11-2 Examples of Task Design

This section provides the design procedure for a project that consists of only the primary periodic task. In any actual application or for specific conditions, you need to consider any elements for which the design procedure must be changed. This example is therefore for reference only.

- **1** Find the I/O response times that are required for the system from the equipment specifications.
- **2** From the system I/O response times, determine the task period for the primary periodic task.
- See if the task execution time fits into the task period that you determined.
 Then, work on paper or use the Task Execution Time Monitor of the Sysmac Studio to estimate the average and maximum values of the task execution time.
- **4** For NJ-series CPU Units, see if the system service times are within the monitor settings. If you use the Sysmac Studio, check the CPU usage.
- Use the physical Controller to see if the task execution time fits into the task period.
 Place the Sysmac Studio online with the physical Controller and use Task Execution Time Monitor to check the task execution times.
- If only the primary periodic task is too large to fit within the specified task period, consider separating it into periodic tasks as follows.
 - For the NX701 CPU Units, among processes required for device control, assign those which require the high-speed control to the primary periodic task and other processes to the priority-5 periodic task.
 - To reduce the task execution time, use the Enable Program (PrgStart) and Disable Program (PrgStop) instructions to execute the program assigned to the primary periodic task only when necessary.
 - If the primary periodic task will still not fit within the specified task period after these measures, among the processes of primary periodic task, assign those which do not require the high-speed or high-accuracy control to the priority-16 periodic task or the priority-17 periodic task. However, if variables such as the Axis Variables are accessed between the primary periodic task and the priority-16 periodic task, the task execution time for the primary periodic task may be longer. For details, refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507).
 - If the primary periodic task will still not fit within the specified task period even after you take all of these measures, change the task period for the primary periodic task.
- If a task is separated, the periodic task will vary greatly with the unused time for primary periodic task execution.

For a periodic task, use twice the average and maximum values calculated for the task execution time to set the task period and then fine-tune the setting from there.

5-11-3 **System Input and Output Response Times**

The times that are required for the system to produce an output after it receives an input are described in this section.

The I/O response times depend on various conditions.

The input response times and output response times between external devices and the slaves and Units must be added to the system I/O response times.

Sequence Control with Basic I/O Units

I/O refreshing between Basic I/O Units and external devices is performed in the task to which I/O refreshing is assigned. The I/O response times that include EtherCAT communications times are given below.


The I/O response times that include EtherCAT communications times are given below.

Performing Control with the Programs in the Primary Periodic Task

The Controller makes a response in the following I/O response time.

Minimum I/O response time = Primary period

Example: Controlling Unit A and Unit B with the Primary Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the Unit.


Maximum I/O response time = Primary task period × 2

Performing Control with the Programs in the Priority-16 Periodic Task

The Controller makes a response in the following I/O response time.

Minimum I/O response time = Priority-16 periodic task period

Example: Controlling Unit A and Unit B with the Priority-16 Periodic Task



Note: The above diagram shows only one input and one output

However, the I/O response time may be as follows depending on the timing of the input from the Unit.

Maximum I/O response time = Priority-16 periodic task period × 2

Sequence Control with EtherCAT Slaves

For EtherCAT slaves, EtherCAT communications with external devices is performed for I/O refreshing in the primary periodic task.


The I/O response times that include EtherCAT communications times are given below.

Performing Control with the Programs in the Primary Periodic Task

The Controller makes a response in the following I/O response time.

Minimum I/O response time = Primary period (= process data communications cycle)

Example: Controlling EtherCAT Input Slave A and EtherCAT Output Slave B with the Primary Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the slave.


Maximum I/O response time = Primary period (= process data communications cycle) \times 2

Performing Control with the Programs in the Priority-5 Periodic Task

When you perform control with the user program in the priority-5 periodic task, the NX701 CPU Unit makes a response in the following I/O response time.

Maximum I/O response time = Priority-5 periodic task period (= process data communications cycle 2)

Example: Controlling EtherCAT Input Slave A and EtherCAT Output Slave B with the Priority-5 Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the slave.


Maximum I/O response time = Priority-5 periodic task period (= process data communications cycle 2) × 2

Performing Control with the Programs in the Priority-16 Periodic Task

The Controller makes a response in the following I/O response time.

I/O response time = Priority-16 periodic task period

Example: Controlling EtherCAT Input Slave A and EtherCAT Output Slave B with the Priority-16 Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the slave.

Maximum I/O response time = Priority-16 periodic task period $\times 2$



Additional Information

Refer to the NX-series EtherCAT Coupler Units User's Manual (Cat. No. W519) for the I/O response times for an EtherCAT Slave Terminal that the NX Units are mounted after the Ether-CAT Coupler Unit.

Sequence Control with NX Units on the CPU Unit

For NX Units on the NX102 CPU Unit and NX1P2 CPU Unit, data exchange with external devices is performed for I/O refreshing in the primary periodic task.

For NX Units on the CPU Unit, the following describes both of the I/O response times for the CPU Unit inside and I/O response times that include NX Unit processing times.


The I/O response times for the CPU Unit inside are given below.

Performing Control with the Programs in the Primary Periodic Task

The Controller makes a response in the following I/O response time.

Minimum I/O response time = Primary period

Example: Controlling Input Unit A and Output Unit B with the Primary Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the Unit.


Maximum I/O response time = Primary period \times 2

Performing Control with the Programs in the Priority-17 Periodic Task

The Controller makes a response in the following I/O response time.

I/O response time = Priority-17 periodic task period

Example: Controlling Input Unit A and Output Unit B with the Priority-17 Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the Unit.

Maximum I/O response time = Priority-17 periodic task period × 2

Next, the I/O response times that include NX Unit processing times are given below.

The I/O response time is the time required for the following processing: The CPU Unit processes an external signal input to one NX Unit, and another NX Unit outputs the processed result as an external signal.

The I/O response times that include NX Unit processing times depend on the I/O refreshing method of the NX Unit.

The following provides a description to perform control with the programs in the primary periodic task for each of the I/O refreshing method of the NX Unit, including synchronous I/O refreshing, time stamp refreshing, and Free-Run refreshing.

The elements in the formulas are as follows:

Tnx-InProc : Input data processing time of the NX Unit Tnx-OutProc : Output data processing time of the NX Unit

Tnx-Indelay : Input delay time of the NX Unit **Tnx-Outdelay** : Output delay time of the NX Unit

For each element, there is a unique value for each type of NX Unit. Refer to the appendix of the NXseries Data Reference Manual (Cat. No. W525-E1-07 or later) for the value of each element.


Synchronous I/O Refreshing

With synchronous I/O refreshing, when there is more than one NX Unit that is connected to the CPU Unit, the inputs are read or the outputs are updated simultaneously for all NX Units that support synchronous I/O refreshing. Therefore, Tnx-InProc (input data processing time of the NX Unit) and Tnx-OutProc (output data processing time of the NX Unit) are the longest time of the NX Units that support synchronous I/O refreshing.

The Controller makes a response in the following I/O response time.

Minimum I/O response time = Tnx-InDelay + Tnx-InProc + Primary period + Tnx-OutDelay + Tnx-OutProc

Example: Controlling Input Unit A and Output Unit B with the Primary Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the Unit.

Maximum I/O response time = Tnx-InDelay + Tnx-InProc + Primary period x 2 + Tnx-OutDelay + Tnx-OutProc + NX Unit processing time*1

^{*1} Refer to NX Unit Processing Time on page A-44 for information on the NX Unit processing time.

Time Stamp Refreshing

The I/O response time for time stamp refreshing is the specific time required to produce the output after the input changed time. You specify the time in the user program. Specify a time that has a sufficient leeway to ensure that the output is produced at the expected time.


The minimum specified time for which the expected output is produced is defined as the maximum I/O response time for time stamp refreshing. It is described in the following.

With input refreshing with input changed times for time stamp refreshing, when there is more than one NX Unit that is connected to the CPU Unit, the inputs for all NX Units that support synchronous input refreshing and the changed times for all NX Units that support input refreshing with input changed times. Therefore, Tnx-InProc (input data processing time of the NX Unit) and Tnx-OutProc (output data processing time of the NX Unit) are the longest time of the NX Units that support synchronous I/O refreshing.

The Controller makes a response in the following I/O response time.

Minimum I/O response time = Tnx-InDelay + Tnx-InProc + Primary period + Tnx-OutDelay + Tnx-OutProc

Example: Controlling Input Unit A and Output Unit B with the Primary Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the Unit.

Maximum I/O response time = Tnx-InDelay + Tnx-InProc + Primary period x 2 + Tnx-OutDelay + Tnx-OutProc + NX Unit processing time*1

^{*1} Refer to NX Unit Processing Time on page A-44 for information on the NX Unit processing time.


Free-Run Refreshing

With Free-Run refreshing, the refresh cycle of the NX bus and the I/O refresh cycle of the NX Units operate asynchronously.

The Controller makes a response in the following I/O response time.

Minimum I/O response time = Tnx-InDelay + Tnx-InProc + Primary period + Tnx-OutDelay + Tnx-OutProc

Example: Controlling Input Unit A and Output Unit B with the Primary Periodic Task



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the Unit and the timing of the output to the Unit.

```
Maximum I/O response time = Tnx-InDelay + Tnx-InProc x 2 + Primary period x 2 + Tnx-OutDelay + Tnx-OutProc
                                      x 2 + NX Unit processing time*1
```

^{*1} Refer to NX Unit Processing Time on page A-44 for information on the NX Unit processing time.



Additional Information

With Free-Run refreshing, the Input Unit, CPU Unit and Output Unit operate asynchronously. Therefore, an offset of timing that the Input Unit reads signals from input terminals, an offset of timing that the CPU Unit reads the input data from the Input Unit, and an offset of timing that the Output Unit outputs signals to output terminals will occur.

Tnx-InProc, primary period, and Tnx-OutProc will be the longest time of an offset of timing for each Unit.

Performing Motion Control with Motion Control Instructions

Motion control instructions access the Servo Drive and encoder input slaves to which axes are assigned.

For the NX102 CPU Units and NX1P2 CPU Units, motion control instructions can be used in the primary periodic task.

The motion control instructions are processed in the motion control processing (MC) section of the primary periodic task.

For NJ-series CPU Units, motion control instructions can be used in the primary periodic task and in a priority-16 periodic task.

In either case, the motion control instructions are processed in the motion control processing (MC) section of the primary periodic task.

For the NX701 CPU Units, motion control instructions can be used in the primary periodic task, in the priority-16 periodic task, and in the priority-5 periodic task.

The motion control instructions included in the primary periodic task and in a priority-16 periodic task are executed in the motion control processing (MC) section of the primary periodic task.


The motion control instructions included in a priority-5 periodic task are executed in the motion control processing (MC) section of the priority-5 periodic task.

The I/O response times that include EtherCAT communications times are given below.

Programming Motion Control Instructions in the Primary Periodic Task

The motion control instructions are processed in the next motion control processing (MC) section of the primary periodic task. The results of processing are output to the EtherCAT slave or NX Unit to which the axis is assigned during the I/O refresh period in the next primary periodic task. The Controller makes a response in the following I/O response time.

I/O response time = Primary period (= process data communications cycle)



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the slave.


Maximum I/O response time = Primary period (= process data communications cycle) × 2

Programming Motion Control Instructions in the Priority-5 Periodic Task

The motion control instructions are processed in the immediate motion control processing (MC) section in the priority-5 periodic task. The results of processing are output to the EtherCAT slave to which the axis is assigned during the I/O refresh period in the next priority-5 periodic task.

The Controller makes a response in the following I/O response time.

I/O response time = Priority-5 periodic task period (= process data communications cycle)



Note: The above diagram shows only one input and one output.

However, the I/O response time may be as follows depending on the timing of the input from the slave.


Maximum I/O response time = Priority-5 periodic task period (= process data communications cycle 2) × 2

Programming Motion Control Instructions in the Priority-16 Periodic Task

The motion control instructions are processed in the next motion control processing (MC) section of the primary periodic task after the priority-16 periodic task. The results of processing are output to the EtherCAT slave to which the axis is assigned during the I/O refresh period in the next primary periodic task.

The Controller responds in the following I/O response time regardless of the execution timing of the motion control instructions.

> Minimum I/O response time = Priority-16 periodic task period + Primary period (= process data communications cycle)




Note: The above diagram shows only one input and one output.

However, the response time may be as follows depending on the timing of the input from the slave.

Maximum I/O response time = Priority-16 periodic task period + Primary period (= process data communications cycle) \times 2

Simultaneous Execution of More Than One Axis

If more than one axis is controlled in the same task period by the programs in the same task, they can be started at the same time.





Additional Information

You can access the values of Axis Variables in the tasks other than those for axis control. For detailed usage and precautions, refer to the *NJ/NX-series CPU Unit Motion Control User's Manual* (Cat. No. W507).



Programming

This section describes programming, including the programming languages, and the variables and instructions that are used in programming.

6-1	Overvi	ew of Programming Procedures	6-3
6-2	POUs	(Program Organization Units)	6-5
	6-2-1	What Are POUs?	
	6-2-2	Overview of the Three Types of POUs	
	6-2-3	Differences between Programs, Functions, and Function Blocks	
	6-2-4	Details on Programs	
	6-2-5	Details on Function Blocks	6-8
	6-2-6	Details on Functions	6-17
	6-2-7	Operation That Applies to Both Functions and Function Blocks	6-22
	6-2-8	POU Restrictions	6-24
6-3	Variabl	es	6-27
	6-3-1	Variables	6-27
	6-3-2	Types of Variables	6-27
	6-3-3	Types of User-defined Variables in Respect to POUs	6-28
	6-3-4	Attributes of Variables	6-29
	6-3-5	Data Types	6-30
	6-3-6	Derivative Data Types	6-40
	6-3-7	Array Specifications and Range Specifications for Data Types	6-50
	6-3-8	Variable Attributes	6-59
	6-3-9	Changes to Variables for Status Changes	6-67
	6-3-10	Function Block Instances	6-82
	6-3-11	Monitoring Variable Values	6-82
	6-3-12	Restrictions on Variable Names and Other Program-related Names	6-83
6-4	Consta	ants (Literals)	6-85
	6-4-1	Constants	6-85
	6-4-2	Notation for Different Data Types	6-85
6-5	Progra	mming Languages	6-90
	6-5-1	Programming Languages	
	6-5-2	Ladder Diagram Language	
	6-5-3	Structured Text Language	

6-6	Instruc	ctions	6-133
	6-6-1	Instructions	6-133
	6-6-2	Basic Understanding of Instructions	6-133
	6-6-3	Instruction Errors	6-136
6-7	Names	spaces	6-142
	6-7-1	Namespaces	6-142
	6-7-2	Namespace Specifications	6-143
	6-7-3	Procedure for Using Namespaces	6-146
6-8	Librari	es	6-147
	6-8-1	Introduction to Libraries	6-147
	6-8-2	Specifications of Libraries	6-148
	6-8-3	Library Object Specifications	6-149
	6-8-4	Procedure to Use Libraries	6-150
6-9	Progra	amming Precautions	6-151
	6-9-1	Array Specifications for Input Variables, Output Variables, In-Out	
		Variables	6-151
	6-9-2	Structure Variables for Input Variables, Output Variables, In-Out	
		Variables	6-151
	6-9-3	Master Control	6-152

6-1 Overview of Programming Procedures

This section provides an overview of programming procedures.

The shaded steps in the overall procedure that is shown below are related to programming.

Step 1. Software Design

Step 1-1 Designing I/O and Processing

Step 1-2 Designing Tasks

Step 1-3 Designing Programs



Step 2. Software Setups and Programming

Step 2-1 Slave and Unit Configurations

Step 2-2 Controller Setup

Step 2-3 Programming

Step 2-4 Offline Debugging



Step 3. Mounting and Setting Hardware



Step 4. Wiring



Step 5. Checking Operation and Starting Operation on the Actual System

Refer to 1-3 Overall Operating Procedure for the NJ/NX-series Controller for details.

POU (Program Organization Unit) Design	Reference
 Determine which processes to put into which POUs and design the POUs. Note Functions cannot contain function block instructions or function blocks. 	6-2 POUs (Pro- gram Organiza- tion Units)
 Determine which languages, such as ladder diagrams, inline ST, and ST, to use to create each process. Note Inline ST is structured text that is written as an element of a ladder diagram. 	6-5 Program- ming Lan- guages



Variable Design	Reference
Design the user-defined variables that you need to create.	6-3-1 Variables 6-3-2 Types of Variables
 Separate variables into those that you use in more than one POU (global variables) and variables that you use in only specific POUs (local variables). 	6-3-3 Types of User-defined Variables in Respect to POUs
 Determine if you need to automatically generate the variable names for the device variables that you use to access slaves and Units or if you need to define them yourself. 	3-3 I/O Ports and Device Variables
Design the attributes for the variables.	6-3-4 Attributes
Variable Name, Data Type, AT Specification, Initial Value, Retain, Constant, and Network Publish	of Variables 6-3-5 Data
Decide the data types of your variables (including array specifications, range specifications, structures, and enumerations).	Types 6-3-6 Deriva- tive Data Types
 Keep the following precautions in mind when you design variables. 	6-3-4 Attributes of Variables
 Retention: Set the Retain attributes to determine the values that are used for variables when the power supply is turned ON or when the operating mode changes. Structures: 	6-3-5 Data Types 6-3-6 Deriva- tive Data Types
When a structure is used for a variable in an instruction, design the program to use the same structure data type for the input parameter, output parameter, or in-out parameter. Example: Communications Instructions	
 Array Specifications: When an array variable is used for the variable for an instruction, design the program to use an array variable for the input parameter, output parameter, or in-out parameter. Examples: Shift Instructions, Stack Instructions, and Table Instructions 	
 AT Specifications: Use AT specifications for the variables used for input parameters to certain instructions. Example: Fixed or user I/O allocations for DeviceNet Units 	
Network Publishing: Design the variables for EtherNet/IP tag data links.	

6-2 POUs (Program Organization Units)

The user program that runs on an NJ/NX-series CPU Unit is made from a combination of POUs (program organization units).

This section describes the configuration and specifications of POUs.

Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details on creating POUs in the Sysmac Studio.

6-2-1 What Are POUs?

A POU (program organization unit) is a unit that is defined in the IEC 61131-3 user program execution model. A POU includes a local variable table and an algorithm (i.e., a series of code or logic). It is the basic unit used to build the user program.

You combine POUs to build a complete user program.

There are three types of POUs, as described below.

- Programs
 - A program corresponds to a main routine. It is the main type of POU that is used for algorithms. You can place any instruction, function, or function block in the algorithm of a program.
- Function Blocks (FBs)
 A function block can output different values even with the same inputs. Function blocks are executed when they are called from a program or another function block.
- Functions (FUNs)
 A function always outputs the same values for the same inputs. Functions are executed when they are called from a program, another function, or a function block.

The POUs consists of a combination of these three types of POUs. You can create many POUs. You assign the programs to tasks to execute them.

6-2-2 Overview of the Three Types of POUs

Programs

Executing Programs and Execution Conditions

- You execute a task to execute the programs that are assigned to that task.
- · Programs are always executed.

Notation

• The POUs must include at least one program. You can assign up to 128 programs to a single task.

Function Blocks (FBs)

Executing Function Blocks and Execution Conditions

- You can call function blocks from programs or other function blocks to execute them.
- · Function blocks are always executed.
- If you want a function block to execute only when a condition is met, you must define an input variable that sets the execution condition.

Notation

- You can use any instruction, user-defined function, or user-defined function block in the algorithm of a function block.
- · You can retain the values of internal variables. Therefore, you can retain status, such as for timers and counters.
- There are both user-defined and system-defined function blocks. User-defined function blocks are called user-defined function blocks. System-defined function blocks are sometimes called FB instructions.

For details on function blocks, refer to 6-2-5 Details on Function Blocks.

Functions

Executing Functions and Execution Conditions

- You can call functions from programs, other functions, or function blocks to execute them.
- The EN input variable specifies the execution condition. A function is executed only once each time EN changes to TRUE.

Notation


- You cannot use FB instructions or user-defined function blocks in algorithms.
- The values of internal variables are not retained. Therefore, the output value remains constant if the input values are the same.
- There are both user-defined and system-defined function blocks. User-defined functions are called user-defined functions. System-defined functions are sometimes called FUN instructions.

For details on functions, refer to 6-2-6 Details on Functions.

6-2-3 Differences between Programs, Functions, and Function Blocks

Item	POU type	Programs	Function blocks	Functions
Execution method		Executed upon execution of assigned task.	Called from a program or another function block.	Called from a program, function, or function block.
	Any instructions	Supported.	Supported.	Not supported.
Algorithm	User-defined functions	Supported.	Supported.	Supported.
Algoritim	User-defined function blocks	Supported.	Supported.	Not supported.
Execution condition		Executed each period.	Executed each period. Specify the execution condition with an input variable.	Specify the execution condition with the EN input.


The hierarchical relationships between programs, functions, and function blocks are shown in the following figure.



6-2-4 Details on Programs

Program Structure

Programs consist of a local variable table and an algorithm. You can use any function or function block in the algorithm of a program.



You cannot call programs from other POUs.

Program Execution Conditions

Programs are executed when the task they are assigned to is executed.

Order of Execution

You can set the order of execution of all programs in a task. You specify this order under Task Settings - Program Assignment Settings in the Sysmac Studio.

Related System-defined Variables

All programs have the following system-defined variables in the local variables.

Variable name	Meaning	Function	Data type	Read/write
P_First_Run- Mode	First RUN Period Flag	This flag is TRUE for only one task period after the operating mode of the CPU Unit is changed from PROGRAM mode to RUN mode if execution of the program is in progress.	BOOL	Read
		This flag remains FALSE if execution of the program is not in progress.		
		Use this flag to perform initial processing when the CPU Unit begins operation.		
P_First_Run*1	First Program Period Flag	This flag is TRUE for one task period after execution of the program starts.*2	BOOL	R
		Use this flag to perform initial processing when execution of a program starts.		
P_PRGER	Instruction Error Flag	This flag changes to and remains TRUE when an instruction error occurs in the program or in a function/function block called from the program.	BOOL	Read/write
		After this flag changes to TRUE, it stays TRUE until the user program changes it back to FALSE.		
P_CY	Carry Flag	This flag is updated by some instructions.	BOOL	Read

^{*1} A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required.

Details on Function Blocks 6-2-5

Procedure to Create Function Blocks

A function block consists of a function block definition that is made in advance and instances that are used in the actual programs. Create function blocks in the following order.

- Create the function block definition. Create the algorithm.
- **2** Placing an Instance of the Function Block Definition in a Program


Call the function block definition from a program or another function block. You can call the same function block definition from more than one program or function block. After you place an instance of a function block definition in a program or in another function block, you can manipulate and execute it as an independent entity.

^{*2} To enable or disable the program, use the PrgStart or PrgStop instruction. You can make setting for the Prg-Start instruction so that it executes the program without changing *P_First_Run* to TRUE.

Structure of Function Blocks


In a ladder diagram, function blocks are represented as rectangular boxes as shown below. Refer to *Calling Function Blocks from ST* on page 6-10 for details about how to express function blocks in ST. Function blocks consist of the following parts.

• Function Block in Ladder Diagram:



• Function Block Settings

When you create an instance of a function block definition, make the following settings.



Function Block Name or Instruction Name

This is the function block name or instruction name assigned in the function block definition when the function block is created.

Instance Name

You give an instance name to a function block instance in a program to enable managing it. You specify an instance name when you call a function block definition from a program or another function block.

Algorithm

You can code the algorithm either as a ladder diagram or in ST. You can use any instruction, userdefined function, or user-defined function block in the algorithm.

Local Variable Table

The local variable table is used to define input variables, output variables, in-out variables, internal variables, and external variables.

Refer to Variable Designations for Function Blocks on page 6-11 for details.

Parameters

Input Parameters to Input Variables

An input parameter passes a value to an input variable in a function block when function block execution begins. An input parameter can be either a variable or a constant.

Output Parameters from Output Variables

An output parameter receives a value from an output variable in a function block when function block execution is completed. A variable is given as the parameter.

In-Out Parameters Shared between In-Out Variables

The value of the in-out parameter changes within the function block. The same variable is used for both the input and output.



Additional Information


You can omit input and output parameters. Refer to information on operation when parameters are omitted in Operation When Parameters Are Omitted on page 6-23 for details.

Calling Function Blocks from ST

The following example shows how to call function blocks from ST.

instance_name(input_variable_1:=input_parameter_1, ... input_variable_N:=input_parameter_N,in-out-_variable_1:=in-out_parameter_1, ... in-out_variable_N:=in-out_parameter_N,output_variable_1=>output_parameter_1, ... output_variable_N=>output_parameter_N);

You can also omit input variable names and other variable names, and give only the parameters. (If you do, the parameters must be given in the order that they are given in the function block definition.) Also, the number of parameters must match the number of input variables and other variables in the function block definition.




Function Blocks Expressed in ST:

```
Instance name
TON_instance(In:=a, PT:=b, Q=>c, ET=>d);
TON_instance(In:=a, PT:=b, Q=>c); (*The ET output is omitted here.*)
TON_instance(a,b,c,d); (*Input and output variables are omitted here.*)
```

Refer to Function Block Calls in ST Language Statement on page 6-120 for details.

Variable Designations for Function Blocks



The specifications for variables in function blocks are given below.

Variables	Number	Specification
Input variables*1	1 to 64	Input variables are used as input arguments within the function block. They cannot be changed inside the function block.
		When the function block is executed, the input variables are set to the values of the input parameters.
		You can specify either constants or variables for input parameters.
		Omitting Input Parameters: Refer to information on operation when parameters are omitted in <i>Operation When Parameters Are Omitted</i> on page 6-23.
		You can specify to detect when the variable changes to TRUE or changes to FALSE.
		You can access and change the values from outside the function block. Access
		these values using the following format: InstanceName.InputVariableName.*2
Output vari-	1 to 64	Output variables are used as output arguments from the function block.
ables ^{*3}		The output parameters are set to the values of the output variables at the end of function block execution.
		You cannot specify a constant or a variable with constant attribute for an output parameter.
		You can omit output parameter connections. If you omit an output parameter, the value of the output variable is not assigned to any parameter.
		You can access the values of output variables from outside of the function block. Access these values with the following format: <i>InstanceName.Output-VariableName</i> . However, you cannot write values directly to an output variable.
In-out variables	0 to 64	In-out variables are used as inputs to and outputs from the function block. They can be changed inside the function block.
		The value of an in-out parameter is passed to an in-out variable and the value of the in-out variable is then passed to the in-out parameter.
		You cannot specify a constant or a variable with constant attribute for an in-out parameter.
		If you change the value of an in-out variable within a function block, the value of the in-out parameter changes at that time.
		You cannot omit in-out parameters.
Internal vari-	No limit	Internal variables are used for temporary storage within a function block.
ables		The values of internal variables are retained regardless of whether the function block is executed.
		Internal variables can have Retain attributes.
		You cannot access the values of internal variables from outside of the function block.

Variables	Number	Specification
External variables	No limit	External variables are used to access global variables.
EN	0	An <i>EN</i> variable cannot be used in a function block. (This applies to both user-defined function blocks and FB instructions.)
ENO	0 or 1	Generally, this is a BOOL output variable that is set to TRUE for a normal end, and to FALSE for an error end.
		You can also omit it for some FB instructions. Refer to <i>ENO</i> on page 6-20 for details.

^{*1} In the Sysmac Studio version 1.01 or lower, at least one BOOL input variable is required when you use function blocks in a ladder diagram or in ST.

- *2 In the Sysmac Studio version 1.07 or lower, it is impossible to change the value of an input variable from outside the function block. However, accessing it from outside the function block is possible.
- *3 At least one BOOL output variable (including ENO) is required when you use function blocks in a ladder diagram.
 - In the Sysmac Studio version 1.01 or lower, at least one BOOL output variable (including ENO) is required when you use function blocks in ST.

Refer to 6-3-4 Attributes of Variables for details on setting variable attributes.



Additional Information

If you define an external variable with the same name as a global variable in a function block, it is defined automatically based on that global variable.

ENO

• When ENO is FALSE, the previous values of all other output variables are retained.

Function Block Definitions and Instances

A function block consists of a function block definition that is made in advance and instances that are then used in the actual programs. All instances of a function block are based on the function block definition.

A function block definition consists of an algorithm and a local variable table.


Function Block Instance

When you place an instance of a function block definition in a program or another function block, the function block definition is treated as a part of that program or function block.

Function block definitions that are called from a program or another function block are called instances.

Every instance of a function block has an identifier known as an instance name associated with it, and every instance uses memory.

You can create instances of a function block definition to process different I/O data in the same way.



Instances cannot be read from other programs or function blocks. If an instance with the same name as another instance is placed in a different program or another function block, that instance will operate as a completely separate instance.

Array Specifications for Instances

Array specifications can be made for instances. You can indirectly specify an array element number with a variable to execute multiple instances with one instance name. Furthermore, you can switch input sources and output destinations and effectively execute multiple instances with a single instance name if you use an array specification for the input parameter and output parameter and specify the element numbers with the same variable.

Example:


In

PT

PT[4]

Q

EΤ



Execution Conditions for Function Blocks


Function blocks do not have an EN input like functions. They are executed each period.


Processes That Require Constant Data Monitoring

Case	Algorithm in FB		ENO	Operations other than ENO
Normal opera- tion	Executed.	Normal end	TRUE	Output parameters: Values are updated according to the internal algorithm.
				In-out parameters: Values are updated according to the internal algorithm.
		Error end	FALSE	Output parameters: Retained
				In-out parameters: Values are updated according to the internal algorithm.
Inside a mas- ter control region	Executed when the state of the power flow input is FALSE.		User-specified	One of the above, depending on the value of ENO.


Refer to 6-5-2 Ladder Diagram Language for details on power flow output and parameter output.


You can specify the edge for an input variable to make the variable TRUE only when the input parameter changes to TRUE.





You can specify falling edges too.





Accessing Variables in a Function Block from Outside the Function **Block**

You can access the input and output variables of a function block from outside the function block. Variables are written as follows:

InstanceName.VariableName

Example: To Access Output Variable B of Function Block Instance FB1_Instance

FB1 Instance.B

You can access the input and output variables for a function block only within the program that contains the function block. However, you cannot access these variables from within other function block instances even if they are in the same program. You cannot access them from other programs.

Program P1 FB1_Instance FB₁ Α В Can be accessed FB1_Instance.B Cannot be accessed. FB2_Instance FB2 D Program P2 Cannot be accessed. FB2_Instance.B

Input and Output Variables for FB1

- Access is possible only from within program P1.
- Access is not possible from program P2.
- Access is not possible from within FB2.

The following variables cannot be accessed from external devices. If these variables are accessed, a building error will occur.


- · In-out variables for function blocks
- Input variables for FB instructions for which the default value is not applied if an input parameter is omitted

6-2-6 Details on Functions

Structure of Functions

In a ladder diagram, functions are represented as rectangular boxes as shown below. Refer to *Expressing Functions in ST* on page 6-18 for details about how to express functions in ST. A function consists of the following parts.

Function in Ladder Diagram:



Function Name or Instruction Name

This is the function name or instruction name assigned in the function definition when the function is defined.


Instance Name

Functions do not have instance names.

Algorithm

You can code the algorithm either as a ladder diagram or in ST. You can use function instructions or user-defined functions in the algorithm of a function. You cannot use any FB instructions or user-defined function blocks. You also cannot use a differentiated instruction (e.g., R TRIG or UP).

You cannot use the P First RunMode and P First Run system-defined variables.



Local Variable Table

A local variable table defines the input variables, output variables, in-out variables, internal variables, and external variables.

Refer to Variable Designations for Functions on page 6-19 for details.

Parameters

Input Parameters to Input Variables

An input parameter passes a value to an input variable in a function when function execution begins. An input parameter can be either a variable or a constant.

Output Parameters from Output Variables

An output parameter receives a value from an output variable in a function when function execution is completed. A variable is given as the parameter.

In-Out Parameters Shared between In-Out Variables

The value of the in-out parameter changes within the function. The same variable is used for both the input and output.

Expressing Functions in ST


The following example shows how to call functions from ST.

return_value:=function_name (input_variable_1:=input_parameter_1, ... input_variable_N:=input_parameter N,in-out variable 1:=in-out parameter 1, ... in-out variable N:=in-out parameter N,output_variable_1=>output_parameter_1, ... output_variable_N=>output_parameter_N);

However, you can also omit the return value.


You can also omit input variable names and other variable names, and give only the parameters. (If you do, the parameters must be given in the order that they are given in the function definition.) Also, the number of parameters must match the number of input variables and other variables in the function definition.

Functions Expressed in ST:



Refer to Function Calls on page 6-123 for details.

Variable Designations for Functions



The specifications for variables in functions are given below.

Variables	Number	Specification
Input variables	0 to 64	Input variables are used as input arguments within the function. They cannot be changed inside the function.
		When the function is executed, the input variables are set to the values of the input parameters.
		You can specify either constants or variables for input parameters.
		Omitting Input Parameters: Refer to information on operation when parameters are omitted in <i>Operation When Parameters Are Omitted</i> on page 6-23.
		Unlike function blocks, you cannot specify to detect changes to TRUE or FALSE.
		You cannot access the values of input variables from outside of the function.
		Some of the instructions provided by OMRON can have varying numbers of input variables, but you cannot make a user-created function that has a varying number of input variables.
Output variables	0 to 64	Output variables are used as output arguments from the function.
		The output parameters are set to the values of the output variables at the end of function execution.
		You cannot specify a constant or a variable with constant attribute for an output parameter.
		At least one BOOL output variable (including <i>ENO</i> and the return value) is required.
		You can omit output parameter connections. If you omit an output parameter, the value of the output variable is not assigned to any parameter.
		 You cannot access the values of output variables from outside of the function. The values of the output variables of user-defined functions must always be set in the algorithms of the functions. If the output variables are not set in the algorithms of the functions, the values of the output variables are undefined.
In-out variables	0 to 64	In-out variables are used as inputs to and outputs from the function. They can be changed inside the function.
		In-out parameters (variable designations) are directly passed to or received from the in-out variables.
		You cannot specify a constant or a variable with constant attribute for an in-out parameter.
		If you change the value of an in-out variable within a function, the value of the in-out parameter changes at that time.
		You cannot omit in-out parameters.
		You cannot access the values of in-out variables from outside of the function.

Variables	Number	Specification
Internal vari-	No limit	Internal variables are used for temporary storage within a function.
ables		The value is not retained after execution is completed. You cannot access the values of internal variables from outside of the function.
External variables	No limit	External variables access global variables.
EN	1	This is a BOOL input variable used to execute the function.
		The function is executed when <i>EN</i> is TRUE. The value of <i>EN</i> in the function is always TRUE.
		You must have one <i>EN</i> variable. (This applies to both user-defined functions and FUN instructions).
ENO	0 or 1	Generally, this is a BOOL output variable that is set to TRUE for a normal end, and to FALSE for an error end.
		You can omit the ENO variable from user-defined functions.
		Refer to ENO on page 6-20 for details.
Return value	1	The return value is the value that is returned to the calling instruction. It represents the results of the process after the algorithm in the function is executed.
		Each function must have one return value.
		You can specify enumerations of all basic data types. You cannot specify an array, structure, or union.
		The return values of user-defined functions must always be set in the algorithms of the functions. If return values are not set in the algorithms of the functions, the return values are undefined.
		Refer to Return Values, below, for details.

Refer to 6-3-4 Attributes of Variables for details on setting variable attributes.



Additional Information

You can register global variables as external variables in a function variable table to access global variables. We recommend that you create your functions so that they produce output values uniquely based on their input parameter values. Algorithms that access global variables and use them to affect the output values are not recommended. When you check the program on the Sysmac Studio, a message will appear that says that it is not recommended to use global variables in functions. Take appropriate measures if necessary.

ENO

• When ENO is FALSE, the previous values of all other output variables are retained.


Return Values

• Return values are blank in ladder diagrams.

Case	Ladde	er diagram notation	n	ST language notation
Using return values	Variable i IN	MyFUN1 ENO	Variable <i>q</i>	variable_q:= MyFUN1(vari- able_i);
Not using a return value	Variable <u>i1</u> In1 Variable <u>i2</u> In2	OutEQ OutGT OutGE OutNE OutLT OutLE	Variable q1 Variable q4	MyFUN2(In1:= <i>vari- able_i1</i> ,In2:= <i>variable_i2</i> , OutEQ=> <i>variable_q1</i> , OutNE=> <i>variable_q4</i>);

- The calling instruction is not required to use the return value in either a ladder diagram or ST.
- If you set the return value within a function algorithm, set the value to a variable with the same name as the function.

For example, the return value of a function called MyFUN is MyFUN.




Execution Conditions for Functions

A function is executed when *EN* is TRUE. The function stops processing when *EN* changes to FALSE.

Input variables	Algorithm in FUN		ENO	Operations other than ENO
EN = TRUE	Executed.	Normal end	TRUE	Output parameters: Values are updated according to the internal algorithm.
				In-out parameters: Values are updated according to the internal algorithm.
		Error end	FALSE	Output parameters: Values are retained.
				In-out parameters: Values are updated according to the internal algorithm.
EN = FALSE	Not executed		FALSE	Output parameters and in-out parameters: Values are retained.
Inside a master control region	Not executed		FALSE	Output parameters and in-out parameters: Values are retained.

Example:



Operation That Applies to Both Functions and Function Blocks 6-2-7

Using or Omitting *EN* and *ENO*

The following table shows when you can use and when you can omit EN and ENO in functions and function blocks.


	POU	EN	ENO	
FB	User-defined	Cannot be used.	Can be used or omitted.	
	functions	A building error occurs if you try to define <i>EN</i> in the variable table from the Sysmac Studio.	You define <i>ENO</i> as an output variable in the Sysmac Studio.	
	Instruction	All FB instructions do not use EN.	Some instructions use <i>ENO</i> , and others do not.	
FUN	User-defined	Required.	Can be used or omitted.	
	functions	When you create a function, the Sysmac Studio automatically adds <i>EN</i> to the variable table by default.	You define <i>ENO</i> as an output variable in the Sysmac Studio.	
	Instruction	All FUN instructions use <i>EN</i> .	Some instructions use <i>ENO</i> , and others do not.	

Operation When Parameters Are Omitted

You can omit both input and output parameters.

	Operation when omitted					
Parameters omitted in	FB	FUN				
Input parameters to input variables	 When the first time the instance is executed, the initial value is used. Thereafter, the function block is executed with the previous value (if the input variable is omitted, the initial value is always used). 	 EN is operated when its value is TRUE. For other input parameters, the initial value is used for operation. 				
Output parameters from output variables	Can be omitted. You can access the results of the operation outside of the instruction by using <i>InstanceName.Output-VariableName</i> .*	You can omit the output parameter. If it is omitted, there is no way to retrieve the result of the operation.				
In-out parameters to/from in-out variables	Cannot be omitted.	Cannot be omitted.				

* You can access the input and output variables of a function block from outside of the function block (but only within the same program) with *InstanceName.VariableName*. However, you cannot access the input and output variables of a function from outside the function.




Operation for Parameter Errors

The following operation occurs when there is an error in an input parameter, output parameter, or in-out parameter.

Errors in Input Parameters

If an error is detected in an input parameter, the function or function block is not executed and *ENO* is FALSE. The power flow output is also FALSE, but all other values are retained.


Example:



Errors in Output Parameters


If an error is detected in an output parameter, all values after that parameter are not output but their values are retained.

Example:



Errors in In-Out Parameters

If an error is detected in an in-out parameter, the function or function block is not executed and ENO is FALSE. The power flow output is also FALSE, but all other values are retained.



Recursive Calling

The following recursive calls are not allowed for functions or function blocks. They will result in an error when you build the user program on the Sysmac Studio.

- · A function or function block cannot call itself.
- A called function or function block cannot call the calling parent.

6-2-8 **POU Restrictions**

This section describes the restrictions in the creation of POUs.

Names

Refer to 6-3-12 Restrictions on Variable Names and Other Program-related Names for restrictions on POU names and function block instance names.

Passing Multiple Arguments

If you need to pass multiple arguments to a function or function block, use an array specification or structure to pass the required data.

This will make your program simpler. However, be aware that if you use an in-out variable, the data passed to the function block or function as a parameter is written and the original data is not retained.




Additional Information


Specifying an Array Variable or Structure Variable as a Parameter

You can also specify an array variable or a structure variable as an input or output parameter. However, it will take longer to pass and receive data for these data types in comparison to a variable with a basic data type (depending on the size). Therefore, when handling array variables or structure variables in a function block, we recommend that you design them in such a way that these variables are passed to and received from in-out variables.

Example 1: Specifying an Array



Example 2: Specifying a Structure Variable




Nesting Levels

Calling another function or function block from a function or function block that was called from a program is called nesting. The limits that are given in the following table apply to the POUs that you can call from a user-defined function or function block and the number of nesting levels. A building error will occur if these limits are exceeded.


POU	Called POUs	Nesting depth
Function blocks	Functions and function blocks	8 levels max.
Functions	Functions	16 levels max.*1

^{*1} A CPU Unit with unit version 1.03 or later and Sysmac Studio version 1.04 or higher are required. For other versions, the limit is 8 levels.

Example 1: From a program, you can call function blocks to a depth of 8 levels. You can then call functions to a depth of 16 levels.



Example 2: From a program, you can call functions to a depth of 16 levels.



6-3 Variables

In the NJ/NX-series System, variables are used to exchange I/O information with external devices, to perform data calculations, and to perform other processes. This section describes variable designations in detail.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details on setting variables with the Sysmac Studio.

6-3-1 Variables

Variables store I/O data for exchange with external devices or temporary data that is used for internal POU processing. In other words, a variable is a container for data with a name, data type, and other attributes.

You do not need to assign a memory address to a variable. However, you can assign a specific memory address if necessary (see note). The NJ/NX-series CPU Unit automatically allocates memory addresses in the memory area for variables.

- * This is done to use specific functions for some CJ-series Special Units or perform the serial communications using the host link (FINS) protocol. You must specify the CJ-series Unit memory address in the AT Specification attribute of the variable. Refer to *AT Specification* on page 6-59 for details.
- * You can use CJ-series Units only with NJ-series CPU Units.

6-3-2 Types of Variables

Variables are broadly classified into the following three types.

User-defined Variables

The user defines all of the attributes of a user-defined variable. The rest of this section describes user-defined variables.

Semi-user-defined Variables

These variables are used to access specific devices and data. There are two types of semi-user-defined variables: device variables and cam data variables. Refer to 2-3-1 Types of Variables and 3-3-1 I/O Ports for details on device variables.

System-defined Variables

System-defined variables are provided in advance in an NJ-series CPU Unit. The names and all attributes are defined by the system. They have specific functions. System-defined variables are supplied for each function module. Refer to A-6 System-defined Variables for details.

Refer to 2-3-1 Types of Variables for details on the different types of variables.

6-3-3 Types of User-defined Variables in Respect to POUs

There are six types of user-defined variables as defined according to their function in a POU.

Type of user-defined variable		POU type				
		Programs	FB	FUN		
	Internal variables	Supported.	Supported.	Supported.		
Local variables	Input variables	Not supported.	Supported.	Supported.		
	Output variables	Not supported.	Supported.	Supported.		
	In-out variables	Not supported.	Supported.	Supported.		
Global variables		Supported (see note).	Supported (see note).	Supported (see note).		
External variables		Supported.	Supported.	Supported.		

^{*} You can define global variables as external variables to access the global variables through the external variables.

Local Variables

Local variables can be read and written only in the POU (program, function, or function block) in which it is defined. Local variables are the same as internal variables if the POU is a program. If the POU is a function block or a function, "local variable" is a collective term for internal variables, input variables, output variables, in-out variables, and external variables.

Internal Variables

A local variable can be used only within one POU. An internal variable is declared in the local variable table for the POU. You cannot access the values of internal variables from outside of the POU. You can declare internal variables with the same names in different POUs. Each of those variables is assigned to a different memory area.

Input Variables

When a POU is called, the input variables are assigned to the values of the input parameters from the calling POU. An input variable is declared in the local variable table of the POU.

Output Variables

Before processing a POU is completed, the output parameters returned to the calling POU are assigned to the output variables. An output variable is declared in the local variable table of the POU.

In-Out Variables

When a POU is called, the in-out variables are assigned to the in-out parameters themselves (variable designations) from the calling POU. If you change the value of an in-out variable within a POU, the value of the in-out parameter changes at that time. An in-out variable is declared in the local variable table of the POU.

External Variables

External variables are used to access data outside of a POU. You can access global variables from POUs.

Global Variables

A global variable is declared in the global variable table.

Device variables that are automatically generated from the Unit configuration and slave configuration and axis/axes group variables that are generated from the Axis Setting Table are automatically registered as global variables.

6-3-4 Attributes of Variables

You can set the following attributes for variables.

Variable Attributes According to Variable Type

Attributes of Variables

Attribute	Description	Specification	Default
Variable Name	The variable name is used to identify the variable.		
Data Type	The data type defines the format of the data that is stored in the variable.		BOOL
AT Specification	If you want to handle a specific address for a CJ-series Unit as a variable, specify the address to assign to that variable.*1	Not specified. Specify.	Not specified.
Retain	Specify whether to retain the value of the variable in the following cases. • When power is turned ON after a power interruption • When the CPU Unit changes to RUN mode • When a major fault level Controller error has occurred.	Retain: Value specified on the left is retained if there is a Battery. Non-retain: Changes to initial value.	Non-retain: Reset to initial value
Initial Value	You can select to set or not set an initial value. Initial value setting: Specify the value of the variable in the following cases and do not specify the Retain attribute. • When power turned ON • When operating mode changes • When a major fault level Controller error occurs If the initial value is not set, the value is not retained.	Initial Value • Yes • None	Depends on the data type. (Refer to the section on initial values.)
Constant	If you set the Constant attribute, you can set the initial value of the variable when it is downloaded, but you cannot overwrite the value afterwards.	Specify making the value a constant or not a constant.	
Network Publish	This attribute allows you to use CIP communications and data links to read/write variables from outside of the Controller.	Do not publishPublish OnlyInputOutput	Do not publish
Edge	An Edge attribute allows you to detect when the input parameter of a function block changes to TRUE or changes to FALSE. This can be used only on BOOL input variables.	None Change to TRUE Change to FALSE	None

^{*1} You can use CJ-series Units only with NJ-series CPU Units.



Additional Information

Exclusive Control between Tasks

You can restrict writing to global variables to a single task to prevent changes to the values of global variables during processing. Specify this as a task setting, not as a variable attribute.

Attributes Supported by Each Type of Variable

Type of	variable	Variable Name	Data Type	AT Specification	Retain	Initial Value	Constant	Network Publish	Edge
Global vari	ables	Sup- ported.	Not sup- ported.						
Programs	Internal variables	Sup- ported.	Sup- ported	Sup- ported	Sup- ported	Sup- ported	Sup- ported	Not sup- ported.	Not sup- ported.
Programs	External variables	Not sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.				
	Internal variables	Sup- ported.	Sup- ported.	Sup- ported.	Sup- ported.	Sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.
	Input vari- able	Sup- ported.	Sup- ported.	Not sup- ported.	Sup- ported.	Sup- ported.	Sup- ported.	Not sup- ported.	Sup- ported.
Function blocks	Output variables	Sup- ported.	Sup- ported.	Not sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.	Not sup- ported.	Not sup- ported.
	In-out variables	Sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.	Not sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.
	External variables	Not sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.				
	Internal variables	Sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.	Sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.
	Input vari- ables	Sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.	Sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.
Functions	Output variable	Sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.	Not sup- ported.	Not sup- ported.	Not sup- ported.	Not sup- ported.
	In-out variables	Sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.	Not sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.
	External variables	Not sup- ported.	Sup- ported.	Not sup- ported.	Not sup- ported.				

6-3-5 **Data Types**

The Data Type attribute defines the type of data and range of data that is expressed by a variable.

The amount of memory that is allocated when you declare a variable depends on the data type of that variable. The more memory allocated, the larger the range of values that the variable can express.

The data types for the input, output, and in-out variables of instructions depend on the instruction. Set the data types of input, output, and in-out parameters for the instruction arguments according to the data types of the input, output, and in-out variables for that instruction.

Basic Data Types and Derivative Data Types

There are two kinds of data types: basic data types, which have predefined specifications, and derivative data types, which are defined according to user specifications.

Basic Data Types

The different kinds of basic data types are listed below.

Classification	Definition
Boolean	A data type with a value of either TRUE or FALSE.
Bit string	A data type that represents a value as a bit string.
Integer	A data type that represents an integer value.
Real number	A data type that represents a real number.
Duration	A data type that represents a time duration (days, hours, minutes, seconds, and milliseconds).

Classification	Definition				
Time of day	A data type that represents a specific time of day (hour, minutes, and seconds).				
Date	A data type that represents a date (year, month, and day).				
Date and time	A data type that represents a date and time (year, month, day, hour, minutes, seconds, and milliseconds).				
Text string	A data type that contains a value that represents a text string.				

There are a total of twenty different basic data types. The specifications are given in the following table.

The meanings of the data size and alignment columns in the following table are as follows:

- Data size: The actual size of the value.
- Alignment: The unit used to allocate memory.

Classification	Data type	Data size	Alignment	Range of values	Notation
Boolean	BOOL	16 bits	2 bytes	FALSE or TRUE	BOOL#1, BOOL#0, TRUE or FALSE
	BYTE	8 bits	1 byte	BYTE#16#00 to FF	BYTE#2#01011010
	WORD	16 bits	2 bytes	WORD#16#0000 to FFFF	BYTE#2#0101_1010
Bit strings	DWORD	32 bits	4 bytes	DWORD#16#00000000 to FFFFFFF	BYTE#16#5A You can also use the "_" character as a
	LWORD	64 bits	8 bytes	LWORD#16#00000000000000000000000000000000000	separator.
	SINT	8 bits	1 byte	SINT#-128 to +127	100
	INT	16 bits	2 bytes	INT#-32768 to +32767	INT#2#00000000_01100100
	DINT	32 bits	4 bytes	DINT#-2147483648 to +2147483647	INT#8#144 INT#10#100
Integers	LINT	64 bits	8 bytes	LINT#-9223372036854775808 to +9223372036854775807	INT#16#64 _100
	USINT	8 bits	1 byte	USINT#0 to +255	
	UINT	16 bits	2 bytes	UINT#0 to +65535	
	UDINT	32 bits	4 bytes	UDINT#0 to +4294967295	
	ULINT	64 bits	8 bytes	ULINT#0 to +18446744073709551615	
Real numbers	REAL	32 bits	4 bytes	REAL#-3.402823e+38 to -1.175495e-38 0 1.175495e-38 to 3.402823e+38 +	REAL#3.14 LREAL#3.14 3.14 -3.14 1.0E+6
	LREAL	64 bits	8 bytes	LREAL#-1.79769313486231e +308 to -2.22507385850721e-308 0 2.22507385850721e-308 to 1.79769313486231e+308 +∞ /-∞	1.234e4
Durations*1*2	TIME	64 bits	8 bytes	T#-9223372036854.775808ms (T#- 106751d_23h_47m_16s_854.7758 08ms) to T#+9223372036854.775807ms (T#+106751d_23h_47m_16s_854. 775807ms)	T#12d3h3s T#3s56ms TIME#6d_10m TIME#16d_5h_3m_4s T#12d3.5h T#10.12s T#61m5s (Equivalent to T#1h1m5s) TIME#25h_3m
Date	DATE	64 bits	8 bytes	D#1970-01-01 to D#2106-02-06 (January 1, 1970 to February 6, 2106)	Add "DATE#", "date#", "D#", or "d#" to the beginning of the string and express the date in the yyyy-mm-dd format. Example: d#1994-09-23

Classification	Data type	Data size	Alignment	Range of values	Notation
Time of day*2	TIME_OF _DAY	64 bits	8 bytes	TOD#00:00:00.000000000 to TOD#23:59:59.999999999 (00:00:0.0000000000 to 23:59:59.999999999)	Add "TIME_OF_DAY#", "time_of_day#", "TOD#", or "tod #" to the beginning of the string and express the time of day in the hh-mm-ss format. Example: tod#12:16:28.12
Date and time*2	DATE_ AND_ TIME	64 bits	8 bytes	DT#1970-01-01- 00:00:00.0000000000 to DT#2106- 02-06-23:59:59.999999999 (Janu- ary 1, 1970 00:00:0.000000000 to February 6, 2106, 23:59.999999999 seconds.)	Add "DT#" or "dt#" to the beginning of the string and express the date and time in the yyyy-mm-dd-hh:mm:ss format. Example: dt#1994-09-23-12:16:28.12
Text strings	STRING	(Number of single-byte characters plus 1) × 8 bits*3	1 byte	The character code is UTF-8. 0 to 1,986 bytes (1,985 single-byte alphanumeric characters plus the final NULL character, for Japanese, this is approximately equal to 0 to 661 characters)*4 The default size is 256 bytes.	Enclose the string in single-byte single quotation marks ('). Example: 'OMRON''PLC'


- Use the NanoSecToTime and TimeToNanoSec instructions to convert between durations and integer data. Refer to the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for detailed instruction specifications.
- *2 Variables are compared with nanosecond precision for comparison instructions. To change the precision for comparison, use the TruncTime, TruncDt, or TruncTod instruction. Refer to the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for detailed instruction specifications.
- *3 A NULL character (1 byte) is added to the end of text strings. Therefore, reserve memory for one more character than the number of handled characters. For example, if a maximum of 10 single-byte characters are handled, define a STRING variable for 11 characters (11 bytes). STRING[11]
- If you want to insert tabs, line break codes, or other special characters, you can use a single-byte dollar sign (\$) as an escape character before them. Refer to Text Strings on page 6-88 for a list of the escape characters.



Precautions for Correct Use

The total amount of memory required by all variables is not equal to the total of the data sizes of each of those variables. This is because the first position where data is stored in memory is automatically set to a multiple of the alignment value for that data type. This results in some empty space in memory between data types. For example, even if the data types are the same, the overall memory space required depends on the order of data types, as shown below.

Example:



You must be aware of the alignment values for different data types when you exchange data such as structure variables between devices so that you can properly align the position of the data in memory. Refer to A-10 Variable Memory Allocation Methods for details.



Additional Information

You cannot compare the sizes of bit string data types (BYTE, WORD, DWORD, and LWORD).
 If value comparisons are necessary, use instructions such as the WORD_TO_UINT instruction to convert to integer data and compare the values of the integer data variables.
 Example:

BCD data: WORD

IF WORD BCD TO UINT (BCD data) > UINT#1234 THEN

 You cannot perform logic processing on integer data types (SINT, INT, DINT, LINT, USINT, UINT, UDINT, and ULINT). If logic processing is necessary, use instructions such as the INT_TO_WORD instruction to convert to bit string data and perform the logic processing on the bit string data variables.

Example:

In the following sample programming, 1 is added to variable *a* if the value of INT variable *a* is an odd number.

```
IF (INT_TO_WORD (a) AND WORD#16#0001) = WORD#16#0001 THEN
    a = a+1;
END IF;
```

Derivative Data Types

A derivative data type is a data type with user-defined specifications. Derivative data types are registered in the Data Type View in the Sysmac Studio. The following is a list of the derivative data types.

Туре	Description
Structures	This data type consists of multiple data types placed together into a single layered structure.
Unions	This data type allows you to handle the same data as different data types depending on the situation.
Enumerations	This data type uses one item from a prepared name list as its value.

Refer to 6-3-6 Derivative Data Types for details.

Specifications for Data Types

The following array specifications and range specifications are possible for all data types.

Туре	Description
Array specification	An array is a group of elements with the same data type. You specify the number (subscript) of the element from the first element to specify the element. You can specify arrays for both basic data types and derivative data types.
Range specification	You can specify a specific range for a data type in advance. You can specify a range for any integer basic data type.

Refer to 6-3-7 Array Specifications and Range Specifications for Data Types for details.



Additional Information

In addition to basic data types and derivative data types, there are also POU instance data types. A POU instance data type is the data type of a function block instance. To create a function block instance, the instance name is registered as a variable and the function block definition name is registered as a data type in the local variable table.

Restrictions on Using Data Types

A list of the data types that you cannot use in different POUs is given below.

POU type	Type of variable	Unusable data types			
POU type	Type of variable	Basic data types	Derivative data types		
Programs	Internal variables	None			
	Global variables	None			
FUN	Input variables, output variables, and in-out variables	None	Unions		
	Internal variables	None			
	Return values	None	A structure or union		
FB	Input variables, output variables, and in-out variables	None	Unions		
	Internal variables	None			

Bit String, Real Number, and Text String Data Formats

This section describes the data formats for bit string data, real number data, and text string data.

Bit String Data Format

Bit 0 is the least significant bit of a bit string variable. Bit values are represented by values of either 1 or 0. However, you can also represent the value of a single bit as a BOOL variable where 1 equals TRUE and 0 equals FALSE.

Real Numbers (REAL and LREAL Data)

REAL and LREAL data have a real number data format. This section describes how to express real numbers and how to perform data processing with real number data types.

Data Size

REAL data is 32 bits, while LREAL data is 64 bits.

Data Formats

The floating-point format is a way to express a real number as a combination of a sign, an exponent, and a mantissa. To express a real number as shown below, the value of s is the sign, the value of e is the exponent, and the value of f is the mantissa.


REAL Data

Number =
$$(-1)^{s}2^{e-127}(1+f \times 2^{-23})$$

LREAL Data

Number =
$$(-1)^{s}2^{e-1023}(1+f \times 2^{-52})$$

This floating-point format follows the IEEE 754 standard. The formats are given below.



Example: Expressing -86.625 as REAL Data

- **1** This is a negative number, so s = 1.
- **2** 86.625 in binary is 1010110.101.
- **3** Normalizing this value gives us 1.010110101×2^6 .
- **4** From the above expression we can determine that e-127 = 6, so e = 133 (or 10000101 in binary).


Therefore, you can express –86.625 as shown in the following figure.

	Sig	n Exponent	Mantissa	
REAL data (32 bits)	1	10000101	010110101000000000000000	
	31	30 23	22	0

Valid Ranges

The valid ranges for REAL and LREAL data are shown in the following table. There are a range of values that you cannot express as you approach 0.

Data type	-∞	Negative numbers	0	Positive numbers	+∞
REAL		-3.402823e+38 to -1.175495e-38	0	+1.175495e-38 to +3.402823e+38	+∞
LREAL	∞	-1.79769313486231e+308 to -2.22507385850721e-308	0	+2.22507385850721e-308 to +1.79769313486231e+308	+∞



Special Values

Values such as positive infinity, negative infinity, +0, -0, and nonnumeric data are called special values. Nonnumeric data refers to data that you cannot express as a floating-point number and therefore cannot be treated as a numeric value. Although +0 and -0 both mathematically mean 0, they are different for the purpose of data processing. This is discussed later in this section. The values for the sign s, exponent e, and mantissa f of special numbers are given in the following table.

Data type name	Special values	Sign s	Exponent e	Mantissa f
REAL	+∞	0	255	0
	-∞	1	255	0
	+0	0	0	0
	-0	1	0	0
	Nonnumeric		255	Not 0

Data type name	Special values	Sign s	Exponent e	Mantissa <i>f</i>
LREAL	+∞	0	2047	0
	-∞	1	2047	0
	+0	0	0	0
	-0	1	0	0
	Nonnumeric		2047	Not 0

Subnormal Numbers

You cannot use the floating-point format to express values close to 0 (i.e., values with an extremely small absolute value). Therefore, you can use subnormal numbers to expand the valid range of numbers near 0. You can use subnormal numbers to express values with a smaller absolute value than with the normal data format (normal numbers). Any number where the exponent e = 0 and the mantissa $f \neq 0$ is a subnormal number and its value is expressed as shown below.

REAL Data

Number =
$$(-1)^{s}2^{-126}(f \times 2^{-23})$$

LREAL Data

Number =
$$(-1)^{s}2^{-1022}(f \times 2^{-52})$$

Example: Expressing 0.75×2^{-127} as REAL Data

1 This is a positive number, so s = 0.

2 0.75 in binary is 0.11.

3 From $(0.11)_2 \times 2^{-127} = 2^{-126} (f \times 2^{-23})$ we can see that $f = (0.11)_2 \times 2^{22}$.

Therefore, you can express 0.75×2^{-127} as shown in the following figure.

Subnormal numbers have less effective digits than normal numbers. Therefore, if a calculation with normal numbers results in a subnormal number or if a subnormal number results in the middle of such a calculation, the effective digits of the result may be less than the effective digits of a normal number.

Data Processing

The floating-point format expresses only an approximate value. Therefore, there may be a difference between the floating-point number and its true value. There is also a limited number of effective digits for these values. Therefore, the following actions are taken when you perform calculations with the floating-point format.



Precautions for Correct Use

Generally, calculation results for real number data may be different if the hardware such as a processor is different. Confirm the calculation results for real number data when you reuse programs and libraries with the different model number of the CPU Unit.

Rounding

If the real value exceeds the effective digits of the mantissa, the value is rounded off according to the following rules.

- The result of the calculation will be the closest value to the value that can be expressed as a floating-point number.
- If there are two values that are the closest to the real value (e.g., if the real value is the median value of two approximate values), the mantissa with a least significant bit value of 0 is selected as the result of the calculation.



Precautions for Correct Use

When you determine if two values are equal, consider the true values and error.

A real number is expressed in the floating-point decimal format. Because of this, there is a slight error from the actual value. When you try to determine if two values are equal, this error may cause unintended results. For example, if you compare 0.1 + 0.2 with 0.3 using boolv := (0.1 + 0.2 = 0.3);, the BOOL variable boolv will not be TRUE. It will be FALSE. To prevent this situation, do not use the EQ, =, NE, or <> instruction to determine if two real numbers are equal. Instead, use the value comparison instructions and determine if the absolute value of the difference between the two values is within a sufficiently small range. For example, the following programming can be used to check to see if the sum of REAL variables real a and real b is equal to 0.3. If the value of *boolv* is TRUE, the two values are considered to be equal.

```
boolv := (ABS((real_a + real_b) - 0.3) < 0.000001);
                                                            // Here, an allowable error
                                                            // of 0.000001 is used.
```

Overflows and Underflows

An overflow occurs when the absolute value of the true value is larger than the maximum value that can be expressed in the floating-point format. An underflow occurs when the absolute value of the true value is smaller than the minimum value that can be expressed in the floating-point format.

- If an overflow occurs and the true value is positive, the result of the calculation is positive infinity. If the true value is negative, the result of the calculation is negative infinity.
- If an underflow occurs and the true value is positive, the result of the calculation is positive zero. If the true value is negative, the result of the calculation is negative zero.

Special Value Calculations

Calculations that involve special values (i.e., positive infinity, negative infinity, +0, -0, and nonnumeric data) are performed according to the following rules.

- Addition of positive and negative infinity results in nonnumeric data.
- Subtraction of two infinite values of the same sign results in nonnumeric data.
- Multiplication of +0 or -0 with infinity results in nonnumeric data.
- Division of +0 by itself, -0 by itself, or infinity by itself results in nonnumeric data.
- Addition of positive and negative zero results in positive zero.
- Subtracting +0 from itself or -0 from itself results in +0.
- Any arithmetic that involves nonnumeric data results in nonnumeric data.
- Comparison instructions (such as for the Cmp instruction) treat +0 and -0 as equal.
- If you compare nonnumeric data with anything else, the result is always not equal.

Text String Data Format

All STRING variables are terminated with a NULL character (character code BYTE#16#00).


Converting Data Types

When you use a variable of a different data type, the data type is automatically converted in some cases. You can also perform the conversion yourself with a data type conversion instruction.

Data Type Conversion

All variables must have data types. Programs must operate properly according to these data types. For example, the left and right sides of an assignment expression should normally use the same data type. In some cases, however, it may be necessary to assign data of a different data type to a variable in order to program something successfully.

Example:



In order to assign the data in *var1* to the data type of *var3*, the data must first be converted. This type of conversion is called "data type conversion" or just "type conversion" for short.

When Data Type Conversion Occurs

Converting between data types occurs in the following two cases.

- (1) Conversion by User Execution of Data Type Conversion Instructions
- (2) Automatic Conversion for Assignments and Instructions
 - · ST assignments
 - · Connecting lines in ladder diagrams



Additional Information

Use the NanoSecToTime and TimeToNanoSec instructions to convert between INT and TIME data. Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for details.

6-3-6 **Derivative Data Types**

A derivative data type has a configuration that is based on one of the basic data types. The following is a list of the derivative data types.

- Structures
- Unions
- Enumerations

Refer to 6-3-12 Restrictions on Variable Names and Other Program-related Names for restrictions on the number of characters in data type names and other restrictions when you create a derivative data type.



Additional Information

NJ/NX-series Controllers come with three different types of system-defined derivative data types.

- System-defined variables that are structures
- · Structures used for input, output, and in-out variables for instructions
- Structures for Special Unit expansion memory (You must register these in the Unit Editor to use them.)


Structures

A structure is a derivative data type that groups together data with the same or different variable types. You can easily change data and add new data if you place your data into a structure.

For example, you can define a "Box" structure that has three members (Width, Height, and Depth) in order to organize and group your data.

You can then use this structure data type to add a variable called Box1. You can then use it to access the different levels of the data by placing a period after the variable name followed by the name of the data you want to access. For example, Box1.Width or Box1.Height.

If you need to create a new variable to store more box data, you can perform the same steps to add a new variable called Box2 to the variable table.



When a structure is used for a variable in an instruction, it is necessary to select a structure for the input parameter, output parameter, or in-out parameter, and register the variable.

Example: Communications Instructions

Expressing Structure Variables and Structure Variable Members

Specifying Members

The individual pieces of data that make up a structure are called "members." You can express individual members of a structure by putting a period after the variable name that represents the entire structure followed by the member name that you want to access. You can even have a structure that is the member of another structure.

Example: *abc.x*: Member *x* of structure variable *abc*

abc.Order.z: Member z of member structure variable Order of structure variable abc

Specifying the Structure


The structure represents all members that make up the structure. A structure is expressed by the name of the structure variable. In the example above, you would write *abc*.

Creating a Structure

1 Create a structure data type in the Data Type Table.
Specify the data type name, members, and the data type.

Da	ta Type Table		
	Name	Member	Data type
	RGB	red	INT
		green	INT
		blue	INT
	ITEM	ItemNo	INT
		Color	RGB

2 Specify the member name and the structure data type from above as the data type and register the variable in the variable table.



Structure Specifications

The specifications of structure data types are given in the following table.

Item	Specification
Structure names	Names are not case sensitive. Prohibited characters and character length restrictions are the same as for variable names.
Member data types	Refer to the table on the data types of structure members that is given below for details.
Member attributes	Member Name
	Comment
Number of mem- bers	1 to 2,048
Nesting depth of structures	Maximum of 8 levels (however, a member name must be 511 bytes or less, including the variable name)
Maximum size of one structure variable	NX701-□□□: 8 MB NX102-□□□: 4 MB NX1P2-□□□: 1 MB NJ501-□□□: 4 MB NJ301-□□□: 2 MB NJ101-□□□: 2 MB

Data Types of Structure Members

Classification	Data type	Usage
Basic data types	Boolean, bit string, integer, real, duration, date, time of day, date and time, or text string data	Supported.
	Array of Boolean, bit string, integer, real, duration, date, time of day, date and time, or text string data	Supported.
Derivative data types	Arrays (see note), unions, and enumerations	Supported.
	Note Recursions and loops are not allowed. (An error will occur when the program is checked.)	
	Array specifications for structures, unions, and enumerations	Supported.
POU instances		Not sup- ported.

Arrays and Structures

You can set an array in which the elements are structures. You can also set a structure in which the members are arrays.

Specifying Structure Member Offsets

When you specify an offset for a member, you can set the memory configuration of the members as required for each structure data type. This allows you to align the memory configuration of the members of the structure data type when you use tag data links with CJ-series CPU Units or with other external devices.

You can select NJ, CJ, or User as the offset type for structure members. If you select NJ, the memory configuration that is optimum for the NJ/NX-series is automatically used. Refer to A-10 Variable Memory Allocation Methods for details on the memory configuration of NJ/NX-series Controllers. Refer to A-10-2 Important Case Examples for examples of tag data lings with CJ-series CPU Units.

The meanings of the offset type are as follows:

Offset type	Meaning
NJ	The memory configuration that is optimum for the NJ/NX-series Controllers is automatically used and operating speed is maximized.
CJ	The memory configuration for CJ-series PLCs is automatically used. This allows you to use the same memory configuration as a CJ-series CPU Unit.
User	You can set the memory offsets for each member. This allows you to use the same memory configuration as external devices other than CJ-series CPU Units.



Version Information

The following table gives the unit version of the CPU Units and the Sysmac Studio version that are required to specify member offsets.

Unit version of CPU Unit	Sysmac Studio version		
Offic version of GFO Offic	1.01 or lower	1.02	1.03 or higher
1.01 or later	Not possible.	Possible.*	Possible.
1.00	Not possible.	Not possible.	Not possible.

^{*} You cannot select the memory offset type. You can set member offsets.

Setting Offsets

If you set the memory offset type to User, you can set memory offsets for each member of the structure. There are byte offsets and bit offsets. If you set the memory offset type to NJ or CJ, the memory configuration is determined automatically. You do not need to set offsets.

The meanings of the offsets are as follows:


Offset	Meaning	Unit	Range of values
Byte offset	The byte offset is the offset of a member from the start of the structure. Bytes offsets are used for all basic data types and derivative data types.	Byte	*1
Bit offset	The bit offset is the offset of a member from the start of the byte position that is specified with the byte offset.	Bit	0 to 63

^{*1} For NX-series CPU Units, the range of values is 0 to 8191. For NJ-series CPU Units, the range of values is 0 to 1023.

Example:

This example shows the memory configuration when the following settings are made with the Structure Editor.

Name	Data type	Offset type	Byte offset	Bit offset
StrA	STRUCT	User		
VarA	DINT		0	0
VarB	INT		4	0
VarC	DINT		6	0



Offsets That You Can Set

Even if you set the memory offset type to *User*, the offsets cannot be changed for some data types. The following table shows when offsets can be set.

Classification	Data type	Byte offsets	Bit offsets
Boolean	BOOL	Can be set.	Can be set.
Bit strings	BYTE, WORD, DWORD, LWORD	Can be set.	Fixed.
Integers	SINT, INT, DINT, LINT, USINT, UINT, UDINT, ULINT	Can be set.	Fixed.
Real numbers	REAL, LREAL	Can be set.	Fixed.
Durations	TIME	Can be set.	Fixed.
Dates	DATE	Can be set.	Fixed.
Times of day	TIME_OF_DAY	Can be set.	Fixed.
Dates and Times	DATE_AND_TIME	Can be set.	Fixed.
Text strings	STRING	Can be set.	Fixed.
Arrays		Can be set.	Can be set only for BOOL elements.
Structures		Can be set.	Fixed.
Unions		Can be set.	Fixed.
Enumerations		Can be set.	Fixed.
POU instances		Fixed.	Fixed.

Restrictions in Specifying Member Offsets

The following restrictions apply to setting member offsets. If you specify member offsets for a structure, the same restrictions apply to structures that are members of that structure.

- If you set the memory offset type to *User* for a structure, you must set offsets for all members of the structure.
- You cannot set initial values for members of structures for which offsets are set. The default initial value for each data type is used. Refer to *When the Initial Value Specification Is Left Blank* on page 6-64.
- The memory size that is required for the structure is determined by the sizes of the members, the alignment values of the data types, and the memory configuration.

Errors in Specifying Member Offsets


The following error can occur when setting member offsets.

Error name	Meaning	Offset type	Correction
Offset Out of Range Error	A value that is out of range was specified for an offset.	User	Change the value of the offset to a suitable value.
Offset Not Set Error	There is a member for which the offsets are not set.	User	Set offsets for all members.
Memory Configuration Overlap Error	The same memory location is allocated to more than one member.	User	Change the values of the offsets to suitable values.
Initial Value Setting Error	An initial value was set for a structure member for which an offset was specified when creating the variable table.	CJ or User	Do not set an initial value.


• Instructions That Take a Structure as a Parameter

Some instructions pass structure variables as parameters. To do so, specify the structure variable as the input parameter.


Example: Passing a Member of a Structure Variable to the MOVE Instruction and Passing a Structure Variable to the MOVE Instruction



■Specifying Just One Member of a Structure



■Specifying the Entire Structure



Passing Values to System-defined Structure Input Variables for Certain Instructions

Some instructions take a predefined structure variable as an input variable.

Example: The Port input variable for the Serial Communications Instructions (which specifies the target port) is a structure with a data type name of _sPORT. When you use one of these instructions, follow the procedure provided below to create a user-defined structure variable and specify that variable for the input parameter to the instruction.

- The system-defined data type for the instruction is registered in the Sysmac Studio in advance. Select that system-defined data type in the Sysmac Studio and add a user-defined structure variable to the variable table.
- Use the user program or initial values to set the member values of that structure.
- Specify the structure variable for the input parameter to the instruction.

Unions

A union is a derivative data type that enables access to the same data with different data types. You can specify different data types to access the data, such as a BOOL array with 16 elements, 16 BOOL variables, or a WORD variable.

Expressing Unions and Union Members

Specifying Members

When you define a union, you must name each data type that can be accessed. These names are called members. You can express individual members of a union by putting a period after the variable name that represents the entire union followed by the member name that you want to access.

Example:

Define the data type as a union as shown for My Union in the following example.

Data Type Definition

Name	Member	Data type
My Union	data	WORD
	bit	ARRAY [015] OF BOOL

Variable Table

Variable name	Data type
Output	My Union

Output.bit[0]: This notation specifies the 0th element, or value at bit 00, of union Output when it is treated

as a 16-bit BOOL array variable.

Output.data: This notation specifies the value when union *Output* is treated as a single WORD variable.

Specifying the Union

The union represents all members that make up the union. Unions are expressed by the name of the union variable. In the example above, you would write *Output*.

Creating Unions

- Create a union data type in the Union Table. Specify the data type names and different data types of the members of the union.
- Specify the union data type from above as the data type and register the variable in the variable table.

Example:

Here, OUT16_ACCESS is defined as the data type of a union. The members of this union are a BOOL array with 16 elements and a WORD variable. The variable Output is registered with a data type of OUT16 ACCESS. You can now read/write variable Output as a BOOL value for any of the 16 bits and as a WORD value.

Name	Member	Data type
OUT16ACCESS	BoolData	ARRAY[015] of BOOL
	ByteData	ARRAY[01] of BYTE
	WordData	WORD
Variable name	Data type	
Output	OUT16ACCESS	

BoolData [15]		BoolData [8]	BoolData [7]		BoolData [0]		
E	ByteDa	ta	ByteData				
	[1]		[0]				
WordData							

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
BoolData	0	0	0	1	0	0	1	0	0	0	1	1	0	1	0	0
ByteData		16#12							16#34							
WordData	16#1234															
							_									

Output.BoolData[11] :=TRUE;

	15	14	13	12	11	10	9	8	/	6	5	4	3	2	1	0
BoolData	*	*	*	*	1	*	*	*	*	*	*	*	*	*	*	*
ByteData	Bit 04 of ByteData[1] is TRUE							No change								
WordData	Bit 11 of WordData is TRUE															

Union Specifications

Item	Specification
Data types that can be specified for members	Refer to the table on the valid data types for union members that is given below.
Number of members	4 max.
Setting initial values	Not supported. Always zero.

Data Types of Union Members

Classification	Data type	Usage
	Boolean and bit strings	Supported.
Basic data types	BOOL and bit string data array specifications	Supported.
	Other basic data types	Not supported.
Derivative data types	Array specification for structures, unions, and enumerations	Not supported.
POU instances		Not supported.

Restrictions

- The initial values for unions are always zero.
- · You cannot move unions.
- You cannot specify unions for parameters to POUs.

Enumerations (ENUM)

An enumeration is a derivative data type that uses text strings called enumerators to express variable values. To use an enumeration, you must first set the values that can be obtained from that variable as enumerators (text strings). Use enumerations to make it easier for humans to understand the meaning behind the values of a variable.

Expressing Enumerations


When you define an enumeration, you must define the possible values of the variable as enumerators and give the enumeration a name.

Creating Enumerations

- Create an enumeration data type in the Enumeration Table. Set the enumerators and their values for the enumeration.
- Specify the enumeration data type from above as the data type and register the variable in the variable table.

Example:

Here, Color is defined as the data type of an enumeration. For this example, we will set three enumerators: red, yellow, and green. The numbers associated with these enumerators are as follows: red = 0, yellow = 1, green = 2. The variable DiscColor will change to one of the following: red (0), yellow (1), or green (2).



E	numeration Table						
	Data type						
:	Color	ENUM					
	Enumerator	Value					
	red	0					
	yellow	1					
	green	2					
V	Variable Table						
-	Variable name	Data type					
	DiscColor	Color					

Enumeration Specifications

Item	Specification
Enumerator names	Enumerator names consist of single-byte alphanumeric characters. They are not case sensitive. A building error will occur if you specify the same enumerator more than once. A building error will occur if you specify an enumerator with the same name as a variable in the user program or if you specify an enumerator that already exists in another enumeration.
Values	Valid range: Integers between -2,147,483,648 and 2,147,483,647
	Values do not have to be consecutive.
	A compiling error will occur if you specify the same value more than once.
	Note You cannot perform size comparisons with enumeration variables. You can only test to see if the enumerators are the same.
Number of enumerators	1 to 2,048


Notation to Use an Enumerator as a Function Block or Function Parameter

There are the following two notations that you can use to specify an enumerator for a function or function block parameter.

Enumerator Only

For a function or function block for which the parameter specifies an enumerator, you can just specify the enumerator.

Example: Passing an Enumerator to the BCDToBins_WORD Instruction




The Format input variable to the BinToBCDs_WORD is specified as an enumerator.

Therefore, it is necessary to specify only the enumerator.

Enumeration#Enumerator Notation

For a function or function block for which the data type of the parameter is not specified, specifying just the enumerator is not valid. A building error will occur. To clarify that the parameter is an enumerator, the following notation is used: *Enumeration#Enumerator*.

Example: Passing an Enumerator to the MOVE Instruction



The data type of the *In* input variable is not specified.

To pass an enumerator, use the Enumeration#Enumerator notation.



Additional Information

For a function or function block for which the parameter specifies an enumerator, you can also use the *Enumeration#Enumerator* notation. Therefore, for the above BinToBCDs_WORD instruction, the following notation can be used to pass the parameter to Format: _eBCD_FOR-MAT#_BCD1.

Value Checks

When a value is written to an enumerated variable through execution of an instruction, an error will not occur even if that value is not defined as one of the enumerators of that variable. Therefore, if it is necessary to confirm that a value is defined as an enumerator of an enumeration, write the user program to check the value.

6-3-7 Array Specifications and Range Specifications for Data Types

You can specify the following attributes for variables with each data types.

- · Array specifications
 - · Fixed-length array specifications
 - · Variable-length array specifications
- · Range specifications

Array Specifications (ARRAY[]OF)

Use an array specification for a data type that handles a group of data with the same attributes as a single entity. You can use an array specification for the basic data types and derivative data types. Arrays are useful when you want to handle multiple pieces of data together as you would, for example, coordinate values for motion control.

Expressing Arrays and Array Elements


Specifying Elements

The individual pieces of data that make up an array are called "elements."

The elements of an array are expressed by adding a subscript (element number) from the start of the array to the name of the variable that represents the entire array.


Enclose the subscript in single-byte braces []. Subscripts can be either constants or variables. In ST, you can also use expressions to express subscripts.

Examples:



x := 10:

Mem[x]: This expression specifies the xth element of the array variable Mem (the variable x has a value of 10, so this would point to the 10th element).



x:=10;

y:=20;


Data[x+y]: This expression specifies the x+yth element of the array variable Data (the variable x has a value of 10 and variable y has a value of 20, so this would point to the 30th element).

Specifying An Array (i.e., the Entire Array)

The array represents all elements that make up the array. Arrays are expressed by the name of the array variable. In the above examples, the arrays are written as Mem and Data.

Creating an Array

- **1** Enter "A" into the *Data type* Column of the variable table and select *ARRAY[?..?] OF ?* from the list of possible data type name candidates.
- **2** Enter the number of the first element in the array for the left question mark and the last number for the right question mark in the "[?..?]" section. Next, enter the data type for the question mark in the "OF?" section and register the variable.





Additional Information

You can use a fixed-length array specification for a variable when you specify the first number and last number for the subscripts. You can use a variable-length array specification for a variable when you specify a single-byte asterisk (*) for the subscript.

There are the restrictions on fixed-length array specifications when you use a variable-length array specification. Refer to *Variable-length Array Specifications* on page 6-54 for details on variable-length array specifications.



Version Information

A CPU Unit with unit version 1.18 or later and Sysmac Studio version 1.22 or higher are required to use variable-length array specification.


Array Variable Specifications


Item		Specification					
Maximum number of elements for an array variable	6	5,535					
Element numbers	_	0 to 65535 The number for the first element in an array does not have to be 0.					
Subscripts	С	onstants: Integer va	alue between 0 a	and 65535	_		
	Va	ariables:					
		Classification		Data type	Usage		
			Integer	SINT, INT, DINT, USINT, UINT, or UDINT	Supported.		
		Basic data type		LINT or ULINT	Not sup- ported.		
			Boolean, bit str day, date and t	Not sup- ported.			
		Derivative data types	Structures, unio	Not sup- ported.			
		POU instances			Not sup- ported.		
	Α	rithmetic expression	ns: Arithmetic ex	pressions can be specified only in	ST.		
	E	xample: y:= x[a+b];					
Maximum size of	N	X701-□□□□: 8 M	В				
one array variable	1	NX102-□□□: 4 MB					
	1	NX1P2-□□□: 1 MB NJ501-□□□: 4 MB					
		J301-□□□□: 4 MI					
	N	J101-□□□□: 2 MI	В				

Dimensions of Array Variables


You can regard the elements of a one-dimensional array as one-dimensional data lined up in a single row. You can set two-dimensional and three-dimensional arrays in the same way. The array elements are expressed by adding the same number of subscripts to the array variable name as the number of dimensions. Arrays can have a maximum of three dimensions.

Two-dimensional Array Specifications






Three-dimensional Array Specifications




Arrays and Structures

You can set an array in which the elements are structures. You can also set a structure in which the members are arrays.

Arrays with Structure Elements




Structure with Array Members



Instructions with an Array Parameter

Some instructions pass array variables as parameters. To do so, specify only the name of the array variable as the input parameter.

Example: Passing a Single Array Element to the MOVE Instruction and Passing an Array to the MOVE instruction



When you specify an array variable, it must be moved to a variable of the same data type with the same range of element numbers.



Additional Information

You cannot specify part of a multi-dimensional array as a parameter.






Variable Table								
	Variable name	Data type						
	х	ARRAY [09 , 09 , 09]OF INT						
	у	ARRAY [09 , 09 , 09]OF INT						
	-							


Array Protection

The following errors occur if you attempt to access an element that exceeds the number of elements in an array.

When the Subscript Is a Constant


An error is displayed when you input the variable or when you check the program on the Sysmac Studio.





When the Subscript Is a Variable

When an output parameter is assigned to an output variable, the CPU Unit checks to see if the number of elements was exceeded after it executes the instruction. When a subscript variable exceeds the range of the elements of the array variable, an instruction error occurs. Even if this error occurs, the value of ENO will be TRUE because internal processing of the instruction ends normally.



Variable-length Array Specifications

You can use a variable-length array variable if you specify a single-byte asterisk (*) for the subscript when you declare the array variable. The maximum number of elements, dimensions, and data types that can be declared are the same as the specification of fixed-length array variables.

However, there are the restrictions on variable declaration and processing.

Restrictions on Variable Declaration

Only in-out variables for functions (FUN) and in-out variables for function blocks (FB) can be declared as variable-length array variables. Other variables cannot be declared as variable-length array variables.

Array variable to declare	Allowed or not allowed
In-out variables for functions	Allowed.
In-out variables for function blocks	Allowed.
Input variables or output variables for functions	Not allowed.

Array variable to declare	Allowed or not allowed
Input variables or output variables for function blocks	Not allowed.
Internal variables, external variables, and global variables	Not allowed.
Members in structure variables or members in union variables	Not allowed.

When you declare an array variable with two or three dimensions as a variable-length array variable, you need to specify a single-byte asterisk (*) for all dimensions. You cannot declare a variable which uses both variable-length dimension and fixed-length dimension.

Array variable to declare	Specification example	Allowed or not allowed
Variable-length array specification for all dimensions	• ARRAY[*] • ARRAY[*, *] • ARRAY[*, *, *]	Allowed.
Both variable-length dimension and fixed-length dimension are used	• ARRAY[*, 35] • ARRAY[*, *, 35]	Not allowed.
Individual specification for first number or last number	• ARRAY[1*] • ARRAY[**]	Not allowed.

Restrictions on Processing

If an in-out variable for a function (FUN) and function block (FB) is a variable-length array variable, an array variable that you can specify for the in-out parameter is only the one whose data type and number of dimensions are the same as the in-out variable. You can use either a variable-length array variable or fixed-length array variable as long as its data type and number of dimensions are the same as the in-out variable. You cannot specify an array variable whose data type or number of dimensions is different.

If an in-out variable for a function (FUN) and function block (FB) is a fixed-length array variable, you cannot specify a variable-length array variable for the in-out parameter.

Example of in-out variable for function and function block	Example of in-out parameter to specify	Allowed or not allowed
Variable-length array whose data type is INT and dimension is 1	Variable-length array whose data type is INT and dimension is 1	Allowed.
Variable-length array whose data type is INT and dimension is 1	Fixed-length array whose data type is INT and dimension is 1	Allowed.
Variable-length array whose data type is INT and dimension is 1	Variable-length array whose data type is UINT and dimension is 1	Not allowed.
Variable-length array whose data type is INT and dimension is 1	Variable-length array whose data type is INT and dimension is 2	Not allowed.
Fixed-length array whose data type is INT and dimension is 1	Variable-length array	Not allowed.

When you write an assignment expression for the entire array in an ST, if you include a variable-length array variable in either the left side or right side of the expression, a building error will occur.

Similarly, when you transfer the entire array with the MOVE instruction in a ladder diagram, if you include a variable-length array variable in either the output parameters or input parameters, a building error will occur.

Left side Output parameter	Right side Input parameter	Example of expression in ST*1	Allowed or not allowed
Variable-length array variable	Variable-length array variable	varlen_ary := varlen_ary;	Not allowed.
Variable-length array variable	Fixed-length array variable	varlen_ary := fixed_ary;	Not allowed.
Fixed-length array variable	Variable-length array variable	fixed_ary := varlen_ary;	Not allowed.
Fixed-length array variable	Fixed-length array variable	fixed_ary := fixed_ary;	Allowed.

^{*1} varlen_ary shows a variable-length array variable, and fixed_ary shows a fixed-length array variable.

● First and Last Element Numbers of Variable-length Array Variable

When the user program is executed, the first and last element numbers are determined. You can obtain the first and last numbers of each dimension of a variable-length array variable with the LOW-ER_BOUND and UPPER_BOUND instructions.

Refer to the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for the details on the LOWER_BOUND and UPPER_BOUND instructions.

Range Specifications ((..))

Use the range specification to restrict the values of the following integer variables to specific ranges of values.

Classification	Data type	
Integers	SINT, INT, DINT, LINT, USINT, UINT, UDINT, and ULINT	

You can check to make sure that the entered value is within the allowed range in the following cases.

- · When you specify an initial value for a variable
- When you write a value to a variable with CIP message communications


Making a Range Specification

Input the start point and end point after the data type name in the Data type Column in the variable

Start point: The minimum value that you can store in the variable.

End point: The maximum value that you can store in the variable.

Example:




• Specifications of Range Specifications

Item	Specification			
Data types that you can specify	Integer type			
		Case	0	peration
	User program		The CPU Unit does n	cur and the value is written. ot perform a range check ariable changes due to the oction.
			When the value is an integer	A command error occurs.
		Write from the Sysmac Studio	For an element of an integer array variable	
	Communi-	or a CIP mes- sage	For a member of an integer structure	
	cations		For an integer structure	A command error does not occur and the value is writ-
			For an integer array	ten.
	Tag data links (both via built- in EtherNet/IP ports and Eth- erNet/IP Units)	An error occurs if you attempt to write to a single member that specifies a range. An error does not occur if you attempt to write to a structure that contains a member for which a range is specified		
	Input refreshing and Units		An error does not occur and the value is written	
	Forced refreshing values		An error does not occ	cur and the value is written.




Precautions for Correct Use

Variables with range specifications are not checked for changes in variable values that result from the execution of instructions in the user program. To check the range of values for a variable that are set from execution of the user program, use instructions that perform range checks.



You cannot perform any checks beforehand if you set data with arithmetic processing results. In this case, check the range of values after arithmetic processing (e.g., ADD).



Make sure that the initial value is within the range specified for the Range Specification. If the initial value field on the Sysmac Studio is left blank, an initial value of 0 is used. This applies even if a range that does not include 0 is set for a Range Specification.

6-3-8 Variable Attributes

This section describes the variable attributes other than the Data Type.

Variable Name

The variable name is used to identify the variable. Each variable in a POU must have a unique name. However, you can declare local variables with the same variable name in different POUs. These are treated as two separate variables.

Refer to 6-3-12 Restrictions on Variable Names and Other Program-related Names for restrictions on variable names.

AT Specification

Use the AT Specification attribute to specify the internal I/O memory address of a variable in memory used for CJ-series Units. AT specifications are used mainly to specify specific memory addresses for the following Special Units.

- · Addresses in fixed allocations for DeviceNet Units
- Addresses in user-specified allocations for DeviceNet Units or CompoNet Master Units from the CX-Integrator (A CompoNet Master Unit must be set to communications mode 8 to use the CX-Integrator.)
- · Addresses in expansion memory for High-speed Counter Units
- · Addresses in expansion memory for Process I/O Units
- Addresses in target node information and user-defined status areas that are used with EtherNet/IP
 Units

If this attribute is not set, the variable is automatically assigned to an address in variable memory.



Precautions for Correct Use

You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.



Additional Information

When you assign a device variable to an I/O port, they are automatically given an AT specification internally.

Allocation Areas

You can specify addresses in the following areas.

Area	Expression
CIO	CIO 0 to CIO 6143
Work	W0 to W511
Holding	H0 to H1535
DM	D0 to D32767*1
EM*2	NX102-□□□: E0_0 to E18_32767 NJ501-□□□: E0_0 to E18_32767 NJ301-□□□: E0_0 to E3_32767 NJ101-□□□: E0_0 to E3_32767

^{*1} For the NX1P2-\(\subseteq\), the address is D0 to D15999.

^{*2} For the NX1P2-\(\superscript{\superscript

The following table gives the data assignments by variable data type.

Variable data type	Assignment position
BOOL	You can specify an assignment for each bit.
	You can specify bit 0 or bit 8 of the specified CJ-series address as the start position of the data assignment.
BYTE/SINT/USINT	Example 1: AT Specification at Bit 0 of D100 (%D100) D100: 16#**12One-byte data (12) is stored from bit 0.
	Example 2: AT Specification at Bit 8 of D100 (%D100.8) D100: 16#12**One-byte data (12) is stored from bit 8.
WORD/INT/UINT	Stored in increments of the data size from bit 0 of the specified CJ-series
DWORD/DINT/UDINT REAL	address.
LWORD/LINT/ULINT LREAL	
STRING	You can specify bit 0 or bit 8 of the specified CJ-series address as the start position of the data assignment.
TIME DATE TIME_OF_DAY DATER_AND_TIME	Stored in increments of the data size from bit 0 of the specified CJ-series address.

Variables for Which You Can Set AT Specifications

AT specifications are made separately for each variable. Set them for all elements and members of array, structure, and union variables.

Attributes of Variables with AT Specifications

	Specification	Remarks
Name	Supported.	
Data Type	Supported.	
Retain	Supported.	An error occurs if the setting of the Retain attribute does not agree with the attribute of the CJ-series Unit memory where the address is assigned.
Initial Value	Supported.	Set the initial value setting to <i>None</i> if you want to use the memory value as it is.
Constant	Supported.	You cannot write to a constant with an instruction.
Network Publish	Supported.	
Edge	Not supported.	(You can specify the Edge attribute only for function block input variables.)

Entering and Displaying AT Specifications

When you specify the AT Specification attribute, input the following in the Allocated Address Box of the variable table in the Sysmac Studio. The following is displayed in the Allocated Address Box of the variable table or the I/O Map.

Type of variable	Entries and displays in the <i>AT</i> field.	Example
User-defined variables with AT specifications to word addresses	%[word_address]	%D100
User-defined variables with AT specifications to bit addresses	%[word_address].[bit_position]	%W0.00

The following variables are also allocated an address internally. The following is displayed in the Allocated Address Box.

Type of variable	Displays in the AT field.	Example
Device variables for CJ-series Units	IOBus://rack#[rack_num- ber]/slot#[slot_num- ber]/[I/O_port_number]	Basic I/O Units: IOBus://rack#0/slot#1/Ch1_In/C h1_In00 Special Units: IOBus://rack#0/slot#1/PeakHold-
Device variables for EtherCAT	For NX Units on EtherCAT Slave Terminals: ECAT://node#[node_ad-dress.NX_Unit_num-ber]/[I/O_port_name]	Cmd/ch1_PeakHoldCmd ECAT://node#[10.15]/Input1
Siaves	Other device variables: ECAT://node#[node_ad- dress]/[I/O_port_name]	ECAT://node#1/Input1
Device variables for NX Units*1	IOBus://unit#[NX_Unit_num- ber]/[I/O_port_name]	IOBus://unit#8/Input Bit 00
Device variables for built-in I/O*2	BuiltInIO://cpu/#0/[//O_port_name]	BuiltInIO://cpu/#0/Input Bit 00
Device variables for Option Boards* ²	BuiltInIO://opt/#[physi- cal_port_num- ber*3]/[I/O_port_name]	BuiltInIO://cpu/#1/Ch1 Analog Input Value
Axis Variables	MC://_MC_AX[] MC://_MC1_AX[]*4 MC://_MC2_AX[]*4	MC://_MC_AX[1]
Axes Group Variables	MC://_MC_GRP[] MC://_MC1_GRP[]*4 MC://_MC2_GRP[]*4	MC://_MC_GR[1]

^{*1} These system-defined variables are available only for the NX102 CPU Unit and NX1P2 CPU Unit.

^{*4} These system-defined variables are available only for the NX701 CPU Unit.



Precautions for Correct Use

You can assign the same address to more than one variable. However, this is not recommended as it reduces readability and makes the program more difficult to debug. If you do this, set an initial value for only one of the variables. If you set a different initial value for each individual variable, the initial value is undefined.

Retain

Use the Retain attribute to specify whether a variable should retain its value in the following cases.

- When power is turned ON after power interruption
- When the operating mode is changed
- · When a major fault level Controller error occurs

^{*2} These system-defined variables are available only for the NX1P2 CPU Unit.

^{*3} The physical port number indicates a physical location for an I/O port. 0 is given for the option board slot 1 and 1 is given for the option board slot 2.

If the Retain attribute is not set, the value of the variable is reset to its initial value in the above situations.

You can specify the Retain attribute when you need to retain the data that is stored in a variable (such as the manufacturing quantities) even after the power to the Controller is turned OFF.

For a variable with an AT specification, the setting of the Retain attribute must agree with address in the memory area where the address is assigned.

(Retained areas: Holding, DM, and EM Areas Non-retained areas: CIO and Work Areas)

Conditions Required to Enable the Retain Attribute

The CPU Unit must contain a Battery.

Using Initial Values for Retain Variables

When you download the user program, select the Clear the present values of variables with Retain attribute Check Box.

Operation with and without the Retain Attribute

The following table shows when variable values are retained or not.

		Values of	variables
Case		Retain attribute speci- fied	Retain attribute not specified
When power is turned ON	l after power interruption	Retained.	Not retained.
When the operating mode is changed			
When a major fault level Controller error occurs			
When you download the user program	When the Clear the present values of variables with Retain attribute Check Box is selected.		
	When the check box is not selected.	Not retained.	

Variables for Which You Can Specify the Retain Attribute

AT specifications are made separately for each variable. Set them for all elements and members of array, structure, and union variables.

Initial Value

The variable is set to the initial value in the following situations.

- · When power is turned ON
- When changing between RUN mode and PROGRAM mode
- · When you select the Clear the present value of variables with Retain attribute Check Box, and download the user program
- · When a major fault level Controller error occurs

You can set an initial value for a variable in advance so that you do not have to write a program to initialize all of the variables. For example, you can preset data such as a recipe as initial values. You do not have to set any initial values.

Types of Variables That Can Have Initial Values

You can set initial values for only some types of variables. A list is provided below.

Type of variable	Initial Value
Global variables	Supported.
Internal variables	
Input variables	
Output variables	
Return values of functions	Not supported.
In-out variables	
External variables	

Enabling an Initial Value

You can specify whether a variable has an initial value when you create the variable.

Initial Value Specified

Initial value	0	Initial value
	Or (Blank)	3.14

No Initial Value Specified

Initial value	
None	

The following table shows the variables for which you can set an initial value.

Туре		Example	Enabling an Initial Value
Basic data type variables		aaa	Supported.
Arrays		bbb	Supported.
Array variables	Elements	bbb[2]	Not supported.
Structure variables	Structures	ddd	Supported.
Structure variables	Members	ddd.xxx	Not supported.
Union variables	Unions	eee	Not supported (initial values are always 0).
Members		eee.word	Initial values are always 0.
Enumerated variables		ссс	Supported.
POU instances		instance	Not supported.



Additional Information

Some Basic I/O Units have more than one access method for the same I/O port, such as bit string data and BOOL data. If you use initial values for this type of I/O port, set the initial values for one of the access types to None.

When Initial Values Are Set

The initial value is assigned to the variable at the following times.

- · When power is turned ON
- When the operating mode changes from PROGRAM to RUN mode or from RUN to PROGRAM mode
- When you select the *Clear the present value of variables with Retain attribute* Check Box, and download the user program
- · When a major fault level Controller error occurs

When the Initial Value Specification Is Left Blank

The following initial values are used for variables for which the initial value specification is left blank.

Data	Default initial value	
Boolean and bit strings	BOOL, BYTE, WORD, DWORD, and LWORD	0
Integers	SINT, INT, DINT, LINT, USINT, UINT, UDINT, and ULINT	0
Real numbers	REAL and LREAL	0.0
	TIME	T#0S
Durations, dates, times of day,	DATE	D#1970-01-01
and dates and times	TIME_OF_DAY	TOD#00:00:00
	DATE_AND_TIME	DT#1970-01-01-00:00:00
Text strings	STRING	' '(blank character)

Initial Value of Array Variables

Data type	Initial value specifications		
Array specifications	 You can specify an initial value for each element. To specify initial values, you must specify a value or leave the specification blank for each element. 		

Initial Values for Derivative Data Types

You do not specify an initial value for the data type itself. You set an initial value for each individual variable.

Data type	Initial value specifications		
Structures	 You can specify an initial value for each member. To specify initial values, you must specify a value or leave the specification blank for each element. 		
Unions	Initial values cannot be specified. Always zero.		
Enumerations	Initial values can be specified.		

Variables That Do Not Apply Initial Values

For the following variables, initial values are not applied when the power is turned ON, and the values before the power interruption are retained.

- · Variables with Retain attribute
- Variables with AT specifications (retained areas or DM, Holding, or EM Area specifications only)



Precautions for Correct Use

If the CPU Unit has no Battery, the above variables are also initialized.

Constant

If you specify the Constant attribute, the value of the variable cannot be written by any instructions, ST operators, or CIP message communications. Setting the Constant attribute will prevent any program from overwriting the variable. The values of variables with a Constant attribute cannot be written from instructions after the initial value is set. If there is an instruction in a POU that attempts to write a value to a variable with the Constant attribute, an error will occur when the user program is compiled.

Operation

If there is an instruction or operator in a POU that attempts to write a value to a variable with the Constant attribute, the following operations will occur.

Soi	urce	Operation for attempts to write the value
User program		An error is detected during the program check. The Sysmac Studio checks the program when it is built. A building error occurs at that time.
	Writing from Sys- mac Studio	Not supported.
Communications	CIP messages	A command error occurs.
	Tag data links	An error occurs when a tag data link starts. The tag data link will continue to operate. However, the values of variables with the Constant attribute are not written.
Input refreshing fro	m slaves and Units	An error does not occur and the value is written.
Forced refreshing		

Range for Constant Attribute Specification

The Constant attribute is specified separately for each variable. Set them for all elements and members of array, structure, and union variables.



Additional Information

You cannot write to variables with the Constant attribute from the user program.

Network Publish

The Network Publish attribute allows a variable to be read/written from external devices (other Controllers, host computers, etc.) through CIP message communications or tag data links. If this attribute is not set, you can read/write the variable from the Controller that declared the variable and external devices (other Controllers, host computers, etc.) cannot read/write that variable.

Variables that have been published to the network are called network variables.

Network Publish Specifications

There are three specifications for publishing variables to the network: Publish Only, Input, and Output. The specifications are given in the following table.

Network Publish Specifications		Specifications	
Do not publish		You cannot access a variable with this attribute from external devices. However, Support Software can still access the variable regardless of this setting.	
Publish	Publish Only	You can access a variable with this attribute from external devices through C communications. Tag data links are not possible for variables with this attribusetting.	
	Input	You can access a variable with this attribute from external devices through CIP communications or a tag data link. For tag data links, this will be a variable for data input (from another CPU Unit to the local CPU Unit).	
	Output	You can access a variable with this attribute from external devices through CIP communications or a tag data link. For tag data links, this will be a variable for data output (from the local CPU Unit to another CPU Unit).	

Ranges for Published to the Network

The Network publish attribute is specified separately for each variable. Set them for all elements and members of array, structure, and union variables.

Edge

The Edge attribute makes the variable pass TRUE to a function block when a BOOL variable changes from FALSE to TRUE or from TRUE to FALSE. You can specify the Edge attribute only for BOOL input variables to function blocks.

Application

Use the Edge attribute when you want the function block to accept the input only when the input parameter changes from FALSE to TRUE or from TRUE to FALSE. For example, you can use this attribute when you want to execute the function block any time there is a change detected in an input parameter.

Operation

- If you specify a change to TRUE, the input variable changes to TRUE only when the input parameter connected to that input variable changes from FALSE to TRUE.
- If you specify a change to FALSE, the input variable changes to TRUE only when the input parameter changes from TRUE to FALSE.

Specification	Value of input parameter	Value of variable
Change to TRUE	FALSE to TRUE	TRUE
Change to TROE	Other	FALSE
Change to FALSE	TRUE to FALSE	TRUE
Change to FALSE	Other	FALSE
None		Changes according to the input parameter value.

6-3-9 Changes to Variables for Status Changes

This section describes the changes to the values of variables for status changes of the CPU Unit.



Version Information

With the combination of a CPU Unit with unit version 1.13 or later and Sysmac Studio version 1.17 or higher, you can set the operations when the operating mode changes or when downloading according to the setting of the *_DeviceOutHoldCfg* (Device Output Hold Configuration) system-defined variable.

The values of variables in the CPU Unit will change as shown in the following table when the power is turned ON, when the operating mode changes, or when downloading.

	f Type of variable				After dow	nloading
Retain attribute of variable			When power is turned ON	When operating mode changes	When the Clear the present values of variables with Retain attribute Check Box is selected.	When the check box is not selected.
	User-defined vari-		 If initial values are 	set, the variables cha	ange to the initial value	S.
	ables		 If initial values are 	not set (None), the v	ariables change to 16#	00.*1
		AT specifi- cations for	If initial values are change to the initial	,	If initial values are s change to the initial	'
		CIO and Work Area addresses in the mem- ory used for CJ- series Units	If initial values are variables change to	not set (None), the	If initial values are r previous value is re	ot set (None), the
	Device variables for EtherCAT slaves*2 Device variables for		If initial values are	set, the variables cha	ange to the initial value	S.
			• If initial values are not set (None), the variables change to 16#00.*1			
Non-retain				•	ange to the initial value	
	NX Units	2			ariables change to 16#	
	Device v	ariables for		•	ange to the initial value	
		ariables for			ariables change to 16# ange to the initial value:	
	Option B			•	ariables change to 16#	
	Device v	ariables for s Units ^{*2}	If initial values are change to the initia If initial values are variables change to	al values. not set (None), the	If initial values are s change to the initial If initial values are r previous value is re	values. not set (None), the
	CIO and Work Area addresses in the memory used for CJ- series Units*2*3		16#00		The previous values a	are retained.

					After dov	vnloading
Retain attribute of variable	Type	of variable	When power is turned ON	When operating mode changes	When the Clear the present values of variables with Retain attribute Check Box is selected.	When the check box is not selected.
		Retain condition is met.*4	No change (retains value before power interruption).	No change (i.e., the values in RUN mode are	If initial values are set, the variables change to the ini-	The values from before the download are retained.
	User- defined	Retain condition is not met.*3		retained).	• If initial values are not set (None), the variables change to 16#00.*1	If initial values are set, the variables change to the initial values. If initial values are not set (None), the variables change to 16#00.*1
	vari- ables	AT specifications for Holding, DM, and EM Area addresses in the memory used for CJ-series Units			If initial values are set, the variables change to the initial values. If initial values are not set (None), the variables change to the values of the memory addresses in the AT specifications.	
Retain	Device v CJ-series	ariables for s Units			If initial values are set, the variables change to the initial values. If initial values are not set (None), the variables change to the values of the memory addresses in the AT specifications.	The variables change to the values of the memory addresses in the AT specifications.
	Area addı	DM, and EM resses in the used for CJ- its*2			The previous values are retained. If device variables for CJseries Units are assigned to setup data in the DM Area, the initial values that are set for the variables are used. If user-defined variables are assigned, the initial values of the variables are used.	The previous values are retained.

^{*1} Values other than 16#00 may be used depending on the data type. For details, refer to When the Initial Value Specification Is Left Blank on page 6-64.

^{*2} Device outputs are retained even when the operating mode changes or when downloading if the device output hold configuration is set to enable (16#A5A5) in the _DeviceOutHoldCfg (Device Output Hold Configuration) system-defined variable. Refer to Device Output Hold Configurations on page 6-70 for the device output hold configurations.

^{*3} This does not include user-defined variables and device variables for CJ-series Units if they have AT specifications.

*4 Refer to *Retain Condition* on page 6-72 for the retain conditions.

The values of variables in the CPU Unit will change as shown in the following table when a major fault level Controller error occurs, or during online editing.

Retain attribute		When a major fault level	During onlin	e editing
of variable	Type of variable	Controller error occurs	Variable added to a POU for online editing.	Variable in a POU for online editing.
Non-retain	User-defined vari- ables and device vari- ables	 If initial values are set, the variables change to the initial values. If initial values are not set, the variables change to 16#00. 	 If initial values are set, the variables change to the initial values. If initial values are not set, the variables change to 16#00. 	No change
CIO and Work mem- ory areas for CJ- series Units		16#00	No change	
Retain	User-defined vari- ables and device vari- ables	No change (retains value before error).	 If initial values are set, the variables change to the initial values. If initial values are not set, the variables change to 16#00. 	
	Holding, DM, and EM memory areas for CJ-series Units		No change	
Others	Forced refreshing status	Cleared.	No change	



Precautions for Correct Use

You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

Device Output Hold Configurations

You can set the operations when the operating mode changes or when downloading according to the setting of the DeviceOutHoldCfg (Device Output Hold Configuration) system-defined variable.

If the device output hold configuration is set to disable (other than 16#A5A5), device outputs will change as given in 6-3-9 Changes to Variables for Status Changes.

Device outputs are retained even when the operating mode changes or when downloading if the device output hold configuration is set to enable (16#A5A5).

Status	Device output he	old configuration	
Sidius	Disable (other than 16#A5A5)	Enable (16#A5A5)	
When the operating mode is changed	Variables are initialized.	Values of variables are retained.	
When downloaded	I/O refreshing is stopped and variables are initialized after downloading.	I/O refreshing is executed and values of variables are retained after downloading.	

Device Outputs for Hold Configurations

The following gives the device outputs for device output hold configuration.

- · Device variables for EtherCAT slaves
- · Device variables for NX Units
- Device variables for built-in I/O
- · Device variables for Option Boards
- Device variables for CJ-series Units (operating data)
- CIO and Work Area addresses in the memory used for CJ-series Units

Conditions To Retain Device Outputs When Downloading

There are restrictions on the changeable items as the conditions to retain device outputs when downloading. The following table gives the items for which device outputs can be retained even if items are changed.

Item		
EtherCAT Backup Parameter Settings of EtherCAT slaves		
CPU/Expansion Racks	Special Unit Settings of CJ Units	
I/O Map	Variable Name	
	Variable Comment	
	Variable Type	
Event Settings		
Task Settings	Program Assignment Settings	
Programming - POUs	Program	
	Section	
	Internal/ External Variable	
	Function	
	Function Block	
Programming - Data	Data Type	
	Global Variable	
EtherNet/IP Connection Settings		
DB Connection Settings		

If items other than those given in the above table are changed and downloaded, device outputs are not retained.

Also, in the Synchronization Window of the Sysmac Studio, select the check box for the **Do not transfer the following.** (All items are not transferred.) - CJ-series Special Unit parameters and EtherCAT slave backup parameters. If you do not select the check box, device outputs are not retained.

Perform the following procedure if you want to retain device outputs, and change EtherCAT slave backup parameters or NX bus Unit operation settings.

- **1** Change the user program only and download it.
- **2** Select the slave in the EtherCAT Tab Page.
- 3 Click the Edit Backup Parameter Settings Button in the Slave Parameter Settings Area on the right of the network configuration.
- 4 Click the Transfer to Slave Button in the Edit Backup Parameter Settings Tab Page.
- **5** Right-click a Unit in the CPU and Expansion Racks Tab Page and select **Edit Unit Operation Settings**.
- **6** Click the **Transfer to Unit** Button for the Unit operation settings.

If you execute **Transfer to Slave** or **Transfer to Unit**, the slave or Unit is restarted after the data is transferred. In this case, device outputs of the slave or Unit are not retained. However, device outputs are retained for the slave or Unit that the data is not transferred.

Related System-defined Variables

The system-defined variables that are related to the operation when system-defined variables are used to back up data are shown below. Refer to A-7 Specifications for Individual System-defined Variables for details on system-defined variables.

Variable	Meaning	Function	Data type	R/W
_DeviceOutHoldCfg	Device Output Hold Configuration	It is 16#A5A5 if you retain the target device output when the operating mode is changed or when downloaded. In the case other than 16#A5A5, the target device output is initialized when the operating mode is changed or when downloaded.	WORD	RW
_DeviceOutHoldStatus	Device Output Hold Status	It is TRUE if the target device output is retained when the operating mode is changed or when downloaded. When the device output hold configuration is other than 16#A5A5, or when a major fault level Controller error occurs, the target device output is initialized and changes to FALSE.	BOOL	R

Retain Condition

Retain condition indicates that all of the following conditions are met both before and after the download.

- · The variable name is the same.
- The data type (name) is the same.
- The Retain attribute is set to retain the value of the variable.

Refer to Values of Retain Variables After New Creations or Changes of POU Names on page 6-72 for the value of a variable with a Retain attribute after its POU name is changed. Also refer to Variable Values When Data Types of Retained Variables Are Changed on page 6-75 for the value of a variable when its data type is changed.



Version Information

For the CPU Unit with unit version 1.10 or earlier, the retain condition indicates that all of the following conditions are met both before and after the download.

- The variable name is the same.
- The data type name and data type size are the same.
- The Retain attribute is set to retain the value of the variable.

Values of Retain Variables After New Creations or Changes of POU Names

When you download a project that you created with the Sysmac Studio to a Controller, the Controller treats it with a POU name that is different from the POU name displayed on the Sysmac Studio. Even if the POU name is the same as the one displayed on the Sysmac Studio, the Controller may treat it as a different POU.

This section describes how the Controller treats POU names and the values of local variables with a Retain attribute when POU names are changed or newly created on the Sysmac Studio and downloaded.

Before an Operation with the Sysmac Studio

A project, named Poject A, which was created with the Sysmac Studio is downloaded to a Controller. The Poject A contains POU A in which a local variable VarA is contained.

Assume the POU that is displayed as POU A on the Sysmac Studio is treated as POU XXX on the Controller. Also, assume the present value of the local variable VarA on the Controller is changed to 20.

On the Sysmac Studio	
Project name:	Project_A
POU name:	POU_A
Variable name:	VarA
Initial value of VarA:	0



On the Controller	
Project name:	Project_A
POU name:	POU_XXX
Variable name:	VarA
Present value of VarA:	20

After Changing a POU Name

The POU name and the present value of the local variable VarA do not change on the Controller even after you change the POU name from POU_A to POU_B on the Sysmac Studio and download it.

On the Sysmac Studio	
Project name:	Project_A
POU name:	POU_B
Variable name:	VarA
Initial value of VarA:	0




On the Controller	
Project name:	Project_A
POU name:	POU_XXX
Variable name:	VarA
Present value of VarA:	<mark>20</mark>


After Creating a New POU

When you create a new POU, POU_C, for a local variable on the Sysmac Studio and download it, the Controller treats it as a new POU, POU_YYY, and as a new local variable VarA.

Therefore, the value of the new local variable VarA is the initial value, 0.







After Copying a POU Name

When you copy a POU, POU_A, to create a POU_A_copy on the Sysmac Studio and download it, the Controller treats it as a new POU, POU ZZZ, and as a new local variable VarA.

Therefore, the value of the new local variable VarA is the initial value, 0.


On the Sysmac Studio	
Project name:	Project_A
POU name:	POU_A
Variable name:	VarA
Initial value of VarA:	0
POU name:	POU_A_copy
Variable name:	VarA
Initial value of VarA:	0




On the Controller	
Project name:	Project_A
POU name:	POU_XXX
Variable name:	VarA
Present value of VarA:	20
POU name:	POU_ZZZ
Variable name:	<mark>VarA</mark>
Present value of VarA:	0

When Copying an Exported Project File

The POU name and the present value of the local variable VarA do not change on the Controller even after you copy the Project_A to create the Project_A copy on the Sysmac Studio and download it.






The present value of the local variable VarB does not change on the Controller if you create a local variable VarB that was nonexistent in the Project A when the Project A was copied, add VarB to the Project_A and download it while you add a local variable VarB of the same definition to the Project A copy and download it.

In the same manner, the present value of the local variable VarB does not change on the Controller if you copy the local VarB from the Project A or merge the variable table.

Download







On the Controller	
Project name:	Project_A_copy
POU name:	POU_XXX
Variable name:	VarA
Present value of VarA:	20
Variable name:	<mark>VarB</mark>
Present value of VarB:	<mark>50</mark>

When Adding a POU of the Same Name to Another Project

When you create Project B which has a POU, POU A, that is the same name as the POU in the Project A on the Sysmac Studio and download it, the Controller treats it as a new POU, POU YYY, and as a new local variable VarA. Therefore, the value of the new local variable VarA is the initial value, 0.









When Copying a POU from Another Project to Original Project

When you create Project B on the Sysmac Studio, copy and past POU_A from the Project_A to Project B, and download it, the Controller treats it as a new POU, POU YYY, and as a new local variable VarA. Therefore, the value of the new local variable VarA is the initial value, 0.





Download



Variable Values When Data Types of Retained Variables Are Changed

This section describes how the Controller treats the variable values when the data types of variables with a Retain attribute are changed on the Sysmac Studio and the present values of variables with a Retain attribute are restored, transferred, or downloaded.

Operation and Variable Values

There are two patterns in the way how the variables with a Retain attribute are treated. The table below shows the relationship between the operations and treatment patterns.

Operation	Treatment pattern of vari- able value
Restoring with Sysmac Studio Controller backups	Pattern 1
Restoring with SD Memory Card backups	
Automatic transfer from SD Memory Cards	
Program transfer from SD Memory Card	
Restoring with variable and memory backup functions on the Sysmac Stu- dio	Pattern 2
Downloading from the Sysmac Studio	Pattern 2*1

^{*1} Pattern 1 applies for a CPU Unit with unit version 1.10 or earlier. The pattern difference depends only on the unit version of the CPU Unit. It does not depend on the unit version settings for project devices.

The following section gives further description on the treatments of pattern 1 and 2 for each data type.

Changes in Basic Data Types

Assume the variables before changes on the Sysmac Studio are defined as in below.

Variable name	Data type	AT specification
ABC	INT	
DEF	INT	%D100

Assume the Retain attribute of each variable is set to retain, and the following present values are given.

Variable/memory	Present value
ABC	10
DEF	20

Assume the following present values are given for the memory used for CJ-series Units, DM100 and DM101.

Variable/memory	Present value
D100	20
D101	50

The relationship between changes in the data types and how the controller treats the variables are given below.

Change description	Pattern 1	Pattern 2
No change	The variable value is retained.	
	ABC = 10	
	DEF = 20	
Changing the variable name	The variable value will be the initial va	lue.
from ABC to GHI	GHI = Initial value	
Changing the data type of the	The variable value will be the initial va	lue.
variable ABC from INT to DINT	ABC = Initial value	
Changing the Retain attribute	The variable value will be the initial va	lue.*1
of the variable ABC to Non- retain	ABC = Initial value	
Changing the AT specifica-	The variable value will be the value of	the AT specification.
tion of the variable DEF from D100 to D101	DEF = 50	
Deleting the AT specification	The variable value will be the initial va	lue.
of the variable DEF	DEF = Initial value	

^{*1} The variable value will be the initial value when the Retain attribute of the variable is changed from Nonretain to Retain.

• Changes in a Structure

Assume the structure before changes on the Sysmac Studio is defined as in below.

Data type name	Member	Data type of the member
STR_1	х	INT
	У	INT

Assume the data type of the variable ABC is STR_1, the Retain attribute is set to retain, and the members have the following present values.

Member	Present value
ABC.x	100
ABC.y	-200

The relationship between changes in the data types and how the controller treats the variables are given below.

If the condition applies both to retain and to change to the initial value, the variable value changes to the initial value.

Change description	Pattern 1	Pattern 2
No change	The member value is retained. ABC.x = 100 ABC.y = -200	
Changing the variable name from ABC to DEF	The member value will be the initial va DEF.x = Initial value DEF.y = Initial value	llue.
Changing the member x to x1	The member value is retained. ABC.x1 = 100 ABC.y = -200	The value of the changed member will be the initial value. ABC.x1 = Initial value ABC.y = -200
Changing the data type of the member x from INT to WORD*1 (Same data size)	The member value is retained. ABC.x = WORD#16#0064 (= 100) ABC.y = -200	
Changing the data type of the member y from INT to UINT*1 (Same data size. Changing from signed to unsigned)	The member value is retained. The absolute value and sign will change because the changed member is directly assigned. ABC.x = 100 ABC.y = 65336	
Changing the data type of the member y from INT to DINT*1 (Expanding data size)	The member value will be the initial value. ABC.x = Initial value ABC.y = Initial value	The member value is retained. The sign of the changed member is expanded while the absolute value and sign do not change. ABC.x = 100 ABC.y = -200
Changing the data type of the member y from INT to UDINT*1 (Expanding data size, and changing from signed to unsigned)	The member value will be the initial value. ABC.x = Initial value ABC.y = Initial value	The member value is retained. The sign of the changed member is expanded and the absolute value and sign change. ABC.x = 100 ABC.y = 4294967096

Change description	Pattern 1	Pattern 2
Changing the data type of the member y from INT to SINT*1 (Decreasing data size)	The member value will be the initial value. ABC.x = Initial value ABC.y = Initial value	The value of the member whose data size is decreased will be the initial value. ABC.x = 100 ABC.y = Initial value
Changing the member x to y and the member y to x	The member value is retained incorrectly. ABC.y = 100 ABC.x = -200	The member value is retained. ABC.y = -200 ABC.x = 100
Adding the member z of INT after the member y	The member value will be the initial value.* 2 ABC.x = Initial value ABC.y = Initial value ABC.z = Initial value	The value of the existing member is retained. The value of the added member will be the initial value. ABC.x = 100 ABC.y = -200 ABC.z = Initial value
Adding the member z of INT between the member x and the member y	The member value will be the initial value.* 2 ABC.x = Initial value ABC.z = Initial value ABC.y = Initial value	The value of the existing member is retained. The value of the added member will be the initial value. ABC.x = 100 ABC.z = Initial value ABC.y = -200
Changing the number of array elements for the member x from 1 to 3	The member value will be the initial value.* 2 ABC.x[0] = Initial value ABC.x[1] = Initial value ABC.x[2] = Initial value ABC.y = Initial value	The value of the existing member is retained. The value of the member whose number of array elements was changed will be retained from the top, and the value of the expanded member will be the initial value. ABC.x[0] = 100 ABC.x[1] = Initial value ABC.x[2] = Initial value ABC.y = -200

^{*1} Implicit casting applies for changes in data types. Refer to Implicit Casts on page 6-126 for details on implicit casting.

^{*2} You can retain the value of the existing member if you upload the variable value before downloading and then download the variable value after downloading.

Changes in a Union

Assume the union before changes on the Sysmac Studio is defined as in below.

Data type name	Member	Data type of the member
UNI_1	х	WORD
	у	DWORD

Assume the data type of the variable ABC is UNI_1, the Retain attribute is set to retain, and the members have the following present values.

Member	Present value
ABC	WORD#16#0100

The relationship between changes in the data types and how the controller treats the variables are given below.

If the condition applies both to retain and to change to the initial value, the variable value changes to the initial value.

Change description	Pattern 1	Pattern 2
No change	The member value is retained.	
	ABC = WORD#16#0100	
Changing the variable name from	The member value will be the initial value.	
ABC to DEF	DEF = Initial value	
Changing the data type of the	The member value is retained.	
member x from WORD to BYTE*1	ABC = WORD#16#0100	
(Same data size as union)		
Changing the data type of the	The member value will be the initial	The member value is retained.
member x from WORD to LWORD*1	value.	ABC = WORD#16#0100
	ABC = Initial value	
(Expanding data size as union)	The many beautiful and the initial of	
Changing the data type of the member y from DWORD to	The member value will be the initial value. ABC = Initial value	
BYTE*1	ABC - Illitial value	
(Decreasing data size as union)		
Changing the member x to y and	The member value is retained.	
the member y to x	ABC = WORD#16#0100	
Adding the member z of BYTE	The member value is retained.	
after the member y	ABC = WORD#16#0100	
(Same data size as union)		
Adding the member z of LWORD	The member value will be the initial value.	The member value is retained.
after the member y		ABC = WORD#16#0100
(Expanding data size as union)	ABC = Initial value	
Adding the member z of BYTE after the member y, and deleting	The member value will be the initial v	/alue.
the member y.	ABC = Initial value	
(Decreasing data size as union)		

^{*1} Implicit casting applies for changes in data types. Refer to *Implicit Casts* on page 6-126 for details on implicit casting.

Changes in Array Variables

Assume the array variables before changes on the Sysmac Studio are defined as in below.

Variable name	Data type
ABC	ARRAY[13] OF INT

Assume the Retain attribute of the variable ABC is set to retain, and the elements have the following present values.

Member	Present value
ABC[1]	100
ABC[2]	200
ABC[3]	300

The relationship between changes in the data types and how the controller treats the variables are given below.

If the condition applies both to retain and to change to the initial value, the variable value changes to the initial value.

Change description	Pattern 1	Pattern 2
No change	The element value is retained.	
	ABC[1] = 100	
	ABC[2] = 200	
	ABC[3] = 300	
Changing the variable name	The element value will be the initial va	lue.
from ABC to DEF	DEF[1] = Initial value	
	DEF[2] = Initial value	
	DEF[3] = Initial value	
Changing the data type of the	The element value will be the initial va	lue.
element from INT to UINT*1	ABC[1] = Initial value	
(Same data size)	ABC[2] = Initial value	
	ABC[3] = Initial value	
Changing the data type of the	The element value will be the initial value. ABC[1] = Initial value	
element from INT to DINT*1		
(Expanding data size)	ABC[2] = Initial value	
	ABC[3] = Initial value	
Changing the data type of the	The element value will be the initial value.	
element from INT to SINT*1	ABC[1] = Initial value	
(Decreasing data size)	ABC[2] = Initial value	
	ABC[3] = Initial value	
Changing the last number of the array element from 3 to 4^{*2}	The element value will be the initial value. ABC[1] = Initial value	The values of the existing element numbers are retained. The values of the new element numbers will be the
Expanding the number of	/LDG[1] Initial Value	initial values.
elements from 3 to 4)	ABC[3] = Initial value	ABC[1] = 100
	ABC[4] = Initial value	ABC[2] = 200
		ABC[3] = 300
		ABC[4] = Initial value

Change description	Pattern 1	Pattern 2
Changing the first number of the array element from 1 to 0*2 (Expanding the number of elements from 3 to 4)	The element value will be the initial value. ABC[0] = Initial value ABC[1] = Initial value ABC[2] = Initial value ABC[3] = Initial value	The values of the existing element numbers are retained. The values of the new element numbers will be the initial values. ABC[0] = Initial value ABC[1] = 100 ABC[2] = 200 ABC[3] = 300
Changing the last number of the array element from 3 to 2*2 (Decreasing the number of elements from 3 to 2)	The element value will be the initial value. ABC[1] = Initial value ABC[2] = Initial value	The values of the existing element numbers are retained. ABC[1] = 100 ABC[2] = 200
Changing the first number of the array element from 1 to 2*2 (Decreasing the number of elements from 3 to 2)	The element value will be the initial value. ABC[2] = Initial value ABC[3] = Initial value	The values of the existing element numbers are retained. ABC[2] = 200 ABC[3] = 300
Changing the first number of the array element from 1 to 3 and the last number from 3 to 5^{*2} (Same number of elements)	If the number of elements is the same, the values of the elements are retained from the top.*3 ABC[3] = 100 ABC[4] = 200 ABC[5] = 300	The values of the existing element numbers are retained. The values of the new element numbers will be the initial values. ABC[3] = 300 ABC[4] = Initial value ABC[5] = Initial value

^{*1} Implicit casting applies for changes in data types. Refer to *Implicit Casts* on page 6-126 for details on implicit casting.

• Changes in an Enumeration

Assume the enumeration before changes on the Sysmac Studio are defined as in below.

Data type name	Enumerator	Value
ENU_1	х	1
	у	2

Assume the data type of the variable ABC is ENU_1, the Retain attribute is set to retain, and the variable has the following present value.

Member	Present value
ABC	1 (= x)

The relationship between changes in the data types and how the controller treats the variables are given below.

^{*2} The result will be the same for basic and derivative data types.

^{*3} If the number of elements is expanded or decreased, all values of the elements will be the initial values.

Change description	Pattern 1	Pattern 2
No change	The variable value is retained.	
	ABC = 1 (= x)	
Changing the variable name	The variable value will be the initial value.	
from ABC to DEF	ABC = Initial value	
Adding the enumerator z The variable value is retained.		
whose value is 3 after the enumerator y	ABC = 1 (= x)	
Deleting the enumerator x	The variable value is retained even if t	he enumerator does not exist.
	ABC = 1	
Changing the value of the	The variable value is retained even aft	er the enumerator value is changed.
enumerator x from 1 to 5	ABC = 1	

6-3-10 Function Block Instances

Function block instances are added to and displayed in the local variable table as a data type.



Additional Information

A function block instance is treated as a local variable of the program in which the instance is created. As such, the instance is added to and displayed in the local variable table of the program. You cannot treat these instances as global variables.

6-3-11 **Monitoring Variable Values**

You can monitor the value of variables from a Watch Tab Page on the Sysmac Studio.

- Select Watch Tab Page from the View Menu. The Watch Tab Page is displayed.
- Establish an online connection with the Controller and register the variables in one of the following ways.
 - (1) Enter the variable in the name cell in the Watch Tab Page.
 - (2) Drag variables to the Watch Tab Page from an editor or variable table.

The present values of the variables are displayed.

6-3-12 Restrictions on Variable Names and Other Program-related Names

The following is a list of restrictions on program-related names.

Character Restrictions

Program-related name	Applicable characters	Reserved words	Multibyte character compatibil- ity	Case sensitiv- ity	Maximum size (not including NULL)	Charac- ter encoding
Variable name (including POU instance names)	Usable characters0 to 9, A to Z, and a to zSingle-byte kana	Refer to Reserved Words	Supported.	Not case sensitive.	127 bytes	UTF-8*
POU definition names	_ (underlines) Multibyte characters (e.g., Japanese)	below.				
Data type	Refer to Reserved Words below					
Structure member names and union member names	for a list of the reserved words. • Characters that cannot be used					
Enumerators	togetherA text string that starts with a					
Task names	number (0 to 9)				63 bytes	
Namespaces	Strings that start with "P_" A taxt string that starts in an				93 bytes	
Full paths of variable names	A text string that starts in an underline (_) character A text string that contains more than one underline (_) character A text string that ends in an underline (_) character				Network variable: 255 bytes Other: 511 bytes	
Device names	Any text string that consists of				127 bytes	
Section names	an identifier and has a prefix or postfix which contains more than one extended empty space			Case sensitive.		
Axis names	character (i.e., multi-byte			Not case		
Axes group names	spaces or any other empty Uni- code space characters)			sensitive.		
Cam table names	codo opudo onaradioroj					

^{*} For UTF-8, single-byte alphanumeric characters each use 1 byte. Multibyte characters each use more than 1 byte. Japanese characters require approximately 3 bytes.

Reserved Words

An error is detected during the program check for the following names.

- A name that is the same as any of the instructions that are described in *NJ/NX-series Instructions Reference Manual* (Cat. No. W502)
- A name that is the same as any of the instructions that are described in *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508)
- · Words that are reserved by the system

Names That Must Be Unique

The following names must be unique. An error is detected during the program check if they are not.

- · Global variable names in the same CPU Unit
- · Variable names in the same POU
- · Section names in the same POU
- · Member names in the same union or structure
- · Enumerators in the same enumeration
- · Local variable names and global variable names
- · POU names and data type names
- · Data type names and variable names
- Enumerators of an enumeration and enumerators of another enumeration
- · Enumerators and variable names

6-4 Constants (Literals)

This section describes constants in detail.

6-4-1 Constants

The value of a variable changes depending on the data that is assigned to that variable. The value of a constant never changes.

Unlike variables, constants are not stored in memory. You can use constants in the algorithm of a POU without the need to declare them.

In the NJ/NX-series Controllers, constants have a data type in the same way as variables,

6-4-2 Notation for Different Data Types

This section gives the notation for constants with different data types. A building error will occur if you use any other notation for a constant.

Boolean Data

"BOOL" is used as the data type name for Boolean data. You can use the following values: 1, 0, TRUE, and FALSE. The meanings of the notations are given in the following table.

Notation	Meaning
TRUE or FALSE	All of the following are equivalent: TRUE, BOOL#1,
BOOL#1 or BOOL#0	BOOL#TRUE, and 1.
BOOL#TRUE or BOOL#FALSE	All of the following are equivalent: FALSE, BOOL#0,
1 or 0*1	BOOL#FALSE, and 0.

^{*1} Sysmac Studio version 1.03 or higher is required to use 1 and 0. A building error will occur if you use 1 or 0 on Sysmac Studio version 1.02 or lower.

Bit Strings

You can use any of the following data type names for bit string data: BYTE, WORD, DWORD, and LWORD. You can use any of the following bases: 2, 8, 10, and 16. The notations and notation examples are given in the following table.

Notation	Notation example
{data_type_name}#{base}#{numeric_value}	WORD#16#0064
{base}#{numeric_value}*1	16#0064
{numeric_value}*1, *2	100

^{*1} Sysmac Studio version 1.03 or higher is required to omit the data type name. A building error will occur if you omit the data type name on Sysmac Studio version 1.02 or lower.

^{*2} A base of 10 (i.e., a decimal number) is assumed.



Version Information

Sysmac Studio Version 1.03 or higher is required to use base 10 for bit string data. A building error will occur if you use base 10 on Sysmac Studio version 1.02 or lower.

Integer Data

You can use any of the following data type names for integer data: SINT, USINT, INT, UINT, DINT, UDINT, LINT, and ULINT. You can use any of the following bases: 2, 8, 10, and 16.

The notations and notation examples are given in the following table.

Notation	Notation example
{data_type_name}#{base}#{numeric_value}	INT#10#–1
{base}#{numeric_value}*1	10#–1
{data_type_name}#{numeric_value}*2	INT#–1
{numeric_value}*1, *2	-1

Sysmac Studio version 1.03 or higher is required to omit the data type name. A building error will occur if you omit the data type name on Sysmac Studio version 1.02 or lower.

Real Numbers

You can use any of the following data type names for real number data: REAL and LREAL. You can use only base 10 for real number data. The notations and notation examples are given in the following table.

Notation	Notation example
{data_type_name}#{base}#{numeric_value}	LREAL#10#-3.14
{base}#{numeric_value}*1	10#–3.14
{data_type_name}#{numeric_value}*2	LREAL#-3.14
{numeric_value}*1, *2	-3.14

Sysmac Studio version 1.03 or higher is required to omit the data type name. A building error will occur if you omit the data type name on Sysmac Studio version 1.02 or lower.

Durations

You can use any of the following data type names for durations: TIME and T. The notations and notation examples are given in the following table.

Notation	Notation example
TIME#{day}d{hour}h{minutes}m{seconds}s{milliseconds}ms	TIME#61m5s
T#{day}d{hour}h{minutes}m{seconds}s{milliseconds}ms	T#61m5s

The following rules apply to duration data constants.

- It is not necessary to give all of the following: days, hours, minutes, seconds, and milliseconds. You must give at least one of them.
- You can use decimal points, such as in TIME#12d3.5h.
- You can give times that exceed the valid time ranges. For example, T#-61m5s expresses the same duration as T#-1h1m5s.
- All numeric values are interpreted as decimal values. A building error will occur if any number that is not a decimal number is used.
- You can change the order of the duration units. For example, T#1h2d expresses the same duration as T#2d1h.

^{*2} A base of 10 (i.e., a decimal number) is assumed.

^{*2} A base of 10 (i.e., a decimal number) is assumed.

Dates

You can use any of the following data type names for date data: DATE and D. The notations and notation examples are given in the following table.

Notation	Notation example
DATE#{year}-{month}-{day}	DATE#2010-1-10
D#{year}-{month}-{day}	D#2010-1-10

The following rules apply to date data constants.

- You can add one or more zeroes to the beginning of the year, month, or day. For example, DATE#2010-01-10 expresses the same date as D#2010-1-10.
- A building error will occur if a valid date range is exceeded. For example, *D#2010-01-35* causes an error.
- All numeric values are interpreted as decimal values. A building error will occur if any number that is not a decimal number is used.

Times of Day

You can use any of the following data type names for time of day data: TIME_OF_DAY and TOD. The notations and notation examples are given in the following table.

Notation	Notation example
TIME_OF_DAY#{hour}:{minutes}:{seconds}	TIME_OF_DAY#23:59:59.999999999
TOD#{hour}:{minutes}:{seconds}	TOD#23:59:59.99999999

The following rules apply to time of day data constants.

- You can add one or more zeroes to the beginning of the hour, minutes, or seconds. For example, *TOD#23:01:01* expresses the same time of day as *TOD#23:1:1*.
- A building error will occur if a valid time range is exceeded. For example, TOD#24:00:00 causes an
 error.
- All numeric values are interpreted as decimal values. A building error will occur if any number that is not a decimal number is used.

Dates and Times

You can use any of the following data type names for date and time data: DATE_AND_TIME and DT. The notations and notation examples are given in the following table.

Notation	Notation example
DATE_AND_TIME#{year}-{month}-{day}:{hour}:{minutes}:{seconds}	DATE_AND_TIME#2010-10-10-23:59:59.123
DT#{year}-{month}-{day}:{hour}:{minutes}:{seconds}	DT#2010-10-10-23:59:59.123

The following rules apply to date and time data constants.

- You can add one or more zeroes to the beginning of the year, month, day, hour, minutes, or seconds. For example, *DT#2010-01-10-23:01:01* expresses the same date and time as *DT#2010-1-10-23:1:1*.
- A building error will occur if a valid date and time range is exceeded. For example, *DT#2010-01-35-00:00:00* or *DT#2010-01-30-24:00:00* causes an error.
- All numeric values are interpreted as decimal values. A building error will occur if any number that is not a decimal number is used.

Text Strings

To give text string data, enclose the text string in single-byte single quotation marks ('). You can also use "STRING" as the data type name. The notations and notation examples are given in the following table.

Notation	Notation example
'{String}'	'This is a string'
STRING#'{String}'*1	STRING#'This is a string'

^{*1} Sysmac Studio version 1.08 or higher is required to use "STRING."

The following rules apply to text string data constants.

- You can also specify a string with 0 characters. To do so, the notation is ".
- · As in the following example, a building error will occur if you specify any strings that span across multiple lines.

strVar := 'ABC DEF'

• If you want to insert tabs, line break codes, or other special characters, you can use a dollar sign (\$) as an escape character before them. The escape character names and meanings are given in the following table.

Escape character	Name	Meaning
\$\$	Single-byte dollar sign	Single-byte dollar sign (\$: character code 0x24)
\$'	Single-byte single quotation mark	Single-byte single quotation mark (': character code 0x27)
\$"	Single-byte double quotation mark	Single-byte double quotation mark (": character code 0x22)
\$L or \$I	Line feed	Moves the cursor to the next line.
		LF control character (line feed: character code 0x0A)
\$N or \$n	New line	Moves the cursor to the next line.
		NL control character (new line: character code 0x0A)
\$P or \$p	Form feed	Moves the cursor to the next page.
		FF control character (form feed: character code 0x0C)
\$R or \$r	Carriage return	Moves the cursor to the start of the line.
		CR control character (carriage return: character code 0x0D)
\$T or \$t	Horizontal tab	Indicates a tab.
		Tab character (character code 0x09)
\$(character_code)	Direct character	Specify the character code with two hexadecimal digits. The
	code specification	range of the character codes is 00 to FF.
		For example, "\$L" is the same as "\$0A".
		For characters of two bytes or more, add \$ for each byte.

- You can also directly designate character codes. To do so, add \$ to the front of the character code. Give the character code with two hexadecimal digits. For example, the character code for a line break (\$L) is 0x0A, so \$0A is given.
- If you designate the character codes directly for characters of two bytes or more, add \$ for each byte.

Enumerated Data Types

For enumerated data, the enumeration data type name and enumerator are given. The notations and notation examples are given in the following table.

Notation	Notation example
{enumeration_data_type_name}#{enumerator}	_eDAYOFWEEK#_WED



Additional Information

To pass an enumerator to a function or function block for which the parameter specifies an enumerator, you can omit the enumeration data type name and give only the enumerator.

For example, the _eBCD_FORMAT enumeration is specified for the Format input variable in the BinToBCDs instruction. Therefore, you can give either the enumeration data type name and enumerator as _eBCD_FORMAT#_BCD0 or omit the enumeration data type name and give only _BCD0.

Programming Languages 6-5

This section describes the programming languages in detail. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details on entering programs with the Sysmac Studio.

6-5-1 **Programming Languages**

The languages used to express the algorithms in a POU (program, function, or function block) are called the programming languages.

There are two different programming languages that you can use for an NJ/NX-series Controller: ladder diagram language (LD) and ST (structured text) language.

6-5-2 Ladder Diagram Language


The ladder diagram language (LD) is a graphical programming language that is written in a form that appears similar to electrical circuits. Each object for processing, including functions and function blocks, is represented as a diagram. Those objects are connected together with lines to build the algorithm. Algorithms that are written in the ladder diagram language are called ladder diagrams.

General Structure of the Ladder Diagram Language

A ladder diagram consists of left and right bus bars, connecting lines, ladder diagram structure elements (e.g., inputs and outputs), functions, and function blocks.*

* Only Jump instructions and Label instructions are expressed with symbols that indicate the jumps and labels.

Algorithms are made of multiple rungs connected together. A rung is a connection of all configuration elements between the left bus bar and the right bus bar. A program rung consists of logic blocks that begin with an LD/LD NOT instruction that indicates a logical start.



Bus Bars

The vertical lines on the left and right sides of a ladder diagram are called the bus bars. These bus bars always have a status of either TRUE or FALSE. If you think of the ladder diagram as an electrical circuit, these states represent the flow of current through the circuit. When a POU that is written as a ladder diagram is executed, the value of the left bus bar changes to TRUE. As a result, all inputs and other configuration elements connected to the left bus bar also become TRUE. Execution progresses as elements to the right are also changed to TRUE based on the operation of these configuration elements. This cascade of the TRUE state is called the "power flow." The left bus bar is the source of this power flow.

Connecting line

The straight horizontal lines that connect the bus bar and the configuration elements are called connecting lines. Connecting lines can be either TRUE or FALSE and can transfer the power flow from the left to the right.

Inputs

Inputs are placed along the connecting line to receive the power flow and operate accordingly. There are several different types of inputs and, depending on their specifications, they will either transfer the power flow from the left to the right or prevent the power flow from passing through. When an input transfers the power flow to the right, the connecting line to the right of the input will become TRUE. If the power flow is inhibited, the connecting line to the right of the input will remain FLASE. For detailed specifications on inputs, refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502).

Output

Outputs are placed along the connecting line to receive the power flow and operate accordingly. An output writes the TRUE or FALSE value to a variable. There are different types of outputs. For detailed specifications on outputs, refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502).

Functions and Function Blocks

Functions and function blocks are placed along the connecting line to receive the power flow and operate accordingly. For detailed instruction specifications, refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502).

Order of Execution for Ladder Diagrams


Inputs, outputs, functions, and function blocks are executed when they receive the power flow. The order of execution for a ladder diagram is from top to bottom. Elements at the same level are executed from left to right.

Ladder Diagram Completion

A ladder diagram is executed in order from top to bottom. When the execution reaches the very bottom, the process is completed. However, the process will also end if an END or RETURN instruction is encountered at any point during the process. No processes after those instructions are executed.

Controlling Execution of Ladder Diagrams

Ladder diagrams are generally executed from top to bottom, but you can use execution control instructions to change the execution order. In the following example, when the value of program input a changes to TRUE, execution will move to the point labeled 'ExceptionProcessing.'



Connecting Functions and Function Blocks in a Ladder Diagram

Connection Configurations


You use the following two types of connections for functions or function blocks.

1) Power Flow Input and Output

In a ladder diagram, the line that connects an input variable of a function or function block and the left bus bar indicates a BOOL input and the line that connects an output variable to the right bus bar indicates a BOOL output.


Example:

Inputs are connected in the power flow that connects to the left bus bar. Outputs are connected in the power flow that connects to the right bus bar.



2) Parameter Inputs and Parameter Outputs

In a ladder diagram, parameter inputs and outputs are specified when the input and output variables of a function or function block are not connected to the left and right bus bars.




As shown below, you can specify either variables or constants for input and output parameters.

Function/function block variables	Input parameters	Output parameters
Input variables	You can specify variables or constants.	
Output variables		You can specify only variables.
In-out variables	You can specify only variables.	You can specify only variables.

Number of BOOL Variables


At least one BOOL variable each is required for the input and the output (such as EN and ENO) of a function or function block.

Example:




Connections Based on the BOOL Variable Positions


The top BOOL variables are connected to the left and right bus bars. In other words, they become the power flow input and power flow output.




There is only one power flow input and one power flow output for each function or function block. All other BOOL variables that are not at the top are for parameter inputs and parameter outputs.




You cannot connect multiple BOOL variables to the left bus bar or the right bus bar as shown below.



You do not have to connect an OUT instruction to the right bus bar. You can connect the function or function block directly.




A LD instruction is not necessarily required. You can also connect directly to the left bus bar.



Cascade Connections


Cascade connections in which the output of a function or function block is connected to the input of another function or function block are allowed only for power flow outputs and inputs.

Example:



You can branch the power flow output.


Example:



Restriction


• You cannot create closed loops or intersect connecting lines.

Example:



Reversing Inputs

You can reverse the value of a BOOL input variable when you input it to an instruction.




Inline ST

Introduction

FALSE→TRUE

Inline ST is a ladder diagram programming element in which you can write ST language code in a box called an inline ST box (a blank text input area) within a ladder diagram. This allows you to easily code numeric data processing and text string processing within ladder diagrams. The connecting line to an inline ST box becomes its execution condition. The ST code inside of the box is executed based on that connecting line. Refer to the following figure.



Inline ST is treated as a rung element in a ladder diagram. Therefore, unlike functions and function blocks, they have no input, output, or in-out variables.

Restrictions for Inline ST

You can write ST language code in inline ST boxes.

Execution Conditions for Inline ST

The execution conditions for inline ST are shown in the following table.

Status	Operation
TRUE execution condition	Operation follows the execution condition. You can use the execution condition at any point in the power flow (e.g., you can connect the inline ST directly to the left bus bar). To specify a change to TRUE or a change to FALSE, specify it for an input in the execution condition.
FALSE execution condition	Nothing is done.
Resetting in a master control region	Nothing is done.

Scope of Variables in Inline ST

The scope of variables that you can access from inline ST is the same as the POU of the ladder diagram that contains the inline ST.

Restrictions for Inline ST

Item	Description
Number of inline ST boxes per rung	1

6-5-3 Structured Text Language

The ST (structured text) language is a high-level language code for industrial controls (mainly PLCs) defined by the IEC 61131-3 standard. The standard control statements, operators, and functions make the ST language ideal for mathematical processing that is difficult to write in ladder diagrams. The features of ST are described below.


- Loop constructs and control constructs such as IF THEN ELSE are provided.
- You can write programs like high-level languages such as C, and you can include comments to make the program easy to read.

```
// Determine TableNo
 2
3
4
5
6
           FOR i:=0 TO ItemNum DO
   巨
   白
                IF (MinNo[i] <= ItemBox[i]) AND (ItemBox[i] <= MaxNo[i]) THEN</pre>
                     TableNo[i] := ItemBox[i];
RangeOK[i] := TRUE;
 8
 9
                ELSIF (ItemBox[i] > MaxNo[i]) THEN
                                                                                               // Upper
                     TableNo[i] := MaxNo[i];
RangeOK[i] := FALSE;
10
11
12
13
                                                                                               // Lower
                ELSE
14
                     TableNo[i] := MinNo[i]:
15
                     RangeOK[i] := FALSE;
16
17
                END_IF:
18
19
           END_FOR:
```

Structure of ST

ST code consists of one or more statements. One statement is the equivalent of one process. Statements are executed from top to bottom, one line at a time, until the process is completed. Statements are made up of keywords and expressions. A keyword is a symbol or string that expresses assignment or execution control. An expression is a code that calculates a value from variables, constants, function return values, and/or a combination of those, along with various operators. A statement represents a process that completes by itself. Expressions form a statement by using a combination of values and keywords.

Example of an Assignment Statement:



Example of an IF Construct:

ST Language Expressions

Statement Separators

- Statements must end with a single-byte semicolon (;). Statements are not considered complete with only a carriage return at the end. This allows you to write long statements across multiple lines.
- One statement must end with one single-byte semicolon (;). In the following example, the IF construct contains a single assignment statement. Each statement must be ended with a single-byte semicolon (;).

Comment

- You can write comments in your program to make the code easier to understand.
- Statements written as comments are not executed.

Comment notation Examples Remarks Enclose the comment in sin-(* Commenting out multiple lines This type of comment can span over gle-byte parenthesis and multiple lines. Comments cannot be IF ErrCode = 3 THEN asterisks, for example, nested. Value := 1000; "(*This is a comment*)". END IF; down to here. *) // Comment Begin the comment with two You can comment out only single forward slashes (//) and end $// A := SIN(X)^2;$ it with a carriage return.

· The two methods to insert comments are described below.

Spaces, Carriage Returns, and Tabs

- You can place any number of spaces, carriage returns, and tabs in your code at any location. This allows you to add spaces or tabs before statements and carriage returns between operators/keywords and expressions in order to make your code easier to read.
- Always enter a token separator, such as a space, carriage return, or tab, between operators/keywords and variables.

Example: The square boxes indicate where you must insert a token separator, such as a space, carriage return, or tab.

```
IF ■ A>0 ■ THEN ■ X:=10;
ELSE ■
X:=0:
END_IF;
```

Lowercase/Uppercase, Single-byte/double-byte Characters

- · Operators, keywords, and variable names are not case sensitive.
- Operators, keywords, and variable names must always be in single-byte characters. A syntax error will occur if you input double-byte characters.

Variables and Prohibited Characters

Refer to 6-3-12 Restrictions on Variable Names and Other Program-related Names for restrictions on variable names.

Text Strings

Refer to 6-3-12 Restrictions on Variable Names and Other Program-related Names for restrictions on text strings.

ST Keywords and Operators

Statement Keywords

Keyword	Meaning	Example
:=	Assignment	d := 10;
Calling	Calling functions and	FBname(para1 := 10, para2 := 20);
	function blocks	Refer to Function Block Calls on page 6-120.
RETURN	Return	
IF	If	IF d < e THEN f := 1;
		ELSIF d = e THEN f :=2;
		ELSE f := 3;
		END_IF;


Keyword	Meaning	Example
CASE	Case	CASE f OF
		1: g :=11;
		2: g :=12;
		ELSE g :=0;
		END_CASE;
FOR	For	FOR i: = 100 TO 1 BY -1 DO
		Val[i] := i;
		END_FOR;
WHILE	While	WHILE Val < MaxVal DO
		Val := Val + 1;
		END_WHILE;
REPEAT	Repeat	REPEAT
		Val := Val + 1;
		UNTIL(Val > 4)
		END_REPEAT;
EXIT	Exit the loop.	FOR i := 1 TO 100 DO
		FOR j := 1 TO 10 DO
		IF Val[i, j]>100 THEN EXIT;
		END_IF;
		END_FOR;
		END_FOR;
;	Empty statement	Val[i] := i
		; (* Empty statement *)
		WHILE(Var <>0) DO
		; (* Empty statement *)
		END_WHILE;
(* Text *)	Comments	(* Commenting out multiple lines
		IF MyFun (ErrorCode) = 3
		THEN ReturnValue := GetDetail();
		END_IF;
		down to here. *)
//Text	Comment	A := SIN(X) ^ 2 + COS (Y) ^2 + 10;
		// A := SIN(X) ^ 2 + COS (Y) ^2 + 5;

Operators

The following table gives the operators and their order of priority.

If operators with different priorities are mixed in one expression, the operators with the highest priorities are executed first. You can use up to 64 operators in one expression.

Example: X:=(1+2)-3*4; In this case, variable X is assigned a value of -9.



Operation Operator		Notation example and evaluated value	Priority		
Parentheses	ntheses () (1+2)*(3+4)		1		
		Value: 21			
Function/function		FUN1(FUN2(Var2A, Var2B), Var1B)	2		
block call		When function and function block calls are nested, the function or function block at the lower level is called first. In the above example, FUN2 is executed first, and then FUN is executed.			
Sign +, - +100		+100	3		
		-100			
NOT	NOT	NOT TRUE			
		Value: FALSE			
Exponent	**	-2**2	4		
		Value: 4			
		A minus sign is given priority over an exponent operator. Therefore, -2**2 in the above example is the same as (-2)**2, so the value is 4.			
		2**3**2			
		Value: 64			
		If there is more than one exponent operator, calculations are performed for them left to right. Therefore, 2**3**2 in the above example is the same as (2**3)**2, so the value is 64.			
Multiplication	*	100*200	5		
•		Value: 20,000			
Division	/	100/200	-		
		Value: 0.5			
Remainder	MOD	10 MOD 7	-		
		Value: 3			
		-17 MOD 6			
		Value: -5			
		-17 MOD (-6)			
		Value: -5			
		17 MOD 6			
		Value: 5			
		17 MOD (-6)			
		Value: 5			

Operation	Operator	Notation example and evaluated value	Priority
Addition	+ 100+200		
		Value: 300	
Subtraction	-	100-200	
		Value: -100	
Comparison	<, >, <=, >=	100<200	7
		If the comparison result is TRUE, the value is set to TRUE. Otherwise, the value is set to FALSE. In the above example, 100 is less than 200, so the value is TRUE.	
Matches	=	100=200	8
		If the two values match, the value is set to TRUE. Otherwise, the value is set to FALSE. In the above example, 100 does not equal 200, so the value is FALSE.	
Does not match	<>	100<>200	-
		If the two values do not match, the value is set to TRUE. Otherwise, the value is set to FALSE. In the above example, 100 does not equal 200, so the value is TRUE.	
Logical AND	AND,&	Applies 1-bit AND logic to all bits.	9
		The results of 1-bit AND logic are as follows:	
		0 AND 0 = 0	
		0 AND 1 = 0	
		1 AND 0 = 0	
		1 AND 1 = 1	
		0101 AND 1100	
		Value: 0100	
Logical exclusive	XOR	Applies 1-bit exclusive OR logic to all bits.	10
OR	XOIX	The results of 1-bit exclusive OR logic are as follows:	
		0 XOR 0 = 0	
		0 XOR 1 = 1	
		1 XOR 0 = 1	
		1 XOR 1 = 0	
		0101 XOR 1100	
		Value: 1001	
Logical OR	OR	Applies 1-bit OR logic to all bits.	11
		The results of 1-bit OR logic are as follows:	
		0 OR 0 = 0	
		0 OR 1 = 1	
		1 OR 0 = 1	
		1 OR 1 = 1	
		0101 OR 1100	
		Value: 1101	



Precautions for Correct Use

The intended operation may not occur if a function is nested under itself. Always separate the functions into different statements as shown below.

Example of incorrect notation: out := MyFunc(In1:=x1, In2:=MyFunc(In1:=x2, In2:=x3));

Example of correct notation: tmp := MyFunc(In1:=x2, In2:=x3);

out := MyFunc(In1:=x1, In2:=tmp);



Precautions for Correct Use

The order of priority for operators is sometimes different for different standards and manufacturers. Special attention is necessary for the priority of exponent operators. We therefore recommend that you use parentheses to ensure that calculations are performed in the intended order.

For $X:= -2^{**}3^{**}4$; we recommend that you use the following expression: $X:=((-2)^{**}3)^{**}4;$



Additional Information

Calculations are performed based on the data types. For example, the result of calculations with integer data will be integer data. Therefore, if the expression A/B is calculated with INT variables A = 3 and B = 2, the result would not be 1.5 because all values after the decimal point are truncated. In this case, the expression (A/B)*2 would evaluate to 2 instead of 3.

Data Types for Operator Operands

If all the operands for an operator have the same data type, any data type given as "Supported" in the following table can be set as operands. However, if an operand with a different data type is set for the operator, an implicit cast is required. Refer to Implicit Casts on page 6-126 for details on implicit casting.

Data type	Assign- ment operator	Argu- ment setting operator	Numeric opera- tors	Modulo- division operator	Power operator	Comparison operators	Equality operators	Logic opera- tors	Posi- tive/neg- ative signs
		:= ^	+ - * /	MOD	**	v	# 	NOT AND & OR XOR	+ -
Boolean	OK	OK					OK	OK	
Bit string	OK	OK					OK	OK	
Integer	OK	OK	OK	OK	OK*1	OK	OK		OK
Real number	OK	OK	OK		OK	OK	OK		OK
Duration	OK	OK							OK
Date	OK	OK							
Time of day	OK	OK							
Date and time	OK	OK							
Text string	OK	OK				*2	*2		
Enumeration	OK	OK					OK		
Structure par- ent	OK	OK							
Array parent	OK	OK							

OK: Possible

^{---:} A building error will occur.

^{*1} If you select the version 1.15 or earlier in the Select Device Area of the Project Properties Dialog Box on the Sysmac Studio for an NX701 CPU Unit and NJ-series CPU Unit, integer variables are calculated as real number variables even if they set as operands. If a rounding error is included in the result of calculations, the result may not be an intended value because all values after the decimal point are truncated. Use the EXPT and TO ** (Integer Conversion Group) instructions together to round values after the decimal point. Example: TO_INT(EXPT(X,Y))

^{*2} Do not use operators to compare text string variables. Use instructions (such as EQascii) instead.

ST Language Statements

Assignment

Overview:

This statement assigns the right side (i.e., the value of the expression) to the left side (i.e., the variable).

Reserved Words:

:=

Combination of a colon (:) and an equals sign (=)

Statement Structure:

```
<variable>:=<expression>;
<variable>:=<variable>;
<variable>:=<constant>;
```

Application:

Use this statement to assign a value to a variable. For example, use it to set initial values or to store the results of a calculation.

Description:

This statement assigns (or stores) the <expression value> to the <variable>.

Example:

Example 1: The following statement assigns the result of the expression X+1 to variable A.

```
A:=X+1;
```

Example 2: The following statement assigns the value of variable B to variable A.

```
A:=B;
```

Example 3: The following statement assigns a value of 10 to variable A.

```
A:=10;
```

Precautions:

- Either the source data type must match the destination data type, or the combination of data types must allow implicit casting. A building error will occur if you do not use this notation.
- If the value that is assigned is STRING data, make the size of the destination STRING variable larger than that of the source string. Otherwise, an error will occur.
- For STRING variables, assignment is allowed if the size of left-hand variable is greater than the size of the text string stored in right-hand variable.
 Example:

Assignment is allowed in the following case.

· Variable Table:

Variable name	Data type	Size
Var1	STRING	10
Var2	STRING	20

· User Program:

Var2 :='ABC';

```
Var1 := Var2;
```

You cannot make assignments to union variables. You must make the assignments to individual members of the unions.

RETURN

Overview:

The following actions occur depending on where the ST statement is used.

The ST program is ended during operation and the next program is executed.

ST in a Function Inside a Function Block Instance

The function or function block is ended during operation and the next instruction after the calling instruction is executed.

Inline ST

The POU that contains inline ST with a RETURN statement is ended.

Reserved Words:

RETURN

Statement Structure:

RETURN;

Application:

Use this statement to force the current program, function, or function block to end.

IF with One Condition

Overview:

The construct executes the specified statement when a condition is met. If the condition is not met, another statement is executed. The following expressions are used to specify whether the condition is met.

TRUE: The condition is met.

FALSE: The condition is not met.

Reserved Words:


IF, THEN, (ELSE), END IF

Note You can omit ELSE.

Construct Structure:

```
IF <condition_expression> THEN
 <statement_1>;
ELSE
 <statement_2>;
END_IF;
```

Process Flow Diagram:



Application:

Use this construct to perform one of two processes depending on evaluation of a condition (condition expression).

Description:

If <condition_expression> is TRUE, <statement_1> is executed.


If <condition_expression> is FALSE, <statement_2> is executed.

Precautions:

- IF must always be used together with END_IF.
- Write a statement that evaluates to TRUE or FALSE (for example IF A>10) or a BOOL variable (for example IF A) for the condition expression.
- You can write <statement_1> and <statement_2> on multiple lines. Separate statements with a semicolon (;).

Example: Another IF Statement before < statement 1>

Process Flow Diagram:




ELSE corresponds to the previous THEN statement, as shown above.

• You can execute more than one statement for both <statement_1> and <statement_2>. Separate statements with a semicolon (;).

• You can omit the ELSE statement. If it is omitted, nothing is executed when <condition expression> is FALSE.

Process Flow Diagram:



Example:

Example 1: A value of 10 is assigned to variable X when the statement A > 0 is TRUE. A value of 0 is assigned to variable X when the statement A > 0 is FALSE.

```
IF A>0 THEN
   X:=10;
ELSE
   X:=0:
END_IF;
```

Example 2: A value of 10 is assigned to variable X and a value of 20 is assigned to variable Y when the statements A > 0 and B > 1 are both TRUE. A value of 0 is assigned to variable X and variable Y when the statements A > 0 and B > 1 are both FALSE.

```
IF A>0 AND B>1 THEN
   X:=10;Y:=20;
ELSE
   X:=0;Y:=0;
END IF;
```

A value of 10 is assigned to variable X when the BOOL variable A is TRUE. A value of 0 is assigned to variable X when variable A is FALSE.

```
IF A THEN X:=10;
ELSE X:=0;
END IF;
```

IF with Multiple Conditions

Overview:

The construct executes the specified statement when a condition is met. If a condition is not met but another condition is met, another statement is executed. If neither condition is met, another statement is executed.

The following expressions are used to specify whether the condition is met.

TRUE: The condition is met. FALSE: The condition is not met.


Reserved Words:

IF, THEN, ELSIF, (ELSE), END_IF

Note You can omit ELSE.

Construct Structure:

Process Flow Diagram:



Application:

Use this construct to perform a process depending on evaluation of multiple conditions (condition expressions).

Description:

```
If <condition_expression_1> is TRUE, <statement_1> is executed.
```

- If <condition_expression_1> is FALSE and <condition_expression_2> is TRUE, then <statement 2> is executed.
- If <condition expression 2> is FALSE and <condition expression 3> is TRUE, then <statement_3> is executed.

If <condition_expression_n> is TRUE, <statement_n> is executed.

If none of the conditions is TRUE, < statement_m> is executed.

Precautions:

- IF must always be used together with END_IF.
- Write statements that can be TRUE or FALSE for the condition expressions. Example: IF(A>10) You can also specify BOOL variables (including functions that return a BOOL value) for the condition expressions instead of an actual expression. In that case, when the variable is TRUE, the evaluated result is TRUE and when the variable is FALSE, evaluated result is FALSE.
- You can write any of the statements on multiple lines. Separate statements with a semicolon (;).
- You can omit the ELSE statement. If it is omitted, and none of the conditions produces a match, nothing is done.

Example:

A value of 10 is assigned to variable X when the statement A > 0 is TRUE.

A value of 1 is assigned to variable X when the statement A > 0 is FALSE and statement B = 1 is TRUE.

A value of 2 is assigned to variable X when the statement A > 0 is FALSE and statement B = 2 is TRUE.

If none of the conditions is TRUE, a value of 0 is assigned to the variable X.

```
IF A>0 THEN X:=10;
   ELSIF B=1 THEN X:=1;
   ELSIF B=2 THEN X:=2;
ELSE X:=0;
END IF;
```

• CASE

Overview:


This construct executes a statement that corresponds to an integer set value that matches the value of an integer expression.

Reserved Words:

CASE

Construct Structure:

Process Flow Diagram:



Application:

Use this construct to perform different actions based on the value of an integer.

Description:

If <integer expression> matches <integer expression value n>, <statement n> is executed. If <integer_expression> does not match any of the integer values, <statement_m> is executed.

Precautions:

- CASE must always be used together with END_CASE.
- Use one of the following for the <integer_expression>:
 - An integer or enumeration variable (example: abc)
 - An integer expression (example abc+def)
 - A function that returns an integer value (example: xyz())
- You can write any of the statements on multiple lines. Separate statements with a semicolon (;).
- To specify OR logic of multiple integers for <integer expression value n>, separate the values with commas. To specify a continuous range of integers, separate the start integer and the end integer with two periods (..).

You can specify a condition for a specific integer value, or the same condition for Example 1: multiple integer values.

```
CASE A OF
              A value of 1 is assigned to variable X when variable A is 1.
   1: X:=1;
             A value of 2 is assigned to variable X when variable A is 2.
   2: X:=2;
                -----
   3: X:=3:
                                  A value of 3 is assigned to variable X when variable A is 3.
FLSE
              -----
                                   If none of the values is matched, a value of 0 is assigned to
   X:=0;
                                   the variable X.
END_CASE;
CASE A OF
                        ---- A value of 1 is assigned to variable X when variable A is 1.
   1: X:=1;
   2,5: X:=2; A value of 1 is assigned to variable X when variable A is 2 or 5.
   6..10: X:=3; ----- A value of 3 is assigned to variable X when variable A is between 6 and 10.
   11,12,15..20: X:=4; ------ A value of 4 is assigned to variable X when variable A is 11, 12,
                                   or between 15 and 20.
ELSE
   X:=0:
              -----
                                   If none of the values is matched, a value of 0 is assigned to the
END_CASE;
                                   variable X.
```

You can give an integer variable, integer expression, integer function return value, Example 2: enumeration variable, or enumeration function return value for the <integer_expression>. An example is shown below.

• Example for an Integer Enumeration Variable

```
CASE ColorVar OF
   RED:
      X := 0;
   BLUE:
      X := 1;
   ELSE
      X := 2:
END CASE;
```

• Example for an Integer Expression

```
CASE (a1 + a2) OF
0:
    X := 0;
1:
    X := 1;
ELSE
    X := 2;
END_CASE;
```

• Example of an Integer Enumeration Function Return Value

Data Types That You Can Use in CASE Constructs

Classification	Data	type	<integer_expression></integer_expression>
	Integers		Supported.
Basic data types	Boolean, bit string, re of day, date and time,	al, duration, date, time or text string data	Not supported.
Data type specifica-		Arrays	Not supported.
tions	Array specifications	Elements	Supported for integers and enumerations only.
			Not supported.
Derivative data types Unions	Structures	Members	Supported for integers and enumerations only.
		Unions	Not supported.
	Unions	Members	Supported for integers and enumerations only.
	Enumerations		Supported.

FOR

Overview:

This construct repeatedly executes the same statements until a variable (called the FOR variable) changes from one value to another value.

The following expressions are used to specify whether the condition is met.

TRUE: The condition is met.

FALSE: The condition is not met.

Reserved Words:


FOR, TO, (BY), DO, END_FOR

Note You can omit BY.

Construct Structure:

```
FOR <FOR_variable>:= <initial_value> TO <end_value> BY <increment/decrement> DO <statement>;
END_FOR;
```

Process Flow Diagram:



Application:

Use this construct when you know in advance how many times you want to repeat a process.

This type of repeat construct is particularly effective to specify each element of an array variable based on the value of a FOR variable.

Description:

A decision is made based on the evaluation of <initial_value>, <end_value>, and <increment/decre-

When <FOR_variable> is <initial_value>, <statement> is executed.

After execution, the value of <increment/decrement> is added to <FOR variable> and <statement> is executed again if <FOR_variable> is less than the value of the <end_value>.

After execution, the value of <increment/decrement> is added to <FOR variable> and <statement> is executed again if <FOR variable> is less than the value of the <end value>.

This process is repeated.


The loop ends when <FOR_variable> > <end_value>.

If <increment/decrement> is negative, the directions of the comparison symbols in the above statements are reversed.

Precautions:

- If the FOR variable is signed, <increment/decrement> can be a negative number.
- FOR must always be used together with END FOR.
- The FOR variable becomes the end value plus increment/decrement after execution of the process is completed for the end value. This ends the FOR construct.

Example: When the FOR construct is completed in the following ST statements, the value of *i* is 101.



• Do not write code that directly modifies the FOR variable inside the FOR construct. Unintended operation may result.

Example:

```
FOR i:=0 TO 100 BY 1 DO
X[i]:=0;
i:=i+INT#5;
END_FOR;
```

- You can write any of the statements on multiple lines. Separate statements with a semicolon (;).
- You can omit BY<increment/decrement>. If it is omitted, the statement is executed with an increment value of 1.
- You can specify an integer (SINT, INT, DINT, LINT, USINT, UINT, UDINT, or ULINT) variable or integer value for the <initial_value>,<end_value>, and <increment/decrement>. You can also specify a function that returns an integer value.
 - Example 1: A value of 100 is assigned to array variable elements *SP[n]*. The FOR variable is variable n, the initial value is 0, the end value is 50, and the increment is 5.

```
FOR n := 0 TO 50 BY 5 DO

SP[n] := 100;

END_FOR;
```

Example 2: The total of elements *DATA[1]* through *DATA[50]* of array variable elements *DATA[n]* is calculated and the result is assigned to the variable *SUM*.

```
IF a THEN
    FOR n := 0 TO 50 BY 1 DO
        DATA[n]:= 1;
    END_FOR;

FOR n := 0 TO 50 BY 1 DO
        SUM:= SUM + DATA[n];
    END_FOR;

a:=FALSE;
END_IF;
```

Example 3: The maximum and minimum values of elements *DATA[1]* through *DATA[50]* of array variable elements *DATA[n]* are found. The maximum value is assigned to the *MAX variable*, and the minimum value is to the *MIN variable*. The value of *DATA[n]* is from 0 to 1,000.

```
MAX :=0;

MIN :=1000;

FOR n :=1 TO 50 BY 1 DO

IF DATA[n] > MAX THEN

MAX :=DATA[n];

END_IF;

IF DATA[n] < MAX THEN

MIN :=DATA[n];

END_IF;

END_FOR;
```

- If the total execution time of the statements in the FOR construct from when the FOR variable is incremented/decremented from the initial value until it reaches the end value exceeds the task period, a Task Period Exceeded error occurs.
 - When the FOR Variable Cannot Logically Reach the End Value

Example:

```
FOR i := 0 TO 100 BY 1 DO
   intArray[i] := i;
   i := INT#50;
                                   ----- An infinite loop occurs and results in a Task
END_FOR;
                                               Period Exceeded error.
```

Example:

```
FOR i := 0 TO 100 BY 0 DO
                                  ----- An infinite loop occurs and results in a Task
                                              Period Exceeded error.
END FOR:
```

· When an Overflow or Underflow Occurs Because the FOR Variable Exceeds the End Value Example:

```
FOR i := 0 TO 254 BY 2 DO
   INTArray[i] := i;
END_FOR;
```



Version Information

With the Sysmac Studio version 1.08 or higher, you can specify arithmetic expressions for <end value> and <increment/decrement>.

However, the evaluation is performed for <end value> or <increment/decrement> only before the execution of FOR loop operation. The values of <end value> and <increment/decrement> do not change after the FOR loop operation is started.

For example, in the following case, the value of <end value> is 10 and <increment/decrement> is 3. Even after the FOR loop operation is started and the values of variable A and C are changed, the value of <end_value> is still 10 and <increment/decrement> is still 3.

```
A := INT#1;
B := INT#2;
C := INT#10;
FOR i := 0 TO C BY A+B DO
   INTArray[i] := i;
   A := B + i;
   C := C + i;
END_FOR;
```

If an arithmetic expressions is specified for <end value> or <increment/decrement> on the Sysmac Studio version 1.07 or lower, a building error will occur.

Data Types That You Can Use in FOR Constructs

Classification	Data type		<pre><for_variable>, <initial_value>, <end_value>, and <increment decrement="">*1</increment></end_value></initial_value></for_variable></pre>
Basic data types	Boolean, bit string, real, duration, date, time of day, date and time, or text string data		Not supported.
	Integers		Supported.
Data tura anasifica		Arrays	Not supported.
Data type specifica- tions	Array specifications Elements	Elements	Supported for integers and enumerations only.*2
		Structures	Not supported.
Derivative data types	Structures	Members	Supported for integers and enumerations only.*2
	Unions	Unions	Not supported.
	Official	Members	Not supported.
	Enumerations		Supported.*2

^{*1} You must use the same data type for the <FOR_variable>, <end_value> and <increment/decrement>. Otherwise, an error occurs when the program is built on the Sysmac Studio.

WHILE

Overview:

This construct repeatedly executes the specified statements as long as a condition expression is TRUE.


Reserved Words:

WHILE, DO, END_WHILE

Construct Structure:

WHILE <condition_expression> DO <statement>; END_WHILE;

Process Flow Diagram:



^{*2} You cannot use enumerations for <FOR_variable>, <end_value> and <increment/decrement>.

Application:

Use this type of repeat construct when you do not know how many times to repeat a process (i.e., when you do not know how many times based on the condition) and you want to repeat a process for as long as a certain condition is met. You can also use this type of repeat construct to execute a process only when a condition expression is TRUE (pre-evaluation repeat construct).

Description:

The <condition_expression> is evaluated before <statement> is executed.

If <condition expression> is TRUE, <statement> is executed. Then the <condition expression> is evaluated again. This process is repeated.

If the <condition expression> is FALSE, <statement> is not executed and the <condition expression> is no longer evaluated.

Precautions:

- WHILE must always be used together with END_WHILE.
- If the <condition expression> is FALSE before <statement> is executed, the WHILE construct is exited and <statement> is not executed.
- You can write <statement 1> and <statement 2> on multiple lines. Separate statements with a semicolon (;).
- You can execute more than one statement for <statement>. Separate statements with a semicolon (;).
- You can also specify a BOOL variable (including functions that return a BOOL value) for the condition expressions instead of an actual expression.

Example:

Example 1: The first multiple of 7 that exceeds 1,000 is calculated and assigned to variable A.

```
A := 0:
WHILE A <= 1000 DO
   A := A+INT#7;
END WHILE;
```

Example 2: The value of variable X is doubled if X is less than 3,000 and the value is assigned to array variable element DATA[1]. Next, the value of X is doubled again and the value is assigned to the array variable element DATA[2]. This process is repeated.

```
n := 1;
X := 1;
WHILE X < 3000 DO
   X:= X*INT#10#2;
   DATA[n]:= X;
   n := n+INT#1:
END WHILE;
```

 If you do not write correct condition expressions, the program execution time increases and may cause a Task Period Exceeded error.

Example:

```
boolVar := TRUE;
WHILE boolVar DO
intVar := intVar + INT#1;
END WHILE;
```

REPEAT

The following expressions are used to specify whether the condition is met.

TRUE: The condition is met. FALSE: The condition is not met.

Overview:

This construct repeatedly executes one or more statements until a condition expression is TRUE.


Reserved Words:

REPEAT, UNTIL, END_ REPEAT

Construct Structure:

```
REPEAT
<statement>;
UNTIL <condition_expression>
END_REPEAT;
```

Process Flow Diagram:



Application:

Use this type of repeat construct when you do not know how many times to repeat a process (i.e., when you do not know how many times based on the condition) and you want to repeat a process for as long as a certain condition is met after processing. Use this type of repeat construct to determine repeat execution based on the result of the execution of a process (post-evaluation repeat construct).

Description:

First, <statement> is executed unconditionally. Then the <condition expression> is evaluated.

If <condition_expression> is FALSE, <statement> is executed.

If <condition_expression> is TRUE, <statement> is not executed and the REPEAT construct is exited.

Precautions:

- · REPEAT must always be used together with END REPEAT.
- Even if the <condition_expression> is TRUE before <statement> is executed, <statement> is executed.
 - In other words, < statement> is always executed at least one time.
- <statement> can contain multiple lines of code for the statement. Separate statements with a semicolon (;).
- You can also specify a BOOL variable (including functions that return a BOOL value) for the condition expressions instead of an actual expression.

Example:

Example 1: Numbers from 1 to 10 are added and the values are assigned to the variable TOTAL.

```
A := 1;
TOTAL := 0;
REPEAT
   TOTAL := TOTAL + A;
   A := A+INT#1;
UNTIL A>10
END_REPEAT;
```

• If you do not write correct condition expressions, the program execution time increases and may cause a Task Period Exceeded error.

Example:

```
intVar := INT#1;
REPEAT
intVar := intVar + INT#1;
UNTIL intVar = INT#0
END_REPEAT;
```

EXIT

Overview:

Use this statement only inside a repeat construct (FOR construct, WHILE construct, or REPEAT construct) to exit the repeat construct.

Use this statement inside an IF construct to exit from the repeat construct when a condition is met.

Reserved Words:

EXIT

Construct Structure (e.g., in an IF Construct):

Application:

Use EXIT to end a repeating process before the end condition is met.

Description (e.g., in an IF Construct):

If the <condition_expression> is TRUE, the repeat construct (FOR construct, WHILE construct, or REPEAT construct) is ended and all code inside the repeat construct after the EXIT statement is ignored.

- Note 1 You can also specify a BOOL variable instead of an expression for the condition expressions.
 - 2 Even if the <condition_expression> is TRUE before <statement> is executed, <statement> is executed.

Example:

Variable n is repeatedly incremented by 1 from 1 to 50 while the value of n is added to array variable elements *DATA[n]*. However, if *DATA[n]* exceeds 100, the repeat construct is exited.

```
IF A THEN
    DATA[3] :=98;
    FOR n := 1; TO 50 BY 1 DO
        DATA[n] := DATA[n] + n;
    IF DATA[n] > 100 THEN EXIT;
    END_IF;
    END_FOR;
    A :=FALSE;
END_IF;
```

Function Block Calls

Overview:

This statement calls a function block.

Reserved Words: None

Statement Structure:

Give the argument specifications (to pass the values of the specified variables to the input variables of the called function block) and the return value specification (to specify the variable that will receive the value of the output variable of the called function block) in parenthesis after the instance name of the function block. There are two methods of writing this statement, as shown in (1) and (2) below. We recommend method 1 for program readability.

Notation Method 1:

Give both the variable names of the called function block and the parameter names of the calling POU.

ABC(A:=x1, B:=x2, C=>y1);

ABC: Function block instance name


A and B: Input or in-out variable names of called function block

x1 and x2: Input or in-out parameter of calling POU (can be a constant)

C: Output variable of called function block

y1: Output parameter of calling POU

· Ladder Diagram Expression



- · You can give the arguments and return values in any order.
- You can omit the input variable names and input parameter names. If you omit these names, the values assigned to the input variables for the previous call are assigned to the input variables again. If this is the first time that the function block is called, the input variables are set to their initial values.
- · You can omit the output variables and output parameters. If they are omitted, the value of the output variable is not assigned to anything.

Notation Method 2:

Omit the variable names of the called function block and give the parameter names of the calling POU.

ABC(x1, x2, y1);

ABC: Function block instance name


A and B: Omitted. (Input or in-out variable of called function block)

x1 and *x2*: Input or in-out parameter of calling POU (can be a constant)

C: Omitted. (Output variable of called function block or constant)

y1: Output parameter of calling POU

• Ladder Diagram Expression



• The order of parameters is based on the function block definition. The order is the same as the local variable definition for the function block, from top to bottom.

Application:

This statement calls a function block.

Example

· Programming

Notation 1

ChangeFixToFloat(Execute:=Exe,Data32_1:=FixPointData1, Data32_2:=FixPointData2,

NoOfDigit_1:=FixPointPos1,

NoOfDigit_2:=FixPointPos2,OK=>Done,Double_1=>RealData1,


Double_2=>RealData2);

Notation 2

ChangeFixToFloat(Exe, FixPointData1, FixPointData2, FixPointPos1, FixPointPos2,

Done, RealData1, RealData2);

· Ladder Diagram Expression



• Function Block Definition

Function block name: ConvData32ToDouble

Function Block Variables

I/O	Variable name	Data type
Input variables	Execute	BOOL
	Data32_1	DINT
	Data32_2	DINT
	NoOfDigit_1	INT
	NoOfDigit_2	INT
Output variables	OK	BOOL
	Double_1	LREAL
	Double_2	LREAL

• Program Variables

Variable name	Data type	Comments
ChangeFixToFloat	ConvData32ToDouble	Convert from fixed-point to floating-point.
Exe	BOOL	Execution trigger
FixPointData1	DINT	Decimal point position specification data 1
FixPointPos1	INT	Number of digits below deci- mal point 1
FixPointData2	DINT	Decimal point position specification data 2
FixPointPos2	INT	Number of digits below decimal point 2
Done	BOOL	Normal end
RealData1	LREAL	Floating-point data 1
RealData2	LREAL	Floating-point data 2

Omitting Parameters

When you call a function block, you can omit parameters that are not required. The following table shows when you can omit parameters.

POU type Variables for the called POU		Notation pa		
		Parameters included	Examples	Omission
FB	Given (nota-	All parameters given	instance(x:=a,y:=b,z:=c);	OK
	tion method 1)	More than one parameter given	instance(x:=a,y:=b);	
		One parameter given	instance(y:=b);]
		No parameters given	instance(x:=);	
	Given (nota-	All parameters given	instance(a,b,c);	OK
	tion method 2)	All parameters not given	instance();]
		Only the first parameter given	instance(a);	
		One parameter given	instance(a, ,);	
		More than one parameter given	instance(a,b);]

OK: Possible (initial used), ---: A building error will occur.

Function Calls

Overview:

This statement calls a function.

Reserved Words: None

Statement Structure:


Give the output parameter to which the return value is assigned on the left side of the assignment keyword (:=). On the right side, give the argument specifications (to pass the values of the specified variables to the input variables of the called function) inside the parenthesis after the function name. There are two methods of writing this statement, as shown in (1) and (2) below.

Notation Method 1:

IF (x0=TRUE) THEN
 y1 := MyFUN(A:=x1, B:=x2, C=>y2);
END_IF;

We recommend method (1) for program readability.

· Ladder Diagram Expression



MyFUN: Function name

x0: Specifies whether to call the function.

A and B: Input variable names of the called function

x1 and x2: Input parameters of the called function

C: Output variable name of the called function

y1: Storage location for the return value from the called function

y2: Output parameters of the called function


- You can give the arguments in any order.
- You can omit the input variable names and input parameter names. If they are omitted, the input variables are assigned their initial values.
- You can omit EN as well. If it is omitted, EN is assigned a value of TRUE.

Notation Method 2:

Omit the variable names of the called function and give the parameter names of the calling POU.

IF
$$(x0=TRUE)$$
 THEN
$$y1 := MyFUN(x1, x2, y2);$$
END IF;

· Ladder Diagram Expression



MyFUN: Function name

x0: Specifies whether to call the function.

A and B: Input variable names of the called function

x1 and x2: Input parameters of the called function

C: Output variable name of the called function

y1: Storage location for the return value from the called function

y2: Output parameters of the called function

• The order of parameters is based on the function definition. The order is the same as the local variable definition for the function, from top to bottom.

Example:


- · Programming
- · Notation 1

ConvData32ToDouble(Data32_1:=FixPointData1,Data32_2:=FixPointData2, NoOfDigit_1:=FixPointPos1, NoOfDigit_2:=FixPointPos2, Double 1=>RealData1, Double 2=>RealData2);

Notation 2

ConvData32ToDouble(FixPointData1, FixPointData2, FixPointPos1, FixPointPos2, RealData1, RealData2);

· Ladder Diagram Expression



Function Definition

Function name: ConvData32ToDouble

Function Variables

I/O	Variable name	Data type
Input variables	Execute	BOOL
	Data32_1	DINT
	Data32_2	DINT
	NoOfDigit_1	INT
	NoOfDigit_2	INT
Output variables	Double_1	LREAL
	Double_2	LREAL
Return value		BOOL

• Program Variables

Variable name	Data type	Comment
ChangeFixToFloat	ConvData32ToDouble	Convert from fixed-point to floating-point.
Exe	BOOL	Execution trigger
FixPointData1	DINT	Decimal point position specification data 1
FixPointPos1	INT	Number of digits below deci- mal point 1
FixPointData2	DINT	Decimal point position specification data 2
FixPointPos2	INT	Number of digits below deci- mal point 2
Done	BOOL	Normal end
RealData	LREAL	Floating-point data 1
RealData	LREAL	Floating-point data 2

Application:

This statement calls a function.

Omitting Parameters

When you call a function, you can omit parameters that are not required. The following table shows when you can omit parameters.

	Variables for	Notation pattern		
POU type the called POU		Parameters included	Example	Omis- sion
FUN	Given (nota-	All parameters given	FUN(x:=a,y:=b,z:=c);	OK
	tion method 1)	More than one parameter given	FUN(x:=a,y:=b);	
		One parameter given	FUN(y:=b);	
		No parameters given	FUN(x:=);	
	Given (nota-	All parameters given	FUN(a,b,c)	OK
	tion method 2)	No parameters given	FUN();	
		Only the first parameter given	FUN(a);	
		One parameter given	FUN(a, ,);	
		More than one parameter given	FUN(a,b);	

OK: Possible (initial used), ---: A building error will occur.

Precautions for the ST Language

Observe the following precautions when you use the ST language in the user program.

Implicit Casts

If the data types of the operands do not match, as shown below, the data types are converted automatically according to the implicit cast rules. If the implicit cast rules are not satisfied, a building error occurs.

(1) When the data types of the operands in the expression on the right side of the assignment statement are not the same

Example:

$$A: = INT#10 + SINT#2;$$

(2) When the data types of the operands on the right and left sides of the assignment statement are not the same

Example:

(3) When the data types of the operands in statement are not the same Example:

INT LINT CASE A+B OF INT#1:

def:=INT#10;

The casting rules are described for the following three cases.

Casting Rules When the Right-hand Side of an Assignment Statement Is an **Arithmetic Expression**

- For the right-hand operand, you can use any combination of the data types that are supported for the operator operand.
- Of the operands on the right side, the operand with the highest rank is considered the data type of the entire side. (Refer to the Data Type Ranking Table given below for the data type ranks.)

Data Type Ranking Table:


The higher the rank, the larger the range of numerical values that the data type can express.

Rank	Data type
1	SINT
2	USINT
3	INT
4	UINT
5	DINT
6	UDINT
7	LINT
8	ULINT
9	REAL
10	LREAL
11	BYTE
12	WORD
13	DWORD

Rank	Data type
14	LWORD

Casting Rules When You Assign the Right-hand Value to the Left-hand Side

In the following chart, a cast is performed if an arrow connects the data type of the source to the data type of the assignment destination. Any combination that is not connected will cause a building error.



When you assign the value, the sign and absolute value of the number do not change.

When you assign the value, the sign and absolute value of the number may change.

Example: intVar := -1; (* intVar := 16#FFFF *)

uintVar := 1;

uintVar := intVar; (* uintVar:= 16#FFFF, or −1 was assigned but the result is 65535 *)

Even if the arrow does not connect directly to a data type, you can still perform assignments for the data types. For example, SINT->USINT->UDINT->ULINT are all connected, so you can write an assignment such as ULINT:=SINT.



Precautions for Correct Use

Observe the following precautions when casting UDINT to ULINT data, DINT to LINT data, or DINT to LREAL data.

All of these are casts from 32-bit data to 64-bit data. If the result of the calculation of the right side of the assignment statement exceeds the range of 32-bit data, the correct value may not be assigned.

Example: For the following assignment statements, the result of the addition in the third statement exceeds the range of 32-bit data. An overflow will result and 0 will be assigned to *LintVar*.

UdintVar := UDINT#16#FFFF_FFFF; // Upper limit of 32-bit data

DintVar := DINT#1; // 1

LintVar := (UdintVar + DintVar)/DINT#2; // (Upper limit of 32-bit data + 1)/2

In a case like this one, convert the data to 64-bit data before you perform the calculation. To do this for the above example, change the assignment status as shown below.

LintTmp1 := UDINT_TO_LINT(UDINT#16#FFFF_FFFF); //Convert UDINT to LINT data.

LintTmp2 := DINT_TO_LINT(DINT#1); // Convert DINT to LINT data.

LintVar := (LintTmp1 + LintTmp2) / DINT#2;

Casting Rules in Expressions in Statements

The implicit cast rules for right-hand arithmetic expressions in assignment statements and for assigning the value of the right-hand side to the left-hand side also apply to expressions in statements.

Example:

```
CASE (A+B+C) OF
  Result1:
     to
  ResultN:
     to
END CASE;
```

Order of Execution of Functions

The order of execution of functions is not defined for functions in expressions. The order of execution of functions depends on the unit version of the CPU Unit, the version of the Sysmac Studio, and the notation. Precaution is required in cases where the results of an expression may depend on the order of execution of the functions, such as in the following cases.

- Expressions that contain more than one function that access the same global variable
- Expressions that contain a function and a variable whose value is changed by that function

Expressions That Contain More Than One Function That Access the Same Global Variable

In the following example, the order of execution of the three functions is not necessarily the same as the order of execution of the calculations, which is determined by the priority of the operators. Therefore, it is possible that the functions are executed in the following order: FUN2, FUN3, and then FUN1.

```
result := FUN1() + FUN2() * FUN3();
```

If all three of the functions in the above expression access and write the same global variable, the value of the result variable may change depending on the order of execution of the functions.

To ensure that the three functions are always executed in the same order, the expression is broken up. The following notation is used to execute the functions in the following order: FUN2, FUN3, and then FUN1.

```
tmp2 := FUN2();
tmp3 := FUN3();
result := FUN1() + tmp2 * tmp3;
```

Expressions That Contain a Function and a Variable Whose Value Is Changed by That Function

The following expression contains a function and a variable whose value is changed by that function.

```
result := varA + FUN4(out => varA);
```

In the above expression, the first element on the right side, variable varA, is not necessarily evaluated before FUN4 is executed. Therefore, the value of the result variable may change depending on the order of varA evaluation and FUN4 execution.

To ensure that varA evaluation and FUN4 execution always occur in the same order, the expression is broken up. The following notation is used to evaluate varA first and then execute FUN4.

```
tmp := varA;
result := tmp + FUN4(out => varA);
```

The following notation is used to execute FUN4 first and then evaluate varA.

```
tmp := FUN4(out => varA);
result := varA + tmp;
```

Calculation Precision of Expressions with Constants without Data Type Specifications


The calculation precision of an expression that contains a constant without a data type specification is automatically determined by the data types of the variables and constants that are given in the expression and destination.

Notation of Constants

If a constant is given without a decimal point, such as 100, it is processed as an integer. If a constant is given with a decimal point, such as 100.0, it is processed as a real number.

Expression Calculation Precision

The calculation precision of an expression is either 32-bit integer, 64-bit integer, or long real precision depending of the data types of the variables and constants given in the expression and destination. The following rules apply to the calculation precision of an expression.



Example: realv := 2 + 3 * 4; // The data type of the realv variable is REAL.

The realv variable is a real number, so the calculation is performed with long real precision. The calculation result is 14.0.

realv := 2 + 3.0 * 4; // The data type of the *realv* variable is REAL.

The 3.0 constant and the realv variable are real numbers, so the calculation is performed with long real precision. The calculation result is 14.0.

lintv := 2 + 3 * 4; // The data type of the *lintv* variable is LINT.

There is no constant or variable that is a real number, but the lintv variable exceeds 32 bits, so the calculation is performed with 64-bit integer precision. The calculation result is 14.

intv := 2 + 3 * 4; // The data type of the *intv* variable is INT.

There is no constant or variable that is a real number and there is no constant that exceeds 32 bits, so the calculation is performed with 32-bit integer precision. The calculation result is 14.

However, the calculation precision of division is determined only by the divisor and dividend. The rules for determining the calculation precision are the same as those in the previous flowchart.

Example: realv := 2 / 3 * 4; // The data type of the *realv* variable is REAL.

Dividing 2 by 3 does not include an integer that exceeds 32 bits for the divisor or dividend, so the calculation is performed with 32-bit integer precision. The calculation result is 0.

In the next step, the realv variable is a real number, so the calculation of 0 * 4 is performed with long real precision. The calculation result is 0.0.



Precautions for Correct Use

The calculation precision of an expression that contains a constant without a data type specification is automatically determined by the notation of the constant and the data types of the variables that are given in the expression. Therefore, calculations may be performed with unintended precision. We recommend that you specify the data type for real numbers, such as REAL#1.0.

Differences between ST and Ladder Diagrams

The differences between ST and ladder diagrams are described below.

Item	Ladder diagram	ST (including inline ST)
Input differ-	Change to TRUE	Change to TRUE
entiation		Method 1
	• Method 1	R_TRIG_instance (Clk:=start, Q=>do);
	start do ↑	* R_TRIG_instance is an instance of the
		R_TRIG instruction.
	• Method 2	
	R_TRIG_instance	
	R_TRIG	
	start Clk Q do	
	start Clk Q -do	
	Method 3	
	Up	
	start In do	
	Statt	
	Change to FALSE	Change to FALSE
	Method 1	Method 1
	start do	F_TRIG_instance (Clk:=start, Q=>do);
	\doldright\ri	* F_TRIG_instance is an instance of the F_TRIG instruction.
	Method 2	1 _ Trice instruction.
	F_TRIG_instance	
	F_TRIG	
	start Clk Q do	
	Method 3	
	Down	
	start In do	
Instruction	Upward Differentiation	Upward Differentiation
differentia-		There is no equivalent in ST. You must create it
tion	start @Inst	in logic.
		Example:
		Method 1
		R_TRIG_instance (Clk:=start, Q=>do);
		IF (do = TRUE) THEN Inst();
		END_IF;
		Method 2
		IF (start = TRUE) THEN
		<pre>IF (pre_start = FALSE) THEN Inst();</pre>
		END_IF;
		END_IF;
		pre_start:=start;// Update previous value.

Item	Ladder diagram	ST (including inline ST)
Instructions that last multiple task periods	With the TON instruction, multiple cycles are required from the start of instruction execution to the end and the instruction is reset when the power flow is FALSE. Therefore, you need to declare only one instance to both execute the instruction and reset it. TON_instance start TON In Q PT ET	You must declare two instances, one for execution and one to reset, as shown below. IF (start = TRUE) THEN TON_instance(In:=TRUE, omitted); // Start timer. ELSE TON_instance(In:=FALSE, omitted); // Reset timer. END_IF;
Func- tion/function block argu- ment rever- sal specifica- tions	Add a circle to indicate reversal at the intersection of the BOOL argument and the function/function block. emergency	Add a NOT operator to the argument. * You can add NOT operators to any BOOL variable, not just arguments. IF (NOT emergency) THEN Func(); END_IF;
Multi-stage connections	start Func1 EN ENO tmp Func2 EN ENO in	IF(start=TRUE) THEN Func2(in := Func1()); END_IF;
Post-con- necting lad- der instructions	You can connect only other Out instructions after an Out instruction.	You cannot continue the ladder diagram after inline ST. NG str :='ABC';
Program divisions	You can create sections.	You cannot create sections.


6-6 Instructions

This section describes the instructions that are pre-defined by the NJ/NX-series Controller.

For details on these instructions, refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) and *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

6-6-1 Instructions

Instructions are the smallest unit of the processing elements that are provided by OMRON for use in POU algorithms. Instructions are classified as shown below.



Programs, user-defined functions, and user-defined function blocks consist of these instructions.

6-6-2 Basic Understanding of Instructions

The fundamental specifications of the instructions follow the specifications of functions and function blocks.

This section describes specifications that are unique to instructions.

Ladder Diagram Structure Elements (Inputs and Outputs)


Locations

Instructions for ladder diagram inputs and outputs have certain positions where they can be placed, as shown below.

Classification		Locations	Diagram	
Input instructions	Logical start	Connected directly to the left bus bar or is at the beginning of an instruction block.		
	Intermediate instructions	Between a logical start and the output instruction.		
Output instructions		Connected directly to the right bus bar.		

Instruction Options

Some ladder diagram instructions for inputs also detect changes to TRUE or changes to FALSE if you add an upward arrow or downward arrow to them.



Function Block Instructions

Execution Conditions

The operation of the execution condition for an FB instruction depends on the instruction.

A specific input variable for the execution condition is defined for each instruction.

Execute specifies a change to TRUE or a change to FALSE in the execution condition.

Enable causes the instruction to be executed each task period according to the current execution condition.

Function block instructions are unconditionally executed for as long as the POU that called them is executed.

Instruction Options

Instruction options cannot be specified.

FUN Instructions

Execution Conditions

All FUN instructions have *EN* inputs as execution conditions. The FUN instruction is executed each task period as long as *EN* is TRUE.


Instruction Options

In a ladder diagram, you can add the following instruction options to specify a change to TRUE or a change to FALSE as the execution condition for that instruction. ST statements do not have options.

Instruction Options		Symbol	
Differentiation option	Change to TRUE	@	This option creates an upwardly differentiated instruction. The instruction is executed only once when <i>EN</i> changes to TRUE.

To add an instruction option, add one of the option symbols listed in the table above before the instruction.

Example:



Information That Applies to Both FB Instructions and FUN Instructions

Condition Flags

System-defined variables that are assigned values that represent the result of instruction processing are called Condition Flags. The only Condition Flag for an NJ/NX-series Controller is the Carry Flag (P_CY).

The Carry Flag serves the following purposes.

- It shows whether the result of processing an instruction exceeds the range that can be expressed by the data type of the output variable.
- It shows whether an overflow occurred in a bit shift instruction for bit string data. For details, refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502).

Instruction Errors 6-6-3

Instruction errors refer to the errors that occur when an instruction is executed. This section describes when an instruction error occurs, which error is detected as an instruction error, and what operation follow an instruction error, etc.

Timing When Instruction Errors Occur

The timing when instruction errors occur can be divided into the following three cases. Detectable errors and operations following to the errors differ by the timing when instruction errors occur.

- When the values of input parameters or in-out parameters are checked before instruction execution.
- When internal processing is performed during instruction execution.
- · When the values of output parameters are checked after instruction execution.

Errors Detected As Instruction Errors

The followings are the errors detected as instruction errors. Different errors are detected depending on the timing when instruction errors occur.

Errors detected before or after instruction execution

The followings are the errors detected before or after instruction execution.

- Reading or writing an array variable from or to an element beyond the array range.
- Assigning a string that is longer than the defined byte length to a STRING variable.
- Assigning a string that does not end with a NULL character to a STRING variable.
- Dividing an integer variable by 0.

Errors detected during instruction execution

Errors detected during instruction execution differ by instruction. For details on errors detected in each instruction, refer to the NJ/NX-series Instructions Reference Manual (Cat. No. W502).

Operation for Instruction Errors

The operation for the following elements differ depending on whether an instruction error occurs or not: output variable ENO, output variable Error, output variable ErrorID, system-defined variable P_PRGER, and events. The details on the operations are described below.

Output variable ENO, output variable Error, and output variable ErrorID

ENO (enable out), Error, and ErrorID (error code) are the output variables that indicate whether an error exists or not. Each instruction has different output variables. The meaning of each variable and its value on an instruction error are shown below. The values vary by the timing when an instruction error occurs.

			Value when	an instruction	error occurs
Output variable	Data type	Meaning	Before instruction execution*1	During instruction execution	After instruction execution*2
ENO	BOOL	TRUE : Normal end	FALSE	FALSE	TRUE
		FALSE: Error end, Execution in progress, or Not executed			
Error	BOOL	TRUE : Error End	FALSE	TRUE	FALSE
		FALSE: Normal end, Execution in progress, or Not executed			
ErrorID	WORD	Error code on Error end, and	WORD#16#0	Error code	WORD#16#0
		WORD#16#0 on Normal end			

^{*1} If an instruction error occurs before execution of an instruction, the instruction will not be executed. Therefore, the value of each output parameter before instruction execution will be retained.

System-defined variable P_PRGER

The system-defined variable P_PRGER is a flag that indicates the occurrence of an instruction error. If an instruction error occurs, the value will change to TRUE regardless of when the error occurred. When the instruction ends normally, the value will be retained.

For the details on P_PRGER, refer to *Instruction Error Flag* on page 6-140.

Events

When an instruction error occurs, an event is created for it. For details on events, refer to *Events for Instruction Errors* on page 6-141.



Version Information

A CPU Unit with unit version 1.02 is required to create events for instruction errors.

^{*2} If an instruction error occurs after execution of an instruction, the instruction itself will be regarded as normally ended. Therefore, the values of output variables of the instruction will be assigned to the output parameters. Values of the output parameter to which an error occurred are retained as the one before the instruction execution.

Output Parameters in Ladder Diagrams

The following table shows the values of output parameters when an instruction, user-defined function, or user-defined function block that is created in a ladder diagram ends normally or has an instruction error.

Condition	Type of output parameter	Value of output parameter
Normal end	Power flow output	Values are updated according to the
	BOOL parameter output	internal algorithm.
	Parameter output other than BOOL	
Instruction error	Power flow output	Set to FALSE.
	BOOL parameter output	The previous values are retained.
	Parameter output other than BOOL	

Operation When a Syntax Error Occurs in a POU Written in ST

Errors in Assignment Statements

When an error occurs in an assignment statement written in ST, that line is not executed.

This operation is the same as when the output ENO of a user-created function is FALSE.

```
5 a = User-created_function_block (b) + c;
6 x := 1;

When the ENO output from the user-created function is FALSE, execution of line 5 is cancelled (the value of a is not changed) and line 6 is executed.
```

• Errors in IF Constructs

If a syntax error occurs in ST, perform error processing for the syntax error. When the value of (c+d), below, is zero, the lines between the IF and END_IF are not executed.

```
POU"AA"
              5 IF a = b / (c + d) THEN
                   x := 1;
                 ELSE
              7
              8
                   x := 2
                 END_IF;
              9
             10 y := 10;
                                                                               The user must include a safety
                                                                               processing for possible errors.
                  IF P PRGER = TRUE THEN
                    x:= initial_value; (*Processing when an error occurs*)
                    y:= initial_value;
                  END_IF;
```

Syntax Errors in ST

The following syntax errors can occur in ST.

- Exceeding the number of elements in an array.
- No parameter set for in-out variable.
- STRING assignment: When the text string size (bytes) of the left side is less than the text string length (bytes) of the right side
- Division by zero (excluding floating-point number calculations)
- * When the value of a floating-point number is nonnumeric, the result of the calculation will also be nonnumeric. This is not considered an error.

Operation for Structure Errors

The P PRGER Flag changes TRUE and the following occurs.

Syntax	Error location	Operation
Assignment		The line is not executed.
statement		

Syntax	Error location	Operation
	IF condition expression	No statements between IF and END_IF are executed.
		No statements between CASE and END_CASE are executed.
Control con- structs	FOR condition expression	No statements between FOR and END_FOR are executed.
	WHILE condition expression	No statements between WHILE and END_WHILE are executed.
	REPEAT condition expression	No statements between REPEAT and END_REPEAT are executed.


Instruction Error Flag

When an instruction error occurs in a ladder algorithm or when a syntax/function error occurs in an ST algorithm, the P_PRGER (Instruction Error Flag) system-defined variable changes to TRUE. The P_PRGER flag is a local variable for the program. This flag changes to TRUE when an instruction error occurs in the program, and remains TRUE during the next task period.

Variable name	Meaning	Function	Data type	Range of values	Initial value	Read /writ e
P_PRGER	Instruction Error Flag	This flag changes to and remains TRUE when an instruction error occurs. After this flag changes to TRUE, it stays TRUE until the program changes it back to FALSE.	BOOL	TRUE or FALSE	FALSE	Read /write


The user can write the P_PRGER Flag. You can temporarily set the value of this flag to FALSE through a user operation to determine if the error occurs within a specific range, for example. After this flag changes to TRUE, it remains TRUE until the operating mode is changed or the flag is overwritten by a program.

Example:



The P PRGER Flag also changes to TRUE when an instruction error occurs inside a user-defined function block that is used by the program.

Example:



Events for Instruction Errors

When an instruction error occurs, an event is created for it. Refer to 8-7 Event Logs for the procedure to check events. For information on the events that are created, refer to the NJ/NX-series Instructions Reference Manual (Cat. No. W502).



Precautions for Correct Use

- To create events for instruction errors, you must select Use for Event Log Settings Instruction Error Output on the Sysmac Studio. Refer to 4-2-2 Controller Setup and to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504-E1-04 or later) for information on the Controller Setup.
- If you change the user program after an instruction error occurs, the information in the event log may no longer be correct.
- If an instruction with an error is executed repeatedly, an instruction error or event is created each time the instruction is executed. This may cause the event log to exceed the maximum number of events. If this occurs, older events are overwritten.



Version Information

- A CPU Unit with unit version 1.02 is required to create events for instruction errors.
- A CPU Unit with unit version 1.02 or later and Sysmac Studio version 1.03 or higher are required to specify whether to output instruction errors when they occur.



Additional Information

- If an error occurs in a motion control instruction, two events are created, one for the instruction
 error and one for the motion control instruction. For details on events for motion control
 instructions, refer to the NJ/NX-series Motion Control Instructions Reference Manual (Cat. No.
 W508).
- Events for motion control instruction are created even if you select Do not use for Event Log Settings – Instruction Error Output in the Controller Setup on the Sysmac Studio.

Namespaces 6-7

This section provides the specifications for namespaces and the procedures to use them. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the procedures to manipulate them.



Version Information

A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required to use namespaces.

6-7-1 Namespaces


Namespaces are a system for grouping function block definitions and other entities to manage them in nested structures. They are similar to grouping files in folders to manage them in a directory structure. If you do not use namespaces, the name of each function block definition or other entity must be unique. If you use namespaces, you can use the same name more than once by setting namespaces. Using namespaces is not required.

Features of Namespaces

Namespaces provide the following features.

Preventing Duplicated Names

As long as different namespaces are used, you can use the same name for a function block or other entity more than once. For example, assume that several systems must be programmed, and that a different programmer will program each of them. Here, it would be likely that the same names would be used for different function block definitions or other entities. If you did not use namespaces, you would have to create naming rules to prevent the duplication of names. However, if you set a different namespace for each system, programming would be possible without worrying about duplicating names with other systems.



6-7-2 Namespace Specifications

This section describes what namespaces can be used for, namespace notation, and namespace declarations.

Namespace Usage

You can use namespaces for the entities that are listed in the following table. You cannot use them for local variables.

Library object	Details	
POU definitions	Function definition names and function block definition names	
Data types	Structure data type names, union data type names, and enumeration data type names	

Namespace Notation

Separate the levels in a namespace with backslashes (\). To use a namespace in a POU algorithm, place two backslashes (\\) at the front of the namespace.

Examples:

Location of namespace	Expression
Outside of an algorithm	System_A\Read_recipe
Inside of an algorithm	\\System_A\Read_recipe

Fully Qualified Names and Short Names

The fully qualified name of an entity is the name that includes the name of the namespace. The short name of an entity is the name that does not include the name of the namespace.

In the algorithm in a POU definition, you can use the short name of any POU definition that has the same namespace as the POU definition of the algorithm.

Example:

System_A\Read_recipe
Name of Short name
namespace
Fully qualified name

Restrictions on Namespace Notation


- You can use the same characters as you can for variable names. For details, refer to 6-3-12 Restrictions on Variable Names and Other Program-related Names.
- The following table gives the limits to the number of characters in the names of namespaces.

Name	Maximum size	Character encoding
Names of name-	93 bytes	UTF-8
spaces		
Short names	127 bytes	




Precautions for Correct Use

An error will occur when you build the program if the short name of a variable is also used in the name of the namespace.




You can use the short name of a POU definition in the algorithm of a POU definition if it is in the same namespace. However, an error will occur when you build the program if there is a POU definition or data type with the same short name at a higher level in that namespace. For example, assume that the following POU definitions are used. You can use the short name to call System A\Read recipe\Process A from within the algorithm of the Process B function block definition (which is in the System A\Read recipe namespace) because Process A is in the same namespace.



If, however, a System A POU definition also exists at a higher level than the System_A\Read_recipe namespace, "Process_A" exists twice. Therefore, an error will occur when you build the program.

In this case, you must use the fully qualified name or change the short name.



If any names are the same as a reserved word, an error will occur when you check the program.

Namespace Declarations

To program with namespaces, you can declare the namespaces in advance before you use them in the algorithm of a POU definition.

After you declare the namespace in the POU definition, you can use the short name of any POU definition or other entity that has the same namespace. You can also use the fully qualified name even if you declare the namespace.

In the algorithm in a POU definition, you can use the short name of any function definition or function block definition that has the same namespace as the POU definition of the algorithm even if you do not declare the namespace.

You can declare more than one namespace for the same POU definition.

Notation Examples

Notation examples are provided below for creating a function block definition when declaring the namespaces to use in the function block definition and when not declaring the namespaces.

Examples:

In this example, the <code>Read_recipe</code> and <code>Calculate_upper_limit</code> function block definitions are used in the algorithm for the <code>Lifter</code> function block definition. Each of these function block definitions is in a different namespace. In the <code>Lifter</code> function block definition, only the <code>System_C</code> namespace is declared. The fully qualified name must be given for the <code>Read_recipe</code> function block, which is not in the <code>System_C</code> namespace. The short name can be given for the <code>Calculate_upper_limit</code> function block, which is in the <code>System_C</code> namespace.


Namespace	Entity	Short name
System_A	Function block definition	Lifter
System_B	Function block definition	Read_recipe
System_C	Function block definition	Calculate_upper_limit

declaration for the *Lifter* function block definition.


System_C

Notation for the Algorithm of the Lifter Function Block


The following notation is used in the namespace



When Namespace Is Not Declared
 The System_B namespace of the Read_recipe function
 block definition is not declared, so you must give the fully
 qualified name.



When Namespace Is Declared
 The System_C namespace of the Calculate_upper_limit function block definition is declared, so you can give the short name.



Restrictions of Declarations

• You can use short names only in the algorithm of a POU definition.



Precautions for Correct Use

- · An error is detected during the program check in the following cases.
 - · If a namespace that does not exist is declared
 - If you declare more than one namespace for one POU definition, and a POU definition, data type, or other entity with the same name exists in two or more namespaces
- · An error will occur when you build the program if the same name is used as follows for different POU definitions or data types.
 - If the same name is used for the namespace of a POU definition and at a higher level in the namespace
 - If the same name is used in a declared namespace
 - If the same name is used without a namespace

Namespace	Entity	Short name	
System_A\Lifter	Function block definition	Process_A	Not allowed.
System_A	Function block definition	Process_A	Not allowed.
System_B	Function block definition	Process_B	
		Process_A	Not allowed.
None	Function block definition	Process A	Not

The name is used in the namespace of the POU definition. The name is used at a higher level than the namespace of the POU definition.

The name is used in a declared namespace.

The name is used without a namespace.

The following notation is used in the namespace declaration for the *Process_A* function block definition. System_B



Additional Information

You cannot set a namespace for a program name. However, you can declare namespaces for objects that are used in the algorithm of the program.

6-7-3 **Procedure for Using Namespaces**

Use the Sysmac Studio to set the namespaces and then declare them. Perform steps 1 and 2 when you create data types or when you create function definitions, function block definitions, or other objects. Declare a namespace with step 3 to use an object for which a namespace is set.

- In the Data Type Editor, set the namespace for the data type.
- Set the namespace in the properties of the function definition or function block definition.
- In the Ladder Editor or ST Editor, declare the namespace in the properties of the function definition or function block definition.
- Use the data types, function definitions, and function block definitions in the user program.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504-E1-03 or later) for specific procedures.

6-8 Libraries

This section describes the specifications of libraries. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504-E1-03 or later) for specific procedures.



Version Information


A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required to use libraries.

6-8-1 Introduction to Libraries

A library contains POU definitions and data types in a form that allows you to reuse them as objects in programming. The objects in a library are called library objects.

The NJ/NX-series CPU Units allow you to create and use libraries.

The following figure illustrates the use of library objects. Here, program A uses FUN:A1 and FB:B1 from the objects in the library, and program B uses Type:C1 and FB:B1.



6-8-2 **Specifications of Libraries**

This section describes the library settings and synchronization.

Library Settings

The following settings are supported for libraries.

Setting	Description
Name	The name of the library.
Version	The version of the library.
Author	The creator of the library. (optional)
Creation date	The date that the library was created.
Update date	The date that the library was last updated.
Comment	A comment on the library. (optional)
Company name	The name of the company that created the library. (optional)
ID	A unique ID that is used to access the library. The ID is generated automatically. You cannot change it.
Display/hide source	You can specify whether to display or hide the source.*
Attached files	You can attach one or more files.

^{*} If data protection is set for a library object, a password is required to display the source code.

You can also access other libraries to create library objects. When you do, you can select whether to include the library data from the accessed library.



Additional Information

When you select to include accessed library data, the accessing library is created so that it contains a copy of the accessed library data. This means that only one library file is required. However, if there is more than one accessing library, you must change each one of them to make any changes. When you select not to include accessed library data, the accessing library is created without the accessed library data. This means that there will be two library files, the accessing file and the accessed file. However, even if there is more than one accessing library, you need to change only the accessed library to make changes.

Selecting Library Objects

You can select the objects to include in a library.

Library Synchronization

You can download a library to a Controller, upload a library from a Controller, or verify a Controller library against one on the computer.



Additional Information

- If you transfer a project for which transferring the source program is disabled from the Sysmac Studio to a Controller that contains libraries for which the source is displayed, the source data for the library is not transferred.
- The libraries in the Controller are deleted for the Clear All Memory operation.

6-8-3 Library Object Specifications

This section describes the library objects that can be created and the settings for the library objects.

Applicable Library Objects

You can handle the following entities as library objects.

Library objects	Details
POU definitions	Functions and function blocks
Data types*	Structure data types, union data types, and enumeration data types

^{*} Data types are always included in the library object selections on the Sysmac Studio.

Library Object Settings

You can set the following for each library object.

Property	Definition
Name	The name of the library object.
Namespace	The namespace of the library object.
Version*	The version of the library object.
Author*	The creator of the library object. (optional)
Creation date*	The date that the library object was created.
Update date*	The date that the object library was last updated.
Comment	A comment on the library object. (optional)

^{*} These items can be set only for functions and function blocks. They are set in the POU definition properties on the Sysmac Studio.

6-8-4 **Procedure to Use Libraries**

Use the following procedures to create and use libraries.

Procedure to Create Libraries

Create a project to use as the library. Use the following procedure to create and save a library.

- Create a library project.
 - When you create the project, select a library project as the project type in the Project Window.
- **2** Create library objects.
 - In the library project, create the required POU definitions and data types, and then check them to make sure that they operate correctly.
- Set the properties of the library.
 - Set the properties of the library project, including selecting the library objects, hiding/displaying source code, and attached files.
- Save the project as a library file. Save the project in a library file in the Create Library File Dialog Box.



Additional Information

- · You can change an existing project to a library project as long as the only device that is registered in the project is a Controller. Simply change the project type in the project properties to a library project.
- You can create data that cannot be used as library objects in a library project. However, you cannot select any of this data as library objects.
- · We recommend that you use namespaces for names of the functions, function block definitions, and data types that you create as library objects to prevent duplicating names with other libraries. For details on namespaces, refer to 6-7 Namespaces.

Procedure to Use Libraries

You can read objects that are created in libraries into a project to use them in the user program. Use the following procedure to use libraries.

- 1 Specify the library.
 - Specify the library file to access in the Library Reference Dialog Box of the project in which to use the library objects.
- 2 Use the library objects in programming.

Use the library objects from the library that you read in the project. Use the library objects in the same way as any other functions, function block definitions, or data types.


6-9 Programming Precautions

This section describes precautions for developing a user program.

6-9-1 Array Specifications for Input Variables, Output Variables, In-Out Variables

Some instructions handle array variables.


Example:



6-9-2 Structure Variables for Input Variables, Output Variables, In-Out Variables


Some instructions have structure variables for input, output, or in-out variables.

Example:



In this case, you must create a structure variable for the input, output, and in-out parameters, then use the MOVE instruction to set the values.

Example:



6-9-3 **Master Control**

Introduction

Master control is used to make output FALSE for all processing between the MC (Master Control Start) instruction and the MCR (Master Control End) instruction. Master control is useful to control the execution conditions of a relatively long series of instructions.

Refer to information on the MC and MCR instructions in the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for details.


Master Control Programming Languages

You can use master control in ladder diagrams.

You cannot use master control with ST. You also cannot use master control for inline ST inside a ladder diagram.

Example:

Inside a Master Control Region:



Operation of Instructions That Are Reset in a Master Control Region

Refer to information on the MC and MCR instructions in the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for the operation of other instructions in the master control region when master control is reset.



Checking Operation and Actual Operation

This section describes the items and procedures for checking the operation of an NJ/NX-series Controller, including offline debugging procedures.

7-1	Overvi	ew of Steps in Checking Operation and Actual Operation	7-2
7-2	Offline	Debugging	7-3
	7-2-1	Features of Simulation	7-3
	7-2-2	Simulation Execution	7-3
	7-2-3	Setting Up Simulations	7-6
7-3	Checki	ng Operation on the Actual System and Actual Operation	7-8
	7-3-1	Procedures	7-8
	7-3-2	Downloading the Project	7-9
	7-3-3	Checking I/O Wiring	7-9
	7-3-4	MC Test Run	7-9
	7-3-5	Checking the Operation of the User Program	7-10
	7-3-6	Starting Actual Operation	⁷ -10

Overview of Steps in Checking 7-1 **Operation and Actual Operation**

The shaded steps in the overall procedure that is shown below are related to the checking operation and actual operation. In Step 2-4. Offline Debugging, a simulation is used to check operation without going online with the Controller. In Step 5. Checking Operation and Starting Operation on the Actual System, you go online with the Controller to check the operation of the physical Controller. When checking operation is completed, you start actual operation.

Refer to 1-3 Overall Operating Procedure for the NJ/NX-series Controller for the overall procedure.

Step 1. Software Design

Step 1-1 Designing I/O and Processing

Step 1-2 Designing Tasks

Step 1-3 Designing Programs



Step 2. Software Setups and Programming

Step 2-1 Slave and Unit Configurations

Step 2-2 Controller Setup

Step 2-3 Programming

Step 2-4 Offline Debugging



Step 3. Mounting and Setting Hardware



Step 4. Wiring



Step 5. Checking Operation and Starting Operation on the **Actual System**

7-2 Offline Debugging

This section describes how to use simulation to debug operation offline. You can simulate the operation of an NJ/NX-series Controller on a computer to check the operation of the user program with only the computer. There are also debugging operations that can be used during simulation that are not supported on the physical Controller. This makes user program development and debugging more efficient.

7-2-1 Features of Simulation

In the following way, simulation is more effective than going online with the Controller to debug operation.

- You can use breakpoints, step execution, pausing, and other functions to check program logic.
- You can select only specific programs to simulate to check only those programs.
- You can change the simulation execution speed to check operation at a slower speed than for actual operation.
- You can use the Task Execution Time Monitor to estimate the task execution times.
- You can use debugging programs to manipulate inputs from outside the Controller.

7-2-2 Simulation Execution

You can do the following for simulations.

- · Start and stop the Simulator.
- · Check the logic of programs.
- · Estimate task execution times.
- Use online debugging functions.

Starting and Stopping the Simulator

You perform simulations by starting the Simulator from the Simulation Pane of the Sysmac Studio. After you complete checking operation with the simulation, you stop the Simulator. The following procedure shows how to start and stop simulations.

Select **Simulation Pane** from the View Menu of the Sysmac Studio.

The Simulation Pane is displayed on the lower right of the window.

Execute Button Stop Button

| Simple |

Click the **Execute** Button in the Simulation Pane.

The user program is transferred to the Simulator and the simulation starts. When a simulation starts, the Editors and other parts of the Sysmac Studio window will enter the same state as when the Sysmac Studio is online with the Controller.

After you complete checking operation, click the Stop Button in the Simulation Pane to stop the Simulator.

Checking the Logic of Programs

You can use simulation debugging to stop the operation of the Simulator or to execute a program one step at a time to check the validity of the program logic. You can perform the following operations with the buttons in the Simulation Pane.

Operation	Description of operation
Breakpoints	Use a breakpoint to specify a location in a program and pause program execution at that location.
Step execution	Use step execution to execute one line of an ST program or one instruction in a ladder diagram program and then pause the Simulator.
Continuous step execution	Use continuous step execution to continually perform step execution at a specified interval.
Pausing	Use pausing to pause execution of the simulation.
Step-in execution	Use step-in execution to perform step execution of source code inside a function or function block.
Step-out execution	Use step-out execution to execute the current function or function block to the end.
One-period execution	Use one-period execution to execute the current task for one period. Execution pauses at the beginning of the program in the next period.
Conditional breakpoints	Use conditional breakpoints to pause the execution of a program at a breakpoint when the specified stopping condition is met.

Estimating Task Execution Times

If you execute the Simulator in Execution Time Estimation Mode, the estimated task execution time from when task execution starts until it stops is displayed on the Task Execution Time Monitor Display. The average and maximum estimated task execution times are displayed. Refer to Task Execution Timeout on page 5-108 for the Task Execution Time Monitor Display.



Precautions for Correct Use

- Select the relevant hardware revision in the Unit that the hardware revision is displayed.
- The estimated task execution times are not necessarily the same as the actual task execution times on the physical Controller. Depending on the user program, I/O configuration, and whether communications are used, the execution times on the physical control may exceed the estimated maximum value. Use them only as guidelines in task design. Always confirm the task execution times while connected to the physical Controller to study the designs and before starting actual system operation.

Online Debugging Functions

With the Simulator, you can use some of the functions for debugging that are supported when you are online with the Controller. The following table shows the differences between online debugging with the Controller or offline debugging with the Simulator. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details on the differences in debugging operations for the Controller and for the Simulator.

Debugging function	Controller	Simulator
Monitoring	Supported.	Supported.
Monitoring in a Watch Tab Page	Supported.	Supported.
Monitoring in the I/O Map	Supported.	Supported.
Differential monitoring	Supported.	Supported.
Controlling BOOL variables	Supported.	Supported.
Forced Refreshing (TRUE/FALSE/Cancel)	Supported.	Supported.
Changing present values of data	Supported.	Supported.
Clearing all memory	Supported.	Not supported.
Cross-reference pop-ups	Supported.	Supported.
Online editing	Supported.	Supported.
Monitoring Controller status	Supported.	Not supported.
Monitoring task execution status	Supported.	Supported.
Monitoring axis status (MC Monitor Table)	Supported.	Supported.
Changing the operating mode	Supported.	Not supported.
Resetting the Controller	Supported.	Not supported.
Data tracing	Supported.	Supported.
Setting triggers	Supported.	Supported.
Setting variables to sample	Supported.	Supported.
Starting and stopping tracing	Supported.	Supported.
Displaying trace results	Supported.	Supported.
Exporting trace results	Supported.	Supported.
Creating 3D equipment models	Supported.	Supported.
Displaying digital and analog charts	Supported.	Supported.
Displaying 3D axis paths	Supported.	Supported.
Monitoring task execution times	Supported.	Supported.
Estimating execution processing times	Not supported.	Supported.
Debugging with program simulations	Not supported.	Supported.
Setting simulation programs	Not supported.	Supported.
Changing the simulation speed	Not supported.	Supported.
Setting breakpoints	Not supported.	Supported.
Step execution	Not supported.	Supported.
Troubleshooting	Supported.	Supported.
Monitoring error information	Supported.	Supported.
Displaying error logs	Supported.	Supported.
Setting event tables	Supported.	Supported.
Monitoring user memory usage	Supported.	Supported.
Clock Information Settings	Supported.	Not supported.
Releasing access rights	Supported.	Not supported.

7-2-3 **Setting Up Simulations**

You set the following for simulations.


- · Setting simulation programs
- · Setting debug programs
- · Setting the simulation speed

Setting Simulation Programs

You can set the task or programs to simulate. You can choose to simulate some or all of the programs in the user program. The following procedure shows how to set the simulation programs.

Display the Simulation Pane.

Check boxes are displayed to the left of the programs that are listed under Tasks in the Multiview Explorer project to designate programs for simulation.



Select the check boxes for the tasks or programs to simulate.

Setting Debug Programs

A debugging program is used to check operation with offline debugging. The debugging program contains instructions to perform virtual input processing on inputs received from outside of the Controller, force user-defined errors, and perform other such debugging tasks. You can execute debugging programs only on the Simulator.

The following procedure shows how to create debugging programs.

- Right-click Programs under Programming POU in the Multiview Explorer and select Add for Debugging - Multipart Ladder or Add for Debugging - Structured Text from the menu. A debug program is created.
- 2 Enter the test program code into the debugging program that you just created.
- Assign the debugging program to a task.

You can also change a normal program that is already completed into a debug program in the same way.

1 Right-click a program under Programming - POU - Programs in the Multiview Explorer and select SettingsForDebugging - Enable.

Setting the Simulation Speed

You can use the Simulation Speed Slider in the Simulation Pane to change the simulation speed from 0.1x to 1x. You can change simulation speed while a simulation is in progress or when it is stopped. Use this to display the execution of the Simulator more slowly than for actual operation.



7-3 **Checking Operation on the Actual System and Actual Operation**

This section describes the procedures from checking operation on the actual system to starting actual operation.

7-3-1 **Procedures**

The procedures from checking operation on the actual system to starting actual operation are given

Step 1. Going Online from the Sysmac Studio and Downloading the Project	Reference
Turn ON the power supply to the Controller.	Sysmac Studio Version 1
2. Place the Sysmac Studio online with the Controller. *1	Operation Manual (Cat.
3. Download the project (i.e., the user program, Unit configuration, and other	No. W504)
settings) from the Sysmac Studio.	

You cannot connect a computer to an NX102 CPU Unit or NX1P2 CPU Unit because it does not provide a peripheral USB port. Refer to 10-2 Connection with Sysmac Studio for the procedure to connect to the Sysmac Studio.



	Step 2. Checking Operation on the Controller	Reference
1.	In PROGRAM mode, check the I/O wiring by performing forced-refreshing with user-specified values from the I/O Map or Ladder Editor.	7-3-3 Checking I/O Wiring NJ/NX-series CPU Unit
2.	For motion control, use the MC Test Run operations to perform the following: check the wiring, jog to check the motor rotation directions, perform relative positioning to check the travel distances (e.g., for electronic gear settings), and check homing operation.	Motion Control User's Manual (Cat. No. W507) 7-3-5 Checking the Operation of the User Program
3.	Change the Controller to RUN mode and check the operation of the user program.	



Ste	Reference	
Confirm that ope tion.	ration is performed as designed and then start actual opera-	
uon.		



Additional Information

Use the synchronization function to download the project from the Sysmac Studio to the Control-Ier. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on the synchronization function.

7-3-2 Downloading the Project

Use the following procedure to download the project from the Sysmac Studio to the physical Controller.

- **1** Go online with the Controller, and then select **Synchronization** from the Controller Menu. The data on the computer and the data in the physical Controller are compared automatically.
- **2** Click the **Transfer to Controller** Button.

7-3-3 Checking I/O Wiring

Check the I/O wiring by using forced refreshing from the Watch Tab Page of the Sysmac Studio. You can write values to I/O for Units or slaves to check the results to test the I/O wiring. Refer to 8-6-1 Forced Refreshing for information on forced refreshing.

7-3-4 MC Test Run

The MC Test Run function is used mainly to perform the following operations from the Sysmac Studio without a user program.

- Checking wiring: You can monitor Servo Drive connector I/O signals and Servo Drive status.
- Checking the operation and direction of the motor: You can turn ON the Servo and jog axes.
- Checking electronic gear settings: You can perform relative positioning, and check and change travel distances.
- Checking homing: You can check the homing operation.

Connect online to the Controller from the Sysmac Studio and perform the MC Test Run on the MC Test Run Tab Page.

For details, refer to the *NJ/NX-series CPU Unit Motion Control User's Manual* (Cat. No. W507). Use the following procedure.

- **1** After you complete the necessary wiring, connect the Sysmac Studio online to the Controller.
- $oldsymbol{2}$ Create axes, assign the axes, and set the following axis parameters.

Axis parameter settings required for an MC Test Run: Unit of Display, Command Pulses Per Motor Rotation, Travel Distance Per Motor Rotation, Maximum Velocity, Maximum Jog Velocity, Maximum Acceleration Rate, Maximum Deceleration Rate, Software Limit Function Selection, Software Limits, and Count Mode

3 Open the MC Test Run Tab Page and perform the following.

Example:

- Monitoring and checking wiring
- · Jogging to check the direction of the motor
- · Check travel distances for relative positioning (electronic gear settings).
- Confirming the homing operation

7-3-5 Checking the Operation of the User Program

To check the operation of the user program on the actual system, change the operating mode of the CPU Unit to RUN mode. You can use the following to check operation.

- · Checking the operation of the user program
- · Correcting the user program with online editing
- Checking the operation of the user program with data tracing

Checking the Operation of the User Program

You can perform the following to check the operation of the user program.

- Monitor the execution status of the user program.
- Check the operation by changing the status of program inputs and program outputs, and the values of variables.

Monitoring the Execution Status of the User Program

You can monitor the TRUE/FALSE status of program inputs and outputs and the present values of variables in the Controller. You can monitor the status on the Ladder Editor, Watch Tab Page, or I/O Map of the Sysmac Studio.

Checking the Operation by Changing the Status of Program Inputs and **Program Outputs, and the Values of Variables**

You can change the TRUE/FALSE status of program inputs and outputs and the present values of variables in the user program to see if the user program operates as designed. Use forced refreshing to change the status of program inputs and program outputs. Use one of the methods to change the present values of variables. Refer to 8-6-1 Forced Refreshing and 8-6-2 Changing Present Values for details.

Correcting the User Program with Online Editing

You can use online editing to correct a user program that you determined needs to be corrected while checking operation. You can use online editing to change a user program without stopping the operation of the CPU Unit. Refer to 8-6-3 Online Editing for details.

Checking Operation with Data Tracing

You can use data tracing to check when program inputs and program outputs are changed to TRUE or FALSE and to check changes in the values of variables. Refer to 8-6-4 Data Tracing for details.

7-3-6 **Starting Actual Operation**

Change the operating mode to RUN mode to start actual operation. Check the user program, data, and parameter settings sufficiently for proper execution before you use them for actual operation.



CPU Unit Functions

This section describes the functionality provided by the CPU Unit.

8-1	Data N	lanagement, Clock, and Operating Functions	8-3
	8-1-1	Clearing All Memory	
	8-1-2	Clock	
	8-1-3	RUN Output	8-6
8-2	Manag	ement Functions for NX Units	8-7
	8-2-1	NX Bus Function Module	8-7
	8-2-2	Mounting Settings of NX Units on the CPU Unit	8-12
	8-2-3	Restarting NX Units on the CPU Unit	8-15
	8-2-4	Checking Wiring for NX Units on the CPU Unit	8-16
	8-2-5	Fail-soft Operation for NX Units on the CPU Unit	8-17
	8-2-6	Monitoring Total Power-ON Time for NX Units on the CPU Unit	8-21
8-3	Manag	ement Functions for CJ-series Units	8-22
	8-3-1	Basic I/O Units	8-22
	8-3-2	Special Units	8-23
8-4	SD Me	mory Card Operations	8-25
	8-4-1	SD Memory Card Operations	8-25
	8-4-2	Specifications of Supported SD Memory Cards, Folders, and Files	8-26
	8-4-3	SD Memory Card Operation Instructions	8-28
	8-4-4	FTP Client Communications Instructions	8-28
	8-4-5	FTP Server	8-29
	8-4-6	File Operations from the Sysmac Studio	8-29
	8-4-7	SD Memory Card Life Expiration Detection	8-29
	8-4-8	List of System-defined Variables Related to SD Memory Cards	8-30
	8-4-9	SD Memory Card Self-diagnostic Functions	
	8-4-10	Exclusive Control of File Access in SD Memory Cards	8-33
8-5	Securi	ty	8-34
	8-5-1	Authentication of User Program Execution IDs	8-35
	8-5-2	User Program Transfer with No Restoration Information	8-38
	8-5-3	Overall Project File Protection	8-39
	8-5-4	Data Protection	8-40
	8-5-5	Operation Authority Verification	
	8-5-6	CPU Unit Write Protection	
	8-5-7	CPU Unit Names and Serial IDs	8-45

8-6	Debug	ging	8-47
	8-6-1	Forced Refreshing	8-47
	8-6-2	Changing Present Values	8-52
	8-6-3	Online Editing	8-54
	8-6-4	Data Tracing	8-56
	8-6-5	Differential Monitoring	8-63
8-7	Event I	Logs	8-68
	8-7-1	Introduction	8-68
	8-7-2	Detailed Information on Event Logs	8-70
	8-7-3	Controller Events (Controller Errors and Information)	8-75
	8-7-4	User-defined Events (User-defined Errors and Information)	8-77
8-8	Changi	ing Event Levels	8-84
	8-8-1	Applications of Changing Event Levels	8-84
	8-8-2	Events for Which the Event Level Can Be Changed	8-84
	8-8-3	Procedure to Change an Event Level	8-85

8-1 Data Management, Clock, and Operating Functions

This section describes the data management, clock, and operating functions.

8-1-1 Clearing All Memory

You can initialize the user program, Controller Configurations and Setup, variables, and absolute encoder home offset in the CPU Unit to the defaults from the Sysmac Studio. This is called the Clear All Memory operation.



Precautions for Correct Use

- The Clear All Memory operation can be performed only in PROGRAM mode.
- You cannot execute the Clear All Memory operation when write protection of the CPU Unit is set in the security functions.
- Do not turn OFF the power supply to the Controller during the Clear All Memory operation.

After you clear the memory, the CPU Unit operates in the same way as immediately after you create the system configuration with the CPU Unit in the factory default condition.

Operations from the Sysmac Studio

Connect the Sysmac Studio to the CPU Unit online, and select *Clear All Memory* from the Controller Menu.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.


8-1-2 Clock

Introduction

A clock (RTC) is built into the CPU Unit. The clock data from this clock is used for timestamps in the event logs and for the time and date of files that are created on the SD Memory Card.

The following functions are supported.

- · Reading/writing the clock from the Sysmac Studio
- · Reading/writing the clock with instructions
- · Reading the clock from system-defined variables (Writing is not possible.)
- · Correcting the clock from an NTP Server





Precautions for Correct Use

- The clock data is retained by the Battery when the power is turned OFF. The clock data is not correct when the power is turned ON. You can reset the clock data from an NTP server over an EtherNet/IP network after the power is turned ON.
- The clock data is retained by an internal capacitor when the battery-free operation is used in the NX102 CPU Unit or NX1P2 CPU Unit. When the power of the device is turned OFF if the retention time in the built-in capacitor exceeded, the clock data are initialized. If you use the clock data in the event log and other functions, specify the clock data when you turn ON the power supply every time.

Clock Data Range

- NX-series CPU Units:1970-01-01 to 2069-12-31 (January 1, 1970 to December 31, 2069).
- NJ-series CPU Units:1970-01-01 to 2106-02-06 (January 1, 1970 to February 6, 2106).

Setting the Time Zone and the Local Time

Before you use the CPU Unit for the first time, set the time zone and local time in the clock data. You can set the time zone and local time from the Sysmac Studio in the Controller Clock Dialog Box. The clock data that is read by the EtherCAT slaves and CJ-series CPU Units from the CPU Unit and the clock data that is set are the local times in the time zone.



Additional Information

When a Battery is not mounted or when the Battery voltage is low, the time zone setting is retained, but the clock data is not retained and will not be correct.

Setting the Clock Data

Use one of the following methods.

Changing Clock Data from the Sysmac Studio

You can use the Sysmac Studio to synchronize the clock data of the built-in clock with the clock on the computer.

Changing Clock Data with Instructions

You can use the SetTime instruction to set the clock data.

Changing the Clock Data from an NTP Server

You can use an NTP server on EtherNet/IP to set the clock data.

Correcting the Clock from an NTP Server

Application

In a network system, the clock data must be shared by the entire system. NTP is supported to enable easy time synchronization.

Specifications

An NTP client is provided.

Refer to the NJ/NX-series Built-in EtherNet/IP User's Manual (Cat. No. W506) for details.

Reading the Clock Data

If the clock data is incorrect, the incorrect value is read.

Reading the Clock Data from Instructions

You can use the GetTime instruction to read the clock data from the user program.

Reading the Clock from System-defined Variables (Writing Is Not Possible)

You can use the following system-defined variable to read the clock data. _CurrentTime (System Time)

Sysmac Studio Procedure

You can select **Controller Clock** from the Controller Menu of the Sysmac Studio to display the clock data.

Logging

When you change the clock data, an event is recorded in the event log. However, nothing is recorded in the event log if the time is corrected for the NTP.


Related System-defined Variables

Variable name	Meaning	Description	Data type	R/W
_CurrentTime	System Time	This variable contains the CPU Unit's internal clock data.	DATE_AND_TIME	R

RUN Output 8-1-3

Introduction

The RUN output on NX-PA9001, NX-PD7001, or NJ-P□3001 Power Supply Unit is ON while the CPU Unit is operating.



The RUN output operates as shown in the following table.

Status	Operation
During RUN mode	ON
Startup state (until RUN mode is entered according to the Startup Mode setting).	OFF
During PROGRAM mode	
When a major fault level Controller error occurs	

The ratings of the RUN output on NX-PA9001, NX-PD7001, or NJ-P□3001 Power Supply Unit are as follows:

Item	Description	
Contact form	SPST-NO	
	2 A at 250 VAC for resistive load	
Switching capacity	0.5 A at 120 VAC for inductive load	
	2 A at 24 VDC for resistive load	

Application

You can use the RUN output for the following purposes:

- Obtain a signal to notify the host that the CPU Unit is functioning normally and is currently operating.
- · Synchronize the completion of startup of more than one CPU Unit
- · Release interlocks when the CPU Unit starts operation.



Precautions for Safe Use

It takes up to approximately 10 to 20 s to enter RUN mode after the power is turned ON. The outputs during this time behave according to the slave or Unit specifications. Use the RUN output on the Power Supply Unit, for example, to implement fail-safe circuits so that external devices do not operate incorrectly.

8-2 Management Functions for NX Units

This section describes the management functions used for NX Units on the NX102 CPU Unit or NX1P2 CPU Unit.

You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

8-2-1 NX Bus Function Module

The NX Bus Function Module performs processing such as a management of event logging, management of status, and I/O refreshing for the NX Units that are connected to the NX bus of the CPU Unit as a master of the NX bus (hereafter NX bus master).

For I/O data that are handled by the NX Bus Function Module, there are two kinds of I/O data, the status of NX Units managed by the NX Bus Function Module as the NX bus master and I/O data for individual NX Units. The variables are the assignable I/O ports for both of them.

There are two kinds of variables to access I/O data, device variables that are assigned to I/O ports and system-defined variables for the NX Bus Function Module.

The following describes the status of NX Units managed by the NX Bus Function Module as the NX bus master, I/O data for individual NX Units, assigning device variables to I/O ports, and programming sample using device variables.

Status of NX Units Managed by the NX Bus Function Module as the NX Bus Master

For the status of NX Units managed by the NX Bus Function Module as the NX bus master, you can use only device variables assigned to I/O ports to access, only system-defined variables to access, or both of device variables and system-defined variables to access.

A List of Status of NX Units Managed by the NX Bus Function Module as the NX Bus Master

Name	I/O port	System-defined variable
NX Unit Registration Status	NX Unit Registration Status	_NXB_UnitRegTbl
NX Unit Message Enabled Status	NX Unit Message Enabled Status	_NXB_UnitMsgActiveTbl
NX Unit I/O Data Active Status	NX Unit I/O Data Active Status	_NXB_UnitIOActiveTbI
NX Unit Error Status	NX Unit Error Status	_NXB_UnitErrFlagTbl
Time Stamp of Synchronous Input	Time Stamp of Synchronous Input	
Time Stamp of Synchronous Output	TimeStamp of Synchronous Output	
NX Bus Function Module Error Status		_NXB_ErrSta
NX Bus Function Module Master Error Status		_NXB_MstrErrSta
NX Bus Function Module Unit Error Status		_NXB_UnitErrStaTbl

Descriptions of Status of NX Units Managed by the NX Bus Function Module as the NX Bus Master

Name	Description					
NX Unit Registration Status	This status tells whether the NX Units are registered in the Unit Configuration.					
	Each bit has the following meaning.					
	TRUE: Registered					
	FALSE: Not registered					
	If the Unit configuration information is registered, the status is TRUE for each Unit that is registered.					
	If the Unit configuration information was automatically created (with only the actual Unit configuration information and no registered information), the status is FALSE for all Units.					
	The status is TRUE for NX Units that are set as unmounted Units.					
	Each bit is updated at the following times.					
	If the Unit Configuration Information Is Registered:					
	The status changes to TRUE when the system is started.					
	The status changes to FALSE when the configuration information is cleared. • If the Unit Configuration Information Is Automatically Created:					
	The status changes to TRUE when the configuration information is confirmed. The status is always FALSE if the Unit configuration information is automatically created.					
NX Unit Message Enabled	This status tells whether the NX Units can process message communications.					
Status	Each bit has the following meaning.					
	TRUE: Message communications possible.					
	FALSE: Message communications not possible.					
	The status says that message communications are enabled for NX Units that meet the following conditions.					
	The comparison shows no differences (only if the Unit configuration information is registered).					
	The NX Unit does not have a WDT error.					
	The status is FALSE for NX Units that are set as unmounted Units.					
	Each bit is updated when the message communications status changes on the corresponding NX Unit.					
NX Unit I/O Data Active Sta-	This status tells whether the NX Units can process I/O data communications.					
tus	Each bit has the following meaning.					
	TRUE: The I/O data in the NX Unit can be used for control.					
	FALSE: The I/O data in the NX Unit cannot be used for control.					
	The status is FALSE for NX Units that are set as unmounted Units.					
	Each bit is updated when the operating status changes on the corresponding NX Unit.					
	If both of NX Unit Registration Status and NX Unit I/O Data Active Status are TRUE, the target NX Units operate normally.					

Name	Description
NX Unit Error Status	This status tells whether an error exists on the NX Units.
	Each bit has the following meaning.
	TRUE: Error
	FALSE: No error
	Each bit is set to TRUE when the level of the error is as follows:
	Major fault
	Partial fault
	Minor fault
	Observation
	The status is FALSE for NX Units that are set as unmounted Units.
	Each bit is updated at the following times.
	The status changes to TRUE when an error occurs.
	The status changes to FALSE when the error is reset. Even if the cause of the error has been removed, you must reset the error for the status to change to FALSE.
Time Stamp of Synchronous Input	This time stamp tells when a synchronous input occurred in the NX Unit that supports synchronous I/O refreshing. The unit is ns.
Time Stamp of Synchronous Output	This time stamp tells when a synchronous output occurred in the NX Unit that supports synchronous I/O refreshing. The unit is ns.
NX Bus Function Module Error Status	Gives the NX Bus Function Module error status. This status collects the NX Bus Function Module Master Error Status and NX Bus Function Module Unit Error Status for all NX Units.
NX Bus Function Module Master Error Status	Gives the status of errors that are detected in the NX Bus Function Module of the CPU Unit. Refer to A-6-8 Meanings of Error Status Bits on page A-123 for the meanings of the error status bits.
NX Bus Function Module Unit Error Status	Gives the status of errors that are detected in the NX Unit on the CPU Unit. This status is given as an array of WORD data. The subscript of the array corresponds to the NX Unit number. Refer to A-6-8 Meanings of Error Status Bits on page A-123 for the meanings of the error status bits.

Refer to A-7-4 NX Bus Function Module, Category Name: _NXB on page A-154 for details on the related system-defined variables.

Update Timing of Status of NX Units Managed by the NX Bus Function Module as the NX Bus Master

Name	I/O port for an NX Unit	System-defined variable	
NX Unit Registration Status	Not synchronized with task execution	Not synchronized with task execution	
NX Unit Message Enabled Status	Not synchronized with task execution	Not synchronized with task execution	
NX Unit I/O Data Active Status	Synchronized with primary periodic task	Synchronized with primary periodic task	
NX Unit Error Status	Synchronized with primary periodic task	Synchronized with primary periodic task	
Time Stamp of Synchronous Input	Synchronized with primary periodic task		
Time Stamp of Synchronous Output	Synchronized with primary periodic task		
NX Bus Function Module Error Status		Not synchronized with task execution	
NX Bus Function Module Master Error Status		Not synchronized with task execution	
NX Bus Function Module Unit Error Status		Not synchronized with task execution	

I/O Data for Individual NX Units

I/O data are determined by the model number of the NX Unit and the functionality. You can use only device variables that are assigned to an I/O port of an NX Unit to access I/O data.

Refer to the user's manual for the specific NX Units for details on I/O data for individual NX Units.

Assigning Device Variables to I/O Ports

When you create the Unit configuration information on the Sysmac Studio, the status of NX Units managed by the NX Bus Function Module as the NX bus master and I/O data for NX Units mounted on the CPU Unit are automatically registered as I/O ports.

The variables that are assigned to I/O ports for status and I/O data are device variables.

I/O Port Names

The status of NX Units managed by the NX Bus Function Module as the NX bus master is given as the following six kinds of I/O port names for each NX Unit.

Name	I/O port name	Data type
NX Unit Registration Status	Device name + NX Unit Registration Status	BOOL
NX Unit Message Enabled Status	Device name + NX Unit Message Enabled Status	BOOL
NX Unit I/O Data Active Status	Device name + NX Unit I/O Data Active Status	BOOL
NX Unit Error Status	Device name + NX Unit Error Status	BOOL
Time Stamp of Synchronous Input	Device name + Time Stamp of Synchronous Input	ULINT
Time Stamp of Synchronous Output	Device name + TimeStamp of Synchronous Output	ULINT

Example for NX Unit Registration Status with a device name N1:

N1 NX Unit Registration Status

Example for Time Stamp of Synchronous Input with a device name N2:

N2 Time Stamp of Synchronous Input

I/O port names are determined by the model number of the NX Unit and the functionality for I/O data for NX Units mounted on the CPU Unit.

Example for a Digital Input Unit:

Input Bit 00

Example for an Analog Output Unit:

Ch1 Analog Output Value

Registering Device Variables

You assign device variables to I/O ports in the I/O Map of the Sysmac Studio. The device variables that you create are registered in the variable table.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details on registering device variables with the Sysmac Studio.

Device Variable Attributes

Refer to Device Variable Attributes on page 3-12 for details on device variable attributes.


Programming Sample Using Device Variables

The following describes a programming sample when using the NX Unit device variables.

Testing the Validity of I/O Data for Individual NX Units

A sample programming that determines whether NX Unit (NX Unit number: 5) I/O data on the CPU Unit is valid is given below. The NX Unit I/O Data Active Status and the NX Unit Error Status are used.

The I/O data is manipulated in the NX Unit (NX Unit number: 5) if I/O data is valid.




Nx_Unit5_IOActive: This is a device variable to indicate the NX Unit I/O Data Active Status with NX Unit number 5. Nx_Unit5_Error: This is a device variable to indicate the NX Unit Error Status with NX Unit number 5.

• Testing Whether Individual NX Units Can Process Message Communications

A sample programming that confirms whether NX Unit (NX Unit number: 5) on the CPU Unit can process message communications is given below. The NX Unit Message Enabled Status is used.

The Write NX Unit instruction is used to send a message to the NX Unit (NX Unit number: 5) if message communications is enabled.



Nx_Unit5_MessageActive: This is a device variable to indicate the NX Unit Message Enabled Status with NX Unit number 5.

8-2-2 Mounting Settings of NX Units on the CPU Unit


This section describes the mounting settings of NX Units on the CPU Unit.

Overview of Function

You can use this function to register NX Units that will be added to at a later time in the Unit configuration information as unmounted Units. With this function, you can create the program in advance for NX Units that are not mounted to the actual configuration.

You can use this function even if a specific Unit is temporarily unavailable such as when commissioning the system.

- I/O memory area is reserved for these unmounted NX Units in the same way that it is reserved for NX Units that are mounted to the actual configuration.
- Unmounted NX Units are also assigned NX Unit numbers. This prevents the NX Unit numbers of other NX Units on the CPU Unit from changing when you change the setting of an NX Unit that is not mounted to the setting of an NX Unit that is mounted to the actual configuration.



Operating Specifications for NX Units That Are Set as Unmounted Units

The operating specifications for NX Units that are set as unmounted Units are given in the following table.

Item	Operation
Bandwidth reservation for I/O refresh data with the EtherCAT master	Bandwidth is reserved.
I/O refreshing with the EtherCAT master	The I/O is not refreshed.
Detection of events	Events are not detected.
Assignment of NX Unit numbers to NX Units	Unit numbers are not assigned because the Units do not exist.
Message communications	Not possible because the Units do not exist.
Transfers for the synchronization function of the Sysmac Studio	Not applicable.
Transfer of the Unit operation settings	Not applicable.
Sysmac Studio Controller backup function	Not applicable.
SD Memory Card backup function	Not applicable.
Instructions	Parameters cannot be read or written. An instruction error will occur.
Clearing all memory	Not applicable.
Reading/writing setting information through backup/restore operations	Not applicable.
Reading event logs	Not applicable.
Notification of status information	Not applicable.

NX Units that are set as unmounted Units are included in the calculations for total power consumption and total Unit width when the Unit configuration is created on the Sysmac Studio.



Precautions for Safe Use

Check the user program, data, and parameter settings for proper execution before you use them for actual operation.




Precautions for Correct Use

When you mount an NX Unit that was set as an unmounted Unit, a Unit Configuration Verification Error will occur.

Setting NX Units as Unmounted Units

In the CPU and Expansion Racks Tab Page on the Sysmac Studio, select the target NX Unit and set the NX Unit Mounting Setting to Disabled. The selected NX Unit is set as an unmounted Unit. After you change the settings for any NX Units, always transfer the Unit configuration information to the CPU Unit.



8-2-3 Restarting NX Units on the CPU Unit

This section describes restarting an NX Unit on the NX1P2 CPU Unit. The restart function is used to enable values that are set for the NX Unit without cycling the power supply to the Controller.

Types of Restarts

The following table gives the types of restarts for individual NX Units.

Туре	Function
Restarting NX Bus Function Module	All NX Units on the CPU Unit are restarted.
Restarting individual NX Units	The specified NX Unit is restarted.

Restarting NX Bus Function Module

All NX Units on the CPU Unit are restarted.

Specify the NX Bus Function Module and then execute the restart. The restart of the NX Bus Function Module does not affect the task execution of the CPU Unit. Also an error will not occur.

The methods for restarting are listed below.

- · Sysmac Studio
- RestartNXUnit (Restart NX Unit) instruction

Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for details on the RestartNX-Unit instruction.

Restarting Individual NX Units

One specified NX Unit is restarted.

The methods for restarting an NX Unit are listed below.

- Sysmac Studio
- RestartNXUnit (Restart NX Unit) instruction

Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for details on the RestartNX-Unit instruction.

The NX Bus Function Module and all NX Units that were not specified for restarting continue to operate.

Restarting an NX Unit

Place the Sysmac Studio online. In the CPU and Expansion Racks Tab Page, right-click the CPU Unit and select **Restart for NX Bus/NX Unit - Yes**. All NX Units on the CPU Unit are restarted.

In the same way, right-click the NX Unit to restart and select **Restart for NX Bus/NX Unit - Yes**. The specified NX Unit is restarted.

Checking Wiring for NX Units on the CPU Unit 8-2-4

This section describes how to check the wiring for NX Units on the NX102 CPU Unit or NX1P2 CPU Unit.

You can use the Sysmac Studio to check the wiring between NX Units on the CPU Unit and I/O devices during system commissioning even if the user program is not created.

Preparation

Create the NX Unit configuration information and check whether the Unit configuration on the Sysmac Studio agrees with the actual Unit configuration if the NX Unit configuration information was transferred to the CPU Unit.

If the NX Unit configuration information was not transferred to the CPU Unit, go online, right-click anywhere in the CPU an Expansion Racks Tab Page and select Compare and Merger with Actual **Unit Configuration**. The configuration is automatically configured.

How to Check the Wiring

Item to check	Checking method
Checking inputs	Place the Sysmac Studio online and you can monitor the present values of Unit I/O ports in the I/O Map.
Checking outputs	Place the Sysmac Studio online, and forced refreshing or set/reset Unit I/O ports in the I/O Map.

Refer to 8-6-1 Forced Refreshing for information on forced refreshing.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the operations on the Sysmac Studio.



Additional Information

- For Position Interface Units and other NX Units that are assigned to axes, use the MC Test Run of the Sysmac Studio. Refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507) for details.
- · Use the I/O checking of EtherCAT Slave Terminals to check the wiring of NX Units on the EtherCAT Coupler Unit. Refer to the NX-series EtherCAT Coupler Unit User's Manual (Cat. No. W519) for details.

8-2-5 Fail-soft Operation for NX Units on the CPU Unit


This section describes the fail-soft operation for the NX bus Function Module of the NX102 CPU Unit and NX1P2 CPU Unit.

Only the NX102 CPU Units and NX1P2 CPU Units have the NX Bus Function Module.

This function allows the NX Bus Function Module to start or continue I/O refreshing only with the NX Units on the CPU Unit that can operate normally when an error occurs for the NX Bus Function Module.

For example, you can use this function in the following cases.

- When it is dangerous to stop all NX Units on the CPU Unit at once
- To continue the operation of the NX Units on the CPU Unit until the system can be stopped safely through the user program or user operation
- To not stop all devices, i.e., to continue operation for only some devices





Precautions for Safe Use

If you change the fail-soft operation setting, the output status when the error occurs may also change. Confirm safety before you change the setting.




Precautions for Correct Use

If you use fail-soft operation, write programming to determine whether Unit I/O data is valid. Without such programming, the user program cannot distinguish between Units for which I/O refreshing is continued and Units for which I/O refreshing is stopped.

To determine whether Unit I/O data is valid, use the variables to indicate the NX Unit I/O Data Active Status and NX Unit Error Status from the NX Unit device variables.

Sample programming that determines whether NX Unit (NX Unit number: 5) I/O data on the CPU Unit is given below.



R HandSensor Active: This is a device variable to indicate the NX Unit I/O Data Active Status with NX Unit number 5.

R HandSensor Error: This is a device variable to indicate the NX Unit Error Status with NX Unit number 5.

Operations for Errors

The following table describes the operation of the NX Bus Function Module when the NX Bus Function Module is used with and without fail-soft operation.

Operating status	Operation when an error occurs while starting	Operation when an error occurs during normal operation	
With fail-soft operation	The NX Bus Function Module starts I/O refreshing for the NX Units that can operate normally.	The NX Bus Function Module continues I/O refreshing for the NX Units that can operate normally.	
	It does not start I/O refreshing for the NX Units that cannot operate normally.	It stops I/O refreshing for the NX Units that cannot operate normally.	
Without fail-soft operation*1	The NX Bus Function Module does not start I/O refreshing for any of the NX Units.	The NX Bus Function Module stops I/O refreshing for any of the NX Units.	

^{*1} When an error occurs, I/O refreshing for the NX Units on the CPU Unit that is not started, i.e., I/O refreshing for the NX Units on the CPU Unit that is stopped is called "entire stop".

Except for the I/O refreshing, the operation when an error occurs for the NX Bus Function Module is the same regardless of whether fail-soft operation is used. Specially, error notification is provided and errors are recorded in the event log.

Setting Fail-soft Operation

Using Fail-soft Operation

To enable fail-soft operation, select the CPU Unit in the CPU and Expansion Racks Tab Page on the Sysmac Studio and set the **Fail-soft Operation Setting** to **Fail-soft operation**.

The default for the Fail-soft Operation Setting for the NX Bus Function Module is Fail-soft operation.

Not Using Fail-soft Operation

To disable fail-soft operation, select the CPU Unit in the CPU and Expansion Racks Tab Page on the Sysmac Studio and set the **Fail-soft Operation Setting** to **Stop**.



Precautions for Correct Use

- · After you change the setting, always transfer the changed settings to the CPU Unit.
- Refer to 4-2-4 Unit Configuration and Unit Setup for NX102 CPU Units and NX1P2 CPU Units
 on page 4-12 for information on the Unit configurations and settings for the NX102 CPU Units
 and NX1P2 CPU Units.

Errors to Which Fail-soft Operation Applies

The following errors are examples of the errors to which fail-soft operation applies.

- NX Bus Communications Error
- · Registered NX Unit Not Mounted
- NX Unit Communications Timeout
- · NX Unit Initialization Error
- NX Unit Startup Error

Even if you enable fail-soft operation, the NX Bus Function Module may not start I/O refreshing for any of the NX Units when the CPU Unit is started, depending on the cause of the error.

Refer to *Errors to Which Fail-soft Operation Applies* on page 8-19 for details on the operation for different error causes.

Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the errors to which fail-soft operation applies.

If an error occurs to which fail-soft operation does not apply, the NX Bus Function Module will stop I/O refreshing for all NX Units even if you enable fail-soft operation.

Errors to Which Fail-soft Operation Applies

Even if fail-soft operation is enabled, I/O refreshing may not start depending on the cause of the error when the CPU Unit starts.

Examples are provided below.

Example of Unit configuration information and actual configuration						ation	Description of configuration	Operation when CPU Unit	
		NX Unit numbers				3	Description of configuration	starts	
		1	2	3	4	5			
Unit contion info	nfigura- ormation	Α	В	С	D	E*1	The following models of Units are mounted after the CPU Unit in the order given on the left: A, B, C, D, and E.		
Actual con- figura- tion	Case 1	Α	В	С			Unit D is not mounted.	I/O refreshing does not start for NX Unit numbers 1, 2, and 3 because fail-soft operation is enabled.	
	Case 2	Α	С	D			Unit B is not mounted.	I/O refreshing does not start for any of the NX Units.	
	Case 3	Α	В	D	С		Unit C and D are mounted in reverse order.	I/O refreshing does not start for any of the NX Units.	
	Case 4	Α	В	С	D	D	An extra Unit D is mounted for NX Unit number 5.	I/O refreshing does not start for any of the NX Units.	
	Case 5	Α	В	С	F		Unit F is mounted for NX Unit number 4, but it does not exist in the Unit configuration information.	I/O refreshing does not start for any of the NX Units.	
	Case 6	A	В	С	D	E	Unit E is mounted for NX Unit number 5 even though its NX Unit Mounting Setting is set to Disable.	I/O refreshing does not start for any of the NX Units.	

^{*1} Unit E has the NX Unit Mounting Setting set to Disable.

8-2-6 Monitoring Total Power-ON Time for NX Units on the CPU Unit

This section describes how to monitor the total power-ON time for NX Units on the NX1P2 CPU Unit.

Each of the NX Units on the CPU Unit records the total time that the Unit power supply is ON to it. You can display these times on the Sysmac Studio.

Specifications of Monitoring Total Power-ON Times

The specifications of monitoring the total power-ON times are given in the following table.

Item	Specification	
Display unit	When total power-ON time is less than 1 hour:	Minutes
	When total power-ON time is 1 hour or longer:	Hours
Update interval	When total power-ON time is less than 24 hours:	10 minutes
	When total power-ON time is 24 hours or longer:	1 hour
Measurement error	1 hour/month max.	
Default setting	0 minutes	

Checking Total Power-ON Times

You can use the Sysmac Studio to check the total power-ON times of NX Units on the CPU Unit.

Or, you can use the following special instruction to check the total power-ON times.

NX_ReadTotalPowerOnTime instruction

This section describes how to check the total power-ON times with the Sysmac Studio. Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for details on the NX_ReadTotalPowerOnTime instruction.

Checking Total Power-ON Times with Sysmac Studio

You can use the Production Information on the Sysmac Studio to check.

- **1** Go online.
- 2 Right-click CPU Rack under Configurations and Setup CPU/Expansion Racks in the Multiview Explorer and select Production Information.

The Production Information Dialog Box is displayed.

You can check the total power-ON times of each NX Unit when you change the view to the production information details.

Display When Times Cannot Be Recorded

If the total power-ON time cannot be recorded because of a non-volatile memory hardware error, the total power-ON time is displayed as *Invalid record* on the Sysmac Studio.

Display for Units That Do Not Support Monitoring the Total Power-ON Time

If a Unit does not support monitoring the total power-ON time, the total power-ON time for the Unit is displayed as "---" on the Sysmac Studio.

Display When Reading the Time Failed

If reading the time failed, the total power-ON time is displayed as "---" on the Sysmac Studio.

Management Functions for CJ-series 8-3 **Units**


This section describes the management functions used for Units in the Controller.

You can use CJ-series Units only with NJ-series CPU Units.

8-3-1 **Basic I/O Units**

Introduction

You can increase the input response time to reduce chattering and the effects of external noise. You can decrease the input response time to enable detection of shorter input pulses. Do not set the ON response time or OFF response time to less than the refresh time.



Setting Methods

From the Multiview Explorer of the Sysmac Studio, double-click CPU/Expansion Racks under Configurations and Setup. Then select the input response times in the Unit information for the Basic I/O Units.



You must do either of the following to enable the settings.

- · Cycle the power supply to the Controller.
- Reset the Controller (the entire CPU Unit) from the Sysmac Studio.

Related System-defined Variables

The set values for the input response times of the Basic Input Units are output to the following system-defined variable.


Variable name	Meaning	Description	Data type	R/W
_CJB_InRespTm	Basic Input Unit Input Response Times	Contains the response times of the Basic I/O Units in 0.1-ms increments.	ARRAY[03, 09]OF UINT	R

8-3-2 Special Units

Restarting Special Units

You can restart a Special Unit (Special I/O Unit or CPU Bus Unit) to enable values that are set for it. If you restart a Special Unit, you do not have to cycle the power supply to the Controller. Execute the following ResetUnit (Restart Unit) instruction to restart Special Units.

Instruction name	Instruction	Description
Restart Unit	ResetUnit	Restarts the CPU Bus Unit or Special I/O Unit.



The ResetUnit instruction restarts a Special Unit across multiple task periods when execution condition a changes to TRUE. If the restart ends normally, the output variable *Done* (normal end) changes to TRUE and variable b therefore changes to TRUE.

If Special Unit settings are changed in any of the following ways, you must restart the Special Unit or cycle the power supply to the Controller.

- Editing from the Special Unit Settings Tab Page of the Sysmac Studio
- Editing from the I/O Map or Watch Tab Page
- · Setting the user program

• Related System-defined Variables


Variable name	Meaning	Description	Data type	R/W
_CJB_C- BU00InitSta to _CJB_C- BU15InitSta	CPU Bus Unit Initializing Flags	The corresponding variable is TRUE during initialization of the CPU Bus Unit. The corresponding variable changes to FALSE when the initialization is completed. The numbers in the variables indicate the unit numbers of the applicable Units.	BOOL	R
_CJB SIO00InitSta to _CJB SIO95InitSta	Special I/O Unit Initializ- ing Flags	The corresponding variable is TRUE during initialization of the Special I/O Unit. The corresponding variable changes to FALSE when the initialization is completed. The numbers in the variables indicate the unit numbers of the applicable Units.	BOOL	R
_CJB_C- BU00Restart to _CJB_C- BU15Restart	CPU Bus Unit Restart Bits	The CPU Bus Unit is restarted when the corresponding variable changes to TRUE. (It is changed to FALSE by the system after the CPU Bus Unit is restarted.) The numbers in the variables indicate the unit numbers of the applicable Units. If you change the Restart Bit to TRUE with an instruction, the restart process begins from refresh processing in the next task period after the instruction is executed.	BOOL	RW
_CJB SIO00Restart to _CJB SIO95Restart	Special I/O Unit Restart Bits	The Special I/O Unit is restarted when the corresponding variable changes to TRUE. (It is changed to FALSE by the system after the Special I/O Unit is restarted.) The numbers in the variable names indicate the unit numbers of the applicable Units. If you change the Restart Bit to TRUE with an instruction, the restart process begins from refresh processing in the next task period.	BOOL	RW

8-4 SD Memory Card Operations

This section describes the functions that you can use for SD Memory Cards.

8-4-1 SD Memory Card Operations

The NJ/NX-series CPU Unit supports the following functions for SD Memory Cards.



Function	Introduction
SD Memory Card operation instructions	You can access SD Memory Cards from instructions in the user program.
FTP client communications instructions*1	You can use these instructions to transfer files via FTP from the CPU Unit to computers or Controllers at Ethernet nodes.
FTP server	You can use FTP commands from an FTP client on the Intranet to read and write large files in the SD Memory Card through EtherNet/IP.
File operations from the Sysmac	You can perform file operations from the Sysmac Studio for the SD Memory Card inserted in the CPU Unit.
Studio	You can perform file operations for Controller files in the SD Memory Card and save standard document files on the computer.
SD Memory Card life expiration detection	Notification of the expiration of the life of the SD Memory Card is provided in a system-defined variable and event log.
SD Memory Card backup, automatic transfer from SD Memory Card, and program transfer from SD Memory Card*2	You use the SD Memory Card inserted in the CPU Unit to backup, restore, and verify user programs and data in the Controller. Refer to 9-2 SD Memory Card Backups, 9-4 Automatic Transfers from SD Memory Cards, and 9-5 Program Transfer from SD Memory Card for details.
Safety Data Logging* ³	You can record I/O data for the NX-SL5□□□ that is mounted to the NX bus of the NX102 CPU Unit in a chronological order into an SD Memory card.
	Refer to the <i>NX-series Safety Control Unit User's Manual</i> (Cat. No. Z930-E1-12 or later) for details.

^{*1} A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the FTP client communications instructions.

^{*2} A CPU Unit with unit version 1.11 or later and Sysmac Studio version 1.15 or higher are required to use the function.

^{*3} An NX102 CPU Unit with unit version 1.31 or later, an NX-SL5 \subseteq \subseteq Safety CPU Unit with unit version 1.3 or later, and Sysmac Studio version 1.24 or higher are required to use the Safety Data Logging.

Specifications of Supported SD Memory Cards, Folders, and 8-4-2 **Files**

SD Memory Card Specifications

The NJ/NX-series Controllers support both SD cards and SDHC cards. However, operation was confirmed only for the OMRON SD Memory Card given in the following table. Correct operation may not be possible if you use any other SD or SDHC card.

Model	Card type	Capacity [GB]	Formatting	Number of overwrites	Write protection
HMC-SD291*1	SD card	2	FAT16	100,000 over-	You can write-protect the SD
HMC-SD491	SDHC card	4	FAT32	writes	Memory Card with a hardware switch on the Card.

^{*1} You cannot use an HMC-SD291 for the NJ501-□□□□ CPU Unit with the hardware revision A and unit version 1.15 or later.

The system-defined variable _Card1Err (SD Memory Card Error Flag) changes to TRUE (observation level) in the following cases.

· When there is a format error


If an error occurs, the SD PWR indicator on the front of the CPU Unit goes out, and accessing the SD Memory Card will not be possible.



Precautions for Correct Use

When you use the SD Memory Card that "MR□" is displayed on the back side with an NX701-□□□□ CPU Unit or an NJ501-□□□□ CPU Unit, be sure to use the unit version as shown below.

- NX701-□□□□: Version 1.14 or later
- NJ501-□□□□: Version 1.13 or later



Folder and File Specifications

Character Restrictions

Object named by user	Usable characters	Reserved words	Multibyte character compatibility	Case sen- sitivity	Maximum size (without NULL)
Volume label	0 to 9, A to Z, and a to z, as well as % @ ! ' () ~= # & + ^ [] { } , . ; and single-byte kana*1	CON, PRN, AUX, CLOCK\$, NUL, COM0,	Not sup- ported.*2	Case insensitive	11 bytes
Directory name File name	0 to 9, A to Z, and a to z, as well as \$ % '@!'() ~= # & + ^[]{},.; and single-byte kana	COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, COM9, LPT0, LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9			65 bytes 65 bytes

^{*1} You cannot begin volume label names with a space.

Subdirectory Levels

You can create up to 5 levels (example: f1/f2/f3/f4/f5/abc.txt)

Maximum Number of Stored Files

The number of files that you can store on an SD Memory Card depends on the directory level in which you store the files. The maximum number of files for each is given in the following table. However, the values in the table assume that 8.3 filename is used. If you use long file names, the maximum number of stored files is less than the value given in the following table.

Directory level	Format	Maximum number of stored files	
Doot divestant	FAT16	511	
Root directory	FAT32	65,533	
Subdirectory	FAT16, FAT32	65,533	

Maximum Size of One File

The maximum size of any one file is 2,147,483,647 bytes (2 GB -1 byte).

^{*2} Even if the computer supports multibyte characters (e.g., for Japanese), you cannot use them in the CPU Unit.

8-4-3 **SD Memory Card Operation Instructions**

You can perform various operations on the SD Memory Card by using the following instructions.

Instruction name	Instruction	Description
Read Variable from File	FileReadVar	The FileReadVar instruction reads the contents of a binary file on the SD Memory Card and writes it to the specified variable. You can specify array and structure variables.
Write Variable to FileWriteVar		The FileWriteVar instruction writes the value of a specified variable to a binary file in the SD Memory Card. You can specify array and structure variables. If the directory specified for the file name does not exist, it is created.
Open File	FileOpen	The FileOpen instruction opens the specified file.
Close File	FileClose	The FileClose instruction closes the specified file.
Seek File	FileSeek	The FileSeek instruction sets a file position indicator in the specified file.
Read File	FileRead	The FileRead instruction reads the data from the specified file.
Write File	FileWrite	The FileWrite instruction writes data to the specified file.
Get Text String	FileGets	The FileGets instruction reads a text string of one line from the specified file.
Put Text String	FilePuts	The FilePuts instruction writes a text string of one line to the specified file.
Delete File	FileRemove	The FileRemove instruction deletes the specified file from the SD Memory Card.
Change File Name	FileRename	The FileRename instruction changes the name of the specified file or directory.
Copy File	FileCopy	The FileCopy instruction copies the specified file to a different file.
Create Directory	DirCreate	The DirCreate instruction creates a directory in the SD Memory Card.
Delete Directory	DirRemove	The DirRemove instruction deletes a directory from the SD Memory Card.

FTP Client Communications Instructions 8-4-4

FTP client communications instructions are used to transfer files via FTP from an NJ/NX-series CPU Unit to computers or Controllers at Ethernet nodes.

The files on the SD Memory Card are read and written when the following instructions are executed.

Instruction name	Instruction	Description
Put File onto FTP Server	FTPPutFile	The FTPPutFile instruction uploads one or more files in the FTP client's SD Memory Card to the FTP server.
Get File from FTP Server	FTPGetFile	The FTPGetFile instruction downloads one or more files from the FTP server to the FTP client's SD Memory Card.




Version Information

A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the FTP client communcations instructions.

8-4-5 FTP Server

You can read and write files on the SD Memory Card via EtherNet/IP by sending FTP commands to the built-in EtherNet/IP port from an FTP client.

Refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP User's Manual (Cat. No. W506) for details.



8-4-6 File Operations from the Sysmac Studio

You can perform file operations from the Sysmac Studio for the SD Memory Card inserted in the CPU Unit. In addition to Controller files, you can also store document files or other files on the SD Memory Card.

8-4-7 SD Memory Card Life Expiration Detection

You can determine the remaining life of the SD Memory Card before the Card becomes physically deteriorated.

You can determine the remaining life of the SD Memory Card with the following functions.

- System-defined variable _Card1Deteriorated (SD Memory Card Life Warning Flag)
- SD Memory Card Life Exceeded (Observation) record in the event log

The life of the SD Memory Card is checked when the power is turned ON and periodically while the SD Memory Card is inserted.

When the end of the life of the SD Memory Card is detected, save the data on the SD Memory Card and replace the SD Memory Card.

8-4-8 List of System-defined Variables Related to SD Memory Cards

The following system-defined variables show the status of the SD Memory Card.

Variable name	Meaning	Description	Data type
_Card1Ready	SD Memory Card Ready	TRUE when the SD Memory Card is recognized. It is FALSE when an SD Memory Card is not recognized.	BOOL
	Flag	TRUE: The Card can be used.	
		FALSE: The Card cannot be used.	
_Card1Protect	SD Memory	TRUE when the SD Memory Card is write-protected.	BOOL
	Card Write	TRUE: Write protected.	
	Protected Flag	FALSE: Not write protected.	
_Card1Err	SD Memory	TRUE when an unusable SD Memory Card is inserted or a format	BOOL
	Card Error	error occurs.	
	Flag	TRUE: There is an error	
		FALSE: There is no error	
_Card1Access	SD Memory	TRUE during SD Memory Card access.	BOOL
	Card Access	TRUE: Card is being accessed.	
	Flag*1	FALSE: Card is not being accessed.	
_Card1Deterio-	SD Memory	TRUE when the end of the life of the SD Memory Card is detected.	BOOL
rated	Card Life	TRUE: The end of the life of the Card is detected.	
	Warning Flag	FALSE: The end of the life of the Card was not detected.	
_Card1Power- Fail	SD Memory Card Power	TRUE when the power supply to the Controller was interrupted during access to the SD Memory Card.	BOOL
	Interruption	TRUE: Power was interrupted during SD Memory Card access.	
	Flag*2	FALSE: Operation is normal.	

^{*1} Precaution When Using SD Memory Card Access Flag (_Card1Access) The SD Memory Card Access Flag is intended for use in notifying external devices. The status of access to the SD Memory Card is not updated in realtime. Because of this, do not use the flag in the user program. Because the status of access to the SD Memory Card is not shown in realtime, it may cause unexpected Controller operation if you use it in the user program.


Note Refer to 9-2 SD Memory Card Backups for the system-defined variables that are used with the SD Memory Card backup function.

^{*2} Precautions When Using the SD Memory Card Power Interruption Flag (_Card1PowerFail) If the SD Memory Card Power Interruption Flag is TRUE, check to see if the correct file is in the SD Memory Card and to see if the SD Memory Card operates properly. If the correct file is missing or the SD Memory Card does not operate properly, download the correct file to the SD Memory Card again. Cycle the power supply to the Controller or reset the Controller, and then see if the SD Memory Card operates properly. When you are finished, change SD Memory Card Power Interruption Flag to FALSE. (_Card1PowerFail does not change to FALSE automatically.)



Additional Information

SD Memory Card Recognition and Unmounting Timing Chart



8-4-9 SD Memory Card Self-diagnostic Functions

You can perform self-diagnosis on the inserted SD Memory Card when the power supply is turned ON.

You can select whether to perform self-diagnosis when the power is turned ON in the Operation Settings of the Controller Setup under the Configurations and Setup from the Sysmac Studio as shown below.

- · File system check
- · Check equivalent to CHKDSK
- · Restoration attempt when check fails

Access point	Setting group	Setting	Description	Set val- ues
Operation Settings, Operation Settings Tab, Basic Settings	SD Memory Card Settings	Memory Card Diagnosis at Startup *1	Sets whether to execute self-diagnosis (file system check and restoration) on the inserted SD Memory Card when the power is turned ON.	Do not check. Check.

^{*1} Self-diagnosis is not executed if write protection is set on the SD Memory Card itself.

Results of Self-diagnosis

Case		Indicators		Error tuno	Correction	Remarks
Case	RUN	SD PWR	SD BUSY	Error type	Correction	Remarks
Self-diagnosis in progress	Flashing.	Not lit.	Lit.			
When self-diag- nosis found no problems		Lit.	Not lit.	Normal	None	
2. The format of the SD Memory Card is not cor- rect.		Not lit.	Not lit.	Observa- tion	Use the Sysmac Studio to format the SD Memory Card.	
3. An error was detected during the file system check and the file system was automatically restored.		Not lit.	Flashes during restore operation. Not lit after restore operation is completed.	Observa- tion	Use file operations in the Sysmac Studio or insert the SD Memory Card into the computer to check whether any files were deleted by the restore operation.	If a cor- rupted file is detected, an attempt is made to restore the file.
4. The SD Mem- ory Card failed.		Not lit.	Not lit.	Observa- tion	Replace the SD Memory Card.	



Precautions for Correct Use

If the recovery function is activated at startup, time is required to enter RUN mode. During that time, outputs will be OFF and external communications are not performed. Use the RUN output on the Power Supply Unit, for example, to implement fail-safe circuits so that external devices do not operate incorrectly.



Precautions for Safe Use

Never interrupt the power supply to the Controller during SD Memory Card access. That includes when SD Memory Card self-diagnosis at startup is enabled. An attempt is made by the SD Memory Card restoration function to restore any corrupted files. If the restoration fails, these files may be deleted automatically at startup.

8-4-10 Exclusive Control of File Access in SD Memory Cards

Access to files on the SD Memory Card is possible with the following methods.

- (1) FTP server
- (2) SD Memory Card operation instructions
- (3) FTP client communications instructions
- (4) File operations from the Sysmac Studio

However, if the same file on the SD Memory Card is accessed from different sources, unintended operations such as reading a file while it is being written or writing a file while it is being read may occur.

It is necessary to perform exclusive controls in order to prevent multiple accesses to the same file.

The following table shows the combinations of operations that require exclusive controls.

When you use a combination of operations that requires exclusive controls, execute the later processing only after checking that the first processing is finished.

			First access					
			Instructions*1		File Operations from the Sysmac Studio		FTP server	
			Reading	Writing	Reading	Writing	Reading	Writing
Later access	Instruc-	Read- ing formed auto an error occ instruction tl		Exclusive control is per- formed automatically, and an error occurs for the instruction that is executed		Perform exclusive control.	Exclusive control is not required.	Perform exclusive control.
SS	lions	Writ- ing	later.		Perform exclusive control.		Perform exclusive control.	
	File operations from the	Read- ing	Exclusive control is not required.	Perform exclusive control.			Exclusive control is not required.	
	Sysmac Studio	Writ- ing	Perform exclu	usive control.			Perform exclusive control.	
	FTP server	Read- ing	Exclusive control is not required.	Perform exclusive control.	Exclusive control is not required.	Perform exclusive control.		
		Writ- ing	Perform exclu	usive control.				

^{*1} The instructions include the SD Memory Card operation instructions and the FTP client communications instructions.

Security 8-5

This section describes the security functions that are supported by the NJ/NX-series Controller.

To protect your assets, you can use security functions to protect the user program and data in the Controller. To prevent incorrect operation, you can use security functions to restrict operations on the Sysmac Studio.

The NJ/NX-series Controller supports the following security functions.


Application	Security function	Outline of function	Reference
Prevention of the theft of assets	Authentication of user program execution IDs	This ensures that a user program cannot be operated on another CPU Unit even if the user program is copied.	8-35
	User program trans- fer with no restoration information	You can transfer the user program to the CPU Unit without the source code. This prevents anyone from displaying the user program on another computer even if they upload it.	8-38
	Overall project file protection	You can place a password on a project file to protect your assets.	8-39
	Data protection*	You can place protection on part of the data in a project file to protect your assets.	8-40
Prevention of incor- rect operation	Operation authority verification	You can set operation authorities to restrict the operations that can be performed on the CPU Unit from the Sysmac Studio.	8-42
	CPU Unit write protection	You can prevent rewriting data in the Controller from the Sysmac Studio.	8-44
Prevention of incor- rect connections	CPU Unit names	You can check to see if the CPU Unit name and serial ID on the computer and in the Controller are the same to prevent going online with the wrong Controller.	8-45

^{*} A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required.

8-5-1 Authentication of User Program Execution IDs

Introduction

You can set a specific ID (called a user program execution ID) in the CPU Unit in advance. If you do, you can execute only a user program with the same ID.




You can therefore prevent different CPU Units (hardware) from executing a user program.

In contrast to the protection function, you can still display and edit the user program even if a user program execution ID is set.

Operating Procedure

- **1** Always backup the project files before you assign a user program execution ID.
- **2** Assign the user program execution ID to the user program offline from the Sysmac Studio.





Precautions for Correct Use

After you assign a user program execution ID to a user program, you cannot change or delete the ID. To use a different ID, read the project file without an ID that was backed up in step 1, above, and assign another user program execution ID. To delete the ID, use the project file without an ID that was backed up in step 1, above.

Connect the Sysmac Studio online and register the user program execution ID that was set in step 2 in the CPU Unit.



The registration of the user program execution ID in the CPU Unit is recorded in the event log. At this time, the user program execution ID in the CPU Unit is overwritten even if it is already registered.

4 Transfer the user program with the same user program execution ID to the CPU Unit.

If the user program execution ID in the user program does not match the user program execution ID in the CPU Unit or if one of them does not have an ID, an ID Verification Error (major fault level Controller error) occurs when you attempt to change to RUN mode and the CPU Unit will not operate.



Precautions for Correct Use

After you assign a user program execution ID to the CPU Unit, you cannot read or delete the ID. To delete the ID from the CPU Unit, perform the Clear All Memory operation on the CPU Unit.

Operation When an ID Verification Error Occurs

When the User Program Execution ID in the CPU Unit Is Incorrect or Not Registered:

Connect online to the CPU Unit from the Sysmac Studio and perform the following steps.

- Overwrite or register the correct user program execution ID in the CPU Unit.
- Cycle the power supply to the Controller, or reset the CPU Unit from the Sysmac Studio.

When the User Program Execution ID Is Not Assigned to the User Program or Is Incorrect

- Read the backed up project file from the Sysmac Studio, and assign the correct user program execution ID.
- 2 Connect the Sysmac Studio to the CPU Unit online and transfer the user program.
- Cycle the power supply to the Controller, or reset the Controller from the Sysmac Studio.

Other Situations

To Delete the User Program Execution ID Assigned to the User Program:

Read the backed up project file in the Sysmac Studio.

To Delete the User Program Execution ID from the CPU Unit:

Connect the Sysmac Studio to the CPU Unit online and perform the Clear All Memory operation.

To Check the User Program Execution ID Assigned to the User Program:

For security, the user program execution ID that is assigned to the user program cannot be checked from the Sysmac Studio. Read the backed up project file in the Sysmac Studio and set the user program execution ID again.

To Check the User Program Execution ID in the CPU Unit:

For security, the user program execution ID that is set in the CPU Unit cannot be checked from the Sysmac Studio. Perform the Clear All Memory operation and register the correct user program execution ID.

Specifications

User Program Execution ID Verification Specifications

Timing of Verification

At startup, the CPU Unit compares the user program execution ID that is registered in the CPU Unit with the user program execution ID that is assigned to the user program.

Verification Conditions

The conditions for verifications are given in the following table.

"A" and "B" indicate the IDs.

User program execution ID that is registered in the CPU Unit	User program execution ID that is assigned to the user program	Error	Operation
A	А	None	Possible
None	None		
None	A	ID Verification Error	Not possible.
A	None		
A	В		

Operation When the IDs Do Not Match

When the IDs do not match, an ID Verification Error (major fault level Controller error) occurs, and the CPU Unit does not operate. However, to reset the error you must cycle the power supply to the Controller or reset the Controller from the Sysmac Studio.

User Program Execution ID Character Specifications

Usable characters	Case sensitivity	Maximum size (without NULL)
0 to 9, A to Z, and a to z	Case sensitive	8 to 32 characters


User Program Transfer with No Restoration Information 8-5-2

You can transfer the user program to the CPU Unit without the source code. This prevents anyone from displaying the user program on another computer even if they upload it.

Introduction

Normally, when you transfer the user program from the Sysmac Studio to the CPU Unit, information is transferred to restore it.

This function does not transfer information for restoration. That makes it impossible to read the user program.



This function is used to prevent theft of user program data when on-site maintenance of the user program is not required.

Operating Procedure

When you transfer the user program to the CPU Unit, select the Do not transfer program source Check Box in the Synchronization Window of the Sysmac Studio and then click the Transfer to Controller Button.


- Clear the present values of variables with Retain attribute (Valid for Transfer to Controller).
- 🔽 Do not transfer the program source (Valid for Transfer to Controller). All data will be re-transferred when this option is changed.
- Do not transfer Special Unit parameters and backup parameters of EtherCAT slaves (out of synchronization scope).

8-5-3 Overall Project File Protection

You can place a password on a project file to protect your assets.

Operating Procedure

This section describes how to set a password for a project. When you use **Save As** to save the project file, select the *Enable password protection for the project file* Check Box to enable setting a password.



Use the following procedure to open a project for which a password is set. If you try to open or import a project file for which a password is set, the Enter a Password Dialog Box is displayed.



Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

8-5-4 **Data Protection**

You can place protection on part of the data in a project file to protect your assets.



Version Information

A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required to use data protection.

Introduction

You can place protection on part of the data in a project file to restrict access to that data. You can select any of three levels of access restrictions when you set protection. Protection must be temporarily cleared to access the restricted data. The length of time for which protection is cleared depends on the operation that you use.

Protected Data

Protection can be set for the following data. Only change protection can be set for cam profiles.

- Ladder diagrams (applies to programs, functions, and function blocks)
- ST (applies to programs, functions, and function blocks)
- · Cam profiles

Levels of Access Restrictions

You can select one of the following levels of access restrictions.

- · Prohibiting copying, displaying, and changing the data
- · Prohibiting displaying and changing the data
- · Prohibiting changing the data


The following table shows the data access methods, restrictions for each restriction level, and the length of time that protection is cleared.

	Levels of access restrictions				
Data access operation	Prohibiting copying, displaying and changing the data Prohibiting displaying changing the data Prohibiting displaying changing the data		Length of time that pro- tection is cleared		
Displaying the data	Restricted.	Restricted.	Not restricted.	While the project is open	
Printing the data	Restricted.	Restricted.	Not restricted.		
Changing the data	Restricted.	Restricted.	Restricted.		
Copying the data	Restricted.	Not restricted.	Not restricted.	Protection must be tem- porarily cleared for each operation	
Displaying basic comparison results	Not restricted.	Not restricted.	Not restricted.	This operation is not restricted.	
Displaying detailed comparison results	Restricted.	Restricted.	Not restricted.	While the project is open	
Jumping from an event log or cross-reference to the data	Restricted.	Restricted.	Not restricted.		
Registering objects in a library	Restricted.	Not restricted.	Not restricted.	Not possible to clear protection temporarily.	

Operating Procedure

This function is used when the Sysmac Studio is offline. The settings are saved in the project file. When you use the synchronization function of the Sysmac Studio to transfer the project, the data protection settings in the data in the computer or Controller are transferred to Controller or computer.

Select **Security** – **Set/Release Data Protection** from the Controller Menu of the Sysmac Studio to set protection.



Select **Security** – **Temporarily Change Prohibition of Data Protection** from the Controller Menu of the Sysmac Studio to temporarily clear protection.



Select **Security** – **Finish Temporary Change Prohibition of Data Protection** from the Controller Menu of the Sysmac Studio to end temporary change protection.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

Operation Authority Verification 8-5-5

Introduction

Online operations are restricted by operation rights to prevent damage to equipment or injuries that may be caused by operating mistakes. Examples are shown below.

- I/O Monitor: Writing, forced refreshing, etc.
- Controller operations: Changing the operating mode, online editing, MC Test Run, etc.

You can register passwords for operation authority for each CPU Unit in the Sysmac Studio. If a correct password is entered when an online connection is made to a Controller, the online operations for the operation authority category for the password that was entered will be allowed.

The Administrator sets a password for each operation authority. Users are notified of the operation authority name and password according to their skills.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific operating procedures for operation authorities.

Operation

For operation authority verification, select Security - Setting of Operation Authority from the Controller Menu on the Sysmac Studio.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

Specifications

Types of Operation Authorities

You can use the following five operation authorities on the Sysmac Studio. They are given in descending order of authority.

English name	Password
Administrator	Required.
Designer*1	Optional*2
Maintainer*1	Whether a password is required is determined by the default operation authority that is set in the
Operator*1	Setting of Operation Authority Dialog Box. The default operation authority is used when a password is not input.
Observer*1	Not required.

- *1 A CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher are required.
- *2 Whether a password is required is determined by the default operation authority that is set in the Setting of Operation Authority Dialog Box. A password must be entered to perform operations that require an operation authority that is higher than the default operation authority. A password is not required to perform operations that require an operation authority that is equal to or lower than the default operation authority.

Examples of Online Operations for Operation Rights

Examples of the online operations that are allowed for each operation authority are given below. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details.

OK: Operation possible, VR: Verification required for each operation, NP: Operation not possible

Status monitor (example)	Adminis- trator	Designer	Main- tainer	Operator	Observer
Monitoring errors for troubleshooting	OK	OK	OK	OK	OK

I/O monitor operations (examples)	Adminis- trator	Designer	Main- tainer	Operator	Observer
I/O monitor: Reading	OK	OK	OK	OK	NP
I/O monitor: Writing	OK	OK	OK	VR	NP
Controlling BOOL variables	OK	OK	OK	VR	NP
Forced refreshing	OK	OK	OK	NP	NP

Controller operations (examples)	Adminis- trator	Designer	Main- tainer	Operator	Observer
RUN mode/PROGRAM mode	OK	OK	VR	NP	NP
Online editing	OK	OK	VR	NP	NP
Resetting the Controller	OK	OK	NP	NP	NP
Resetting errors (troubleshooting)	OK	OK	OK	VR	NP
Starting or restarting an MC Test Run	OK	OK	VR	NP	NP
User program execution IDs for Controllers	OK	NP	NP	NP	NP
CPU Unit write-protection	ОК	OK	OK	NP	NP

Password Specifications


Item	Description		
Valid number of characters	8 to 32		
Applicable characters	Single-byte alphanumeric characters (case sensitive)		

CPU Unit Write Protection 8-5-6

This function disables the ability to write data to CPU Units to protect user program assets and prevent misuse.

Controller Write Protection at Startup

This setting automatically enables write protection when you turn ON the power supply to the Controller.




Set whether to automatically enable write protection when the power supply is turned ON in the Operation Settings under Configurations and Setup - Controller Setup of the Sysmac Studio.

Access point	Setting group	Setting	Description	Set values
Operation Settings, Operation Settings Tab, Basic Settings	Security Settings	Write Protection at Startup	Sets whether to enable write protection.	Do not use. Use.

Setting and Removing Write Protection from the Sysmac Studio


In the Sysmac Studio, go online and select Security - CPU Unit Write Protection from the Controller Menu to toggle write protection.



8-5-7 CPU Unit Names and Serial IDs

Introduction


Register a CPU Unit name in the CPU Unit. When going online to a CPU Unit from the Sysmac Studio, the CPU Unit name in the project is compared to the name of the CPU Unit being connected to. This helps prevent incorrect connections to the CPU Unit from the Sysmac Studio. It is particularly effective for operations performed over an EtherNet/IP network.



In addition to the CPU Unit name, it is also possible to use serial ID identification based on the CPU Unit production information (optional).

Setting Methods

1 Set the CPU Unit name when you create a project on the Sysmac Studio. The CPU Unit name is displayed as shown below.



To change the name, right-click the Controller icon and select *Rename*.

- When you first connect to the CPU Unit online, the Sysmac Studio prompts you to store the CPU Unit name in the CPU Unit.
- After that, when you connect to the CPU Unit online, the Sysmac Studio refers to the CPU Unit name in the project and the CPU Unit name of the CPU Unit you connect to. A warning dialog box is shown if they do not match, and you are asked whether to continue to connect.




Additional Information

You can name EtherNet/IP ports in the Network Configurator.

Serial IDs

When the Sysmac Studio first connects online, you can obtain the serial ID from the CPU Unit's production information and store it in the project. After that, when the Sysmac Studio connects online, both the CPU Unit name and the serial ID are compared. This enables stricter verification of the CPU Unit.



8-6 Debugging

This section describes debugging.

The NJ/NX-series Controller provides the following debugging operations.

- · Forced refreshing
- · Changing present values
- · Online editing
- · Data tracing
- · Differential monitoring


8-6-1 Forced Refreshing

Description

Forced refreshing allows the user to refresh external inputs and outputs with user-specified values from the Sysmac Studio to debug the system. Forced refreshing is executed not for the specified device variables, but for the I/O ports that are assigned to the device variables. The state that is specified with forced refreshing is retained until forced refreshing is cleared from the Sysmac Studio. (Refer to *Hold-ing/Clearing Forced Refreshing* on page 8-50 for information how forced refreshing is retained or cleared according to changes in CPU Unit status.) All forced refreshing is cleared when a fatal error occurs, when a Clear All Memory operation is performed, when the operating mode is changed, when power is interrupted, or when the project is downloaded.

Inputs


The I/O port and device variable change to the status that is specified with forced refreshing regardless of the status of the external input.



(2) I/O port and device variable change to TRUE.

Outputs

The I/O port and the output to the external device change to the status that is specified with forced refreshing. In the user program, the status of the device variable that is assigned to the I/O port will not necessarily be the status that was specified with forced refreshing. It will change with the results of user program execution.



(2) The I/O port and the output to the external device change to TRUE. The device variable changes with the result of user program execution.

Applicable Areas

You can execute forced refreshing for the following I/O ports and memory used for CJ-series Units.

- I/O ports for EtherCAT slaves
- I/O ports from data handled by the NX Bus Function Module of the NX102 CPU Unit and NX1P2 CPU Unit
- I/O ports for I/O built in the NX1P2 CPU Unit
- I/O ports for Analog I/O Option Boards in the NX1P2 CPU Unit
- I/O ports for CJ-series Basic I/O Units
- I/O ports for CJ-series Special Units
- I/O bits for DeviceNet or CompoNet slaves that are specified for AT specifications from variables

If you execute forced refreshing from the Ladder Editor or the Watch Tab Page, the status of the I/O port or memory element for a CJ-series Unit will change via the variable.

Note For I/O ports from data handled by the NX Bus Function Module of the NX102 CPU Unit and NX1P2 CPU Unit, only the I/O ports for I/O data for individual NX Units are applicable. The I/O ports for status of NX Units managed by the NX Bus Function Module as the NX bus master are not applicable.

Note You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

Number of Simultaneous I/O for Forced Refreshing

The number of variables that you can refresh with forced refreshing is listed below.

- · CJ-series Units: 64 points total
- · EtherCAT slaves: 64 points total

The number of external I/O points are given for the above limits. For example, if more than one variable is assigned the same external I/O point as the AT specifications, it is counted as only one point.

Application

Inputs

- To apply a simulated input signal to debug the user program
- To create a status that would occur only when a failure occurs (e.g., two exclusive bits turning ON or OFF at the same time)

Outputs

- · To turn outputs ON and OFF to check wiring
- To intentionally turn OFF an output you do not want to operate regardless of results of user program execution

Operating Procedure

Operations can be performed from the following panes.

- Program Panes (Ladder diagram language)
- I/O Map
- · Watch Tab Page

Procedure for Forced Refreshing from Ladder Editor

- **1** Select *Monitor* from the Controller Menu. The monitor turns ON.
- **2** Double-click the ladder program, ladder function, or ladder function block under **Programming** in the Multiview Explorer.

The rungs are displayed on the Ladder Editor in monitor status.

- Right-click the input or output and select *Forced Refreshing TRUE*. The input or output is forced to TRUE. Right-click the input or output and select *Forced Refreshing FALSE*. The input or output is forced to FALSE.
- **4** The input or output in the Ladder Editor changes to TRUE or FALSE and the execution condition changes accordingly.

A mark that indicates that the input or output has forced status is displayed as shown below.



Ladder diagram

The TRUE or FALSE mark for forced status indicates the status that was specified for forced refreshing. It does not indicate the current value of the input or output.

Forced status mark	Operation
T	TRUE specified with forced refreshing
	FALSE specified with forced refreshing



Additional Information

If there are other variables that are assigned the same memory address as one that is specified as the AT specification of a variable for which forced refreshing is specified, the forced status mark is displayed for all of the variables with that AT specification.

Affect of Operating Modes and Power Interruptions

Operating Modes for Forced Refreshing

You can execute forced refreshing in either PROGRAM mode or RUN mode. Forced refreshing is not possible while there is a major fault level Controller error.

Status of Forced Refreshing during Operating Mode Changes or Power Interruptions

By default, the forced refreshing is cleared when the operating mode changes between RUN mode and PROGRAM mode and when the power is interrupted.

Holding/Clearing Forced Refreshing


Forced refreshing is retained and cleared according to changes in the status of the CPU Unit as shown below.

Change in status		Forced refreshing status
When power is turned ON		Cleared
When operating mode changes	RUN to PROGRAM mode PROGRAM to RUN mode	Cleared
After downloading		Cleared
When a major fault level Controller error occurs		Cleared
During online editing		Retained


Programming Precautions for Forced Refreshing

If forced refreshing is set in the user program, the status of variables for which forced refreshing is specified are overwritten by the user program. Therefore, the status that is specified for forced refreshing is not maintained in the user program. However, refreshing to external devices uses the values that were specified for forced refreshing, and not the status of the variables in the user program. If forced refreshing is used in a program, the values of variables in the program may be different from the status of the external outputs.

Example: When a Is Refreshed to TRUE with Forced Refreshing



When There Is Another Input that is Controlled by the Forced Input





Precautions for Safe Use


- · Confirm that no adverse effect will occur in the system before you use forced refreshing.
- Forced refreshing ignores the results of user program execution and refreshes I/O with the specified values. If forced refreshing is used for inputs for which I/O refreshing is not supported, the inputs will first take the specified values, but they will then be overwritten by the user program.

Depending on the difference in the forced status, the control system may operate unexpectedly.

8-6-2 **Changing Present Values**

Description

You can change the present values of variables that are used in the user program and settings and you can change program inputs and outputs to TRUE or FALSE. This allows you to check the operation of the user program and settings.





Precautions for Safe Use

Always confirm the safety of the system before you change the present value of a variable.

Application

Changing Program Inputs and Outputs to TRUE or FALSE

You can change the value of any BOOL variable to TRUE or FALSE. The specified value is then overwritten by the execution results of the user program. If the operating mode is changed or the power supply is cycled, the initial value is restored. You can control BOOL variables in the Ladder Editor, Watch Tab Page, or I/O Map.

Changing the Values of Other Variables

You can change the present values of user-defined variables, system-defined variables, and device variables as required. You can do this on a Watch Tab Page.



Precautions for Safe Use

Always confirm the safety of the system before you change the present value of a variable.

Operating Procedure

Operations can be performed from the following panes to change the present values. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details on the operating procedures on the panes.

- Program panes (ladder diagrams and ST)
- I/O Map
- · Watch Tab Page

Precautions on Changing the Status of Outputs Assigned to External Devices by Changing Present Values

Observe the following precautions when you change the status of an output that is assigned to an I/O port of a CJ-series Basic Output Unit or EtherCAT output slave by changing a present value.

Changing Present Values in the I/O Map in RUN Mode

Any value of an I/O port that is changed in the I/O Map is then overwritten by the execution results of the user program. The value that was specified by changing the present value is not output to the external device. To change the value of an I/O port and output that value to an external device, use forced refreshing.

Changing Present Values in a Watch Tab Page in PROGRAM Mode

The value that was specified in a Watch Tab Page by changing the present value of a device variable* that is defined as an external or local variable is not output to the external device. To output a specified value to an external device, do one of the following:

- · Use forced refreshing.
- Change the present value in a Watch Tab Page of a device variable* that is defined as a global variable.
 - * The devices variables must be assigned to an I/O port of a CJ-series Basic Output Unit or EtherCAT output slave. This also applies to a global variable with an AT specification to an output bit that is assigned to a CJ-series Basic Output Unit.

Precaution When Directly Writing to I/O Memory Addresses Assigned to Output Bits for CJ-series Basic Output Units

Any value that is written to an I/O memory address that corresponds to an output bit that is assigned to a CJ-series Basic Output Unit through a tag data link will be overwritten by the execution results of the user program. The value that is written directly to the I/O memory address from the tag data link will therefore not be output to the external device.

Note You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

8-6-3 **Online Editing**

This section introduces online editing. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details.

Introduction

The online editing function is used to add to or change part of a program in the CPU Unit directly from the Sysmac Studio.

You can select any of the following to perform online editing.

- · POUs (programs, functions, and function blocks) For a ladder diagram program, select a section.
- · Global variables

Application

You can use online editing to change a user program without stopping the operation of the CPU Unit.

Sysmac Studio Operations

- Performing Online Editing
 - Select the item to edit online.
 - Select Online Edit from the Project Menu.
 - Make the required changes.
 - Select Online Edit Transfer from the Project Menu.
 - Check the results.
 - The user program will begin operation after online editing.

Caution

Execute online editing only after confirming that no adverse effects will occur if the I/O timing is disrupted. If you perform online editing, the task execution time may exceed the task period, I/O may not be refreshed with external devices, input signals may not be read, and output timing may be changed.





Precautions for Correct Use

- The differentiation status of differentiated instructions in a program that is edited online is initialized.
- When online editing changes are applied, the execution times of the tasks are extended. Set
 the task period appropriately so that you do not cause a Task Period Exceeded error due to
 online editing.
- If the power supply to the Controller is interrupted when online edits are being saved,* a major fault level Controller error (User Program/Controller Configurations and Setup Transfer Error, Incorrect User Program/Controller Configurations and Setup, or Non-volatile Memory Restored or Formatted) occurs. If one of these errors occurs, download the user program again.
- Do not execute the MC_SaveCamTable instruction while online edits are being saved.* Otherwise the online edits may not be saved correctly.
- * Online edits are saved from when you click the **Yes** Button in the confirmation dialog box until the Online Editing Pane closes. However, with a CPU Unit with a unit version of 1.04 or later and Sysmac Studio version 1.05 or higher, saving continues until the dialog box that indicates saving data to built-in non-volatile memory (which is displayed after the confirmation dialog box) closes.

8-6-4 **Data Tracing**

You can use data tracing to sample variables without any additional programming. You can read and check the data from the Sysmac Studio, and save the data to a file. This is used to start up, operate, and maintain devices.

This section introduces data tracing. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific operating procedures.



Precautions for Correct Use

If you use data tracing to sample following variables, correct data may not be sampled.

- Structure members whose data size is 16 bits or more, except for system-defined variables for motion control
- · Array elements whose data size is 16 bits or more

If you sample the data with the above variables, perform either of the followings.


- Copy the above variables to the internal variables with a basic data type other than a data size of 64 bits, and trace data for the copied variables.
- Use the settings for exclusive control of variables in tasks, and the task for which you use data tracing to sample is set as a refreshing task.

The two tracing methods are described below.

Triggered Tracing

Trigger conditions are set to record data before and after an event. Sampling stops automatically when the maximum number of sampled variables is reached. Even if the Sysmac Studio is not online, you can trace data when trigger conditions are met and then upload the data after placing the Sysmac Studio online.


- · You can check the flow of the program based on the status of changes in the present values of variables.
- You can use the data to investigate the cause of unexpected changes in the values of variables.



When the maximum number of sampled variables is reached, the trace stops and the trace data is sent to the Sysmac Studio and displayed.

Continuous Tracing

Sampling starts without any trigger and continues on even after 10,000 samples are collected. Sample data is transferred to the computer as it is collected and saved to a file. When the display buffer is full, the data is automatically saved to a CSV file. You can use this to store trace results data for a long tracing period in multiple CSV files.



Data Tracing Specifications

The following table gives the specifications of data tracing.

Item		Description	
Tunon of data traces	Single triggered trace	Set a trigger condition to start sampling. Data from before and after the condition is met is saved.	
Types of data traces	Continuous tracing	Sample data is transferred to a computer as it is collected and saved to a file.	
	Period of specified task	Specify a task. The period of that task is set as the sampling period.*1	
Setting of timing of sampling	Specified fixed interval	The time you enter is set as the sampling period. However, the time you enter is rounded off to an integer multiple of the primary periodic task.	
	Trace sampling instruction	With this method, sampling is performed whenever the TraceSamp instruction is executed in the user program.	
Setting sampled data*2	Maximum number of targets	NX701-□□□: 192 variables NX102-□□□: 48 variables NX1P2-□□□: 48 variables NJ501-□□□: 192 variables NJ301-□□□: 48 variables NJ101-□□□: 48 variables	
	Data types	NJ101-□□□□: 48 variables Basic data types except for text strings Arrays (specify the element) Enumerations Members of structures and unions	
Maximum number of rec	ords	10,000 samples per variable	
Setting trigger positions		The trigger position is set in respect to the overall trace time or quantity.	
	Condition data types	Basic data types except for times, durations, dates, and text strings Arrays (specify the element), structures (specify the member), and unions (specify the member)	
	Condition expression*3	Tracing is started when one of the following conditions is met. BOOL: TRUE or FALSE Non-BOOL: Equals (=), Greater than (>), Greater than or equal (\geq), Less Than (<), Less than or equal (\leq), Not equal (\neq)*4	
Setting triggers	Commands from Sys- mac Studio	Tracing starts when the Trigger TRUE Button is clicked.	
	Data Trace Trigger instruction	Tracing starts when the TraceTrig instruction is executed.	
	Evaluation timing	 If something other than the TraceSamp instruction is used to set the timing of sampling, the trigger is evaluated only once in the specified task period. If the TraceSamp instruction is used to set the timing of sampling, the trigger is evaluated whenever the instruction is executed. 	
	Delay	A slider is used to set the percentage of sampling before and after the trigger condition is met. (Example: 20%/80%)	


Ite	em	Description
	Commands from Sys- mac Studio	Tracing is started when the Execute Button is clicked on the Sysmac Studio.
Starting a trace	Starting tracing at start of operation	Tracing can be started when operation of the Controller starts (i.e., when the operating mode is changed from PROGRAM mode to RUN mode).
	Triggered traces	 Tracing stops when the maximum value of 10,000 samples is reached. Tracing is stopped when the Stop Button is clicked on
Stopping a trace	Continuous traces	 the Sysmac Studio. If stopping tracing is set as the operation to perform when the maximum number of samples is reached, tracing stops when the maximum number of samples or maximum amount of time is reached. Tracing is stopped when the Stop Button is clicked on the Sysmac Studio.
	Maximum data storage period	You can set the maximum amount of time to save continuous trace data.
	Maximum data storage size	You can set the maximum total size of all files saved during continuous tracing.
	Data items per file	You can set the number of samples to save in each file during a continuous trace.
Setting continuous tracing	File save location	You can specify the location to create files to save data during a continuous trace.
	File name prefix	You can specify a prefix to automatically add to the beginning of the file names.
	Setting of operation when limit is reached	You can specify the operation to perform when the storage time period or size limit is reached. • Stopping the trace • Deleting the oldest files and continuing
	Graph display	You can display a graph where the X axis represents time and the Y axis represents the value of the variable. You can display both BOOL variables and other variables on the same graph.
Displaying trace results	Table display	You can display the maximum value, minimum value, average value, and value at the specified time for each variable in a table.
	3D Motion Monitor Display Mode	You can position a virtual composition model in 3D space and display the composition motion based on the command positions and actual positions of the motion axes.
Exporting trace data	Exporting to CSV files	You can save the trace results and all settings other than the trace number to a CSV file.
Number of data traces that can be executed simultaneously*5		NX701-□□□: 4 traces NX102-□□□: 2 traces NX1P2-□□□: 2 traces NJ501-□□□: 4 traces NJ301-□□□: 2 traces NJ101-□□□: 2 traces
Importing trace data		You can display CSV format trace results on top of the current graph.
Saving		You can save the trace results in the project along with the trace settings.
Printing		You can print graphs. The Sysmac Studio's printing functionality is used.

- *1 For an NJ-series CPU Unit and NX701 CPU Unit, if you perform an internal variable with a data size of 64 bits or more to the sampled data, specify the task that assigns the program in which the target internal variable is defined. If the different task is specified, the concurrency of variable values may not be ensured.
- *2 You cannot perform data traces for the EN, ENO, P_off, P_on, P_CY, P_First_RunMode, P_First_Run and P_PRGER system-defined variables, in-out variables that are used in function block instances, and variables in functions.
- *3 Data tracing will not start at the data trace starting point even if the trigger condition is met.
- *4 Combinations of multiple condition expressions are not permitted. Also, the valid range for comparison constants is determined by the valid range of the literal expressions for the variable type on the left side of the condition expression.
- *5 Trace numbers 0 to 3 are set for the NX701 and NJ501. Trace numbers 0 and 1 are set for the NX102, NX1P2, NJ301, and NJ101. These numbers are used to execute instructions and to access system-defined variables.

Data Trace Operation

Processing for data traces (sampling and trigger detection) are performed in System Common Processing 1, between I/O refreshing and user program execution.

Example: If sampling is specified in the primary periodic task, data tracing is executed in System Common Processing 1, as shown in the following diagram.



Display examples for data trace operations and execution results is given below for sampling in a specified task period.




Additional Information

I/O refreshing, user program execution, and motion control processing are all executed in the same task period. For data tracing, user program execution and motion control processing for the current task period and I/O refreshing for the next task period are displayed at the same time. The timing charts in the NJ/NX-series Motion Control Instructions Reference Manual (Cat. No. W508) are based on the task periods, so the display are not the same as those for data tracing.

Example 1:

In this example, the *SysRun* variable is changed to TRUE in the user program when the *Sensor1* variable (assigned to the sensor input signal) changes to TRUE.




The data trace operations and display of the execution results are given below.

- 1. In data trace processing in System Common Processing 1, TRUE is obtained for Sensor1.
- 2. SysRun is changed to TRUE in the user program.
- 3. In data trace processing in System Common Processing 1 in the next primary period, TRUE is obtained for *SysRun*.

Therefore, in the data trace display, SysRun is shown as TRUE one task period after Sensor1.

Data Trace Display






Additional Information

If the values of variables change during user program execution, the changes in the values and changes for output processing for I/O refreshing are changed in the same task period.

Example 2:


When the *Button2* variable (assigned to an input signal from a pushbutton) changes to TRUE during velocity control, the user program in this example decelerates axis 0 (*MC_Axis000*) to a stop.



The data trace operations and display of the execution results are given below.

- 1. In data trace processing in System Common Processing 1, TRUE is obtained for Button2.
- 2. STP_BSY is changed to TRUE in the user program and the Motion Control Function Module performs deceleration processing.
- 3. In data trace processing in System Common Processing 1 in the next primary period, TRUE is obtained for *STP_BSY* and the status of the motion variable is obtained.
- 4. *STP_ACT* is changed to TRUE in the user program.
- 5. In data trace processing in System Common Processing 1 in the next primary period, TRUE is obtained for *STP_ACT*.

The command value in the MC Function Module starts changing (B in the following diagram) when STP BSY changes to TRUE in the user program and the Motion Control Function Module starts to perform deceleration processing. The command value changes stepwise in synchronization with the primary periodic task. The data trace, however, interpolates the values to connect the values for the previous and current periods. Therefore, the display shows that the command value for the Command Velocity motion control variable (MC Axis000.Cmd.Vel) changes one period early, i.e., when Button2 changes to TRUE (A in the following figure). The display also shows that STP_BSY changes to TRUE one period after deceleration starts and then STP_ACT changes to TRUE after another period.





Additional Information

For function blocks that contain motion control instructions, the values of input parameters are passed to the input variables when execution of the function block starts, and the values of the output variables are passed to the output parameters when execution of the function block ends. (Refer to Variable Designations for Function Blocks on page 6-11.) On the data trace displays, input parameters and input variable, and output parameters and output variables, change in the same task period.

Related System-defined Variables


Varia	ble name	Meaning	Description	Data type	R/W
	Member	Modring	Becompacin	Data type	1000
_PLC_Tr	raceSta[03] *			_sTRACE_STA	R
	.lsStart	Trace Busy Flag	TRUE when a trace starts.	BOOL	R
	.lsComplete	Trace Completed	TRUE when a trace is completed.	BOOL	R
		Flag	Changes to FALSE when the next trace starts.		
	.lsTrigger	Trace Trigger Monitor Flag	TRUE when the trigger condition is met. Changes to FALSE when the next trace starts.	BOOL	R
	.ParamErr	Trace Parameter Error Flag	Changes to TRUE when a trace starts if there is an error in the trace settings. FALSE when the settings are normal.	BOOL	R

^{*} These numbers correspond to the data trace numbers 0 to 3.

Note You cannot use these system-defined variables in the user program. Use the GetTraceStatus instruction to read the status of data tracing from the user program.

8-6-5 Differential Monitoring

Differential monitoring reports the number of times the value of the specified BOOL variable matches the specified condition. The specified condition is evaluated for a match in every task period of the primary periodic task (called the primary period). Differential monitoring provides a running total of the number of times the condition is matched.





Version Information

A CPU Unit with unit version 1.03 or later and Sysmac Studio version 1.04 or higher are required to use differential monitoring.

Application

You can use differential monitoring to check or count the number of times an external input signal turns ON or OFF or a input in the user program changes to TRUE or FALSE. This is useful during system commissioning and for troubleshooting operation failures during production.

Specifications of Differential Monitoring

The specifications of differential monitoring are given in the following table.

Ite	m	Specification
Differential monitoring	Number of variables	8 max.
condition	Specified variables	• BOOL
		Element of BOOL array
		BOOL member of structure or union
	Condition expres-	Change to TRUE
	sion	Change to FALSE
Conditional match	Timing	Once every primary period
evaluation	Match count	The number of times the specified variable matches the condition is counted.
Starting and stopping	Start condition	Command from Sysmac Studio
	Stop condition	Command from Sysmac Studio
		Occurrence of a major fault level Controller error
		User program download
		Clear All Memory operation
		Disconnecting online connection to Sysmac Studio
Operating modes		RUN mode
		PROGRAM mode

Differential Monitoring Conditions

The variables and the changes that you can monitor with differential monitoring are called differential monitoring conditions. The specifications for the differential monitoring conditions are described below.

Number of Variables

You can specify a maximum of eight variables. This means differential monitoring can detect the numbers of times conditions are met for eight variables in parallel.

Specified Variables

The data types of the variables that you can specify for differential monitoring are given below.

- BOOL
- · Elements of BOOL arrays
- · BOOL members of structures or unions

You cannot specify an array, structure, or union.

The types of variables that you can specify are listed below.

	Specification	
System-defined variables		Possible.*1
Semi-user-defined va	ariables	Possible.
User-defined variables	Global variables	Possible.
	Variables used in a program	Possible.
	Variables used in a function block	Possible.*2
	Variables used in a function	Not possible.

^{*1} The following variables cannot be used: EN, ENO, P_Off, P_CY, P_First_RunMode, P_First_Run, and P_PRGER.

^{*2} In-out variables cannot be used.

Condition Expressions

The condition of the change in the variable to detect is called the condition expression. There are two types of condition expressions that you can select from. You specify a condition expression for each variable.

- Change to TRUE
- Change to FALSE



Precautions for Correct Use

For example, we will assume the condition expression was set to a change to TRUE. Even if the value of the specified variable is TRUE when differential monitoring is started, the status of the value of the variable is not detected as a change to TRUE. The value of the variable must first change to FALSE and then to TRUE to be considered as a change to TRUE.

When Conditions Are Evaluated and the Match Count

The condition for the specified variable is evaluated every primary period. The value of the variable from the previous evaluation is compared with the value of the variable for the current evaluation. If the value of the variable that matches the specified condition has changed, the count is incremented.

- The number of times a condition match occurs is counted separately for each variable.
- The count values are reset to zero when differential monitoring is started.
- The count value for just one variable cannot be reset to zero.



Precautions for Correct Use

- Even if the value changes to match the condition expression more than one time within the same primary period, the count will be incremented only once in each primary period.
- If the values of the variable are the same at the time of the previous and current evaluations, the condition is not considered to be a match, even if the value changed between evaluations.

Start Condition and Stop Condition

Use the Sysmac Studio to start differential monitoring.


Normally, use the Sysmac Studio to stop differential monitoring. Differential monitoring will stop automatically at the following times.

- · When a major fault level Controller error occurs
- · When the user program is downloaded
- · When the Clear All Memory operation is performed
- · When an online connection to the Sysmac Studio is broken

Procedure


Use the following procedures to control differential monitoring. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details.

- Select Differential Monitor from the View Menu on the Sysmac Studio.
- Right-click a variable that can be specified for differential monitoring and select Add Differential Monitor.
- Set the differential monitoring condition expression for each variable in the Differential Monitor Window.



Execute the user program.

The number of times that the condition is met for each variable is displayed in the Differential Monitor Window.



Precautions for Differential Monitoring

Observe the following precautions when you use differential monitoring.

Loss of Communications with Sysmac Studio While Differential Monitoring Is in Progress

Let's assume that communications with the Sysmac Studio were cut off during differential monitoring because the communications cable was disconnected or because the Sysmac Studio ended due to an error. In such cases, the CPU Unit will continue execution of differential monitoring. To restart execution of differential monitoring, you must resume communications with the Sysmac Studio and stop differential monitoring.

Simultaneous Execution of Differential Monitoring


You cannot run differential monitoring from more than one copy of the Sysmac Studio running on the same computer or from the Sysmac Studio running on different computers.

Specifying Global Variables and External Variables

You can specify global variables or external variables (which specify global variables in POUs) for differential monitoring. Keep in mind that the values of global variables and external variables are updated at different times. A global variable is updated as soon as the value is written. An external variable, however, is updated only when the CPU Unit executes the POU in which that external variable is declared. The following figure shows this. In this example, the following two variables are monitored.

Variable	Type of variable	POU that executes the read/write
GVar1	Global variable	The P1 program that is assigned to the primary periodic task
P2.GVar1	This is an external variable that is declared in the P2 program and points to <i>GVar1</i> .	The P2 program that is assigned to the periodic task

The *GVar1* global variable is read and written by the P1 program that is assigned to the primary periodic task. Therefore, it will be updated in the primary period as long as the program writes to it every period. The *P2.GVar1* external variable, however, is updated only when the CPU Unit executes the P2 program that is assigned to the periodic task. This means the external variable is updated only in the task period of the periodic task. Because the task period of the periodic task is longer than the primary period, the count for *P2.GVar1* is updated fewer times than the count for *GVar1*.



Event Logs 8-7


This section describes the event logs.

8-7-1 Introduction

The event logs contain records of events,* such as errors, status changes, and user-defined events, that occurred in the NJ/NX-series Controller.

- Here, events are unscheduled events that occur on the Controller, such as errors. "Event" refers to an error or to information that does not indicate an error but for which the user must be notified by the Controller or for a user definition. There are two types and four classifications of events.
 - · Controller events Controller errors Controller information
 - · User-defined events User-defined errors User-defined information

NX-series CPU Units




*1. The event logs are saved in battery-backup memory in the NX701 CPU Unit. The event logs are saved in the non-volatile memory in the NX102 CPU Unit and NX1P2 CPU Unit.



Precautions for Correct Use

- Only the NX102 CPU Units and NX1P2 CPU Units have the NX Bus Function Module.
- The only CPU Units on which NX Units can be mounted are the NX102 CPU Units and NX1P2 CPU Units.
- Refer to the appendices of the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for the applicable range of the HMI Troubleshooter.

NJ-series CPU Units



To use an NS-series PT to check events, connect the PT to the built-in EtherNet/IP port on the CPU Unit.



Precautions for Correct Use

- You can use CJ-series Units only with NJ-series CPU Units.
- Refer to the appendices of the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the applicable range of the HMI Troubleshooter.

Features

Event logs have the following features.

- In addition to error records, various records are recorded for events such as the time the power supply is turned ON or OFF, and the time when operation is started.
- · You can check these records based on the time. You can therefore use them to isolate the causes of errors when problems occur.

Types of Events

Events are classified as shown below.

System-defined Events (Controller Events)

The Controller automatically detects these events. Controller events include events for the function modules in the CPU Unit, NX Units, NX-series Slave Terminals, EtherCAT slaves, and CJ-series Units. The different types of system-defined events are as follows:

- Controller errors
- Controller information

User-defined Events

These are events that occur in applications that the user developed. You can execute instructions to create the following types of events.

- · User-defined errors
- · User-defined information

You can read the event logs from the Sysmac Studio or from an HMI.

8-7-2 **Detailed Information on Event Logs**

Event Sources

This information identifies where an event occurred in the Controller. The event sources are given below for Controller events and user-defined events.

Sources of Controller Events

Controller events occur in the function modules in the CPU Unit.

For some function modules, there is more detailed information about the event source. This information is called the detailed event source.

The following are Controller events.

Event source	Source details
PLC Function Module	Instruction, power supply, built-in I/O, Option Board, I/O bus master or CJ-series Unit*1
NX Bus Function Module*1	Master or NX Unit
Motion Control Function Module	Common, axis, or axes group
EtherCAT Master Function Module	Communications port, EtherCAT master, or EtherCAT slave
EtherNet/IP Function Module	Communications port/communications port 1/communications port 2, CIP/CIP1/CIP2, FTP, NTP, or SNMP

^{*1} The source details information does not show information from the error histories from within CJ-series CPU Special Units or EtherCAT slaves. Read the error histories from the appropriate Support Software.

^{*2} Only the NX102 CPU Units and NX1P2 CPU Units have the NX Bus Function Module.

Sources of User-defined Events

User-defined events occur in the PLC Function Module.

Category

This information displays the category of event log. It is used to access error logs from the Sysmac Studio or an HMI.

Event type	Event log category	Description
Controller events	System log	The Controller automatically detects and records these events. CJ-series Unit errors are also included.
	Access log	This is a record of events that have affect Controller operation due to user actions.
User-defined events	User event log	This is a log of events that are defined by the user.

Number of Records

Each event log can contain the following number of records. If the number of events exceeds the number of records permitted, the CPU Unit overwrites the oldest events.

Event type	Event log category	Number of records permitted					
Event type	Eventing category	NX701	NX102	NX1P2	NJ501	NJ301	NJ101
Controller events	System log	2,048	768	576	1,024	512	512
	Access log	1,024	576	528	1,024	512	512
User-defined events	User event log	1,024	512	512	1,024	512	512

Retaining Events during Power Interruptions

When the power is interrupted, the NJ-series CPU Unit and NX701 CPU Unit use a Battery to retain the event logs, and the NX102 CPU Unit and NX1P2 CPU Unit use non-volatile memory to retain the event logs.



Precautions for Correct Use

For the CPU Unit that uses a Battery to retain the event logs, the event logs are not retained when there is no Battery.

Periodically export event logs as required.

Event Codes

Event codes are assigned to Controller events by the system in advance according to the type of event. Event codes are assigned to user-defined events by the user. Controller event codes are 8-digit hexadecimal values. You can use the Get Error Status instruction to read the error codes of current errors. You can assign a decimal number from 1 to 60,000 as the event code for a user-defined event.

Event Levels

Each event has an event level that indicates its level. The event level depends on the type of event. Levels are defined separately for Controller events and user-defined events.

Controller Events

Controller events are classified into five levels according to the degree of the effect that the events have on control, as shown in the following table.

No.	Level		Classification	
1	High	Controller errors	Major fault level	
2	A		Partial fault level	
3			Minor fault level	
4	▼		Observation level	
5	Low	Controller information	Information level	

Errors with a higher level have a greater impact on the functions that the Controller provides, and are more difficult to recover from.

When an event in one of these levels occurs, the Sysmac Studio or an HMI will display the error.

User-defined Events

User-defined events are classified into the following levels. These levels are defined by the NJ/NXseries System.

The event levels are defined for user-defined events.


No.	Level	Туре	Meaning
1	High	User fault Level 1	These event levels indicate a user-defined error in
2	A	User fault Level 2	an application. The user executes the SetAlarm (Create User-defined Error) instruction to create the
3		User fault Level 3	event.
4		User fault Level 4	
5		User fault Level 5	
6		User fault Level 6	
7		User fault Level 7	
8	▼	User fault Level 8	
9	Low	User Information	These event levels indicate user-defined information in an application. The user executes the SetInfo (Create User-defined Information) instruction to create the event.

Displaying Event Logs

The Sysmac Studio or an HMI displays two event logs: the Controller event log and the user-defined event log. The Controller logs include both the access log and the system log.

The Sysmac Studio can also display the error logs that are recorded in the CJ-series Units and Ether-CAT slaves.

The events in these logs are displayed in tables on the Sysmac Studio. Select an event from the table to display detailed information.





Additional Information

If an event occurs in the Controller that is not supported by the version of the Sysmac Studio or an HMI, the source is displayed as "Unknown" and the event name is displayed as "Unknown Event." The event code and attached information are displayed correctly.

Clearing Event Logs

Clearing Event Logs from the Sysmac Studio or an HMI

You can clear the event logs from the Sysmac Studio or from an HMI. You can clear the Controller event log and user-defined event log separately.



Precautions for Correct Use

- If you need to delete event log in the CPU Unit from the Sysmac Studio or an HMI, make sure you do not need any of the event information before you delete the event log. You may have overlooked some important information and observation level Controller events or userdefined events. Always check for these before you delete an event log.
- Refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for restrictions on clearing an event log from the PT.

Clearing Event Logs with the Clear All Memory Operation

When you perform the Clear All Memory operation for an NJ/NX-series CPU Unit from the Sysmac Studio, you can select whether to clear the event logs.

Exporting Event Logs

You can use the Sysmac Studio or an HMI to export the displayed event log to a CSV file.

8-7-3 Controller Events (Controller Errors and Information)

Introduction

Controller errors and information are defined by the NJ/NX-series System.

These events occur when the NJ/NX-series System detects an error or information factor.

Controller Errors

These are system-defined errors.

"Controller error" is a collective term for major fault level, partial fault level, minor fault level, and observation level Controller events.

Errors in the function modules of the CPU Unit, NX Units, NX-series Slave Terminals, EtherCAT slaves, and CJ-series Units are detected. When one of these events occurs, a Controller error is recorded in the event log.

To check the status of a Controller error on the user program, you execute the Get Error Status instruction to access the status of the Error Status variable, which is a system-defined variable.

Note You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.


Note You can use CJ-series Units only with NJ-series CPU Units.

Controller errors are not reset when the operating mode changes.

Refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for details on Controller errors.

Controller Information

Controller information is system-defined notification information. This information does not indicate errors. It represents information level Controller events. Examples include events other than errors, such as turning the power ON and OFF, starting and stopping operation, connecting the Sysmac Studio online, and downloading user programs.



8-7-4 User-defined Events (User-defined Errors and Information)

Introduction

These errors and information are defined by the user. You can use instructions to create them.


User-defined Errors

These errors are defined by the user. Use the Create User-defined Error (SetAlarm) instruction to create user-defined errors. When this instruction is executed, a user-defined error is recorded in the event log.

The corresponding system-defined variable changes to TRUE. User-defined errors are not reset when the operating mode changes.

User-defined Information

User-defined information is user-defined notification information. This information does not indicate errors. Use the Create User-defined Information (SetInfo) instruction to create user-defined information. When this instruction is executed, user-defined information is recorded in the event log.



Application Procedures

Use the following procedures.

User-defined Errors

1. Register a user-defined error in the Event Setting Table.



2. Execute the Create User-defined Error (SetAlarm) instruction. (Specify an event code that is defined in the Event Setting Table.)



3. A user-defined error occurs.



4. The corresponding system-defined variable _AlarmFlag (User-defined Error Status) changes to TRUE. Execute any process for that condition.



5. Check the user-defined error in the event log with the Sysmac Studio, an instruction, or an HMI.

User-defined information

1. Register user-defined information in the Event Setting Table.



2. Execute the Create User-defined Information (SetInfo) instruction.



3. Check the record in the event log.


Setting the Event Setting Table

To create a user-defined error or user-defined information, register the user-defined error or user-defined information in the Event Setting Table in the Sysmac Studio in advance.


The user events that you set here can be displayed on the Sysmac Studio or an HMI with the same information.

You can register up to 5,120 events in the Event Setting Table.

Event Setting Table



The following items are set in the Event Setting Table.



Contents of the Event Setting Table

Item	Description	Values
Event Code	You can specify a number to identify the	User-defined error: 1 to 40,000
	event according to the event level.	User-defined information: 40,001 to 60,000
Event Name	You can include a title for the event.	128 characters max.
Event Level	You can specify the level of the event. The level is indicated with a number.	User-defined error: User fault levels: 1 to 8
	The lower the number is, the higher the level is.	User-defined information: User information
Group	You can specify a group name to repre-	32 characters max.
	sent the location or type of the event. You can use user-defined groupings for the events.	There are no restrictions on the characters that can be used. Case sensitive. Reserved words: None
Details	You can include a message that	1,024 characters max.
	describes the event. The user can enter any text string. The message is used when the event is displayed on the Sysmac Studio or an HMI.	There are no restrictions on the characters that can be used. Case sensitive. Reserved words: None
Error details that are	Refer to the additional information that is	128 characters max.
displayed on the HMI when a major fault level	given below on displaying user mes- sages on an HMI when a major fault	There are no restrictions on the characters that can be used.
Controller error occurs	level Controller error occurs for more details.	Case sensitive. Reserved words: None
Comment	The comment is attached for each set of table entries.	



Additional Information

You can set up to nine different languages for the same event code for different regions and users. On the Sysmac Studio, you can import an Event Setting Table from a Microsoft Excel file via the clipboard.



Additional Information

Displaying User Messages on an HMI When a Major Fault Level Controller Error Occurs:

When a major fault level Controller error occurs, the user program execution stops.

The NJ/NX-series Controllers can display user messages on an HMI when a major fault level Controller error occurs. You can set the display messages under the list of user-defined events in the Event Setting Table on the Sysmac Studio.

Event Levels and Event Codes

Event classi- fication	Level	Event level cate- gory*	Range of corre- sponding event code	Description
User-defined	High	User fault Level1	1 to 5000	Select from eight levels.
errors	A	User fault Level2	5001 to 10000	
		User fault Level3	10001 to 15000	
		User fault Level4	15001 to 20000	
		User fault Level5	20001 to 25000	
		User fault Level6	25001 to 30000	
		User fault Level7	30001 to 35000	
	V	User fault Level8	35001 to 40000	
	Low			
User-defined Information	Lowest	User Information	40001 to 60000	The event type is user-defined information.

^{*} User-defined error levels are separate from Controller error levels.



Precautions for Correct Use

If you update the Event Setting Table and transfer it to the CPU Unit, the event logs for user-defined events still contain old information. This can result in inconsistencies with the new Event Setting Table. Program operations with caution.

Related Instructions

There are instructions that you can use to create and check user-defined errors and to clear existing user-defined errors.

Creating and Clearing User-defined Errors

Use the following instructions to create and reset user-defined errors and to create user-defined information. Up to 32 events per level can occur simultaneously, for a total of 256 possible simultaneous events.


Instruction name	Instruction	Description
Create User-defined Error	SetAlarm	The SetAlarm instruction creates a user-defined error.
Reset User-defined Error	ResetAlarm	The ResetAlarm instruction resets a user-defined error.
Create User-defined Information	SetInfo	The SetInfo instruction records the specified user-defined information in the event log.

Checking for User-defined Errors

You can use the Get User-defined Error Status (GetAlarm) instruction to obtain the status of the current user-defined errors and the highest priority event level and code of the current user-defined errors.

Example:

Event Setting Table





Additional Information

You can use user-defined errors to add a message on possible corrections or other information when a Controller error occurs. Use instructions such as the GetPLCError instruction to obtain information about the error status or event code when a Controller error occurs. You can then use the information to trigger a user-defined error.

Example 1

When a Low Battery Voltage error occurs, the event code (16#000B0000) is obtained and the following message is displayed.

Battery is dead.

Apply power for at least five minutes before changing the Battery.

Install a new Battery within five minutes of turning OFF the power supply.

Example 2

When a partial fault level Controller error occurs, the event error level is obtained (highest level status: 2) and the following message is displayed.

A device failed. Call the following number for support.

Repair Contact

Hours: 8:00 AM to 9:00 PM

TEL: xxx-xxxx-xxxx

System-defined Variables Related to User-defined Errors

Variable name	Meaning	Description		R/W
_AlarmFlag	User-defined Error Status	The bit corresponding to the event level is TRUE while there is a user-defined error. Bits 00 to 07 correspond to user fault levels 1 to 8.	WORD	R

Records in Event Log

An event is recorded in the event log when you create user-defined information or a user-defined error, or when you use the ResetAlarm instruction to reset an error. When this happens, the time, event code, event level, and attached information 1 and 2 are recorded in the user-defined event log in the event logs.

Reset User-defined Errors

User-defined errors are cleared when the power supply to the NJ/NX-series Controller is turned ON. You can also clear errors with the Sysmac Studio, the Reset User-defined Error instruction (ResetAlarm) and an HMI.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details.

Changing Event Levels 8-8

Errors, status changes, and user-defined events that occur in the NJ/NX-series Controller are all called events. You can tell what type of event has occurred by viewing the display in Sysmac Studio, or by checking the indicators on the front panel of the CPU Unit.

There are two types of events: Controller events that are defined in the system and user-defined events. The Controller events are further classified into five event levels. Refer to Event Levels on page 8-72 for details on event levels.

You can change the event levels that are assigned to some of the Controller events.



Version Information

A CPU Unit with unit version 1.03 or later and Sysmac Studio version 1.04 or higher are required to change event levels.

8-8-1 **Applications of Changing Event Levels**

The lighting pattern for the indicators on the front panel of the CPU Unit is predefined according to the event level that is assigned to each Controller event. You can change the event level for some events to change how the Controller operates when that event occurs.

For example, the ERROR indicator flashes for minor fault level events and stays unlit for observation level events. You can change the lighting pattern of the ERROR indicator so that it goes out or flashes for a given event.

Refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for details on how the Controller operates for different event levels.

8-8-2 **Events for Which the Event Level Can Be Changed**


Whether an event level can be changed depends on the specific event.

Refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503) for details on the types and levels of the Controller events, and whether the event levels can be changed.

8-8-3 Procedure to Change an Event Level


1 Double-click Operation Settings under Configurations and Setup – Controller Setup in the Sysmac Studio. Or right-click Operation Settings and select *Edit* from the menu.

The Basic Settings Display is displayed on the Operation Setting Tab Page in the Edit Pane.



2 Click the Event Level Settings Button.

A list of the events for which you can change the event level is displayed.



3 Change the levels of the required events in the *Event Level* column.



Precautions for Correct Use

If you change an event level on the Sysmac Studio and download the event level setting to the Controller when the event already exists on the Controller, the event will be reset when the download is started. If the same event occurs again while the download is in progress, the Controller will operate according to the previous event level. If the same event occurs after the download is completed, the Controller will operate according to the new level.



Backup Functions

This section describes the backup functions for the settings in an NJ/NX-series Controller. There are different types of backup functions that handle different data or different storage locations. First an overall description of the backup functions is provided followed by descriptions of the individual functions.

9-1	1 The Backup Functions		
	9-1-1	Applications of Backup Functions	9-4
	9-1-2	Examples of Operating Procedures for the Backup Functions	9-4
	9-1-3	Data That Is Backed Up	9-7
	9-1-4	Types of Backup Functions	9-9
	9-1-5	Relation Between the Different Types of Backup Functions and Data Groups	9-11
	9-1-6	Applicable Range of the Backup Functions	
9-2	SD Me	mory Card Backups	9-14
	9-2-1	Backup (Controller to SD Memory Card)	9-15
	9-2-2	Restore (SD Memory Card to Controller)	9-20
	9-2-3	Verify (between Controller and SD Memory Card)	9-28
9-3	Disabling Backups to SD Memory Cards		
9-4	Automatic Transfers from SD Memory Cards 9-3		
9-5	Program Transfer from SD Memory Card		
9-6	Sysma	c Studio Controller Backups	9-43
	9-6-1	Backup (Controller to Computer)	9-44
	9-6-2	Restore (Computer to Controller)	9-45
	9-6-3	Verify (between Controller and Computer)	9-47
9-7	Import	ing and Exporting Sysmac Studio Backup File Data	9-48
9-8	Sysma	c Studio Variable and Memory Backup Functions	9-49
	9-8-1	Applicable Data for Sysmac Studio Variable and	
		Memory Backup Functions	
	9-8-2	Using Sysmac Studio Variable and Memory Backup Functions	
	9-8-3	Compatibility between CPU Unit Models	
9-9		p Functions When EtherCAT Slaves Are Connected	
	9-9-1	Backed Up EtherCAT Slave Data	
	9-9-2	Backup Support Depending on the Controller Status	
	9-9-3	Conditions for Restoring EtherCAT Slave Data	9-53

	9-9-4	EtherCAT Slaves for Which You Can Back Up Data	9-54
9-10	Backup	Functions When EtherCAT Slave Terminals Are Connected	. 9-57
	9-10-1	Backing Up Data in an EtherCAT Slave Terminal	9-57
	9-10-2	Backup Support Depending on the EtherCAT Slave Terminal Status	9-58
	9-10-3	Conditions for Restoring EtherCAT Slave Terminal Data	9-58
9-11	Backup	Functions When NX Units Are Connected	. 9-59
	9-11-1	Backing Up Data in NX Units on the CPU Unit	9-59
	9-11-2	Backup Support Depending on the Controller Status	9-59
	9-11-3	Conditions for Restoring NX Unit Data on the CPU Unit	9-60
9-12	Backup	Functions When CJ-series Units Are Connected	. 9-61
	9-12-1	Backed Up CJ-series Unit Data	9-61
	9-12-2	Backup Support Depending on the Controller Status	9-61
	9-12-3	Conditions for Restoring CJ-series Unit Data	9-61
9-13	Backup	o-related Files	. 9-63
	9-13-1	Types of Backup-related Files	9-63
	9-13-2	Specifications of a Backup File	9-64
	9-13-3	Specifications of a Restore Command File	
	9-13-4	Specifications of an Automatic Transfer Command File	9-67
	9-13-5	Specifications of a Controller Verification Results File	
	9-13-6	Specifications of an EtherCAT Verification Results File	
	9-13-7	Specifications of an EtherCAT Slave Terminal Verification Results File	
	9-13-8	Specifications of an NX Unit Verification Results File	
	9-13-9	Specifications of CJ-series Unit Verification Results File	9-74
9-14	Compa	tibility between Backup-related Files	. 9-76
	9-14-1	Compatibility between Backup Functions	
	9-14-2	Compatibility between CPU Unit Models	
	9-14-3	Compatibility between Unit Versions of CPU Units	9-78
9-15	Functio	ons That Cannot Be Executed during Backup Functions	9-80

9-1 The Backup Functions

The following three functions are supported for data backup for an NJ/NX-series Controller.

Function	Description
Backing up data	You can back up all of the data in the Controller to an SD Memory Card or to a computer. The file that is saved is called a backup file.
Restoring data	You can transfer the contents of a backup file on the SD Memory Card or computer to the Controller. The data in the Controller is restored to the data at the time the backup file was made.
Verifying data	You can compare the contents of a backup file on the SD Memory Card or computer with the data in the Controller to see if they are the same.

The following items are described for the backup functions.

Item	Description
Applications of backup functions	Effective usage of the backup functions is described.
Examples of operating procedures for the	The backup functions are executed with simple procedures.
backup functions	Examples are provided.
Data that is backed up	The data that can be saved with the backup functions from the
	connected Units and slaves is described.
Types of backup functions	There are different types of backup functions that differ in
	where the data is saved. The types of backup functions and
	the difference between them are described.
Relation between the different types of backup	Different types of backup functions handle different data
functions and data groups	groups. The relation between the different types of backup
	functions and data groups is described.
Applicable range of the backup functions	The connected Units and slaves for which you can save data
	with the backup functions are described.



Precautions for Safe Use

- The performance may be different if the hardware revisions are different. Before you transfer the user program, data, and parameter settings to the CPU Units with the different hardware revisions, check them for proper execution and then use them for actual operation.
- For an NX-series CPU Unit, we recommend that you back up the present values of variables while the retained variables are not refreshed.
- If you back up the following variables while the values of retained variables are refreshed, the data may not be saved correctly.
- Structure members whose data size is 16 bits or more
- · Array elements whose data size is 16 bits or more

9-1-1 **Applications of Backup Functions**

You can use the backup functions in the following instances.

Item	Application
Program and setting changes	When you change the user program and settings for equipment that is currently in operation.
Hardware replacements	When you replace the hardware for the CPU Unit, other Units, or slaves.
Troubleshooting equipment failures	When you want to save data in the Controller to analyze the cause of an error that occurs in the equipment.
Equipment backup and recovery	When an error occurs in the equipment, and when you want to restore the equipment with data from an normal operating status. When you want to backup the data in the equipment while it is in operation.
Manufacture of equipment	When you want to manufacture the same equipment and need to transfer the data from the existing equipment to new equipment in its initial state.

9-1-2 **Examples of Operating Procedures for the Backup Functions**

You can use the backup functions to easily back up, restore, and verify Controller data.

This section provides the procedures to back up, restore, and verify data with an SD Memory Card by using the DIP switch on the front panel of the CPU Unit.



Precautions for Correct Use

For the NX701 CPU Units, eight pins, pins 1 to 8, are provided on the DIP switch. Before you use the backup functions, set all of pins 5 to 8 to OFF.

Backup Procedure

Preparations

- Insert the SD Memory Card into the CPU Unit.
- Set pins 1 to 4 on the DIP switch on the CPU Unit as follows: 1: OFF, 2: OFF, 3: ON, and 4: OFF.

Executing the Backup

Press the SD Memory Card power supply switch for 3 seconds.

The backup is started. The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds.

When the backup operation is completed, the SD PWR indicator will stop flashing and remain lit.

Ending the Backup Procedure

- Set all of pins 1 to 4 on the DIP switch on the CPU Unit to OFF.
- Press the SD Memory Card power supply switch to turn OFF the SD PWR indicator.
- Remove the SD Memory Card.

Restoration Procedure

Preparations

- 1 Turn OFF the power supply to the NJ/NX-series Controller and to the EtherCAT slaves.
- 2 Insert the SD Memory Card that contains the backup file into the CPU Unit.
- **3** Set pins 1 to 4 on the DIP switch on the CPU Unit as follows: 1: OFF, 2: OFF, 3: ON, and 4: ON.

Restoring Data

4 Turn ON the power supply to the NJ/NX-series Controller and to the EtherCAT slaves.

The restoration operation is started. The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds.

When the restoration operation is completed, the SD PWR indicator will stop flashing and remain lit.

Ending the Restoration Procedure

- **5** Press the SD Memory Card power supply switch to turn OFF the SD PWR indicator.
- **6** Turn OFF the power supply to the NJ/NX-series Controller and to the EtherCAT slaves.

Starting Normal Operation

- **7** Remove the SD Memory Card.
- **8** Set all of pins 1 to 4 on the DIP switch on the CPU Unit to OFF.
- **9** Turn ON the power supply to the NJ/NX-series Controller and to the EtherCAT slaves.



Precautions for Correct Use

Restoring Data When EtherCAT Slaves Are Connected

- Always cycle the power supply to the NJ/NX-series Controller and the EtherCAT slaves after you restore data when EtherCAT slaves are connected. If you start operation without cycling the power supply, the Controller may perform unexpected operation.
- To verify the data after you restore data with EtherCAT slaves connected, first turn OFF the
 power supply to the NJ/NX-series Controller and EtherCAT slaves, and then start in Safe
 Mode before you perform the verification procedure. If you cycle the power supply normally,
 the Controller will start operation before you can perform the verification procedure. That
 means that operation could be started with data that is not correct. For information on Safe
 Mode, refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503).

Verification Procedure

Preparations

- 1 Insert the SD Memory Card that contains the backup file into the CPU Unit.
- **2** Set all of pins 1 to 4 on the DIP switch on the CPU Unit to OFF.

Verifying the Data

3 Press the SD Memory Card power supply switch for 3 seconds.

Data comparison is started. The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds.

If the verification operation is completed and the data is the same, the SD PWR indicator will stop flashing and remain lit.

If the verification operation is completed and differences were found in the data, the SD PWR indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds.

Ending the Verification Procedure

Press the SD Memory Card power supply switch to turn OFF the SD PWR indicator.

Remove the SD Memory Card.

9-1-3 Data That Is Backed Up

The following data is backed up. This section describes the backup functions based on the following data groups for the backup data.

Data group	Data items
User program and settings	EtherCAT configuration (EtherCAT slave configuration and EtherCAT master settings)
	Unit Configuration and Unit Setup*1
	I/O Map
	Controller Setup (Operation Settings, Built-in EtherNet/IP Port Settings,
	Built-in I/O Settings, and Option Board Settings)*2
	Motion Control Setup
	Cam Data Settings
	Event Setup
	Task Setup
	Data Trace Settings
	Tag Data Link Tables
	Controller name
	Operation authority verification
	User program execution ID in user program
	Built-in clock (time zone setting)
	POUs
	Data (data types and global variables)
	Memory Settings for CJ-series Units*3
IP address of built-in EtherNet/IP port*4	Of the TCP/IP Settings in the Built-in EtherNet/IP Port Settings, setting type, IP address, subnet mask, and default gateway
Present values of variables	Values of variables with a Retain attribute*5
Present values of memory used for CJ-series Units	Values of the Holding, DM, and EM Areas in the memory for CJ-series Units*3
Units and slaves settings	Backup parameters for EtherCAT slaves*6
	Parameters in the CJ-series Units*3*7
	NX Unit Settings
Absolute encoder home offset	The set value to restore the actual position of a Servo Drive with an absolute encoder

- *1 For the NX Units on the NX102 CPU Unit and NX1P2 CPU Unit, data of configuration information, Unit operation settings and Unit application data is backed up.
- *2 Data of Built-in I/O Settings, Option Board Settings, and Memory Settings for CJ-series Units is backed up only for the NX1P2 CPU Units.
- *3 You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units. You can use parameters in the CJ-series Units only with NJ-series CPU Units.
- *4 With a combination of the CPU Unit with unit version 1.14 or later and Sysmac Studio version 1.18 or higher, IP address of the Built-in EtherNet/IP Port Settings can be used as a data group. IP address is included in the user program and settings other than the above combination.
- *5 Of the system-defined variables with a Retain attribute, some variables are not applicable for the data backup function. Refer to A-7 Specifications for Individual System-defined Variables for details on the specifications for individual system-defined variables.
- *6 A part or all of the set parameters are not backed up for some EtherCAT slave models. For the details on the target EtherCAT slaves for the data backup function, refer to 9-9-4 EtherCAT Slaves for Which You Can Back Up Data.
- *7 Refer to the *CJ-series CJ2 CPU Unit Hardware User's Manual* (Cat. No. W472) for details on the data that is backed up.



Precautions for Safe Use

Precautions on the Absolute Encoder Home Offset

The absolute encoder home offsets are backed up with a Battery in the CPU Unit as absolute encoder information. If any of the following conditions is met, clear the absolute encoder home offsets from the list of data items to restore, and then restore the data. Then, define the absolute encoder home again. If you do not define home, unintended operation of the controlled system may occur.

- The Servomotor or Servo Drive was changed since the data was backed up.
- The absolute encoder was set up after the data was backed up.
- The absolute data for the absolute encoder was lost.

9-1-4 Types of Backup Functions

There are backup functions for the NJ/NX-series Controllers that save data to SD Memory Cards and others that save data to a computer. Also, there are three methods used to execute the backup functions: the CPU Unit front-panel DIP switches, system-defined variables, and the Sysmac Studio.

Functions That Save Data to SD Memory Cards

The SD Memory Card backup functions are used to back up, restore, and compare data on SD Memory Cards. Related functions include disabling backups to SD Memory Cards, automatic transfers from SD Memory Cards, and program transfer from SD Memory Card.

			Ope	Operating method			
Function	n name	Description	CPU Unit front-panel DIP switch	System- defined variables	Sysmac Studio	Reference	
SD Mem- ory Card backups	Backing up data	The Controller data is saved in a backup file on the SD Memory Card.	√	√	√	9-2-1 Backup (Controller to SD Memory Card)	
	Restor- ing data	The data in a backup file on the SD Memory Card is transferred to the Controller.	✓	✓		9-2-2 Restore (SD Memory Card to Controller)	
	Verifying data	The Controller data and the data in a backup file on the SD Memory Card are compared.	✓	✓	✓	9-2-3 Verify (between Control- ler and SD Memory Card)	
Disabling backups to SD Memory Cards		You can disable backing up data to SD Memory Cards.			✓	9-3 Disabling Backups to SD Memory Cards	
Automatic transfers from SD Memory Cards		When the power supply is turned ON, the data in a backup file on the SD Memory Card is automatically transferred to the Controller. After the data transfer, the operating mode of the CPU Unit will change to the mode that is specified in Startup Mode setting.	✓			9-4 Automatic Transfers from SD Memory Cards	
Program transfer from SD Memory Card		With a system-defined variable, you can transfer a program that is stored in the SD Memory Card to the Controller. After the transfer, the operating mode of the CPU Unit will change to the mode that is specified in Startup Mode setting.		V		9-5 Program Transfer from SD Memory Card	
Safety unit restore*1		The data in a safety unit restore file on the SD Memory Card is transferred to the NX-SL5□□□ that is mounted to the NX102 CPU Unit.	*2			NX-series Safety Control Unit User's Manual (Cat. No. Z930-E1-12 or later)	

^{*1} An NX102 CPU Unit with unit version 1.31 or later and Sysmac Studio version 1.24 or higher are required to use the function. The safety unit restore function restores only the data in the NX-SL5□□□. If you restore in the entire system, you must execute the safety unit restore with a combination of the SD Memory Card backups.

^{*2} Set the front-panel DIP switch on the NX-SL5□□□ Safety CPU Unit. Refer to the NX-series Safety Control Unit User's Manual (Cat. No. Z930-E1-12 or later) for details.

Functions That Save Data to the Computer

The Sysmac Studio Controller backup functions are used to back up, restore, and compare data on the computer. Importing and exporting Sysmac Studio backup file data are used to save and read different types of data between the Sysmac Studio projects and backup files on the computer without using a Controller. The Sysmac Studio variable and memory backup functions are used to back up batterybackup present values to the computer and restore them from the computer.

			Op			
Function name		Description	CPU Unit front-panel DIP switch	System- defined variables	Sysmac Studio	Reference
Sysmac Stu- dio Control- ler backups	Backing up data	The Controller data is saved in a backup file on the computer.			✓	9-6-1 Backup (Controllerto Computer)
ing data on the complete form for the control data on the complete form for the control data in a basis of the control data.		The data in a backup file on the computer is transferred to the Controller.			✓	9-6-2 Restore (Computer to Controller)
		The Controller data and the data in a backup file on the computer are compared.			✓	9-6-3 Verify (between Controller and Com- puter)
and exporting Sysmac Stu- dio backup file data	Export- ing data	The data is exported from the project on the Sysmac Studio to a backup file without using a Controller.			✓	9-7 Import- ing and Exporting Sysmac Stu-
	Import- ing data	The data in the backup file is imported into the Sysmac Studio project without using a Controller.			✓	dio Backup File Data
Sysmac Studio variable and memory backup functions	Backing up data	You can back up the present values of data that is backed up by a battery to an XML file on the computer.			✓	9-8 Sysmac Studio Vari- able and Memory Backup
	Restor- ing data	You can restore the present values of data that is backed up by a battery from the computer to the CPU Unit.			√	Functions



Version Information

- A CPU Unit with unit version 1.03 or later and Sysmac Studio version 1.04 or higher are required to use the following backup functions: SD Memory Card backups, automatic transfers from SD Memory Cards, Sysmac Studio Controller backups, and importing and exporting Sysmac Studio backup file data.
- A CPU Unit with unit version 1.11 or later and Sysmac Studio version 1.15 or higher are required to transfer programs from the SD Memory Card.
- A CPU Unit with unit version 1.14 or later and Sysmac Studio version 1.18 or higher are required to use the restore of SD Memory Card backups by the system-defined variable.



Additional Information

The backup functions are executed as a system service. This means that if you perform a backup or verification operation in RUN mode with an NJ-series CPU Unit, it may take time for the operation to be completed. If you perform a backup or verification operation in RUN mode, make sure that the sufficient execution time is allocated for the system service. You can reduce the processing time by performing the system service in PROGRAM mode.

9-1-5 Relation Between the Different Types of Backup Functions and Data Groups

Different types of backup functions handle data for different data groups. The relation between the different types of backup functions and data groups is given in the following table.

(OK: Applicable, NA: Not applicable)

	Data group						
			rogram and ettings		Present		
Type of backup function			IP address of built-in Ether- Net/IP port*2	Present values of variables	values of memory used for CJ-series Units*1	Units and slaves set- tings	Absolute encoder home off- sets
SD Memory Card backups	Backing up data	OK	OK	OK* ³	OK*4	OK	OK
	Restoring data	OK	OK	OK*3	OK*4	OK	OK
	Verifying data	OK*5	OK	NA	NA	OK	NA
	Automatic transfers from SD Memory Cards*6		OK	OK*3	OK*4	NA	NA
Program transfer ory Card *7	from SD Mem-	OK	OK	OK*3	OK*4	NA	NA
Sysmac Studio Controller back-	Backing up data	OK	OK	OK*3	OK*4	OK*8	OK
ups	Restoring data	OK	OK	OK*3	OK*4	OK*8	OK
	Verifying data	OK*5	OK	NA	NA	OK*8	NA
Importing and exporting Sysmac Studio backup file data	Exporting backup file data	OK*9	OK	NA	NA	NA	NA
	Importing backup file data	OK*9	ОК	NA	NA	ОК	NA
Sysmac Studio variable and memory backup functions	Backing up and restoring data	NA	NA	OK* ³	OK*4	NA	OK

^{*1} You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

^{*2} With a combination of the CPU Unit with unit version 1.14 or later and Sysmac Studio version 1.18 or higher, IP address of the Built-in EtherNet/IP Port Settings can be used as a data group. IP address is included in the user program and settings other than the above combination.

^{*3} The backup data is processed only for the present values of variables that are specified for retention with the Retain attribute.

- *4 The backup data is processed only for the present values of addresses that are specified for retention with the Retain attribute in the memory for CJ-series Units.
- *5 Of the user program and setting data groups, the Data Trace Settings are not compared.
- *6 For all of the data groups except for the user program and setting group, only the items that are specified to be transferred in the automatic transfer command file are transferred.
- For all of the data groups, only the data that is specified as the transfer target by the system-defined variable is transferred.
- *8 If the CJ-series Units are specified for backup, the parameters in the CJ-series Units are backed up. If the EtherCAT slaves are specified for the backup, parameters for the EtherCAT slaves are backed up.
- *9 The following data is not processed: The data that is not processed depends on the version of the Sysmac Stu-

Using Sysmac Studio Version 1.16 or Higher

- The built-in EtherNet/IP port name in the Controller name
- · Words allocated to CPU Bus Units in the Unit Configuration and Unit Settings
- · Operation authority verification
- · Data Trace Settings

Using Sysmac Studio Version 1.15 or Lower

- The built-in EtherNet/IP port name in the Controller name
- The built-in EtherNet/IP tag data link settings in the Controller Setup
- · Words allocated to CPU Bus Units in the Unit Configuration and Unit Settings
- · Operation authority verification
- · Data Trace Settings



Additional Information

The files that are handled for backing up variables and memory from the Sysmac Studio are not compatible with other backup files. Refer to 9-8 Sysmac Studio Variable and Memory Backup Functions for details on the Sysmac Studio variable and memory backup functions.

9-1-6 Applicable Range of the Backup Functions

Different types of backup functions handle data for different Units or slaves. The applicable Units and slaves for each backup function are given in the following table.

(OK: Applicable, NA: Not applicable)


	Units/slaves						
	NJ/NX-	Ether-	NXUnits	CJ-series Units*4		Ether-	Com-
Type of backup function	series CAT CPU Unit slaves*1		on the CPU Unit*2*3	Units and Master Units	Slaves	Net/IP slaves	puter and HMIs
SD Memory Card backups	OK	OK*3	OK	OK	NA	NA	NA
Automatic transfers from SD Memory Cards	OK	NA	NA	NA	NA	NA	NA
Program transfer from SD Memory Card	OK	NA	NA	NA	NA	NA	NA
Sysmac Studio Controller backups	OK	OK*3	OK	OK	NA	NA	NA
Importing and exporting Sysmac Studio backup file data	OK	OK*5	OK	NA	NA	NA	NA
Sysmac Studio variable and memory backup functions	OK	NA	NA	NA	NA	NA	NA

^{*1} EtherCAT Slave Terminals are included. If EtherCAT Slave Terminals are set for backup, the backup function applies to both the EtherCAT Coupler Unit and the NX Units.

^{*2} You can use NX Units on the CPU Unit only with the NX102 and NX1P2 CPU Units.

- *3 This does not apply to Safety Control Units. Refer to the *NX-series Safety Control Unit User's Manual* (Cat. No. Z930-E1-12 or later) for information on importing and exporting settings and safety unit restore settings for a Safety Control Unit.
- *4 You can use CJ-series Units only with NJ-series CPU Units.
- *5 Only importing data is possible. Exporting is not possible.

The Units and slaves that are shown in the following figure are covered by the SD Memory Card backup functions and Sysmac Studio Controller backup functions.



Applicable range for the SD Memory Card backup functions and Sysmac Studio Controller backup functions.

Note You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

Note You can use CJ-series Units and NJ-series Expansion Racks only with the NJ-series CPU Unit.




Version Information

A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to connect EtherCAT Slave Terminals.

SD Memory Card Backups

You can use SD Memory Cards to back up, restore, and verify Controller data.



When you back up data, the backup file, restore command file, and automatic transfer command file are created in the specified directory on the SD Memory Card. When you verify data, the verification results files are created in the specified directory. All of these files are collectively referred to as backuprelated files. The functions of the backup-related files are given in the following table.

	Function						
File	Contents	Backing up data	Restor- ing data	Verifying data			
Backup files	This file contains the Controller data that is handled by the functions that are related to data backup.	Created.	Accessed.	Accessed.			
Restore command file	This file specifies the data groups to restore when restoring data. You can edit this file with a text editor on a computer to specify the data groups to restore.	Created.	Accessed.	Accessed.			
Automatic transfer command file	This file specifies the data groups to transfer when automatically transferring data from a SD Memory Card. You can edit this file with a text editor on a computer to specify the data groups to transfer.	Created.	Nothing is done.	Nothing is done.			
Verification results files	These files contain the verification results after data is verified.	Nothing is done.	Nothing is done.	Created.			

The execution method for the functions, applicable directory, and applicable operating modes are given in the following table.

Procedure	Directory*1	Applicable operating modes			
riocedure	Directory ·	Backing up data	Restoring data	Verifying data	
CPU Unit front-panel DIP switch*2	The root directory	RUN mode and PROGRAM mode	At startup	RUN mode and PROGRAM mode	
System-defined variables*3*4	The directory that you specified in the system-defined variable	RUN mode and PROGRAM mode	RUN mode and PROGRAM mode*5	RUN mode and PROGRAM mode	
SD Memory Card Window in Sysmac Studio	The directory that you specified on the SD Memory Card Window	RUN mode and PROGRAM mode	Execution is not possible.	RUN mode and PROGRAM mode	

^{*1} You can specify a directory only on the SD Memory Card.

^{*2} Before you restore or verify data, save the backup file and restore command file in the root directory.

^{*3} This method is used to control the backup functions from an HMI. You can access the system-defined variables only for the restore from the user program.

- *4 Make arrangements to prevent backup or verification operations from being performed on HMIs while a backup, restore, or verification operation is in progress. Otherwise, the intended operation may not occur.
- *5 Execution is not possible for the CPU Unit with unit version 1.13 or earlier because the restore by the systemdefined variable is not supported.

9-2-1 Backup (Controller to SD Memory Card)

This operation is used to save data in the Controller to the SD Memory Card in the CPU Unit.

Processing Contents

- · This backup operation processes all data groups.
- When you back up data, the backup file, restore command file, and automatic transfer command file
 are created in the specified directory on the SD Memory Card.
- If the backup-related files are already in the specified directory, they are overwritten.
- If an error occurs while writing the backup-related files to the SD Memory Card, the previous backup-related files will be deleted. Also, the new backup-related files will not be created.
- If an error occurs before the new backup-related files are created, the previous files are retained and the new files are not created.
- The power is continued to supply even if the SD Memory Card power supply switch is pressed when a backup is in progress.
- The SD Memory Card will remain mounted after completion of the backup.

Procedure

Backing Up Data with the CPU Unit Front-panel DIP Switch

Processing stage	Procedure
Start command	The backup starts when the SD Memory Card power supply switch is pressed for 3 seconds with the DIP switch pins set as follows: 1: OFF, 2: OFF, 3: ON, and 4: OFF.*1
Executing	Immediately after Starting Backup*2
	The SD PWR indicator will light, go out for 0.5 seconds, and then light again.
	While Backing Up Data
	The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds.
	The SD BUSY indicator will flash irregularly.
	The value of the _BackupBusy (Backup Function Busy Flag) system-defined variable will change to TRUE.
Execution results	Normal End:
	The SD PWR indicator will light.
	Error End:
	The SD PWR indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds. The indicator stop flashing and stay lit when the SD Memory Card power supply switch is pressed.*1

^{*1} For the NX701 CPU Unit, set all of pins 5 to 8 on the DIP switch to OFF.

^{*2} If an SD Memory Card is not inserted, the SD PWR indicator will not light.

● Backing Up Data with the _Card1BkupCmd (SD Memory Card Backup Command) System-defined Variable

Processing stage	Procedure
Start command	The name of the directory where the files are saved is stored in the _Card1BkupCmd.Dir- Name (Directory Name) system-defined variable.
	Example: "dirA/dirB" specifies the dirB directory inside the dirA directory.
	The backup operation starts when you change the _Card1BkupCmd.ExecBkup (Execute Backup Flag) system-defined variable to TRUE.
Cancel command	You can cancel the backup operation.
	The backup operation ends in an error if you change the _Card1BkupCmd.CancelBkup (Cancel Backup Flag) system-defined variable to TRUE.
Executing	The _Card1BkupSta.Active (Active Flag) system-defined variable changes to TRUE.
	The value of the _BackupBusy (Backup Function Busy Flag) system-defined variable will change to TRUE.
Execution results	Normal End:
	The _Card1BkupSta.Done (Done Flag) system-defined variable changes to TRUE.
	Error End:
	The _Card1BkupSta.Err (Error Flag) system-defined variable changes to TRUE.

Note You cannot access these system-defined variables from the user program.

Backing Up Data from the SD Memory Card Window on the Sysmac Studio

Processing stage	Procedure
Start command	Click the SD Memory Card Backup Button on the SD Memory Card Window in the Sysmac Studio, specify the directory to save the backup file in, and execute the backup.
Executing	The progress of the backup is displayed in the dialog box. The value of the _BackupBusy (Backup Function Busy Flag) system-defined variable will change to TRUE.
Execution results	A message will appear when the backup is completed. You will then be asked to confirm whether to verify the backup data.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

Backing Up Data with Special Instruction

Processing stage	Procedure
Start command	Execute the BackupToMemoryCard instruction in the user program.
Executing	The value of the <i>Busy</i> output variable from the BackupToMemoryCard instruction will change to TRUE. The value of the <i>BackupBusy</i> (Backup Function Busy Flag) system-defined variable will change to TRUE.
Execution results	Normal End: The value of the <i>Done</i> output variable from the BackupToMemoryCard instruction changes to TRUE.
	Error End: The value of the <i>Error</i> output variable from the BackupToMemoryCard instruction changes to TRUE. The error code is stored in the <i>ErrorID</i> output variable from the BackupToMemoryCard instruction.



Version Information

A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the BackupToMemoryCard instruction.

Related System-defined Variables

The system-defined variables that are related to the operation when system-defined variables are used to back up data are shown below. Refer to A-7 Specifications for Individual System-defined Variables for details on system-defined variables.

Variable	- Meaning	Function	Data type	R/W	
Member name	Wearing	i unction	Data type	10/44	
_Card1BkupCmd*	SD Memory Card Backup Commands		_sBKUP_CMD	RW	
ExecBkup*	Execute Backup Flag	Change this variable to TRUE to back up Controller data to an SD Memory Card.	BOOL	RW	
CancelBkup*	Cancel Backup Flag	Change this variable to TRUE to cancel backing up data to an SD Memory Card.	BOOL	RW	
DirName*	Directory Name	Use this variable to specify the directory name in the SD Memory Card for which to back up data.	STRING(64)	RW	
_Card1BkupSta*	SD Memory Card Backup Status		_sBKUP_STA	R	
Done*	Done Flag	TRUE when a backup is completed.	BOOL	R	
Active*	Active Flag	TRUE when a backup is in progress.	BOOL	R	
Err*	Error Flag	TRUE when processing a backup ended in an error.	BOOL	R	
_BackupBusy	Backup Function Busy Flag	TRUE when a backup, restoration, or verification is in progress.	BOOL	R	

^{*} You cannot access these system-defined variables from the user program.




Additional Information

- Refer to the NA-series Programmable Terminal Software User's Manual (Cat. No. V118) for information on mapping variables when you connect an NA-series PT to the NJ/NX-series Controller.
- Refer to A-11 Registering a Symbol Table on the CX-Designer for the procedure to register these system-defined variables in the variable table of the CX-Designer when you connect an NSseries PT to the NJ/NX-series Controller.


Timing Charts

The operation of the system-defined variables when they are used to backup data is shown below. In the charts, "pre-execution checks" indicates processing to check whether there is a SD Memory Card in the CPU Unit and other items before the backup starts. The value of *_Card1BkupSta.Active* (Active Flag) changes to TRUE only after all of the pre-execution checks are cleared and the actual backup is started.


Normal Operation



Operation When the Backup Cannot Start Because Another Backup Function Is in Progress




Operation When the Backup Fails After a Normal Start



Operation When the Backup Is Canceled While the Backup Is in Progress

The time required to stop the backup operation after it is canceled depends on the progress of the backup operation.



Processing Time and Backup File Size

The time that is required to back up the data depends on factors such as the CPU Unit, operating mode, Unit configuration, and user program. The size of the backup file depends on factors such as the Unit configuration and user program. Some guidelines for the backup time and backup file size are given in the following table.

CPU Unit	Operat- ing mode	Con- nected Ether- CAT slaves	Connected NX Units or CJ-series Units	Con- nected Option Boards	Number of user- defined POUs	User program memory size (Mbytes)	Backup time (s)	Backup file size (Mbytes)
NX701-	PRO- GRAM	*1			113	7.13	Approx. 30	29.45
NX102-	mode	*2	*3		15	0.37	Approx. 30	13.8
NX1P2-		*2	*3	*4	15	0.35	Approx. 30	2.96
NJ501-		*1	*5		53	2.36	Approx. 50	20
NJ301-		*6			20	0.53	Approx. 30	9.85
NJ101-		*2			15	0.38	Approx. 30	9.94

Thirty-two each of the following: R88D-KNA-ECT AC Servo Drives, GX-ID1611 Digital I/O Terminals, and GX-OD1611 Digital I/O Terminals.

^{*2} Two each of the following: R88D-KNA-ECT AC Servo Drives, GX-ID1600 Digital I/O Terminals, and GX-OD1611 Digital I/O Terminals.

^{*3} One NX-PF0630 Additional I/O Power Supply Unit, three NX-ID5342 Digital Input Units, two NX-OD3153 Digital Output Units, one NX-AD4608 Analog Input Unit, and one NX-DA3605 Analog Output Unit.

^{*4} Two NX1W-CIF01 Serial Communications Option Boards.

^{*5} Four CJ1W-SCU22 Serial Communications Units and one CJ1W-EIP21 EtherNet/IP Unit.

^{*6} Eight each of the following: R88D-KNA-ECT AC Servo Drives, GX-ID1611 Digital I/O Terminals, and GX-OD1611 Digital I/O Terminals.

9-2-2 Restore (SD Memory Card to Controller)

You can transfer the data in a backup file on the SD Memory Card in the CPU Unit to the Controller. You can use the front-panel DIP switch on the CPU Unit or system-defined variables to perform this operation.

The transfer starts when the power supply is turned ON with the CPU Unit front-panel DIP switch. You can specify the data to restore by the restore command file. You cannot specify the source directory for backup-related files. The backup file to restore must be stored in the root directory on the SD Memory Card.

With system-defined variables, you can specify the data to restore and source directory for backuprelated files, and give a command to start the transfer by a system-defined variable. You can specify whether to use this function or not and set a password in the Controller Setup. You can use this function to operate the CPU Unit with the data in a backup file on the SD Memory Card, by operating an HMI.

Processing Contents

The following describes the processing contents for restoring data with the CPU Unit front-panel DIP switch and with system-defined variables.

Restoring Data with the CPU Unit Front-panel DIP Switch

- The data in a backup file in the root directory on the SD Memory Card is transferred to the Controller.
- The data groups that are processed by the restoration operation in the RestoreCommand.ini file (restore command file) that is stored in the root directory. Refer to 9-13-3 Specifications of a Restore Command File for details on the restore command file.
- If there is not a restore command file in the root directory of the SD Memory Card, all of the data from the backup files in the root directory that can be transferred to the Controller will be transferred.
- · After the operation is completed, the operating mode will change to PROGRAM mode. You cannot start operation in this state. To start operation, turn OFF all DIP switch pins and then cycle the power supply to the Controller or reset the Controller.
- Cycle the power supply to all of the EtherCAT slaves after you restore data.
- While the data is being restored, the CPU Unit will be in startup state.
- · If an error occurs in the checks that are performed before starting to restore the data, the previous data will be retained in the Controller.
- If the power supply to the Controller is interrupted while the data is being restored, a User Program/Controller Configurations and Setup Transfer Error (a major fault level Controller error) will occur. If that occurs, the data in the Controller is not dependable. Use one of the following methods to clear the error
 - Perform the restore operation again.
 - Clear all of memory and then download the project from the Sysmac Studio.
- If the configuration for Units and slaves in the backup file does not match the actual configuration where data is restored, a Restore Execution Error will occur when you restore the data.
- The restore operation is possible even if the Option Board configuration in the backup file do not match the actual configuration where data is restored. However, the Option Board does not operate. Refer to the NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual (Cat. No. W579) for details.
- If the present values of variables that are set to be retained (with the Retain attribute) are not set to be restored, the previous present values of those variables will be retained. However, the values of any variables that do not meet the retain conditions are initialized. These are the retain conditions for the variable:
 - The variable name, data type name, and data type size must be the same before and after restoring the data.

- For the NX102 CPU Unit and NX1P2 CPU Unit, memory for CJ-series Units is generated by the settings in the Memory Settings for CJ-series CPU Units in the backup file.
- If the present values of memory for CJ-series Units are not set to be restored in the NX102 CPU Unit
 or NX1P2 CPU Unit, the previous present values in the DM, EM and Holding Areas will be retained.
 However, when the DM, EM and Holding Areas are newly generated or the area is expanded, the values in those areas will be the initial values.
- The SD Memory Card will remain mounted after completion of the restore operation.
- The write protection for the CPU Unit that is set in the Write Protection at Startup setting is used after completion of the restore operation.

Restoring Data with System-defined Variables



Precautions for Correct Use

- The data to be restored is the group of data specified with the system-defined variable. A
 specification of the restore command file (RestoreCommand.ini) is not affected. Refer to
 Related System-defined Variables on page 9-24 for details on the related system-defined variables.
- To prevent an unexpected restoration, set to enter the password every time before the restore operation.
- Executing this function automatically resets the Controller. The outputs during the Controller reset behave according to the slave and Unit specifications. Also, during the Controller reset, variables in the Controller cannot be accessed from the outside.
- If a variable on the Controller that was accessed before the transfer is deleted by the restoration, the system-defined variables may not be accessed because the deleted variable cannot be recovered by an HMI. For example with an NS-series PT, if the tag verification result finds any inconsistency, the list of tag verification result is displayed and the screen cannot be changed to others. Confirm, in advance, no such error occurs on the HMI you will use.
- If the power is interrupted while this function is in progress, a User Program/Controller Configurations and Setup Transfer Error (event code 10200000 hex) or other errors may occur.
- You cannot execute the restore by the system-defined variable after you transfer a backup file
 for which Restore by system-defined variable is set to Do not use in the Controller Setup. If
 you intend to continue restoring, transfer a backup file for which the above setting is set to
 Use.
- You cannot execute other backup function while a restore operation is in progress.
- With the _Card1RestoreCmd (SD Memory Card Restore Command) system-defined variable, you
 can transfer the data saved in the SD Memory Card that is mounted on the CPU Unit to the Controller.
- The backup file to be restored is the file stored in the directory specified with the system-defined variable. The target backup file must be stored in a directory on the SD Memory Card in advance.
- If the password set on the Password of the SD Memory Card Restore Setting differs from the password set in the _Card1RestoreCmd.Password system-defined variable, the Restore Operation Failed to Start error occurs.
- When the restore is started, the password set in the _Card1RestoreCmd.Password system-defined variable is initialized.
- The Controller is automatically reset during the restore operation.
- After the Controller reset, the CPU Unit will be in startup state. After the restore operation is completed, the operating mode will change to PROGRAM mode. You cannot start operation in this state. To start operation, cycle the power supply to the Controller or reset the Controller.
- Cycle the power supply to all of the EtherCAT slaves after you restore data.
- If an error occurs in the checks that are performed before starting the restore operation or in the preexecution checks, the previous data will be retained in the Controller.

- If the power supply to the Controller is interrupted while the data is being restored, a User Program/Controller Configurations and Setup Transfer Error (a major fault level Controller error) will occur. If that occurs, the data in the Controller is not dependable. Use one of the following methods to clear the error.
 - Perform the restore operation again.
 - Clear all of memory and then download the project from the Sysmac Studio.
- All data items that are not specified for the restore will retain their present values.
- If the present values of variables that are set to be retained (with the Retain attribute) are not set to be transferred, the previous present values of those variables will be retained. However, the values of any variables that do not meet the retain conditions are initialized. These are the retain conditions for the variable.
 - The variable name, data type name, and data type size must be the same before and after transferring the data.
- If the present values of memory for CJ-series Units are not set to be restored in the NX102 CPU Unit or NX1P2 CPU Unit, the previous present values in the DM, EM and Holding Areas will be retained. However, when the DM, EM and Holding Areas are newly generated or the area is expanded, the values in those areas will be the initial values.
- The power is continued to supply even if the SD Memory Card power supply switch is pressed when a restore operation is in progress.
- The SD Memory Card will remain mounted after completion of the restore operation.
- The write protection for the CPU Unit that is set in the Write Protection at Startup setting is used after completion of the restore operation.

Procedure

Restoring Data with the CPU Unit Front-panel DIP Switch

Processing stage	Procedure
Start command	Turn ON the power supply to the Controller with the DIP switch set as follows: 1: OFF, 2:
	OFF, 3: ON, and 4: ON.*1
Executing	While Restoring Data
	The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds. The RUN indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds. The SD BUSY indicator will flash irregularly.
Execution results	Normal End:
	The SD PWR indicator will light.
	Error End:
	The SD PWR indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds. The indicator stop flashing and stay lit when the SD Memory Card power supply switch is pressed.*2

^{*1} For the NX701 CPU Unit, set all of pins 5 to 8 on the DIP switch to OFF.

^{*2} If an SD Memory Card is not inserted, the SD PWR indicator will not light.

Restoring Data with the _Card1RestoreCmd (SD Memory Card Restore Command) System-defined Variable

Processing stage	Procedure
Pre-start prepara-	To use the restore by the system-defined variable, set to use the Restore by system-
tion	defined variable in the Controller Setup.*1
Start command	Specify the name of the directory where the backup files are saved in the _Card1Resto-reCmd.DirName (Directory Name) system-defined variable.
	Example: "dirA/dirB" specifies the dirB directory inside the dirA directory.
	Specify a password in the _Card1RestoreCmd.Password (Password) system-defined variable.*2
	Change the _Card1RestoreCmdTargetIPAdr (IP Address Transfer Flag) system-defined variable to TRUE to specify IP address of the built-in EtherNet/IP port as the restore target.*3
	Change the _Card1RestoreCmdTargetVariable (Present Values of Variables with the Retain Attribute Transfer Flag) system-defined variable to TRUE to specify the present values of variables with the Retain attribute as the restore target.
	Change the _Card1RestoreCmdTargetMemory (Present Values of Memory Used for CJ-series Units with the Retain Attribute Transfer Flag) system-defined variable to TRUE to specify the present values of the memory used for CJ-series Units with the Retain attribute as the restore target.
	Change the _Card1RestoreCmdTargetUnitConfig (Unit and Slave Parameters Transfer Flag) system-defined variable to TRUE to specify Units and slaves settings as the restore target.
	Change the _Card1RestoreCmdTargetAbsEncoder (Absolute Encoder Home Offset Transfer Flag) system-defined variable to TRUE to specify the absolute encoder home offsets as the restore target.
	The restore operation starts when you change the _Card1RestoreCmd.Exec (Execute Restore Flag) system-defined variable to TRUE.
Executing	The _BackupBusy (Backup Function Busy Flag) system-defined variable changes to TRUE.
	The _Card1RestoreSta.Active (Active Flag) system-defined variable changes to TRUE.
	While Restoring Data
	The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds.
	The SD BUSY indicator will flash irregularly.
	The RUN indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds.
	The Controller is automatically reset during the restore operation.
Execution results	Normal End:
	The SD PWR indicator will light.
	The RUN indicator goes out.
	The _Card1RestoreSta.Done (Done Flag) system-defined variable changes to TRUE.
	Error End at Checks Performed Before Restore Start:
	The SD PWR indicator will light.*4
	RUN and ERR indicators are in the state before the restore starts.
	The _Card1RestoreSta.Err (Error Flag) system-defined variable changes to TRUE.
	The Controller is not reset for an error end at checks performed before restore start.
	Error End at Pre-execution Check or during Execution:
	The SD PWR indicator will light.* 4
	The RUN indicator goes out.
	The _Card1RestoreSta.Err (Error Flag) system-defined variable changes to TRUE.

- *1 You cannot execute the restore by the system-defined variable after you transfer a backup file for which Restore by system-defined variable is set to Do not use in the Controller Setup. If you intend to continue restoring, transfer a backup file for which the above setting is set to Use.
- *2 The password is initialized when the restore by the system-defined variable is started. Specify a password every time you start a restore.
 - If a password is not set on the Password of the SD Memory Card Restore Setting on the Controller Setup, the restore is started when the value of the _Card1RestoreCmd.Password system-defined variable is the initial value. The restore is not started if the value is not the initial value.
- *3 The IP address means setting type, IP address, subnet mask, and default gateway.
- *4 If an SD Memory Card is not inserted, the SD PWR indicator will not light.

Related System-defined Variables

The following table lists the related system-defined variables. Refer to A-7 Specifications for Individual System-defined Variables for details on system-defined variables.

Variable name	Meaning	Function	Data turna	R/W
Member name	Wieaming	Function	Data type	IK/VV
_Card1RestoreCmd	SD Memory Card Restore Com- mand		_sRE- STORE_C MD	RW
Exec	Execute Restore Flag	Change this variable to TRUE to restore the data in a backup file on the SD Memory Card to the Controller.	BOOL	RW
DirName	Directory Name	Use this variable to specify the directory name in the SD Memory Card in which the backup file to be restored by the system-defined variable is stored.	STRING (64)	RW
Password	Password	Use this variable to specify the password that is used for verification when you start the restore by the system-defined variable. The password is initialized every time you start transferring programs from the SD Memory Card.	STRING(3 3)	RW
_Card1RestoreSta	SD Memory Card Restore Status		_sRE- STORE_S TA	R
Done	Done Flag	TRUE when a restore operation is completed.	BOOL	R
Active	Active Flag	TRUE when a restore operation is in progress.	BOOL	R
Err	Error Flag	TRUE when a restore operation ended in an error.	BOOL	R

Variable Name	Meaning	Function	Data type	R/W
_Card1RestoreCmd- TargetUserProgram	User Program and Settings Transfer Flag	Change this variable to TRUE to set a user program or setting for the restore by the system-defined variable as the transfer target.	BOOL	RW
		Always set this variable to TRURE for the restore by the system-defined variable.		
_Card1RestoreCmd- TargetlPAdr	IP Address Transfer Flag	Change this variable to TRUE to include the IP address of the built-in EtherNet/IP port for the restore by the system-defined variable as the transfer target.	BOOL	RW
		The IP address means setting type, IP address, subnet mask, and default gateway.		

Variable Name	Meaning	Function	Data type	R/W
_Card1RestoreCmd- TargetVariable	Present Values of Variables with the Retain Attri- bute Transfer Flag	Change this variable to TRUE to set the present values of variables with the Retain attribute for the restore by the system-defined variable as the transfer target.	BOOL	RW
_Card1RestoreCmd- TargetMemory	Present Values of Memory Used for CJ-series Units with the Retain Attribute Transfer Flag	Change this variable to TRUE to set the present values of the memory used for CJ-series Units with the Retain attribute for the restore by the system-defined variable as the transfer target.	BOOL	RW
_Card1RestoreCmd- TargetUnitConfig	Unit and Slave Parameters Transfer Flag	Change this variable to TRUE to set the Unit and slave settings for the restore by the system-defined variable as the transfer target.	BOOL	RW
_Card1RestoreCmd- TargetAbsEncoder	Absolute Encoder Home Offset Transfer Flag	Change this variable to TRUE to set the absolute encoder home offset for the restore by the system-defined variable as the transfer target.	BOOL	RW



Additional Information


- Refer to the *NA-series Programmable Terminal Software User's Manual* (Cat. No. V118) for information on mapping variables when you connect an NA-series PT to the NJ/NX-series Controller.
- Refer to A-11 Registering a Symbol Table on the CX-Designer for the procedure to register these system-defined variables in the variable table of the CX-Designer when you connect an NS-series PT to the NJ/NX-series Controller.

Timing Charts


The operation of the system-defined variables when they are used for the restart of SD Memory Card backups is shown below.

In the charts, "checks performed before starting" indicates the processing performed before the restore operation to check whether the password matches. The value of _Card1PrgRestoreSta.Active (Active Flag) changes to TRUE only after the checks performed before starting result in OK.


Normal Operation



Operation When the Restoration Cannot Start Because Another Backup **Function Is in Progress**



Operation When the Restoration Fails After a Normal Start



Processing Time

The time that is required to restore the data depends on factors such as the CPU Unit, Unit configuration, and user program. Guidelines for the restoration time are given in the following table.

CPU Unit	Connected EtherCAT slaves	Connected NX Units or CJ- series Units	Connected Option Boards	Number of user-defined POUs	User program memory size (Mbytes)	Restoration time (s)
NX701-000	*1			113	7.13	Approx. 50
NX102-000	*2	*3		15	0.37	Approx. 70
NX1P2-000	*2	*3	*4	15	0.35	Approx. 60
NJ501-□□□□	*1	*5		53	2.36	Approx. 100
NJ301-□□□□	*6			20	0.53	Approx. 70
NJ101-□□□□	*2			15	0.38	Approx. 70

- *1 Thirty-two each of the following: R88D-KNA-ECT AC Servo Drives, GX-ID1611 Digital I/O Terminals, and GX-OD1611 Digital I/O Terminals.
- *2 Two each of the following: R88D-KNA-ECT AC Servo Drives, GX-ID1600 Digital I/O Terminals, and GX-OD1611 Digital I/O Terminals.
- *3 One NX-PF0630 Additional I/O Power Supply Unit, three NX-ID5342 Digital Input Units, two NX-OD3153 Digital Output Units, one NX-AD4608 Analog Input Unit, and one NX-DA3605 Analog Output Unit.
- *4 Two NX1W-CIF01 Serial Communications Option Boards.
- *5 Four CJ1W-SCU22 Serial Communications Units and one CJ1W-EIP21 EtherNet/IP Unit.
- 6 Eight each of the following: R88D-KNA-ECT AC Servo Drives, GX-ID1611 Digital I/O Terminals, and GX-OD1611 Digital I/O Terminals.

9-2-3 **Verify (between Controller and SD Memory Card)**

You can compare the Controller data and the data in a backup file on the SD Memory Card in the CPU Unit.

Processing Contents

- The Controller data and the data in a backup file that is saved in the specified directory of the SD Memory Card are compared.
- The data groups that are processed by the verification operation are specified in the RestoreCommand.ini file (restore command file).
- The present values of variables, the present values in memory used for the CJ-series Units, and the absolute encoder home offsets are not compared because these values may change while the verification is in process.
- · When you verify the data, the verification results file (VerifyResult.log) is created in the specified directory. The verification results are stored in this file. If a verification results file already exists in the specified directory, it will be overwritten. However, if the SD Memory Card is write-protected, the verification results files will not be created.
- If there is not a restore command file in the specified directory of the SD Memory Card, all of the data from the backup files in the specified directory that can be compared will be compared.
- If the Unit and slave configuration in the backup file is not the same as the actual configuration of the Controller, a Verification Error will occur.
- The SD Memory Card will remain mounted after completion of the verification operation.

Procedure

Verifying Data with the CPU Unit Front-panel DIP Switch

Processing stage	Procedure
Start command	The verification operation starts when the SD Memory Card power supply switch is pressed for 3 seconds with the DIP switch pins set as follows: 1: OFF, 2: OFF, 3: OFF, and 4: OFF.*1
Executing	Immediately after Starting Verification*2
	The SD PWR indicator will light, go out for 0.5 seconds, and then light again.
	While Verifying Data
	The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds.
	The SD BUSY indicator will flash irregularly.
	The value of the _BackupBusy (Backup Function Busy Flag) system-defined variable will change to TRUE.
Execution results	Normal End with No Differences Found:
	The SD PWR indicator will light.
	Normal End with Differences Found:
	The SD PWR indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds. The indicator stop flashing and stay lit when the SD Memory Card power supply switch is pressed.
	Error End:
	The SD PWR indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds. The indicator stop flashing and stay lit when the SD Memory Card power supply switch is pressed.*1

^{*1} For the NX701 CPU Unit, set all of pins 5 to 8 on the DIP switch to OFF.

^{*2} If an SD Memory Card is not inserted, the SD PWR indicator will not light.

Verifying Data with the _Card1BkupCmd (SD Memory Card Backup Command) System-defined Variable

Processing stage	Procedure		
Start command	The name of the directory where the files are saved is stored in the _Card1BkupCmd.Dir-Name (Directory Name) system-defined variable.		
	Example: "dirA/dirB" specifies the dirB directory inside the dirA directory.		
	The verification operation starts when you change the _Card1BkupCmd.ExecVefy (Execute Verify Flag) system-defined variable to TRUE.		
Cancel command	You can cancel the verification operation.		
	The verification operation ends in an error if you change the _Card1BkupCmd.CancelVefy (Cancel Verify Flag) system-defined variable to TRUE.		
Executing	The _Card1VefySta.Active (Active Flag) system-defined variable changes to TRUE. The value of the _BackupBusy (Backup Function Busy Flag) system-defined variable will change to TRUE.		
Execution results	Normal End with No Differences Found:		
	The _Card1BkupSta.Done (Done Flag) and the _Card1BkupSta.VefyRslt (Verify Result Flag) system-defined variables change to TRUE.		
	Normal End with Differences Found:		
	The _Card1BkupSta.Done (Done Flag) system-defined variable changes to TRUE and the _Card1BkupSta.VefyRslt (Verify Result Flag) system-defined variable changes to FALSE		
	Error End:		
	The _Card1BkupSta.Err (Error Flag) system-defined variable changes to TRUE.		

Note You cannot access these system-defined variables from the user program.

• Verifying Data from the SD Memory Card Window on the Sysmac Studio

Processing stage	Procedure
Start command	Click the Compare SD Memory Card Backup Button on the SD Memory Card Window in Sysmac Studio, specify the directory that contains the file to compare, and execute the verification.
Executing	The progress of the verification is displayed in the dialog box. The value of the _BackupBusy (Backup Function Busy Flag) system-defined variable will change to TRUE.
	The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds.
	The SD BUSY indicator will flash irregularly.
Execution results	The results of the verification are displayed in the dialog box.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for specific procedures.

Related System-defined Variables

The system-defined variables that are related to the operation when system-defined variables are used to restore data are shown below. Refer to *A-7 Specifications for Individual System-defined Variables* for details on system-defined variables.

Variable name	Meaning	Function	Data type	R/W	
Member name	Wearing	Function	Data type	FK/VV	
_Card1BkupCmd* SD Memory Card Backup Commands			_sBKUP_CMD	RW	
ExecVefy*	Execute Verify Flag	Change this variable to TRUE to compare the Controller data to a backup file in the SD Memory Card.	BOOL	RW	
CancelVefy*	Cancel Verify Flag	Change this variable to TRUE to cancel comparing the Controller data to a backup file in the SD Memory Card.	BOOL	RW	
DirName*	Directory Name	Use this variable to specify the directory name in the SD Memory Card for which to back up data.	STRING(64)	RW	
_Card1VefySta*	SD Memory Card Verify Status		_sVEFY_STA	R	
Done*	Done Flag	TRUE when a verification is completed.	BOOL	R	
Active*	Active Flag	TRUE when a verification is in progress.	BOOL	R	
VefyRslt*	Verify Result Flag	TRUE if the data was the same. FALSE if differences were found.	BOOL	R	
Err*	Error Flag	TRUE when processing a verification ended in an error.	BOOL	R	
BackupBusy	Backup Function Busy Flag	TRUE when a backup, restoration, or verification is in progress.	BOOL	R	

You cannot access these system-defined variables from the user program.




Additional Information

- Refer to the NA-series Programmable Terminal Software User's Manual (Cat. No. V118) for information on mapping variables when you connect an NA-series PT to the NJ/NX-series Controller.
- Refer to A-11 Registering a Symbol Table on the CX-Designer for the procedure to register these system-defined variables in the variable table of the CX-Designer when you connect an NSseries PT to the NJ/NX-series Controller.


Timing Charts

The operation of the system-defined variables when they are used to verify data is shown below. In the charts, "pre-execution checks" indicates processing to check whether there is a SD Memory Card in the CPU Unit and other items. The value of *_Card1VefySta.Active* (Active Flag) changes to TRUE only after all of the pre-execution checks are cleared and the actual verification is started.


Normal End with No Differences Found




Normal End with Differences Found



Operation When the Verification Cannot Start Because Another Backup **Function Is in Progress**




Operation When the Verification Fails After a Normal Start



Operation When the Operation Is Canceled While Verification Is in Progress

The time required to stop the verification operation after it is canceled depends on the progress of the verification operation.



9-3 Disabling Backups to SD Memory Cards


You can disable the backup function from writing data to the SD Memory Card to protect your programming assets.

The following three functions are applicable for disabling backup to SD Memory Card.

- · Backups using the CPU Unit front-panel DIP switch
- · Backups using system-defined variables
- · Backups from the SD Memory Card Window on the Sysmac Studio

Backup function using the BackupToMemoryCard instruction is not applicable. This means that you can backup data using the BackupToMemoryCard instruction even if the *Prohibit data backup to the SD Memory Card* setting is set to be used.

Use the following procedure to set the *Prohibit data backup to the SD Memory Card* setting. Select the *Use* Option for the **Prohibit data backup to the SD Memory Card** setting in the Basic Settings Display of the Operation Settings Tab Page under **Configurations and Setup** – **Controller Setup** on the Sysmac Studio.






Version Information

A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the BackupToMemoryCard instruction.

9-4 Automatic Transfers from SD Memory Cards

This function automatically transfers the data in a backup file to the Controller when the power supply is turned ON. The backup file must be stored in the /autoload directory on the SD Memory Card in the CPU Unit. You can use this to operate the CPU Unit with the data in a backup file on the SD Memory Card. The only way to perform this operation is to use the front-panel DIP switch on the CPU Unit.



The automatic transfer uses a backup file that is created with the backup function and an automatic transfer command file. Save both files in the /autoload directory in advance.

File	Function
Backup file	This file contains the Controller data that is handled by the functions that are related to data backup.
Automatic transfer command file	This file specifies the data groups to transfer when transferring data from a SD Memory Card. You can edit this file with a text editor on a computer to specify the data groups to transfer.

The following tables gives the procedure, the applicable directory, and the timing at which the transfer is executed.

Procedure	Directory	Execution timing
CPU Unit front-panel DIP switch	/autoload directory on the SD Memory Card	At startup

Processing Contents

- When the power is turned ON, the data in the backup file in the /autoload directory on the SD Memory Card is automatically transferred to the Controller.
- The automatic transfer function transfers the data in the data groups that are specified in the Autload-Command.ini file in the /autoload directory. Refer to 9-13-4 Specifications of an Automatic Transfer Command File for details on the automatic transfer command file.
- If an AutoloadCommand.ini file is not in the /autoload directory on the SD Memory Card, all of the data from the backup file in the /autoload directory that can be transferred will be transferred.
- The operating mode that is set in the Startup Mode setting in the Controller Setup is used after completion of the automatic transfer.
- While the data is being automatically transferred, the CPU Unit will be in startup state.
- If an error occurs in the checks that are performed before starting the automatic transfer, the previous data will be retained in the Controller.
- If the power supply to the Controller is interrupted while the data is being automatically transferred, a User Program/Controller Configurations and Setup Transfer Error (a major fault level Controller error) will occur. If that occurs, the data in the Controller is not dependable. Use one of the following methods to clear the error.
 - Perform the automatic transfer again.

- Clear all of memory and then download the project from the Sysmac Studio.
- All data items that are not specified for the automatic transfer will retain their present values.
- If the present values of variables that are set to be retained (with the Retain attribute) are not set to be transferred, the previous present values of those variables will be retained. However, the values of any variables that do not meet the retain conditions are initialized. These are the retain conditions for the variable:
 - The variable name, data type name, and data type size must be the same before and after transferring the data.
- For the NX102 CPU Unit and NX1P2 CPU Unit, memory for CJ-series Units is generated by the settings in the Memory Settings for CJ-series CPU Units in the backup file.
- If the present values of memory for CJ-series Units are not set to be restored in the NX102 CPU Unit or NX1P2 CPU Unit, the previous present values in the DM, EM and Holding Areas will be retained. However, the values in the DM, EM and Holding Areas, which are newly generated or the area is expanded, will be the initial values.
- The SD Memory Card will remain mounted after completion of the automatic transfer operation.
- The write protection for the CPU Unit that is set in the Write Protection at Startup setting is used after completion of the automatic transfer operation.

Procedure

Transferring Data with the CPU Unit Front-panel DIP Switch

Processing stage	Procedure	
Start command	Turn ON the power supply to the Controller with the DIP switch set as follows: 1: OFF, 2: ON, 3: OFF, and 4: OFF.*1	
Executing	The transfer is in progress.	
_	The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds. The RUN indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds. The SD BUSY indicator will flash irregularly.	
Execution results	Normal End:	
	The SD PWR indicator will light.	
	The operating mode that is set in the Startup Mode setting in the Controller Setup is used after completion of the transfer.	
	Error End:	
	The RUN indicator goes out, the ERR indicator lights, and a major fault level Controller error occurs.	
	The SD PWR indicator will light.*2	

^{*1} For the NX701 CPU Unit, set all of pins 5 to 8 on the DIP switch to OFF.


^{*2} If an SD Memory Card is not inserted, the SD PWR indicator will not light.

Program Transfer from SD Memory Card

With the Card1PrgTransferCmd (SD Memory Card Program Transfer Command) system-defined variable, you can transfer a program stored in the SD Memory Card that is mounted on the CPU Unit to the Controller.

You can specify whether to use this function or not and set a password in the Controller Setup.

You can use this function to operate the CPU Unit with the program in a backup file on the SD Memory Card, by operating an HMI.



The transfer uses a backup file that is created with the backup function. Save the backup file in a directory on the SD Memory Card in advance.

Use the system-defined variable to specify the directory that contains the backup file.

File	Function
Backup file	This file contains the Controller data that is handled by the functions that are related
	to data backup.

The execution method for the functions, applicable directory, and applicable operating modes are given in the following table.

Operating method	Directory*1	Applicable operating modes
System-defined variable	The directory that you specified in the system-defined variable	RUN mode and PROGRAM mode

^{*1} You can specify a directory only on the SD Memory Card.



Precautions for Correct Use

- When you use this function to transfer a program whose Startup Mode setting is set to RUN mode, the operating mode changes to RUN after the transfer is completed regardless of the status and setting before the transfer. Use this function after you confirm that system startup does not cause any problem.
- To prevent an unexpected transfer of a program, set to enter the password every time before a transfer.
- Executing this function automatically resets the Controller. The outputs during the Controller reset behave according to the slave and Unit specifications. Also, during the Controller reset, variables in the Controller cannot be accessed from the outside.
- When an EtherCAT slave is used or a motion control is executed, an error may occur on the EtherCAT Master Function Module or Motion Control Function Module after the program transfer is completed. If an error occurs, reset the error after the program transfer is completed. Refer to sample programming for the ResetMCError instruction in the NJ/NX-series Instructions Reference Manual (Cat. No. W502) for details on resetting errors in the user program.

- If a variable on the Controller that was accessed before the transfer is deleted by the program transfer, the system-defined variables may not be accessed because the deleted variable cannot be recovered by an HMI. For example with an NS-series PT, if the tag verification result finds any inconsistency, the list of tag verification result is displayed and the screen cannot be changed to others. Confirm, in advance, no such error occurs on the HMI you will use.
- If the power is interrupted while this function is in progress, a User Program/Controller Configurations and Setup Transfer Error (event code 10200000 hex) or other errors may occur.
- You cannot transfer programs after you transfer a backup file for which *Program transfer by* system-defined variable is set to *Do not use* in the Controller Setup. If you intend to continue transferring programs, transfer a backup file for which the above setting is set to *Use*.
- You cannot execute other backup function while a program transfer is in progress.

Processing Contents

- With the _Card1PrgTransferCmd (SD Memory Card Program Transfer Command) system-defined variable, you can transfer a program saved in the SD Memory Card that is mounted on the CPU Unit to the Controller.
- The backup file of the programs to be transferred is the file stored in the directory specified with the system-defined variable. The target backup file must be stored in a directory on the SD Memory Card in advance.
- The data of the programs to be transferred is the group of data specified with the system-defined variable. Refer to Related System-defined Variables on page 9-39 for details on the related systemdefined variables.
- If the password set on the *Password* of the *SD Memory Card Program Transfer Setting* differs from the password set in the *_Card1PrgTransferCmd.Password* system-defined variable, the SD Memory Card Program Transfer Failed to Start error occurs.
- When the program transfer is started, the password set in _Card1PrgTransferCmd.Password system-defined variable is initialized.
- The Controller is automatically reset during the program transfer. The outputs during the Controller reset behave according to the slave and Unit specifications.
- After the Controller reset, the CPU Unit will be in startup state. Then when the program transfer is
 completed, the CPU Unit will be in normal operation state and operate in the operating mode set in
 the Startup Mode setting in the Controller Setup, which was transferred by the program transfer function. However, the CPU Unit will operate in PROGRAM mode when the CPU Unit front-panel DIP
 switch is set to the Safe Mode.
- If an error occurs in the checks that are performed before starting the user program transfer or in the pre-execution checks, the previous data will be retained in the Controller.
- If the power supply to the Controller is interrupted while the program transfer is in progress, a User Program/Controller Configurations and Setup Transfer Error (a major fault level Controller error) will occur. If that occurs, the data in the Controller is not dependable. Use one of the following methods to clear the error.
 - Transfer the programs from the SD Memory Card again.
 - Use the automatic transfer from SD Memory Card, or restore with SD Memory Card backup functions.
 - Clear all of memory and then download the project from the Sysmac Studio.
- All data items that are not specified for the program transfer will retain their present values.
- If the present values of variables that are set to be retained (with the Retain attribute) are not set to be transferred, the previous present values of those variables will be retained. However, the values of any variables that do not meet the retain conditions are initialized. These are the retain conditions for the variable.
 - The variable name, data type name, and data type size must be the same before and after transferring the data.
- For the NX102 CPU Unit and NX1P2 CPU Unit, memory for CJ-series Units is generated by the settings in the Memory Settings for CJ-series CPU Units in the backup file.

- If the present values of memory for CJ-series Units are not set to be restored in the NX102 CPU Unit or NX1P2 CPU Unit, the previous present values in the DM, EM and Holding Areas will be retained. However, when the DM, EM and Holding Areas are newly generated or the area is expanded, the values in those areas will be the initial values.
- The power is continued to supply even if the SD Memory Card power supply switch is pressed while the program transfer is in progress.
- The SD Memory Card will remain mounted after completion of the program transfer operation.
- The write protection for the CPU Unit that is set in the Write Protection at Startup setting is used after completion of the program transfer operation.

Operating Method

_Card1PrgTransferCmd (SD Memory Card Program Transfer Command) **System-defined Variable**

Processing stage	Procedure
Pre-start prepara-	To use the program transfer from the SD Memory Card, set to use the <i>Program transfer by</i> system-defined variable in the Controller Setup.*1
Start command	Specify the name of the directory where the backup files are saved in the _Card1PrgTrans-ferCmd.DirName (Directory Name) system-defined variable.
	Example: "dirA/dirB" specifies the dirB directory inside the dirA directory.
	Specify a password in the _ <i>Card1PrgTransferCmd.Password</i> (Password) system-defined variable.*2
	Change the _Card1PrgTransferCmd.TargetIPAdr (IP Address Transfer Flag) system-defined variable to TRUE to specify the built-in EtherNet/IP port settings as the transfer target.*3
	Change the _Card1PrgTransferCmd.TargetVariable (Present Values of Variables with the Retain Attribute Transfer Flag) system-defined variable to TRUE to specify the present values of variables with the Retain attribute as the transfer target.
	Change the _Card1PrgTransferCmd.TargetMemory (Present Values of Memory Used for CJ-series Units with the Retain Attribute Transfer Flag) system-defined variable to TRUE to specify the present values of the memory used for CJ-series Units with the Retain attribute as the transfer target.
	Change the _Card1PrgTransferCmd.Exec (Execute Program Transfer Flag) system- defined variable to TRUE to start the transfer operation.
Executing	The _BackupBusy (Backup Function Busy Flag) system-defined variable changes to TRUE.
	The _Card1PrgTransferSta.Active (Active Flag) system-defined variable changes to TRUE.
	During program transfer
	The SD PWR indicator will flash, lighting for 3 seconds and going out for 0.5 seconds.
	The SD BUSY indicator will flash irregularly.
	The RUN indicator will flash, lighting for 0.5 seconds and going out for 0.5 seconds.
	The Controller is automatically reset during the program transfer.

Processing stage	Procedure
Execution results	Normal End:
	The SD PWR indicator will light.
	The operating mode that is set in the Startup Mode setting in the Controller Setup is used after completion of the transfer.
	The _Card1PrgTransferSta.Done (Done Flag) system-defined variable changes to TRUE.
	Error End at Checks Performed Before Transfer Start:
	The SD PWR indicator will light.*4
	RUN and ERR indicators are in the state before the transfer starts.
	The _Card1PrgTransferSta.Err (Error Flag) system-defined variable changes to TRUE.
	The Controller is not reset for an error end at checks performed before transfer start.
	Error End at Pre-execution Check or during Execution:
	The SD PWR indicator will light.*4
	The RUN indicator goes out, the ERR indicator lights, and a major fault level Controller error occurs.
	The _Card1PrgTransferSta.Err (Error Flag) system-defined variable changes to TRUE.

- *1 You cannot transfer programs after you transfer a backup file for which *Program transfer by system-defined variable* is set to *Do not use* in the Controller Setup. If you intend to continue transferring programs, transfer a backup file for which the above setting is set to *Use*.
- *2 The password is initialized when transferring programs from the SD Memory Card is started. Specify a password every time you start a transfer.
 - If a password is not set on the *Password* of the *SD Memory Card Program Transfer Setting* on the Controller Setup, the program transfer is started when the value of the *_Card1PrgTransferCmd.Password* system-defined variable is the initial value. The transfer is not started if the value is not the initial value.
- *3 The IP address means setting type, IP address, subnet mask, and default gateway.
- *4 If an SD Memory Card is not inserted, the SD PWR indicator will not light.

Related System-defined Variables

The following table lists the related system-defined variables. Refer to A-7 Specifications for Individual System-defined Variables for details on system-defined variables.

Variable name	Meaning	g Function	Data type	R/W	
	Member name			2000 1760	
_	Card1PrgTransfer- md	SD Memory Card Program Trans- fer Command		_sPRG- TRANS- FER_CMD	RW
	Exec	Execute Program Transfer Flag	Change this variable to TRUE to transfer the data in a backup file on the SD Memory Card to the Controller by using the function to transfer programs from the SD Memory Card.	BOOL	RW
	DirName	Directory Name	Use this variable to specify the directory name in the SD Memory Card for which to back up data.	STRING (64)	RW
•	Password	Password	Use this variable to specify the password that is used for verification when you start transferring the programs.	STRING(3 3)	RW
			The password is initialized every time you start transferring programs from the SD Memory Card.		

	Variable name	Meaning	Function	Data type	R/W
	TargetUserPro- gram	User Program and Settings Transfer	Change this variable to TRUE to set a user program or setting as the transfer target.	BOOL	RW
		Flag*1	Always set this variable to TRUE for transfer- ring programs from SD Memory Card.		
•	TargetIPAdr	IP Address Transfer Flag	Change this variable to TRUE to include the IP address of the built-in EtherNet/IP port as the transfer target.	BOOL	RW
			The IP address means setting type, IP address, subnet mask, and default gateway.		
	TargetVariable	Present Values of Variables with the Retain Attri- bute Transfer Flag	Change this variable to TRUE to set the present values of variables with the Retain attribute as the transfer target.	BOOL	RW
-	TargetMemory	Present Values of Memory Used for CJ-series Units with the Retain Attribute Transfer Flag	Change this variable to TRUE to set the present values of the memory used for CJ-series Units with the Retain attribute as the transfer target.	BOOL	RW
	Card1PrgTransfer- ta	SD Memory Card Program Trans- fer Status		_sPRG- TRANS- FER_STA	R
	Done	Done Flag	TRUE when a program transfer is completed.	BOOL	R
	Active	Active Flag	TRUE when a program transfer is in progress.	BOOL	R
	Err	Error Flag	TRUE when a program transfer ended in an error.	BOOL	R

^{*1} The data in the user program and setting data groups is the target of settings. However, the IP address for the built-in EtherNet/IP port is set with the IP Address Transfer Flag.



Additional Information


- Refer to the NA-series Programmable Terminal Software User's Manual (Cat. No. V118) for information on mapping variables when you connect an NA-series PT to the NJ/NX-series Controller.
- Refer to A-11 Registering a Symbol Table on the CX-Designer for the procedure to register these system-defined variables in the variable table of the CX-Designer when you connect an NS-series PT to the NJ/NX-series Controller.

Timing Charts


The operation of the system-defined variables when they are used to transfer programs from the SD Memory Card is shown below.

In the charts, "checks performed before starting" indicates the processing performed before the program transfer to check whether the password matches. The value of *_Card1PrgTransferSta.Active* (Active Flag) changes to TRUE only after the checks performed before starting result in OK.


Normal Operation



Operation When the Program Transfer Cannot Be Started Because Another Backup Function Is in Progress




• Operation When the Program Transfer Fails After a Normal Start of Program Transfer



9-6 Sysmac Studio Controller Backups

You can use Sysmac Studio to back up, restore, and verify Controller data from a computer.



When you back up data, the backup file, restore command file, and automatic transfer command file are created in the specified directory in the computer. The functions of the backup-related files are given in the following table.

	Function					
File	Contents	Backing up data	Restor- ing data	Verifying data		
Backup file	This file contains the Controller data that is handled by the functions that are related to data backup.	Created.	Accessed.	Accessed.		
Restore command file	This file specifies the data groups to transfer when restoring data. You can edit this file with a text editor on a computer to specify the data groups to transfer.	Created.	Accessed.	Accessed.		
Automatic transfer command file	This file specifies the data groups to transfer when automatically transferring data from a SD Memory Card. You can edit this file with a text editor on a computer to specify the data groups to transfer.	Created.	Nothing is done.	Nothing is done.		
Verification results files	These files contain the verification results after data is verified.	Nothing is done.	Nothing is done.	Created.		

You can execute these functions in the following operating modes.

Processing	Applicable operating modes
Backing up data	RUN mode and PROGRAM mode
Restoring data	PROGRAM mode
Verifying data	RUN mode and PROGRAM mode



Additional Information

You can change the operating mode of the CPU Unit while a backup or verification operation is in progress. However, an error will occur if the backup or verification cannot be processed normally due to faulty memory in the CPU Unit, or some other failure.

9-6-1 **Backup (Controller to Computer)**

The Controller data is saved in the specified directory on the computer.

Processing Contents

- For the Units and slaves settings in the backup data, you must select all EtherCAT slaves that are connected and all of the CJ-series Units that are connected.
- The backing up conditions for data groups are given in the following table.

Data group	Backing up condition
User program and settings	The CPU Unit must be selected.
IP address of built-in EtherNet/IP port*1	The CPU Unit must be selected.
Present values of variables	The CPU Unit must be selected.
Present values of memory used for CJ- series Units	The CPU Unit must be selected.
Event logs	The CPU Unit must be selected.
Units and slaves settings	The NX Units on the CPU Unit*2, CJ-series Units*3 and EtherCAT slaves must be selected.
Absolute encoder home offsets	The CPU Unit must be selected.

^{*1} A CPU Unit with unit version 1.14 or later and Sysmac Studio version 1.18 or higher are required.

- · When you back up data, the backup file, restore command file, and automatic transfer command file are created in the specified directory in the computer.
- If the backup-related files are already in the specified directory, they are overwritten.
- · If an error occurs while writing the backup-related files to specified directory, the previous backuprelated files will be deleted. Also, the new backup-related files will not be created.
- · If an error occurs before the new backup-related files are created, the previous files are retained and the new files are not created.
- The value of the _BackupBusy (Backup Function Busy Flag) system-defined variable will be TRUE during the backup operation.

Procedure

- Select Backup Backup Controller from the Tools Menu on the Sysmac Studio.
- Specify the folder in which to save the backup file, restore command file, and automatic transfer command file.
- Click the **Execute** Button on the Backup Confirmation Dialog Box. The data is backed up and the backup file, restore command file, and automatic transfer command file are created.

^{*2} You can select NX Units on the CPU Unit only for the NX102 CPU Units and NX1P2 CPU Units.

^{*3} You can select CJ-series Units only for NJ-series CPU Units.

9-6-2 Restore (Computer to Controller)

The data in a backup file in the specified directory on the computer is transferred to the Controller. This operation can only be performed in PROGRAM mode.

Processing Contents

- The data in a backup file in the specified directory on the computer is transferred to the Controller.
- You can select the data groups to restore from the Sysmac Studio. The conditions for restoring the data are given in the following table.

Data group	Restoring condition
User program and settings	The CPU Unit must be selected.
IP address of built-in EtherNet/IP port*1	The IP address of built-in EtherNet/IP port must be selected.
Present values of variables	The present values of variables that are specified for retention with the Retain attribute must be selected.
Present values of memory used for CJ- series Units	The present values of memory used for CJ-series Units that are specified for retention with the Retain attribute must be selected.*2
Units and slaves settings	The NX Units on the CPU Unit*3, CJ-series Units*2 and EtherCAT slaves must be selected.
Absolute encoder home offsets	The absolute encoder home offsets must be selected.

- *1 A CPU Unit with unit version 1.14 or later and Sysmac Studio version 1.18 or higher are required.
- *2 You can select the present values of variables with a Retain attribute in memory used for CJ-series Units only for the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.
- *3 You can select NX Units on the CPU Unit only for the NX102 CPU Units and NX1P2 CPU Units.
- If an error occurs in the checks that are performed before starting to restore the data, the previous data will be retained in the Controller.
- If the power supply to the Controller is interrupted while the data is being restored, a User Program/Controller Configurations and Setup Transfer Error (a major fault level Controller error) will occur. If that occurs, the data in the Controller is not dependable. Use one of the following methods to clear the error.
 - · Perform the restore operation again.
 - Clear all of memory and then download the project from the Sysmac Studio.
- If the present values of variables that are set to be retained (with the Retain attribute) are not set to be restored, the previous present values of those variables will be retained. However, the values of any variables that do not meet the retain conditions are initialized. These are the retain conditions for the variable:
 - The variable name, data type name, and data type size must be the same before and after restoring the data.
- The restore operation is possible even if the Option Board configuration in the backup file do not
 match the actual configuration where data is restored. However, the Option Board does not operate.
 Refer to the NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual (Cat. No.
 W579) for details.
- For the NX102 CPU Unit and NX1P2 CPU Unit, memory for CJ-series Units is generated by the settings in the Memory Settings for CJ-series CPU Units in the backup file.
- If the present values of memory for CJ-series Units are not set to be restored in the NX102 CPU Unit
 or NX1P2 CPU Unit, the previous present values in the DM, EM and Holding Areas will be retained.
 However, when the DM, EM and Holding Areas are newly generated or the area is expanded, the values in those areas will be the initial values.
- Cycle the power supply to all of the EtherCAT slaves after you restore data.

Procedure

- Select **Backup Restore Controller** from the Tools Menu on the Sysmac Studio.
- Specify the folder that contains the backup file and restore command file.
- **3** Click the **Execute** Button on the Restoration Confirmation Dialog Box. The restoration operation is executed.

9-6-3 Verify (between Controller and Computer)

The Controller data and the data in a backup file in the specified directory on the computer are compared.

Processing Contents

The Controller data and the data in a backup file in the specified directory on the computer are compared. You can select the data groups to verify from the Sysmac Studio. The conditions for verifying the data are given in the following table. If you specify all data, all of the following data will be compared.


Data group		Verification condition
User program and settings		The CPU Unit must be selected.
	IP address of built-in EtherNet/IP port*1	The IP address of built-in EtherNet/IP port must be selected.
Units and slaves settings		The NX Units on the CPU Unit*2, CJ-series Units*3 and EtherCAT slaves must be selected.

- *1 A CPU Unit with unit version 1.14 or later and Sysmac Studio version 1.18 or higher are required.
- *2 You can select NX Units on the CPU Unit only for the NX102 CPU Units and NX1P2 CPU Units.
- *3 You can select CJ-series Units only for NJ-series CPU Units.
- The results of the verification are displayed in the dialog box on the Sysmac Studio.
- The value of the _BackupBusy (Backup Function Busy Flag) system-defined variable will be TRUE during the backup operation.

Procedure

- 1 Select Backup Compare with Backup File from the Tools Menu on the Sysmac Studio.
- **2** Specify the folder that contains the backup file.
- 3 Click the **Execute** Button on the Comparison Confirmation Dialog Box.

The data is compared and the verification results files are created in the folder that contains the backup file. The comparison results are also displayed in the Output Tab Page.



Importing and Exporting Sysmac **Studio Backup File Data**

You can create or read from a backup file in the specified directory on the computer from the Sysmac Studio project without using the Controller. This following data is processed:

Function		Data group					
		-	orogram and settings	Duccount	Present values of	Units and	Absolute
			IP address of built-in EtherNet/IP port*2	Present values of variables	memory used for CJ-series Units*1	slaves settings	encoder home off- sets
Importing and exporting Sysmac Studio backup file	Exporting backup file data	OK*3	OK	OK	OK	×	×
data	Importing backup file data	OK*4	ОК	OK	OK	OK	×

^{*1} You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.

- *2 With a combination of the CPU Unit with unit version 1.14 or later and Sysmac Studio version 1.18 or higher, IP address of the Built-in EtherNet/IP Port Settings can be used as a data group. IP address is included in the user program and settings other than the above combination.
- *3 The following data is not processed:
 - The built-in EtherNet/IP port name in the Controller name
 - The built-in EtherNet/IP tag data link settings in the Controller Setup
 - · Words allocated to CPU Bus Units in the Unit Configuration and Unit Settings
 - · Operation authority verification
 - · Data Trace Settings
- *4 The following data is not processed. The data that is not processed depends on the version of the Sysmac Stu-

Using Sysmac Studio Version 1.16 or Higher

- The built-in EtherNet/IP port name in the Controller name
- · Words allocated to CPU Bus Units in the Unit Configuration and Unit Settings
- · Operation authority verification
- · Data Trace Settings

Using Sysmac Studio Version 1.15 or Lower

- The built-in EtherNet/IP port name in the Controller name
- The built-in EtherNet/IP tag data link settings in the Controller Setup
- · Words allocated to CPU Bus Units in the Unit Configuration and Unit Settings
- · Operation authority verification
- · Data Trace Settings


Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for more information on these functions.

9-8 Sysmac Studio Variable and Memory Backup Functions

You can back up the present values of the battery-backup memory in the CPU Unit to an XML file on your computer or restore the battery-backup memory from a previously saved backup file.

This section describes the applicable data, operating procedures, and CPU Unit model compatibility for the Sysmac Studio variable and memory backup functions.

Sysmac Studio



9-8-1 Applicable Data for Sysmac Studio Variable and Memory Backup Functions

Applicable Data for Sysmac Studio Variable and Memory Backup Functions

- · Present values of variables with a Retain attribute
- · Present values in the DM, EM, and Holding Areas of memory used for CJ-series Units
- · Absolute encoder home offsets

Note You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.



Version Information

With a CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher, you can select specific variables to back up or restore the present values of variables with a Retain attribute.

9-8-2 Using Sysmac Studio Variable and Memory Backup Functions

The Sysmac Studio procedure is as follows:

Place the Sysmac Studio online with the CPU Unit, and select either **Backup** – **Backup Variables and Memory** or **Backup** – **Restore Variables and Memory** from the Tools Menu.

Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details.

9-8-3 Compatibility between CPU Unit Models

With the Sysmac Studio variable and memory backup functions, you can restore the data even if the models of the CPU Units for backing up and restoring data are different.



Additional Information

Database Connection CPU Units, SECS/GEM CPU Units, NJ Robotics CPU Units, and NC Integrated Controller are not compatible.

Refer to the relevant manuals for specific Units for details on the compatibility of these CPU Units.



Version Information

The models of the CPU Units for backing up and restoring data can be different only when using a CPU Unit with version 1.04 or later and Sysmac Studio version 1.05 or higher. The compatibility for all other cases is given in the following table.

(C: Compatible, N: Not compatible.)

	CPU Unit model to restore to		
CPU Unit model where data was backed up	NJ501-1500 NJ501-1400 NJ501-1300	NJ301-1200 NJ301-1100	
NJ501-1500, NJ501-1400, or NJ501-1300	С	N	
NJ301-1200 or NJ301-1100	N	С	

The following precautions are required for the data that is being backed up and restored.

Present Values of Variables with a Retain Attribute

There are no precautions for the present values of variables with a Retain attribute. You can restore the data with no problems regardless of the models of the backup and restore CPU Units.

Present Values in the DM, EM, and Holding Areas of Memory Used for CJ-series Units

For memory used for CJ-series Units, if the area data saved in the backup file and area data in the actual CPU Unit to restore to are different, only the duplicated area data is restored.

The following precautions are necessary for the present values in the DM, EM, and Holding Areas of memory used for CJ-series Units if the models of the backup and restore CPU Units are different. An example of the NJ-series CPU Unit is given in the following table.

CPU Unit model where data was backed up	CPU Unit model to restore to	Precaution
NJ501-1300, NJ501-1400, or NJ501-1500	NJ301-1200, NJ301-1100, NJ101-1000, or NJ101-9000	For EM Area data, only data for banks E0 to E3 in the backup file is restored. The data for banks E4 to E18 in the backup file is ignored.
NJ301-1200, NJ301-1100, NJ101-1000, or NJ101-9000	NJ501-1300, NJ501-1400, or NJ501-1500	For EM Area data, only data for banks E0 to E3 in the backup file are restored. Banks E4 to E18 for the CJ-series Units retain their previous values.

The following provides examples when the area data saved in the backup file and area data in the actual CPU Unit to restore to are different.

If Area Data in the Backup File Is Larger Than Area Data in the Restore CPU Unit

Size of DM Area data	when backed up = 8	Size of DM Area data in the restore CPU Unit		
wo	rds	= 4 words		
Address	Value	Address	Value	
DM0	0x0001	DM0	0x0001	
DM1	0x0002	DM1	0x0002	
DM2	0x0003	DM2	0x0003	
DM3	0x0004	DM3	0x0004	
DM4	0x0005		-	
DM5	0x0006	-	-	
DM6	0x0007	-	-	
DM7	0x0008	-	-	

If Area Data in the Backup File Is Less Than Area Data in the Restore CPU Unit

Size of DM Area data when backed up = 8 words		Size of DM Area data in the restore CPU Unit = 4 words		
Address	Value	Address	Value	
DM0	0x0001	DM0	0x0001	
DM1	0x0002	DM1	0x0002	
DM2	0x0003	DM2	0x0003	
DM3	0x0004	DM3	0x0004	
		DM4	No change	
		DM5	No change	
		DM6	No change	
		DM7	No change	

Absolute Encoder Home Offsets

The following precautions are necessary for the absolute encoder home offsets if the models of the backup and restore CPU Units are different. An example of the NJ-series CPU Unit is given in the following table.

CPU Unit model where data was backed up	CPU Unit model to restore to	Precaution
NJ501-1300, NJ501-1400, or NJ501-1500	NJ301-1200, NJ301-1100, or NJ101-1000	Regardless of the number of enabled axes in the backup CPU Unit, the data for all axis in the backup file is restored in order for the number of enabled axes in the restore CPU Unit. Any remaining data in the backup file is ignored.
NJ301-1200, NJ301-1100, or NJ101-1000	NJ501-1300, NJ501-1400, or NJ501-1500	Regardless of the number of enabled axes in the backup CPU Unit, the data for all axis in the backup file is restored in order for the number of enabled axes in the restore CPU Unit. If the number of enabled axes in the restore CPU Unit exceeds the number of enabled axes for which there is data in the backup file, the remaining data in the restore CPU Unit retains the previous values.

Backup Functions When EtherCAT 9-9 **Slaves Are Connected**

For EtherCAT slaves, you can use the SD Memory Card backup functions, the Sysmac Studio Controller backup functions, and Sysmac Studio backup import function.

This section provides precautions for connected EtherCAT slaves for the data that is backed up, backup support according to Controller status, restore conditions, and specific models of EtherCAT



Additional Information

To use the backup functions for EtherCAT Slave Terminals, refer to 9-10 Backup Functions When EtherCAT Slave Terminals Are Connected.

Backed Up EtherCAT Slave Data 9-9-1

The data that is backed up for EtherCAT slaves is given in the following table.

Setting	Data that is backed up
EtherCAT Master Settings	The following data is backed up: Model name, Product name, Number of Slaves, PDO Communications Cycle, Fail-soft Operation Setting, Wait Time for Slave Startup, PDO communications timeout detection count, Revision Check Method, and Serial Number Check Method.
EtherCAT Slaves Settings	The following data is backed up: Device name, model name, product name, revision, node address, enabled/disabled settings, serial number, PDO map settings, enable distributed clock, reference clock, and setting parameter settings.

9-9-2 **Backup Support Depending on the Controller Status**

The following table shows when backup, restore, and verify operations can be performed for EtherCAT slaves based on the Controller status.

Controller status		Execution			
		Backing up data	Restoring data	Verifying data	
Link OFF		Not possible.*1	Not possible.*2	Possible.*3	
Illegal master status*4		Not possible.*1	Not possible.*2	Possible.*3	
Network configuration mismatch with configuration information*5		Not possible.*1	Not possible.*2	Possible. ³	
Network configuration mismatch with configuration at time of backup		Possible.	Not possible.*2	Possible.*3	
Disabled slave in net- work configuration	Disabled slaves in actual configuration	Possible. *6	Possible. *6	Possible. *6	
	No disabled slaves in actual configuration	Possible.	Possible.	Possible.	

Controller status		Execution			
		Backing up data	Restoring data	Verifying data	
Slave disconnected for "Disconnect" des- ignation in network configuration	for "Disconnect" designation in network		Possible, but data for disconnected slaves is not restored.	Possible, but data for disconnected slaves is not restored.	
	No disconnected slaves in actual configuration	Not possible.*1	Not possible.*2	Possible.*3	
Slave Initialization Erro	r	Not possible.*1	Not possible.*2	Possible.*3	

- *1 EtherCAT Slave Backup Failed events are recorded in the event log.
- *2 EtherCAT Slave Restore Operation Failed events are recorded in the event log.
- *3 The verification results will show differences.
- *4 This refers to the following errors: Duplicate Slave Node Address, Network Configuration Information Error, Network Configuration Error, Slave Initialization Error, Network Configuration Verification Error for Operation Setting of "Stop", and Link OFF Error.
- *5 This refers to the following errors: Network configuration mismatch with configuration when the backup was performed (incorrect connection ports for slaves on branched networks are treated as a mismatch) and network configuration information mismatch with actual network configuration (incorrect connection ports for slaves on branched network are treated as a match).
- *6 For a CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher, data for disabled slaves is also covered by the backup functions. Data for disabled slaves is not backed up for other versions.

9-9-3 Conditions for Restoring EtherCAT Slave Data

The following conditions must be met before you can restore the backup data to the EtherCAT slaves.

- The backup files must contain the EtherCAT slave data.
- The Network Configuration Information must match the actual network configuration where data is being restored.
- The revision values that are preset in the EtherCAT slaves must match. The conditions used to evaluate the match are based on the Revision Check Method in the backup file. Even if you set the Revision Check Method to not check revisions, the restoration operation cannot be performed if the set revision is greater than the actual revision of the slave. You cannot change the revision values.
- The serial numbers must match if the Serial Number Verification setting in the backup file is set to verify the serial numbers.
- The node addresses must match if the hardware switches are used to set the node address.



Precautions for Correct Use

- Cycle the power supply to all of the EtherCAT slaves after you restore data.
- All slaves are disconnected after the data is restored. You must connect the target slaves again to reset the disconnected slaves.
- If you set the Serial Number Verification setting in the backup file to verify the serial numbers,
 the data cannot be restored if you replace any of the hardware for the EtherCAT slaves. In this
 case, change the network configuration in Sysmac Studio and download the configuration data
 to the new slaves. Then, transfer the slave parameters to restore the slaves to their original
 condition. If the node address is set on the hardware switches, use the same setting as when
 the data was backed up.

EtherCAT Slaves for Which You Can Back Up Data 9-9-4

You can back up data for the following EtherCAT slaves. Observe the precautions.

EtherCAT slaves	Precautions
NX-ECC NX-series EtherCAT Coupler Unit	You cannot back up, restore, or compare data for Safety Control Units on EtherCAT Slave Terminals. Refer to the <i>NX-series Safety Control Unit User's Manual</i> (Cat. No. Z930) for information on importing and exporting settings for a Safety Control Unit.
R88D-1SN□□□-ECT AC Servo Drives	*1
R88D-KN□□□-ECT AC Rotary Servo Drives	*1*2
R88D-KN□□□-ECT-L AC Linear Servo Drives	*1*2
3G3AX-MX2-ECT and 3G3AX-RX-ECT Inverters	 When the unit version of the CPU Unit is 1.11 or later, the inverter parameters are not included in the restore target. An EtherCAT Slave Restore Operation Failed event (event code 10300000 hex) will not occur for Inverters. Refer to Procedure to Write Parameters for an 3G3AX-MX2-ECT or 3G3AX-RX-ECT Inverter on page 9-55 to write the parameters from the Sysmac Studio to the Inverter. If you execute verification without writing the parameters, the verification result for the inverter will be Not matched in the EtherCAT slaves verification result file. When the unit version of the CPU Unit is 1.10 or earlier, data is sometimes not restored due to Inverter restrictions. If an EtherCAT Slave Restore Operation Failed event (event code 10300000 hex) occurs when you try to restore the data, use the procedure that is given below in Procedure to Write Parameters for an 3G3AX-MX2-ECT or 3G3AX-RX-ECT Inverter on page 9-55 to transfer the parameters from the Sysmac Studio to the Inverter. Note that even if the restore operation for the Inverter fails, all other data are restored including settings of Units and slaves, user program settings,
FH-3□□□□ and FH-1□□□□ Vision Sensors	and present values of variables. The setup data for these Vision Sensors (such as the scene data and system data) is not backed up, restored, or verified. To transfer the setup data to an external file or to the Vision Sensor, select Sensor data – Save to file or Sensor data – Load from file from the Tools Menu on the editing tab page for the Configurations and Setup of the Sysmac Studio. Refer to the Vision System FH/FZ5 series User's Manual (Cat. No. Z340) for details.
FQ-M□□□□-ECT and FQ-M□□□□-M-ECT Vision Sensors	The setup data for these Vision Sensors (such as the scene data and system data) is not backed up, restored, or verified. To transfer the setup data to an external file or to the Vision Sensor, select Sensor data – Save to file or Sensor data – Load from file from the Tools Menu on the editing tab page for the Configurations and Setup of the Sysmac Studio. For details, refer to the FQ-M-series Specialized Vision Sensor for Positioning User's Manual (Cat. No. Z314).
FZM1-□□□-ECT Vision Sensors	The setup data for these Vision Sensors (such as the scene data and system data) is not backed up, restored, or verified. To save the setup data for the Vision Sensor to a USB memory device or to write it to the Controller, use the software tool for the Vision Sensor. Refer to the FZ3 Series Vision Sensor User's Manual (Cat. No. Z290) for details.
GX-□D16□□, GX-□D32□8, and GX-OC1601 Digital I/O Ter- minals	*1

EtherCAT slaves	Precautions
GX-AD0471 and GX-DA0271 Analog I/O Terminals	*1
GX-EC0211 and GX-EC0241 Encoder Input Terminals	
GX-JC0□ EtherCAT Junction Slaves	There is no internal data that needs to be backed up.
ZW-CE1 T Confocal Fiber Type Displacement Sensors	None of the settings are backed up, restored, or verified. Refer to the <i>Displacement Sensor ZW Series Confocal Fiber Type Displacement Sensor Users Manual</i> (Cat. No. Z332) for information on saving the settings and loading them to the Controller.
E3NW-ECT and E3X-ECT Digital Sensors	The parameters in the Sensor are not backed up, restored, or verified.
Slaves from other manufacturers	Data is backed up, restored, and verified only when it is correctly defined in the ESI. To back up, restore, or verify data that is not defined in the ESI, use the software tool for the slave.
	If backing up, restoring, or verifying data fails, contact the manufacturer of the slave for the appropriate procedures.

- *1 Cycle the power supply to a slave after you restore data. Cycle the power supply to a slave before you verify the data after you restore it. The verification will fail if you do not cycle the power supply before you perform the verification.
- *2 If any of the following conditions applies, do not turn the Servo ON while the data is being backed up or restored before you verify the data. If you turn the Servo ON while the data is being backed up or restored before you verify the data, the parameters are updated before the verification operation and may cause differences in the verification results.
 - When the Realtime Autotuning Mode Selection (3002 hex) is set to 1 to 4, or 6 (enabled).
 - When the Adaptive Filter Selection (3200 hex) is set to 1 or 2 (enabled).

Procedure to Write Parameters for an 3G3AX-MX2-ECT or 3G3AX-RX-ECT Inverter

When the unit version of the CPU Unit is 1.11 or later, the inverter parameters are not included in the restore target.

When the unit version of the CPU Unit is 1.10 or earlier, an EtherCAT Slave Restore Operation Failed event (event code 10300000 hex) will occur if you restore data while a 3G3AX-MX2-ECT or 3G3AX-RX-ECT Inverter is connected. Use the follow procedure from the Sysmac Studio to write the backup parameters to the Inverter. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details.

- 1 Import the Inverter parameters from the backup file with the backup file import function of the Sysmac Studio.
 - Display the Inverter parameters on the Inverter Parameters Tab Page for the Controller Configurations and Setup of the Sysmac Studio.
- Confirm that the model number of the Inverter in the parameters that you imported agrees with the model number of the Inverter that is actually connected.
- **3** Download the parameters to the Inverter using the "To Drive" menu on the Inverter Parameters Tab Page for the Controller Configurations and Setup of the Sysmac Studio.



Precautions for Correct Use

If you use the Inverter Mode Selection parameter (parameter number b171) in a 3G3AX-MX2-ECT Inverter, change the Inverter to the mode that was used when the backup data was created before you write the parameters. After you change the mode setting, you must initialize the Inverter to enable the change.



Additional Information

When the unit version of the CPU Unit is 1.10 or earlier, even if the restore operation for the Inverter fails, all other data are restored including settings of Units and slaves, user program settings, and present values of variables.

9-10 Backup Functions When EtherCAT Slave Terminals Are Connected

For EtherCAT Slave Terminals, you can use the SD Memory Card backup functions, the Sysmac Studio Controller backup functions, and Sysmac Studio backup import function.

This section provides information on the data that is backed up, backup support according to Controller status, and restore conditions when EtherCAT Slave Terminals are connected.



Precautions for Correct Use

You cannot back up, restore, or compare data for Safety Control Units on EtherCAT Slave Terminals. Refer to the *NX-series Safety Control Unit User's Manual* (Cat. No. Z930) for information on importing and exporting settings for a Safety Control Unit.



Version Information

A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required to use EtherCAT Slave Terminals.

9-10-1 Backing Up Data in an EtherCAT Slave Terminal

The data that can be backed up for an EtherCAT Slave Terminal is different for the EtherCAT Coupler Unit and the NX Units. The data that is backed up is given in the following table.

(OK: Applicable, NA: Not applicable)

Unit	Data	Backup	Restore	Compare
EtherCAT Coupler Unit	Configuration information*1	OK	OK	OK
	Unit operation settings	OK	OK	OK
NX Units	Configuration information*1	OK	ОК	OK
	Unit operation settings	OK	OK	OK
	Unit application data*2	OK	OK	OK

^{*1} The configuration information includes the Unit configuration information and I/O allocation information.

^{*2} This is the specific data for each NX Unit. Some NX Units do not have Unit application data.



Precautions for Correct Use

To restore backup data to an EtherCAT Slave Terminal that has an identical Unit configuration to the EtherCAT Slave Terminal from which data was backed up, make sure that all hardware switches are set to the same settings as when the backup was made. Backup data cannot be restored if the hardware switches are set differently from those in the backup data. This will cause a Restore Operation Failed to Start (EtherCAT Slave) observation event to occur.

9-10-2 Backup Support Depending on the EtherCAT Slave Terminal **Status**

The following table shows when backup, restore, and compare operations can be performed for Ether-CAT Slave Terminals based on the EtherCAT Slave Terminal status.

	Execution		
EtherCAT Slave Terminal status	Backing up data	Restoring data	Verifying data
Automatic creation of the Unit configuration information	Possible.*1	Possible.*2	Possible.
Waiting for NX Unit participation	Not possible.*3	Not possible.*4	Possible.*5
Watchdog time error in EtherCAT Coupler Unit or NX Unit	Not possible.*3	Not possible.*4	Possible.*5
During Bus Controller Error	Not possible.*3	Not possible.*4	Possible.*5
During Unit Configuration Information Error	Not possible.*3	Possible.	Possible.*5
During Unit Configuration Verification Error	Not possible.*3	Possible.	Possible.*5
The Unit configuration information does not agree with the Unit configuration information in the backup data.		Not possible.*4	Possible.*5

^{*1} The backup contains information saying that the Unit configuration information does not exist.

9-10-3 Conditions for Restoring EtherCAT Slave Terminal Data

The following conditions must be met before you restore the backup data to the EtherCAT Slave Termi-

- The backup files must contain the data for the EtherCAT Coupler Unit and NX Unit.
- The original Unit Configuration in the backup must match the actual Unit configuration where data is being restored.
- The serial number of the EtherCAT Coupler Unit from which the data was backed up and the serial number of the EtherCAT Coupler Unit to which the data is restored must be the same. However, this assumes that the setting of the Serial Number Check Method in the Unit operation settings of the Communications Coupler Unit in the backup file is set to Setting = Actual device.
- The serial numbers of the NX Units from which the data was backed up and the serial numbers of the NX Units to which the data is restored must be the same. However, this assumes that the setting of the Serial Number Check Method in the Unit operation settings of the Communications Coupler Unit in the backup file is set to Setting = Actual device.
- The hardware switch settings of the EtherCAT Coupler Unit from which the data was backed and the hardware switch settings of the EtherCAT Coupler Unit to which the data is restored must be the same.
- The unit version setting of the EtherCAT Coupler Unit from which the data was backed up and the unit version of the actual EtherCAT Coupler Unit to which the data is restored must be the same.
- . The unit version settings of the NX Unit from which the data was backed up and the unit versions of the actual NX Units to which the data is restored must be the same.

^{*2} After the data is restored, automatic Unit configuration status continues.

^{*3} A Backup Failed event is recorded in the event log.

^{*4} A Restore Operation Failed event is recorded in the event log.

^{*5} The verification results will show differences.

9-11 Backup Functions When NX Units Are Connected

For NX Units on the NX102 CPU Unit and NX1P2 CPU Unit, you can use the SD Memory Card backup functions and the Sysmac Studio Controller backup functions.

This section provides information on the data that is backed up, backup support according to Controller status, and restore conditions when NX Units are connected to the NX1P2 CPU Unit.



Precautions for Correct Use

You can mount an NX-SL \ Safety Control Unit on the NX102 CPU Unit. However, you cannot back up, restore, or compare data for the Safety Control Unit. Refer to the *NX-series Safety Control Units User's Manual* (Cat. No. Z930-E1-12 or later) for information on importing and exporting settings and safety unit restore settings for a Safety Control Unit.

9-11-1 Backing Up Data in NX Units on the CPU Unit

The data that is backed up for NX Units on the CPU Unit is given in the following table.

(OK: Applicable, NA: Not applicable)

Unit	Data	Backup	Restore	Compare
NX Units	Configuration information*1	OK	OK	OK
	Unit operation settings	OK	OK	OK
	Unit application data ^{*2}	OK	OK	OK

^{*1} The configuration information includes the Unit configuration information and I/O allocation settings.

9-11-2 Backup Support Depending on the Controller Status

The following table shows when backup, restore, and compare operations can be performed for NX Units based on the Controller status.

	Execution			
Controller status	Backing up data	Restoring data	Verifying data	
Automatic creation of the Unit configuration information	Possible.*1	Possible.*2	Possible.	
Watchdog time error in NX Unit	Not possible.*3	Not possible.*4	Possible.*5	
During NX Bus Controller Error	Not possible.*3	Not possible.*4	Possible.*5	
During Unit Configuration Verification Error	Not possible.*3	Possible.	Possible.*5	
The Unit configuration information does not agree with the Unit configuration information in the backup data.		Not possible.*4	Possible.*5	

^{*1} The backup contains information saying that the Unit configuration information does not exist.

^{*2} This is the specific data for each NX Unit. Some NX Units do not have Unit application data.

^{*2} After the data is restored, automatic Unit configuration status continues.

^{*3} An NX Unit Backup Failed event is recorded in the event log.

^{*4} An NX Unit Restore Operation Failed event is recorded in the event log.

^{*5} The verification results will show differences.

9-11-3 Conditions for Restoring NX Unit Data on the CPU Unit

The following conditions must be met before you restore the backup data to the NX Units on the CPU Unit.

- The backup files must contain the data of the relevant CPU Unit and the data of the NX Units on the relevant CPU Unit.
- The original Unit Configuration in the backup must match the actual Unit configuration where data is being restored.
- The serial numbers of the NX Units from which the data was backed up and the serial numbers of the NX Units to which the data is restored must be the same. However, this assumes that the setting of the Serial Number Check Method in the CPU Racks in the backup file is set to Setting = Actual device.
- The unit version settings of the NX Unit from which the data was backed up and the unit versions of the actual NX Units to which the data is restored must be the same.

9-12 Backup Functions When CJ-series Units Are Connected

Data in CJ-series Units is covered by the SD Memory Card backup functions and Sysmac Studio Controller backup functions. This section provides precautions for connected CJ-series Units for the data that is backed up, backup support according to Controller status, and restore conditions.



Precautions for Correct Use

You can connect CJ-series Units only with NJ-series CPU Units.

9-12-1 Backed Up CJ-series Unit Data

The present values in memory used for CJ-series Units and the parameters in the CJ-series Units are backed up. Some of this data is in the CJ-series Unit and some are in the CPU Unit. You do not need to be aware of where the data is located because the backup, restoration, and verification operations will automatically process this data.

9-12-2 Backup Support Depending on the Controller Status

The following table shows when backup, restore, and verify operations can be performed for CJ-series Units based on the Controller status.

Controller status	Execution			
Controller status	Backing up data	Restoring data	Verifying data	
I/O Bus Check Error	Not possible.*1	Not possible.*2	Possible.*3	
End Cover Missing				
Incorrect Unit/Expansion Rack Connection				
Duplicate Unit Number Error				
Too Many I/O Points				
I/O Setting Check Error				
Restarting the CJ-series Unit	Not possible.*1	Possible.	Possible.*3	

^{*1} CJ-series Unit Backup Failed events are recorded in the event log.

9-12-3 Conditions for Restoring CJ-series Unit Data

The following conditions must be met before you can restore the backup data to the CJ-series Units.

- The backup files must contain the CJ-series Unit data.
- The Unit Configuration in the backup file must match the actual Unit Configuration where data is being restored.
- Each CJ-series Unit must meet the conditions for that Unit. (Refer to the manuals for the CJ-series Units for the specific conditions for each Unit.)

^{*2} CJ-series Unit Restore Operation Failed events are recorded in the event log.

^{*3} The verification results will show differences.



Precautions for Correct Use

If you restore data using the SD Memory Card backup functions or the Sysmac Studio Controller backup functions while CJ-series Units are connected, a CPU Unit Service Monitor Error will occur. This means that servicing the CJ-series Units from the CPU Unit was not completed within a specific amount of time. However, this is the result of the time that is required to restore the data and it does not indicate an error. The following will occur at this time.

- For communications-related CJ-series Units, the MS indicator flashes red.
- For CJ-series Units with seven-segment indicator, the indicator displays "HE".
- For CJ-series Units that have an ERH indicator, the ERH indicator lights.
- An event code of 00000002 hex is recorded in the Controller event logs to indicate a CPU Unit Service Monitor Error or Refresh Timeout event.
- If a CJ-series CJ1W-CT021 High-speed Counter Unit is connected, an event code of 68010000 hex is recorded in the Controller event logs to indicate a Unit Error. The attached information will be 0002 hex.

9-13 Backup-related Files

This section describes the specifications of the backup-related files. These backup-related files apply to all backup functions except for the Sysmac Studio variable and memory backup functions.

9-13-1 Types of Backup-related Files

There are four types of files that are related to backup functions: backup files, restore command files, automatic transfer command files, and verification results files.

Backup File

This file contains the Controller data that is handled by the backup-related functions. Backup files are created when data is backed up.

Restore Command File

This file specifies the data groups to transfer by restoring data from a SD Memory Card. You can edit this file with a text editor on a computer to specify the data groups to transfer. These files are created when data is backed up.

Automatic Transfer Command File

This file specifies the data groups to transfer by automatically transferring data from a SD Memory Card. You can edit this file with a text editor on a computer to specify the data groups to transfer. These files are created when data is backed up.

Verification Results Files

The verification results files contain the results of comparing the Controller data and the data in a backup file on the SD Memory Card in the CPU Unit.

There are four different verification results files, as described below. These files are created when you perform a verification using the SD Memory Card backup function.

Verification results files	Description
Controller verification results file	This file contains the verification results for all backup data specified by the restore command file.
EtherCAT slave verification results file	This file contains the verification results for each EtherCAT slave. It is created when the Unit and slave settings are set to be restored in the restore command file and the EtherCAT slave settings are contained in the backup file.
EtherCAT Slave Ter- minal verification	This file contains the verification results for each EtherCAT Coupler Unit and NX Unit. This file is created when all of the following conditions are met.
results file	The Unit and slave settings are specified for restoration in the restore command file.
	The EtherCAT slave settings are included in the backup file.
	One or more EtherCAT Slave Terminals is connected.
	If an EtherCAT Slave Terminal verification results file is created, an EtherCAT slave verification results file is always created at the same time.
NX Unit verification results file*1	This file contains the verification results for each NX Unit on the CPU Unit. It is created when the Unit and slave settings are set to be restored in the restore command file and the NX Unit settings on the CPU Unit are contained in the backup file.
CJ-series Unit verification results file*2	This file contains the verification results for each CJ-series Unit. It is created when the Unit and slave settings are set to be restored in the restore command file and the CJ-series Unit settings are contained in the backup file.

^{*1} You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

^{*2} You can use CJ-series Units only with NJ-series CPU Units.

9-13-2 Specifications of a Backup File

This section describes the file name, creation timing, and created directory for a backup file.

File Name

A different backup file name is given depending on the CPU Unit series.

File	CPU Units	File name
Backup file	NX-series CPU Units	NXBackup.dat
	NJ-series CPU Units	NJBackup.dat

File Creation Timing and Created Directories

Function	Procedure	Creation timing	Created directory
SD Memory Card backups	CPU Unit front-panel DIP switch	When backup is executed	Root directory on the SD Memory Card
	System-defined variables	When backup is executed	Directory on the SD Memory Card that you specified with the system-defined variable
	SD Memory Card Window in Sysmac Studio	When backup is executed	Directory on the SD Memory Card that you specified with the Sysmac Studio
	Special instruction*1	When backup is executed	The directory on the SD Memory Card that you specified for the input variable of the Backup- ToMemoryCard instruction
Sysmac Studio Controller backups	Sysmac Studio Controller Backup Dialog Box	When backup is executed	Directory in the computer that you specified with the Sysmac Studio
Importing and exporting Sys- mac Studio backup file data	Sysmac Studio Backup File Export Dialog Box	When data is exported	Directory in the computer that you specified with the Sysmac Studio

^{*1} A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required.

9-13-3 Specifications of a Restore Command File

This section describes the file name, creation timing, created directory, and data group specification method for a restore command file.

File Name

File	File name
Restore command file	RestoreCommand.ini

File Creation Timing and Created Directories

Function	Procedure	Creation timing	Created directory
SD Memory Card backups	CPU Unit front-panel DIP switch	When backup is executed	Same directory as backup file
	System-defined variables	When backup is executed	Same directory as backup file
	SD Memory Card Window in Sysmac Studio	When backup is executed	Same directory as backup file
Sysmac Studio Controller backups	Sysmac Studio Controller Backup Dialog Box	When backup is executed	Same directory as backup file
Importing and exporting Sysmac Studio backup file data	Sysmac Studio Backup File Export Dialog Box	When data is exported	Same directory as backup file

Specifying the Data Groups to Restore

The restore command file allows you to specify the data groups to restore. You can change the data group specifications by editing the file with a text editor on a computer.

For example, if you change "Variable=yes" on line 8 in the file contents that are shown in the following table to "Variable=no," the present values of variables will not be restored.

File contents (defaults when the file is created)	Description
[Restore] ; User Program and Configuration ; Always select "yes". UserProgram=yes	User program and settings This data group is always restored. Always select
; IP Address of Built-in EtherNet/IP Port Settings ; "yes":will be restored, "no":will not be restored IPAdr=yes	IP address of built-in EtherNet/IP port yes/no: Restore/Do not restore. Present values of variables (only variables that are
; Present values of variables (Retained variables only) ; "yes":will be restored, "no":will not be restored Variable=yes	set to be retained with the Retain attribute) yes/no: Restore/Do not restore.
; Present values of memory used for CJ-series Units (Holding, EM, and DM Area data) ; "yes":will be restored, "no":will not be restored Memory=yes	Present values of memory used for CJ-series Units (only addresses that are set to be retained with the Retain attribute) yes/no: Restore/Do not restore.
:Unit/Slave Parameters ; "yes";will be restored."no";will not be restored UnitConfig=yes	Units and slaves settings yes/no: Restore/Do not restore.
; Absolute encoder home offset ; "yes":will be restored, "no":will not be restored AbsEncoder=yes	Absolute encoder home offset yes/no: Restore/Do not restore.

- Note 1 The default file contents when the restore command file is created are given above. All of the data groups that are listed in the file are set to be restored.
 - 2 The restore command file lists the restorable data groups that were in the backup file when the backup file was created.
 - 3 Only single-byte alphanumeric characters are used. The text is not case sensitive.
 - 4 An entry of IP Address of Built-in EtherNet/IP Port Settings is not created if the backup is performed in the CPU Unit with unit version 1.13 or earlier. In the CPU Unit with unit version 1.14 or later, if an entry of IP Address of Built-in EtherNet/IP Port Settings for which the restore command file is not created is used, the operation is performed as "IPAdr=yes". Refer to Compatibility between Restore Command Files on page 9-67 for compatibility between the restore command file with unit version 1.13 or earlier and the restore command file with unit version 1.14 or later.



Precautions for Correct Use

When you edit the restore command file, do not change anything in the file except for the "yes" and "no" specifications for the selectable data groups. If you change anything else in the file, the Controller may perform unexpected operation when you restore the data.

Compatibility between Restore Command Files

The following table shows the compatibility between the restore command file with unit version 1.13 or earlier and the restore command file with unit version 1.14 or later.

Unit version of CPU Unit that	Unit version of CPU Unit	where data is being restored
creates the restore command file and backup file	Version 1.13 or earlier	Version 1.14 or later
Version 1.13 or earlier	Restorable.	Restorable.
	IP Address of Built-in EtherNet/IP Port Settings is restored.	IP Address of Built-in EtherNet/IP Port Settings is restored.
Version 1.14 or later	Not restorable.	Restorable.
	In the CPU Unit with unit version 1.13 or earlier, because the entry of IP Address of Built-in Ether-Net/IP Port Settings cannot be interpreted, a Restore Operation Failed to Start error in an observation level occurs. The error details will be "0104 hex: The contents of the restore command file are not correct".	IP Address of Built-in EtherNet/IP Port Settings corresponds to "yes/no" of "IPAdr".

9-13-4 Specifications of an Automatic Transfer Command File

This section describes the file name, creation timing, created directory, and data group specification method for an automatic transfer command file.

File Name

File	File name
Automatic transfer command file	AutoloadCommand.ini

File Creation Timing and Created Directories

Function	Procedure	Creation timing	Created directory
SD Memory Card backups	CPU Unit front-panel DIP switch	When backup is executed	Same directory as backup file
	System-defined variables	When backup is executed	Same directory as backup file
	SD Memory Card Window in Sysmac Studio	When backup is exe- cuted	Same directory as backup file
Sysmac Studio Controller backups	Sysmac Studio Controller Backup Dialog Box	When backup is exe- cuted	Same directory as backup file
Importing and exporting Sysmac Studio backup file data	Sysmac Studio Backup File Export Dialog Box	When data is exported	Same directory as backup file

Specifying the Data Groups to Automatically Transfer

The automatic transfer command file allows you to specify the data groups to transfer automatically. You can change the data group specifications by editing the file with a text editor on a computer. For example, if you change "Variable=yes" on line 8 in the file contents that are shown in the following table to "Variable=no," the present values of variables will not be automatically transferred.

File contents (defaults when the file is created)	Description
[Autoload] ; User Program and Configuration ; Always select "yes". UserProgram=yes	User program and settings This data group is always transferred. Always select
; IP Address of Built-in EtherNet/IP Port Settings ; "yes":will be transferred, "no":will not be transferred IPAdr=yes ; Present values of variables (Retained variables only) ; "yes":will be transferred, "no":will not be transferred	IP address of built-in EtherNet/IP port yes/no: Transfer/Do not transfer. Present values of variables (only variables that are set to be retained with the Retain attribute) yes/no: Transfer/Do not transfer.
Variable=yes ; Present values of memory used for CJ-series Units (Holding, EM, and DM Area data) ; "yes":will be transferred, "no":will not be transferred Memory=yes	Present values of memory used for CJ-series Units (only addresses that are set to be retained with the Retain attribute) yes/no: Transfer/Do not transfer.

- Note 1 The default file contents when the automatic transfer command file is created are given above. All of the data groups that are listed in the file are set to be automatically transferred.
 - 2 The automatic transfer command file lists the transferable data groups that were in the backup file when the backup file was created.
 - 3 Only single-byte alphanumeric characters are used. The text is not case sensitive.
 - 4 An entry of IP Address of Built-in EtherNet/IP Port Settings is not created if the backup is performed in the CPU Unit with unit version 1.13 or earlier. In the CPU Unit with unit version 1.14 or later, if an entry of IP Address of Built-in EtherNet/IP Port Settings for which the automatic transfer file is not created is used, the operation is performed as "IPAdr=yes". Refer to Compatibility between Automatic Transfer Files on page 9-69 for compatibility between the automatic transfer file with unit version 1.13 or earlier and the automatic transfer file with unit version 1.14 or later.



Precautions for Correct Use

When you edit the automatic transfer command file, do not change anything in the file except for the "yes" and "no" specifications for the selectable data groups. If you change anything else in the file, the Controller may perform unexpected operation when you automatically transfer the data.

9-69

Compatibility between Automatic Transfer Files

The following table shows the compatibility between the automatic transfer file with unit version 1.13 or earlier and the automatic transfer file with unit version 1.14 or later.

Unit version of CPU Unit that creates the automatic transfer	_	e data is being automatically trans- erred	
file and backup file	Version 1.13 or earlier	Version 1.14 or later	
Version 1.13 or earlier	Automatic transfer is possible.	Automatic transfer is possible.	
	IP Address of Built-in EtherNet/IP Port Settings is automatically transferred.	IP Address of Built-in EtherNet/IP Port Settings is automatically trans- ferred.	
Version 1.14 or later	Automatic transfer is not possible. In the CPU Unit with unit version 1.13 or earlier, because the entry of IP Address of Built-in Ether-Net/IP Port Settings cannot be interpreted, an Error in Starting Automatic Transfer in a major fault level occurs. The error details will be "0104 hex: The contents of the automatic transfer command file are not correct".	Automatic transfer is possible. IP Address of Built-in EtherNet/IP Port Settings corresponds to "yes/no" of "IPAdr".	

9-13-5 Specifications of a Controller Verification Results File

This section describes the file name, creation timing, created directory, and verification results confirmation method for a Controller verification results file.

File name

File	File name
Controller Verification Results File	VerifyResult.log

File Creation Timing and Created Directories

Function	Procedure	Creation timing	Created directory
SD Memory Card backups	SD Memory Card Window in Sysmac Studio	When verification is executed	Same directory as backup file
	System-defined variables	When verification is executed	Same directory as backup file
	CPU Unit front-panel DIP switch	When verification is executed	Same directory as backup file

Note However, if the SD Memory Card is write-protected, the verification results files will not be created.

How to Check the Verification Results

The verification results files contain the results of comparing the Controller data and the data in a backup file on the SD Memory Card in the CPU Unit for each data group. You can check the verification results in the portion that gives the verification results for each data group. "Result=Matched" indicates a data group for which no differences were found. "Result=Not matched" indicates a data group for which differences were found. In the file shown below, the user program and configuration data matched, and the Units and slave parameters did not match.

File contents	Description
[UserProgram] ; User Program and Configuration	User program and settings
Result=Matched	Matched: No differences were found, Not matched: Differ-
	ences were found.
[UnitConfig]	Units and slaves settings
; Unit/Slave Parameters Result=Not matched	Matched: No differences were found, Not matched: Differ-
Result-Not matched	ences were found.

Note 1 The verification results are given only for the data groups that were compared.

2 The verification results of IP Address of Built-in EtherNet/IP Port Settings are including in an entry of user program and settings even for the CPU Unit with unit version 1.14 or later.

9-13-6 Specifications of an EtherCAT Verification Results File

This section describes the file name, creation timing, created directory, and verification results confirmation method for an EtherCAT verification results file.

File Name

File	File name
EtherCAT Verification Results File	VerifyResult_ECAT.log

File Creation Timing and Created Directories

Function	Procedure	Creation timing	Created directory
SD Memory Card backups	SD Memory Card Window in Sysmac Studio	When verification is executed	Same directory as backup file
	System-defined variables	When verification is executed	Same directory as backup file
	CPU Unit front-panel DIP switch	When verification is executed	Same directory as backup file

Note However, if the SD Memory Card is write-protected, the verification results files will not be created.

How to Check the Verification Results

The verification results files contain the results of comparing the Controller data and the data in a backup file on the SD Memory Card in the CPU Unit for each data group. You can check the verification results in the portion that gives the verification results for each EtherCAT slave. "Result=Matched" indicates a data group for which no differences were found. "Result=Not matched" indicates a data group for which differences were found.

The following table gives an example of the verification results for the following file contents.

- Matched: EtherCAT slave called Master and EtherCAT Slave Terminal E022
- Not matched: EtherCAT slave E001

File contents	Description			
[Verification Results]				
; EtherCAT Parameters				
: See the VerifyResult_ECAT_NX.log about detail result if NX mark is included in square brackets.	The slaves are indicate	d with the user-set device names. For an EtherCAT Slave		
[Master]	Terminal, ":NX" is added	d to the end of the device name.*1		
Result=Matched	The verification regults	ore given as fellows:		
[E001]	The verification results Result=Matched	Same		
Result=Not matched	Result=Not matched	Different		
Factor=Verification error	Result-Not matched	Different		
[E002:NX]				
Result=Matched				

^{*} If EtherCAT Slave Terminals are set for verification, the EtherCAT Slave Terminal verification results file is created. The detailed verification results for the EtherCAT Slave Terminals are given in the EtherCAT Slave Terminal verification results file.

Note The verification results are given only for the EtherCAT slaves that were compared.

Specifications of an EtherCAT Slave Terminal Verification Results File

This section describes the file name, creation timing, created directory, and verification results confirmation method for an EtherCAT Slave Terminal verification results file.

File Name

File	File name
EtherCAT Slave Terminal verification results file	VerifyResult_ECAT_NX.log

File Creation Timing and Created Directories

Operation	Operating method	Creation timing	Created directory
SD Memory	SD Memory Card Window in	When verification is	Same directory as backup file
Card backups	Sysmac Studio	executed	
	System-defined variables	When verification is	Same directory as backup file
		executed	
	CPU Unit front-panel DIP	When verification is	Same directory as backup file
	switch	executed	

Note However, if the SD Memory Card is write-protected, the verification results files will not be created.

How to Check the Verification Results

The verification results files contain the results of comparing the Controller data and the data in a backup file on the SD Memory Card in the CPU Unit for each data group.

You can check the verification results in the portion that gives the verification results for the EtherCAT Coupler Units and NX Units.

"Result=Matched" indicates a data group for which no differences were found. "Result=Not matched" indicates a data group for which differences were found.

The following table gives an example of the verification results for the following file contents.

- Matched: EtherCAT Coupler Unit E002, NX Unit N1, and NX Unit N2
- Not matched: EtherCAT Coupler Unit E005 and NX Unit N3

File contents	Description			
[Verification Results]	The Units are indicated in the following format:			
; NX Parameters	{Device name}:UnitNo.{Unit number}[blank]{Unit model}			
[E002:UnitNo.0 NX-ECC201] Result=Matched	Device Name: The device name set by the user.			
[N1:UnitNo.1 NX-AD2203] Result=Matched	Unit Number: Text string of decimal numbers. The value will be between 0 and 1: Unit Model:			
[N2:UnitNo.2 NX-DA2203] Result=Matched	Text string that identifies the Unit model. Consecutive spaces at the end of the model number are deleted.			
[N3:UnitNo.3 NX-TS3201]	The verification results are given as follows:			
Result=Not matched	Result=Matched Same			
Factor=Verification error	Result=Not matched Different			
[E005:UnitNo.0 NX-ECC201] Result=Not matched Factor=Verification error				

9-13-8 Specifications of an NX Unit Verification Results File

This section describes the file name, creation timing, created directory, and verification results confirmation method for an NX Unit verification results file.



Precautions for Correct Use

You can use NX Units on the CPU Unit only with the NX102 CPU Units and NX1P2 CPU Units.

File Name

File	File name	
NX Unit verification results file	VerifyResult_NXUnit.log	

File Creation Timing and Created Directories

Operation	Operating method	Creation timing	Created directory
SD Memory Card backups	SD Memory Card Window in Sysmac Studio	When verification is executed	Same directory as backup file
	System-defined variables	When verification is executed	Same directory as backup file
	CPU Unit front-panel DIP switch	When verification is executed	Same directory as backup file

Note However, if the SD Memory Card is write-protected, the verification results files will not be created.

How to Check the Verification Results

The verification results files contain the results of comparing the Controller data and the data in a backup file on the SD Memory Card in the CPU Unit for each data group.

You can check the verification results in the portion that gives the verification results for the NX Units.

"Result=Matched" indicates a data group for which no differences were found. "Result=Not matched" indicates a data group for which differences were found.

The following table gives an example of the verification results for the following file contents.

Matched: NX Unit N1
Not matched: NX Unit N3
Not verified: NX Unit N2

File contents	Description			
[Verification Results]	The Units are indicated in the following format:			
; NX Parameters	{Device name}:UnitNo.{Unit number}[blank]{Unit model}			
[N1:UnitNo.1 NX-AD2203] Result=Matched	Device Name: The device name s	et by the user.		
[N2:UnitNo.2 NX-DA2203] Result=Not verified	Unit Number: Text string of decimal numbers. The value will be between 0 and 125. Unit Model:			
[N3:UnitNo.3 NX-TS3201]	Text string that identifies the Unit model.			
Result=Not matched Factor=Verification error	Consecutive spaces at the end of the model number are deleted.			
	The verification results a	are given as follows:		
	Result=Matched	Same		
	Result=Not matched	Different		
	Result=Not verified No verification			

9-13-9 Specifications of CJ-series Unit Verification Results File

This section describes the file name, creation timing, created directory, and verification results confirmation method for a CJ-series Unit verification results file.



Precautions for Correct Use

You can use CJ-series Units only with NJ-series CPU Units.

File name

File	File name	
CJ-series Unit Verification Results File	VerifyResult_CJUnit.log	

File Creation Timing and Created Directories

Function	Procedure	Creation timing	Created directory
SD Memory Card backups	SD Memory Card Window in Sysmac Studio	When verification is executed	Same directory as backup file
	System-defined variables	When verification is executed	Same directory as backup file
	CPU Unit front-panel DIP switch	When verification is executed	Same directory as backup file

Note However, if the SD Memory Card is write-protected, the verification results files will not be created.

How to Check the Verification Results

The verification results files contain the results of comparing the Controller data and the data in a backup file on the SD Memory Card in the CPU Unit for each data group. You can check the verification results in the portion that gives the verification results for each CJ-series Unit. "Result=Matched" indicates a data group for which no differences were found. "Result=Not matched" indicates a data group for which differences were found. In the file shown below, CJ1W-CRM21 (MODE0) and CJ1W-EIP21 matched, and CJ1W-DRM21 and CJ1W-PRM21-DPV1 did not match.

File contents	Description		
[Verification Results]	The Units are given in the following format:		
; CJ Unit Parameters [Rack0 Slot0: CJ1W-CRM21(MODE0) UnitNo.10]	Rack{Rack No.}[space]Slot{Slot No}:[space]{Unit model}[space]Unit No.{unit number}		
Result=Matched			
	Rack No.:		
[Rack0 Slot9: CJ1W-DRM21 UnitNo.0] Result=Not matched	Text string of decimal numbers. The value will be between 0 and 3.		
Result-Inol matched	Slot No.:		
[Rack1 Slot0: CJ1W-EIP21 UnitNo.10]	Text string of decimal numbers. The value will be between 0 and 9.		
Result=Matched	Unit Model		
	Text string that identifies the Unit model.		
[Rack1 Slot1: CJ1W-PRM21-DPV1 UnitNo.1] Result=Not matched	The Unit model is obtained from the cyclic initialization data. Consecutive spaces at the end of the model number are deleted.		
	Unit No.:		
	Text string of decimal numbers. Leading zeros are suppressed. Range for a CPU Bus Unit: 0 to 15. Special I/O Units: 0 to 95.		
	The match/no match results are given in the following format:		
	Result=Matched: No differences were found.		
	Result=No matched: Differences were found.		

Note The verification results are given only for the EtherCAT slaves that were compared.

9-14 Compatibility between Backuprelated Files

The files may not be compatible if you back up and restore data under different conditions.

The files may not be compatible in these three cases:

- · When the function that was used to back up data is different from the function that was used to restore it.
- · When the model number of the CPU Unit where the data was backed up from does not match the model number where data is being restored.
- · When the unit versions of the CPU Unit, other Units, or slaves where the data was backed up from do not match the unit versions where data is being restored.

In this context, the term "restore" is used collectively for these backup functions: restore, automatic transfer, program transfer, and read (back up).

9-14-1 Compatibility between Backup Functions

The following table shows the file compatibility when the function used to back up the data is different from the function used to restore it.

(C: Compatible, N: Not compatible.)

	Function used to restore data				
Function used to back up data	Restoring with SD Memory Card backup functions (SD Memory Card to Con- troller)	Automatic transfer and program transfer	Restoring with Sysmac Studio Con- troller backup func- tions (com- puter to Controller)	Restoring with Sysmac Studio variable and memory backup functions (computer to Controller)	Importing Sysmac Stu- dio backup file data (computer to project)
Backing up with SD Memory Card backup functions (Con- troller to SD Memory Card)	С	С	С	N	C*1
Backing up with Sysmac Stu- dio Controller backup func- tions (Controller to computer)	С	С	С	N	C*1
Backing up with Sysmac Stu- dio variables and memory data backup functions (Controller to computer)	N	N	N	С	N
Exporting from a Sysmac Stu- dio backup file (project to com- puter)	C*1	C*1	C*1	N	С

^{*1} The following data is not included.

- · The built-in EtherNet/IP port name and built-in EtherNet/IP tag data link settings in the Controller Setup
- · Words allocated to CPU Bus Units in the Unit Configuration
- · Operation authority verification
- · Data Trace Settings
- · Time zone setting

- · Present values of variables
- · Present values of memory used for CJ-series Units
- · Absolute encoder home offsets



Additional Information

The files that are handled for backing up variables and memory from the Sysmac Studio are not compatible with other backup files. Refer to 9-8 Sysmac Studio Variable and Memory Backup Functions for details on these functions.

9-14-2 Compatibility between CPU Unit Models

The following table shows the file compatibility when the CPU Unit model where the data was backed up from is different from the group where the data is being restored.

(C: Compatible, N: Not compatible.)

	CPU Unit model to restore to								
CPU Unit model where data was backed up	NX701-	NX102-		NX1P2-		NJ501-	NJ301- NJ101-		101-
	1700 1600	1200 1100 1000	9000	1140DT 1140DT1 1040DT 1040DT1	9024DT 9024DT1	1500 1400 1300	1200 1100	1000	9000
NX701-1700 or NX701-1600	С	N*1	N*1	N*1	N*1	N*1	N*1	N*1	N*1
NX102-1200	N*1	С	N*1	N*1	N*1	N*1	N*1	N*1	N*1
NX102-1100									
NX102-1000									
NX102-9000	N*1	N*1	С	N*1	N*1	N*1	N*1	N*1	N*1
NX1P2-1140DT, NX1P2- 1140DT1,NX1P2- 1040DT, or NX1P2-1040DT1	N*1	N*1	N*1	С	N*1	N*1	N*1	N*1	N*1
NX1P2-9024DT or NX1P2-9024DT1	N*1	N*1	N*1	N*1	С	N*1	N*1	N*1	N*1
NJ501-1500, NJ501- 1400, or NJ501-1300	N*1	N*1	N*1	N*1	N*1	С	N*1	N*1	N*1
NJ301-1200 or NJ301-1100	N*1	N*1	N*1	N*1	N*1	N*1	С	N*1	N*1
NJ101-1000	N*1	N*1	N*1	N*1	N*1	N*1	N*1	С	N
NJ101-9000	N*1	N*1	N*1	N*1	N*1	N*1	N*1	N	С

^{*1} The Sysmac Studio variable and memory backup functions are compatible. However, a CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher are required. Refer to 9-8-3 Compatibility between CPU Unit Models for the CPU Unit Models for the CPU Unit Models for the Sysmac Studio variable and memory backup functions.



Additional Information

Database Connection CPU Units, SECS/GEM CPU Units, NJ Robotics CPU Units, and NC Integrated Controller are not compatible.

Refer to the relevant manuals for specific Units for details on the compatibility of these CPU Units.

Even if the CPU Unit models are compatible, there may be restrictions between various CPU Unit models.

The following table shows which restoration function can be used based on whether the CPU Unit models are compatible.

	Function used to restore data							
Compatibility between CPU Unit Models	Restoring with SD Memory Card backup functions (SD Memory Card to Controller)	Automatic transfer and program trans- fer	Restoring with Sysmac Studio Controller backup functions (computer to Controller)*1	Restoring with Sysmac Studio variable and memory backup functions (com- puter to Con- troller)	Importing Sys- mac Studio backup file data (computer to project)			
Compatible	R*2	R*2	R	R	R			
Not compatible	×*3	×*4	×	×	×			

^{*1} Only the files that were backed up using this function can be restored.

9-14-3 Compatibility between Unit Versions of CPU Units

The following table shows the compatibility of backup files when the unit versions of the CPU Unit are different between where the data was backed up and where it is being restored. You can restore data without any restrictions if the unit versions are the same before and after the backup and restoration.

(R: Restored, x: Not restored)

	Function used to restore data							
Unit version of CPU Unit	Restoring with SD Memory Card backup functions (SD Memory Card to Controller)	Automatic transfer and program trans- fer	Restoring with Sys- mac Studio Con- troller backup functions (com- puter to Controller)	Restoring with Sysmac Studio variable and memory backup functions (computer to Controller)				
Version of CPU Unit where data is being restored is newer.	R	R	R	R				
Unit version of CPU Unit where data is being restored is older.	×	x*1	×	R				

^{*2} If the contents of the backup file are outside the range of specifications where the data is restored, the Controller will not operate normally. When you operate the Controller, a major fault level Controller error or a partial fault level Controller error will occur. For example, this error occurs if the number of controlled axes that is used is outside the specifications.

^{*3} A Restore Start Failed observation will occur.

^{*4} The Error in Starting Automatic Transfer (a major fault level Controller error) occurs during an automatic transfer. The SD Memory Card Program Transfer Failed to Start error (an observation level Controller error) occurs during a program transfer.

*1 The Error in Starting Automatic Transfer (a major fault level Controller error) occurs during an automatic transfer. The SD Memory Card Program Transfer Failed to Start error (an observation level Controller error) occurs during a program transfer.

9-15 Functions That Cannot Be Executed during Backup Functions

The following functions cannot be executed at the same time as any of the backup functions. Do not execute any backup function while the CPU Unit is executing any of these functions. Also, do not execute any of these functions during execution of any of the backup functions.

- · While a backup function is being performed
- · Synchronization transfer from the computer to the Controller
- · Execution of online editing
- Execution of Clear All Memory operation
- · Time zone changes
- Execution of the Save Cam Table instruction (MC_SaveCamTable)
- Execution of CPU Unit name write operation
- · Execution of transferring Slave Terminal parameters



Communications Setup

This section describes how to go online with the CPU Unit and how to connect to other devices.

10-1 Cor	mmunications System Overview
10-1	-1 Introduction
10-2 Cor	nnection with Sysmac Studio10-7
10-2	2-1 Configurations That Allow Online Connections
10-2	2-2 Configurations That Do Not Allow Online Connections
10-3 Cor	nnection with Other Controllers or Slaves 10-10
10-3	3-1 Connection Configurations between Controllers
10-3	3-2 Connection Configuration between Controllers and Slaves 10-13
10-4 Cor	nnection with HMIs or Serial Communications Devices 10-14
10-4	-1 Connection with HMIs
10-4	-2 Connection with Serial Communications Devices

10-1 Communications System Overview

This section gives an overview of the communications systems that are supported by NJ/NX-series Controllers.

The shaded steps in the overall procedure that is shown below are related to the communications systems.

Step 1. Software Design

Step 1-1 Designing I/O and Processing

Step 1-2 Designing Tasks

Step 1-3 Designing Programs



Step 2. Software Setups and Programming

Step 2-1 Slave and Unit Configurations

Step 2-2 Controller Setup

Step 2-3 Programming

Step 2-4 Offline Debugging



Step 3. Mounting and Setting Hardware



Step 4. Wiring




Step 5. Checking Operation and Starting Operation on the **Actual System**

Refer to 1-3 Overall Operating Procedure for the NJ/NX-series Controller for details.

10-1-1 Introduction

NX701 System


You can use the NX701 System to build the communications system shown below.



	Connection	Connection method
Sysmac Studio connection	on	Use USB or the built-in EtherNet/IP port.
Connections between Controllers	Connections with NJ/NX-series Controller or CJ2 CPU Unit	Use the built-in EtherNet/IP port.
Connections between Controllers and slaves	Connections to Servo Drives and general- purpose slaves	Use the built-in EtherCAT port.
Connections to HMIs		Use the built-in EtherNet/IP port.
Connections to servers	Connections to FTP servers, BOOTP servers, DNS servers, or NTP servers	Use the built-in EtherNet/IP port.

NX102 System


You can use the NX102 System to build the communications system shown below.



	Connection	Connection method
Sysmac Studio connection	on	Use the Built-in EtherNet/IP port.
Connections between Controllers	Connections with NJ/NX-series Controller or CJ2 CPU Unit	Use the Built-in EtherNet/IP port.
Connections between Controllers and slaves	Connections to Servo Drives and general- purpose slaves	Use the built-in EtherCAT port.
Connections to HMIs		Use the Built-in EtherNet/IP port.
Connections to servers	Connections to FTP servers, BOOTP servers, DNS servers, or NTP servers	Use the Built-in EtherNet/IP port.

NX1P2 System


You can use the NX1P2 System to build the communications system shown below.



	Connection	Connection method
Sysmac Studio connecti	on	Use the built-in EtherNet/IP port.
Connections between Controllers	Connections with NJ/NX-series Controller or CJ2 CPU Unit	Use the built-in EtherNet/IP port.
Connections between Controllers and slaves	Connections to Servo Drives and general- purpose slaves	Use the built-in EtherCAT port.
Connections to HMIs		Use the built-in EtherNet/IP port.
Connections to servers	Connections to FTP servers, BOOTP servers, DNS servers, or NTP servers	Use the built-in EtherNet/IP port.

NJ-series System

You can use the NJ-series System to build the communications system shown below.



Conr	Connection method		
Sysmac Studio connection	Use USB or the built-in EtherNet/IP port.		
Connections between Controllers	Connections with NJ/NX-series Controller or CJ2 CPU Unit	Use the built-in EtherNet/IP port or a port on an EtherNet/IP Unit*1	
Connections between Controllers and slaves	Connections to Servo Drives and general-purpose slaves	Use the built-in EtherCAT port.	
	I/O controls	Mount a DeviceNet Unit and use DeviceNet or mount a CompoNet Master Unit and use CompoNet.	
Connections to HMIs	Use the built-in EtherNet/IP port or a port on an EtherNet/IP Unit*1, *2		
Connections for serial communication	Mount a Serial Communications Unit.		
Connections to servers	Connections to FTP servers*3, BOOTP servers, DNS servers, or NTP servers	Use the built-in EtherNet/IP port or a port on an EtherNet/IP Unit*1	

^{*1} Use an EtherNet/IP Unit with unit version 2.1 or later. Also use a CPU Unit with unit version 1.01 or later and Sysmac Studio version 1.02 or higher. Refer to A-16 Version Information for NJ-series Controllers for information on version upgrades.

^{*2} Connect an NA-series PT to the built-in EtherNet/IP port on the CPU Unit. To perform troubleshooting from an NS-series PT, connect the PT to the built-in EtherNet/IP port on the CPU Unit.

^{*3} A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use FTP servers.


10-2 Connection with Sysmac Studio

This section describes the configurations for connecting the Sysmac Studio to an NJ/NX-series Controller.

10-2-1 Configurations That Allow Online Connections

You can connect online from the Sysmac Studio to the peripheral USB port or built-in EtherNet/IP port of the NJ/NX-series CPU Unit.

Connecting with USB




A direct connection is made from the computer that runs Sysmac Studio. You do not need to specify the connection device.

Note Connect a computer and the CPU Unit with a USB 2.0 certified cable. Do not use a USB hub to connect them.

Note You cannot connect a computer to an NX102 CPU Unit or NX1P2 CPU Unit because it does not provide a peripheral USB port.


Connecting with EtherNet/IP

1:1 Connection



- A direct connection is made from the computer that runs Sysmac Studio. You do not need to specify the IP address or connection device.
- You can make the connection either with or without a Ethernet switch.
- You can use either a cross cable or a straight cable.
- For NX701 CPU Units and NX102 CPU Units, 1:1 connection is supported only for port 1.


1:N Connections



- Specify the IP address of the remote node from the Sysmac Studio.
- You can use either a cross cable or a straight cable.

Connecting to EtherNet/IP through USB

You can connect to the built-in EtherNet/IP port through a USB port of the NJ-series CPU Unit or NX701 CPU Unit.



- Specify the IP address of the remote node from the Sysmac Studio.
- You can use either a cross cable or a straight cable.


Note Connect a computer and the CPU Unit with a USB 2.0 certified cable. Do not use a USB hub to connect them.

Note The NX102 CPU Units and NX1P2 CPU Units do not provide a peripheral USB port.

10-2-2 Configurations That Do Not Allow Online Connections

Connection through an EtherNet/IP Unit


You cannot connect through a CJ1W-EIP21 EtherNet/IP Unit that is connected to an NJ-series CPU Unit.



Note You cannot use a CJ1W-EIP21 EtherNet/IP Unit for NX-series CPU Units.


Routing through CS/CJ-series EtherNet/IP Units/Ports

You cannot connect to an NJ/NX-series CPU Unit by routing through a CS/CJ-series Ethernet/IP Unit or port (CS1W-EIP2, CJ1W-EIP21, CJ2 CPU Unit built-in EtherNet/IP port, or CJ2M CPU Unit built-in EtherNet/IP port).



• Routing through Networks Other Than EtherNet/IP, Such as DeviceNet

You cannot route through any networks other than EtherNet/IP networks. (For example, routing is not possible for Controller Link networks and DeviceNet networks.)



Note You cannot connect a DeviceNet Unit with NX-series CPU Units.

10-3 Connection with Other Controllers or **Slaves**

This section shows the connection configurations that are used between Controllers and between Controllers and slaves.

Connection Configurations between Controllers 10-3-1

EtherNet/IP


You can use the built-in EtherNet/IP ports or ports on CJ1W-EIP21 EtherNet/IP Units.

For information on the built-in EtherNet/IP port, refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual (Cat. No. W506). For information on the CJ1W-EIP21 EtherNet/IP Unit, refer to the CJ-series EtherNet/IP Unit Operation Manual for NJ-series CPU Unit (Cat. No. W495).

Note You cannot use a CJ1W-EIP21 EtherNet/IP Unit for NX-series CPU Units.


Tag Data Links

You can create tag data links between NJ/NX-series CPU Units on an EtherNet/IP network.




Message Communications

You can send CIP messages from the user program.




Sending and Receiving Files

You can send and receive files on the SD Memory Card that is inserted in the NJ/NX-series CPU Unit from an FTP client application.




Socket Services

You can directly use TCP or UDP from the user program to send and receive any data with remote nodes between a host computer and the Controller, or between Controllers. The socket services are supported only for the built-in EtherNet/IP ports.



Updating Clock Information


You can obtain clock information from an NTP server to update the built-in clock.



Specifying Host Names


You can use the DNS client or set up your Hosts so that you can specify the IP address of the NTP server or SNMP manager or the target destination of a socket instruction or CIP communications instruction with a host name instead of an IP address.

Example: Setting Host Names on the DNS Server



Obtaining an IP Address When the Power is Turned ON

You can obtain an IP address for the built-in EtherNet/IP port from the BOOTP server when the power supply is turned ON.



Specifying an SNMP Agent

Built-in EtherNet/IP port internal status information is provided to network management software that uses an SNMP manager.




10-3-2 Connection Configuration between Controllers and Slaves

EtherCAT

High-speed, high-precision communications are possible with Servo Drives and general-purpose slaves.

Refer to the NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual (Cat. No. W505) for details.




10-4 Connection with HMIs or Serial **Communications Devices**

This section shows the connection configurations used to connect HMIs and devices with serial communications to the NJ/NX-series Controller.

10-4-1 Connection with HMIs

EtherNet/IP

You can use a built-in EtherNet/IP port or a CJ1W-EIP21 EtherNet/IP Unit to connect to an HMI.



Note You cannot use a CJ1W-EIP21 EtherNet/IP Unit for NX-series CPU Units.


Connect an NA-series PT to the built-in EtherNet/IP port on the CPU Unit.

To perform troubleshooting from an NS-series PT, connect the PT to the built-in EtherNet/IP port on the CPU Unit.

Refer to the NJ/NX-series CPU Unit Built-in EtherNet/IP Port User's Manual (Cat. No. W506) for details on the built-in EtherNet/IP port and CJ-series EtherNet/IP Unit Operation Manual for NJseries CPU Unit (Cat. No. W495) for details on the CJ1W-EIP21 EtherNet/IP Unit.

Serial Communications

You can use a Serial Communications Unit to connect to an NS-series PT.



Note You cannot use a Series Communications Unit for NX-series CPU Units.

Refer to the CJ-series Serial Communications Units Operation Manual for NJ-series CPU Unit (Cat. No. W494) for details on the Serial Communications Unit.

10-4-2 Connection with Serial Communications Devices

NX701 CPU Units


You cannot use a Serial Communications Unit or a Serial Communications Option Board to connect to an NX701 CPU Unit.

NX102 CPU Units

You can use an NX-series Communications Interface Unit.

Refer to the *NX-series Communications Interface Units User's Manual* (Cat. No. W540) for details of NX-series Communications Interface Units.


NX-series Communications Interface Unit



NX1P2 CPU Units


You can use a Serial Communications Option Board or an NX-series Communications Interface Unit to connect to an NX1P2 CPU Unit.

Refer to the *NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual* (Cat. No. W579) for details on the Serial Communications Option Board and *NX-series Communications Interface Units User's Manual* (Cat. No. W540) for details on the NX-series Communications Interface Unit.



NJ-series CPU Units

You can use a Serial Communications Unit to connect to an NJ-series CPU Unit. Refer to the *CJ-series Serial Communications Units Operation Manual for NJ-series CPU Unit* (Cat. No. W494) for details on the Serial Communications Unit.





Example of Actual Application Procedures

This section describes the procedures that are used to actually operate an NJ-series Controller.


11-1	Examp	le Application	2
	11-1-1	System Configuration	2
	11-1-2	Operation	2
11-2	Overvi	ew of the Example Procedure11-5	3
	11-2-1	Wiring and Settings11-3	3
	11-2-2	Software Design11-3	3
	11-2-3	Software Settings from the Sysmac Studio11-4	4
	11-2-4	Programming with the Sysmac Studio	8
	11-2-5	Simulation with the Sysmac Studio11-5	9
	11-2-6	Checking Operation and Starting Operation on the Actual System	9

11-1 Example Application

This section describes an example application for an NJ-series Controller.


11-1-1 System Configuration

Ur	nit name	Qty	Connected device
Power Supply Unit		1	
CPU Unit		1	
CJ-series Basic I/O Units		2	
CJ-series Analog Input Unit		1	Displacement Sensor
EtherCAT slaves	Servo Drives (G5 EtherCAT)	2	
	I/O Terminal	1	



11-1-2 Operation

Interrupt feeding starts when the sensor signal changes to ON during velocity control.



The vertical position changes based on the analog input from the Displacement Sensor.

11-2 Overview of the Example Procedure

This section describes examples of the actual operating procedures for an NJ-series Controller.

11-2-1 Wiring and Settings

Wire the Controller and make the hardware settings.

11-2-2 Software Design

Design the I/O, tasks, POUs, and variables.

I/O Design

- Design the relationship between the external I/O and the Unit configuration.
- Determine the intervals at which to refresh external I/O.

Task and POU Design

Consider the following:

- · What task configuration is required
- · Which programs to assign to which tasks
- · Which Units to assign to which tasks
- · What processing to place in programs and what processing to place in function blocks and functions

Variable Design

Consider the following:


- The separation of variables into those that you use in more than one POU (global variables) and variables that you use in only specific POUs (local variables)
- Defining the variable names for the device variables that you use to access slaves and Units
- · Defining the attributes of variables, such as the Name and Retain attributes
- · Designing the data types of variables

11-2-3 Software Settings from the Sysmac Studio

On the Sysmac Studio, you set the Unit and slave configurations, register global variables and device variables, create axes (axis variables), and set the Controller Setup and Special Unit Setup.


Start the Sysmac Studio.

Create a project in Sysmac Studio.



Create the Unit Configuration.


- 1 Double-click CPU/Expansion Racks under Configurations and Setup.
- **2** Create the Unit configuration by dragging Units.



3 Select each Unit and make the required settings.

Create the EtherCAT Slave Configuration.

- 1 Double-click EtherCAT under Configurations and Setup.
- **2** Create the slave configuration by dragging slaves.



- **3** Select the master and set the master parameters.
- **4** Select each slave and set the slave parameters.



Additional Information

At this point, you can use forced resetting from the I/O Map to check the wiring.

Register the Global Variables and Device Variables.


Registering Global Variables

- 1 Double-click Global Variables under Programming Data.
- **2** Register the global variables in the global variable table.

• Registering Device Variables

- 1 Double-click I/O Map under Configurations and Setup.
- 2 In the I/O Map, assign the variables to the I/O ports. (The I/O ports are created automatically from the Unit and slave configurations.)


You can automatically create device variable names with the Sysmac Studio. To do so, right-click an I/O port and select *Create Device Variable* from the menu.



By default, device variables are registered in the global variable table. If necessary, you can change the variable type from a global variable to a local variable (internal variable) for a POU.

Create Axes (Axis Variables)

- 1 Right-click Axis Settings under Configurations and Setups Motion Control Setup and select Add Axis Settings from the menu.
- **2** Assign Servo Drives to the axes (axis variables) that you created in the EtherCAT configuration.



- · Set the Axis Use parameter to Used Axis.
- For an NX-series CPU Unit, set the Motion Control parameter to Primary periodic task.
- Set the Axis Type parameter to Servo Axis.
- Set the *Input Device* and *Output Device* parameters to the EtherCAT slaves that you registered in the slave configuration.

Set the other parameters, such as the Unit Conversion Settings and Operation Settings.

Set the Controller Setup and the Special Unit Setup.

• Initial Settings for the PLC Function Module:

The Controller Setup includes the Startup Mode and other parameters.

• Initial Settings for Special Units:


Unit Configuration and Setup: Set the initial settings of the Analog Input Unit.

11-2-4 Programming with the Sysmac Studio

On the Sysmac Studio, create the programs, set the tasks, and build the project.

Write the Programs.

- 1 Right-click **Programs** under **Programming POU** and select **Add Ladder or Add ST** from the menu.
- **2** Double-click **Section**□ under the program that you registered.
- **3** Register the local variables for each program.
- **4** Enter the programs.



Create a program with the following instructions.

- · Homing: MC Home instruction
- · Velocity control: MC MoveVelocity instruction
- Interrupt feeding: MC_MoveFeed instruction
- · Positioning: MC Move instruction
- **5** As required, right-click **Functions** or **Function Blocks** under **Programming POU** and select **Add Ladder or Add ST** from the menu.

Double-click the function or function block that you registered. Register local variables for each function and function block. Create the algorithms.

Note For a ladder diagram, press the **R** Key and create the following rungs.

Set Up the Tasks.

Double-click Task Settings under Configurations and Setup.

- In the *Task Settings*, set the task period and execution condition for the primary periodic task from the pulldown list.
- In the I/O Control Task Settings, select the task name to which to assign each Unit and slave.
- In the *Program Assignment Settings*, assign the programs to the primary periodic task or the priority-16 periodic task.

Build the Project.

Select Build from the Project Menu.

11-2-5 Simulation with the Sysmac Studio

Simulation is used to perform desktop debugging.


Check the task execution times and the real processing times of tasks. Review the task design as required.

Starting the Simulator and Connecting to It

Select *Run in Execution Time Estimation Mode* from the Simulation Menu. Select the relevant hardware revision in the Unit that the hardware revision is displayed. The Simulator (i.e., the virtual Controller) starts. An online connection is created automatically.

Checking the Task Execution Time on the Simulator

Double-click **Task Settings** under **Configurations and Setup**. Check to see if the task execution times in the Task Execution Time Monitor exceed the task periods.



If necessary, review the task configuration, program assignments, and task periods.

Saving the Project

Select Save As from the File Menu.

11-2-6 Checking Operation and Starting Operation on the Actual System

Go online with the Controller, download the project, check the wiring and perform test operation before you start actual operation.

Going Online

- **1** Turn ON the power supply to NJ-series Controller.
- **2** Connect the computer and the CPU Unit with a USB cable.
- 3 Select *Communications Setup* from the Controller Menu. Select the connection method for the connection configuration in the *Connection Type* Field.
- **4** Select **Online** from the Controller Menu.

Downloading the Project with the Synchronize Menu

Select Synchronize from the Controller Menu and download the project to the Controller.


Note Use the Synchronize Menu of the Sysmac Studio to upload and download the project.

Checking Wiring

Check the wiring by performing forced-refreshing with user-specified values from the I/O Map or Ladder Editor.

MC Test Run

- **1** Open the MC Test Run Tab Page.
- **2** Change the CPU Unit to PROGRAM mode.
- **3** Monitor input signals on the display to check the wiring.
- **4** Jog the axis from the display.



Manual Operation

Change the CPU Unit to RUN mode.

- Turning the Servo ON and OFF: Execute the MC Power motion control instruction.
- Jogging: Execute the MC MoveJog motion control instruction.

Homing

Homing: Execute the MC_Home instruction.

Actual Operation

Select $Operation\ Mode - RUN\ Mode$ from the Controller Menu. If an error occurs, investigate the cause and edit the user program.



Troubleshooting


This section describes the overview of methods for checking errors.

12.1 Overview of Troublesheeting	 122
12-1 Overview of Troubleshooting	 12-2

12-1 Overview of Troubleshooting

You manage all of the errors that occur on the NJ/NX-series Controller as events. This allows you to see what errors have occurred and find corrections for them with the same methods for the entire range of errors that is managed (i.e., CPU Unit, NX Units, NX-series Slave Terminals, EtherCAT slaves, *1 and CJ-series Units).

*1 Only Sysmac devices are supported.



You can use the troubleshooting functions of the Sysmac Studio or the Troubleshooter on an HMI to quickly check for errors that have occurred and find corrections for them.

Refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for types of errors, meanings, specific corrections when errors occur and for troubleshooting information on the entire NJ/NX-series Controller.



Appendices

The appendices provide the CPU Unit specifications, real processing times of tasks, system-defined variable lists, and other supplemental information for the body of this manual.

A-1	Specif	fications	. A-3
	A-1-1	General Specifications	A-3
	A-1-2	Performance Specifications	A-3
	A-1-3	Function Specifications	. A-12
A-2		lating Guidelines for the Real Processing Times of	
		for the NX701 System	
	A-2-1	Calculating the Average Real Processing Times of Tasks	. A-22
	A-2-2	Example of Calculating the Average Real Processing Time of a Task and Setting the Task Period	. A-29
A-3	Calcul	lating Guidelines for the Real Processing Times of Tasks for the	
	NX102	2 System	A-32
	A-3-1	Calculating the Average Real Processing Times of Tasks	. A-32
	A-3-2	Example of Calculating the Average Real Processing Time of a Task and Setting the Task Period	. A-38
A-4		lating Guidelines for the Real Processing Times of	
		for the NX1P2 System	
	A-4-1	Calculating the Average Real Processing Times of Tasks	. A-43
	A-4-2	Example of Calculating the Average Real Processing Time of a Task and Setting the Task Period	. A-49
A-5		lating Guidelines for the Real Processing Times of	
		for the NJ-series System	
	A-5-1	Calculating the Average Real Processing Times of Tasks	. A-53
	A-5-2	Example of Calculating the Average Real Processing Time of a Task and Setting the Task Period	. A-63
A-6	Syster	m-defined Variables	A-67
	A-6-1	System-defined Variables for the Overall NJ/NX-series Controller (No Category)	۸.68
	A-6-2	PLC Function Module, Category Name: _PLC	
	A-6-3	PLC Function Module, Category Name:CJB	
	A-6-4	NX Bus Function Module, Category Name: NXB	
	A-6-5	Motion Control Function Module, Category Name: MC	
	/ \-U-J	Motion Control i dilottori Module, Category MarileMO	00

	A-6-6	EtherCAT Master Function Module, Category Name: _EC	A-91
	A-6-7	EtherNet/IP Function Module, Category Name: _EIP	A-96
	A-6-8	Meanings of Error Status Bits	A-123
A-7	Specif	ications for Individual System-defined Variables	A-125
	A-7-1	System-defined Variables for the Overall NJ/NX-series	
		Controller (No Category)	A-126
	A-7-2	PLC Function Module, Category Name: _PLC	A-143
	A-7-3	PLC Function Module, Category Name: _CJB	A-149
	A-7-4	NX Bus Function Module, Category Name: _NXB	A-154
	A-7-5	Motion Control Function Module, Category Name: _MC	A-157
	A-7-6	EtherCAT Master Function Module, Category Name: _EC	A-161
	A-7-7	EtherNet/IP Function Module, Category Name: _EIP	A-170
A-8	Attribu	ites of CPU Unit Data	A-195
A-9	Conter	nts of Memory Used for CJ-series Units	A-200
	A-9-1	CIO Area	
	A-9-2	Internal I/O Area	
	A-9-3	Holding Area	
	A-9-4	DM Area	A-203
	A-9-5	EM Area	
Δ-10) Variah	le Memory Allocation Methods	Δ-205
Α-1	A-10-1		
	A-10-1 A-10-2	•	
	_	ering a Symbol Table on the CX-Designer	
A-12	2 Enable	P/Disable EtherCAT Slaves and Axes	
	A-12-1	Project Settings When Using EtherCAT Slaves and Axes	
	A-12-2	Using Instructions to Enable/Disable EtherCAT Slaves and Axes	
	A-12-3	System-defined Variables That Indicate EtherCAT Slave or Axis Status	
	A-12-4		
	A-12-5	Checking Enabled/Disabled Program	
	A-12-6	Settings with the Sysmac Studio	A-223
	A-12-7	Examples of Applications of Enabling/Disabling EtherCAT Slaves	
		and Axes	
A-13	Size R	estrictions for the User Program	A-227
	A-13-1	User Program Object Restrictions	A-227
	A-13-2	Counting User Program Objects	A-231
A-14	4Replac	eing CPU Units with Unit Version 1.02 or Earlier	A-233
	A-14-1	Uploading the Data from the CPU Unit	
	A-14-2	Connecting the New CPU Unit	A-236
	A-14-3	Downloading the Data to the CPU Unit	A-237
A-1	Versio	n Information for NX-series Controllers	A-241
	A-15-1	Relationship Between Unit Versions of CPU Units and	
		Sysmac Studio Versions	A-241
	A-15-2	Functions That Were Added or Changed for Each Unit Version	A-243
A-16	6 Versio	n Information for NJ-series Controllers	A-245
	A-16-1	Relationship between Unit Versions of CPU Units and	
		Sysmac Studio Versions	A-245
	A-16-2	Relationship between Hardware Revisions of CPU Units and	
		Sysmac Studio Versions	A-247
	A-16-3	Functions That Were Added or Changed for Each Unit Version	A-248
	A-16-4	Performance Improvements for Unit Version Ungrades	Δ-251

A-1 Specifications

This section gives the specifications of the NJ/NX-series Controllers.

A-1-1 General Specifications

Refer to the following hardware manuals for general specifications.

- NX-series CPU Unit Hardware User's Manual (Cat. No. W535)
- NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593)
- NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
- NJ-series CPU Unit Hardware User's Manual (Cat. No. W500)

A-1-2 Performance Specifications

		tem		NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
Process-	Instruction	LD instruction ecution Math instruction (for long)		0.37 ns or more	3.3 ns		1.2 ns (1.9 ns or less)*1	2.0 ns (3.0 ns or less)*2	3.3 ns (5.0 ns or less)*3
ing time	times			3.2 ns or more	70 ns or more		26 ns or more ^{*4}	42 ns or more*5	70 ns or more ^{*6}
	Size		80 MB	5 MB	1.5 MB	20 MB	5 MB	3 MB	
	Program capacity*7	Quantity	Number of POU definitions	6,000	3,000	450	3,000	750	450
	Сарасну	apacity ^{*/} Quantity	Number of POU Instances	48,000	9,000	1,800	9,000 (*)	3,000 (*)	1,800
		Retain attri-	Size	4 MB	1.5 MB	32 KB* ⁹	2 MB	0.5 MB	
	Memory capacity for	butes*8	Number of variables	40,000	10,000	5,000	10,000	5,000 (*)	
	variables	No Retain	Size	256 MB	32 MB	2 MB	4 MB	2 MB	
Program-		attributes*10	Number of variables	360,000	90,000	90,000	180,000 (*)	90,500 (*)	22,500
ming	Data types	Number of dat	a types	8,000	1,000	1,000	2,000	1,000	
		CIO Area			6,144 words (CI 6143)* ¹¹	O 0 to CIO	6,144 words (C	IO 0 to CIO 61	43)
		Work Area			512 words (W0	to W511)* ¹¹	512 words (W0	to W511)	
	Memory for CJ-series	Holding Area			1,536 words (H0	0 to H1535)* ¹²	1,536 words (H	0 to H1535)	
	Units (Can be specified with AT specifica-	Units (Can be pecified with NT specifica-			32,768 words (D0 to D32767)*12	16,0000 words (D0 to D15999)*12	32,768 words (D0 to D32767)	
	tions for variables.)				32,768 words × 25 banks (E0_00000 to E18_32767) *12		32,768 words × 25 banks (E0_00000 to E18_32767)	32,768 words (E0_00000 to	
Motion co	ontrol			Refer to Perform	nance Specification	ons of Motion Con	trol for Each Type	e of CPU Units	on page A-9.
Periph-	Supported serv	rices		Sysmach Stu- dio connection			Sysmach Studi	o connection	
eral USB port	Physical layer			USB 2.0-com- pliant B-type connector			USB 2.0-compl	iant B-type cor	nnector
	Transmission d	listance		5 m max.			5 m max.		

Number of ports 2 2 1 10BASE-T/100BASE-TX 10BASE-T/100BASE-TX 10BASE-TX 10	nents (*)		
T/100BASE-TX/ 1000BASE-T Frame length 1,514 bytes max. Media access method CSMA/CD Modulation Baseband Topology Star Baud rate 1 Gbps (1000BASE-TX) (1000BASE-T) Transmission media Maximum transmission distance between Ethernet switch and node Maximum number of cascade connections Maximum number of connections Maximum number of connections Maximum number of connections Maximum number of connections Can be set for each connection. There are no restrictions if an Ethernet switch is used. 256 per port 32 pe	nents (*)		
Media access method CSMA/CD	nents (*)		
Modulation Baseband Topology Star	nents (*)		
Topology Star 1 Gbps (100BASE-TX) 100 Mbps (100BASE-TX)	nents (*)		
Baud rate 1 Gbps (1000BASE-TX) Transmission media STP (shielded, twisted-pair) cable of Ethernet category 5, 5e or higher Maximum transmission distance between Ethernet switch and node Maximum number of cascade connections There are no restrictions if an Ethernet switch is used. Maximum number of connections There are no restrictions if an Ethernet switch is used. 256 per port 32 per port 512 total 64 total Can be set for each connection. 1 to 10,000 ms in 1.0-ms increments (*) Can be set for each connection.	nents (*)		
Transmission media STP (shielded, twisted-pair) cable of Ethernet category 5, 5e or higher Maximum transmission distance between Ethernet switch and node Maximum number of cascade connections There are no restrictions if an Ethernet switch is used. Maximum number of connections There are no restrictions if an Ethernet switch is used. 256 per port 512 total 64 total Can be set for each connection.	nents (*)		
Maximum transmission distance between Ethernet switch and node Maximum number of cascade connections There are no restrictions if an Ethernet switch is used. Maximum number of connections There are no restrictions if an Ethernet switch is used. 256 per port 512 total 64 total Can be set for each connection.	nents (*)		
Ethernet switch and node Maximum number of cascade connections There are no restrictions if an Ethernet switch is used. Maximum number of connections There are no restrictions if an Ethernet switch is used. 256 per port 512 total 64 total Can be set for each connection.	nents (*)		
Maximum number of connections 256 per port 512 total 32 per port 64 total Can be set for each connection. 510 total 510 tota	nents (*)		
nections 512 total 64 total Can be set for each connection. 1 to 10,000 ms in 1.0-ms increments (*) Can be set for each connection. in 1.0-ms increments (*)	nents (*)		
Can be set for each connection.	nents (*)		
each connection. each connection. in 1.0-ms increments (*) Can be set for each connection	nents (*)		
Packet interval*13 0.5 to 10,000 1 to 10,000 ms Can be set for	I.		
ms in 0.5-ms in 1-ms incre- each connection.			
Built-in Ether- Net/IP port Permissible communications band Permissible communications band 40,000 pps*14 (including heartbeat) 12,000 pps*14 (including heartbeat) CIP Safety routing) 3,000 pps*14 (including heartbeat) (*)			
Maximum number of tag 256 per port 32 per port 32			
sets 512 total 40 total*15			
Tag types Network variables, CIO, Work, Holding and DM Areas Network variables, CIO, Work, DM, and EM Areas	Holding,		
CIP service: Tag data links (cyclic com- Number of tags per connection (i.e., per tag set) 8 (7 tags if Controller status is included in the tag set.)			
munications) Maximum number of tags 256 per port 512 total			
Maximum link data size per node (total size for all tags) 369,664 bytes 19,200 bytes			
Maximum data size per connection 1,444 bytes 600 bytes			
256 per port 32 per port 32 (1 connection = 1 tag set)			
Maximum number of regis- 512 total 40 total*15			
trable tag sets (1 connection = 1 tag set) (1 connection = 1 tag set)			
Maximum tag set size 1,444 bytes (Two bytes are used if Controller status is included in the tag set.) 600 bytes (Two bytes are used if Controller status is included in the tag set.)	e tag set.)		
Multi-cast packet filter*16 Supported			

				NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
		tem							
				128 per port	32 per port	32 (clients plus	server)		
		Class 3 (numb	er of connec-	256 total	64 total				
		tions)		(clients plus	(clients plus				
			Maximum	server) 32 per port	server)	32			
			number of	64 total		32			
	CIP message service:		clients that	04 total					
	Explicit mes-		can com- municate at						
	sages	UCMM (non- connection	one time						
		type) Maximum	32 per port		32				
			number of servers that	64 total					
			can com-						
			municate at one time						
		Maximum num			16 total				
	CIP Safety	routable CIP S							
	routing (*)	tions							
		Maximum rout			32 bytes				
	Number of TCP	data length per connection per of TCP sockets		30 (*)	60	30 (*)			
Built-in					UA 1.02 Micro		UA 1.02 Micro	-	
Ether- Net/IP	Ether- Net/IP				Embedded Device Server		Embedded Device Server		
port		Support Profile	e/Model		Profile		Profile		
					PLCopen Information		PLCopen Information		
					Model		Model		
	Default Endpoi	int/Port		opc.tcp://192.1 68.250.1:4840/		opc.tcp://192. 168.250.1:48	-		
							40/		
		Maximum num sions(Client)	ber of ses-		5		5	-	
		Maximum number of MonitoredItems per server			2000		2000	-	-
		Sampling rate of the Monitored Items (ms)			0 ^{*18} , 50, 100,		0*18, 50, 100,	-	-
					250, 500, 1000,2000,		250, 500, 1000,2000,		
					5000, 10000		5000, 10000		
		Maximum number of Sub- scriptions per server			100		100	-	
	OPC UA	Maximum num ables to open a			10,000		10,000	-	
	Server*17	objects	ops ud						
		Maximum num attribute of va			10,000		10,000	-	-
		open as OPC L							
	Structure's de		initions able		100		100	-	
Built-in		Variables unab	le to open		*19		*19	-	
Ether- Net/IP		SecurityPolicy	/Mode		*20		*20	_	-
port									
	Applic		Authentica- tion		X.509		X.509	-	
		Application			Trusted certifi- cation: 32		Trusted certifi- cation: 32	-	
Built-in		Authentica- tion	Maximum		Issuer certifi-		Issuer certifi-		
Ether- Net/IP		1011	number of certification		cation: 32		cation: 32		
port					Rejected certi- fication: 32		Rejected cer- tification: 32		
		Hear Author	Authentica-		User name /		User name /	-	-
		User Authen- tication	tion		Password		Password		
					Anonymous		Anonymous		

	Item	NX701-	NX102-	NX1P2-	NJ501- NJ301-	NJ101-				
	Communications standard	IEC 61158 Type	:12							
	EtherCAT master specifications	Class B (Featur	e Pack Motion Co	ontrol compliant)						
	Physical layer	100BASE-TX								
	Modulation	Baseband								
	Baud rate	100 Mbps (100BASE-TX)								
	Duplex mode	Auto	· · · · · · · · · · · · · · · · · · ·							
	Topology	Line, daisy chain, and branching								
	Transmission media	Twisted-pair cat and braiding)	ole of category 5 o	or higher (double-	shielded straight cable with alu	ıminum tape				
	Maximum transmission distance between nodes	100 m								
	Maximum number of slaves	512	64	16	192	64				
	Range of node addresses that can be set	1 to 512	1 to 192							
		Inputs: 11,472 bytes	Inputs: 5,736 bytes	Inputs: 1,434 bytes	Inputs: 5,736 bytes Outputs: 5,736 bytes					
Duilt in	Maximum process data size	Outputs: 11,472 bytes	Outputs: 5,736 bytes	Outputs: 1,434 bytes	However, the maximum num data frames is 4.	ber of process				
Built-in Ether- CAT port	maximum process data size	However, the maximum number of process data frames is 8.	However, the maximum number of process data frames is 4.	However, the maximum number of process data frames is 1.						
	Maximum process data size per slave	Inputs: 1,434 bytes Outputs: 1,434 bytes								
	Communications cycle	• Primary periodic task 125 µs 250 µs to 8 ms (in 250-µs increments)	1,000 µs to 32,000 µs (in 250-µs incre- ments)	2,000 µs to 8,000 ms (in 250-µs incre- ments)	500, 1,000, 2,000, or 4,000 μs (*)	1,000, 2,000, or 4,000 μs				
		periodic task 125 μs 250 μs to 100 ms (in 250-μs increments)								
	Sync jitter	1 μs max.		I	T					
	Communications method			Half duplex (when con- nected to the Serial Commu- nications Option Board)						
Serial commu- nications	Synchronization method			Start-stop syn- chronization (when con- nected to the Serial Commu- nications Option Board)						
	Baud rate			1.2/2.4/4.8/9.6/ 19.2/38.4/57.6/ 115.2 kbps (when connected to the Serial Communications Option Board)						

	ltem			NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-	
		item								
		Maximum num					10			
		Units per CPU								
	Maximum	Expansion Rack			32	Lo				
	number of		Maximum number of NX Units per CPU Rack		32	8				
	connectable	Maximum num					40			
	Units	Units for entire								
		Maximum num		4,096	432	24	4,096		400	
		Units for entire								
Unit con-	Maximum numl	ber of Expansion		0			3			
figura- tion	I/O capacity	Maximum number of I/O points on CJ-series Units					2,560			
			NX-PA9001	A non-isolated power supply for		NJ-P□3001				
	Power Supply Unit for CPU	Model		NX-PD7001	NX-PD7001 DC input is built into the CPU Unit.					
	Rack and Expansion	Power OFF supply		30 to 45 ms			30 to 45 ms			
	Racks	time	DC power supply	5 to 20 ms	2 to 8 ms		22 to 25 ms			
	Maximum NV B	us I/O data size			Input: 8,192 bytes					
	Maximum NA B	ous I/O data size			Output: 8,192 b	ytes				
Option Board	Number of slots	s				*21				
	Input	Number of poi	nts			*22				
Built-in		Number of poi	nts			*23				
I/O	Output	Load short-cir	cuit		*24					
		protection								
						-3.5 to +0.5 min e				
Internal	Accuracy			At ambient temperature of 25°C: –1.5 to +1.5 min error per month At ambient temperature of 0°C: –3 to +1 min error per month						
clock	Retention time of built-in capacitor		At ambient temperature of 40°C: 10 days							

- *1 When the hardware revision for the Unit is A or B, the processing time is 1.1 ns (1.7 ns or less).
- *2 When the hardware revision for the Unit is A, the processing time is 1.6 ns (2.5 ns or less).
- *3 When the hardware revision for the Unit is A, the processing time is 3.0 ns (4.5 ns or less).
- *4 When the hardware revision for the Unit is A or B, the processing time is 24 ns or more.
- *5 When the hardware revision for the Unit is A, the processing time is 35 ns or more.
- *6 When the hardware revision for the Unit is A, the processing time is 63 ns or more.
- *7 Execution objects and variable tables (including variable names)
- *8 Does not include Holding, DM, and EM Area memory for CJ-series Units.
- *9 Memory for CJ-series Units is included.
- *10 Does not include CIO and Work Area memory for CJ-series Units.
- *11 Variables without a Retain attribute are used. The value can be set in 1-word increments.
- *12 Variables with a Retain attribute are used. The value can be set in 1-word increments.
- *13 Data will be refreshed at the set interval, regardless of the number of nodes.
- *14"pps" means packets per second, i.e., the number of communications packets that can be sent or received in one second.
- *15 If more than 40 tag sets are registered in total, the Number of Tag Sets for Tag Data Links Exceeded (840E0000 hex) event will occur.
- *16 As the EtherNet/IP port implements the IGMP client, unnecessary multi-cast packets can be filtered by using an Ethernet switch that supports IGMP Snoop-
- *17The CPU Unit that supports OPC UA in NJ-series is an NJ501-1□00 CPU Unit with unit version 1.17 or later.
- *18 If set to 0, it is assumed that is set to 50.
- *19 The following variables cannot be published.
 - · Variable which size are over 1024Bytes
 - · Double and over dimensional array of structures
 - Structures includes double and over dimensional array
 - · Structures nested 4 and over
 - Unions
 - Array which's index number don't start from 0
 - Array which's element is over 1024
 - Structures which's members are over 100.
- *20 The followings can be selected.
 - None
 - Sign Basic128Rsa15
 - Sign Basic256
 - Sign Basic256Sha256
 - SignAndEncrypt Basic128Rsa15
 - SignAndEncrypt Basic256
 - SignAndEncrypt Basic256Sha256

Note Items that are marked with asterisks in the table are improvements that were made during version upgrades. Refer to *A-15 Version Information for NX-series Controllers* and *A-16 Version Information for NJ-series Controllers* for information on version upgrades.

• Performance Specifications of Motion Control for Each Type of CPU Units

	lán		NX7	01-			
	Item		17□□	16□□			
	Maximum nun	mber of controlled axes	256 axes 128 axes				
		Motion control axes	256 axes 128 axes				
		Single-axis position control axes					
	Maximum nun	mber of used real axes	256 axes	128 axes			
Number of controlled		Used motion control servo axes	256 axes	128 axes			
axes*1	Used single-axis position control servo axes						
	Maximum number of axes for linear interpolation axis control		4 axes per axes group				
	Number of axes for circular interpolation axis control		2 axes per axes group				
Maximum num	ber of axes gro	ups	64 axes groups				
Motion control	period		The same control period as that is used for the process data communications cycle for EtherCAT.				
	Number of cam data	Maximum points per cam table	65,535 points				
Cams	points	Maximum points for all cam tables	1,048,560 points				
	Maximum number of cam tables		640 tables				
Position units	Position units		Pulse, mm, μm, nm, degree, and inch				
Override factor	rs		0.00%, or 0.01% to 500.00%				

^{*1} Refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507) for descriptions of axes.

				NV	400			
	Item				102-	To the second se		
			12□□	11□□	10□□	90□□		
	Maximum n axes	umber of controlled	15 axes			4 axes		
		Motion control axes	11 axes	11 axes				
Number of controlled axes*1		Single-axis posi- tion control axes	4 axes					
		umber of used real	12 axes	8 axes	6 axes	4 axes		
		Used motion con- trol servo axes	8 axes	4 axes	2 axes			
		Used single-axis position control servo axes	4 axes					
		umber of axes for lin- ation axis control	4 axes per axes group					
		axes for circular n axis control	2 axes per axes group					
Maximum nu	mber of axes	groups	8 axes groups					
Motion contr	ol period		The same control period	as that is used for the proce	ess data communications of	cycle for EtherCAT.		
	Number of cam data	Maximum points per cam table	65,535 points					
Cams	points	Maximum points for all cam tables	262,140 points					
	Maximum n	umber of cam tables	160 tables					
Position unit	s		Pulse, mm, µm, nm, degree, and inch					
Override fact	ors		0.00%, or 0.01% to 500.00%					

^{*1} For details on each axis, refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507).

	14			NX1P2-			
	Item		1100000	100000	900000		
	Maximum nur	nber of controlled axes	12 axes	10 axes	4 axes		
	Motion control axes		8 axes	6 axes			
		Single-axis position control axes	4 axes				
	Maximum nur	nber of used real axes	8 axes	6 axes	4 axes		
Number of controlled		Used motion control servo axes	4 axes	2 axes			
axes ^{*1}	Used single-axis position control servo axes		4 axes				
	Maximum number of axes for linear interpolation axis control		4 axes per axes group				
	Number of axtion axis cont	es for circular interpola- rol	2 axes per axes group				
Maximum num	ber of axes gro	ups	8 axes groups				
Motion control	period		The same as for the primary periodic task.				
	Number of cam data	Maximum points per cam table	65,535 points				
Cams	points	Maximum points for all cam tables	262,140 points				
	Maximum number of cam tak		80 tables				
Position units			Pulse, mm, μm, nm, degree, and inch				
Override factor	rs		0.00%, or 0.01% to 500.00%				

^{*1} Refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507) for descriptions of axes.

				NJ501-			
	Item		□5□□	□4□□	□3□□		
	Maximum number of controlled axes		64 axes	32 axes	16 axes		
	Motion control axes		64 axes	32 axes	16 axes		
		Single-axis position control axes					
	Maximum nur	mber of used real axes	64 axes	32 axes	16 axes		
Number of controlled		Used motion control servo axes	64 axes	32 axes	16 axes		
axes ^{*1}	Used single-axis position control servo axes						
	Maximum nur interpolation	mber of axes for linear axis control	4 axes per axes group				
	Number of axtion axis cont	es for circular interpola- rol	2 axes per axes group				
Maximum num	ber of axes gro	ups	32 axes groups				
Motion control	period		The same control period as that is used for the process data communications cycle for EtherCAT.				
	Number of cam data	Maximum points per cam table	65,535 points				
Cams	points	Maximum points for all cam tables	1,048,560 points				
	Maximum nur	mber of cam tables	640 tables				
Position units			Pulse, mm, μm, nm, degree, and inch				
Override facto	rs		0.00%, or 0.01% to 500.00%				

^{*1} Refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507) for descriptions of axes.

	14		NJS	01-			
	Item		12□□	11□□			
	Maximum nun	mber of controlled axes	15 axes (*)				
		Motion control axes	15 axes (*)				
		Single-axis position control axes					
	Maximum number of used real axes		8 axes	4 axes			
Number of controlled		Used motion control servo axes	8 axes	4 axes			
axes*1	Used single-axis position control servo axes						
	Maximum number of axes for linear interpolation axis control		4 axes per axes group				
	Number of axes for circular interpolation axis control		2 axes per axes group				
Maximum num	ber of axes gro	ups	32 axes groups				
Motion control	period		The same control period as that is used for the process data communications cycle for EtherCAT.				
	Number of cam data	Maximum points per cam table	65,535 points				
Cams	points	Maximum points for all cam tables	262,140 points				
	Maximum nun	nber of cam tables	160 tables				
Position units	Position units		Pulse, mm, μm, nm, degree, and inch				
Override factor	rs		0.00%, or 0.01% to 500.00%				

^{*1} Refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507) for descriptions of axes.

Note Items that are marked with asterisks in the table are improvements that were made during version upgrades. Refer to A-15 Version Information for NX-series Controllers and A-16 Version Information for NJ-series Controllers for information on version upgrades.

	ltam		NJ1	01-		
	Item		10□□	90□□		
	Maximum nur	nber of controlled axes	6 axes			
	Motion control axes Single-axis position control axes		6 axes			
	Maximum nur	mber of used real axes	2 axes			
Number of controlled		Used motion control servo axes	2 axes			
axes ^{*1}		Used single-axis position control servo axes				
	Maximum number of axes for linear interpolation axis control		4 axes per axes group			
	Number of axes for circular interpolation axis control		2 axes per axes group			
Maximum num	ber of axes gro	ups	32 axes groups			
Motion control	period		The same control period as that is used for the process data communications cycle for Ether-CAT.			
	Number of cam data	Maximum points per cam table	65,535 points			
Cams	points	Maximum points for all cam tables	262,140 points			
	Maximum nun	nber of cam tables	160 tables			
Position units			Pulse, mm, μm, nm, degree, and inch			
Override facto	rs		0.00%, or 0.01% to 500.00%			

^{*1} Refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507) for descriptions of axes.

A-1-3 Function Specifications

		Item		NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
	Function			I/O refresh a	nd the user p	rogram are exection conditions ar	uted in units th	at are called t	
		Periodi- cally exe-	Maximum number of pri- mary periodic tasks	1				,	
Taaka		cuted tasks	Maximum number of peri- odic tasks	4	2		3		
Tasks		Condi- tionally exe-	tionally number of						
		cuted tasks (*)	Execution con- ditions	When Activa variable is m		instruction is ex	ecuted or wher	n condition ex	pression for
	Setup	System Service Monitor- ing Settings					age of the tot time are mon	n interval and al user progra hitored for the sses that are e	m execution system ser-
	POUs (pro-	Programs			re assigned to				
	gram orga-	Function	blocks			ate objects with			
	nization units)	Functions	3	POUs that are used to create an object that determine unique outputs for the inputs, such as for data processing.					
n I:	Program- ming languages	Types		Ladder diagı	rams ^{*1} and str	ructured text (ST)		
	Namespaces	Namespaces (*)		Namespaces	s are used to	create named gr	oups of POU d	lefinitions.	
	Variables	External access of variables	Network vari- ables	The function which allows access from the HMI, host computers, or other Controllers					
			Boolean	BOOL					
			Bit strings		D, DWORD, a				
			Integers			NT, USINT, UDIN	T, and ULINT		
Pro-		Basic	Real numbers	REAL and L	REAL				
gram-	Data to an	data	Durations	TIME					
ming	Data types	types	Dates	DATE OF B	141/				
			Times of day Dates and	TIME_OF_D DATE_AND					
			times		_11101⊏				
			Text strings	STRING					
		Derivative	data types		Jnions, and E	numerations groups together	المام مانداد الماندان	ront dete to	
			Function Maximum number of members	2,048	data type tnat	groups together	data with diffe	erent data type	es.
	Data types	Struc- tures	Nesting maxi- mum levels	8					
			Member data types	Basic data ty	/pes, structure	es, unions, enum	erations, or an	ray variables	
			Specifying member off- sets (*)	You can use	member offse	ets to place struc	ture members	at any memo	ry locations.

				NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-		
		Item									
			Function	A derivative of types.	data type that	enables access t	to the same d	ata with differe	ent data		
	Data types	Union	Maximum number of members	4							
	Duta types		Member data types	BOOL, BYTE	BOOL, BYTE, WORD, DWORD, and LWORD						
		Enumer- ation	Function	values.	A derivative data type that uses text strings called enumerators to express variable values. An array is a group of elements with the same data type. You specify the number						
Pro- gram- ming Data type attributes			Function			nents with the sar from the first elen					
		Array	Maximum number of dimensions	3							
		specifi- cations	Maximum number of ele- ments	65,535							
			Array specifi- cations for FB instances	Supported							
	Range specifications				cify a range fo in the specifie	r a data type in ad d range.	dvance. The o	lata type can t	ake only val-		
	Libraries (*)	raries (*)			user libraries.						
	Control mode	ntrol modes			rol, Velocity c	ontrol, and Torqu	e control				
	Axis types	s types			Servo axes, Virtual servo axes, Encoder axes, and Virtual encoder axes						
	Positions that	t can be ma	anaged	Command positions and actual positions							
			Absolute posi- tioning	value.		or a target position					
		Single-	Relative posi- tioning	position.		or a specified trav					
		position	Interrupt feed- ing	interrupt inpu	it was receive	or a specified trav d from an externa	al input.				
Motion control *2	Single axes	control	Cyclic syn- chronous absolute posi- tioning (*)	A positioning	command is	output each conti	rol period in P	osition Contro	l Mode.		
	Onigio axos	Single-	Velocity con- trol	Velocity cont	rol is performe	ed in Position Co	ntrol Mode.				
		axis velocity control	Cyclic syn- chronous velocity con- trol	A velocity con	mmand is out	put each control բ	period in Velo	city Control M	ode.		
		Single- axis torque control	Torque control	The torque o	f the motor is	controlled.					

		Item		NX701- NX102- NX1P2- NJ501- NJ301- NJ101-					
			Starting cam operation	A cam motion is performed using the specified cam table.					
		Single- axis	Ending cam operation	The cam motion for the axis that is specified with the input parameter is ended.					
			Starting gear operation	A gear motion with the specified gear ratio is performed between a master axis and slave axis.					
			Positioning gear operation	A gear motion with the specified gear ratio and sync position is performed between a master axis and slave axis.					
		synchro- nized	Ending gear operation	The specified gear motion or positioning gear motion is ended.					
		control	Synchronous positioning	Positioning is performed in sync with a specified master axis.					
			Master axis phase shift	The phase of a master axis in synchronized control is shifted.					
			Combining axes	The command positions of two axes are added or subtracted and the result is output as the command position.					
	Single- axis	Powering the Servo	The Servo in the Servo Drive is turned ON to enable axis motion.						
		manual opera- tion	Jogging	An axis is jogged at a specified target velocity.					
			Resetting axis errors	Axes errors are cleared.					
			Homing	A motor is operated and the limit signals, home proximity signal, and home signal are used to define home.					
			Homing with specified parameters (*)	The parameters are specified, the motor is operated, and the limit signals, home proximity signal, and home signal are used to define home.					
Motion			High-speed homing	Positioning is performed for an absolute target position of 0 to return to home.					
control *2	Single axes		Stopping	An axis is decelerated to a stop.					
		Auxil-			Immediately stopping	An axis is stopped immediately.			
			Setting over- ride factors	The target velocity of an axis can be changed.					
			Changing the current position	The command current position or actual current position of an axis can be changed to any position.					
		iary func-	Enabling exter- nal latches	The position of an axis is recorded when a trigger occurs.					
		tions for single-axis	Disabling external latches	The current latch is disabled.					
		control	Zone monitor- ing	You can monitor the command position or actual position of an axis to see when it is within a specified range (zone).					
			Enabling digi- tal cam switches (*)	You can turn a digital output ON and OFF according to the position of an axis.					
			Monitoring axis following error	You can monitor whether the difference between the command positions or actual positions of two specified axes exceeds a threshold value.					
			Resetting the following error	The error between the command current position and actual current position is set to 0.					
			Torque limit	The torque control function of the Servo Drive can be enabled or disabled and the torque limits can be set to control the output torque.					
			Command position compensation	The function which compensate the position for the axis in operation.					
			Start velocity (*)	You can set the initial velocity when axis motion starts.					

		Itama		NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-								
		Item															
			Absolute lin- ear interpola- tion	Linear interpo	olation is perfo	ormed to a specif	ied absolute	position.									
		Multi- axes	Relative linear interpolation	Linear interpo	olation is perfo	ormed to a specif	ied relative p	osition.									
		coordi- nated	Circular 2D interpolation	Circular interpolation is performed for two axes.													
		control	Axes group cyclic synchro- nous absolute positioning (*)	A positioning	command is	output each conti	ol period in F	Position Contro	l Mode.								
			Resetting axes group errors	Axes group e	errors and axis	errors are cleare	ed.										
			Enabling axes groups	Motion of an	axes group is	enabled.											
	Axes groups		Disabling axes groups	Motion of an	axes group is	disabled.											
		Auxil- iary	Stopping axes groups	All axes in int	terpolated mo	tion are decelera	ted to a stop.										
		func- tions for multi- axes	Immediately stopping axes groups	All axes in int	terpolated mo	tion are stopped	immediately.										
		coordinated	coordi- nated	coordi- nated	coordi- nated	coordi- nated	coordi- nated	coordi- nated	coordi- nated	coordi- nated	Setting axes group override factors	The blended	target velocity	is changed durii	ng interpolate	ed motion.	
				Reading axes group posi- tions (*)	be read.		tions and actual										
Motion control	group (*)			<u> </u>													
*2			Setting cam table properties	The end point index of the cam table that is specified in the input parameter is changed.					neter is								
	0	Cams	Saving cam tables	The cam table that is specified with the input parameter is saved in non-volatile memory in the CPU Unit.													
	Common		Generating cam tables (*)	The cam table is generated from the cam property and cam node that is specified input parameters.					specified in								
		Parame-	Writing MC set- tings	Some of the axis parameters or axes group parameters are overwritten													
		ters	Changing axis parameters (*)	Some of the	axis paramete	ers can be access	sed or chang	ed from the us	er program.								
		Count mo				r Mode (finite ler t for each axis ac			e length).								
		Acceler- ation/de	Automatic accelera- tion/decelera- tion control			tion/deceleration			axes group								
		tion con- trol	Changing the acceleration and deceleration rates	You can char deceleration.	-	eration or deceler	ation rate eve	en during acce	leration or								
	Auxiliary functions	In-positio	n check	You can set a tioning is con		range and in-pos	ition check ti	me to confirm	when posi-								
		Stop meth				od to the immedia											
			tion of motion structions		-	rariables for a mo again to change			-								
			cution of motion structions (Buf-	You can spec	cify when to st	art execution and	I how to conr	nect the velocit	ies between								
		Continuo motions (Transitio	us axes group n Mode)	You can spec group operat		tion Mode for mu	ti-execution	of instructions	for axes								

		Item		NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
			Software limits	The movement range of an axis is monitored.					
			Following error		tween the con	nmand current va		ctual current	value is mon-
Motion control *2	acceleration rate,					rarning values fo			
			encoder support	Encoder to e	eliminate the n	S-seies or G5-s eed to perform h	oming at start	tup.	
		Input sign	al logic inversion	negative limi	t input signal,	of immediate stop or home proximi	ty input signal	l	input signal,
External interface signals			Home signal	, home proxim	nals listed on the nity signal, position of interrupt input s	ve limit signal,		signal,	
Unit (I/O)	EtherCAT slaves	Maximum slaves	number of	512	64	16	192		64
manage- ment	CJ-series Units	Maximum Units	number of				40		
	Peripheral (U	ISB) port		communi- cations with various kinds of Support Software running on a personal computer.			kinds of Sup personal cor	port Software nputer.	running on a
		Commun	ications protocol	TCP/IP and	UDP/IP				
		CIP commu-	Tag data links	Programless cyclic data exchange is performed with the devices on the EtherNet/IP network. CIP commands are sent to or received from the devices on the EtherNet/IP net-					e EtherNet/IP
		nica- tions services	Message com- munications	CIP commar work.	nds are sent to	or received fror	n the devices	on the EtherN	let/IP net-
Commu- nica-			Socket services	col. Socket c	ommunication	d from any node s instructions are	used.		,
tions			FTP client (*)	Files are transferred via FTP from the CPU Unit to computers or Controllers at other Ethernet nodes. FTP client communications instructions are used.					
	EtherNet/IP	TCP/IP applica-	FTP server		read from or v er Ethernet no	vritten to the SD odes.	Memory Card	in the CPU U	nit from com-
	port tions Automatic clock adjustment SNMP agent		interval after	the power sup	rom the NTP ser oply to the CPU t I with the read tir	Jnit is turned (•	
				•	ternal status info n SNMP manage	•	vided to netw	ork manage-	
		OPC UA*3	Server Func- tion		Functions to respond to requests from cli- ents on the OPC UA network		Functions to respond to requests from cli- ents on the OPC UA network		

				NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
		Item							
		Sup-	Process data communications	A communications between	A communications method to exchange control information in cyclic communications between the EtherCAT master and slaves. This communications method is defined by CoE.				
	ported services SDO communications		A communications	ations method between Ethe	to exchange co erCAT master and thod is defined by	ntrol informat d slaves.	ion in noncyclio	event com-	
		Network s	canning		s read from co	onnected slave d		e slave configu	uration is
	EtherCAT	DC (distri	buted clock)	Time is sync	-	haring the Ether(CAT system ti	me among all	EtherCAT
	port	Packet m	onitoring	The frames t	hat are sent be saved. The	by the master and data that is save			
		Enable/di for slaves	sable settings	The slaves c	an be enable	d or disabled as	communication	ons targets.	
		Disconne ing slaves	cting/reconnect-			slave from the E slave, and then c			nance, such
Communica- tions	applica-		SDO messa	ges of the CA	N application car	n be sent to s	laves via Ether	CAT	
	Serial com- munications	Protocol				Host link (FINS), no- protocol, and Modbus-RTU master (when connected to the Serial Communica- tions Option Board)			
	Communications instructions		tions instruct tions instruct instructions, instructions,	ions, socket c ions, SDO me no-protocol co Modbus RTU '), and Modbu	essage ommunications	nications instructions, tions instruct	nstructions (*), structions, sock ructions, SDO i no-protocol co tions, protocol and Modbus F (*)	tet communi- message ommunica- macro	
Operation man- age- ment	- RUN output contacts		The output on the Power Sup- ply Unit turns ON in RUN mode.				on the Power S RUN mode.	Supply Unit	
	Function			ecorded in the			_		
Sys- tem		Maxi- mum	System event log	2,048	768 ^{*5}	576 ^{*6}	1,024	512	
man- age-	Event logs	number	Access event log	1,024	576 ^{*7}	528 ^{*8}	1,024	512	
ment		events	User-defined event log	1,024	512	512	1,024	512	

		Item		NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
	1			Drograma fu	unation blocks	functions and			god opline
	Online editing	9		Programs, function blocks, functions, and global variables can be changed online. More than one operators can change POUs individually via network.					
	Forced refres	hing		The user car	n force specifi	c variables to TR	RUE or FALSE		
		Maxi- mum	Device vari- ables for Ether- CAT slaves	64					
		number of forced vari- ables	Device variables for CJ-series Units and variables with AT specifications				64		
	MC Test Run*	2		Motor opera	tion and wiring	g can be checked	d from the Sys	smac Studio.	
	Synchronizin	g		The project f		nac Studio and th	ne data in the	CPU Unit can l	be made the
	Differential m	onitoring (*)	You can mor	nitor when a v	ariable changes	to TRUE or cl	hanges to FAL	SE.
			number of d variables	8					
Debug- ging	_		Single trig- gered trace		When the trigger condition is met, the specified number of samples are taken and then tracing stops automatically. Data tracing is executed continuously and the trace data is collected by the Sysmac				
			Continuous trace	Studio.					
		Maximum number of simultaneous data traces		4	2	2	4	2	
	Data tracing	Maximum records	number of	10,000					
			number of sam-	192 vari- ables	48 vari- ables	48 variables	192 vari- ables	48 variables	
		Timing of	sampling	Sampling is performed for the specified task period, at the specified time, or when a sampling instruction is executed.					
		Triggered	traces	Trigger conditions are set to record data before and after an event.					
	Data tracing		Trigger conditions	Compariso Compariso	on of non-BOC on Method: Ec	anges to TRUE DL variable with a juals (=), Greate n or equals (≤), N	a constant r than (>), Gre	eater than or ed	quals (≥),
			Delay		ion setting: A trigger condi	slider is used to tion is met.	set the percer	ntage of sampli	ing before
	Simulation			The operation	n of the CPU	Unit is emulated	in the Sysma	c Studio.	
		Control-	Levels Maximum	Major faults, partial faults, minor faults, observation, and information 9 (Sysmac Studio)					
Reli-		ler errors	number of message lan- guages	2 (NS-series PT)					
ability func-	Self-diagno- sis		Function	User-defined cuting instru-		gistered in advar	nce and then	records are cre	eated by exe-
tions		User-	Levels	8			<u> </u>		
		defined errors	Maximum number of message lan- guages	9					

		Item		NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
		CPU Unit	names and	When going	online to a CP	PU Unit from the the name of the	Sysmac Studio	o, the CPU Ur	nit name in
			User program transfer with no restoration information	You can prev	ent reading d	ata in the CPU L	Init from the S	ysmac Studio	
	Protecting software	Protec- tion	CPU Unit write- protection	You can prevent writing data to the CPU Unit from the Sysmac Studio or SD Memory Card.					
Secu- rity	assets and preventing		Overall Project file protection	mac Studio.		protect .smc file			g on the Sys-
	operating mistakes		Data protection (*)			protect POUs or			
		Verification authority	on of operation	ment or injur		estricted by ope e caused by ope			age to equip-
			Number of groups (*)	5					
		Verification gram exe	on of user pro- cution ID	ID from the S	Sysmac Studio	pe executed with for the specific	•		execution
	Storage type			SD card or S					
SD		SD Memo	c transfer from ory Card (*)	autoload dire	ectory of the S	the Controller is D Memory Card	is transferred	to the Control	ler.
Mem- ory		tion instructions		With the specification of the system-defined variable, you can transfer a program that is stored in the SD Memory Card to the Controller.					
Card func-	Application					ry Cards from in			
tions		File operations from the Sysmac Studio		You can perform file operations for Controller files in the SD Memory Card and read/write general-purpose document files on the computer.					
		SD Memo	ory Card life expi- tection	Notification of the expiration of the life of the SD Memory Card is provided in a system-defined variable and event log.				led in a sys-	
			CPU Unit front- panel DIP switch	front-panel D	IP switch on t		•	-	
		Operat-	Specification with system- defined vari- ables	Backup and variables.	verification op	erations are per	formed by man	ipulating syst	em-defined
	SD Memory Card back- ups	methods	SD Memory Card Window in Sysmac Stu- dio		verification op ysmac Studio.	erations are perf	formed from th	e SD Memory	Card Win-
			Special instruction (*)	The special i	nstruction is u	sed to backup d	ata.		
Back- ing up		Protec- tion	Disabling backups to SD Memory Cards	Backing up o	lata to a SD M	lemory Card is p	rohibited.		
data (*)	Safety unit restore (*)				You can perform to restore data in a Safety CPU Unit with an SD Memory Card and the front-panel DIP switch on the Safety CPU Unit.				
	Sysmac Stud	lio Controll	er backups	The Sysmac		d to backup, rest	ore, or verify C	Controller data	l.
*4 1 1	-		T is ST that is writt			• • • • • • • • • • • • • • • • • • • •	. ,		

^{*1} Inline ST is supported. (Inline ST is ST that is written as an element in a ladder diagram.)

^{*2} This function is not available for NJ101-90□□ CPU Units.

^{*3} The CPU Unit that supports OPC UA in NJ-series is an NJ501-1□00 CPU Unit with unit version 1.17 or later.

^{*4} Available only with NX102- $\square\square\square\square$ CPU Units.

- *5 This is the total of 512 events for the CPU Unit and 256 events for the NX Unit.
- *6 This is the total of 512 events for the CPU Unit and 64 events for the NX Unit.
- *7 This is the total of 512 events for the CPU Unit and 64 events for the NX Unit.
- *8 This is the total of 512 events for the CPU Unit and 16 events for the NX Unit.

Note Items that are marked with asterisks in the table were added for version upgrades. Refer to *A-15 Version Information for NX-series Controllers* and *A-16 Version Information for NJ-series Controllers* for information on version upgrades.

A-2 Calculating Guidelines for the Real Processing Times of Tasks for the NX701 System

This section describes how to calculate guidelines for the average real processing times of tasks on paper for the NX701 System.

You must use the physical Controller to check the real processing times of tasks and task execution times. For details, refer to 5-11 Task Design Methods and I/O Response Times.



Precautions for Safe Use

The task execution times in the physical Controller depends on the logic operations that are performed in the user program, the presence of communications commands and data links, on whether data tracing is performed, and on other factors.

Before starting actual operation, you must test performance under all foreseeable conditions on the actual system and make sure that the task periods are not exceeded and that suitable communications performance is achieved.



Precautions for Correct Use

Calculation of the average real processing times of tasks for the priority-5 periodic task will require the value of PDO Communications Cycle 2: Transmission Delay Time, which is displayed in the EtherCAT Tab Page after the EtherCAT configuration is created with the Sysmac Studio.



Additional Information

Periodic tasks may be interrupted for the execution of tasks with higher execution priorities. The real processing time of a task does not include the time for which the task is interrupted. It is the task execution time that gives the actual time from when the task is started until it is finished, including the interrupted time. For a detailed description of the differences between the real processing times of tasks and the task execution times, refer to *Meaning of the Task Execution Time* and the *Real Processing Time of the Task* on page 5-113.

A-2-1 Calculating the Average Real Processing Times of Tasks

The average real processing time of a task is the total of the I/O refresh processing time, user program execution time, motion control processing time and common processing time.

Average real processing time of task = I/O refresh processing time + User program execution time

+ Motion control processing time + Common processing time

The following processing is performed.

Proc	cessing	Processing contents	Primary periodic task	Priority-5 periodic task	Priority-16 periodic task	Priority-17 and priority-18 periodic tasks
I/O refresh	n processing	I/O is refreshed for EtherCAT slaves.	Performed.	Performed.	Not per- formed.	Not per- formed.
User progration	ram execu-	Programs assigned to tasks are executed in the order that they are assigned.	Performed.	Performed.	Performed.	Performed.
Motion control processing		Motion control commands from the user program are executed. Motion output processing	Performed.	Performed.	Not per- formed.	Not per- formed.
Com- mon pro- cessing time	System common processing 1	Variable refresh processing (if there are accessing tasks) is performed. Motion input processing Data trace processing	Performed.	Performed.	Performed.	Performed.
	System common processing 2	 Variable refresh processing (if there are refreshing tasks) is performed. Variable access processing external to the Controller to ensure concurrency with task execution 	Performed.	Performed.	Performed.	Performed.
	System overhead time	Other system common processing	Performed.	Performed.	Performed.	Performed.

Guidelines are provided below for calculating the various processing times.

I/O Refresh Processing Time

Use the following formula for the I/O refresh processing time.

I/O refresh processing time = EtherCAT slave processing time

The formula for calculating the EtherCAT slave processing time is different between the primary periodic task and the priority-5 periodic task.

The following describes how to determine the EtherCAT slave processing time for each type of tasks.



Precautions for Correct Use

When calculating for the priority-5 periodic task, you need to determine the task period of the primary periodic task in advance.



Additional Information

The EtherCAT slave processing time is 0 in tasks to which EtherCAT slaves are not assigned.

• EtherCAT Slave Processing Time in Primary Periodic Task

Use the following formula to calculate the EtherCAT slave processing time in the primary periodic task.

EtherCAT slave processing time [μ s] = 0.0006 × pDout + 0.0001 × pDin + 0.082 × pDinout + (1.24 × Snum + 0.01 × Clen) + 25.58

pDout : Total output processing data size [byte] of EtherCAT slaves assigned to the primary

periodic task or the priority-16 periodic task

pDin : Total input processing data size [byte] of EtherCAT slaves assigned to the primary

periodic task or the priority-16 periodic task

pDinout : Total of the larger of the input and output processing data size of each EtherCAT

slave assigned to the primary periodic task or the priority-16 periodic task [byte]

Snum : Total number of EtherCAT slaves connected to the built-in EtherCAT port

Clen : Total length of cables connected to the built-in EtherCAT port [m]

• EtherCAT Slave Processing Time in Priority-5 Periodic Task

Use the following formula to calculate the EtherCAT slave processing time in the priority-5 periodic task.

EtherCAT slave processing time [μ s] = 0.0006 × pDout + (Larger of the following A and B) + sTsend + 0.0001 × sDin + 16

```
A [\mus] = ((0.0623 × sDout + 37) × pTcycle) ÷ (pTcycle – (0.0243 × pDout + 35))
B [\mus] = 0.082 × pDinout
```

pDout : Total output processing data size [byte] of EtherCAT slaves assigned to the primary

periodic task

 $sTsend^{\star 1}$: Transmission delay time of PDO communications cycle 2 [μs] displayed on the Sys-

mac Studio

sDin : Total input processing data size [byte] of EtherCAT slaves assigned to the priority-5

periodic task

sDout : Total output processing data size [byte] of EtherCAT slaves assigned to the priority-

5 periodic task

pTcycle : Task period of the primary periodic task [μs]

pDinout : Total of the larger of the input and output processing data size of each EtherCAT

slave assigned to the primary periodic task [byte]

*1 The value of sTsend (transmission delay time) cannot be calculated on paper. Assign the value of PDO Communications Cycle 2: Transmission Delay Time, which is displayed in the EtherCAT Tab Page after the EtherCAT configuration is created with the Sysmac Studio, to sTsend (transmission delay time). Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No W504-E1-14 or later) for how to display the PDO Communications Cycle 2: Transmission Delay Time on the Sysmac Studio.

User Program Execution Time

The user program execution time depends on the specific instructions multiplied by the numbers of instructions used.

As a guideline, instructions are divided into three groups and the number of instructions in each group is used for measurements and estimates.

- · Standard instructions
- Arithmetic instructions for LREAL data
- · Trigonometric instructions for LREAL data

Different instructions are used in a ladder diagram and in ST. Refer to *Instruction Configuration for Standard Ladder Diagram Instructions* on page A-25 and *Instruction Configuration for Standard ST Instructions* on page A-27 for information on the instruction configuration.


Simple Estimate

For the number of instructions in each group, read the execution time for each instruction group from the following graphs and calculate the total.

- · Execution time for standard instructions
- · Execution time for arithmetic instructions for LREAL data
- Execution time for trigonometric instructions for LREAL data

This will allow you to estimate the execution time of the user program.

Execution Time for Standard Ladder Diagram Instructions




Instruction Configuration for Standard Ladder Diagram Instructions

The instruction execution ratio for this configuration is 20%.

Types of instructions	Instructions	Percent of instructions [%]	Percent of execution time in instruction group [%]
Ladder diagram instructions	LD, AND, OUT, SET, and RESET	81.0%	40.2%
Comparison instructions	EQ and LT	4.1%	8.3%
Timer and counter instructions	Timer, TON/TOF, and CTU/CTD	1.6%	7.3%
Math instructions	+, -, *, /, ADD, SUB, MUL, and DIV	2.4%	6.5%
BCD conversion instructions and data conversion instructions	INT_TO_DINT and WORD_BC- D_TO_UINT	0.2%	1.2%

Types of instructions	Instructions	Percent of instructions [%]	Percent of execution time in instruction group [%]
Bit string processing instructions	AND and OR	6.2%	13.0%
Data movement instructions	MOVE	4.6%	23.5%
Total		100.0%	100.0%

Execution Times for Ladder Diagram Arithmetic and Trigonometric Instructions for LREAL Data



- Arithmetic instructions for LREAL data ---- Trigonometric instructions for LREAL data


· Configuration of Arithmetic Instructions for LREAL Data

Instructions	Percent of instructions [%]
Addition instructions for LREAL data	20.0%
Subtraction instructions for LREAL data	20.0%
Multiplication instructions for LREAL data	30.0%
Division instructions for LREAL data	30.0%
Total	100.0%

• Configuration of Trigonometric Instructions for LREAL Data

Instructions	Percent of instructions [%]
Sin of LREAL data	16.7%
Cos of LREAL data	16.7%
Tan of LREAL data	16.7%
Sin ⁻¹ of LREAL data	16.7%
Cos ⁻¹ of LREAL data	16.7%
Tan ^{−1} of LREAL data	16.7%
Total	100.0%


Execution Time for Standard ST Instructions



• Instruction Configuration for Standard ST Instructions

Types of instructions	Instructions	Percent of instructions [%]	Percent of execution time in instruction group [%]
ST constructs	IF ELSIF END_IF	75.4%	41.6%
Comparison instructions	EQ and LT	5.2%	8.7%
Timer and counter instructions	Timer, TON/TOF, and CTU/CTD	2.1%	18.8%
Math instructions	+, -, *, and /	3.1%	10.2%
BCD conversion instructions and data conversion instructions	INT_TO_DINT and WORD_BC- D_TO_UINT	0.2%	1.6%
Bit string processing instructions	AND and OR	8.0%	11.7%
Data movement instructions	:=	5.9%	7.3%
Total		100.0%	100.0%

Execution Times for ST Arithmetic and Trigonometric Instructions for LREAL Data



• Configuration of Arithmetic Instructions for LREAL Data

Instructions	Percent of instructions [%]
Addition instructions for LREAL data	20.0%
Subtraction instructions for LREAL data	20.0%
Multiplication instructions for LREAL data	30.0%
Division instructions for LREAL data	30.0%
Total	100.0%


• Configuration of Trigonometric Instructions for LREAL Data

Instructions	Percent of instructions [%]
Sin of LREAL data	16.7%
Cos of LREAL data	16.7%
Tan of LREAL data	16.7%
Sin ⁻¹ of LREAL data	16.7%
Cos ⁻¹ of LREAL data	16.7%
Tan ⁻¹ of LREAL data	16.7%
Total	100.0%

Motion Control Processing Time

The motion control processing time depends on the number of servo axes and virtual servo axes that are used.

For the number of servo and virtual servo axes, read the motion control processing time from the following graph.



Common Processing Time

The common processing time is the following values by the total time for system overhead, system common processing 1, and system common processing 2. The common processing time depends on the type of task.

Type of task	Common processing times [µs] (reference values)
Type of task	NX701-□□□□
Primary periodic task	15
Priority-5 periodic task	55
Priority-16, 17, or 18 periodic task	10

A-2-2 Example of Calculating the Average Real Processing Time of a Task and Setting the Task Period

Example of Calculating the Average Real Processing Times of Tasks

If you are using an NX701- $\square\square\square$ CPU Unit with a unit version of 1.10, first find the average real processing time of the task for the following conditions.

The task is the primary periodic task.

Item		Conditions	
		GX-ID1611 (Ver. 1.1) Input Slave: 1	
		GX-OD1611 (Ver. 1.1) Output Slave: 1	
		R88D-1SN□□□-ECT Servo Drives: 4	
		EtherCAT Slave Terminal: 1	
		NX-ECC203 EtherCAT Coupler Unit: 1	
Slaves/Units that are used	EtherCAT slaves	NX-ID5342 DC Input Unit: 1	
		NX-OD5121 Transistor Output Unit: 1	
		NX-AD3608 Analog Input Unit: 1	
		NX-DA2605 Analog Output Unit: 1	
		NX-CIF101 and NX-CIF105 Communications Interface Units: 1 per Unit	
	Language	Ladder diagrams	
	Standard instruction configuration	Number of instructions: 5,000	
User program Arithmetic instructions for LREAL data Trigonometric instructions for LREAL data		Number of instructions: 200	
		Number of instructions: 100	
Motion control processing	Number of axes	4	

Note Total length of cables connected to the built-in EtherCAT port is 10 [m].

I/O Refresh Time

EtherCAT slave processing time:

The following table gives the pDout (output processing data size), pDin (input processing data size), and pDinout (larger of the input and output data size) values of the GX-ID1611 (Ver. 1.1) Input Slave, GX-OD1611 (Ver. 1.1) Output Slave, R88D-1SN $\square\square$ -ECT Servo Drives, and EtherCAT Slave Terminal configured with Units shown above.

EtherCAT slave	pDout: Output processing data size in bytes	pDin: Input process- ing data size in bytes	pDinout: Larger of the input and output data size
GX-ID1611 (Ver. 1.1)	0	3	3
GX-OD1611 (Ver. 1.1)	2	1	2
R88D-1SN□□□-ECT	23	26	26
EtherCAT Slave Terminal (Total)	62	88	88
NX-ECC203	0	18	
NX-ID5342	0	2	
NX-OD5121	2	0	
NX-AD3608	0	8	
NX-DA2605	4	0	
NX-CIF101	28	30	
NX-CIF105	28	30	

Total number of bytes are given below for pDout, pDin and pDinout.

pDout =
$$2 + 23 \times 4 + 62 = 156$$
 [byte]
pDin = $3 + 1 + 26 \times 4 + 88 = 196$ [byte]
pDinout = $3 + 2 + 26 \times 4 + 88 = 197$ [byte]

From these values, the I/O refresh time is calculated by the following formula.

I/O refresh processing time

- = EtherCAT slave processing time
- $= 0.0006 \times pDout + 0.0001 \times pDin + 0.082 \times pDinout + (1.24 \times Snum + 0.01 \times Clen) + 25.58$
- $= 0.0006 \times 156 + 0.0001 \times 196 + 0.082 \times 197 + (1.24 \times 7 + 0.01 \times 10) + 25.58$
- = 0.0936 + 0.0196 + 16.154 + (8.68 + 0.1) + 25.58
- $\approx 51 \, [\mu s]$

User Program Execution Time

The graphs show the following values.

- Standard instruction configuration
 From the graph of the execution time for standard ladder diagram instructions, the user program execution time of 5,000 instructions for the NX701-□□□□ is 12 µs.
- Arithmetic instructions for LREAL data
 From the graph of the execution time for ladder diagram arithmetic and trigonometric instructions for LREAL data, the user program execution time of 200 instructions for the NX701-□□□□ is 4 μs.

Trigonometric instructions for LREAL data
 From the graph of the execution time for ladder diagram arithmetic and trigonometric instructions for LREAL data, the user program execution time of 100 instructions for the NX701-□□□□ is 9 μs.

Therefore, the user program execution time is the total of the above values, which is given by the following formula.

User program execution time =
$$12 + 4 + 9$$

= $25 [\mu s]$

Motion Control Processing Time

From the graph of the execution time for motion control processing, the execution time of the motion control processing for four axes for the NX701- $\square\square\square\square$ with a unit version 1.10 is read as 10 μ s.

Common Processing Time

Because the task is the primary periodic task, the common processing time for the NX701- $\square\square\square$ is 15 μ s.

Therefore, the average real processing time of the task is given by the following formula.

Average real processing time of task = I/O refresh processing time + User program execution time

+ Motion control processing time + Common processing time

$$= 51 + 25 + 10 + 15$$

= 101 [µs]

Setting the Task Period

The task period is set based on the average real processing time of the task that is calculated as above. The task is the primary periodic task.

The value of the task period must be larger than the average real processing time of the task that you calculated. More specifically, you should allow sufficient margin and set the task period value to at least 1.1 times as large as the average real processing time of the task.

Task period ≥ Average real processing time of task × 1.1

Because the average real processing time of the task that is calculated above is 101 μ s, as the value larger than 1.1 times the average time, the task period is set to 125 μ s.

The task execution times in the physical Controller depends on the logic operations that are performed in the user program, the presence of communications commands and data links, on whether data tracing is performed, and on other factors. The task execution time for a periodic task depends on whether it is interrupted for the execution of tasks with higher execution priorities.

Use the physical Controller and verify the task execution time with the Task Execution Time Monitor.

A-3 Calculating Guidelines for the Real Processing Times of Tasks for the NX102 System

This section describes how to calculate guidelines for the average real processing times of tasks on paper for the NX102 System.

You must use the physical Controller to check the real processing times of tasks and task execution times. For details, refer to 5-11 Task Design Methods and I/O Response Times.



Precautions for Safe Use

The task execution times in the physical Controller depends on the logic operations that are performed in the user program, the presence of communications commands and data links, on whether data tracing is performed, and on other factors.

Before starting actual operation, you must test performance under all foreseeable conditions on the actual system and make sure that the task periods are not exceeded and that suitable communications performance is achieved.



Additional Information

Periodic tasks may be interrupted for the execution of tasks with higher execution priorities. The real processing time of a task does not include the time for which the task is interrupted. It is the task execution time that gives the actual time from when the task is started until it is finished, including the interrupted time. For a detailed description of the differences between the real processing times of tasks and the task execution times, refer to *Meaning of the Task Execution Time* and the *Real Processing Time of the Task* on page 5-113.

A-3-1 Calculating the Average Real Processing Times of Tasks

The average real processing time of a task is the total of the I/O refresh processing time, user program execution time, motion control processing time and common processing time.

Average real processing time of task = I/O refresh processing time + User program execution time

+ Motion control processing time + Common processing time

The following processing is performed.

Processing	Processing contents	Primary periodic task	Priority-17 and priority-18 periodic tasks
I/O refresh processing	I/O is refreshed for NX Units on the CPU Unit and EtherCAT slaves.	Performed.	Not per- formed.
User program execution	Programs assigned to tasks are executed in the order that they are assigned.	Performed.	Performed.
Motion control processing	Motion control commands from the user program are executed. Motion output processing	Performed.	Not per- formed.

Proc	cessing	Processing contents	Primary periodic task	Priority-17 and priority-18 periodic tasks
Common processing time	System common processing 1	 Variable refresh processing (if there are accessing tasks) is performed. Motion input processing Data trace processing 	Performed.	Performed.
	System common processing 2	 Variable refresh processing (if there are refreshing tasks) is performed. Variable access processing external to the Controller to ensure concurrency with task execution 	Performed.	Performed.
	System overhead time	Other system common processing	Performed.	Performed.

Guidelines are provided below for calculating the various processing times.

I/O Refresh Processing Time

Use the following formula for the I/O refresh processing time.

I/O refresh processing time = EtherCAT slave processing time + NX Unit processing time

The following describes how to determine EtherCAT slave processing time, NX Unit processing time used in the above formula.

EtherCAT Slave Processing Time

Use the following formula to calculate the EtherCAT slave processing time.

EtherCAT slave processing time [μ s] = 0.017 × pDout + 0.010 × pDin + 0.082 × pDinout + (1.24 × Snum + 0.01 × Clen) + 151.11

pDout : Total output processing data size [byte] of EtherCAT slaves assigned to the primary

periodic task

pDin : Total input processing data size [byte] of EtherCAT slaves assigned to the primary

periodic task

pDinout : Total of the larger of the input and output processing data size of each EtherCAT

slave assigned to the primary periodic task [byte]

Snum : Total number of EtherCAT slaves connected to the built-in EtherCAT port

Clen : Total length of cables connected to the built-in EtherCAT port [m]



Additional Information

The EtherCAT slave processing time is 0 if EtherCAT slaves are not connected.

NX Unit Processing Time

Use the following formula for the NX Unit processing time.

The calculation must include all NX Units on the CPU Unit.

NX Unit processing time [μ s] = 0.149 × Dnxout + 0.064 × Dnxin + 0.549 × Dnxnum + 97.48

Dnxout : Total output data size [byte]^{*1}
Dnxin : Total input data size [byte]^{*1}
Dnxnum : Number of connected NX Units

^{*1} If the data size of an NX Unit is less than 2 bytes, calculate as 2 bytes.



Additional Information

The NX Unit processing time is 0 if NX Units are not connected to the CPU Unit.

User Program Execution Time

The user program execution time depends on the specific instructions multiplied by the numbers of instructions used.

As a guideline, instructions are divided into three groups and the number of instructions in each group is used for measurements and estimates.

- · Standard instructions
- · Arithmetic instructions for LREAL data
- · Trigonometric instructions for LREAL data

Different instructions are used in a ladder diagram and in ST. Refer to *Instruction Configuration for Standard Ladder Diagram Instructions* on page A-25 and *Instruction Configuration for Standard ST Instructions* on page A-27 for information on the instruction configuration.


Simple Estimate

For the number of instructions in each group, read the execution time for each instruction group from the following graphs and calculate the total.

- · Execution time for standard instructions
- · Execution time for arithmetic instructions for LREAL data
- Execution time for trigonometric instructions for LREAL data

This will allow you to estimate the execution time of the user program.


Execution Time for Standard Ladder Diagram Instructions



• Instruction Configuration for Standard Ladder Diagram Instructions
The instruction execution ratio for this configuration is 20%.

Types of instructions	Instructions	Percent of instructions [%]	Percent of execution time in instruction group [%]
Ladder diagram instructions	LD, AND, OUT, SET, and RESET	81.0%	40.2%
Comparison instructions	EQ and LT	4.1%	8.3%
Timer and counter instructions	Timer, TON/TOF, and CTU/CTD	1.6%	7.3%
Math instructions	+, -, *, /, ADD, SUB, MUL, and DIV	2.4%	6.5%
BCD conversion instructions and data conversion instructions	INT_TO_DINT and WORD_BC-D_TO_UINT	0.2%	1.2%
Bit string processing instructions	AND and OR	6.2%	13.0%
Data movement instructions	MOVE	4.6%	23.5%
Total		100.0%	100.0%

Execution Times for Ladder Diagram Arithmetic and Trigonometric Instructions for LREAL Data



---- Trigonometric instructions for LREAL data ----- Arithmetic instructions for LREAL data


• Configuration of Arithmetic Instructions for LREAL Data

Instructions	Percent of instructions [%]
Addition instructions for LREAL data	20.0%
Subtraction instructions for LREAL data	20.0%
Multiplication instructions for LREAL data	30.0%
Division instructions for LREAL data	30.0%
Total	100.0%

• Configuration of Trigonometric Instructions for LREAL Data

Instructions	Percent of instructions [%]
Sin of LREAL data	16.7%
Cos of LREAL data	16.7%
Tan of LREAL data	16.7%
Sin ⁻¹ of LREAL data	16.7%
Cos ⁻¹ of LREAL data	16.7%
Tan ⁻¹ of LREAL data	16.7%
Total	100.0%


Execution Time for Standard ST Instructions



• Instruction Configuration for Standard ST Instructions

Types of instructions	Instructions	Percent of instructions [%]	Percent of execution time in instruction group [%]
ST constructs	IF ELSIF END_IF	75.4%	41.6%
Comparison instructions	EQ and LT	5.2%	8.7%
Timer and counter instructions	Timer, TON/TOF, and CTU/CTD	2.1%	18.8%
Math instructions	+, -, *, and /	3.1%	10.2%
BCD conversion instructions and data conversion instructions	INT_TO_DINT and WORD_BC- D_TO_UINT	0.2%	1.6%
Bit string processing instructions	AND and OR	8.0%	11.7%
Data movement instructions	:=	5.9%	7.3%
Total		100.0%	100.0%

Execution Times for ST Arithmetic and Trigonometric Instructions for LREAL Data



· Configuration of Arithmetic Instructions for LREAL Data

Instructions	Percent of instructions [%]
Addition instructions for LREAL data	20.0%
Subtraction instructions for LREAL data	20.0%
Multiplication instructions for LREAL data	30.0%
Division instructions for LREAL data	30.0%
Total	100.0%


• Configuration of Trigonometric Instructions for LREAL Data

Instructions	Percent of instructions [%]
Sin of LREAL data	16.7%
Cos of LREAL data	16.7%
Tan of LREAL data	16.7%
Sin ⁻¹ of LREAL data	16.7%
Cos ⁻¹ of LREAL data	16.7%
Tan ^{−1} of LREAL data	16.7%
Total	100.0%

Motion Control Processing Time

The motion control processing time depends on the number of servo axes and virtual servo axes that are used.

For the number of servo and virtual servo axes, read the motion control processing time from the following graph.



Common Processing Time

The common processing time is the following values by the total time for system overhead, system common processing 1, and system common processing 2. The common processing time depends on the type of task.

Type of task	Common processing times [µs] (reference values)	
Type of task	NX102-□□□	
Primary periodic task	133	
Periodic task	175	

A-3-2 Example of Calculating the Average Real Processing Time of a Task and Setting the Task Period

Example of Calculating the Average Real Processing Times of Tasks

If you are using an NX102- $\square\square\square$ CPU Unit with a unit version of 1.30, first find the average real processing time of the task for the following conditions.

The task is the primary periodic task.

Item		Conditions	
Slaves/Units that are used	EtherCAT slaves	GX-ID1611 (Ver. 1.1) Input Slave: 1	
		GX-OD1611 (Ver. 1.1) Output Slave: 1	
		R88D-1SN□□□-ECT Servo Drives: 4	
	NX Units (on CPU Rack)	NX-PF0630 Additional I/O Power Supply Unit: 1	
		NX-ID5342 Digital Input Units: 3	
		NX-OD3153 Digital Output Units: 2	
		NX-AD4608 Analog Input Unit: 1	
		NX-DA3605 Analog Output Unit: 1	

Item		Conditions	
User program	Language	Ladder diagrams	
	Standard instruction configuration	Number of instructions: 5,000	
	Arithmetic instructions for LREAL data	Number of instructions: 200	
	Trigonometric instructions for LREAL data	Number of instructions: 100	
Motion control processing	Number of axes	4	

Note Total length of cables connected to the built-in EtherCAT port is 10 [m].

I/O Refresh Time

EtherCAT slave processing time:

The following table gives the pDout (output processing data size), pDin (input processing data size), and pDinout (larger of the input and output data size) values of the GX-ID1611 (Ver. 1.1) Input Slave, GX-OD1611 (Ver. 1.1) Output Slave, and R88D-1SN ——-ECT Servo Drives.

EtherCAT slave	pDout: Output processing data size in bytes	pDin: Input process- ing data size in bytes	pDinout: Larger of the input and output data size
GX-ID1611 (Ver. 1.1)	0	3	3
GX-OD1611 (Ver. 1.1)	2	1	2
R88D-1SN□□□-ECT	23	26	26

Total number of bytes are given below for pDout, pDin and pDinout.

pDout =
$$2 + 23 \times 4 = 94$$
 [byte]
pDin = $3 + 1 + 26 \times 4 = 108$ [byte]
pDinout = $3 + 2 + 26 \times 4 = 109$ [byte]

NX Unit processing time:

The following table gives the Dnxout (output data size), Dnxin (input data size) values of the NX-PF0630 Additional I/O Power Supply Unit, NX-ID5342 Digital Input Unit, NX-OD3153 Digital Output Unit, NX-AD4608 Analog Input Unit, and NX-DA3605 Analog Output Unit.

NX Units	Dnxout: Output data size in bytes	Dnxin: Input data size in bytes
NX-PF0630	0	0
NX-ID5342	0	2
NX-OD3153	2	0
NX-AD4608	0	16
NX-DA3605	8	0

Total number of bytes are given below for Dnxout and Dnxin.

Dnxout =
$$2 \times 2 + 8 = 12$$
 [byte]
Dnxin = $2 \times 3 + 16 = 22$ [byte]

From these values, the I/O refresh time is calculated by the following formula.

I/O refresh processing time

```
= EtherCAT slave processing time + NX Unit processing time
```

```
= 0.017 × pDout + 0.010 × pDin + 0.082 × pDinout + (1.24 × Snum + 0.01 × Clen) + 151.11
+ 0.149 × Dnxout + 0.064 × Dnxin + 0.549 × Dnxnum + 97.48
= 0.017 × 94 + 0.010 × 108 + 0.082 × 109 + (1.24 × 6 + 0.01 × 10) + 151.11
```

=
$$0.017 \times 94 + 0.010 \times 108 + 0.082 \times 109 + (1.24 \times 6 + 0.01 \times 10) + 151.11 + 0.149 \times 12 + 0.064 \times 22 + 0.549 \times 8 + 97.48$$

 $\approx 275 [\mu s]$

User Program Execution Time

The graphs show the following values.

- Standard instruction configuration
 From the graph of the execution time for standard ladder diagram instructions, the user program execution time of 5,000 instructions for the NX102-□□□□ is 189 μs.
- Arithmetic instructions for LREAL data
 From the graph of the execution time for ladder diagram arithmetic and trigonometric instructions
 for LREAL data, the user program execution time of 200 instructions for the NX102-□□□□ is 41
 µs.
- Trigonometric instructions for LREAL data
 From the graph of the execution time for ladder diagram arithmetic and trigonometric instructions for LREAL data, the user program execution time of 100 instructions for the NX102-□□□□ is 51 μs.

Therefore, the user program execution time is the total of the above values, which is given by the following formula.

User program execution time =
$$189 + 41 + 51$$

= $281 [\mu s]$

Motion Control Processing Time

From the graph of the execution time for motion control processing, the execution time of the motion control processing for four axes for the NX102- $\square\square\square\square$ with a unit version 1.30 is read as 148 μ s.

Common Processing Time

Because the task is the primary periodic task, the common processing time for the NX102- $\square\square\square$ is 133 μ s.

Therefore, the average real processing time of the task is given by the following formula.

Average real processing time of task = I/O refresh processing time + User program execution time

+ Motion control processing time + Common processing time

= 275 + 281 + 148 + 133

 $= 837 [\mu s]$

Setting the Task Period

The task period is set based on the average real processing time of the task that is calculated as above. The task is the primary periodic task.

The value of the task period must be larger than the average real processing time of the task that you calculated. More specifically, you should allow sufficient margin and set the task period value to at least 1.1 times as large as the average real processing time of the task.

Task period \geq Average real processing time of task \times 1.1

Because the average real processing time of the task that is calculated above is 837 μ s, as the value larger than 1.1 times the average time, the task period is set to 1000 μ s.

The task execution times in the physical Controller depends on the logic operations that are performed in the user program, the presence of communications commands and data links, on whether data tracing is performed, and on other factors. The task execution time for a periodic task depends on whether it is interrupted for the execution of tasks with higher execution priorities.

Use the physical Controller and verify the task execution time with the Task Execution Time Monitor.

A-4 Calculating Guidelines for the Real Processing Times of Tasks for the NX1P2 System

This section describes how to calculate guidelines for the average real processing times of tasks on paper for the NX1P2 System.

You must use the physical Controller to check the real processing times of tasks and task execution times. For details, refer to 5-11 Task Design Methods and I/O Response Times.



Precautions for Safe Use

The task execution times in the physical Controller depends on the logic operations that are performed in the user program, the presence of communications commands and data links, on whether data tracing is performed, and on other factors.

Before starting actual operation, you must test performance under all foreseeable conditions on the actual system and make sure that the task periods are not exceeded and that suitable communications performance is achieved.



Additional Information

Periodic tasks may be interrupted for the execution of tasks with higher execution priorities. The real processing time of a task does not include the time for which the task is interrupted. It is the task execution time that gives the actual time from when the task is started until it is finished, including the interrupted time. For a detailed description of the differences between the real processing times of tasks and the task execution times, refer to *Meaning of the Task Execution Time and the Real Processing Time of the Task* on page 5-113.

A-4-1 Calculating the Average Real Processing Times of Tasks

The average real processing time of a task is the total of the I/O refresh processing time, user program execution time, motion control processing time and common processing time.

Average real processing time of task = I/O refresh processing time + User program execution time

+ Motion control processing time + Common processing time

The following processing is performed.

Processing		Processing contents	Primary periodic task	Priority-17 and priority-18 periodic tasks
I/O refresh	processing	I/O is refreshed for NX Units on the CPU Unit, built-in I/O, and EtherCAT slaves.	Performed.	Not per- formed.
User program execution		Programs assigned to tasks are executed in the order that they are assigned.	Performed.	Performed.
Motion control processing		 Motion control commands from the user program are executed. Motion output processing 	Performed.	Not per- formed.
Common processing time	System common processing 1	 Variable refresh processing (if there are accessing tasks) is performed. Motion input processing Data trace processing 	Performed.	Performed.
	System common processing 2	 Variable refresh processing (if there are refreshing tasks) is performed. Variable access processing external to the Controller to ensure concurrency with task execution 	Performed.	Performed.
	System overhead time	Other system common processing	Performed.	Performed.

Guidelines are provided below for calculating the various processing times.

I/O Refresh Processing Time

Use the following formula for the I/O refresh processing time.

I/O refresh processing time = EtherCAT slave processing time + NX Unit processing time

The following describes how to determine EtherCAT slave processing time, NX Unit processing time used in the above formula.

EtherCAT Slave Processing Time

Use the following formula to calculate the EtherCAT slave processing time.

EtherCAT slave processing time [μ s] = 0.017 × pDout + 0.010 × pDin + 0.082 × pDinout + (1.24 × Snum + 0.01 × Clen) + 151.11

pDout : Total output processing data size [byte] of EtherCAT slaves assigned to the primary

periodic task

pDin : Total input processing data size [byte] of EtherCAT slaves assigned to the primary

periodic task

pDinout : Total of the larger of the input and output processing data size of each EtherCAT

slave assigned to the primary periodic task [byte]

Snum : Total number of EtherCAT slaves connected to the built-in EtherCAT port

Clen : Total length of cables connected to the built-in EtherCAT port [m]



Additional Information

The EtherCAT slave processing time is 0 if EtherCAT slaves are not connected.

NX Unit Processing Time

Use the following formula for the NX Unit processing time.

The calculation must include all NX Units on the CPU Unit.

NX Unit processing time [μ s] = 0.248 × Dnxout + 0.241 × Dnxin + 0.549 × Dnxnum + 125.36

Dnxout : Total output data size [byte]*1

Dnxin : Total input data size [byte]*1

Dnxnum : Number of connected NX Units

^{*1} If the data size of an NX Unit is less than 2 bytes, calculate as 2 bytes.



Additional Information

The NX Unit processing time is 0 if NX Units are not connected to the CPU Unit.

User Program Execution Time

The user program execution time depends on the specific instructions multiplied by the numbers of instructions used.

As a guideline, instructions are divided into three groups and the number of instructions in each group is used for measurements and estimates.

- · Standard instructions
- Arithmetic instructions for LREAL data
- · Trigonometric instructions for LREAL data

Different instructions are used in a ladder diagram and in ST. Refer to *Instruction Configuration for Standard Ladder Diagram Instructions* on page A-25 and *Instruction Configuration for Standard ST Instructions* on page A-27 for information on the instruction configuration.


Simple Estimate

For the number of instructions in each group, read the execution time for each instruction group from the following graphs and calculate the total.

- · Execution time for standard instructions
- · Execution time for arithmetic instructions for LREAL data
- Execution time for trigonometric instructions for LREAL data

This will allow you to estimate the execution time of the user program.

Execution Time for Standard Ladder Diagram Instructions




• Instruction Configuration for Standard Ladder Diagram Instructions

The instruction execution ratio for this configuration is 20%.

Types of instructions	Instructions	Percent of instructions [%]	Percent of execution time in instruction group [%]
Ladder diagram instructions	LD, AND, OUT, SET, and RESET	81.0%	40.2%
Comparison instructions	EQ and LT	4.1%	8.3%
Timer and counter instructions	Timer, TON/TOF, and CTU/CTD	1.6%	7.3%
Math instructions	+, -, *, /, ADD, SUB, MUL, and DIV	2.4%	6.5%
BCD conversion instructions and data conversion instructions	INT_TO_DINT and WORD_BC- D_TO_UINT	0.2%	1.2%

Types of instructions	Instructions	Percent of instructions [%]	Percent of execution time in instruction group [%]
Bit string processing instructions	AND and OR	6.2%	13.0%
Data movement instructions	MOVE	4.6%	23.5%
Total	100.0%	100.0%	

Execution Times for Ladder Diagram Arithmetic and Trigonometric Instructions for LREAL Data




• Configuration of Arithmetic Instructions for LREAL Data

Instructions	Percent of instructions [%]
Addition instructions for LREAL data	20.0%
Subtraction instructions for LREAL data	20.0%
Multiplication instructions for LREAL data	30.0%
Division instructions for LREAL data	30.0%
Total	100.0%

• Configuration of Trigonometric Instructions for LREAL Data

Instructions	Percent of instructions [%]
Sin of LREAL data	16.7%
Cos of LREAL data	16.7%
Tan of LREAL data	16.7%
Sin ⁻¹ of LREAL data	16.7%
Cos ⁻¹ of LREAL data	16.7%
Tan ⁻¹ of LREAL data	16.7%
Total	100.0%


Execution Time for Standard ST Instructions



• Instruction Configuration for Standard ST Instructions

Types of instructions	Instructions	Percent of instructions [%]	Percent of execution time in instruction group [%]
ST constructs	IF ELSIF END_IF	75.4%	41.6%
Comparison instructions	EQ and LT	5.2%	8.7%
Timer and counter instructions	Timer, TON/TOF, and CTU/CTD	2.1%	18.8%
Math instructions	+, -, *, and /	3.1%	10.2%
BCD conversion instructions and data conversion instructions	INT_TO_DINT and WORD_BC-D_TO_UINT	0.2%	1.6%
Bit string processing instructions	AND and OR	8.0%	11.7%
Data movement instructions	:=	5.9%	7.3%
Total	100.0%	100.0%	

Execution Times for ST Arithmetic and Trigonometric Instructions for LREAL Data



· Configuration of Arithmetic Instructions for LREAL Data

Instructions	Percent of instructions [%]
Addition instructions for LREAL data	20.0%
Subtraction instructions for LREAL data	20.0%
Multiplication instructions for LREAL data	30.0%
Division instructions for LREAL data	30.0%
Total	100.0%


· Configuration of Trigonometric Instructions for LREAL Data

Instructions	Percent of instructions [%]
Sin of LREAL data	16.7%
Cos of LREAL data	16.7%
Tan of LREAL data	16.7%
Sin ⁻¹ of LREAL data	16.7%
Cos ⁻¹ of LREAL data	16.7%
Tan ⁻¹ of LREAL data	16.7%
Total	100.0%

Motion Control Processing Time

The motion control processing time depends on the number of servo axes and virtual servo axes that are used.

For the number of servo and virtual servo axes, read the motion control processing time from the following graph.



Common Processing Time

The common processing time is the following values by the total time for system overhead, system common processing 1, and system common processing 2. The common processing time depends on the type of task.

Type of task	Common processing times [µs] (reference values)	
Type of task	NX1P2-□□□	
Primary periodic task	133	
Periodic task	175	

A-4-2 Example of Calculating the Average Real Processing Time of a Task and Setting the Task Period

Example of Calculating the Average Real Processing Times of Tasks

If you are using an NX1P2- $\square\square\square\square$ CPU Unit with a unit version of 1.13, first find the average real processing time of the task for the following conditions.

The task is the primary periodic task.

Item		Conditions
	EtherCAT slaves	GX-ID1611 (Ver. 1.1) Input Slave: 1
		GX-OD1611 (Ver. 1.1) Output Slave: 1
		R88D-1SN□□□-ECT Servo Drives: 4
Slaves/Units that are used	NX Units (on CPU Rack)	NX-PF0630 Additional I/O Power Supply Unit: 1
Slaves/Offits that are used		NX-ID5342 Digital Input Units: 3
		NX-OD3153 Digital Output Units: 2
		NX-AD4608 Analog Input Unit: 1
		NX-DA3605 Analog Output Unit: 1
	Language	Ladder diagrams
	Standard instruction configuration	Number of instructions: 5,000
User program	Arithmetic instructions for LREAL data	Number of instructions: 200
	Trigonometric instructions for LREAL data	Number of instructions: 100
Motion control processing	Number of axes	4

Note Total length of cables connected to the built-in EtherCAT port is 10 [m].

I/O Refresh Time

EtherCAT slave processing time:

The following table gives the pDout (output processing data size), pDin (input processing data size), and pDinout (larger of the input and output data size) values of the GX-ID1611 (Ver. 1.1) Input Slave, GX-OD1611 (Ver. 1.1) Output Slave, and R88D-1SN ——-ECT Servo Drives.

EtherCAT slave	pDout: Output processing data size in bytes	pDin: Input process- ing data size in bytes	pDinout: Larger of the input and output data size
GX-ID1611 (Ver. 1.1)	0	3	3
GX-OD1611 (Ver. 1.1)	2	1	2
R88D-1SN□□□-ECT	23	26	26

Total number of bytes are given below for pDout, pDin and pDinout.

pDout = $2 + 23 \times 4 = 94$ [byte]

pDin = $3 + 1 + 26 \times 4 = 108$ [byte]

pDinout = $3 + 2 + 26 \times 4 = 109$ [byte]

NX Unit processing time:

The following table gives the Dnxout (output data size), Dnxin (input data size) values of the NX-PF0630 Additional I/O Power Supply Unit, NX-ID5342 Digital Input Unit, NX-OD3153 Digital Output Unit, NX-AD4608 Analog Input Unit, and NX-DA3605 Analog Output Unit.

NX Units	Dnxout: Output data size in bytes	Dnxin: Input data size in bytes
NX-PF0630	0	0
NX-ID5342	0	2
NX-OD3153	2	0
NX-AD4608	0	16
NX-DA3605	8	0

Total number of bytes are given below for Dnxout and Dnxin.

Dnxout =
$$2 \times 2 + 8 = 12$$
 [byte]

Dnxin = $2 \times 3 + 16 = 22$ [byte]

From these values, the I/O refresh time is calculated by the following formula.

I/O refresh processing time

- = EtherCAT slave processing time + NX Unit processing time
- = $0.017 \times pDout + 0.010 \times pDin + 0.082 \times pDinout + (1.24 \times Snum + 0.01 \times Clen) + 151.11 + 0.248 \times Dnxout + 0.241 \times Dnxin + 0.549 \times Dnxnum + 125.36$
- = $0.017 \times 94 + 0.010 \times 108 + 0.082 \times 109 + (1.24 \times 6 + 0.01 \times 10) + 151.11 + 0.248 \times 12 + 0.241 \times 22 + 0.549 \times 8 + 125.36$
- = 1.598 + 1.080 + 8.938 + (7.44 + 0.1) + 151.11 + 2.976 + 5.302 + 4.392 + 125.36
- $\approx 308 \, [\mu s]$

User Program Execution Time

The graphs show the following values.

- Standard instruction configuration
 From the graph of the execution time for standard ladder diagram instructions, the user program execution time of 5,000 instructions for the NX1P2-□□□□ is 189 μs.
- Arithmetic instructions for LREAL data
 From the graph of the execution time for ladder diagram arithmetic and trigonometric instructions
 for LREAL data, the user program execution time of 200 instructions for the NX1P2-□□□□ is 41
 µs.
- Trigonometric instructions for LREAL data
 From the graph of the execution time for ladder diagram arithmetic and trigonometric instructions for LREAL data, the user program execution time of 100 instructions for the NX1P2-□□□□ is 51 µs.

Therefore, the user program execution time is the total of the above values, which is given by the following formula.

User program execution time =
$$189 + 41 + 51$$

= $281 [\mu s]$

Motion Control Processing Time

From the graph of the execution time for motion control processing, the execution time of the motion control processing for four axes for the NX1P2- $\square\square\square\square$ with a unit version 1.13 is read as 148 μ s.

Common Processing Time

Because the task is the primary periodic task, the common processing time for the NX1P2- $\square\square\square$ is 133 μ s.

Therefore, the average real processing time of the task is given by the following formula.

Average real processing time of task = I/O refresh processing time + User program execution time

+ Motion control processing time + Common processing time

= 308 + 281 + 148 + 133

 $= 870 [\mu s]$

Setting the Task Period

The task period is set based on the average real processing time of the task that is calculated as above. The task is the primary periodic task.

The value of the task period must be larger than the average real processing time of the task that you calculated. More specifically, you should allow sufficient margin and set the task period value to at least 1.1 times as large as the average real processing time of the task.

Task period ≥ Average real processing time of task × 1.1

Because the average real processing time of the task that is calculated above is 870 μ s, as the value larger than 1.1 times the average time, the task period is set to 2000 μ s.

The task execution times in the physical Controller depends on the logic operations that are performed in the user program, the presence of communications commands and data links, on whether data tracing is performed, and on other factors. The task execution time for a periodic task depends on whether it is interrupted for the execution of tasks with higher execution priorities.

Use the physical Controller and verify the task execution time with the Task Execution Time Monitor.

A-5 Calculating Guidelines for the Real Processing Times of Tasks for the NJ-series System

This section describes how to calculate guidelines for the average real processing times of tasks on paper for the NJ-series System.

You must use the physical Controller to check the real processing times of tasks and task execution times. For details, refer to 5-11 Task Design Methods and I/O Response Times.



Precautions for Safe Use

- The task execution times in the physical Controller depends on the logic operations that are
 performed in the user program, the presence of communications commands and data links, on
 whether data tracing is performed, and on other factors.
 Before starting actual operation, you must test performance under all foreseeable conditions
 on the actual system and make sure that the task periods are not exceeded and that suitable
- The performance may be different if the hardware revisions are different. Before you transfer the user program, data, and parameter settings to the CPU Units with the different hardware revisions, check them for proper execution and then use them for actual operation.



Precautions for Correct Use

communications performance is achieved.

When the hardware revisions are different, the actual execution timing of the event tasks, tag data link service and system services may be different even if the user program, data, and parameter settings are same.



Additional Information

Periodic tasks will be interrupted for the execution of tasks with higher execution priorities. The real processing time of a task does not include the time for which the task is interrupted. It is the task execution time that gives the actual time from when the task is started until it is finished, including the interrupted time. For a detailed description of the differences between the real processing times of tasks and the task execution times, refer to *Meaning of the Task Execution Time* and the *Real Processing Time of the Task* on page 5-113.

A-5-1 Calculating the Average Real Processing Times of Tasks

The average real processing time of a task is the total of the I/O refresh processing time, user program execution time, motion control processing time and common processing time.

Average real processing time of task = I/O refresh processing time + User program execution time + Motion control processing time + Common processing time

The following processing is performed.

Processing		Processing contents	Primary periodic task	Priority-16 periodic task	Priority-17 and prior- ity-18 peri- odic tasks
I/O refresh processing		I/O is refreshed for CJ-series Units (Basic I/O Units, Special I/O Units, and CPU Bus Units) and EtherCAT slaves.	Performed.	Performed.	Not per- formed.
User program execution		Programs assigned to tasks are executed in the order that they are assigned.	Performed.	Performed.	Performed.
Motion control processing		 Motion control commands from the user program are executed. Motion control outputs are processed. 	Performed.	Not per- formed.	Not per- formed.
Common processing time	System com- mon pro- cessing 1	 Variable refresh processing (if there are accessing tasks) is performed. Motion input processing Data trace processing 	Performed.	Performed.	Performed.
	System common processing 2	Variable refresh processing (if there are refreshing tasks) is performed. Variable access processing external to the Controller to ensure concurrency with task execution	Performed.	Performed.	Performed.
	System over- head time	Other system common processing	Performed.	Performed.	Performed.

Guidelines are provided below for calculating the various processing times.

I/O Refresh Processing Time

Use the following formula for the I/O refresh processing time.

I/O refresh processing time = I/O refresh overhead time

+ (Larger of the EtherCAT slave processing time and the CJ-series Unit processing time)

The following describes how to determine the I/O refresh overhead time, EtherCAT slave processing time, and CJ-series Unit processing time used in the above formula.

I/O Refresh Overhead Time

The I/O refresh overhead time is given by the following table, depending on whether there are Ether-CAT slaves and CJ-series Units, and also depending on the models of the CPU Units.

EtherCAT slave	CJ-series	I/O refresh overhead time [μs]			
Unit		NJ501-□□□□	NJ301-□□□□	NJ101-□□□□	
Present	Present	65 ^{*1}	95	135	
Present	None	35 ^{*2}	50	65	
None	Present	30	45	70	

^{*1} The value is 90 for a CPU Unit with unit version 1.01 or earlier.

EtherCAT Slave Processing Time

Use the following formula for the EtherCAT slave processing time.

EtherCAT slave processing time [μ s] = Tout \times Dout + Tin \times Din + Tref \times Dinout + (1.24 \times Snum + 0.01 \times Clen - Tec)

Tout : Output processing time per byte [μs]

Dout : Total output processing data size [byte] of EtherCAT slaves assigned to the primary peri-

odic task or the priority-16 periodic task

Tin : Input processing time per byte [μs]

Din : Total input processing data size [byte] of EtherCAT slaves assigned to the primary periodic

task or the priority-16 periodic task

Snum : Number of connected EtherCAT slaves
Tref : Refresh processing time per byte [µs]

Dinout : Total of the larger of the input and output processing data size of each EtherCAT

slave assigned to the primary periodic task or the priority-16 periodic task [byte]

Clen : Total cable length [m]

Tec : EtherCAT communications adjustment time [μs]

The values of the output processing time, input processing time, refresh processing time, and Ether-CAT communications adjustment time in the above formula are fixed. They are determined by the model of the CPU Unit as given in the following table.

CPU Unit	Tout: Output processing time per byte [μs]	Tin: Input pro- cessing time per byte [μs]	Tref: Refresh processing time per byte [μs]	Tec: EtherCAT communications adjustment time [μs]
NJ501-□□□□	0.004	0.011	0.082	55 ^{*1}
NJ301-□□□□	0.005	0.013	0.082	90
NJ101-□□□□	0.010	0.004	0.082	145

^{*1} The value is 70 for a CPU Unit with unit version 1.01 or earlier.

If the result that is calculated from the part (1.24 \times Snum + 0.01 \times Clen - Tec) of the above formula is a negative number, the result is regarded as 0.

^{*2} The value is 60 for a CPU Unit with unit version 1.01 or earlier.

CJ-series Unit Processing Time

Use the following formula for the CJ-series Unit processing time.

 Σ (I/O refresh time for each CJ-series Unit \times Number of Units) - Tcj [μ s]

In the above formula, Σ represents the total processing time for all CJ-series Units.

If the result that is calculated from the above formula is a negative number, the CJ-series Unit processing time is regarded as $0 \, \mu s$.

The method for calculating the I/O refresh time for each CJ-series Unit is provided later.

The value of Tcj depends on the model and the unit version of the CPU Unit.

Model	Unit version	Tcj [μs]
NJ501-□□□□	Ver. 1.01 or earlier	230
	Ver. 1.02 or later	110
NJ301-□□□□	Ver. 1.01 or earlier	230
	Ver. 1.02 or later	165
NJ101-□□□□	Ver. 1.10 or later*1	225

^{*1} There is no NJ101- CPU Unit with unit version 1.09 or earlier.

If any of the following CJ-series Units is used, add Tcj μ s to the result that is calculated from the above formula, regardless of the number of Units.

- CJ1W-PH41U Analog Input Unit with Universal Inputs
- · CJ1W-AD04U Analog Input Unit with Universal Inputs
- CJ1W-PDC15 Analog Input Unit with Universal Inputs
- CJ1W-V680C11 ID Sensor Unit
- CJ1W-V680C12 ID Sensor Unit
- CJ1W-CRM21 CompoNet Master Unit

I/O Refresh Times for CJ-series Units

This section gives the I/O refresh times for CJ-series Units.

Basic I/O Units

The following table gives the I/O refresh times for Basic I/O Units that are used on the CPU Rack. The I/O refresh times for these Units on Expansion Racks are approx. 1.5 times the values that are given in the table.

Unit name	Model numbers	I/O refresh time per Unit [μs]
8/16-point DC Input Units	CJ1W-ID201/211/212	1
32-point DC Input Units	CJ1W-ID231/232/233	2
64-point DC Input Units	CJ1W-ID261/262	4
8/16-point AC Input Units	CJ1W-IA201/111	1
16-point Interrupt Input Unit	CJ1W-INT01	1
16-point Quick-response Input Unit	CJ1W-IDP01	1
Relay Contact Output Units	CJ1W-OC201/211	1
Triac Output Unit	CJ1W-OA201	1
8/16-point Transistor Output Units	CJ1W-OD201/202/203/204//211/212/213	1
32-point Transistor Output Units	CJ1W-OD231/232/233/234	2
64-point Transistor Output Units	CJ1W-OD261/262/263	4
24-VDC Input/Transistor Output Units (16 inputs/16 outputs)	CJ1W-MD231/232/233	1
24-VDC Input/Transistor Output Units (32 inputs/32 outputs)	CJ1W-MD261/263	2
TTL I/O Unit	CJ1W-MD563	4
	CJ1W-B7A04	4
B7A Interface Units	CJ1W-B7A14	4
	CJ1W-B7A22	4

Special I/O Units

The following table gives the I/O refresh times for Special I/O Units that are used on the CPU Rack. The I/O refresh times for these Units on Expansion Racks are approx. 1.5 times the values that are given in the table.

Unit name	Model numbers	I/O refresh time per Unit [μs]
Isolated-type Units with Universal Inputs	CJ1W-AD04U	66
Analog Input Units	CJ1W-AD041-V1/081-V1/042	24
Analog Output Units	CJ1W-DA021/041/042V/08V/08C	24
Analog I/O Units	CJ1W-MAD42	24
Isolated-type Units with Universal Inputs	CJ1W-PH41U	80 (180) ^{*1}
Isolated-type DC Input Unit	CJ1W-PDC15	60 (100) ^{*1}
Temperature Control Units	CJ1W-TC□□□	114
ID Sensor Units	CJ1W-V680C11	76
ID Selisor Offics	CJ1W-V680C12	86
High-speed Counter Unit	CJ1W-CT021	54

Unit name	Model numbers		I/O refresh time per Unit [μs]
	CJ1W-CRM21	Communications mode 0	34
		Communications mode 1	52
CompoNet Master Unit		Communications mode 2	88
Componet master omt		Communications mode 3	84
		Communications mode 8	14 + (1.0 × Number of allocated words)

^{*1} The values in parentheses are the I/O refresh times when an expansion allocation area is used.

CPU Bus Units

The following table gives the I/O refresh times for CPU Bus Units. The times are the same regardless of whether the Units are used on the CPU Rack or an Expansion Rack.

Unit name	Model numbers	I/O refresh time per Unit [μs]
Serial Communications Units	CJ1W-SCU42 CJ1W-SCU32 CJ1W-SCU22	Coefficient*1 × 25*2
DeviceNet Unit	CJ1W-DRM21	Coefficient*1 × (Number of allocated words*3 + 25)
EtherNet/IP Unit	CJ1W-EIP21	$7.0 + 0.8 \times \text{Number of tags}^{*4}$

^{*1} The coefficient is determined by the model of the CPU Unit as follows.

NJ501-□□□: 0.1 NJ301-□□□: 0.2 NJ101-□□□: 0.3

User Program Execution Time

The user program execution time depends on the specific instructions multiplied by the numbers of instructions used.

As a guideline, instructions are divided into three groups and the number of instructions in each group is used for measurements and estimates.

- · Standard instructions
- · Arithmetic instructions for LREAL data
- Trigonometric instructions for LREAL data

Different instructions are used in a ladder diagram and in ST. Refer to *Instruction Configuration for Standard Ladder Diagram Instructions* on page A-58 and *Instruction Configuration for Standard ST Instructions* on page A-60 for information on the instruction configuration.

Simple Estimate

For the number of instructions in each group, read the execution time for each group from the following graphs and calculate the total.

- · Execution time for standard instructions
- Execution time for arithmetic instructions for LREAL data
- Execution time for trigonometric instructions for LREAL data

This will allow you to estimate the execution time of the user program.


^{*2} The number of allocated words is the total number of I/O area words that are allocated to all of the slaves.

^{*2} The following maximum time is added if a protocol macro is executed: Coefficient × Number of refresh words [μs]

^{*3} The number of allocated words is the total number of I/O area words that are allocated to all of the slaves.

^{*4} For a CPU Unit with unit version 1.03 or later, the I/O refresh times for EtherNet/IP Units are not added.

Execution Time for Standard Ladder Diagram Instructions




- *1 It is the case when the hardware revision for the Unit is A or B. The other cases are for the Units that hardware revisions are in blank.
 - Instruction Configuration for Standard Ladder Diagram Instructions The instruction execution ratio for this configuration is 20%.

Types of instructions	Instructions	Percent of instructions [%]	Percent of exe- cution time in instruction group [%]
Ladder diagram instructions	LD, AND, OUT, SET, and RESET	81.0%	40.2%
Comparison instructions	EQ and LT	4.1%	8.3%
Timer and counter instructions	Timer, TON/TOF, and CTU/CTD	1.6%	7.3%
Math instructions	+, -, *, /, ADD, SUB, MUL, and DIV	2.4%	6.5%
BCD conversion instructions and data conversion instructions	INT_TO_DINT and WORD_BC-D_TO_UINT	0.2%	1.2%
Bit string processing instructions	AND and OR	6.2%	13.0%
Data movement instructions	MOVE	4.6%	23.5%
Total		100.0%	100.0%


Execution Times for Ladder Diagram Arithmetic and Trigonometric Instructions for LREAL Data

· When hardware revisions for the Units are in blank



Arithmetic instructions for LREAL data ---- Trigonometric instructions for LREAL data

• When the hardware revision for the Units is A or B




• Configuration of Arithmetic Instructions for LREAL Data

Instructions	Percent of instructions [%]
Addition instructions for LREAL data	20.0%
Subtraction instructions for LREAL data	20.0%
Multiplication instructions for LREAL data	30.0%
Division instructions for LREAL data	30.0%
Total	100.0%

• Configuration of Trigonometric Instructions for LREAL Data

Instructions	Percent of instructions [%]
Sin of LREAL data	16.7%
Cos of LREAL data	16.7%
Tan of LREAL data	16.7%
Sin ⁻¹ of LREAL data	16.7%
Cos ⁻¹ of LREAL data	16.7%
Tan ^{−1} of LREAL data	16.7%
Total	100.0%

Execution Time for Standard ST Instructions




- *1 It is the case when the hardware revision for the Unit is A or B. The other cases are for the Units that hardware revisions are in blank.
 - · Instruction Configuration for Standard ST Instructions

Types of instructions	Instructions	Percent of instructions [%]	Percent of exe- cution time in instruction group [%]
ST constructs	IF ELSIF END_IF	75.4%	41.6%
Comparison instructions	EQ and LT	5.2%	8.7%
Timer and counter instructions	Timer, TON/TOF, and CTU/CTD	2.1%	18.8%
Math instructions	+, -, *, and /	3.1%	10.2%
BCD conversion instructions and data conversion instructions	INT_TO_DINT and WORD_BC-D_TO_UINT	0.2%	1.6%
Bit string processing instructions	AND and OR	8.0%	11.7%
Data movement instructions	:=	5.9%	7.3%
Total		100.0%	100.0%


Execution Times for ST Arithmetic and Trigonometric Instructions for LREAL Data

· When hardware revisions for the Units are in blank



---- Trigonometric instructions for LREAL data ----- Arithmetic instructions for LREAL data

• When the hardware revision for the Units is A or B



· Configuration of Arithmetic Instructions for LREAL Data


Instructions	Percent of instructions [%]
Addition instructions for LREAL data	20.0%
Subtraction instructions for LREAL data	20.0%
Multiplication instructions for LREAL data	30.0%
Division instructions for LREAL data	30.0%
Total	100.0%

• Configuration of Trigonometric Instructions for LREAL Data

Instructions	Percent of instructions [%]
Sin of LREAL data	16.7%
Cos of LREAL data	16.7%
Tan of LREAL data	16.7%
Sin ⁻¹ of LREAL data	16.7%
Cos ⁻¹ of LREAL data	16.7%
Tan ⁻¹ of LREAL data	16.7%
Total	100.0%

Motion Control Processing Time


The motion control processing time depends on the number of servo axes and virtual servo axes that are used. For the number of servo and virtual servo axes, read the motion control processing time from the following graph.




Number of axes

20

0





Note You cannot use the motion control functions with an NJ101-90□□ CPU Unit.

2

Common Processing Time

The common processing time is the following values by the total time for system overhead, system common processing 1, and system common processing 2. The common processing time depends on the type of task.

Type of task	Common processing times [µs] (reference values)		
Type of task	NJ501-□□□□	NJ301-□□□□	NJ101-□□□□
Primary periodic task	150 ^{*1}	240 ^{*2}	300
Periodic task	10	32	82

^{*1} The processing time is 265 µs for a CPU Unit with unit version 1.01 or earlier.

A-5-2 Example of Calculating the Average Real Processing Time of a Task and Setting the Task Period

Example of Calculating the Average Real Processing Times of Tasks

If you are using an NJ501- $\square\square$ CPU Unit with a unit version of 1.02 and the hardware revision for the Unit is in blank, first find the average real processing time of the task for the following conditions. The task is the primary periodic task.

	Item	Conditions
Slaves/Units that are	EtherCAT slaves	GX-ID1611 (Ver. 1.1) Input Slave: 1
used		GX-OD1611 (Ver. 1.1) Output Slave: 1
		R88D-1SN□□□-ECT Servo Drives: 4
	CJ-series Units (on CPU	CJ1W-ID211 DC Input Unit: 1
	Rack)	CJ1W-OD211 Transistor Output Unit: 1
		CJ1W-AD042 Analog Input Unit: 1
		CJ1W-DA021 Analog Output Unit: 1
		CJ1W-SCU42 Serial Communications Unit: 1
		(Protocol macros are not used.)
User program	Language	Ladder diagrams
	Standard instruction configuration	Number of instructions: 5,000
	Arithmetic instructions for LREAL data	Number of instructions: 200
	Trigonometric instructions for LREAL data	Number of instructions: 100
Motion control pro- cessing	Number of axes	4

Note Total length of cables connected to the built-in EtherCAT port is 10 [m].

I/O Refresh Time

I/O refresh overhead time:

The I/O refresh overhead time is $65~\mu s$ because the EtherCAT slaves and CJ-series Units are connected.

 $^{^{*}2}$ The processing time is 360 μs for a CPU Unit with unit version 1.01 or earlier.

EtherCAT slave processing time:

The following table gives the Tout (output processing time per byte), Tin (input processing time per byte), and Tref (refresh processing time per byte) values when an NJ501- $\square\square\square\square\square$ CPU Unit is used.

Tout: Output processing time per byte [μs]	Tin: Input processing time per byte [μs]	Tref: Refresh processing time per byte [μs]	Tec: EtherCAT commu- nications adjustment time [μs]
0.004	0.011	0.082	55

The following table gives the Dout (output processing data size), Din (input processing data size), and Dinout (larger of the input and output data size) values of the GX-ID1611 (Ver. 1.1) Input Slave, GX-OD1611 (Ver. 1.1) Output Slave, and R88D-1SN \(\subseteq \subseteq -ECT \) Servo Drives.

EtherCAT slave	Dout: Output processing data size in bytes	Din: Input processing data size in bytes	Dinout: Larger of the input and output data size
GX-ID1611 (Ver. 1.1)	0	3	3
GX-OD1611 (Ver. 1.1)	2	1	2
R88D-1SN□□□-ECT	23	26	26

Total number of bytes are given below for Dout, Din and Dinout.

Dout =
$$2 + 23 \times 4 = 94$$
 [byte]

Din =
$$3 + 1 + 26 \times 4 = 108$$
 [byte]

Dinout =
$$3 + 2 + 26 \times 4 = 109$$
 [byte]

From these values, the I/O refresh time is calculated by the following formula.

I/O refresh processing time

- = EtherCAT slave processing time
- = Tout \times Dout + Tin \times Din + Tref \times Dinout + (1.24 \times Snum + 0.01 \times Clen Tec)

$$= 0.004 \times 94 + 0.011 \times 108 + 0.082 \times 109 + (1.24 \times 6 + 0.01 \times 10 - 55)$$

$$= 0.376 + 1.188 + 8.938 + (7.44 + 0.1 - 55)$$

- $= 10.502 + 0^{*1}$
- \approx 11 [μ s]

CJ-series Unit processing time:

The following table gives the I/O refresh time per Unit for the CJ1W-ID211 DC Input Unit, CJ1W-OD211 Transistor Output Unit, CJ1W-AD042 Analog Input Unit, CJ1W-DA021 Analog Output Unit, and CJ1W-SCU42 Serial Communications Unit that are used on the CPU Rack.

Model	I/O refresh time per Unit [μs]	
CJ1W-ID211		1
CJ1W-OD211		1
CJ1W-AD042		24
CJ1W-DA021		24
CJ1W-SCU42		2.5

Because the number of Units is all one, the CJ-series Unit processing time is regarded as $0 \mu s$.

^{*1.} Because the result that is calculated inside the parenthesis is a negative number, it is regarded as $0 \mu s$.

CJ-series Unit processing time =
$$\Sigma$$
 (I/O refresh time for each CJ-series Unit \times Number of Units) - 110 = $1 \times 1 + 1 \times 1 + 24 \times 1 + 24 \times 1 + 2.5 \times 1 - 110$ = -57.5 [μ s]

Because the result that is calculated from the above formula is a negative number, the CJ-series Unit processing time is regarded as $0 \, \mu s$.

The following values of the I/O refresh overhead time, EtherCAT slave processing time, and CJ-series Unit processing time are found by the above calculations.

Item	Value [µs]
I/O refresh overhead time	65
EtherCAT slave processing time	11
CJ-series Unit processing time	0

From these values, the I/O refresh time is calculated by the following formula.

I/O refresh time

= I/O refresh overhead time + (Larger of the EtherCAT slave processing time and the CJ-series Unit processing time)

= 65 + 11

 $= 76 [\mu s]$

User Program Execution Time

The graphs show the following values.

- Standard instruction configuration
 - From the graph of the execution time for standard ladder diagram instructions, the user program execution time of 5,000 instructions for the NJ501- $\square\square\square\square$ is 100 μ s.
- · Arithmetic instructions for LREAL data
 - From the graph of the execution time for ladder diagram arithmetic and trigonometric instructions for LREAL data, the user program execution time of 200 instructions for the NJ501- $\square\square\square\square$ is 20 μ s.
- Trigonometric instructions for LREAL data
 - From the graph of the execution time for ladder diagram arithmetic and trigonometric instructions for LREAL data, the user program execution time of 100 instructions for the NJ501- $\square\square\square\square$ is 27 μ s.

Therefore, the user program execution time is the total of the above values, which is given by the following formula.

User program execution time =
$$100 + 20 + 27$$

= $147 [\mu s]$

Motion Control Processing Time

From the graph of the execution time for motion control processing, the execution time of the motion control processing for four axes for the NJ501- $\square\square\square\square$ with a unit version 1.02 is read as 46 μ s.

Common Processing Time

Because the task is the primary periodic task, the common processing time for the NJ501- $\square\square\square\square$ is 150 μ s.

Therefore, the average real processing time of the task is given by the following formula.

```
Average real processing time of task = I/O refresh processing time + User program execution time + Motion control processing time + Common processing time = 76 + 147 + 46 + 150 = 419 [µs]
```

Setting the Task Period

The task period is set based on the average real processing time of the task that is calculated as above. The task is the primary periodic task.

The value of the task period must be larger than the average real processing time of the task that you calculated. More specifically, you should allow sufficient margin and set the task period value to at least 1.1 times as large as the average real processing time of the task.

Task period ≥ Average real processing time of task × 1.1

Because the average real processing time of the task that is calculated above is 419 μ s, the task period is set to 500 μ s, which is larger than 1.1 times the average time.

The task execution times in the physical Controller depends on the logic operations that are performed in the user program, the presence of communications commands and data links, on whether data tracing is performed, and on other factors. The task execution time for a periodic task depends on whether it is interrupted for the execution of tasks with higher execution priorities.

Use the physical Controller and verify the task execution time with the Task Execution Time Monitor.

A-6 System-defined Variables

System-defined variables are assigned specific functions by the system. They are registered in the global variable table, or the local variable table for each POU, in advance.

These variables cannot be changed. Some of the variables start with an underbar and some start with "P ".

Some of the system-defined variables are read-only and some are read/write.

You read and write the variables with the user program, with communications from external devices, with the Sysmac Studio, or with an NS/NA-series PT.

Basically, system-defined variables are classified according to the function modules. The variables start with the following category names.

Function module	Category name
System-defined variables for the overall NJ/NX-series Controller	None
PLC Function Module	_PLC
	_CJB
NX Bus Function Module	_NXB
Motion Control Function Module	_MC, _MC1, and _MC2
EtherCAT Master Function Module	_EC
EtherNet/IP Function Module	_EIP, _EIP1, and _EIP2

The variables are described in the tables of this appendix as shown below.

Variable name	Meaning	Function	Data type	Range of values	Reference
This is the system- defined variable name. The prefix gives the category name.	This is the meaning of the variable.	The function of the variable is described.	The data type of the variable is given.	The range of values that the variable can take is given.	The page of the individual system- defined vari- able specifi- cations table is given.

A version in parentheses in the *Variable name* column is the unit version of the CPU Unit when the system-defined variable was added.



Precautions for Correct Use

There are system-defined variables that are not supported or differ in specifications such as the number of arrays. Refer to *A-7 Specifications for Individual System-defined Variables* for details on the specifications for individual system-defined variables.

A-6-1 System-defined Variables for the Overall NJ/NX-series Controller (No Category)

• Functional Classification: Clock

Variable name	Meaning	Function	Data type	Range of values	Reference
CurrentTime	System Time	Contains the CPU Unit's internal clock data.	DATE AND_ TIME	NX-series CPU Units DT#1970-01- 01-00:00:00 to DT#2069-12- 31-23:59:59 NJ-series CPU Units DT#1970-01- 01-00:00:00 to DT#2106-02- 06-23:59:59	page A-126

• Functional Classification: Tasks

Variable name	Meaning	Function	Data type	Range of values	Reference
TaskName Active	Task Active Flag	TRUE during task execution. FALSE when task execution is not in progress.	BOOL	TRUE or FALSE	page A-126
		Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.			
_ <i>TaskName</i> _ LastExecTime	Last Task Execution Time	Contains the task execution time the last time the task was executed (unit: $0.1 \mu s$).	TIME	Depends on data type.	page A-126
		Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.			
_ <i>TaskName</i> _ MaxExecTime	Maximum Task Execution Time	Contains the maximum value of the task execution time (unit: 0.1 µs).	TIME	Depends on data type.	page A-127
		Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.			
_ <i>TaskName</i> _ MinExecTime	Minimum Task Execution Time	Contains the minimum value of the task execution time (unit: 0.1 µs).	TIME	Depends on data type.	page A-127
		Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.			
_ <i>TaskName</i> _ ExecCount	Task Execution Count	Contains the number of executions of the task.	UDINT	Depends on data type.	page A-127
		If 4294967295 is exceeded, the value returns to 0 and counting is continued.			
		Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.			

Variable name	Meaning	Function	Data type	Range of values	Reference
TaskName Exceeded	Task Period Exceeded Flag	TRUE if the task period was exceeded. FALSE if task execution was completed within the task period.	BOOL	TRUE or FALSE	page A-127
		Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.			
_ <i>TaskName</i> _ ExceedCount	Task Period Exceeded Count	Contains the number of times that the period was exceeded.	UDINT	Depends on data type.	page A-128
		If the present value exceeds the maximum value of the data type, the present value returns to 0 and the count is continued.			
		If 4294967295 is exceeded, the value returns to 0 and counting is continued.			
		Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.			

• Functional Classification: Errors

Variable name	Meaning	Function	Data type	Range of values	Reference
_ErrSta	Controller Error Status	TRUE if there is a Controller error. FALSE if there is no Controller error. Note Do not use this variable in the user program. There may be a delay in updating it and concurrency problems in relation to the error status of the function module. Use this variable only to access status through communications from an external device. Refer to information on the meanings of the error status bits at the end of this appendix for details.	WORD	16#0000 to 16#C0F0	page A-128
_AlarmFlag	User-defined Error Status	The bit corresponding to the event level is TRUE while there is a user-defined error. Bits 00 to 07 correspond to user fault levels 1 to 8. This variable contains 0000 hex when there is no user-defined error.	WORD	16#0000 to 16#00FF	page A-128

• Functional Classification: SD Memory Card

Variable name	Meaning	Function	Data type	Range of values	Reference
_Card1Ready	SD Memory Card Ready Flag	TRUE when the SD Memory Card is recognized. FALSE when the SD Memory Card is not recognized. TRUE: The Card can be used. FALSE: The Card cannot be used.	BOOL	TRUE or FALSE	page A-129
_Card1Protect	SD Memory Card Write Protected Flag	TRUE when the SD Memory Card is write-protected with the LOCK switch. TRUE: Write protected. FALSE: Not write protected.	BOOL	TRUE or FALSE	page A-129
_Card1Err	SD Memory Card Error Flag	TRUE when an unusable SD Memory Card is inserted or a format error occurs. TRUE: There is an error FALSE: There is no error	BOOL	TRUE or FALSE	page A-129
_Card1Access	SD Memory Card Access Flag	TRUE during SD Memory Card access. TRUE: Card is being accessed. FALSE: Card is not being accessed. The system updates the flag every 100 ms. Because of this, access to the SD Memory Card is shown by this flag with a delay of up to 100 ms. We therefore do not recommend the use of this variable in the user program.	BOOL	TRUE or FALSE	page A-129
_Card1Deteriorated	SD Memory Card Life Warning Flag	TRUE when the life of the SD Memory Card is exceeded. TRUE: The life of the Card has been exceeded. FALSE: The Card can still be used.	BOOL	TRUE or FALSE	page A-130
_Card1PowerFail	SD Memory Card Power Interrup- tion Flag	TRUE when the power supply to the CPU Unit was interrupted during access to the SD Memory Card. TRUE: Power was interrupted during SD Memory Card access. FALSE: Normal	BOOL	TRUE or FALSE	page A-130

Variable name	Magning	Frankina	Data tour	Range of	Deference
Member name	Meaning	Function	Data type	values	Reference
_Card1BkupCmd (Ver.1.03)	SD Memory Card Backup Com- mands		_sBKUP_ CMD		page A-130
ExecBkup	Execute Backup Flag	Change this variable to TRUE to back up Controller data to an SD Memory Card. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-130
CancelBkup	Cancel Backup Flag	Change this variable to TRUE to cancel backing up data to an SD Memory Card. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-130
ExecVefy	Execute Verify Flag	Change this variable to TRUE to compare the Controller data to a backup file in the SD Memory Card. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-131
CancelVefy	Cancel Verify Flag	Change this variable to TRUE to cancel comparing the Controller data to a backup file in the SD Memory Card. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-131
DirName	Directory Name	Used to specify the directory name in the SD Memory Card for which to back up or verify data. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	STRING(64)	Depends on data type.	page A-131

Variable name Member name	Meaning	Function	Data type	Range of values	Reference
_Card1BkupSta (Ver. 1.03)	SD Memory Card Backup Status		_sBKUP_ STA		page A-131
Done	Done Flag	TRUE when a backup is completed. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-131
Active	Active Flag	TRUE when a backup is in progress. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-132
Err	Error Flag	TRUE when processing a backup ended in an error. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-132
_Card1VefySta [Ver. 1.03)	SD Memory Card Verify Status		_sVEFY_ STA		page A-132
Done	Done Flag	TRUE when a verification is completed. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-132
Active	Active Flag	TRUE when a verification is in progress. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-132
VefyRsIt	Verify Result Flag	TRUE if the data was the same. FALSE if differences were found. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-133
Err	Error Flag	TRUE when processing a verification ended in an error. Note You cannot use this system-defined variable in the user program. Use it in CIP message communications when sending a command from an HMI or host computer.	BOOL	TRUE or FALSE	page A-133
_Card1PrgTransfer- Cmd (Ver.1.11)	SD Memory Card Program Trans- fer Command		_sPRG- TRANS- FER_CMD		page A-133
Exec	Execute Program Transfer Flag	Change this variable to TRUE to transfer the data in a backup file on the SD Memory Card to the Controller by using the function to transfer programs from the SD Memory Card.	BOOL	TRUE or FALSE	page A-133
DirName	Directory Name	Use this variable to specify the directory name in the SD Memory Card in which the backup file to be transferred is stored.	STRING(64)	Depends on data type.	page A-133

Variable name Member name	Meaning	Function	Data type	Range of values	Reference
Password	Password	Use this variable to specify the password that is used for verification when you start transferring the programs.	STRING(33)	Depends on data type.	page A-134
		The password is initialized every time you start transferring programs from the SD Memory Card.			
TargetUserPro- gram	User Program and Settings Transfer Flag	Change this variable to TRUE to set a user program or setting as the transfer target. Always set this variable to TRUE for transfer-	BOOL	TRUE or FALSE	page A-134
		ring programs from SD Memory Card.			
TargetIPAdr	IP Address Transfer Flag	Change this variable to TRUE to include the IP address of the built-in EtherNet/IP port as the transfer target.	BOOL	TRUE or FALSE	page A-134
		The IP address means setting type, IP address, subnet mask, and default gateway.			
TargetVariable	Present Values of Variables with the Retain Attribute Transfer Flag	Change this variable to TRUE to set the present values of variables with the Retain attribute as the transfer target.	BOOL	TRUE or FALSE	page A-134
TargetMemory	Present Values of Memory Used for CJ-series Units with the Retain Attribute Trans- fer Flag	Change this variable to TRUE to set the present values of the memory used for CJ-series Units with the Retain attribute as the transfer target.	BOOL	TRUE or FALSE	page A-135
Card1PrgTransfer- a (Ver.1.11)	SD Memory Card Program Trans- fer Status		_sPRG- TRANS- FER_STA		page A-135
Done	Done Flag	TRUE when a program transfer is completed.	BOOL	TRUE or FALSE	page A-135
Active	Active Flag	TRUE when a program transfer is in progress.	BOOL	TRUE or FALSE	page A-135
Err	Error Flag	TRUE when a program transfer ended in an error.	BOOL	TRUE or FALSE	page A-135
Card1RestoreCmd er.1.14)	SD Memory Card Restore Com- mand		_sRE- STORE_CM D		page A-135
Exec	Execute Restore Flag	Change this variable to TRUE to restore the data in a backup file on the SD Memory Card to the Controller.	BOOL	TRUE or FALSE	page A-135
DirName	Directory Name	Use this variable to specify the directory name in the SD Memory Card in which the backup file to be restored by the system-defined variable is stored.	STRING(64)	Depends on data type.	page A-136
Password	Password	Use this variable to specify the password that is used for verification when you start the restore by the system-defined variable. The password is initialized every time when the restore by the system-defined variable is	STRING(33)	Depends on data type.	page A-136
		started.			

Variable name Member name	- Meaning	Function	Data type	Range of values	Reference
_Card1RestoreSta (Ver.1.14)	SD Memory Card Restore Status		_sRE- STORE_ST A		page A-136
Done	Done Flag	TRUE when a restore operation is completed.	BOOL	TRUE or FALSE	page A-136
Active	Active Flag	TRUE when a restore operation is in progress.	BOOL	TRUE or FALSE	page A-136
Err	Error Flag	TRUE when a restore operation ended in an error.	BOOL	TRUE or FALSE	page A-136

Variable name	Meaning	Function	Data type	Range of values	Reference
_Card1RestoreCmd- TargetUserProgram (Ver.1.14)	User Program and Settings Transfer Flag	Change this variable to TRUE to set a user program or setting for the restore by the system-defined variable as the transfer target.	BOOL	TRUE or FALSE	page A-137
		Always set this variable to TRURE for the restore by the system-defined variable.			
_Card1RestoreCmd- TargetIPAdr (Ver.1.14)	IP Address Transfer Flag	Change this variable to TRUE to include the IP address of the built-in EtherNet/IP port for the restore by the system-defined variable as the transfer target.	BOOL	TRUE or FALSE	page A-137
		The IP address means setting type, IP address, subnet mask, and default gateway.			
_Card1RestoreCmd- TargetVariable (Ver.1.14)	Present Values of Variables with the Retain Attribute	Change this variable to TRUE to set the present values of variables with the Retain attribute for the restore by the system-defined	BOOL	TRUE or FALSE	page A-137
_Card1RestoreCmd- TargetMemory (Ver.1.14)	Present Values of Memory Used for CJ-series Units with the Retain Attribute Trans- fer Flag	variable as the transfer target. Change this variable to TRUE to set the present values of the memory used for CJ-series Units with the Retain attribute for the restore by the system-defined variable as the transfer target.	BOOL	TRUE or FALSE	page A-137
_Card1RestoreCmd- TargetUnitConfig (Ver.1.14)	Unit and Slave Parameters Transfer Flag	Change this variable to TRUE to set the Unit and slave settings for the restore by the system-defined variable as the transfer target.	BOOL	TRUE or FALSE	page A-138
_Card1RestoreCmd- TargetAbsEncoder (Ver.1.14)	Absolute Encoder Home Offset Transfer Flag	Change this variable to TRUE to set the absolute encoder home offset for the restore by the system-defined variable as the transfer target.	BOOL	TRUE or FALSE	page A-138

• Functional Classification: Backup

Variable name	Meaning	Function	Data type	Range of values	Reference
_BackupBusy (Ver. 1.03)	Backup Function Busy Flag	TRUE when a backup, restoration, or verification is in progress.	BOOL	TRUE or FALSE	page A-138

• Functional Classification: Power Supply

Variable name	Meaning	Function	Data type	Range of values	Reference
_PowerOnHour	Total Power ON Time	Contains the total time that the power has been ON.	UDINT	0 to 4294967295	page A-138
		Contains the total time that the CPU Unit has been ON in 1-hour increments.			
		To reset this value, overwrite the current value with 0.			
		The value is not updated after it reaches 4294967295.			
		This variable is not initialized at startup.			
_PowerOnCount	Power Interruption Count	Contains the number of times that the power supply has been interrupted. The value is incremented by 1 each time the power supply is interrupted after the first time that the power was turned ON.	UDINT	0 to 4294967295	page A-139
		To reset this value, overwrite the current value with 0.			
		The value is not updated after it reaches 4294967295.			
		This variable is not initialized at startup.			
_RetainFail	Retention Failure Flag	TRUE at the following time (failure of retention during power interruptions).	BOOL	TRUE or FALSE	page A-139
		When an error is detected in the battery- backup memory check at startup.			
		FALSE at the following times (no failure of retention during power interruptions).			
		When no error is detected in the battery- backup memory check at startup.			
		When the user program is downloaded.			
		When the Clear All Memory operation is performed.			
		Note When the encoder home offset data is not retained, the status is given in the error status of the axis variable, and not in this flag.			

• Functional Classification: Programming

Variable name	Meaning	Function	Data type	Range of values	Reference
P_On	Always TRUE Flag	This flag is always TRUE.	BOOL	TRUE	page A-139
P_Off	Always FALSE Flag	This flag is always FALSE.	BOOL	FALSE	page A-139
P_CY	Carry Flag	This flag is updated by some instructions.	BOOL	TRUE or FALSE	page A-139
P_First_RunMode	First RUN Period Flag	This flag is TRUE for only one task period after the operating mode of the CPU Unit is changed from PROGRAM mode to RUN mode if execution of the program is in progress. This flag remains FALSE if execution of the program is not in progress.	BOOL	TRUE or FALSE	page A-140
		When the CPU Unit begins operation. Note You cannot use this system-defined			
P_First_Run (Ver.1.08)	First Program Period Flag	variable inside functions. This flag is TRUE for one task period after execution of the program starts. Use this flag to perform initial processing when execution of a program starts. Note You cannot use this system-defined	BOOL	TRUE or FALSE	page A-140
P_PRGER	Instruction Error Flag	variable inside functions. This flag changes to and remains TRUE when an instruction error occurs in the program or in a function/function block called from the program. After this flag changes to TRUE, it stays TRUE until the user program changes it back to FALSE.	BOOL	TRUE or FALSE	page A-140

• Functional Classification: Communications

Variable name	Meaning	Function	Data type	Range of values	Reference
_Port_numUsingPort	Number of Used Ports	Gives the number of internal logical ports that are currently used. You can use this variable when you debug the user program. Note You can use this system-defined variable only for NJ-series CPU Units.	USINT	0 to 32	page A-140
_Port_isAvailable	Network Commu- nications Instruc- tion Enabled Flag	Indicates whether there is an available internal logical port. TRUE when an internal logical port is available. Otherwise FALSE. Note You can use this system-defined variable only for NJ-series CPU Units.	BOOL	FALSE or TRUE	page A-141
_FINSTCPConnSta	FINS/TCP Connection Status	Gives the FINS/TCP connection status. Note You can use this system-defined variable only for NJ-series CPU Units.	WORD	16#0000 to 16#FFFF	page A-141

• Functional Classification: Version

Variable name	Meaning	Function	Data type	Range of values	Reference	
_UnitVersion	Unit Version	Contains the unit version of the CPU Unit.	ARRAY[01]	0 to 99	page A-141	
(Ver.1.08)		The integer part of the unit version is stored in element number 0.	OF USINT	OF USINT		
		The fractional part of the unit version is stored in element number 1.				
		Example 1) If the unit version is 1.08, "1" is stored in element number 0 and "8" is stored in element number 1.				
		Example 2) If the unit version is 1.10, "1" is stored in element number 0 and "10" is stored in element number 1.				
_HardwareRevision (Ver.1.11)	Hardware Revision	Contains the hardware revision of the CPU Unit.	STRING[2]	- or A to Z	page A-141	
		Contains - if the hardware revision is in blank, and A to Z for other cases.				

• Functional Classification: Self-diagnosis

Variable name	Meaning	Function	Data type	Range of values	Reference
_SelfTest_HighTem- perature (Ver.1.10)	CPU Unit High Tem- perature Flag	TRUE when the internal temperature of the CPU Unit is too high. Note Always FALSE for the NX102 CPU Unit and NX1P2 CPU Unit.	BOOL	TRUE or FALSE	page A-142
_SelfTest_LowBattery (Ver.1.10)	Low Battery Flag	TRUE when the battery is disconnected or the battery voltage is dropped.	BOOL	TRUE or FALSE	page A-142
_SelfTest_LowFan- Revolution (Ver.1.10)	Low FAN Revolution Flag	TRUE when the fan is disconnected or the rotation speed of a fan is decreased. Note Always FALSE for the NX102 CPU Unit, NX1P2 CPU Unit, and NJ-series CPU Unit.	BOOL	TRUE or FALSE	page A-142

• Functional Classification: PLC Built-in

Variable name	Meaning	Function	Data type	Range of values	Reference
_DeviceOutHoldCfg (Ver.1.13)	Device Output Hold Configuration	It is 16#A5A5 if you retain the target device output when the operating mode is changed or when downloaded.	BOOL	16#0000 to 16#FFFF	page A-142
		In the case other than 16#A5A5, the target device output is initialized when the operating mode is changed or when downloaded.			
_DeviceOutHoldSta- tus (Ver.1.13)	Device Output Hold Status	It is TRUE if the target device output is retained when the operating mode is changed or when downloaded.	BOOL	TRUE or FALSE	page A-142
		When the device output hold configuration is other than 16#A5A5, or when a major fault level Controller error occurs, the target device output is initialized and changes to FALSE.			

A-6-2 PLC Function Module, Category Name: _PLC

• Functional Classification: Debugging

Variable name Member	Meaning	Function	Data type	Range of values	Reference
_PLC_TraceSta[03]			_sTRACE_ STA		page A-143
.lsStart	Trace Busy Flag	Note You cannot use this system-defined variable in the user program. It is used only to monitor the status of data tracing from the Sysmac Studio.	BOOL	TRUE or FALSE	page A-143
.IsComplete	Trace Completed Flag	Note You cannot use this system-defined variable in the user program. It is used only to monitor the status of data tracing from the Sysmac Studio.	BOOL	TRUE or FALSE	page A-143
.lsTrigger	Trace Trigger Monitor Flag	TRUE when the trigger condition is met. FALSE when the next trace starts. Note You cannot use this system-defined variable in the user program. It is used only to monitor the status of data tracing from the Sysmac Studio.	BOOL	TRUE or FALSE	page A-143
.ParamErr	Trace Parameter Error Flag	TRUE when a trace starts, but there is an error in the trace settings. FALSE when the settings are normal. Note You cannot use this system-defined variable in the user program. It is used only to monitor the status of data tracing from the Sysmac Studio.	BOOL	TRUE or FALSE	page A-144

• Functional Classification: Errors

Variable name	Meaning	Function	Data type	Range of values	Reference
_PLC_ErrSta	PLC Function Module Error Sta-	TRUE when there is a Controller error that involves the PLC Function Module.	WORD	16#0000 to 16#00F0	page A-144
	tus	FALSE when there is no Controller error that involves the PLC Function Module. Refer to information on the meanings of the error status bits at the end of this appendix for details.			

• Functional Classification: Option Boards

Variable name Member	Meaning	Function	Data type	Range of values	Reference
_PLC_OptBoardSta (Ver.1.13)	Option Board Status	Contains the status of Option Boards. This variable is commonly used regardless of the models of Option Boards. The array element 1 corresponds to the option board slot 1 and array element 2 corresponds to the option board slot 2. Note You can use this system-defined vari-	ARRAY[02] OF _sOPT- BOARD_S TA		page A-144
isDetect	Option Board Mounted	able only for the NX1P2 CPU Units. Indicates an Option Board is mounted to the option board slot. TRUE: Mounted. FALSE: Not mounted. Note You can use this system-defined variable or by face the NX1P2 CPU Units.	BOOL	TRUE or FALSE	page A-144
Run	Option Board Normal Opera- tion	able only for the NX1P2 CPU Units. Indicates whether an Option Board is normally operating. To use device variables or communications instructions for an Option Board, program this member as an interlock condition in the user program. TRUE: Normally operating. FALSE: Initializing, changing settings, or an error occurred. Note You can use this system-defined variable only for the NX1P2 CPU Units.	BOOL	TRUE or FALSE	page A-145
Error	Option Board Error	Indicates whether an Option Board error occurred. TRUE: An error occurred. FALSE: An error not occurred. Note You can use this system-defined variable only for the NX1P2 CPU Units.	BOOL	TRUE or FALSE	page A-145
_PLC_OptSeri- alErrSta (Ver.1.13)	Serial Option Board Error Sta- tus	Contains the error status of an transmission error for the Serial Communications Option Board. When the Serial communications mode of an Serial Communications Option Board is only set to Host Link (FINS), the value of each member is updated. Other than the above setting, the values of all members are FALSE. The array element 1 corresponds to the option board slot 1 and array element 2 corresponds to the option board slot 1 and array element 2 corresponds to the option board slot 2. Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI. Note You can use this system-defined variable only for the NX1P2 CPU Units.	ARRAY[02] OF _sOPTSE-RIALER-R_STA		page A-146

Variable name Member	- Meaning	Function	Data type	Range of values	Reference
Error	Transmission Error	Indicates whether a transmission error occurred.	BOOL	TRUE or FALSE	page A-146
		TRUE: A parity error, framing error, or an overrun error occurred.			
		FALSE: FALSE due to one of the following causes.			
		A parity error, framing error, or an overrun error not occurred.			
		A port is restarted.			
		The Serial communications mode is not set to Host Link (FINS).			
		The Option Board that is mounted is not a Serial Communications Option Board.			
		The Option Board is not mounted.			
		Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI.			
		Note You can use this system-defined variable only for the NX1P2 CPU Units.			

Variable name	Maryly	Function	Dete t	Range of	Deference
Member	- Meaning	Function	Data type	values	Reference
ParityErr	Parity Error	Indicates whether a parity error occurred. If this error occurs, it means that the serial communications settings may not apply to the remote device to connect.	BOOL	TRUE or FALSE	page A-146
		TRUE: A parity error occurred.			
		FALSE: FALSE due to one of the following causes.			
		A parity error not occurred.			
		A port is restarted.			
		The Serial communications mode is not set to Host Link (FINS).			
		The Option Board that is mounted is not a Serial Communications Option Board.			
		The Option Board is not mounted.			
		Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI.			
		Note You can use this system-defined variable only for the NX1P2 CPU Units.			
FramingErr	Framing Error	Indicates whether a framing error occurred. If this error occurs, it means that the serial communications settings may not apply to the remote device to connect.	BOOL	TRUE or FALSE	page A-147
		TRUE: A framing error occurred.			
		FALSE: FALSE due to one of the following causes.			
		A framing error not occurred.			
		A port is restarted.			
		The Serial communications mode is not set to Host Link (FINS).			
		The Option Board that is mounted is not a Serial Communications Option Board.			
		The Option Board is not mounted.			
		Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI.			
		Note You can use this system-defined variable only for the NX1P2 CPU Units.			

Variable name	Meaning	Function	Data type	Range of	Reference
Member	Meaning	1 unction	Data type	values	Kelefelice
OverRun	Overrun Error	Indicates whether an overrun error occurred. If this error occurs, it means that the baud rate of an Option Board may be too large. TRUE: An overrun error occurred. FALSE: FALSE due to one of the following causes. • An overrun error not occurred. • A port was restarted. • The Serial communications mode is not set	BOOL	TRUE or FALSE	page A-147
		to Host Link (FINS). The Option Board that is mounted is not a Serial Communications Option Board. The Option Board is not mounted. Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI. Note You can use this system-defined variable only for the NX1P2 CPU Units.			

• Functional Classification: Safety Data Logging

	Variable name Member	Meaning	Function	Data type	Range of values	Reference
_PLC_SFLogSta (Ver.1.31)		Safety Data Log- ging Status	Stores the status of safety data logging. Element number 0 corresponds to Logging Setting Number 1. Element number 1 corresponds to Logging Setting Number 2. Note You can use this system-defined variable only for the NX102 CPU Units.	ARRAY[01] OF _sS- FLOG_STA		page A-148
	.lsStart	Safety Data Log- ging Busy Flag	TRUE when safety data logging starts. Note You can use this system-defined variable only for the NX102 CPU Units.	BOOL	TRUE or FALSE	page A-148
	.lsComplete	Safety Data Log- ging Completed Flag	TRUE when logging stops. FALSE when the next logging starts. When this flag is TRUE, it means that the logging has completed. Note You can use this system-defined variable only for the NX102 CPU Units.	BOOL	TRUE or FALSE	page A-148
	.lsOutput	Log File Output Completed Flag	TRUE when the log file is output. FALSE when the next logging starts. Note You can use this system-defined variable only for the NX102 CPU Units.	BOOL	TRUE or FALSE	page A-148

A-6-3 PLC Function Module, Category Name: _CJB

• Functional Classification: I/O Bus Status

Variable name	Meaning	Function	Data type	Range of values	Reference
_CJB_MaxRackNo	Largest Rack Number	Contains the largest rack number of the Expansion Racks that are detected by the Controller. Note You can use this system-defined variable only for NJ-series CPU Units.	UINT	0 to 3 0: Only CPU Rack.	page A-149
_CJB_MaxSlotNo	Largest Slot Number	Contains one higher than the largest slot number with a CJ-series Unit on each of the Racks that are detected by the Controller. Note You can use this system-defined variable only for NJ-series CPU Units.	ARRAY [03] OF UINT	0 to 10 0: No CJ- series Unit mounted.	page A-149

• Functional Classification: I/O Bus Errors

Variable name	Meaning	Function	Data type	Range of values	Reference
_CJB_ErrSta	I/O Bus Error Status	Note Do not use this variable in the user program. There may be a delay in updating it. Use this variable only to access status through communications from an external device. Refer to information on the meanings of the error status bits at the end of this appendix for details. Note You can use this system-defined variable only for NJ-series CPU Units.	WORD	16#0000 to 16#C0F0	page A-149
_CJB_MstrErrSta	I/O Bus Master Error Status	Note Do not use this variable in the user program. There may be a delay in updating it. Use this variable only to access status through communications from an external device. Refer to information on the meanings of the error status bits at the end of this appendix for details. Note You can use this system-defined variable only for NJ-series CPU Units.	WORD	16#0000 to 16#00F0	page A-150
_CJB_UnitErrSta	I/O Bus Unit Error Status	Gives the error status of the I/O Bus Unit. Note Do not use this variable in the user program. There may be a delay in updating it. Use this variable only to access status through communications from an external device. Refer to information on the meanings of the error status bits at the end of this appendix for details. Note You can use this system-defined variable only for NJ-series CPU Units.	ARRAY [03, 09] OF WORD	16#0000 to 16#80F0	page A-150
_CJB_InRespTm	Basic Input Unit Input Response Times	Contains the response times of the Basic Input Units. Note You can use this system-defined variable only for NJ-series CPU Units.	ARRAY [03, 09] OF UNIT	0 to 320	page A-150

• Functional Classification: Auxiliary Area Bits for CJ-series Units

Variable name	Meaning	Function	Data type	Range of values	Reference
_CJB_IOUnitInfo	Basic I/O Unit Information	Shows the status of the Basic I/O Unit alarm output (load short-circuit protection). TRUE: Load short-circuit FALSE: No load short-circuit	ARRAY [03, 09, 07] OF BOOL	TRUE or FALSE	page A-151
		Note You can use this system-defined variable only for NJ-series CPU Units.			
_CJB_CBU00InitSta to	CPU Bus Unit Initializing Flags	The corresponding variable is TRUE during initialization of the CPU Bus Unit.	BOOL	TRUE or FALSE	page A-151
_CJB_CBU15InitSta		The corresponding variable changes to FALSE when the initialization is completed.			
		The numbers in the variables indicate the unit numbers of the applicable Units.			
		Note You can use this system-defined variable only for NJ-series CPU Units.			
_CJB_SIO00InitSta to	Special I/O Unit Initializing Flags	The corresponding variable is TRUE during initialization of the Special I/O Unit.	BOOL	TRUE or FALSE	page A-151
_CJB_SIO95InitSta		The corresponding variable changes to FALSE when the initialization is completed.			
		The numbers in the variables indicate the unit numbers of the applicable Units.			
		Note You can use this system-defined variable only for NJ-series CPU Units.			
_CJB_CBU00Restart to _CJB_CBU15Restart	CPU Bus Unit Restart Bits	The CPU Bus Unit is restarted when the corresponding variable changes to TRUE. (It is changed to FALSE by the system after the CPU Bus Unit is restarted.)	BOOL	TRUE or FALSE	page A-152
		The numbers in the variables indicate the unit numbers of the applicable Units.			
		If you change the Restart Flag to TRUE with an instruction, the restart process begins from refresh processing in the next task period.			
		Note You can use this system-defined variable only for NJ-series CPU Units.			
_CJB_SIO00Restart to _CJB_SIO95Restart	Special I/O Unit Restart Bits	The Special I/O Unit is restarted when the corresponding variable changes to TRUE. (It is changed to FALSE by the system after the Special I/O Unit is restarted.)	BOOL	TRUE or FALSE	page A-152
		The numbers in the variables indicate the unit numbers of the applicable Units.			
		If you change the Restart Flag to TRUE with an instruction, the restart process begins from refresh processing in the next task period.			
		Note You can use this system-defined variable only for NJ-series CPU Units.			
_CJB_SCU00P1ChgSta to	Serial Communications Unit 0,	TRUE when the parameters of the specified port are being changed.	BOOL	TRUE or FALSE	page A-153
_CJB_SCU00P2ChgSta	Port 1/2 Settings Changing Flags	FALSE after the parameters are changed. It is also possible for the user to indicate a			
_CJB_SCU15P1ChgSta to	Serial Communications Units 1 to 15, Port 1/2 Set-	change in serial port settings by turning ON the corresponding flag through the execution of an instruction or a user operation.	BOOL	TRUE or FALSE	page A-153
_CJB_SCU15P2ChgSta	tings Changing Flags	Note You can use this system-defined variable only for NJ-series CPU Units.			

A-6-4 NX Bus Function Module, Category Name: _NXB

• Functional Classification: NX Bus Function Module Status

Variable name	Meaning	Function	Data type	Range of values	Reference
_NXB_MaxUnitNo (Ver.1.13)	Largest Unit Number	Contains the largest NX Unit number of the NX Units on the CPU Unit that are detected by the NX Bus Function Module. If the Unit configuration information is registered by the Sysmac Studio, the value will be largest NX Unit number of the registered Unit configuration. Units that are set as unmounted Units are also included. If the Unit configuration information is not registered by the Sysmac Studio, the value will be the largest Unit number of an actual Unit configuration. Note You can use this system-defined vari-	UINT	0 to 32*1 0: No NX Unit mounted.	page A-154
_NXB_UnitIOAc- tiveTbl (Ver.1.13)	NX Unit I/O Data Active Status	able only for the NX102 CPU Units and NX1P2 CPU Units. Indicates whether I/O data in the NX Units on the CPU Unit is valid. This status is given as an array of BOOL data. The subscript of the array corresponds to the NX Unit number. A subscript of 0 indicates the NX Bus Function Module and it is always TRUE. TRUE: The I/O data in the NX Unit is valid. FALSE: The I/O data in the NX Unit is invalid. The status is FALSE for NX Units that are set as unmounted Units. Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.	ARRAY [032] OF BOOL*2	TRUE or FALSE	page A-154
_NXB_UnitMsgAc- tiveTbl (Ver.1.13)	NX Unit Mes- sage Enabled Status	Indicates whether the NX Units on the CPU Unit can process message communications. This status is given as an array of BOOL data. The subscript of the array corresponds to the NX Unit number. A subscript of 0 indicates the NX Bus Function Module and it is always TRUE. TRUE: Message communications possible. FALSE: Message communications not possible. The status is FALSE for NX Units that are set as unmounted Units. Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.	ARRAY [032] OF BOOL*2	TRUE or FALSE	page A-154

Variable name	Meaning	Function	Data type	Range of values	Reference
_NXB_UnitRegTbl (Ver.1.13)	NX Unit Registration Status	Indicates whether the NX Units on the CPU Unit are registered in the Unit configuration. This status is given as an array of BOOL data. The subscript of the array corresponds to the NX Unit number. A subscript of 0 indicates the NX Bus Function Module. TRUE: Registered. FALSE: Not registered. If the Unit configuration information is not registered by the Sysmac Studio, the status is FALSE for all Units. The status is TRUE for NX Units that are set as unmounted Units. Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.	ARRAY [032] OF BOOL*2	TRUE or FALSE	page A-155

• Functional Classification: NX Bus Function Module Errors

Variable name	Meaning	Function	Data type	Range of values	Reference
_NXB_ErrSta (Ver.1.13)	NX Bus Function Module Error Status	Gives the NX Bus Function Module error status. This system-defined variable provides the collective status of the NX Bus Function Module Master Error Status and NX Bus Function Module Unit Error Status for all NX Units.	WORD	16#0000 to 16#40F2	page A-155
		Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI. Refer to A-6-8 Meanings of Error Status Bits for the meaning of the error status bits.			
		Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.			
_NXB_MstrErrSta (Ver.1.13)	NX Bus Function Module Master Error Status	Gives the status of errors that are detected in the NX Bus Function Module of the CPU Unit.	WORD	16#0000 to 16#40F2	page A-155
		Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI. Refer to A-6-8 Meanings of Error Status Bits for the meaning of the error status bits.			
		Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.			

^{*1} For the NX1P2 CPU Units, the range of values is 0 to 8.
*2 For the NX1P2 CPU Units, the data type is ARRAY [0..8] OF BOOL.

Variable name	Meaning	Function	Data type	Range of values	Reference
_NXB_UnitErrStaTbl (Ver.1.13)	NX Bus Function Module Unit Error Status	detected in the NX Unit on the CPU Unit. [ARRAY [032] OF WORD *1*2	16#0000 to 16#40F2	page A-156
		Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI. Refer to A-6-8 Meanings of Error Status Bits for the meaning of the error status bits.			
		Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.			
_NXB_UnitErrFlagTbl (Ver.1.13)	NX Unit Error Status	Indicates whether errors occurred in the NX Unit on the CPU Unit.	ARRAY [032] OF	TRUE or FALSE	page A-156
(vel.1.13)		This status is given as an array of BOOL data. The subscript of the array corresponds to the NX Unit number. A subscript of 0 indicates the NX Bus Function Module and whether an event occurred that is detected by the NX Bus Function Module.	BOOL*1		
		TRUE: Error.			
		FALSE: No error. The status is FALSE for NX Units that are set as unmounted Units.			
		Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.			

^{*1} For the NX1P2 CPU Units, the data type is ARRAY [0..8] OF BOOL.

^{*2} For the NX1P2 CPU Units, the data type is ARRAY [0..8] OF WORD.

A-6-5 Motion Control Function Module, Category Name: _MC

• Functional Classification: Motion Control Functions

Variable name	Meaning	Function	Data type	Range of values	Reference
_MC_ErrSta	Motion Control Function Module Error Status	Shows the status of errors that are detected in the Motion Control Function Module.	WORD	16#0000 to 16#40F0	page A-157
		You can use this variable directly in the user program.			
		Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_MC_ComErrSta	Common Error Status	Shows the status of errors that are detected in common processing for motion control.	WORD	16#0000 to 16#00F0	page A-157
		You can use this variable directly in the user program.			
		Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_MC_AX_ErrSta	Axis Error Status	Shows the error status for each axis. The status of up to 256 axes ^{*1} is shown.	ARRAY [0255] OF	16#0000 to 16#00F0	page A-157
		You can use this variable directly in the user program. Refer to information on the meanings of the error status bits at the end of this appendix for details.	WORD*1		
_MC_GRP_ErrSta	Axes Group Error Status	Shows the error status for each axes group. The error status for up to 64 axes groups ^{*2} is shown.	ARRAY [063] OF WORD*2	16#0000 to 16#00F0	page A-157
		You can use this variable directly in the user program. Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_MC_COM	Common Variable	Shows the status that is common to the Motion Control Function Module.	_sCOM- MON_REF		page A-158
		Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.			
_MC_GRP	Axes Group Variables	NX701 CPU Units: Used to specify axes groups and shows multi-axes coordinated control status, and multi-axes coordinated control settings for motion control instructions used for motion control 1.	ARRAY[063] OF _sGROUP_R EF ^{*3}		page A-158
		NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units: Used to specify axes groups and shows multi-axes coordinated control status, and multi-axes coordinated control settings for motion control instructions.			
		When you create an axes group on the System Studio, a user-defined axes group variable with a different name is created.			
		Normally, you use an Axes Group Variable with a different name.			
		Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_MC1_GRP	Axes Group Variables	Used to specify axes groups and shows multi-axes coordinated control status, and multi-axes coordinated control settings for motion control instructions used for motion control 1.	ARRAY[063] OF _sGROUP_R EF		page A-158
		When you create an axes group on the System Studio, a user-defined axes group variable with a different name is created.			
		Normally, you use an Axes Group Variable with a different name.			
		Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.			
		Note You can use this system-defined variable only for the NX701 CPU Units. You can access the same values of _MC1_GRP and _MC_GRP if the array element numbers of them are the same.			
_MC2_GRP	Axes Group Variables	Used to specify axes groups and shows multi-axes coordinated control status, and multi-axes coordinated control settings for motion control instructions used for motion control 2.	ARRAY[063] OF _sGROUP_R EF		page A-159
		When you create an axes group on the System Studio, a user-defined axes group variable with a different name is created.			
		Normally, you use an Axes Group Variable with a different name.			
		Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.			
		Note You can use this system-defined variable only for the NX701 CPU Units.			
_MC_AX	Axis Variables	NX701 CPU Units: Used to specify axes and shows single-axis control status, and single-axis control settings for motion control instructions used for motion control 1.	ARRAY[025 5] OF _sAX- IS_REF*4		page A-159
		NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units: Used to specify axes and shows single-axis control status, and single-axis control settings for motion control instructions.			
		When you create an axis on the System Studio, a user-defined axis variable with a different name is created.			
		Normally, you use an Axis Variable with a different name.			
		Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_MC1_AX	Axis Variables	Used to specify axes and shows single- axis control status, and single-axis control settings for motion control instructions used for motion control 1.	ARRAY[025 5] OF _sAX- IS_REF		page A-159
		When you create an axis on the System Studio, a user-defined axis variable with a different name is created.			
		Normally, you use an Axis Variable with a different name.			
		Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.			
		Note You can use this system-defined variable only for the NX701 CPU Units. You can access the same values of _MC1_AX and _MC_AX if the array element numbers of them are the same.			
_MC2_AX	Axis Variables	Used to specify axes and shows single- axis control status, and single-axis control settings for motion control instructions used for motion control 2.	ARRAY[025 5] OF _sAX- IS_REF		page A-160
		When you create an axis on the System Studio, a user-defined axis variable with a different name is created.			
		Normally, you use an Axis Variable with a different name.			
		Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.			
		Note You can use this system-defined variable only for the NX701 CPU Units.			

^{*1} For the NX102 CPU Units and NX1P2 CPU Units, the error status of up to 16 axes is shown and the data type is ARRAY [0..15] OF WORD. For NJ-series CPU Units, the error status of up to 64 axes is shown and the data type is ARRAY [0..63] OF WORD.

^{*2} For the NX102 CPU Units and NX1P2 CPU Units, the error status of up to 8 axes groups is shown and the data type is ARRAY [0..7] OF WORD.

For NJ-series CPU Units, the error status of up to 32 axes groups is shown and the data type is ARRAY [0..31] OF WORD.

^{*3} For the NX102 CPU Units and NX1P2 CPU Units, the error status of up to 8 axes groups is shown and the data type is ARRAY [0..7] OF sGROUP REF.

For NJ-series CPU Units, the error status of up to 32 axes groups is shown and the data type is ARRAY [0..31] OF _sGROUP_REF.

^{*4} For the NX102 CPU Units and NX1P2 CPU Units, the error status of up to 16 axes is shown and the data type is ARRAY [0..15] OF _sAX-IS_RFF

For NJ-series CPU Units, the error status of up to 64 axes is shown and the data type is ARRAY [0..63] OF _sAXIS_REF.

A-6-6 EtherCAT Master Function Module, Category Name: _EC

• Functional Classification: EtherCAT Communications Errors

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_ErrSta	Built-in EtherCAT Error	This system-defined variable provides the collective status of errors in the EtherCAT Master Function Module.	WORD	16#0000 to 16#40F0	page A-161
		Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_EC_PortErr	Communications Port Error	This system-defined variable provides the collective status of errors in the communications ports for the EtherCAT master.	WORD	16#0000 to 16#00F0	page A-161
		Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_EC_MstrErr	Master Error	This system-defined variable provides the collective status of EtherCAT master errors and slave errors detected by the EtherCAT master.	WORD	16#0000 to 16#00F0	page A-161
		Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_EC_SlavErr	Slave Error	This system-defined variable provides the collective status of all the error status for EtherCAT slaves.	WORD	16#0000 to 16#00F0	page A-161
		Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_EC_SlavErrTbl	Slave Error Table	This system-defined variable gives the error status for each EtherCAT slave. The error status is given for each slave in the actual system configuration. This variable array indicates slaves in which there are errors. Status is provided for each Ethere.	ARRAY [1512] OF WORD*1	16#0000 to 16#00F0	page A-162
		erCAT slave node address (1 to 512)*1. Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_EC_MacAdrErr	MAC Address Error	TRUE if there is an illegal MAC address.	BOOL	TRUE or FALSE	page A-162
_EC_LanHwErr	Communications Controller Error	TRUE if there is a communications controller hardware error.	BOOL	TRUE or FALSE	page A-162
_EC_LinkOffErr	Link OFF Error	TRUE if the communications controller link is not established.	BOOL	TRUE or FALSE	page A-162
_EC_NetCfgErr	Network Configuration Information Error	TRUE if there is illegal network configuration information.	BOOL	TRUE or FALSE	page A-162
_EC_NetCfgCmpErr	Network Configuration Verifi- cation Error	TRUE if the network configuration information does not match the actual network configuration.	BOOL	TRUE or FALSE	page A-163
_EC_NetTopologyErr	Network Configuration Error	TRUE if there is a network configuration error (too many devices connected or ring connection).	BOOL	TRUE or FALSE	page A-163
_EC_PDCommErr	Process Data Communications Error	TRUE if there is an unexpected slave disconnection or connection or if a slave WDT error is detected during process data communications.	BOOL	TRUE or FALSE	page A-163
_EC_PDTimeoutErr	Process Data Reception Timeout Error	TRUE if a timeout occurs while receiving process data.	BOOL	TRUE or FALSE	page A-163

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_PDSendErr	Process Data Trans- mission Error	TRUE if there is a process data transmission error (cannot send within the process data communications cycle or transmission jitter is over the limit).	BOOL	TRUE or FALSE	page A-163
_EC_SlavAdrDupErr	Slave Node Address Duplicated Error	TRUE if the same node address is set for more than one slave.	BOOL	TRUE or FALSE	page A-163
_EC_SlavInitErr	Slave Initialization Error	TRUE if there is an error in an initialization command addressed to a slave.	BOOL	TRUE or FALSE	page A-164
_EC_SlavAppErr	Slave Application Error	TRUE if there is an error in the slave's application status register.	BOOL	TRUE or FALSE	page A-164
_EC_MsgErr	EtherCAT Message Error	TRUE when a message is sent to a slave that does not support messages or when there is an error in the format of the response to a message that was sent to a slave.	BOOL	TRUE or FALSE	page A-164
_EC_SlavEmergErr	Emergency Message Detected	TRUE if the master detects an emergency message that was sent by a slave.	BOOL	TRUE or FALSE	page A-164
_EC_IndataInvalidErr (Ver.1.13)	Input Process Data Invalid Error	TRUE if the Input Data Invalid state continued for the following period because the EtherCAT master could not perform process data communications normally when it was in the Operational state.	BOOL	TRUE or FALSE	page A-164
		When the task period is 10 ms or shorter: 100 ms When the task period is longer than 10 ms: 10 periods o the task			
_EC_CommErrTbl	Communications Error Slave Table	Slaves are given in the table in the order of slave node addresses. The corresponding slave element is TRUE if the master detected an error for the slave.	ARRAY [1512] OF BOOL*2	TRUE or FALSE	page A-165
_EC_CycleExceeded	EtherCAT Communications Cycle Exceeded	TRUE if the CPU Unit cannot establish communications within the set communications period at startup.	BOOL	TRUE or FALSE	page A-165
		Note You can use this system-defined variable only for NX-series CPU Units.			

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the node address is 1 to 192 and the data type is ARRAY [1..192] OF WORD.

^{*2} For NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.



Additional Information

Typical Relationships for the Built-in EtherCAT Error Flags

Variable Name	Meaning	Variable Name	Meaning	Variable Name	Meaning	Event level
_EC_ErrSta	Built-in	_EC_PortErr	Communi-	_EC_MacAdrErr	MAC Address Error	Partial fault
	EtherCAT Error		cations Port Error	_EC_LanHwErr	Communications Controller Error	level
				_EC_LinkOffErr	Link OFF Error	
		_EC_MstrErr	Master Error	_EC_NetCfgErr	Network Configura- tion Information Error	Minor fault level
				_EC_NetCfgCmpErr	Network Configura- tion Verification Error	
				_EC_NetTopologyErr	Network Configura- tion Error	
				_EC_PDCommErr	Process Data Com- munications Error	
				_EC_PDTimeoutErr	Process Data Reception Timeout Error	
				_EC_PDSendErr	Process Data Trans- mission Error	
				_EC_SlavAdrDupErr	Slave Node Address Duplicated Error	
				_EC_SlavInitErr	Slave Initialization Error	
				_EC_SlavAppErr	Slave Application Error	
				_EC_CommErrTbl	Communications Error Slave Table	
				_EC_CycleExceeded	EtherCAT Communications Cycle Exceeded	
				_EC_MsgErr	EtherCAT Message Error	Observation
				_EC_SlavEmergErr	Emergency Message Detected	
		_EC_SlavErr	Slave Error	_EC_SlavErrTbl	Slave Error Table	Defined by the slave.

Note The values of all system-defined variables that are related to errors in EtherCAT communications do not change until the cause of the error is removed and then the error in the Controller is reset with the trouble-shooting functions of the Sysmac Studio or the ResetECError instruction.

• Functional Classification: EtherCAT Communications Status

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_RegSlavTbl	Registered Slave Table	This table indicates the slaves that are registered in the network configuration information. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if the corresponding slave is registered.		TRUE or FALSE	page A-165
_EC_EntrySlavTbl	Network Connected Slave Table	This table indicates which slaves are connected to the network. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if the corresponding slave has entered the network.	ARRAY [1512] OF BOOL*1	TRUE or FALSE	page A-165
_EC_MBXSlavTbl	Message Communications Enabled Slave Table	This table indicates the slaves that can perform message communications. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if mes-	ARRAY [1512] OF BOOL*1	TRUE or FALSE	page A-166
		sage communications are enabled for it (pre-operational, safe-operation, or operational state).			
		Note Use this variable to confirm that message communications are possible for the relevant slave before you execute message communications with an EtherCAT slave.			
_EC_PDSlavTbl	Process Data Communicating Slave Table	This table indicates the slaves that are performing process data communications. Slaves are given in the table in the order of slave node addresses.	ARRAY [1512] OF BOOL*1	TRUE or FALSE	page A-166
		The element for a slave is TRUE if process data of the corresponding slave is enabled (operational) for both slave inputs and outputs.			
		Note Use this variable to confirm that the data for the relevant slave is valid before controlling an EtherCAT slave.			
_EC_DisconnSlavTbl	Disconnected Slave Table	Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if the	ARRAY [1512] OF BOOL*1	TRUE or FALSE	page A-166
_EC_DisableSlavTbl	Disabled Slave Table	corresponding slave was disconnected. Slaves are given in the table in the order	ARRAY	TRUE or	page A-167
_LO_DISABICGIAVTSI	Disabled Glave Table	of slave node addresses. The element for a slave is TRUE if the	[1512] OF BOOL*1	FALSE	page A-107
_EC_PDActive	Process Data Com-	corresponding slave is disabled. TRUE when process data communica-	BOOL	TRUE or	page A-167
	munications Status	tions are performed with all slaves*. * Disabled slaves are not included.		FALSE	
_EC_PktMonStop	Packet Monitoring Stopped	TRUE when packet monitoring is stopped.	BOOL	TRUE or FALSE	page A-167
_EC_LinkStatus	Link Status	TRUE if the communications controller link status is Link ON.	BOOL	TRUE or FALSE	page A-167
_EC_PktSaving	Saving Packet Data File	Shows whether a packet data file is being saved.	BOOL	TRUE or FALSE	page A-167
		TRUE: Packet data file being saved. FALSE: Packet data file not being saved.			
_EC_InDataInvalid	Input Data Invalid	TRUE when process data communications performed in the primary periodic task are not normal and the input data is not valid.	BOOL	TRUE or FALSE	page A-168

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_InData1Invalid	Input Data1 Invalid	TRUE when process data communications performed in the primary periodic task are not normal and the input data is not valid.	BOOL	TRUE or FALSE	page A-168
		Note You can use this system-defined variable only for NX-series CPU Units.			
_EC_InData2Invalid	Input Data2 Invalid	TRUE when process data communications performed in the priority-5 periodic task are not normal and the input data is not valid.	BOOL	TRUE or FALSE	page A-168
		Note You can use this system-defined variable only for NX-series CPU Units.			
		Note This variable is always TRUE for the NX102 CPU Units and NX1P2 CPU Units.			

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.

Note All system-defined variables that are related to the status of EtherCAT communications give the current status.

Functional Classification: EtherCAT Communications Diagnosis/Statistics Log

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_StatisticsLogEnable	Diagnosis/Statistics Log Enable	Changes to TRUE when the diagnosis/statistics log is started.	BOOL	TRUE or FALSE	page A-169
(Ver.1.11)		Changes to FALSE when the diagnosis/statistics log is ended.			
_EC_StatisticsLogCy- cleSec (Ver.1.11)	Diagnosis/Statistics Log Cycle	Specifies the interval to write the diagnostic and statistical information of the diagnosis/statistics log in units of seconds.	UINT	0, or 30 to 1800	page A-169
,		When 0 is specified, the diagnostic and statistical information is written only once when the diagnosis/statistics log is ended.			
		Note The write interval does not change even if you change the value of this system-defined variable while the diagnosis/statistics log operation is in progress.			
_EC_StatisticsLog- Busy (Ver.1.11)	Diagnosis/Statistics Log Busy	TRUE while the diagnosis/statistics log operation is in progress.	BOOL	TRUE or FALSE	page A-169
_EC_StatisticsLogErr (Ver.1.11)	Diagnosis/Statistics Log Error	TRUE when the diagnosis/statistics log failed to start or it is impossible to write into the log.	BOOL	TRUE or FALSE	page A-169
		The value of this flag is determined when _EC_StatisticsLogBusy (Diagnosis/Statistics Log Busy) changes to FALSE after the diagnosis/statistics log operation is started.			
		The error end is caused by the following.			
		Another records cannot be added in the log file because the capacity of the SD Memory Card is fully used. The SD Memory Card is write protected.			
		The SD Memory Card is write protected. There is no SD Memory Card.			
		The function cannot be started because the value specified for _EC_Statis- ticsLogCycleSec (Diagnosis/Statistics Log Cycle) is invalid.			

A-6-7 EtherNet/IP Function Module, Category Name: _EIP

• Functional Classification: EtherNet/IP Communications Errors

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_ErrSta	Built-in EtherNet/IP Error	This is the error status variable for the built-in EtherNet/IP port.	WORD	16#0000 to 16#00F0	page A-170
		NX-series CPU Units: Represents the collective status of the following error flags.			
		_EIP1_PortErr (Communications Port1 Error)			
		_EIP2_PortErr (Communications Port2 Error)			
		_EIP1_CipErr (CIP Communications1 Error)			
		_EIP2_CipErr (CIP Communications2 Error)			
		_EIP_TcpAppErr (TCP Application Commu- nications Error)			
		NJ-series CPU Units: Represents the collective status of the following error flags.			
		_EIP_PortErr (Communications Port Error)			
		_EIP_CipErr (CIP Communications Error)			
		_EIP_TcpAppErr (TCP Application Communications Error)			
		Note Refer to information on the meanings of the error status bits at the end of this appendix for details.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_PortErr	Communications Port Error	This is the error status variable for the communications port. NX-series CPU Units: Represents the col-	WORD	16#0000 to 16#00F0	page A-170
		lective status of the following error flags.			
		_EIP1_MacAdrErr (Port1 MAC Address Error)			
		_EIP1_LanHwErr (Port1 Communications Controller Error)			
		_EIP1_EtnCfgErr (Port1 Basic Ethernet Set- ting Error)			
		_EIP1_IPAdrCfgErr (Port1 IP Address Set- ting Error)			
		_EIP1_IPAdrDupErr (Port1 IP Address Duplication Error)			
		_EIP1_BootpErr (Port1 BOOTP Server Error)			
		_EIP_DNSCfgErr (DNS Setting Error)			
		_EIP_DNSSrvErr (DNS Server Connection Error)			
		_EIP_IPRTblErr (IP Route Table Error)			
		NJ-series CPU Units: Represents the collective status of the following error flags.			
		_EIP_MacAdrErr (MAC Address Error)			
		_EIP_LanHwErr (Communications Controller Error)			
		_EIP_EtnCfgErr (Basic Ethernet Setting Error)			
		_EIP_IPAdrCfgErr (IP Address Setting Error)			
		_EIP_IPAdrDupErr (IP Address Duplication Error)			
		_EIP_BootpErr (BOOTP Server Error)			
		_EIP_IPRTblErr (IP Route Table Error)			
		Note If a Link OFF Detected or Built-in EtherNet/IP Processing Error occurs, it is recorded in the event log and then the corresponding bit turns ON. Refer to information on the meanings of the error status bits			
		at the end of this appendix for details.			

Variable name	Meaning	Function	Data type	Range of values	Reference
Variable name _EIP1_PortErr	Meaning Communications Port1 Error	This is the error status variable for the communications port. It represents the collective status of the following error flags. • _EIP1_MacAdrErr (Port1 MAC Address Error) • _EIP1_LanHwErr (Port1 Communications Controller Error) • _EIP1_EtnCfgErr (Port1 Basic Ethernet Setting Error) • _EIP1_IPAdrCfgErr (Port1 IP Address Setting Error) • _EIP1_IPAdrDupErr (Port1 IP Address Duplication Error) • _EIP1_BootpErr (Port1 BOOTP Server Error) • _EIP_DNSCfgErr (DNS Setting Error) • _EIP_DNSSrvErr (DNS Server Connection Error)	Data type WORD	_	Reference page A-170
		_EIP_IPRTblErr (IP Route Table Error) Note If a Link OFF Detected or Built-in EtherNet/IP Processing Error occurs, it is recorded in the event log and then the corresponding bit turns ON. Refer to information on the meanings of the error status bits at the end of this appendix for details. Note You can use this system-defined variable only for NX-series CPU Units.			
_EIP2_PortErr	Communications Port2 Error	This is the error status variable for the communications port. It represents the collective status of the following error flags. • _EIP2_MacAdrErr (Port2 MAC Address Error) • _EIP2_LanHwErr (Port2 Communications Controller Error) • _EIP2_EtnCfgErr (Port2 Basic Ethernet Setting Error) • _EIP2_IPAdrCfgErr (Port2 IP Address Setting Error) • _EIP2_IPAdrDupErr (Port2 IP Address Duplication Error) • _EIP2_BootpErr (Port2 BOOTP Server Error) • _EIP_DNSCfgErr (DNS Setting Error) • _EIP_DNSSrvErr (DNS Server Connection Error) • _EIP_IPRTbIErr (IP Route Table Error) Note If a Link OFF Detected or Built-in EtherNet/IP Processing Error occurs, it is recorded in the event log and then the corresponding bit turns ON. Refer to information on the meanings of the error status bits at the end of this appendix for details. Note You can use this system-defined variable only for the NX701 CPU	WORD	16#0000 to 16#00F0	page A-170

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_CipErr	CIP Communications Error	This is the error status variable for CIP communications. NX-series CPU Units: Represents the collective status of the following error flags. • _EIP1_IdentityErr (CIP Communications1 Identity Error) • _EIP1_TDLinkCfgErr (CIP Communications1 Tag Data Link Setting Error) • _EIP1_TDLinkOpnErr (CIP Communications1 Tag Data Link Connection Failed) • _EIP1_TDLinkErr (CIP Communications1 Tag Data Link Communications Error) • _EIP1_TagAdrErr (CIP Communications1 Tag Name Resolution Error) • _EIP1_MultiSwONErr (CIP Communications1 Multiple Switches ON Error) NJ-series CPU Units: Represents the collective status of the following error flags. • _EIP_IdentityErr (Identity Error) • _EIP_TDLinkCfgErr (Tag Data Link Setting Error) • _EIP_TDLinkOpnErr (Tag Data Link Communications Error) • _EIP_TDLinkErr (Tag Data Link Communications Error) • _EIP_TagAdrErr (Tag Name Resolution Error) • _EIP_MultiSwONErr (Multiple Switches ON Error)	WORD	16#0000 to 16#00F0	page A-172
		occurs, it is recorded in the event log and this variable changes to TRUE. Refer to information on the meanings of the error status bits at the end of this appendix for details.			
_EIP1_CipErr	CIP Communications1 Error	This is the error status variable for CIP communications 1. It represents the collective status of the following error flags. • _EIP1_IdentityErr (CIP Communications1 Identity Error) • _EIP1_TDLinkCfgErr (CIP Communications1 Tag Data Link Setting Error) • _EIP1_TDLinkOpnErr (CIP Communications1 Tag Data Link Connection Failed) • _EIP1_TDLinkErr (CIP Communications1 Tag Data Link Communications Error) • _EIP1_TagAdrErr (CIP Communications1 Tag Name Resolution Error) • _EIP1_MultiSwONErr (CIP Communications1 Multiple Switches ON Error) Note If a Tag Name Resolution Error occurs, it is recorded in the event log and this variable changes to TRUE. Refer to information on the meanings of the error status bits at the end of this appendix for details. Note You can use this system-defined variable only for NX-series CPU Units.	WORD	16#0000 to 16#00F0	page A-172

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP2_CipErr	CIP Communica- tions2 Error	This is the error status variable for CIP communications 2.	WORD	16#0000 to 16#00F0	page A-173
		It represents the collective status of the following error flags.			
		_EIP2_IdentityErr (CIP Communications2 Identity Error)			
		_EIP2_TDLinkCfgErr (CIP Communications2 Tag Data Link Setting Error)			
		_EIP2_TDLinkOpnErr (CIP Communications2 Tag Data Link Connection Failed)			
		_EIP2_TDLinkErr (CIP Communications2 Tag Data Link Communications Error)			
		_EIP2_TagAdrErr (CIP Communications2 Tag Name Resolution Error)			
		_EIP2_MultiSwONErr (CIP Communications2 Multiple Switches ON Error)			
		Note If a Tag Name Resolution Error occurs, it is recorded in the event			
		log and this variable changes to TRUE. Refer to information on the			
		meanings of the error status bits at the end of this appendix for details.			
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			
_EIP_TcpAppErr	TCP Application Communications Error	This is the error status variable for TCP application communications.	WORD	16#0000 to 16#00F0	page A-173
		It represents the collective status of the following error flags.			
		_EIP_TcpAppCfgErr (TCP Application Setting Error)			
		_EIP_NTPSrvErr (NTP Server Connection Error)			
		Note Refer to information on the meanings of the error status bits at the			
_EIP_MacAdrErr	MAC Address Error	end of this appendix for details. NX-series CPU Units: Indicates that an	BOOL	TRUE or	page A-173
		error occurred when the MAC address was read on the communications port 1 at startup.		FALSE	
		TRUE: Error			
		FALSE: Normal			
		NJ-series CPU Units: Indicates that an error occurred when the MAC address was read at startup.			
		TRUE: Error			
EIP1_MacAdrErr	Port1 MAC Address	FALSE: Normal Indicates that an error occurred when the	BOOL	TRUE or	page A-174
_EII I_WAOAUILII	Error	MAC address was read on the communications port 1 at startup.	DOOL	FALSE	page A-114
		TRUE: Error			
		FALSE: Normal			
		Note You can use this system-defined variable only for NX-series CPU Units.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP2_MacAdrErr	Port2 MAC Address Error	Indicates that an error occurred when the MAC address was read on the communications port 2 at startup.	BOOL	TRUE or FALSE	page A-174
		TRUE: Error FALSE: Normal			
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			
_EIP_LanHwErr	Communications Controller Error	NX-series CPU Units: Indicates that a communications controller failure occurred on the communications port 1.	BOOL	TRUE or FALSE	page A-174
		TRUE: Failure FALSE: Normal			
		NJ-series CPU Units: Indicates that a communications controller failure occurred.			
		TRUE: Failure			
FIDA L I b - F	D. H.O	FALSE: Normal	DOO!	TDUE	
_EIP1_LanHwErr	Port1 Communica- tions Controller Error	Indicates that a communications controller failure occurred on the communications port 1. TRUE: Failure	BOOL	TRUE or FALSE	page A-174
		FALSE: Normal			
		Note You can use this system-defined variable only for NX-series CPU Units.			
_EIP2_LanHwErr	Port2 Communications Controller Error	Indicates that a communications controller failure occurred on the communications port 2.	BOOL	TRUE or FALSE	page A-175
		TRUE: Failure FALSE: Normal			
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			
_EIP_EtnCfgErr	Basic Ethernet Setting Error	NX-series CPU Units: Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 1 is incorrect. Or, a read operation failed.	BOOL	TRUE or FALSE	page A-175
		TRUE: Setting incorrect or read failed FALSE: Normal			
		NJ-series CPU Units: Indicates that the Ethernet communications speed setting (Speed/Duplex) is incorrect. Or, a read operation failed.			
		TRUE: Setting incorrect or read failed			
		FALSE: Normal			
_EIP1_EtnCfgErr	Port1 Basic Ethernet Setting Error	Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 1 is incorrect. Or, a read operation failed.	BOOL	TRUE or FALSE	page A-175
		TRUE: Setting incorrect or read failed			
		FALSE: Normal Note You can use this system-defined variable only for NX-series CPU Units.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP2_EtnCfgErr	Port2 Basic Ethernet Setting Error	Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 2 is incorrect. Or, a read operation failed. TRUE: Setting incorrect or read failed FALSE: Normal	BOOL	TRUE or FALSE	page A-175
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			
_EIP_IPAdrCfgErr	IP Address Setting Error	NX-series CPU Units: Indicates the IP address setting errors for the communications port 1. TRUE:	BOOL	TRUE or FALSE	page A-176
_EIP1_IPAdrCfgErr	Port1 IP Address Setting Error	Indicates the IP address setting errors for the communications port 1. TRUE: There is an illegal IP address setting. A read operation failed. The IP address obtained from the BOOTP server is inconsistent. FALSE: Normal Note You can use this system-defined variable only for NX-series CPU Units.	BOOL	TRUE or FALSE	page A-176
_EIP2_IPAdrCfgErr	Port2 IP Address Setting Error	Indicates the IP address setting errors for the communications port 2. TRUE: • There is an illegal IP address setting. • A read operation failed. • The IP address obtained from the BOOTP server is inconsistent. FALSE: Normal Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.	BOOL	TRUE or FALSE	page A-176

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_IPAdrDupErr	IP Address Duplication Error	NX-series CPU Units: Indicates that the same IP address is assigned to more than one node for the communications port 1. TRUE: Duplication occurred. FALSE: Other than the above. NJ-series CPU Units: Indicates that the same IP address is assigned to more than one node. TRUE: Duplication occurred. FALSE: Other than the above.	BOOL	TRUE or FALSE	page A-177
_EIP1_IPAdrDupErr	Port1 IP Address Duplication Error	Indicates that the same IP address is assigned to more than one node for the communications port 1. TRUE: Duplication occurred. FALSE: Other than the above. Note You can use this system-defined variable only for NX-series CPU Units.	BOOL	TRUE or FALSE	page A-177
_EIP2_IPAdrDupErr	Port2 IP Address Duplication Error	Indicates that the same IP address is assigned to more than one node for the communications port 2. TRUE: Duplication occurred. FALSE: Other than the above. Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.	BOOL	TRUE or FALSE	page A-177
_EIP_DNSCfgErr*1	DNS Setting Error	Indicates that the DNS or hosts settings are incorrect. Or, a read operation failed. TRUE: Setting incorrect or read failed FALSE: Normal	BOOL	TRUE or FALSE	page A-177
_EIP_BootpErr	BOOTP Server Error	NX-series CPU Units: Indicates that a BOOTP server connection failure occurred on the communications port 1. TRUE: There was a failure to connect to the BOOTP server (timeout). FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the BOOTP server. NJ-series CPU Units: Indicates that a BOOTP server connection failure occurred. TRUE: There was a failure to connect to the BOOTP server (timeout). FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the BOOTP server.	BOOL	TRUE or FALSE	page A-178
_EIP1_BootpErr	Port1 BOOTP Server Error	Indicates that a BOOTP server connection failure occurred on the communications port 1. TRUE: There was a failure to connect to the BOOTP server (timeout). FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the BOOTP server. Note You can use this system-defined variable only for NX-series CPU Units.	BOOL	TRUE or FALSE	page A-178

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP2_BootpErr	Port2 BOOTP Server Error	Indicates that a BOOTP server connection failure occurred on the communications port 2.	BOOL	TRUE or FALSE	page A-178
		TRUE: There was a failure to connect to the BOOTP server (timeout).			
		FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the BOOTP server.			
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			
_EIP_IPRTblErr	IP Route Table Error	NX-series CPU Units: Indicates that the default gateway settings or IP router table settings are incorrect.	BOOL	TRUE or FALSE	page A-178
		Or, a read operation failed.			
		TRUE: Setting incorrect or read failed			
		FALSE: Normal			
		NJ-series CPU Units: Indicates that the IP router table or hosts settings are incorrect. Or, a read operation failed.			
		TRUE: Setting incorrect or read failed			
		FALSE: Normal			
_EIP_IdentityErr	Identity Error	NX-series CPU Units: Indicates that the identity information for CIP communications 1 (which you cannot overwrite) is incorrect. Or, a read operation failed.	BOOL	TRUE or FALSE	page A-179
		TRUE: Setting incorrect or read failed			
		FALSE: Normal			
		NJ-series CPU Units: Indicates that the identity information (which you cannot overwrite) is incorrect. Or, a read operation failed.			
		TRUE: Setting incorrect or read failed			
		FALSE: Normal			
_EIP1_IdentityErr	CIP Communications1 Identity Error	Indicates that the identity information for CIP communications 1 (which you cannot overwrite) is incorrect. Or, a read operation failed.	BOOL	TRUE or FALSE	page A-179
		TRUE: Setting incorrect or read failed			
		FALSE: Normal Note You can use this system-defined variable only for NX-series CPU Units.			
EIP2_IdentityErr	CIP Communica-	Indicates that the identity information for	BOOL	TRUE or	page A-179
_Lii 2_identityLii	tions2 Identity Error	CIP communications 2 (which you cannot overwrite) is incorrect. Or, a read operation failed.	BOOL	FALSE	page A-179
		TRUE: Setting incorrect or read failed FALSE: Normal			
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_TDLinkCfgErr	Tag Data Link Setting Error	NX-series CPU Units: Indicates that the tag data link settings for CIP communications 1 are incorrect. Or, a read operation failed.	BOOL	TRUE or FALSE	page A-179
		TRUE: Setting incorrect or read failed FALSE: Normal			
		NJ-series CPU Units: Indicates that the tag data link settings are incorrect. Or, a read operation failed.			
		TRUE: Setting incorrect or read failed FALSE: Normal			
_EIP1_TDLinkCfgErr	CIP Communica- tions1 Tag Data Link Setting Error	Indicates that the tag data link settings for CIP communications 1 are incorrect. Or, a read operation failed.	BOOL	TRUE or FALSE	page A-180
		TRUE: Setting incorrect or read failed			
		FALSE: Normal			
		Note You can use this system-defined variable only for NX-series CPU Units.			
_EIP2_TDLinkCfgErr	CIP Communica- tions2 Tag Data Link Setting Error	Indicates that the tag data link settings for CIP communications 2 are incorrect. Or, a read operation failed.	BOOL	TRUE or FALSE	page A-180
		TRUE: Setting incorrect or read failed			
		FALSE: Normal			
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			
_EIP_TDLinkOpnErr	Tag Data Link Con- nection Failed	NX-series CPU Units: Indicates that establishing a tag data link connection for CIP communications 1 failed.	BOOL	TRUE or FALSE	page A-180
		TRUE: Establishing a tag data link con- nection failed due to one of the following causes.			
		 The information registered for a target node in the tag data link parameters is different from the actual node informa- tion. 			
		There was no response from the remote node.			
		FALSE: Other than the above.			
		NJ-series CPU Units: Indicates that establishing a tag data link connection failed.			
		TRUE: Establishing a tag data link con- nection failed due to one of the following causes.			
		The information registered for a target node in the tag data link parameters is different from the actual node information.			
		There was no response from the remote node.			
		FALSE: Other than the above.			

Variable name	Meaning	Function	Data type	Range of values	Reference	
_EIP1_TDLinkOpnErr	CIP Communica- tions1 Tag Data Link Connection Failed	Indicates that establishing a tag data link connection for CIP communications 1 failed.	BOOL	TRUE or FALSE	page A-181	
		TRUE: Establishing a tag data link connection failed due to one of the following causes.				
		The information registered for a target node in the tag data link parameters is different from the actual node information. There was no response from				
		the remote node. FALSE: Other than the above.				
		Note You can use this system-defined variable only for NX-series CPU Units.				
_EIP2_TDLinkOpnErr	CIP Communica- tions2 Tag Data Link Connection Failed	Indicates that establishing a tag data link connection for CIP communications 2 failed. TRUE: Establishing a tag data link con-	BOOL	TRUE or FALSE	page A-181	
		nection failed due to one of the following causes.				
		The information registered for a target node in the tag data link parameters is different from the actual node informa- tion.				
		There was no response from the remote node.				
		FALSE: Other than the above.				
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.				
_EIP_TDLinkErr	Tag Data Link Com- munications Error	NX-series CPU Units: Indicates that a timeout occurred in a tag data link connection for CIP communications 1.	BOOL	TRUE or FALSE	page A-181	
		TRUE: A timeout occurred.				
		FALSE: Other than the above.				
		NJ-series CPU Units: Indicates that a tim- eout occurred in a tag data link connec- tion.				
		TRUE: A timeout occurred.				
		FALSE: Other than the above.				
_EIP1_TDLinkErr	CIP Communica- tions1 Tag Data Link Communications	Indicates that a timeout occurred in a tag data link connection for CIP communications 1.	BOOL	TRUE or FALSE	page A-181	
	Error	TRUE: A timeout occurred.				
		FALSE: Other than the above. Note You can use this system-defined vari-				
		able only for NX-series CPU Units.				
_EIP2_TDLinkErr	CIP Communica- tions2 Tag Data Link Communications	Indicates that a timeout occurred in a tag data link connection for CIP communications 2.	BOOL	TRUE or FALSE	page A-182	
	Error	TRUE: A timeout occurred.				
		FALSE: Other than the above.				
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.				

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_TagAdrErr	Tag Name Resolution Error	NX-series CPU Units: Indicates that tag resolution for CIP communications 1 failed (i.e., the address could not be identified from the tag name).	BOOL	TRUE or FALSE	page A-182
		TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.			
		 The size of the network variable is different from the tag settings. 			
		The I/O direction that is set in the tag data link settings does not agree with the I/O direc- tion of the variable in the CPU Unit.			
		There is no network variable in the CPU Unit that corre- sponds to the tag setting.			
		FALSE: Other than the above.			
		NJ-series CPU Units: Indicates that tag resolution failed (i.e., the address could not be identified from the tag name).			
		TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.			
		 The size of the network variable is different from the tag settings. 			
		The I/O direction that is set in the tag data link settings does not agree with the I/O direc- tion of the variable in the CPU Unit.			
		 There is no network variable in the CPU Unit that corre- sponds to the tag setting. 			
		FALSE: Other than the above.			
_EIP1_TagAdrErr	CIP Communica- tions1 Tag Name Resolution Error	Indicates that tag resolution for CIP communications 1 failed (i.e., the address could not be identified from the tag name).	BOOL	TRUE or FALSE	page A-182
		TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.			
		 The size of the network variable is different from the tag settings. 			
		The I/O direction that is set in the tag data link settings does not agree with the I/O direc- tion of the variable in the CPU Unit.			
		There is no network variable in the CPU Unit that corre- sponds to the tag setting.			
		FALSE: Other than the above.			
_		Note You can use this system-defined variable only for NX-series CPU Units.			

Variable name	Meaning				Reference	
_EIP2_TagAdrErr	CIP Communica- tions2 Tag Name Resolution Error	Indicates that tag resolution for CIP communications 2 failed (i.e., the address could not be identified from the tag name).	BOOL	TRUE or FALSE	page A-183	
		TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.				
		 The size of the network variable is different from the tag settings. 				
		The I/O direction that is set in the tag data link settings does not agree with the I/O direc- tion of the variable in the CPU Unit.				
		There is no network variable in the CPU Unit that corre- sponds to the tag setting.				
		FALSE: Other than the above.				
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.				
_EIP_MultiSwONErr	Multiple Switches ON Error	NX-series CPU Units: Indicates that more than one switch turned ON at the same time in CIP communications 1.	BOOL	TRUE or FALSE	page A-183	
		TRUE: More than one data link start/stop switch changed to TRUE at the same time.				
		FALSE: Other than the above.				
		NJ-series CPU Units: Indicates that more than one switch turned ON at the same time.				
		TRUE: More than one data link start/stop switch changed to TRUE at the same time.				
		FALSE: Other than the above.				
_EIP1_MultiSwONErr	CIP Communica- tions1 Multiple Switches ON Error	Indicates that more than one switch turned ON at the same time in CIP communications 1.	BOOL	TRUE or FALSE	page A-183	
		TRUE: More than one data link start/stop switch changed to TRUE at the same time.				
		FALSE: Other than the above.				
		Note You can use this system-defined variable only for NX-series CPU Units.				
_EIP2_MultiSwONErr	CIP Communica- tions2 Multiple Switches ON Error	Indicates that more than one switch turned ON at the same time in CIP communications 2.	BOOL	TRUE or FALSE	page A-183	
		TRUE: More than one data link start/stop switch changed to TRUE at the same time.				
		FALSE: Other than the above.				
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.				
_EIP_TcpAppCfgErr	TCP Application Set- ting Error	TRUE: At least one of the set values for a TCP application (FTP, NTP, SNMP) is incorrect. Or, a read operation failed.	BOOL	TRUE or FALSE	page A-184	
		FALSE: Normal				

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_NTPSrvErr	NTP Server Connection Error	TRUE: The NTP client failed to connect to the server (timeout).	BOOL	TRUE or FALSE	page A-184
		FALSE: NTP is not set or the connection was successful.			
_EIP_DNSSrvErr	DNS Server Connection Error	TRUE: The DNS client failed to connect to the server (timeout).	BOOL	TRUE or FALSE	page A-184
		FALSE: DNS is not enabled. Or, DNS is enabled and the connection was successful.			

^{*1} With the NJ-series CPU Unit, this variable can be used with the unit version 1.11 or later.

Hierarchical Relationship of System-defined Variables Related to EtherNet/IP Errors in the NJ-series CPU Unit

The system-defined variables that are related to EtherNet/IP errors have the following hierarchical relationship. For example, if the value of any of the _EIP_PortErr, _EIP_CipErr, or _EIP_Tc-pAppErr variables in the second level is TRUE, then the _EIP_ErrSta variable in the first level also changes to TRUE. Therefore, you can check the values of system-defined variables in a higher level to see if an error has occurred for a variable in a lower level.

Level 1		Leve	el 2	Level 3		
Variable	Name	Variable	Name	Variable	Name	
_EIP_ErrSta	Built-in Ether- Net/IP Error	_EIP_PortErr	Communica- tions Port Error	_EIP_MacAdr Err	MAC Address Error	
				_EIP_LanHwErr	Communications Controller Error	
				_EIP_EtnCfgErr	Basic Ethernet Set- tings Error	
				_EIP_IPAdrCfg Err	IP Address Setting Error	
				_EIP_IPAdrDupErr	IP Address Duplication Error	
				_EIP_BootpErr	BOOTP Server Error	
				_EIP_DNSSrvErr	DNS Server Connection Error	
				_EIP_IPRTblErr	IP Route Table Error	
		_EIP_CipErr	CIP Communi- cations Error	_EIP_Identity Err	Identity Error	
				_EIP_TDLink CfgErr	Tag Data Link Setting Error	
				_EIP_TDLink OpnErr	Tag Data Link Con- nection Failed	
				_EIP_TDLink Err	Tag Data Link Com- munications Error	
				_ EIP_TagAdr Err	Tag Name Resolution Error	
				_EIP_MultiSw ONErr	Multiple Switches ON Error	
		_EIP_TcpAppErr	TCP Applica- tion Communi-	_EIP_TcpApp CfgErr	TCP Application Set- ting Error	
			cations Error	_EIP_NTPSrv Err	NTP Server Connection Error	

Hierarchical Relationship of System-defined Variables Related to EtherNet/IP Errors in the NX-series CPU Unit

The system-defined variables that are related to EtherNet/IP errors have the following hierarchical relationship. For example, if the value of any of the _EIP1_PortErr, _EIP2_PortErr, EIP1_CipErr, _EIP2_CipErr, and _EIP_TcpAppErr variables in the second level is TRUE, then the _EIP_ErrSta variable in the first level also changes to TRUE. Therefore, you can check the values of system-defined variables in a higher level to see if an error has occurred for a variable in a lower level.

Connection Failed EIP1_TDLinkErr CIP Communications1 Tag Data Link Communications Error EIP1_TagAdrErr CIP Communications1 Tag Name Resolution Error EIP1_MultiSwONErr CIP Communications1 Multiple Switches ON Error EIP2_TDLinkCfgErr CIP Communications2 Identity Error EIP2_TDLinkCfgErr CIP Communications2 Tag Data Link Setting Error EIP2_TDLinkCpnErr CIP Communications2 Tag Data Link Connection Failed EIP2_TDLinkErr CIP Communications2 Tag Data Link Connection Failed EIP2_TDLinkErr CIP Communications2 Tag Data Link Communications Error EIP2_TagAdrErr CIP Communications2 Tag Data Link Communications Error EIP2_TagAdrErr CIP Communications2 Tag Name Resolution Error EIP2_MultiSwONErr CIP Communications2 Tag Name Resolution Error EIP2_MultiSwONErr CIP Communications2 Multiple Switches ON Error EIP2_TCPAppErr TCP Application Setting Error TCP Applica- EIP_TCPAppErr NTP Server Connection Error	Lev	rel 1	Lev	rel 2	Level 3			
EtherNet/IP Error Ether Error Eiror Eir					Variable Name			
EtherNet/IP Error	_EIP_ErrSta	Built-in	_EIP1_Po	Communi-	_EIP1_MacAdrErr	Port1 MAC Address Error		
EIP1_EIN.dgErr Port1 IP Address Setting Error			rtErr	Port1	_EIP1_LanHwErr			
EIP1_IPAdrDupErr Port1 IP Address Duplication Error EIP1_BootpErr Port1 BOOTP Server Error EIP2_IP_DNSC/gErr DNS Setting Error EIP2_DNSC/gErr DNS Setting Error EIP2_IPRTbiErr IP Route Table Error EIP2_IPRTbiErr IP Route Table Error EIP2_IPRTbiErr Port2 MacAddress Error EIP2_LanHwErr Port2 Communications Controller Error EIP2_LanHwErr Port2 Communications Controller Error EIP2_IPAdrC/gErr Port2 P Address Setting Error EIP2_IPAdrC/gErr Port2 P Address Duplication Error EIP2_IPAdrC/gErr Port2 P Address Duplication Error EIP2_IPAdrC/gErr Port2 P Address Duplication Error EIP2_IPADrDupErr CIP Communications I Tag Data Lind Connection Failed EIP1_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP1_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Error EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Error EIP2_IDLinkC/gErr CIP Communications I Multiple EIP2_IDLinkC/gErr CIP Communications I Multiple EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP2_IDLinkC/gErr EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP2_IDLinkC/gErr CIP Communications I Tag Data Lind Connection Failed EIP2_IDLinkC				Error	_EIP1_EtnCfgErr	Port1 Basic Ethernet Setting Error		
EIP1_BootpErr Port1 BOOTP Server Error					_EIP1_IPAdrCfgErr	Port1 IP Address Setting Error		
EIP_PONSCIGER DNS Serting Error EIP_DNSSrvErr DNS Server Connection Error EIP_IPRTbiErr IP Route Table Error EIP_JMacAdrers Error EIP2_MacAdrers Port2 MacAddress Error EIP2_LanHwErr Port2 Communications Controller Error EIP2_LanHwErr Port2 Dort2 Paddress Setting Error EIP2_IPAdrCigErr Port2 Basic Ethernet Setting Error EIP2_IPAdrCigErr Port2 BoOTP Server Error EIP2_IPAdrDupErr Port2 BOOTP Server Error EIP2_IPNSSrvErr DNS Server Connection Error EIP2_IPNSSrvErr DNS Server Error EIP2_IPNSSrvErr DNS Server Connection Error EIP2_IPNSSrvErr DNS Server Error EIP1_DNSSrvErr DNS Server Connection Error EIP1_IPRTbiErr IP Route Table Error IP Route Table Error EIP1_IPRTbiErr IP Communications1 Identity Error EIP1_IPTDLinkCfgErr CIP Communications1 Tag Data Lind Connection Failed EIP1_IPTDLinkErr CIP Communications1 Tag Data Lind Connection Failed EIP1_IPTDLinkErr CIP Communications1 Tag Name Resolution Error EIP1_IPI3_IPI3_IPI3_IPI3_IPI3_IPI3_IPI3_I					_EIP1_IPAdrDupErr	Port1 IP Address Duplication Error		
EIP2_Po Communications EIP2_MacAdrErr Port2_MAC_Address Error EIP2_Handward Port2_Mac_Address Error EIP2_LanHwErr Port2_Mac_Address Error EIP2_LanHwErr Port2_Dassic_Ethernet Setting_Error EIP2_InAdrC(gErr Port2_Basic_Ethernet Setting_Error EIP2_IPAdrC(gErr Port2_Basic_Ethernet Setting_Error EIP2_IPAdrC(gErr Port2_IPAddress_Duplication_Error EIP2_IPAdrDupErr Port2_IPAddress_Duplication_Error EIP2_IPASIVERr DNS_Server_Connection_Error EIP2_IPASIVERr DNS_Server_Connection_Error EIP2_IPATDIErr IP_Route_Table_Error EIP2_IPATDIErr IP_Route_Table_Error EIP1_TDLinkCfgErr CIP_Communications1_Identity_Error EIP1_TDLinkCfgErr CIP_Communications1_Tag_Data_LinkCfgErr EIP1_TDLinkCfgErr CIP_Communications1_Tag_Data_LinkCfgErr CIP_Communications2_Tag_Data_LinkCfgErr					_EIP1_BootpErr	Port1 BOOTP Server Error		
EIP2_PO rtErr EIP2_PO rtErr EIP2_PO rtErr EIP2_Error EIP2_MacAdrErr EIP2_LanHwErr Port2 Basic Ethernet Setting Error EIP2_LandrOupErr Port2 IP Address Detting Error EIP2_LandrOupErr Port2 BOOTP Server Error EIP2_DNSCrgErr DNS Server Connection Error EIP2_DNSSrvErr EIP2_DNSSrvErr EIP2_DNSSrvErr EIP1_DNSSrvErr EIP1_TDLinkCrgErr CIP Communications1 Identity Error EIP1_TDLinkCrgErr EIP1_TDLinkCrgErr CIP Communications1 Tag Data Lind Communications1 Tag Data Lind Communications1 Tag Name Resolution Error EIP1_TagAdrErr EIP1_TagAdrErr CIP Communications2 Identity Error EIP2_TDLinkCrgErr EIP2_TDLinkCrgErr CIP Communications2 Tag Data Lind Setting Error EIP2_TDLinkCrgErr EIP2_TDLinkCrgErr CIP Communications2 Tag Data Lind Communications2 Tag Data Lind Communications2 Tag Data Lind Setting Error EIP2_TDLinkCrgErr EIP2_TDLinkCrgErr CIP Communications2 Tag Data Lind Commu					_EIP_DNSCfgErr	DNS Setting Error		
EIP2_Porter Communications EIP2_LanHwErr Port2 MAC Address Error					_EIP_DNSSrvErr	DNS Server Connection Error		
rtErr cations Port2 Error					_EIP_IPRTblErr	IP Route Table Error		
Port2 Error ElP2_EtnCfgErr _ElP2_IPAdrCigErr _ElP2_IPAdrCigErr _ElP2_BootpErr _ElP2_BootpErr _ElP_DNSCrgErr _DNS Setting Error _ElP2_DNSSrvErr _DNS Setting Error _ElP2_DNSSrvErr _DNS Setting Error _ElP2_DNSSrvErr _DNS Setting Error _ElP2_DNSSrvErr _ElP2_DNSSrvErr _DNS Server Connection Error _ElP1_IDLinkCigErr _ElP1_TDLinkCigErr _ElP1_TagAdrErr _ElP1_TagAdrErr _ElP2_Cir _ElP1_TagAdrErr _ElP2_IdentityErr _ElP2_IdentityErr _ElP2_TDLinkCigErr _Cip Communications2 Tag Data LinkCigerr _ElP2_TDLinkCigErr _E				_	_EIP2_MacAdrErr	Port2 MAC Address Error		
EIP2_IPAdrCgErr Port2 IPA Address Setting Error			rtErr	Port2	_EIP2_LanHwErr			
EIP2_Ci- pErr EIP2_IDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_IDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP1_MultiswONErr CIP Communications I Tag Data Lind Connection Error EIP2_IP3_IDLinkCrgErr CIP Communications I Tag Data Lind Connection Firor EIP1_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Failed EIP1_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Failed EIP1_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Failed EIP1_MultiswONErr CIP Communications I Tag Data Lind Communications Error EIP2_Ci- pErr EIP2_IDLinkCrgErr CIP Communications I Multiple Switches ON Error EIP2_IDLinkCrgErr CIP Communications I Multiple Switches ON Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Setting Error EIP2_TDLinkCrgErr CIP Communications I Multiple Switches ON Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Failed EIP2_TDLinkCrgErr CIP Communications I Multiple Switches ON Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Failed EIP2_TDLinkCrgErr CIP Communications I Multiple Switches ON Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I Tag Data Lind Connection Error EIP2_TDLinkCrgErr CIP Communications I T				Error	_EIP2_EtnCfgErr	Port2 Basic Ethernet Setting Error		
EIP2_Ci- pErr					_EIP2_IPAdrCfgErr	Port2 IP Address Setting Error		
EIP_DNSCfgErr DNS Setting Error EIP_DNSSvErr DNS Server Connection Error EIP_IPRTblErr IP Route Table Error EIP_IPRTblErr CIP Communications1 Identity Error EIP1_TDLinkCfgErr CIP Communications1 Tag Data Link Setting Error EIP1_TDLinkCpnErr CIP Communications1 Tag Data Link Connection Failed EIP1_TDLinkErr CIP Communications1 Tag Data Link Connection Failed EIP1_TDLinkErr CIP Communications1 Tag Name Resolution Error EIP1_MultiswONErr CIP Communications1 Tag Name Resolution Error EIP1_MultiswONErr CIP Communications1 Multiple Switches ON Error EIP2_Cir CIP Communications2 Identity Error EIP2_TDLinkCfgErr CIP Communications2 Identity Error EIP2_TDLinkCfgErr CIP Communications2 Tag Data Link Setting Error EIP2_TDLinkCpnErr CIP Communications2 Tag Data Link Communications Error EIP2_TDLinkErr CIP Communications2 Tag Data Link Communications Error EIP2_TDLinkErr CIP Communications2 Tag Data Link Communications Error EIP2_TDLinkErr CIP Communications2 Tag Data Link Communications Error EIP2_TagAdrErr CIP Communications Error EIP2_TagAdrErr CIP Communications Error EIP2_TagAdrErr CIP Communications Error EIP2_TagAdrErr CIP Communications Error EIP2_TagAdrErr CI					_EIP2_IPAdrDupErr	•		
EIP_DNSSrvErr					_EIP2_BootpErr	Port2 BOOTP Server Error		
EIP1_Ci- perr					_EIP_DNSCfgErr	-		
EIP1_Ci- pErr					_EIP_DNSSrvErr			
pErr munications1 Error					_EIP_IPRTblErr			
tions1 Error EIP1_TDLinkOpnErr EIP1_TDLinkErr CIP Communications1 Tag Data Lind Communications Error EIP1_TagAdrErr EIP1_TagAdrErr EIP1_MultiSwoNErr EIP2_Gi- PErr EIP2_TDLinkCfgErr EIP2_TDLinkCfgErr EIP2_TDLinkCfgErr EIP2_TDLinkCfgErr EIP2_TDLinkCfgErr EIP2_TDLinkCfgErr EIP2_TDLinkCfgErr EIP2_TDLinkCfgErr EIP2_TDLinkCfgErr CIP Communications2 Identity Error EIP2_TDLinkCfgErr CIP Communications2 Tag Data Lind Connection Failed						-		
EIP1_TDLinkErr			pErr	tions1	_EIP1_TDLinkCfgErr	_		
Communications Error EIP1_TagAdrErr CIP Communications1 Tag Name Resolution Error EIP2_Ci- pErr CIP Communications2 Identity Error EIP2_TDLinkCfgErr CIP Communications2 Identity Error EIP2_TDLinkCfgErr CIP Communications2 Tag Data Link Connection Failed EIP2_TDLinkErr CIP Communications2 Tag Data Link Communications Error EIP2_TagAdrErr CIP Communications2 Tag Name Resolution Error EIP2_MultiSwONErr CIP Communications2 Multiple Switches ON Error EIP2_TopAppErr Applica- EIP2_TopAppCfgErr Top Application Setting Error EIP2_NTPSrvErr NTP Server Connection Error				Error	_EIP1_TDLinkOpnErr	CIP Communications1 Tag Data Link Connection Failed		
Resolution Error _EIP1_MultiSwONErr _EIP2_Ci- pErr _EIP2_Ci- pErr _EIP2_IdentityErr _EIP2_IdentityE					_EIP1_TDLinkErr	CIP Communications1 Tag Data Link Communications Error		
Switches ON Error _EIP2_Ci- pErr					_EIP1_TagAdrErr	-		
pErr munications2 Error EIP2_TDLinkCfgErr CIP Communications2 Tag Data Link Setting Error EIP2_TDLinkOpnErr CIP Communications2 Tag Data Link Connection Failed EIP2_TDLinkErr CIP Communications2 Tag Data Link Communications Error EIP2_TDLinkErr CIP Communications Error EIP2_TagAdrErr CIP Communications Error EIP2_MultiSwONErr CIP Communications Multiple Switches ON Error EIP2_TC- pAppErr Applica- EIP_NTPSrvErr NTP Server Connection Error					_EIP1_MultiSwONErr	1		
tions2 Error EIP2_TDLinkOpnErr CIP Communications2 Tag Data Link Connection Failed EIP2_TDLinkErr CIP Communications2 Tag Data Link Communications Error EIP2_TagAdrErr CIP Communications Error CIP Communications2 Tag Name Resolution Error EIP2_MultiSwONErr CIP Communications2 Multiple Switches ON Error EIP_Tc- pAppErr Applica- EIP_TcpAppCfgErr TCP Application Setting Error NTP Server Connection Error				CIP Com-	_EIP2_IdentityErr	CIP Communications2 Identity Error		
EIP2_TDLinkErr			pErr	tions2	_EIP2_TDLinkCfgErr	CIP Communications2 Tag Data Link Setting Error		
Communications Error _EIP2_TagAdrErr				Error	_EIP2_TDLinkOpnErr	CIP Communications2 Tag Data Link Connection Failed		
Resolution Error _EIP2_MultiSwONErr CIP Communications2 Multiple Switches ON Error _EIP_Tc- pAppErr ApplicaEIP_NTPSrvErr NTP Server Connection Error					_EIP2_TDLinkErr	CIP Communications2 Tag Data Link Communications Error		
Switches ON Error _EIP_Tc- pAppErr ApplicaEIP_NTPSrvErr NTP Server Connection Error					_EIP2_TagAdrErr	-		
pAppErr Applica- EIP_NTPSrvErr NTP Server Connection Error					_EIP2_MultiSwONErr	·		
					_EIP_TcpAppCfgErr	TCP Application Setting Error		
municatio			pAppErr	tion Com-	_EIP_NTPSrvErr	NTP Server Connection Error		
ns Error								

Note You can access the same values of the system-defined variables whose variable names with *_EIP1* and the system-defined variables whose variable names with *_EIP*. For example, you can access the same values of *_EIP1_PortErr* (Communications Port1 Error) and *_EIP_PortErr* (Communications Port Error).

Note You can use the system-defined variables whose variable names with *_EIP2* only for the NX701 CPU Units and NX102 CPU Units.

• Functional Classification: EtherNet/IP Communications Status

Variable name	Meaning	Function	Data type	Range of values	Reference	
_EIP_EtnOnlineSta	Online	NX-series CPU Units: Indicates that the built-in EtherNet/IP port's communications can be used via the communications port 1 (that is, the link is ON, IP address is defined, and there are no errors).	BOOL	TRUE or FALSE	page A-184	
		TRUE: The built-in EtherNet/IP port's communications can be used.				
		FALSE: The built-in EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.				
		NJ-series CPU Units: Indicates that the built-in EtherNet/IP port's communications can be used via the communications port (that is, the link is ON, IP address is defined, and there are no errors).				
		TRUE: The built-in EtherNet/IP port's communications can be used.				
		FALSE: The built-in EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.				
_EIP1_EtnOnlineSta	Port1 Online	Indicates that the built-in EtherNet/IP port's communications can be used via the communications port 1 (that is, the link is ON, IP address is defined, and there are no errors).	BOOL	TRUE or FALSE	page A-185	
		TRUE: The built-in EtherNet/IP port's communications can be used.				
		FALSE: The built-in EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.				
		Note You can use this system-defined variable only for NX-series CPU Units.				
_EIP2_EtnOnlineSta	Port2 Online	Indicates that the built-in EtherNet/IP port's communications can be used via the communications port 2 (that is, the link is ON, IP address is defined, and there are no errors).	BOOL	TRUE or FALSE	page A-185	
		TRUE: The built-in EtherNet/IP port's communications can be used.				
		FALSE: The built-in EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.				
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.				

Variable name	Meaning	Function	Data type	Range of values	Reference	
_EIP_TDLinkRunSta	Tag Data Link Communications Status	NX-series CPU Units: Indicates that at least one connection is in normal operation in CIP communications 1. TRUE: Normal operation FALSE: Other than the above. NJ-series CPU Units: Indicates that at least one connection is in normal operation. TRUE: Normal operation	BOOL	TRUE or FALSE	page A-185	
_EIP1_TDLinkRunSta	CIP Communica- tions1 Tag Data Link Communications Sta- tus	FALSE: Other than the above. Indicates that at least one connection is in normal operation in CIP communications 1. TRUE: Normal operation FALSE: Other than the above. Note You can use this system-defined variable only for NX-series CPU Units.	BOOL	TRUE or FALSE	page A-185	
_EIP2_TDLinkRunSta	CIP Communications2 Tag Data Link Communications Status	Indicates that at least one connection is in normal operation in CIP communications 2. TRUE: Normal operation FALSE: Other than the above. Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.	BOOL	TRUE or FALSE	page A-186	
_EIP_TDLinkAllRun-Sta	All Tag Data Link Communications Sta- tus	NX-series CPU Units: Indicates that all tag data links are communicating in CIP communications 1. TRUE: Tag data links are communicating in all connections as the originator. FALSE: An error occurred in at least one connection. NJ-series CPU Units: Indicates that all tag data links are communicating. TRUE: Tag data links are communicating in all connections as the originator. FALSE: An error occurred in at least one connection.	BOOL	TRUE or FALSE	page A-186	
_EIP1_TDLinkAllRun- Sta	CIP Communica- tions1 All Tag Data Link Communica- tions Status	Indicates that all tag data links are communicating in CIP communications 1. TRUE: Tag data links are communicating in all connections as the originator. FALSE: An error occurred in at least one connection. Note You can use this system-defined variable only for NX-series CPU Units.	BOOL	TRUE or FALSE	page A-186	
_EIP2_TDLinkAllRun- Sta	CIP Communica- tions2 All Tag Data Link Communica- tions Status	Indicates that all tag data links are communicating in CIP communications 2. TRUE: Tag data links are communicating in all connections as the originator. FALSE: An error occurred in at least one connection. Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.	BOOL	TRUE or FALSE	page A-186	

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_RegTargetSta [255]	Registered Target Node Information	NX-series CPU Units: Gives a list of nodes for which built-in EtherNet/IP connections are registered for CIP communications 1.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-187
		This variable is valid only when the built-in EtherNet/IP port is the originator.			
		Array[x] is TRUE: The connection to the node with a target node ID of x is registered.			
		Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.			
		NJ-series CPU Units: Gives a list of nodes for which built-in EtherNet/IP connections are registered.			
		This variable is valid only when the built-in EtherNet/IP port is the originator.			
		Array[x] is TRUE: The connection to the node with a target node ID of x is registered.			
		Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.			
_EIP1_RegTargetSta [255]	CIP Communica- tions1 Registered Tar- get Node Information	Gives a list of nodes for which built-in EtherNet/IP connections are registered for CIP communications 1.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-187
		This variable is valid only when the built-in EtherNet/IP port is the originator.			
		Array[x] is TRUE: The connection to the node with a target node ID of x is registered.			
		Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.			
		Note You can use this system-defined variable only for NX-series CPU Units.			
_EIP2_RegTargetSta [255]	CIP Communica- tions2 Registered Tar- get Node Information	Gives a list of nodes for which built-in Eth-	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-187
		This variable is valid only when the built-in EtherNet/IP port is the originator.			
		Array[x] is TRUE: The connection to the node with a target node ID of x is registered.			
		Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.			
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_EstbTargetSta [255]	Normal Target Node Information	NX-series CPU Units: Gives a list of nodes that have normally established EtherNet/IP connections for CIP communications 1.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-188
		Array[x] is TRUE: The connection to the node with a target node ID of x was established normally.			
		Array[x] is FALSE: The connection to the node with a target node ID of x was not established, or an error occurred.			
		NJ-series CPU Units: Gives a list of nodes that have normally established Ether-Net/IP connections.			
		Array[x] is TRUE: The connection to the node with a target node ID of x was established normally.			
		Array[x] is FALSE: The connection to the node with a target node ID of x was not established, or an error occurred.			
_EIP1_EstbTargetSta [255]	CIP Communica- tions1 Normal Target Node Information	Gives a list of nodes that have normally established EtherNet/IP connections for CIP communications 1.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-188
		Array[x] is TRUE: The connection to the node with a target node ID of x was established normally.			
		Array[x] is FALSE: The connection to the node with a target node ID of x was not established, or an error occurred.			
		Note You can use this system-defined variable only for NX-series CPU Units.			
_EIP2_EstbTargetSta [255]	CIP Communica- tions2 Normal Target Node Information	Gives a list of nodes that have normally established EtherNet/IP connections for CIP communications 2.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-188
		Array[x] is TRUE: The connection to the node with a target node ID of x was established normally.			
		Array[x] is FALSE: The connection to the node with a target node ID of x was not established, or an error occurred.			
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_TargetPLC- ModeSta [255]	Target PLC Operating Mode	NX-series CPU Units: Shows the operating status of the target node Controllers that are connected for CIP communications 1, with the built-in EtherNet/IP port as the originator.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-189
		The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, the Target Node Controller Operating Information indicates the previous operating status.			
		Array[x] is TRUE: This is the operating state of the target Controller with a node address of x.			
		Array[x] is FALSE: Other than the above.			
		NJ-series CPU Units: Shows the operating status of the target node Controllers that are connected with the built-in Ether-Net/IP port as the originator.			
		The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, the Target Node Controller Operating Information indicates the previous operating status.			
		Array[x] is TRUE: This is the operating state of the target Controller with a node address of x.			
		Array[x] is FALSE: Other than the above.			
_EIP1_TargetPLC- ModeSta [255]	CIP Communications1 Target PLC Operating Mode	Shows the operating status of the target node Controllers that are connected for CIP communications 1, with the built-in EtherNet/IP port as the originator.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-189
		The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, the Target Node Controller Operating Information indicates the previous operating status.			
		Array[x] is TRUE: This is the operating state of the target Controller with a node address of x.			
		Array[x] is FALSE: Other than the above.			
		Note You can use this system-defined variable only for NX-series CPU Units.			

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP2_TargetPLC- ModeSta [255]	CIP Communications2 Target PLC Operating Mode	Shows the operating status of the target node Controllers that are connected for CIP communications 2, with the built-in EtherNet/IP port as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, the Target Node Controller Operating Information indicates the previous operating status. Array[x] is TRUE: This is the operating state of the target Controller with a node address of x. Array[x] is FALSE: Other than the above. Note You can use this system-defined variable only for the NX701 CPU Units	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-189
_EIP_TargetPLCErr [255]	Target PLC Error Information	and NX102 CPU Units. NX-series CPU Units: Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected for CIP communications 1, with the built-in EtherNet/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE. Array[x] is TRUE: A fatal or non-fatal error occurred in the target Controller with a target node ID of x. Array[x] is FALSE: Other than the above. NJ-series CPU Units: Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected with the built-in EtherNet/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE. Array[x] is TRUE: A fatal or non-fatal error occurred in the target Controller with a target node ID of x. Array[x] is FALSE: Other than the above.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-190

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP1_TargetPLCErr [255]	CIP Communications1 Target PLC Error Information	Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected for CIP communications 1, with the built-in Ether-Net/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE. Array[x] is TRUE: A fatal or non-fatal error occurred in the target Controller with a target node ID of x. Array[x] is FALSE: Other than the above.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-190
		able only for NX-series CPU Units.			
_EIP2_TargetPLCErr [255]	CIP Communications2 Target PLC Error Information	Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected for CIP communications 2, with the built-in Ether-Net/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE. Array[x] is TRUE: A fatal or non-fatal error occurred in the target Controller with a target node ID of x. Array[x] is FALSE: Other than the above. Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-190

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_TargetNodeErr [255]	Target Node Error Information	NX-series CPU Units: Indicates that the connection for the Registered Target Node Information for CIP communications 1 was not established or that an error occurred in the target Controller.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-191
		The array elements are valid only when the Registered Target Node Information is TRUE.			
		Array[x] is TRUE: A connection was not normally established with the target node for a target node ID of x (the Registered Target Node Information is TRUE and the Normal Target Node Information is FALSE), or a connection was established with the target node but an error occurred in the target Controller.			
		Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE and the Normal Target Node Information is TRUE). An error occurred in the target Controller (the Target PLC Error Information is TRUE).			
		NJ-series CPU Units: Indicates that the connection for the Registered Target Node Information was not established or that an error occurred in the target Controller.			
		The array elements are valid only when the Registered Target Node Information is TRUE.			
		Array[x] is TRUE: A connection was not normally established with the target node for a target node ID of x (the Registered Target Node Information is TRUE and the Normal Target Node Information is FALSE), or a connection was established with the target node but an error occurred in the target Controller.			
		Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE and the Normal Target Node Information is TRUE).			
		An error occurred in the target Controller (the Target PLC Error Information is TRUE).			

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP1_Target- NodeErr [255]	CIP Communications1 Target Node Error Information	Indicates that the connection for the Registered Target Node Information for CIP communications 1 was not established or that an error occurred in the target Controller. The array elements are valid only when the Registered Target Node Information is TRUE. Array[x] is TRUE: A connection was not normally established with the target node for a target node ID of x (the Registered Target Node Information is TRUE and the Normal Target Node Information is FALSE), or a connection was established with the target node but an error occurred in the target Controller. Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE and the Normal Target Node Information is TRUE and the Normal Target Node Information is TRUE). An error occurred in the target Controller (the Target PLC Error Information is TRUE). Note You can use this system-defined vari-	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-191
_EIP2_Target- NodeErr [255]	CIP Communications2 Target Node Error Information	able only for NX-series CPU Units. Indicates that the connection for the Registered Target Node Information for CIP communications 2 was not established or that an error occurred in the target Controller. The array elements are valid only when the Registered Target Node Information is TRUE. Array[x] is TRUE: A connection was not normally established with the target node for a target node ID of x (the Registered Target Node Information is TRUE and the Normal Target Node Information is FALSE), or a connection was established with the target node but an error occurred in the target Controller. Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE and the Normal Target Node Information is TRUE and the Normal Target Node Information is TRUE). An error occurred in the target Controller (the Target PLC Error Information is TRUE). Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.	ARRAY [0255] OF BOOL	TRUE or FALSE	page A-192

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP_NTPResult	NTP Operation Information	Use the GetNTPStatus instruction to read the NTP operation information from the user program. Direct access is not possible.	_sNTP_ RESULT		page A-192
.ExecTime	NTP Last Operation Time	Gives the last time that NTP processing ended normally. The time that was obtained from the NTP server is stored when the time is obtained normally. The time is not stored if it is not obtained from the NTP server normally. Note Do not use this variable in the user program. There may be a delay in updating it. Use this variable only to access status through communications from an external device.	DATE_AND_ TIME	Depends on data type.	page A-192
.ExecNormal	NTP Operation Result	TRUE: Indicates an NTP normal end. FALSE: Indicates that NTP operation ended in an error or has not been executed even once. Note Do not use this variable in the user program. There may be a delay in updating it. Use this variable only to access status through communications from an external device.	BOOL	TRUE or FALSE	page A-192



Additional Information

Communications Status with Target Node

The communications status with the target node of an NJ/NX-series Controller is shown by the combination of the values of four system-defined variables.

- _EIP_RegTargetSta (Registered Target Node Information)
- _EIP_EstbTargetSta (Normal Target Node Information)
- _EIP_TargetPLCErr (Target PLC Error Information)
- _EIP_TargetNodeErr (Target Node Error Information)

Value of _EIP_RegTarget- Sta	Value of _EIP_EstbTar- getSta	Value of _EIP_Target- PLCErr	Value of _EIP_Target- NodeErr	Communications status with target node
TRUE	TRUE	FALSE	FALSE	A connection with the target node was established normally and there is no error in the target PLC.
		TRUE	TRUE	A connection with the target node was established but there is an error in the target PLC.
	FALSE	Disabled	TRUE	A connection with the target node was not established normally.
FALSE	Disabled	Disabled	Disabled	The information is not valid because the target node is not registered.

For the NX-series Controller, the communications status of CIP communications 1 and CIP communications 2 is shown by the combination of the values of four system-defined variables in the same way as shown in the above table.

- CIP Communications 1
 - _EIP1_RegTargetSta (CIP Communications1 Registered Target Node Information)
 - _EIP1_EstbTargetSta (CIP Communications1 Normal Target Node Information)
 - _EIP1_TargetPLCErr (CIP Communications1 Target PLC Error Information)
 - EIP TargetNodeErr (Target Node Error Information)
- CIP Communications 2
 - _EIP2_RegTargetSta (CIP Communications2 Registered Target Node Information)
 - EIP2 EstbTargetSta (CIP Communications2 Normal Target Node Information)
 - _EIP2_TargetPLCErr (CIP Communications2 Target PLC Error Information)
 - _EIP_TargetNodeErr (Target Node Error Information)

• Functional Classification: EtherNet/IP Communications Switches

Variable name	Meaning	Function	Data type	Range of values	Reference	
_EIP_TDLinkStart- Cmd	Tag Data Link Com- munications Start Switch	NX-series CPU Units: Change this variable to TRUE to start tag data links for CIP communications 1.	BOOL	TRUE or FALSE	page A-193	
		It automatically changes back to FALSE after tag data link operation starts.				
		NJ-series CPU Units: Change this variable to TRUE to start tag data links.				
		It automatically changes back to FALSE after tag data link operation starts.				
		Note Do not force this switch to change to FALSE from the user program or from the Sysmac Studio. It changes to FALSE automatically.				
_EIP1_TDLinkStart- Cmd	CIP Communica- tions1 Tag Data Link	Change this variable to TRUE to start tag data links for CIP communications 1.	BOOL	TRUE or FALSE	page A-193	
Onid	Communications Start Switch	It automatically changes back to FALSE after tag data link operation starts.		TALOE		
		Note Do not force this switch to change to FALSE from the user program or from the Sysmac Studio. It changes to FALSE automatically.				
		Note You can use this system-defined variable only for NX-series CPU Units.				
_EIP2_TDLinkStart- Cmd	CIP Communica- tions2 Tag Data Link	Change this variable to TRUE to start tag data links for CIP communications 2.	BOOL	TRUE or FALSE	page A-193	
	Communications Start Switch	It automatically changes back to FALSE after tag data link operation starts.				
		Note Do not force this switch to change to FALSE from the user program or from the Sysmac Studio. It changes to FALSE automatically.				
		Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.				
_EIP_TDLinkStop- Cmd	Tag Data Link Com- munications Stop Switch	NX-series CPU Units: Change this variable to TRUE to stop tag data links for CIP communications 1.	BOOL	TRUE or FALSE	page A-194	
		It automatically changes back to FALSE after tag data link operation stops.				
		NJ-series CPU Units: Change this variable to TRUE to stop tag data links.				
		It automatically changes back to FALSE after tag data link operation stops.				
		Note Do not force this switch to change to FALSE from the user program or from the Sysmac Studio. It changes to FALSE automatically.				
_EIP1_TDLinkStop- Cmd	CIP Communica- tions1 Tag Data Link	Change this variable to TRUE to stop tag data links for CIP communications 1.	BOOL	TRUE or FALSE	page A-194	
Oma	Communications Stop Switch	It automatically changes back to FALSE after tag data link operation stops.		17.232		
		Note Do not force this switch to change to FALSE from the user program or from the Sysmac Studio. It changes to FALSE automatically.				
		Note You can use this system-defined variable only for NX-series CPU Units.				

Variable name	Meaning	Function	Data type	Range of values	Reference
_EIP2_TDLinkStop- Cmd	CIP Communications2 Tag Data Link Communications Stop Switch	Change this variable to TRUE to stop tag data links for CIP communications 2. It automatically changes back to FALSE after tag data link operation stops. Note Do not force this switch to change to FALSE from the user program or from the Sysmac Studio. It changes to FALSE automatically. Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.	BOOL	TRUE or FALSE	page A-194

A-6-8 Meanings of Error Status Bits


The meanings of the individual bits in the following error status are the same.

- ErrSta (Controller Error Status)
- _PLC_ErrSta (PLC Function Module Error Status)
- _CJB_ErrSta (I/O Bus Error Status)
- _CJB_MstrErrSta (I/O Bus Master Error Status)
- _CJB_UnitErrSta (I/O Bus Unit Error Status)
- NXB ErrSta (NX Bus Function Module Error Status)
- _NXB_MstrErrSta (NX Bus Function Module Master Error Status)
- _NXB_UnitErrStaTbl (NX Bus Function Module Unit Error Status)
- _MC_ErrSta (Motion Control Function Module Error Status)
- _MC_ComErrSta (MC Common Error Status)
- _MC_AX_ErrSta (Axis Error Status)
- _MC_GRP_ErrSta (Axes Group Error Status)
- _EC_ErrSta (Built-in EtherCAT Error)
- EC PortErr (Communications Port Error)
- _EC_MstrErr (Master Error)
- _EC_SlavErr (Slave Error)
- _EC_SlavErrTbl (Slave Error Table)
- _EIP_ErrSta (Built-in EtherNet/IP Error)
- *EIP_PortErr* (Communications Port Error), _*EIP1_PortErr* (Communications Port1 Error), and _*EIP2_PortErr* (Communications Port2 Error)
- _*EIP_CipErr* (CIP Communications Error), _*EIP1_CipErr* (CIP Communications1 Error), and _*EIP2_CipErr* (CIP Communications2 Error)
- _EIP_TcpAppErr (TCP Application Communications Error)

The meaning of the bits are shown in the following table.

However, do not use the following variables in the user program: *ErrSta* (Controller Error Status), *_CJB_ErrSta* (I/O Bus Error Status), *_CJB_MstrErrSta* (I/O Bus Master Error Status), *_CJB_UnitErrSta* (I/O Bus Master Unit Status), *_NXB_ErrSta* (NX Bus Function Module Error Status), *_NXB_MstrErrSta* (NX Bus Function Module Master Error Status), and *_NXB_UnitErrStaTbI* (NX Bus Function Module Unit Error Status). There may be a delay in updating them and concurrency problems in relation to the error status of the function module.

Use these variables only to access status through communications from an external device.



Bit	Meaning
15	Master-detected error: This bit indicates whether the master detected a Controller error in the Unit/slave for the error status of the Controller error.
	TRUE: The master detected a Controller error.
	FALSE: The master has not detected a Controller error. (Valid for _CJB_U_ErrSta)
14	Collective slave error status: This bit indicates if a Controller error was detected for levels (e.g., a Unit, slave, axis, or axes group) that are lower than the event source (i.e., for a function module).
	TRUE: A Controller error has occurred at a lower level.
	FALSE: A Controller error has not occurred at a lower level. (Valid for _CJB_ErrSta, _MC_ErrSta, and _EC_ErrSta.)
8 to 13	Reserved.
7	This bit indicates whether a major fault level Controller error has occurred.
	TRUE: A major fault level Controller error has occurred.
	FALSE: A major fault level Controller error has not occurred.
6	This bit indicates whether a partial fault level Controller error has occurred.
	TRUE: A partial fault level Controller error has occurred.
	FALSE: A partial fault level Controller error has not occurred.
5	This bit indicates whether a minor fault level Controller error has occurred.
	TRUE: A minor fault level Controller error has occurred.
	FALSE: A minor fault level Controller error has not occurred.
4	This bit indicates whether an observation level Controller error has occurred.
	TRUE: An observation level Controller error has occurred.
	FALSE: An observation level Controller error has not occurred.
0 to 3	Reserved.

A-7 Specifications for Individual Systemdefined Variables

The specifications for each system-defined variable are given as described below.

Variable name	This is the system-defined variable name. The prefix gives the category name.			Members (for structures)	The member names are given for structure only.	
Meaning	This is the meaning of the variable.			Global/local	Global: Global variable, Local: Local variable	
Function	The function of the	e variable is descrit	oed.			
Data type	The data type of the variable is given.			Range of values	The range of values that the variable can take is given.	
R/W access	R: Read only, RW: Read/write	Retained	The Retain attri- bute of the vari- able is given.	Network Publish	The Network Publish attribute of the variable is given.	
Usage in user program	Whether you	Related instruc-	The instructions the	hat are related to th	e variable are given.	
	can use the variable directly in the user program is specified.	tions	If you cannot use the variable directly in the user program, the instruction that access the variable are given.			

A-7-1 System-defined Variables for the Overall NJ/NX-series Controller (No Category)

• Functional Classification: Clock

Variable name	_CurrentTime	_CurrentTime						
Meaning	System Time			Global/local	Global			
Function	This variable cont	ains the CPU Unit's	internal clock data	i.				
Data type	DATE_AND_TIME			Range of values	NX-series CPU Units			
					DT#1970-01-01-00:00:00 to DT#2069-12-31-23:59:59			
					NJ-series CPU Units			
					DT#1970-01-01-00:00:00 to DT#2106-02-06-23:59:59			
R/W access	R	Retained Not retained.			Published.			
Usage in user program	Possible.	Related instructions	Clock instructions					

• Functional Classification: Tasks

Meaning Tunction	_TaskName_Activ Task Active Flag TRUE during task FALSE when task			Global/local	Global	
Function	TRUE during task	execution.		Global/local	Global	
	J	execution.			# · - · - · ·	
F	FALSE when task					
		execution is not in	progress.			
1		Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.				
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Not published.	
Usage in user program	Not possible.	Related instruc-	ActEventTask			
		tions	You can access this variable from the user program only wit instruction.			
			Task_IsActive			
<u> </u>						
Variable name	_ <i>TaskName</i> _LastE	ExecTime				
Meaning L	Last Task Execution	on Time		Global/local	Global	
Function (Contains the task	execution time the	last time the task w	as executed (unit: 0).1 μs).	
,		use this system-de from the Sysmac S		e user program. It	is used only to access task status for	
Data type	TIME			Range of values	Depends on data type.	
R/W access	R	Retained	Not retained.	Network Publish	Not published.	
Usage in user program	Not possible.	Related instruc- tions	You can access this variable from the user program only with the following instruction. • GetMyTaskStatus			

Variable name	_TaskName_MaxExecTime					
Meaning	Maximum Task Execution Time			Global/local	Global	
Function	Contains the maximum value of the task execution time (unit: 0.1 µs). Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.					
Data type	TIME			Range of values	Depends on data type.	
R/W access	R	Retained	Not retained.	Network Publish	Not published.	
Usage in user program	Not supported.	Related instruc- tions	You can access this variable from the user program only with the following instruction. • GetMyTaskStatus			

Variable name	_TaskName_MinExecTime					
Meaning	Minimum Task Execution Time			Global/local	Global	
Function	Contains the minimum value of the task execution time (unit: 0.1 µs). Note You cannot use this system-defined variable in the user program. It is used only to access task status for data tracing from the Sysmac Studio.					
Data type	TIME			Range of values	Depends on data type.	
R/W access	R	Retained	Not retained.	Network Publish	Not published.	
Usage in user program	Not possible.	Related instruc- tions	You can access this variable from the user program only with the following instruction. • GetMyTaskStatus			

Variable name	_TaskName_ExecCount						
Meaning	Task Execution Co	ount		Global/local	Global		
Function	Contains the number of executions of the task. If 4294967295 is exceeded, the value returns to 0 and counting is continued. Note You cannot use these system-defined variables in the user program. It is used only to access task status for data tracing from the Sysmac Studio.						
Data type	UDINT			Range of values	Depends on data type.		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Not possible.	Related instructions	You can access this variable from the user program only with the following instruction. • GetMyTaskStatus				

Variable name	_TaskName_Exceeded						
Meaning	Task Period Excee	eded Flag		Global/local	Global		
Function	TRUE if the task period was exceeded. FALSE if task execution was completed within the task period. Note You cannot use this system-defined variable in the user program. It is used only to access task status fo data tracing from the Sysmac Studio.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Not possible.	Related instruc- tions					

Variable name	_TaskName_ExceedCount						
Meaning	Task Period Exce	eded Count		Global/local	Global		
Function	Contains the num	ber of times that the	e period was excee	ded.			
	If the present value exceeds the maximum value of the data type, the present value returns to 0 and the count is continued.						
	If 4294967295 is exceeded, the value returns to 0 and counting is continued.						
		use this system-de from the Sysmac		e user program. It i	is used only to access task status for		
Data type	UDINT			Range of values	Depends on data type.		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Not possible.	Related instructions	You can access this variable from the user program only with the following instruction.				
			GetMyTaskStatu	JS			

• Functional Classification: Errors

Variable name	_ErrSta						
Meaning	Controller Error Status			Global/local	Global		
Function	TRUE if there is a	Controller error.					
	FALSE if there is a	no Controller error.					
	Note Do not use this variable in the user program. There may be a delay in updating it and concurrency problems in relation to the status of the function module. Use this variable only to access status through communications from an external device. Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#C0F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Not possible.	Related instruc-	ResetPLCError				
		tions	ResetCJBError				
			ResetECError				
			ResetMCError				
			MC_Reset				
			MC_GroupRese	et			
			You can access th instructions.	is variable from the	user program only with the following		
			GetPLCError				
			GetCJBError				
			GetECError				
			GetMCError				
			GetEIPError				

Variable name	_AlarmFlag						
Meaning	User-defined Error Status			Global/local	Global		
Function	The bit correspon	ding to the event le	vel is TRUE while t	nere is a user-defin	ed error.		
	Bits 00 to 07 corre	Bits 00 to 07 correspond to user fault levels 1 to 8.					
	This variable cont	This variable contains 0000 hex when there is no user-defined error.					
Data type	WORD			Range of values	16#0000 to 16#00FF		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	SetAlarm				
		tions	ResetAlarm				
			GetAlarm				

• Functional Classification: SD Memory Card

Variable name	_Card1Ready						
Meaning	SD Memory Card Ready Flag			Global/local	Global		
Function	TRUE when the S	TRUE when the SD Memory Card is recognized.					
	FALSE when an S	FALSE when an SD Memory Card is not recognized.					
	TRUE: The Card of	TRUE: The Card can be used.					
	FALSE: The Card	cannot be used.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-					
		tions					

Variable name	_Card1Protect						
Meaning	SD Memory Card Write Protected Flag			Global/local	Global		
Function	TRUE when the SE	TRUE when the SD Memory Card is write-protected with the LOCK switch.					
	TRUE: Write protect	TRUE: Write protected.					
	FALSE: Not write p	FALSE: Not write protected.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_Card1Err							
Meaning	SD Memory Card Error Flag			Global/local	Global			
Function	TRUE when an ur	TRUE when an unusable SD Memory Card is inserted or a format error occurs.						
	TRUE: There is an error							
	FALSE: There is n	FALSE: There is no error						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained Not retained. Network Publish Published.						
Usage in user program	Possible.	Related instruc- tions						

Variable name	_Card1Access							
Meaning	SD Memory Card	Access Flag		Global/local	Global			
Function	TRUE during SD I	TRUE during SD Memory Card access.						
	TRUE: Card is bei	TRUE: Card is being accessed.						
	FALSE: Card is no	FALSE: Card is not being accessed.						
		The system updates the flag every 100 ms. Because of this, access to the SD Memory Card is shown by this flag with a delay of up to 100 ms. We therefore do not recommend the use of this variable in the user program.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_Card1Deteriorate	_Card1Deteriorated					
Meaning	SD Memory Card	Life Warning Flag		Global/local	Global		
Function	TRUE when the life	fe of the SD Memor	ry Card is exceeded	1.			
	If this variable cha	inged to TRUE, rep	lace the SD Memor	ry Card.			
	Read/write operat	ion may fail if the S	D Memory Card is	not replaced.			
	TRUE: The life of	the Card has been	exceeded.				
	FALSE: The Card	can still be used.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					
Variable name	_Card1PowerFail						
Meaning	SD Memory Card	Power Interruption	Flag	Global/local	Global		
Function	TRUE when the p	ower supply to the	CPU Unit was inter	rupted during acces	ss to the SD Memory Card.		
	TRUE: Power was	s interrupted during	SD Memory Card a	access.			
	FALSE: Normal.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	RW	Retained	Retained.*1				
Usage in user program	Possible.	Related instruc-					

^{*1} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1BkupCmd ^{*1}			Member name	.ExecBkup	
Meaning	Execute Backup Flag			Global/local	Global	
Function	Change this variable to TRUE to back up Controller data Note You cannot use this system-defined variable in the when sending a command from an HMI or host co			ne user program. Use it in CIP message communications		
Data type	Structure: _sBKUl	P_CMD, Member: I	300L	Range of values	TRUE or FALSE	
R/W access	RW	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Not possible.	Related instructions				

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1BkupCmd ^{*1}			Member name	.CancelBkup
Meaning	Cancel Backup Flag			Global/local	Global
Function	Note You cannot			Card. se it in CIP message communications	
Data type	Structure: _sBKUI	P_CMD, Member: I	300L	Range of values	TRUE or FALSE
R/W access	RW	Retained	Not retained.	Network Publish	Published.
Usage in user program	Not possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1BkupCmd ^{*1}			Member name	.ExecVefy	
Meaning	Execute Verify Flag			Global/local	Global	
Function	Change this variable to TRUE to compare the Controller Note You cannot use this system-defined variable in the when sending a command from an HMI or host command the command			ne user program. Use it in CIP message communications		
Data type	Structure: _sBKUI	P_CMD, Member: E	BOOL	Range of values	TRUE or FALSE	
R/W access	RW	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Not possible.	Related instructions				

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1BkupCmd ^{*1}			Member name	.CancelVefy	
Meaning	Cancel Verify Flag			Global/local	Global	
Function	Note You cannot use this system-defined variable in the when sending a command from an HMI or host or			ne user program. Use it in CIP message communications		
Data type	Structure: _sBKUI	P_CMD, Member: E	BOOL	Range of values	TRUE or FALSE	
R/W access	RW	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Not possible.	Related instructions				

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1BkupCmd ^{*1}			Member name	.DirName
Meaning	Directory Name			Global/local	Global
Function	Used to specify the directory name in the SD Memory Ca Note You cannot use this system-defined variable in the when sending a command from an HMI or host co			e user program. Us	•
Data type	Structure: _sBKUF	P_CMD, Member: \$	STRING(64)	Range of values	Depends on data type.
R/W access	RW	Retained	Not retained.	Network Publish	Published.
Usage in user program	Not possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1BkupSta ^{*1}			Member name	.Done
Meaning	Done Flag			Global/local	Global
Function	TRUE when a backup is completed. Note You cannot use this system-defined variable in the to read the status from an HMI or host computer.			e user program. Us	se it in CIP message communications
Data type	Structure: _sBKUI	P_STA, Member: B	OOL	Range of values	TRUE or FALSE
R/W access	Read	Retained	Not retained.	Network Publish	Published.
Usage in user program	Not possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1BkupSta ^{*1}			Member name	.Active
Meaning	Active Flag			Global/local	Global
Function	Note You cannot	ckup is in progress. use this system-de status from an HMI	efined variable in th	e user program. Us	se it in CIP message communications
Data type	Structure: _sBKU	P_STA, Member: B	OOL	Range of values	TRUE or FALSE
R/W access	Read	Retained	Not retained.	Network Publish	Published.
Usage in user program	Not possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1BkupSta ^{*1}			Member name	.Err
Meaning	Error Flag			Global/local	Global
Function	TRUE when processing a backup ended in an error. Note You cannot use this system-defined variable in the to read the status from an HMI or host computer.			e user program. Us	se it in CIP message communications
Data type	Structure: _sBKUI	P_STA, Member: B	OOL	Range of values	TRUE or FALSE
R/W access	Read	Retained	Not retained.	Network Publish	Published.
Usage in user program	Not possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1VefySta ^{*1}			Member name	.Done
Meaning	Done Flag			Global/local	Global
Function	TRUE when a verification is completed. Note You cannot use this system-defined variable in the to read the status from an HMI or host computer.			e user program. Us	se it in CIP message communications
Data type	Structure: _sVEF	Y_STA, Member: B	OOL	Range of values	TRUE or FALSE
R/W access	Read	Retained	Not retained.	Network Publish	Published.
Usage in user program	Not possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1VefySta ^{*1}			Member name	.Active
Meaning	Active Flag			Global/local	Global
Function	TRUE when a verification is in progress. Note You cannot use this system-defined variable in the user program. Use it in CIP message commute to read the status from an HMI or host computer.				
Data type	Structure: _sVEF	Y_STA, Member: B	OOL	Range of values	TRUE or FALSE
R/W access	Read	Retained	Not retained.	Network Publish	Published.
Usage in user program	Not possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1VefySta ^{*1}			Member name	.VefyRslt		
Meaning	Verify Result Flag			Global/local	Global		
Function	TRUE if the data was the same. FALSE if differences w			ere found.			
		Note You cannot use this system-defined variable in the user program. Use it in CIP message communications to read the status from an HMI or host computer.					
Data type	Structure: _sVEF	Y_STA, Member: B	OOL	Range of values	TRUE or FALSE		
R/W access	Read	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Not possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1VefySta ^{*1}			Member name	.Err
Meaning	Error Flag			Global/local	Global
Function	TRUE when processing a verification ended in an error. Note You cannot use this system-defined variable in the to read the status from an HMI or host computer.			e user program. Us	se it in CIP message communications
Data type	Structure: _sVEF	/_STA, Member: B	OOL	Range of values	TRUE or FALSE
R/W access	Read	Retained	Not retained.	Network Publish	Published.
Usage in user program	Not possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Variable name	_Card1PrgTransferCmd ^{*1}			Member name	.Exec	
Meaning	Execute Program Transfer Flag			Global/local	Global	
Function	using the function	to transfer progran	ns from the SD Mer	ackup file on the SD Memory Card to the Controller by mory Card. NJ/NX-series CPU Units.		
Data type	Structure: _sPRG	TRANSFER_CMD,	Member: BOOL	Range of values	TRUE or FALSE	
R/W access	RW	Retained	Retained.*2	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions				

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1PrgTransferCmd ^{*1}			Member name	.DirName
Meaning	Directory Name			Global/local	Global
Function	Use this variable to specify the directory name in the SD is stored. Note You can use this system-defined variable only for			·	·
Data type	Structure: _sPRG STRING(64)	TRANSFER_CMD,	Member:	Range of values	Depends on data type.
R/W access	RW	Retained	Retained.*2	Network Publish	Published.
Usage in user program	Possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1PrgTransferCmd ^{*1}			Member name	.Password		
Meaning	Password			Global/local	Global		
Function	Use this variable to specify the password that is used for			r verification when y	ou start transferring the programs.		
	The password is initialized every time you start transferring programs from the SD Memory Card.						
	Note You can use this system-defined variable only for NJ/NX-series CPU Units.						
Data type	Structure: _sPRGTRANSFER_CMD, Member: STRING(33)			Range of values	Depends on data type.		
R/W access	RW	Retained	Not retained. Network Publish Published.				
Usage in user program	Possible.	Related instruc-					
		tions					

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_Card1PrgTransferCmd ^{*1}			Member name	.TargetUserProgram
Meaning	User Program and Settings Transfer Flag			Global/local	Global
Function	Change this variable to TRUE to set a user program or Note You can use this system-defined variable only for			J	· ·
Data type	Structure: _sPRG	TRANSFER_CMD,	Member: BOOL	Range of values	TRUE or FALSE
R/W access	RW	Retained	Retained.*2	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1PrgTransferCmd ^{*1}			Member name	.TargetIPAdr		
Meaning	IP Address Transf	er Flag		Global/local	Global		
Function	Change this varial	ble to TRUE to incl	ude the IP address	of the built-in EtherNet/IP port as the transfer target.			
	The IP address means setting type, IP address, subnet mask, and default gateway.						
	Note You can use this system-defined variable only for NJ/NX-series CPU Units.						
Data type	Structure: _sPRG	TRANSFER_CMD,	Member: BOOL	Range of values	TRUE or FALSE		
R/W access	RW	Retained	Retained.*2	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1PrgTransfe	erCmd ^{*1}		Member name	.TargetVariable
Meaning	Present Values of Variables with the Retain Attribute Transfer Flag			Global/local	Global
Function	Change this variable to TRUE to set the present values of variables with the Retain attribute as the transfeget. Note You can use this system-defined variable only for NJ/NX-series CPU Units.				
Data type	Structure: _sPRG	TRANSFER_CMD,	Member: BOOL	Range of values	TRUE or FALSE
R/W access	RW	Retained	Retained.*2	Published.	
Usage in user program	Possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1PrgTransferCmd ^{*1}			Member name	.TargetMemory
Meaning	Present Values of Memory Used for CJ-series Units with the Retain Attribute Transfer Flag			Global/local	Global
Function	attribute as the tra	insfer target.	•	of the memory used NJ/NX-series CPU	d for CJ-series Units with the Retain Units.
Data type	Structure: _sPRG	TRANSFER_CMD,	Member: BOOL	Range of values	TRUE or FALSE
R/W access	RW	Retained	Retained.*2	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1PrgTransferSta ^{*1}			Member name	.Done
Meaning	Done Flag			Global/local	Global
Function	TRUE when a program transfer is completed. Note You can use this system-defined variable only for NJ/NX-series CPU Units.				
Data type	Structure: _sPRG	TRANSFER_STA,	Member: BOOL	Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_Card1PrgTransferSta ^{*1}			Member name	.Active
Meaning	Active Flag			Global/local	Global
Function		gram transfer is in e this system-define		NJ/NX-series CPU	Units.
Data type	Structure: _sPRG	TRANSFER_STA,	Member: BOOL	Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_Card1PrgTransferSta ^{*1}			Member name	.Err
Meaning	Error Flag			Global/local	Global
Function	TRUE when a program transfer ended in an error. Note You can use this system-defined variable only for NJ/NX-series CPU Units.				
Data type	Structure: _sPRG	TRANSFER_STA,	Member: BOOL	Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instructions			

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_Card1RestoreCmd ^{*1}			Member name	.Exec
Meaning	Execute Restore Flag			Global/local	Global
Function	Change this variable to TRUE to restore the data in a backup file on the SD Memory Card to the Controller. Note You can use this system-defined variable only for NJ/NX-series CPU Units.				
Data type	Structure: _sRES	TORE_CMD, Meml	oer: BOOL	Range of values	TRUE or FALSE
R/W access	RW	Retained	Retained.*2	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1RestoreCmd ^{*1}			Member name	.DirName	
Meaning	Directory Name			Global/local	Global	
Function	the system-define	d variable is stored		O Memory Card in which the backup file to be restored by NJ/NX-series CPU Units.		
Data type	Structure: _sRES	TORE_CMD, Meml	ber: STRING(64)	Range of values	Depends on data type.	
R/W access	RW	Retained	Retained.*2	Network Publish	Published.	
Usage in user program	Possible.	Related instructions				

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1RestoreCmd ^{*1}			Member name	.Password		
Meaning	Password			Global/local	Global		
Function	Use this variable to specify the password that is used for verification when you start the restore by the system-defined variable.						
	The password is initialized every time when the restore by the system-defined variable is started.						
	Note You can use this system-defined variable only for NJ/NX-series CPU Units.						
Data type	Structure: _sRES	TORE_CMD, Meml	ber: STRING(33)	Range of values	Depends on data type.		
R/W access	RW	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

Variable name	_Card1RestoreSta ^{*1}			Member name	.Done
Meaning	Done Flag			Global/local	Global
Function		tore operation is co e this system-define	•	NJ/NX-series CPU	Units.
Data type	Structure: _sRES	TORE_STA, Memb	er: BOOL	Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

Variable name	_Card1RestoreSta ^{*1}			Member name	.Active	
Meaning	Active Flag			Global/local	Global	
Function	TRUE when a restore operation is in progress.					
	Note You can use this system-defined variable only for NJ/NX-series CPU Units.					
Data type	Structure: _sRES	TORE_STA, Memb	er: BOOL	Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-				
		tions				

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

Variable name	_Card1RestoreSta ^{*1}			Member name	.Err
Meaning	Error Flag			Global/local	Global
Function		tore operation ender this system-define		NJ/NX-series CPU	Units.
Data type	Structure: _sRES	TORE_STA, Memb	er: BOOL	Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

Variable name	_Card1RestoreCmdTargetUserProgram ^{*1}					
Meaning	User Program and	d Settings Transfer	Flag	Global/local	Global	
Function	Change this variable to TRUE to set a user program or setting for the restore by the system-defined variable as the transfer target. Always set this variable to TRURE for the restore by the system-defined variable.					
	Note You can use this system-defined variable only for NJ/NX-series CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	RW	Retained	Retained.*2	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions				

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

_Card1RestoreCmdTargetIPAdr*1					
IP Address Transf	er Flag		Global/local	Global	
Change this variable to TRUE to include the IP address of the built-in EtherNet/IP port for the restore by the system-defined variable as the transfer target.					
The IP address means setting type, IP address, subnet mask, and default gateway.					
Note You can use this system-defined variable only for NJ/NX-series CPU Units.					
BOOL			Range of values	TRUE or FALSE	
RW	Retained	Retained.*2	Network Publish	Published.	
Possible.	Related instruc-				
	IP Address Transf Change this varial tem-defined varial The IP address m Note You can use BOOL RW	IP Address Transfer Flag Change this variable to TRUE to inclutem-defined variable as the transfer to The IP address means setting type, I Note You can use this system-defined BOOL RW Retained	IP Address Transfer Flag Change this variable to TRUE to include the IP address tem-defined variable as the transfer target. The IP address means setting type, IP address, subnet Note You can use this system-defined variable only for BOOL RW Retained Retained.*2 Possible. Related instruc-	IP Address Transfer Flag Change this variable to TRUE to include the IP address of the built-in Ether tem-defined variable as the transfer target. The IP address means setting type, IP address, subnet mask, and default g Note You can use this system-defined variable only for NJ/NX-series CPU BOOL Retained Retained Retained.*2 Network Publish Possible.	

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1RestoreCr	_Card1RestoreCmdTargetVariable*1					
Meaning	Present Values of Variables with the Retain Attribute Transfer Flag			Global/local	Global		
Function	Change this variable to TRUE to set the present values of variables with the Retain attribute for the restore by the system-defined variable as the transfer target. Note You can use this system-defined variable only for NJ/NX-series CPU Units.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	RW	Retained	Retained.*2	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1RestoreCmdTargetMemory ^{*1}					
Meaning	Present Values of Memory Used for CJ-series Units with the Retain Attribute Transfer Flag			Global/local	Global	
Function	hange this variable to TRUE to set the present values of the memory used for CJ-series Units with the Retain attribute for the restore by the system-defined variable as the transfer target. Note You can use this system-defined variable only for NJ/NX-series CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	RW	Retained	Retained.*2	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions				

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1RestoreCmdTargetUnitConfig ^{*1}					
Meaning	Unit and Slave Parameters Transfer Flag			Global/local	Global	
Function	Change this variable to TRUE to set the Unit and slave settings for the restore by the system-defined variable as the transfer target. Note You can use this system-defined variable only for NJ/NX-series CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	RW	Retained	Retained.*2	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions				

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_Card1RestoreCmdTargetAbsEncoder ^{*1}					
Meaning	Absolute Encoder	Home Offset Trans	sfer Flag	Global/local	Global	
Function	Change this variable to TRUE to set the absolute encoder home offset for the restore by the system-defined variable as the transfer target. Note You can use this system-defined variable only for NJ/NX-series CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	RW	Retained	Retained.*2	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions				

^{*1} This system-defined variable was added for unit version 1.14 of the CPU Unit.

Functional Classification: Backup

Variable name	_BackupBusy ^{*1}					
Meaning	Backup Function Busy Flag			Global/local	Global	
Function	TRUE when a bad	TRUE when a backup, restoration, or verification is in progress.				
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	Read	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions				

^{*1} This system-defined variable was added for unit version 1.03 of the CPU Unit.

Functional Classification: Power Supply

Variable name	_PowerOnHour						
Meaning	Total Power ON T	ime		Global/local	Global		
Function	Contains the total	time that the power	r has been ON.				
	Contains the total	Contains the total time that the CPU Unit has been ON in 1-hour increments.					
	To reset this value, overwrite the current value with 0.						
	The value is not updated after it reaches 4294967295.						
	This variable is no	ot initialized at startu	ıp.				
Data type	UDINT			Range of values	0 to 4294967295		
R/W access	RW	Retained	Retained.*1	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

^{*2} This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_PowerOnCount					
Meaning	Power Interruption	n Count		Global/local	Global	
Function	Contains the num	ber of times that the	e power supply has	been interrupted.		
	The value is incremented by 1 each time the power supply is interrupted after the first time that the power was turned ON.					
	To reset this value, overwrite the current value with 0.					
	The value is not u	pdated after it reac	hes 4294967295.			
	This variable is no	ot initialized at startı	ıр.			
Data type	UDINT			Range of values	0 to 4294967295	
R/W access	RW	Retained	Retained.*1 Network Publish Published.			
Usage in user program	Possible.	Related instructions				

*1 This system-defined variable is not applicable for the data backup function even with a Retain attribute.

Variable name	_RetainFail	_RetainFail					
Meaning	Retention Failure	Retention Failure Flag Global/local Global					
Function	TRUE at the follow	ving times (failure c	of retention during p	ower interruptions)			
	When an error is	s detected in the ba	attery-backup memo	ory check at startup			
	FALSE at the follo	wing times (no failu	ure of retention duri	ng power interruption	ons).		
	When no error is	s detected in the ba	attery-backup memo	ory check at startup			
	When the user p	orogram is downloa	ded.				
	When the Clear	All Memory operati	on is performed.				
		encoder home offse ot in this flag.	t data is not retaine	ed, the status is giv	ren in the error status of the axis vari-		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	R Retained Not retained. Network Publish Not published.					
Usage in user program	Possible.	Related instruc- tions					

• Functional Classification: Programming

Variable name	P_On	P_On					
Meaning	Always TRUE Flag			Global/local	Global		
Function	This flag is always	TRUE.					
Data type	BOOL			Range of values	TRUE		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Possible.	Related instructions					
		•					
Variable name	P_Off	P_Off					
Meaning	Always FALSE Fla	ag		Global/local	Global		
F 41	This	EALOE					

		· = · · ·					
Meaning	Always FALSE Flag			Global/local	Global		
Function	This flag is always	FALSE.					
Data type	BOOL			Range of values	FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Possible.	Related instructions					

Variable name	P_CY		
Meaning	Carry Flag	Global/local	Local
Function	This flag is updated by some instructions.		

Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Not published.
Usage in user program	Possible.	Related instructions			

Variable name	P_First_RunMode	P_First_RunMode					
Meaning	First RUN Period	Flag		Global/local	Local		
Function		This flag is TRUE for only one task period after the operating mode of the CPU Unit is changed from PROGRAM mode to RUN mode if execution of the program is in progress.					
	This flag remains	This flag remains FALSE if execution of the program is not in progress.					
	Use this flag to pe	Use this flag to perform initial processing when the CPU Unit begins operation.					
	Note You cannot	Note You cannot use this system-defined variable inside functions.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained Not retained. Network Publish Not published.					
Usage in user program	Possible.	Related instruc- tions					

Variable name	P_First_Run*1						
Meaning	First Program Period Flag			Global/local	Local		
Function	This flag is TRUE	This flag is TRUE for one task period after execution of the program starts.					
	Use this flag to pe	Use this flag to perform initial processing when execution of a program starts.					
	Note You cannot	Note You cannot use this system-defined variable inside functions.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.08 of the CPU Unit.

Variable name	P_PRGER				
Meaning	Instruction Error Flag			Global/local	Local
Function	This flag changes to and remains TRUE when an instruction error occurs in the program or in a function/function block called from the program. After this flag changes to TRUE, it stays TRUE until the user program changes it back to FALSE.				
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	RW	Retained	Not retained.	Network Publish	Not published.
Usage in user program	Possible.	Related instructions			

• Functional Classification: Communications

Variable name	_Port_numUsingPort						
Meaning	Number of Used Ports			Global/local	Global		
Function	Gives the number	Gives the number of internal logical ports that are currently used.					
	You can use this v	You can use this variable when you debug the user program.					
	Note You can use	Note You can use this system-defined variable only for NJ-series CPU Units.					
Data type	USINT			Range of values	0 to 32		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Possible.	Related instructions	Communications instructions (ExecPMCR, SerialSend, SerialRcv, Send, Rcv, and SendCmd)				

Variable name	_Port_isAvailable						
Meaning	Network Commun	ications Instruction	Enabled Flag	Global/local	Global		
Function	Indicates whether	Indicates whether there is an available internal logical port.					
	TRUE when an in	TRUE when an internal logical port is available. Otherwise FALSE.					
	Note You can use	Note You can use this system-defined variable only for NJ-series CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Possible.	Related instruc- tions	Communications instructions (ExecPMCR, SerialSend, SerialRcv, Send, Rcv, and SendCmd)				

Variable name	_FINSTCPConnSta							
Meaning	FINS/TCP Connection Status			Global/local	Global			
Function	Gives the FINS/To	CP connection statu	ıs.					
	Note You can use	Note You can use this system-defined variable only for NJ-series CPU Units.						
Data type	WORD			Range of values	16#0000 to 16#FFFF			
R/W access	R	Retained	Not retained.	Network Publish	Published.*1			
Usage in user program	Possible.	Related instructions						

^{*1} The network for CPU Units with unit version 1.07 or earlier is not published.

• Functional Classification: Version

Variable name	_UnitVersion ^{*1}						
Meaning	Unit Version			Global/local	Global		
Function	Contains the unit	Contains the unit version of the CPU Unit.					
	The integer part of	The integer part of the unit version is stored in element number 0.					
	The fractional part of the unit version is stored in element number 1.						
	Example 1) If the unit version is 1.08, "1" is stored in element number 0 and "8" is stored in element number 1.						
	Example 2) If the	unit version is 1.10	, "1" is stored in ele	ment number 0 and	l "10" is stored in element number 1.		
Data type	ARRAY[01] OF L	JSINT		Range of values	0 to 99		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.08 of the CPU Unit.

Variable name	_HardwareRevision ^{*1}						
Meaning	Hardware Revision			Global/local	Global		
Function		Contains the hardware revision of the CPU Unit. Contains - if the hardware revision is in blank, and A to Z for other cases.					
Data type	STRING[2]			Range of values	- or A to Z		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

• Functional Classification: Self-diagnosis

Variable name	_SelfTest_HighTemperature ^{*1}						
Meaning	CPU Unit High Temperature Flag			Global/local	Global		
Function	TRUE when the internal temperature of the CPU Unit is too high. Note Always FALSE for the NX102 CPU Unit and NX1P2 CPU Unit.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.10 of the CPU Unit.

Variable name	_SelfTest_LowBattery ^{*1}						
Meaning	Low Battery Flag			Global/local	Global		
Function	TRUE when the b	TRUE when the battery is disconnected or the battery voltage is dropped.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related instruc-					
gram		tions					

^{*1} This system-defined variable was added for unit version 1.10 of the CPU Unit.

Variable name	_SelfTest_LowFanRevolution*1						
Meaning	Low FAN Revolution Flag			Global/local	Global		
Function		TRUE when the fan is disconnected or the rotation speed of a fan is decreased. Note Always FALSE for the NX102 CPU Unit, NX1P2 CPU Unit, and NJ-series CPU Unit.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.10 of the CPU Unit.

• Functional Classification: PLC Built-in

Variable name	_DeviceOutHoldCfg*1						
Meaning	Device Output Ho	ld Configuration		Global/local	Global		
Function	It is 16#A5A5 if yo	It is 16#A5A5 if you retain the target device output when the operating mode is changed or when downloaded.					
	In the case other to downloaded.	In the case other than 16#A5A5, the target device output is initialized when the operating mode is changed or when downloaded.					
Data type	WORD			Range of values	16#0000 to 16#FFFF		
R/W access	RW	Retained	Retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_DeviceOutHoldStatus ^{*1}						
Meaning	Device Output Hold Status			Global/local	Global		
Function	It is TRUE if the ta	It is TRUE if the target device output is retained when the operating mode is changed or when downloaded.					
	When the device output hold configuration is other than 16#A5A5, or when a major fault level Controller error occurs, the target device output is initialized and changes to FALSE.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related instruc-					
gram		tions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

A-7-2 PLC Function Module, Category Name: _PLC

• Functional Classification: Debugging

Variable name	_PLC_TraceSta[0	3]		Member name	.lsStart
Meaning	Trace Busy Flag			Global/local	Global
Function	TRUE when a trace starts. Note You cannot use these system-defined variables in data tracing from the Sysmac Studio.			the user program.	It is used only to monitor the status of
Data type	Structure: _sTRA0	CE_STA, Members	: BOOL	Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Not published.
Usage in user program	Not possible.	Related instructions	TraceTrig TraceSamp You can access this variable from the user program only with the following instruction. GetTraceStatus		

Variable name	_PLC_TraceSta[0	3]		Member name	.lsComplete
Meaning	Trace Completed	Flag		Global/local	Global
Function	TRUE when a trace is completed. Note You cannot use this system-defined variable in the user program. It is used only to monitor the status data tracing from the Sysmac Studio.				
Data type	Structure: _sTRA	CE_STA, Members	: BOOL	Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Not published.
Usage in user program	Not possible.	Related instructions	TraceTrig TraceSamp You can access this variable from the user program only with the following instruction. GetTraceStatus		

Variable name	_PLC_TraceSta[0	3]		Member name	.lsTrigger	
Meaning	Trace Trigger Mor	nitor Flag		Global/local	Global	
Function	TRUE when the tr	igger condition is m	net.			
	FALSE when the I	next trace starts.				
	Note You cannot use these system-defined variables in the user program. It is used only to monitor the status of data tracing from the Sysmac Studio.					
Data type	Structure: _sTRA	CE_STA, Members	: BOOL	Range of values	TRUE or FALSE	
R/W access	R	Retained	Retained.	Network Publish	Not published.	
Usage in user program	Not possible.	Related instruc- tions	TraceTrig TraceSamp			
			 TraceSamp You can access this variable from the user program only with the followir instruction. GetTraceStatus 			

Variable name	_PLC_TraceSta[0	3]		Member name	.ParamErr		
Meaning	Trace Parameter I	Error Flag		Global/local	Global		
Function	TRUE when a trace starts, but there is an error in the tra			ice settings.	e settings.		
	FALSE when the settings are normal.						
		Note You cannot use these system-defined variables in the user program. It is used only to monitor the status of data tracing from the Sysmac Studio.					
Data type	Structure: _sTRA0	CE_STA, Members	: BOOL	Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Not published.		
Usage in user program	Not possible.	Related instructions	You can access the instruction.	is variable from the	user program only with the following		
			GetTraceStatus				

• Functional Classification: Errors

Variable name	_PLC_ErrSta					
Meaning	PLC Function Module Error Status			Global/local	Global	
Function	TRUE when there	TRUE when there is a Controller error that involves the PLC Function Module.				
	FALSE when ther	FALSE when there is no Controller error that involves the PLC Function Module.				
	Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.					
Data type	WORD			Range of values	16#0000 to 16#00F0	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	GetPLCError	•		
		tions	You can use the following instruction to clear this variable.			
			ResetPLCError			

• Functional Classification: Option Boards

Variable name	_PLC_OptBoardSta ^{*1}						
Meaning	Option Board Stat	us		Global/local	Global		
Function	Contains the statu	Contains the status of Option Boards. This variable is commonly used regardless of the models of Option Boards.					
	The array elemen slot 2.	The array element 1 corresponds to the option board slot 1 and array element 2 corresponds to the option board slot 2.					
	Note You can us	e this system-define	ed variable only for	the NX1P2 CPU Ur	nits.		
Data type	ARRAY[02] OF	sOPTBOARD_STA	١	Range of values			
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_PLC_OptBoardSta ^{*1}			Member name	isDetect			
Meaning	Option Board Mou	ınted		Global/local	Global			
Function	Indicates an Option	n Board is mounte	d to the option boar	d slot.				
	TRUE: Mounted.	TRUE: Mounted.						
	FALSE: Not mounted.							
	Note You can us	Note You can use this system-defined variable only for the NX1P2 CPU Units.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related instruc-						
gram		tions						

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_PLC_OptBoardS	ta ^{*1}		Member name	Run		
Meaning	Option Board Nori	mal Operation		Global/local	Global		
Function	Indicates whether an Option Board is normally operating.						
	To use device variables or communications instructions for an Option Board, program this member as an interlock condition in the user program.						
	TRUE: Normally operating.						
	FALSE: Initializing, changing settings, or an error occurred.						
	Note You can use	e this system-define	ed variable only for	the NX1P2 CPU Ur	nits.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related instruc-					
gram		tions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_PLC_OptBoardSta ^{*1}			Member name	Error	
Meaning	Option Board Error			Global/local	Global	
Function	Indicates whether	an Option Board e	rror occurred.	•		
	TRUE: An error occurred.					
	FALSE: An error not occurred.					
	Note You can use this system-defined variable only for the NX1P2 CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user pro-	Possible.	Related instruc-				
gram		tions				

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_PLC_OptSerialErrSta ^{*1}						
Meaning	Serial Option Boa	rd Error Status	Error Status Global/local Global				
Function	Contains the error status of an transmission error for the Serial Communications Option Board.						
	When the Serial communications mode of an Serial Communications Option Board is only set to Host Link (FINS), the value of each member is updated.						
	Other than the above setting, the values of all members are FALSE.						
	The array element 1 corresponds to the option board slot 1 and array element 2 corresponds to the option board slot 2.						
					here may be a delay in updating it. Use an external device such as an HMI.		
	Note You can use	e this system-define	ed variable only for	the NX1P2 CPU Ui	nits.		
Data type	ARRAY[02] OF _	sOPTSERIALERR	_STA	Range of values			
R/W access	RW	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_PLC_OptSerialE	rrSta ^{*1}		Member name	Error			
Meaning	Transmission Erro	or		Global/local	Global			
Function	Indicates whether	Indicates whether a transmission error occurred.						
	TRUE: A parity err	or, framing error, o	r an overrun error o	ccurred.				
	FALSE: FALSE du	ue to one of the follo	owing causes.					
	A parity error, fra	aming error, or an o	verrun error not oc	curred.				
	A port is restarted.	ed.						
	The Serial communications mode is not set to Host Link (FINS).							
	The Option Boa	rd that is mounted i	s not a Serial Com	munications Option	Board.			
	The Option Boa	rd is not mounted.						
					here may be a delay in updating it. Use in external device such as an HMI.			
	Note You can use	e this system-define	ed variable only for	the NX1P2 CPU Ur	nits.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	RW	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						
	<u> </u>							

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_PLC_OptSerialE	rrSta ^{*1}		Member name	ParityErr		
Meaning	Parity Error	Global/local Global					
Function	Indicates whether a parity error occurred. If this error occurs, it means that the serial communications settings may not apply to the remote device to connect. TRUE: A parity error occurred.						
	FALSE: FALSE du	ue to one of the follo	owing causes.				
	A parity error no	t occurred.					
	A port is restarted.	ed.					
	The Serial communications mode is not set to Host Link (FINS).						
	The Option Boa	rd that is mounted i	s not a Serial Com	nunications Option	Board.		
	The Option Boa	rd is not mounted.					
					here may be a delay in updating it. Use an external device such as an HMI.		
	Note You can use	e this system-define	ed variable only for	the NX1P2 CPU U	nits.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	RW	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_PLC_OptSerialE	rrSta ^{*1}		Member name	FramingErr		
Meaning	Framing Error			Global/local	Global		
Function	Indicates whether a framing error occurred. If this error occurs, it means that the serial communications settings may not apply to the remote device to connect.						
	TRUE: A framing	error occurred.					
	FALSE: FALSE du	ue to one of the follo	owing causes.				
	A framing error	not occurred.					
	A port is restarted.	ed.					
	The Serial communications mode is not set to Host Link (FINS).						
	The Option Boa	rd that is mounted i	s not a Serial Com	nunications Option	Board.		
	The Option Boa	rd is not mounted.					
					here may be a delay in updating it. Use an external device such as an HMI.		
	Note You can use	e this system-define	ed variable only for	the NX1P2 CPU Ui	nits.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	RW	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related instruc-					
gram		tions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	PLC OptSerialE	rrSta ^{*1}		Member name	OverRun		
Meaning	Overrun Error			Global/local	Global		
Function	Indicates whether an overrun error occurred. If this error occurs, it means that the baud rate of an Option Board may be too large.						
	TRUE: An overrur	error occurred.					
	FALSE: FALSE du	ue to one of the follo	owing causes.				
	An overrun erro	r not occurred.					
	A port was resta	irted.					
	The Serial comr	nunications mode is	s not set to Host Lir	nk (FINS).			
	The Option Boa	rd that is mounted i	s not a Serial Com	munications Option	Board.		
	The Option Boa	rd is not mounted.					
	Note We do not recommend the use of this variable in the user program. There may be a delay in use these variables only to access status through communications from an external device such a Note You can use this system-defined variable only for the NX1P2 CPU Units.						
Data type	BOOL	o uno oyotom donne	sa variable erriy ter	Range of values	TRUE or FALSE		
R/W access	RW	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

• Functional Classification: Safety Data Logging

Variable name	_PLC_SFLogSta*1					
Meaning	Safety Data Logging Status			Global/local	Global	
Function	Stores the status of safety data logging.					
	Element number 0 corresponds to Logging Setting Number 1. Element number 1 corresponds to Logging Setting Number 2.					
	Note You can use this system-defined variable only for the NX102 CPU Units.					
Data type	ARRAY[01] OF _sSFLOG_STA			Range of values		
R/W access	R	Retained	Not retained.	Network Publish	Not published.	
Usage in user pro-	Not possible.	Related instruc-				
gram		tions				

^{*1} This system-defined variable was added for unit version 1.31 of the CPU Unit.

Variable name	_PLC_SFLogSta ^{*1}			Member name	.lsStart	
Meaning	Safety Data Logging Busy Flag			Global/local	Global	
Function	TRUE when safety data logging starts.					
	Note You can use this system-defined variable only for the NX102 CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Not published.	
Usage in user pro-	Not possible.	Related instruc-				
gram		tions				

^{*1} This system-defined variable was added for unit version 1.31 of the CPU Unit.

Variable name	_PLC_SFLogSta ^{*1}			Member name	.lsComplete	
Meaning	Safety Data Logging Completed Flag			Global/local	Global	
Function	TRUE when logging stops. FALSE when the next logging starts.					
	When this flag is TRUE, it means that the logging has completed.					
	Note You can use this system-defined variable only for the NX102 CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Not published.	
Usage in user pro-	Not possible.	Related instruc-				
gram		tions				

^{*1} This system-defined variable was added for unit version 1.31 of the CPU Unit.

Variable name	_PLC_SFLogSta ^{*1}			Member name	.lsOutput	
Meaning	Log File Output Completed Flag			Global/local	Global	
Function	TRUE when the log file is output. FALSE when the next logging starts.					
	Note You can use this system-defined variable only for the NX102 CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Not published.	
Usage in user pro-	Not possible.	Related instruc-				
gram		tions				

^{*1} This system-defined variable was added for unit version 1.31 of the CPU Unit.

A-7-3 PLC Function Module, Category Name: _CJB

• Functional Classification: I/O Bus Status

Variable name	_CJB_MaxRackNo						
Meaning	Largest Rack Nun	nber		Global/local	Global		
Function	J	Contains the largest rack number of the Expansion Racks that are detected by the Controller. Note You can use this system-defined variable only for NJ-series CPU Units.					
Data type	UINT			Range of values	0 to 3 "0" means there are no Expansion Racks.		
R/W access	R	Retained Not retained.			Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_CJB_MaxSlotNo						
Meaning	Largest Slot Numb	per		Global/local	Global		
Function	Contains one higher than the largest slot number with a CJ-series Unit on each of the Racks that are detected by the Controller. Note You can use this system-defined variable only for NJ-series CPU Units.						
Data type	ARRAY [03] OF	UINT		Range of values	0 to 10		
					0: No CJ-series Unit mounted.		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

• Functional Classification: I/O Bus Errors

Variable name	_CJB_ErrSta	_CJB_ErrSta						
Meaning	I/O Bus Error Stat	us		Global/local	Global			
Function	Gives the I/O bus error status. Note Do not use this variable in the user program. There may be a delay in updating it and concurrency problems may occur. Use this variable only to access status through communications from an external device. Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.							
	Note You can use	this system-defined	variable only for NJ-	series CPU Units.				
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Not possible.	Related instruc- tions						
		You can use the following instruction to clear this variable.						
			ResetCJBError	-				

Variable name	_CJB_MstrErrSta	_CJB_MstrErrSta				
Meaning	I/O Bus Master Er	ror Status		Global/local	Global	
Function	Gives the I/O bus	master error status	S.			
	lems may o device. Ref	occur. Use these ver to A-6-8 Meaning	ariables only to a	ccess status throug Bits for the meaning	in updating it and concurrency prob- gh communications from an external s of the error status bits.	
Data type	WORD		<u> </u>	Range of values	16#0000 to 16#00F0	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Not possible.	Related instruc- tions	instruction. • GetCJBError		user program only with the following	
				ollowing instruction	to clear this variable.	
			ResetCJBError			
V : 11	l a.p= s:					
Variable name	_CJB_UnitErrSta	0		0	Lau	
Meaning Function	I/O Bus Unit Error	atus of the I/O Bus	11.26	Global/local	Global	
	lems may o Refer to <i>A-</i>	occur. Use this varia 6-8 Meanings of En		status through com ne meanings of the	in updating it and concurrency prob- nmunications from an external device. error status bits.	
Data type	ARRAY [03, 09]] OF WORD		Range of values	16#0000 to 16#80F0	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Not possible.	Related instructions	instruction. • GetCJBError	nis variable from the	e user program only with the following	
Variable name	_CJB_InRespTm					
		nput Response Tim	95	Global/local	Global	
Meaning Function		·		Global/local	Global	
	Contains the response times of the Basic I/O Units. Note You can use this system-defined variable only for			NJ-series CPU Uni	its.	
Data type	ARRAY [03, 09]	OF UINT		Range of values	0 to 320	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions				

• Functional Classification: Auxiliary Area Bits for CJ-series Units

Variable nar	me	_CJB_IOUnitInfo					
Meaning		Basic I/O Unit Info	ormation		Global/local	Global	
Function		TRUE: Load short FALSE: No load s	-circuit hort-circuit		d short-circuit prote		
Data tuna		ARRAY [03, 09		ed variable only for	NJ-series CPU Uni	TRUE or FALSE	
Data type R/W access		R R R R R R R R R R R R R R R R R R R	Retained	Not retained.	Range of values Network Publish	Not published.	
Usage in us		Possible.	Related instruc-		Network i ublisti	Not published.	
Auxiliary	Words	A50 to A69					
Area addresses	Bits	A50.00 to A69.15					
Variable nar	ne	_CJB_CBU00InitS to _CJB_CBU15InitS					
Meaning		CPU Bus Unit Initi	alizing Flags		Global/local	Global	
Function		The corresponding variable is TRUE during initialization The corresponding variable changes to FALSE when th The numbers in the variables indicate the unit numbers Note You can use this system-defined variable only for			e initialization is cor of the applicable Ur	npleted. nits.	
Data type		BOOL			Range of values	TRUE or FALSE	
R/W access	;	R	Retained	Not retained.	Network Publish	Published.	
Usage in us	er program	Possible.	Related instructions	ResetUnit			
Auxiliary	Words	A302					
Area addresses	Bits	A302.00 to A302.1	15				
		<u>I</u>					
Variable nar	me	_CJB_SIO00InitSi to _CJB_SIO95InitSi					
Meaning		Special I/O Unit In	nitializing Flags		Global/local	Global	
Function		The corresponding variable is TRUE during initialization The corresponding variable changes to FALSE when the The numbers in the variables indicate the unit numbers Note You can use this system-defined variable only for			e initialization is cor of the applicable Ur	npleted. nits.	
Data type	BOOL				Range of values	TRUE or FALSE	
R/W access	3	R	Retained	Not retained.	Network Publish	Published.	
Usage in us	er program	Possible.	Related instructions	ResetUnit			
Auxiliary	Words	A330 to A335					
Area addresses	Bits	A330.00 to A335.1	15				

Variable na	me	_CJB_CBU00Restart					
		to					
		_CJB_CBU15Restart					
Meaning		CPU Bus Unit Res	start Bits		Global/local	Global	
Function			is restarted when t PU Bus Unit is res		ariable changes to	TRUE. (It is changed to FALSE by the	
		The numbers in th	e variables indicate	e the unit numbers	of the applicable Ur	nits.	
		If you change the the next task period	•	JE with an instruction	on, the restart proce	ess begins from refresh processing in	
		Note You can use	e this system-define	ed variable only for	NJ-series CPU Uni	ts.	
Data type		BOOL			Range of values	TRUE or FALSE	
R/W access	3	RW	Retained	Not retained.	Network Publish	Published.	
Usage in us	ser program	Possible.	Related instruc- tions	ResetUnit			
Auxiliary	Words	A501					
Area addresses	Bits	A501.00 to A501.1	15				
Variable na	me	_CJB_SIO00Rest	art				
		to					
		_CJB_SIO95Rest	art				
Meaning		Special I/O Unit R	estart Bits		Global/local	Global	
Function			nit is restarted whe ne CPU Bus Unit is		g variable changes	to TRUE. (It is changed to FALSE by	
		The numbers in th	e variables indicate	e the unit numbers	of the applicable Ur	nits.	
		If you change the the next task perio		JE with an instruction	on, the restart proce	ess begins from refresh processing in	
		Note You can use	e this system-define	ed variable only for	NJ-series CPU Uni	ts.	
Data type		BOOL Range of values TRUE or FALSE					
R/W access	3	RW	Retained	Not retained.	Network Publish	Published.	
Usage in us	ser program	Possible.	Related instruc- tions	ResetUnit			
Auxiliary	Words	A502 to A507		•			
Area addresses	Bits	A502.00 to A507.1	15				

Variable name	е	_CJB_SCU00P1C	hgSta					
		_CJB_SCU00P2C	_CJB_SCU00P2ChgSta					
		to						
		_CJB_SCU15P1C	hgSta					
		_CJB_SCU15P2C	hgSta					
Meaning		Serial Communications Unit 0, Port 1/2 Settings Changing Flags			Global/local	Global		
		Serial Communica Changing Flags	itions Units 1 to 15	, Port 1/2 Settings				
Function		TRUE when the pa	arameters of the sp	ecified port are bei	ng changed.			
		FALSE after the pa	arameters are char	nged.				
		•		ate a change in ser on or a user operatio		turning ON the corresponding flag		
		Note You can use	e this system-define	ed variable only for	NJ-series CPU Uni	ts.		
Data type		BOOL			Range of values	TRUE or FALSE		
R/W access		RW	Retained	Not retained.	Network Publish	Published.		
Usage in user	r program	Possible.	ble. Related instruc- tions					
Auxiliary Words Port on Serial Communications Unit with unit number 0: A620								
Area		Ports on Serial Co	mmunications Unit	with unit numbers	1 to 15: A621 to A6	35		
addresses B	Bits	Port on Serial Con	nmunications Unit	with unit number 0:	A620.01 to A620.02	2		
		Ports on Serial Communications Unit with unit numbers 1 to 15: A621.01 to A635.02						

A-7-4 NX Bus Function Module, Category Name: _NXB

• Functional Classification: NX Bus Function Module Status

Variable name	_NXB_MaxUnitNo ^{*1}						
Meaning	Largest Unit Num	ber		Global/local	Global		
Function	Contains the large Module.	est NX Unit number	of the NX Units on	the CPU Unit that a	are detected by the NX Bus Function		
			registered by the S ts that are set as ur	,	value will be largest NX Unit number of also included.		
	If the Unit configu ber of an actual U		s not registered by t	he Sysmac Studio,	the value will be the largest Unit num-		
	Note You can use	e this system-define	ed variable only for	the NX102 CPU Ur	nits and NX1P2 CPU Units.		
Data type	UINT			Range of values	0 to 32*2		
		0: No NX Unit mounted.					
R/W access	R	Retained	Not retained. Network Publish Published.				
Usage in user program	Possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

^{*2} For the NX1P2 CPU Units, the range of values is 0 to 8.

Variable name	_NXB_UnitIOActiveTbl ^{*1}						
Meaning	NX Unit I/O Data	Active Status		Global/local	Global		
Function	Indicates whether I/O data in the NX Units on the CPU Unit is valid. This status is given as an array of BOOL data. The subscript of the array corresponds to the NX Unit number. A subscript of 0 indicates the NX Bus Function Module and it is always TRUE. TRUE: The I/O data in the NX Unit is valid. FALSE: The I/O data in the NX Unit is invalid. The status is FALSE for NX Units that are set as unmounted Units.						
	Note You can us	e this system-define	ed variable only for	the NX102 CPU Ur	nits and NX1P2 CPU Units.		
Data type	ARRAY[032] OF	BOOL*2		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained. Network Publish Published.				
Usage in user program	Possible.	Related instruc- tions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

^{*2} For the NX1P2 CPU Units, the data type is ARRAY [0..8] OF BOOL.

Variable name	_NXB_UnitMsgActiveTbl ^{*1}						
Meaning	NX Unit Message	Enabled Status		Global/local	Global		
Function	Indicates whether the NX Units on the CPU Unit can process message communications. This status is given as an array of BOOL data. The subscript of the array corresponds to the NX Unit number. A subscript of 0 indicates the NX Bus Function Module and it is always TRUE. TRUE: Message communications possible. FALSE: Message communications not possible. The status is FALSE for NX Units that are set as unmounted Units.						
	Note You can us	e this system-define	ed variable only for	the NX102 CPU Ur	nits and NX1P2 CPU Units.		
Data type	ARRAY[032] OF	BOOL*2		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained. Network Publish Published.				
Usage in user program	Possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

^{*2} For the NX1P2 CPU Units, the data type is ARRAY [0..8] OF BOOL.

Variable name	_NXB_UnitRegTbl ^{*1}							
Meaning	NX Unit Registrati	NX Unit Registration Status Global/local Global						
Function	Indicates whether	the NX Units on th	e CPU Unit are regi	stered in the Unit c	onfiguration.			
	This status is give	n as an array of BC	OOL data.					
	The subscript of the ule.	ne array correspond	ds to the NX Unit nu	mber. A subscript o	f 0 indicates the NX Bus Function Mod-			
	TRUE: Registered	d.						
	FALSE: Not regist	ered.						
			s not registered by t set as unmounted l	•	the status is FALSE for all Units. The			
	Note You can us	e this system-define	ed variable only for	the NX102 CPU Ur	nits and NX1P2 CPU Units.			
Data type	ARRAY[032] OF BOOL*2 Range of values TRUE or FALSE							
R/W access	R	Retained	Not retained. Network Publish Published.					
Usage in user program	Possible.	Related instruc- tions						

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

• Functional Classification: NX Bus Function Module Errors

Variable name	_NXB_ErrSta*1						
Meaning	NX Bus Function	NX Bus Function Module Error Status Global/local Global					
Function	Gives the NX Bus Function Module error status. This system-defined variable provides the collective status of the NX Bus Function Module Master Error Status and NX Bus Function Module Unit Error Status for all NX Units. Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI. Refer to A-6-8 Meanings of Error Status Bits for the meaning of the error status bits. Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.						
Data type	WORD			Range of values	16#0000 to 16#40F2		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions	You can access this variable from the user program only with the following instruction. • GetNXBError You can use the following instructions to clear this variable. • ResetNXBError • RestartNXUnit				

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_NXB_MstrErrSta	NXB MstrErrStal ^{*1}						
Meaning	NX Bus Function	Module Master Erro	or Status	Global/local	Global			
Function	Gives the status of	of errors that are de	tected in the NX Bu	s Function Module	of the CPU Unit.			
	 Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI. Refer to A-6-8 Meanings of Error Status Bits for the meaning of the error status bits. Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units. 							
Data type	WORD			Range of values	16#0000 to 16#40F2			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc- tions	You can access the instruction.	nis variable from the	e user program only with the following			
			GetNXBError					
			You can use the following instructions to clear this variable.					
			ResetNXBError					
			RestartNXUnit					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

^{*2} For the NX1P2 CPU Units, the data type is ARRAY [0..8] OF BOOL.

Variable name	_NXB_UnitErrStaTbl*1						
Meaning	NX Bus Function	Module Unit Error S	Status	Global/local	Global		
Function	Gives the status of errors that are detected in the NX Unit on the CPU Unit. This status is given as an array of BOOL data. The subscript of the array corresponds to the NX Unit number.						
	 Note We do not recommend the use of this variable in the user program. There may be a delay in updating it. Use these variables only to access status through communications from an external device such as an HMI. Refer to A-6-8 Meanings of Error Status Bits for the meaning of the error status bits. Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units. 						
Data time			ca variable only for				
Data type	ARRAY [132] OF	WORD ²		Range of values	16#0000 to 16#40F2		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions	You can access this variable from the user program only with the following instruction. • GetNXBError				
			You can use the following instructions to clear this variable.				
			ResetNXBError				
			RestartNXUnit				

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

^{*2} For the NX1P2 CPU Units, the data type is ARRAY [0..8] OF WORD.

Variable name	_NXB_UnitErrFlag	_NXB_UnitErrFlagTbl*1						
Meaning	NX Unit Error Status			Global/local	Global			
Function	Indicates whether errors occurred in the NX Unit on the CPU Unit. This status is given as an array of BOOL data. The subscript of the array corresponds to the NX Unit number. A subscript of 0 indicates the NX Bus Function Module and whether an event occurred that is detected by the NX Bus Function Module. TRUE: Error. FALSE: No error. The status is FALSE for NX Units that are set as unmounted Units. Note You can use this system-defined variable only for the NX102 CPU Units and NX1P2 CPU Units.							
Data type	ARRAY [032] OF	BOOL*2		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions	You can access this variable from the user program only with the following instruction. GetNXBError You can use the following instructions to clear this variable. ResetNXBError RestartNXUnit					

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

^{*2} For the NX1P2 CPU Units, the data type is ARRAY [0..8] OF BOOL.

A-7-5 Motion Control Function Module, Category Name: _MC

• Functional Classification: Motion Control Functions

Variable name	_MC_ErrSta						
Meaning	Motion Control Fu	nction Module Erro	r Status	Global/local	Global		
Function	Shows the status	of errors that are de	etected in the Motio	n Control Function	Module.		
	You can use this v	You can use this variable directly in the user program.					
	Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#40F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	GetMCError				
		tions	ResetMCError				
			MC_Reset				
			MC_GroupRese	et			

Variable name	_MC_ComErrSta						
Meaning	Common Error Status			Global/local	Global		
Function	Shows the status of errors that are detected in common processing for motion control.						
	You can use this variable directly in the user program.						
	Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions	GetMCError ResetMCError				

Variable name	_MC_AX_ErrSta						
Meaning	Axis Error Status			Global/local	Global		
Function	Shows the error status for each axis. The status of up to 256 axes ^{*1} is shown. You can use this variable directly in the user program. Refer to <i>A-6-8 Meanings of Error Status Bits</i> for the mean-						
	ings of the error status bits.						
Data type	ARRAY [0255] C	F WORD*1		Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	GetMCError				
		tions	ResetMCError				
			MC_Reset				

^{*1} For the NX102 CPU Units and NX1P2 CPU Units, the error status of up to 16 axes is shown and the data type is ARRAY [0..15] OF WORD. For NJ-series CPU Units, the error status of up to 64 axes is shown and the data type is ARRAY [0..63] OF WORD.

Variable name	_MC_GRP_ErrSta						
Meaning	Axes Group Error	Status		Global/local	Global		
Function	Shows the error status for each axes group. The error status for up to 64 axes groups ^{*1} is shown. You can use this variable directly in the user program. Refer to <i>A-6-8 Meanings of Error Status Bits</i> for the meanings of the error status bits.						
Data type	ARRAY [063] OF	WORD		Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions	GetMCError ResetMCError MC_GroupReset				

^{*1} For the NX102 CPU Units and NX1P2 CPU Units, the error status of up to 8 axes groups is shown and the data type is ARRAY [0..7] OF WORD

For NJ-series CPU Units, the error status of up to 32 axes groups is shown and the data type is ARRAY [0..31] OF WORD.

Variable name	_MC_COM						
Meaning	Common Variable			Global/local	Global		
Function	Shows the status	Shows the status that is common to the Motion Control Function Module.					
	Refer to the NJ/NZ members.	Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.					
Data type	_sCOMMON_REF	=		Range of values			
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

Variable name	_MC_GRP							
Meaning	Axes Group Varia	Axes Group Variables Global/local Global						
Function	NX701 CPU Units: Used to specify axes groups and shows multi-axes coordinated control status, and multi-axes coordinated control settings for motion control instructions used for motion control 1.							
	NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units: Used to specify axes groups and shows multi-axes coordinated control status, and multi-axes coordinated control settings for motion control instructions.							
	When you create an axes group on the System Studio, a user-defined axes group variable with a different name is created.							
	Normally, you use	an Axes Group Va	riable with a differer	nt name.				
	Refer to the NJ/NZ members.	X-series Motion Col	ntrol Instructions Re	eference Manual (C	at. No. W508) for details on structure			
Data type	ARRAY[063] OF	_sGROUP_REF*1		Range of values				
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

^{*1} For the NX102 CPU Units and NX1P2 CPU Units, the data type is ARRAY [0..7] OF _sGROUP_REF. For NJ-series CPU Units, the data type is ARRAY[0..31] OF _sGROUP_REF.

Variable name	_MC1_GRP						
Meaning	Axes Group Variables Global/local Global						
Function	Used to specify axes groups and shows multi-axes coordinated control status, and multi-axes coordinated control settings for motion control instructions used for motion control 1.						
	When you create an axes group on the System Studio, a user-defined axes group variable with a different name is created.						
	Normally, you use an Axes Group Variable with a different name.						
	Refer to the <i>NJ/NX-series Motion Control Instructions Reference Manual</i> (Cat. No. W508) for details on structure members.						
		•	ed variable only for if the array elemen		nits. You can access the same values are the same.		
Data type	ARRAY[063] OF	_sGROUP_REF		Range of values			
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_MC2_GRP						
Meaning	Axes Group Va	riables		Global/local	Global		
Function	Used to specify axes groups and shows multi-axes coordinated control status, and multi-axes coordinated control settings for motion control instructions used for motion control 2.						
	When you create an axes group on the System Studio, a user-defined axes group variable with a different name is created.						
	Normally, you use an Axes Group Variable with a different name.						
	Refer to the <i>NJ</i> members.	/NX-series Motion	n Control Instruct	ions Reference Manual (C	Cat. No. W508) for details on structure		
	Note You can	use this system-d	efined variable o	nly for the NX701 CPU U	nits.		
Data type	ARRAY[063] (OF _sGROUP_R	ΞF	Range of values			
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_MC_AX							
Meaning	Axis Variables	Axis Variables Global/local Global						
Function		NX701 CPU Units: Used to specify axes and shows single-axis control status, and single-axis control settings for motion control instructions used for motion control 1.						
	NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units: Used to specify axes and shows single-axis control status, and single-axis control settings for motion control instructions.							
	When you crea	When you create an axis on the System Studio, a user-defined axis variable with a different name is created.						
	Normally, you u	se an Axis Variab	ole with a differen	t name.				
	Refer to the <i>NJ</i> , members.	/NX-series Motion	n Control Instruct	ions Reference Manual (C	Cat. No. W508) for details on structure			
Data type	ARRAY[0255]	OF _sAXIS_REF	: *1	Range of values				
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

^{*1} For the NX102 CPU Units and NX1P2 CPU Units, the data type is ARRAY [0..15] OF _sAXIS_REF. For NJ-series CPU Units, the data type is ARRAY[0..63] OF _sAXIS_REF.

Variable name	_MC1_AX				
Meaning	Axis Variables			Global/local	Global
Function	' '	axes and shows	J	ol status, and single-axis	control settings for motion control
	When you crea	te an axis on the	System Studio, a	a user-defined axis variabl	e with a different name is created.
	Normally, you u	se an Axis Variab	ole with a differen	t name.	
	Refer to the <i>NJ</i> members.	/NX-series Motion	n Control Instruct	ions Reference Manual (C	Cat. No. W508) for details on structure
		•		nly for the NX701 CPU Ur nt numbers of them are th	nits. You can access the same values of e same.
Data type	ARRAY[0255]	OF _sAXIS_REF	=	Range of values	
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user pro-	Possible.	Related		_	
gram		instructions			

Variable name	_MC2_AX				
Meaning	Axis Variables			Global/local	Global
Function		axes and shows	0	ol status, and single-axis	control settings for motion control
	When you creat	te an axis on the	System Studio, a	user-defined axis variable	e with a different name is created.
	Normally, you u	se an Axis Variab	le with a differen	t name.	
	Refer to the <i>NJ</i> members.	/NX-series Motion	n Control Instruct	ions Reference Manual (C	Cat. No. W508) for details on structure
	Note You can	use this system-d	lefined variable o	nly for the NX701 CPU U	nits.
Data type	ARRAY[0255]	OF _sAXIS_REF		Range of values	
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instructions			
grain		III Sti Gottoris			

A-7-6 EtherCAT Master Function Module, Category Name: _EC

• Functional Classification: EtherCAT Communications Errors

Variable name	_EC_ErrSta				
Meaning	Built-in EtherCAT	Error		Global/local	Global
Function	This system-defined variable provides the collective sta			tus of errors in the EtherCAT Master Function Module.	
	Refer to A-6-8 Me	anings of Error Sta	<i>tus Bits</i> for the mea	nings of the error s	tatus bits.
Data type	WORD			Range of values	16#0000 to 16#40F0
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instructions	Get EtherCAT Erro GetECError Reset EtherCAT Co ResetECError		

Variable name	_EC_PortErr					
Meaning	Communications	Port Error		Global/local	Global	
Function	This system-defin master.	ed variable provides	s the collective statu	us of errors in the co	mmunications ports for the EtherCAT	
	Refer to A-6-8 Me	anings of Error Sta	<i>tus Bits</i> for the mea	nings of the error s	tatus bits.	
Data type	WORD			Range of values	16#0000 to 16#00F0	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Get EtherCAT Erro	rror Status		
		tions	GetECError			
			Reset EtherCAT C	Controller Error		
			ResetECError			

Variable name	_EC_MstrErr				
Meaning	Master Error			Global/local	Global
Function	This system-defined variable provides the collective star by the EtherCAT master.				
	Refer to A-6-8 Me	anings of Error Sta	tus Bits for the mea	inings of the error s	tatus bits.
Data type	WORD			Range of values	16#0000 to 16#00F0
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Get EtherCAT Err	or Status	
		tions	GetECError		
			Reset EtherCAT C	Controller Error	
			ResetECError		

Variable name	_EC_SlavErr				
Meaning	Slave Error			Global/local	Global
Function	This system-define	ed variable provide	us of all the error st	atus for EtherCAT slaves.	
	Refer to A-6-8 Me	anings of Error Sta	<i>tus Bits</i> for the mea	nings of the error s	tatus bits.
Data type	WORD			Range of values	16#0000 to 16#00F0
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Get EtherCAT Erro	or Status	
		tions	GetECError		
			Reset EtherCAT C	Controller Error	
			ResetECError		

Variable name	_EC_SlavErrTbl				
Meaning	Slave Error Table			Global/local	Global
Function	This system-define	ed variable gives th	e error status for ea	ach EtherCAT slave).
	The error status is	given for each slav	ve in the actual sys	tem configuration.	
	This variable array address (1 to 512)	_	n which there are er	rors. Status is prov	ided for each EtherCAT slave node
	Refer to A-6-8 Me	anings of Error Sta	<i>tus Bits</i> for the mea	nings of the error s	tatus bits.
Data type	ARRAY [1512] O	F WORD*1		Range of values	16#0000 to 16#00F0
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Get EtherCAT Erro	or Status	
		tions	GetECError		
			Reset EtherCAT C	Controller Error	
			ResetECError		

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the node address is 1 to 192 and the data type is ARRAY [1..192] OF WORD.

Variable name	_EC_MacAdrErr				
Meaning	MAC Address Erro	or		Global/local	Global
Function	TRUE if there is a	n illegal MAC addre	ess.		
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Reset EtherCAT (Controller Error	
		tions	ResetECError		

Variable name	_EC_LanHwErr				
Meaning	Communications	Controller Error		Global/local	Global
Function	TRUE if there is a	communications co	ontroller hardware e	error.	_
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Reset EtherCAT (Controller Error	_
		tions	ResetECError		

Variable name	_EC_LinkOffErr				
Meaning	Link OFF Error			Global/local	Global
Function	TRUE if the comn	nunications controlle	er link is not establi	shed.	
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Reset EtherCAT (Controller Error	
		tions	ResetECError		

_EC_NetCfgErr				
Network Configura	ation Information Er	ror	Global/local	Global
TRUE if there is ill	legal network confiç	guration information	1.	
BOOL			Range of values	TRUE or FALSE
R	Retained	Not retained.	Network Publish	Published.
Possible.	Related instruc-	Reset EtherCAT (Controller Error	
	tions	ResetECError		
	Network Configura TRUE if there is ill BOOL R	Network Configuration Information Enter TRUE if there is illegal network configuration Information Enter Information Ent	Network Configuration Information Error TRUE if there is illegal network configuration information BOOL R Retained Not retained. Possible. Related instructure.	Network Configuration Information Error Global/local TRUE if there is illegal network configuration information. BOOL Range of values R Retained Not retained. Network Publish Possible. Related instructure Reset EtherCAT Controller Error

Variable name	_EC_NetCfgCmp	Err			
Meaning	Network Configur	ation Verification Er	ror	Global/local	Global
Function	TRUE if the netwo	ork configuration inf	formation does not	match the actual ne	twork configuration.
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Controller Error	
		tions	ResetECError		
Variable name	_EC_NetTopology	/Err			
Meaning	Network Configur			Global/local	Global
Function	TRUE if there is a	network configurat	tion error (too many	/ devices connected	I or ring connection).
Data type	BOOL		` ` `	Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Controller Error	
3 1 3		tions	ResetECError		
Variable name	EC PDCommEr	 r			
Meaning		· mmunications Error		Global/local	Global
Function					ave WDT error is detected during pro
	cess data commu				
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
	Possible.	Related instruc-	Reset EtherCAT	Controller Error	
Usage in user program	i ossible.	Related Histiac-	LIVESET ETHELONI	Controller Ellor	
Usage in user program	i ossible.	tions	ResetECError	Controller Error	
Usage in user program	i ussible.			Controller Error	
Variable name	_EC_PDTimeout	tions		Controller Error	
	_EC_PDTimeoutE	tions	ResetECError	Global/local	Global
Variable name	_EC_PDTimeoutE	tions	ResetECError or		Global
Variable name Meaning	_EC_PDTimeoutE	tions Err ception Timeout Err	ResetECError or		Global TRUE or FALSE
Variable name Meaning Function	_EC_PDTimeoutE Process Data Red TRUE if a timeout	tions Err ception Timeout Err	ResetECError or	Global/local	
Variable name Meaning Function Data type	_EC_PDTimeoutE Process Data Red TRUE if a timeout BOOL	Err ception Timeout Err	ResetECError or ving process data.	Global/local Range of values Network Publish	TRUE or FALSE
Variable name Meaning Function Data type R/W access	_EC_PDTimeoutE Process Data Red TRUE if a timeout BOOL	Err ception Timeout Err coccurs while receive	ResetECError or ving process data. Not retained.	Global/local Range of values Network Publish	TRUE or FALSE
Variable name Meaning Function Data type R/W access	_EC_PDTimeoutE Process Data Red TRUE if a timeout BOOL	tions Err ception Timeout Err coccurs while receiver Retained Related instruc-	ResetECError or ving process data. Not retained. Reset EtherCAT	Global/local Range of values Network Publish	TRUE or FALSE
Variable name Meaning Function Data type R/W access	_EC_PDTimeoutE Process Data Red TRUE if a timeout BOOL	tions Err ception Timeout Err coccurs while receiver Retained Related instruc-	ResetECError or ving process data. Not retained. Reset EtherCAT	Global/local Range of values Network Publish	TRUE or FALSE
Variable name Meaning Function Data type R/W access Usage in user program	_EC_PDTimeoutE Process Data Red TRUE if a timeout BOOL R Possible.	Err Ception Timeout Err Coccurs while received Retained Related instructions	ResetECError or ving process data. Not retained. Reset EtherCAT	Global/local Range of values Network Publish	TRUE or FALSE
Variable name Meaning Function Data type R/W access Usage in user program Variable name	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a	Err Ception Timeout Err Coccurs while received Retained Related instructions	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError emission error (can	Range of values Network Publish Controller Error	TRUE or FALSE Published.
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a	Retained Related instructions nsmission Error	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError emission error (can	Range of values Network Publish Controller Error	TRUE or FALSE Published. Global
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit	Retained Related instructions nsmission Error	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError emission error (can	Global/local Range of values Network Publish Controller Error Global/local not send within the	TRUE or FALSE Published. Global Global process data communications period
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL	Retained Related instructions nsmission Error process data transter is over the limit)	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError emission error (canii	Global/local Range of values Network Publish Controller Error Global/local not send within the land send values Network Publish	TRUE or FALSE Published. Global process data communications period
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL R	Retained Related instructions nsmission Error process data transter is over the limit) Retained	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError emission error (canii	Global/local Range of values Network Publish Controller Error Global/local not send within the land send values Network Publish	TRUE or FALSE Published. Global process data communications period
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL R	Retained Related instructions Retained Related instructions Retained Related instructions	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError smission error (candal candal can	Global/local Range of values Network Publish Controller Error Global/local not send within the land send values Network Publish	TRUE or FALSE Published. Global process data communications period
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access Usage in user program	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL R Possible.	Retained Related instructions Retained Related instructions Retained Related instructions	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError smission error (candal candal can	Global/local Range of values Network Publish Controller Error Global/local not send within the land send values Network Publish	TRUE or FALSE Published. Global process data communications period
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access Usage in user program	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL R Possible.	Err Deption Timeout Err Coccurs while received Retained Related instructions Insmission Error Inprocess data transter is over the limit) Retained Related instructions Err	ResetECError or ving process data. Not retained. Reset EtherCAT (ResetECError omission error (candom candom ca	Global/local Range of values Network Publish Controller Error Global/local not send within the Range of values Network Publish Controller Error	TRUE or FALSE Published. Global process data communications period TRUE or FALSE Published.
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning	_EC_PDTimeoutE Process Data Red TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL R Possible. _EC_SlavAdrDup Slave Node Addre	Retained Retained Instructions Retained Related instructions Retained Related instructions Retained Instructions Retained Instructions Retained Instructions Retained Instructions Retained Instructions	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError mission error (candidate) Not retained. Reset EtherCAT ResetECError r	Global/local Range of values Network Publish Controller Error Global/local not send within the land send values Network Publish Controller Error Global/local	TRUE or FALSE Published. Global process data communications period
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL R Possible. _EC_SlavAdrDup Slave Node Addre TRUE if the same	Err Deption Timeout Err Coccurs while received Retained Related instructions Insmission Error Inprocess data transter is over the limit) Retained Related instructions Err	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError mission error (candidate) Not retained. Reset EtherCAT ResetECError r	Global/local Range of values Network Publish Controller Error Global/local not send within the part of values Network Publish Controller Error Global/local e slave.	TRUE or FALSE Published. Global orocess data communications period TRUE or FALSE Published. Global
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type All particles program Data type Meaning Function Data type	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL R Possible. _EC_SlavAdrDup Slave Node Addre TRUE if the same BOOL	Retained Related instructions	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError mission error (candata). Not retained. Reset EtherCAT (candata). Reset EtherCAT (candata).	Global/local Range of values Network Publish Controller Error Global/local not send within the Range of values Network Publish Controller Error Global/local e slave. Range of values	TRUE or FALSE Published. Global process data communications period TRUE or FALSE Published. Global TRUE or FALSE
Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type R/W access Usage in user program Variable name Meaning Function	_EC_PDTimeoutE Process Data Rec TRUE if a timeout BOOL R Possible. _EC_PDSendErr Process Data Tra TRUE if there is a or transmission jit BOOL R Possible. _EC_SlavAdrDup Slave Node Addre TRUE if the same	Retained Retained Instructions Retained Related instructions Retained Related instructions Retained Instructions Retained Instructions Retained Instructions Retained Instructions Retained Instructions	ResetECError or ving process data. Not retained. Reset EtherCAT ResetECError mission error (candidate) Not retained. Reset EtherCAT ResetECError r	Global/local Range of values Network Publish Controller Error Global/local not send within the Range of values Network Publish Controller Error Global/local e slave. Range of values Network Publish	TRUE or FALSE Published. Global orocess data communications period TRUE or FALSE Published. Global

Variable name	EC SlavInitErr				
Meaning	Slave Initialization	n Error		Global/local	Global
Function	TRUE if there is a	an error in an initial	ization command a	iddressed to a slave).
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Controller Error	
		tions	ResetECError		
	•		•		
Variable name	_EC_SlavAppErr				
Meaning	Slave Application	Error		Global/local	Global
Function	TRUE if there is a	an error in the slave	e's application statu	us register.	
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Controller Error	
		tions	ResetECError		
Variable name	_EC_MsgErr				
Meaning	EtherCAT Messa	ge Error		Global/local	Global
Function					or when there is an error in the format
	of the response to	o a message that w	as sent to a slave.		
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc-		(Read CoE SDO)	
		tions	• EC_CoESDO		
				(Write CoE SDO)	
			• EC_CoESDO	vrite	
		_			
Variable name	_EC_SlavEmergl				T
Meaning	Emergency Mess			Global/local	Global
Function		er detects an emer	gency message th	at was sent by a sla	
Data type	BOOL			Range of values	
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions	Reset EtherCAT		
		tions	ResetECError		
Variable name	_EC_IndataInvalid	Err ^{*1}			
Meaning	Input Process Data			Global/local	Global
Function	•			• .	use the EtherCAT master could not
	 When the task per 		•	was in the Operatio	nai siale.
	When the task po			f the task	
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user pro-	Possible.	Related instruc-	Reset EtherCAT C	Controller Error	
gram		tions	ResetECError		

^{*1} This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_EC_CommErrTbl						
Meaning	Communications Error Slave Table			Global/local	Global		
Function	Slaves are given i	Slaves are given in the table in the order of slave node addresses.					
	The corresponding slave element is TRUE if the master detected an error for the slave.						
Data type	ARRAY [1512] O	F BOOL*1		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Reset EtherCAT Controller Error				
		tions	ResetECError				

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.

Note The values of all system-defined variables that are related to errors in EtherCAT communications do not change until the cause of the error is removed and then the error in the Controller is reset with the troubleshooting functions of the Sysmac Studio or the ResetECError instruction.

Variable name	_EC_CycleExceeded							
Meaning	EtherCAT Com	munications Cycl	e Exceeded	Global/local	Global			
Function		TRUE if the CPU Unit cannot establish communications within the set communications period at startup. Note You can use this system-defined variable only for NX-series CPU Units.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

• Functional Classification: EtherCAT Communications Status

Variable name	_EC_RegSlavTbl						
Meaning	Registered Slave Table			Global/local	Global		
Function	This table indicates the slaves that are registered in the network configuration information.						
	Slaves are given in the table in the order of slave node addresses.						
	The element for a slave is TRUE if the corresponding slave is registered.						
Data type	ARRAY [1512] O	F BOOL*1		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.

Variable name	_EC_EntrySlavTbl						
Meaning	Network Connected Slave Table			Global/local	Global		
Function	This table indicates which slaves are connected to the network.						
	Slaves are given i	Slaves are given in the table in the order of slave node addresses.					
	The element for a slave is TRUE if the corresponding slave has entered the network.						
Data type	ARRAY [1512] O	F BOOL*1		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.

Variable name	_EC_MBXSlavTbl						
Meaning	Message Commu	nications Enabled	Slave Table	Global/local	Global		
Function	This table indicate	s the slaves that c	an perform messag	e communications.			
	Slaves are given i	n the table in the o	rder of slave node a	addresses.			
	The element for a slave is TRUE if message communications are enabled for it (pre-operational, safe-operation, or operational state).						
	Note Use this variable to confirm that message communications are possible for the relevant slave before you execute message communications with an EtherCAT slave.						
Data type	ARRAY [1512] O	F BOOL*1		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Disconnect Ether	CAT Slave			
		tions	EC_Disconnect	Slave			
			Connect EtherCA	T Slave			
			EC_ConnectSla	ive			

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.

Variable name	_EC_PDSlavTbl						
Meaning	Process Data Cor	nmunicating Slave	Table	Global/local	Global		
Function	This is a table tha	t indicates the slave	es that are performi	ng process data co	mmunications.		
	Slaves are given i	n the table in the o	rder of slave node a	iddresses.			
	The element for a slave is TRUE if process data of the corresponding slave is enabled (operational) for both slave inputs and outputs.						
	Note Use this variable to confirm that the data for the relevant slave is valid before controlling an EtherCAT slave.						
Data type	ARRAY [1512] O	F BOOL*1		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Disconnect Ether	CAT Slave			
		tions	EC_Disconnects	Slave			
			Connect EtherCA	T Slave			
			EC_ConnectSla	ive			

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.

Variable name	_EC_DisconnSlavTbl						
Meaning	Disconnected Slav	ve Table		Global/local	Global		
Function	Slaves are given i	n the table in the or	der of slave node a	nddresses.			
	The element for a	The element for a slave is TRUE if the corresponding slave was disconnected.					
Data type	ARRAY [1512] O	ARRAY [1512] OF BOOL*1			TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Disconnect Ether	CAT Slave			
		tions	• EC_DisconnectSlave				
			Connect EtherCAT Slave				
			EC_ConnectSla	ive			

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.

Variable name	_EC_DisableSlavTbl					
Meaning	Disabled Slave Table			Global/local	Global	
Function	Slaves are given in the table in the order of slave node addresses.					
	The element for a slave is TRUE if the corresponding slave is disabled.					
Data type	ARRAY [1512] O	F BOOL*1		Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions				

^{*1} For the NX102 CPU Units, NX1P2 CPU Units, and NJ-series CPU Units, the data type is ARRAY [1..192] OF BOOL.

Variable name	_EC_PDActive	_EC_PDActive						
Meaning	Process Data Cor	nmunications Statu	s	Global/local	Global			
Function	TRUE when proce	ess data communic	ations are performe	d with all slaves*.				
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions	Disconnect EtherCAT Slave • EC_DisconnectSlave Connect EtherCAT Slave • EC_ConnectSlave					

^{*} Disabled slaves are not included.

Variable name	_EC_PktMonStop						
Meaning	Packet Monitoring Stopped			Global/local	Global		
Function	TRUE when pack	et monitoring is stop	oped.				
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Stop Packet Moni	Monitor			
		tions	EC_StopMon				
			Start Packet Monitor				
			EC_StartMon				

Variable name	_EC_LinkStatus						
Meaning	Link Status	Link Status			Global		
Function	TRUE if the comm	TRUE if the communications controller link status is Link ON.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions					

Variable name	_EC_PktSaving					
Meaning	Saving Packet Data File			Global/local	Global	
Function	Shows whether a packet data file is being saved.					
	TRUE: Packet dat	TRUE: Packet data file being saved.				
	FALSE: Packet data file not being saved.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	nstruc- Saving Packet Data File			
		tions	EC_SaveMon			

Variable name	_EC_InDataInvalid					
Meaning	Input Data Invalid			Global/local	Global	
Function	TRUE when process data communications performed in the primary periodic task are not normal and the input data is not valid.				ic task are not normal and the input	
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained Not retained.		Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions				

Note All system-defined variables that are related to the status of EtherCAT communications give the current status.

Variable name	_EC_InData1Inva	_EC_InData1Invalid						
Meaning	Input Data1 Invalid			Global/local	Global			
Function	is not valid.		ations performed in ed variable only for		c task are not normal and the input data			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc- tions						

Note All system-defined variables that are related to the status of EtherCAT communications give the current status.

Variable name	_EC_InData2Inva	_EC_InData2Invalid					
Meaning	Input Data2 Invalid			Global/local	Global		
Function	TRUE when process data communications performed i data is not valid. Note You can use this system-defined variable only for Note This variable is always TRUE for the NX102 CPU			NX-series CPU Un	its.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained. Network Publish Published.				
Usage in user program	Possible.	Related instruc- tions					

Note All system-defined variables that are related to the status of EtherCAT communications give the current status.

• Functional Classification: EtherCAT Communications Diagnosis/Statistics Log

Variable name	_EC_StatisticsLogEnable ^{*1}						
Meaning	Diagnosis/Statistics Log Enable			Global/local	Global		
Function	Changes to TRUE	Changes to TRUE when the diagnosis/statistics log is started.					
	Changes to FALS	Changes to FALSE when the diagnosis/statistics log is ended.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	RW	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related instruc-					
gram		tions					

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_EC_StatisticsLog	_EC_StatisticsLogCycleSec ^{*1}					
Meaning	Diagnosis/Statistic	cs Log Cycle		Global/local	Global		
Function	Specifies the interval to write the diagnostic and statistical information of the diagnosis/statistics log in units of seconds. When 0 is specified, the diagnostic and statistical information is written only once when the diagnosis/statistics log						
	 which o is specified, the diagnostic and statistical information is written only once when the diagnosis/statistics log is ended. Note The write interval does not change even if you change the value of this system-defined variable while the diagnosis/statistics log operation is in progress. 						
Data type	UINT			Range of values	0, or 30 to 1800		
R/W access	RW	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_EC_StatisticsLo	_EC_StatisticsLogBusy ^{*1}						
Meaning	Diagnosis/Statistics Log Busy			Global/local	Global			
Function	TRUE while the c	TRUE while the diagnosis/statistics log operation is in progress.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related instruc-						
gram		tions						

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_EC_StatisticsLogErr ^{*1}							
Meaning	Diagnosis/Statistic	Diagnosis/Statistics Log Error Global/local Global						
Function	TRUE when the d	TRUE when the diagnosis/statistics log failed to start or it is impossible to write into the log.						
	The value of this flag is determined when <i>_EC_StatisticsLogBusy</i> (Diagnosis/Statistics Log Busy) changes to FALSE after the diagnosis/statistics log operation is started.							
	The error end is c	aused by the follow	ing.					
	Another records	cannot be added i	n the log file becaus	se the capacity of th	ne SD Memory Card is fully used.			
	The SD Memory	/ Card is write prote	ected.					
	There is no SD	Memory Card.						
	The function can Log Cycle) is in		ause the value spec	cified for _EC_Stati	sticsLogCycleSec (Diagnosis/Statistics			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related instruc-						
gram		tions						

^{*1} This system-defined variable was added for unit version 1.11 of the CPU Unit.

A-7-7 EtherNet/IP Function Module, Category Name: _EIP

• Functional Classification: EtherNet/IP Communications Errors

Variable name	_EIP_ErrSta							
Meaning	Built-in EtherNet/I	P Error		Global/local	Global			
Function	This is the error st	This is the error status variable for the built-in EtherNet/IP port.						
	NX-series CPU U	nits: Represents the	e collective status o	of the following error	flags.			
	• _EIP1_PortErr (Communications P	ort1 Error)					
	• _EIP2_PortErr (Communications P	ort2 Error)					
	`	CIP Communication	,					
		CIP Communication						
	_EIP_TcpAppErr (TCP Application Communications Error)							
	NJ-series CPU Units: Represents the collective status of the following error flags.							
	_EIP_PortErr (Communications Port Error)							
	_EIP_CipErr (CIP Communications Error)							
	_EIP_TcpAppErr (TCP Application Communications Error)							
	Note Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.							
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc- tions	You can access the instruction.	nis variable from the	user program with the following			
			GetEIPError					

Variable name	_EIP_PortErr						
Meaning	Communications I	Port Error		Global/local	Global		
Function	This is the error status variable for the communications port.						
	NX-series CPU Units: Represents the collective status of the following error flags.						
	• _EIP1_MacAdrErr (Port1 MAC Address Error)						
	_EIP1_LanHwErr (Port1 Communications Controller Error)						
	_EIP1_EtnCfgErr (Port1 Basic Ethernet Setting Error)						
	• _EIP1_IPAdrCfg	g <i>Err</i> (Port1 IP Addre	ess Setting Error)				
		•	ess Duplication Erro	or)			
		r (Port1 BOOTP Se	•				
	_EIP_DNSCfgErr (DNS Setting Error)						
	• _EIP_DNSSrvErr (DNS Server Connection Error)						
	• _EIP_IPRTblErr (IP Route Table Error)						
	NJ-series CPU Units: Represents the collective status of the following error flags.						
	• _EIP_MacAdrErr (MAC Address Error)						
	• _EIP_LanHwErr (Communications Controller Error)						
	• _EIP_EtnCfgErr (Basic Ethernet Setting Error)						
	_EIP_IPAdrCfgErr (IP Address Setting Error) EIP IPAdrDupErr (IP Address Duplication Error)						
	EIP BootpErr (BOOTP Server Error)						
	EIP_DNSSrvErr (DNS Server Connection Error)						
	EIP IPRTblErr (IP Route Table Error)						
	Note If a Link OFF Detected or Built-in EtherNet/IP Processing Error occurs, it is recorded in the event log and then corresponding bit turns ON. Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc- tions	You can access th instruction.	is variable from the	e user program with the following		
			GetEIPError				

Variable name	_EIP1_PortErr						
Meaning	Communications F	Port1 Error		Global/local	Global		
Function	This is the error st	atus variable for the	e communications p	oort 1.			
	It represents the c	ollective status of t	ne following error fla	ags.			
	EIP1 MacAdrE	Err (Port1 MAC Add	ress Error)				
		•	cations Controller E	rror)			
			ernet Setting Error)	•			
	• _EIP1_IPAdrCfg	<i>Err</i> (Port1 IP Addre	ess Setting Error)				
	• _EIP1_IPAdrDuj	<i>Err</i> (Port1 IP Addr	ess Duplication Erro	or)			
	• _EIP1_BootpErr	(Port1 BOOTP Se	rver Error)				
	• _EIP_DNSCfgE	rr (DNS Setting Err	or)				
	• _EIP_DNSSrvE	rr (DNS Server Cor	nnection Error)				
	• _EIP_IPRTblErr	(IP Route Table Er	ror)				
	 Note If a Link OFF Detected or Built-in EtherNet/IP Processing Error occurs, it is recorded in the event log and then corresponding bit turns ON. Refer to A-6-8 Meanings of Error Status Bits for the meanings of the erro status bits. Note You can use this system-defined variable only for NX-series CPU Units. 						
Data type	WORD	and dyelenn demin		Range of values			
R/W access	R	Retained	Not retained.	Network Publish			
Usage in user program	Possible. Related instructions You can access this variable from the user program with the following instruction.						
	GetEIPError						
Variable name	EIP2 PortErr						
Meaning	Communications F	Port2 Error		Global/local	Global		
Function	This is the error st	atus variable for the	e communications p	port 2.			
	It represents the c	ollective status of t	he following error fla	ags.			
	• _EIP2_MacAdrE	Err (Port2 MAC Add	ress Error)				
	• _EIP2_LanHwE	rr (Port2 Communic	cations Controller E	rror)			
	_EIP2_EtnCfgErr (Port2 Basic Ethernet Setting Error)						
	• _EIP2_EthCtgE	rr (Port2 Basic Ethe	ernet Setting Error)				
		rr (Port2 Basic Ethe <i>Err</i> (Port2 IP Addre					
	• _EIP2_IPAdrCfg	Err (Port2 IP Addre		or)			
	• _EIP2_IPAdrCfg • _EIP2_IPAdrDup	Err (Port2 IP Addre	ess Setting Error) ess Duplication Erro	or)			
	_EIP2_IPAdrCfg _EIP2_IPAdrDup _EIP2_BootpErr _EIP_DNSCfgEr	nErr (Port2 IP Addre DErr (Port2 IP Addre Tr (Port2 BOOTP Se Tr (DNS Setting Err	ess Setting Error) ess Duplication Error rver Error) or)	or)			
	• _EIP2_IPAdrCfg • _EIP2_IPAdrDup • _EIP2_BootpErr • _EIP_DNSCfgEr • _EIP_DNSSrvEr	Err (Port2 IP Addre DErr (Port2 IP Addr (Port2 BOOTP Se Tr (DNS Setting Err Tr (DNS Server Cor	ess Setting Error) ess Duplication Error rver Error) or) nnection Error)	or)			
	• _EIP2_IPAdrCfg • _EIP2_IPAdrDup • _EIP2_BootpErr • _EIP_DNSCfgEr • _EIP_DNSSrvEr	nErr (Port2 IP Addre DErr (Port2 IP Addre Tr (Port2 BOOTP Se Tr (DNS Setting Err	ess Setting Error) ess Duplication Error rver Error) or) nnection Error)	or)			
	_EIP2_IPAdrCfg _EIP2_IPAdrDup _EIP2_BootpErr _EIP_DNSCfgEr _EIP_DNSSrvEr _EIP_IPRTbIErr Note If a Link OF	DETR (Port2 IP Address DETR (Port2 IP Address PORT2 BOOTP See PORT2 BOOTP SETT PORT3 SETT (DNS SETT CORT) PORT3 SETT (IP Route Table ER PORT3 SETT CORT) PORT4 IP ROUTE TABLE TO THE PORT5 IP ADDRESS PORT5 IP ADD	ess Setting Error) ess Duplication Error rver Error) or) nnection Error) ror) t-in EtherNet/IP Pro	ocessing Error occu			
	_EIP2_IPAdrCfg _EIP2_IPAdrDup _EIP2_BootpErr _EIP_DNSCfgEr _EIP_DNSSrvEr _EIP_IPRTbIErr Note If a Link OF then corresponders status bits.	DETR (Port2 IP Address DETR (Port2 IP Address PORT2 BOOTP See PORT2 BOOTP See PORT3 Setting Err PORT3 Server Cor PORT4 Server Cor PORT5 Server	ess Setting Error) ess Duplication Error rver Error) or) nnection Error) ror) t-in EtherNet/IP Pro N. Refer to A-6-8 M	ocessing Error occuleanings of Error St	urs, it is recorded in the event log and atus Bits for the meanings of the error		
Data type	_EIP2_IPAdrCfg _EIP2_IPAdrDup _EIP2_BootpErr _EIP_DNSCfgEr _EIP_DNSSrvEr _EIP_IPRTbIErr Note If a Link OF then corresponders status bits.	DETR (Port2 IP Address DETR (Port2 IP Address PORT2 BOOTP See PORT2 BOOTP See PORT3 Setting Err PORT3 Server Cor PORT4 Server Cor PORT5 Server	ess Setting Error) ess Duplication Error rver Error) or) nnection Error) ror) t-in EtherNet/IP Pro N. Refer to A-6-8 M	ocessing Error occuleanings of Error St	atus Bits for the meanings of the erro		

instruction.GetEIPError

You can access this variable from the user program with the following

Possible.

Related instruc-

Usage in user program

Variable name	_EIP_CipErr						
Meaning	CIP Communication	ons Error		Global/local	Global		
Function	This is the error status variable for CIP communications.						
	NX-series CPU Units: Represents the collective status of the following error flags.						
	• _EIP1_IdentityErr (CIP Communications1 Identity Error)						
	_EIP1_TDLinkCfgErr (CIP Communications1 Tag Data Link Setting Error)						
			unications1 Tag Dat				
			ations1 Tag Data Lir		s Error)		
		•	ations1 Tag Name F	,			
		•	unications1 Multiple		•		
	NJ-series CPU Units: Represents the collective status of the following error flags.						
	• _EIP_IdentityErr (Identity Error)						
	_EIP_TDLinkCfgErr (Tag Data Link Setting Error) _EIP_TDLinkOpnErr (Tag Data Link Connection Failed)						
	• _EIP_TDLinkErr (Tag Data Link Communications Error)						
	• _EIP_TagAdrErr (Tag Name Resolution Error)						
	_EIP_MultiSwOnErr (Multiple Switches ON Error)						
	Note If a Tag Name Resolution Error occurs, it is recorded in the event log and this variable changes to TRUE.						
	Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions	You can access the instruction.	nis variable from the	e user program with the following		
			GetEIPError				
Variable name	_EIP1_CipErr						
Meaning	CIP Communication	ons1 Error		Global/local	Global		
Function	This is the error st	tatus variable for C	IP communications	1.			
	It represents the c	collective status of t	he following error fla	ags.			
	It represents the collective status of the following error flags. • _EIP1_IdentityErr (CIP Communications1 Identity Error)						
	_EIP1_TDLinkCfgErr (CIP Communications1 Tag Data Link Setting Error)						

Function	This is the error status variable for CIP communications 1.						
	It represents the collective status of the following error flags.						
	EIP1 IdentityErr (CIP Communications1 Identity Error)						
	'	•	•	, Link Setting Error)			
	• _EIP1_TDLinkC	OpnErr (CIP Commu	unications1 Tag Dat	a Link Connection F	⁼ ailed)		
	• _EIP1_TDLinkE	Err (CIP Communica	ations1 Tag Data Lir	nk Communications	Error)		
	• _EIP1_TagAdrE	Err (CIP Communica	ations1 Tag Name R	Resolution Error)			
	• _EIP1_MultiSw	O <i>NErr</i> (CIP Commu	ınications1 Multiple	Switches ON Error)		
				ded in the event log ie meanings of the	g and this variable changes to TRUE. error status bits.		
	Note You can use	e this system-define	ed variable only for	NX-series CPU Uni	its.		
Data type	WORD			Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					
			GetEIPError				

Function	CIP Communica	ations2 Error						
	This is the error			Global/local	Global			
		This is the error status variable for CIP communications 2.						
	It represents the collective status of the following error flags.							
	• _EIP2_Identit	yErr (CIP Commi	unications2 Ident	ity Error)				
	• _EIP2_TDLini	k <i>CfgErr</i> (CIP Cor	nmunications2 Ta	ag Data Link Setting Error)			
				ag Data Link Connection	•			
			_	Data Link Communications	Error)			
		`	ū	Name Resolution Error)				
·	• _EIP2_MUITIS	WONER (CIP Co	mmunications2 i	Multiple Switches ON Error)			
	Note If a Tag Name Resolution Error occurs, it is recorded in the event log and this variable changes to TRUE Refer to <i>A-6-8 Meanings of Error Status Bits</i> for the meanings of the error status bits.							
1	Note You can u	use this system-d	efined variable o	nly for the NX701 CPU Ur	nits and NX102 CPU Units.			
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related	You can access	this variable from the use	r program with the following instruction.			
		instructions	GetEIPError					
Variable name	_EIP_TcpAppEr	r						
Meaning	TCP Application	Communication	s Error	Global/local	Global			
Function	This is the error	status variable fo	or TCP applicatio	n communications.				
	It represents the	It represents the collective status of the following error flags.						
	• _EIP_TcpApp	CfgErr (TCP App	lication Setting E	Error)				
•	• _EIP_NTPSrv	Err (NTP Server	Connection Erro	r)				

Variable name	_EIP_MacAdrErr								
Meaning	MAC Address E	Error		Global/local	Global				
Function	NX-series CPU Units: Indicates that an error occurred when the MAC address was read on the communications port 1 at startup.								
	TRUE: Error								
	FALSE: Norma	l							
	NJ-series CPU Units: Indicates that an error occurred when the MAC address was read at startup.								
	NJ-series CPU	Units: Indicates t	hat an error occu	urred when the MAC add	lress was read at startup.				
	NJ-series CPU TRUE: Error	Units: Indicates t	hat an error occu	urred when the MAC add	dress was read at startup.				
			hat an error occเ	urred when the MAC add	lress was read at startup.				
Data type	TRUE: Error		hat an error occເ	Range of values	TRUE or FALSE				
Data type R/W access	TRUE: Error FALSE: Norma		hat an error occu						

Note Refer to A-6-8 Meanings of Error Status Bits for the meanings of the error status bits.

Not retained.

GetEIPError

Range of values

Network Publish

16#0000 to 16#00F0

Published.

You can access this variable from the user program with the following instruction.

WORD

Possible.

Retained

Related

instructions

R

Data type

R/W access

Usage in user program

Variable name	_EIP1_MacAdrErr							
Meaning	Port1 MAC Add	ress Error		Global/local	Global			
Function	Indicates that an error occurred when the MAC address was read on the communications port 1 at startup. TRUE: Error FALSE: Normal							
	Note You can use this system-defined variable only for NX-series CPU Units.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						
Variable name	_EIP2_MacAdr							
Meaning	Port2 MAC Add			Global/local	Global			
Function	Indicates that a TRUE: Error FALSE: Normal	n error occurred		address was read on the	e communications port 2 at startup. J Units and NX102 CPU Units.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						
Variable name Meaning	_EIP_LanHwEr	r is Controller Erro	or	Global/local	Global			
Function	TRUE: Failure FALSE: Normal	Units: Indicates		ations controller failure	occurred on the communications port 1. occurred.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						
Variable name	EID4 Lanthus	-rr						
Variable name	_EIP1_LanHwE		or Error	Global/local	Clobal			
Meaning Function		communications			Global			
Function	Indicates that a communications controller failure occurred on the communications port 1. TRUE: Failure FALSE: Normal Note You can use this system-defined variable only for NX-series CPU Units.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP2_LanHwErr						
Meaning	Port2 Commun	Port2 Communications Controller Error Global/local Global					
Function	Indicates that a	Indicates that a communications controller failure occurred on the communications port 2.					
	TRUE: Failure	TRUE: Failure					
	FALSE: Norma	I					
	Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					
Variable name	_EIP_EtnCfgEr	r					
Meaning	Basic Ethernet	Basic Ethernet Setting Error Global/local Global					
Function		NX-series CPU Units: Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 1 is incorrect. Or a read operation failed					

Variable name	_EIP_EtnCfgErr						
Meaning	Basic Ethernet	asic Ethernet Setting Error Global/local Global					
Function	NX-series CPU Units: Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 1 is incorrect. Or, a read operation failed.						
	TRUE: Setting i	incorrect or read	failed				
	FALSE: Normal						
	NJ-series CPU Units: Indicates that the Ethernet communications speed setting (Speed/Duplex) is incorrect. Or, a read operation failed.						
	TRUE: Setting i	ncorrect or read	failed				
	FALSE: Normal						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP1_EtnCtgErr								
Meaning	Port1 Basic Eth	Port1 Basic Ethernet Setting Error Global/local Global							
Function		Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 1 is incorrect. Or, a read operation failed.							
	TRUE: Setting i	TRUE: Setting incorrect or read failed							
	FALSE: Normal								
	Note You can	use this system-o	defined variable o	only for NX-series CPU U	nits.				
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained. Network Publish Published.						
Usage in user program	Possible.	Related instructions							

Variable name	_EIP2_EtnCfgErr						
Meaning	Port2 Basic Eth	ort2 Basic Ethernet Setting Error Global/local Global					
Function	Indicates that the Ethernet communications speed setting (Speed/Duplex) for the communications port 2 is incorrect. Or, a read operation failed. TRUE: Setting incorrect or read failed FALSE: Normal Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained. Network Publish Published.				
Usage in user program	Possible.	Related instructions					

Variable name	_EIP_IPAdrCfgErr					
Meaning	IP Address Sett	ing Error		Global/local	Global	
Function	NX-series CPU Units: Indicates the IP address setting errors for the communications port 1. TRUE: • There is an illegal IP address setting. • A read operation failed. • The IP address obtained from the BOOTP server is inconsistent. FALSE: Normal NJ-series CPU Units: Indicates the IP address setting errors. TRUE: • There is an illegal IP address setting. • A read operation failed. • The IP address obtained from the BOOTP server is inconsistent. • The default gateway settings are not correct. FALSE: Normal					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions				
Variable name	_EIP1_IPAdrCfgErr					
Meaning	Port1 IP Addres	ss Setting Error		Global/local	Global	
	TRUE: • There is an illegal IP address setting. • A read operation failed. • The IP address obtained from the BOOTP server is inconsistent. FALSE: Normal Note You can use this system-defined variable only for NX-series CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions				
Variable name	_EIP2_IPAdrCf	gErr				
Meaning	Port2 IP Addres	ss Setting Error		Global/local	Global	
Function	Indicates the IP address setting errors for the communications port 2. TRUE: • There is an illegal IP address setting. • A read operation failed. • The IP address obtained from the BOOTP server is inconsistent. FALSE: Normal Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions				

Variable name	_EIP_IPAdrDup	_EIP_IPAdrDupErr						
Meaning	IP Address Duplication Error Global/local Global							
Function	NX-series CPU Units: Indicates that the same IP address is assigned to more than one node for the communications port 1.							
	TRUE: Duplicat	ion occurred.						
	FALSE: Other to	han the above.						
	NJ-series CPU	Units: Indicates t	hat the same IP a	address is assigned to mo	re than one node.			
	TRUE: Duplicat	ion occurred.						
	FALSE: Other to	han the above.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP1_IPAdrDupErr						
Meaning	Port1 IP Addres	s Duplication En	ror	Global/local	Global		
Function	Indicates that the same IP address is assigned to more than one node for the communications port 1. TRUE: Duplication occurred. FALSE: Other than the above. Note You can use this system-defined variable only for NX-series CPU Units.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP2_IPAdrDu	_EIP2_IPAdrDupErr						
Meaning	Port2 IP Addres	s Duplication Err	or	Global/local	Global			
Function	Indicates that th	Indicates that the same IP address is assigned to more than one node for the communications port 2.						
	TRUE: Duplicat	TRUE: Duplication occurred.						
	FALSE: Other to	FALSE: Other than the above.						
	Note You can i	Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related						
gram		instructions						

Variable name	_EIP_DNSCfgErr*1						
Meaning	DNS Setting Er	ror		Global/local	Global		
Function	Indicates that the	Indicates that the DNS or hosts settings are incorrect. Or, a read operation failed.					
	TRUE: Setting i	TRUE: Setting incorrect or read failed					
	FALSE: Normal	FALSE: Normal					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related					
gram		instructions					

^{*1} With the NJ-series CPU Unit, this variable can be used with the unit version 1.11 or later.

Variable name	_EIP_BootpErr							
Meaning	BOOTP Server	Error		Global/local	Global			
Function	NX-series CPU	Units: Indicates	that a BOOTP s	erver connection failure	e occurred on the communications port 1.			
	TRUE: There was a failure to connect to the BOOTP server (timeout).							
		FALSE: The BOOTP is not enabled, or BOOTP is enabled and an IP address was normally obtained from the						
	BOOTP server.		,		,			
	N.I-series CPU	Units: Indicates t	that a BOOTP se	erver connection failure	occurred			
				OTP server (timeout).	occurred.			
				,	Idraca was narmally obtained from the			
		TP server.	nied, of BOOTP i	s enabled and an IP ac	Idress was normally obtained from the			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related		Network Fubilish	i ublisticu.			
gram	l Ossible.	instructions						
gram		moduciono						
Variable name	_EIP1_BootpEr							
Meaning	Port1 BOOTP S			Global/local	Global			
Function	Indicates that a	BOOTP server of	connection failure	e occurred on the comr	nunications port 1.			
	TRUE: There w	as a failure to co	nnect to the BO	OTP server (timeout).				
	FALSE: The BC	OTP is not enab	led, or BOOTP i	s enabled and an IP ac	Idress was normally obtained from the			
	BOOTP server.							
	Note You can i	use this system-	defined variable	only for NX-series CPU	I I Inite			
Data type	BOOL	use tills system-c	delined variable	Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
	Possible.	Related		Metwork Fubilish	Fublished.			
Usage in user program	Possible.	instructions	l					
9								
Variable name	_EIP2_BootpEr			1				
Meaning	Port2 BOOTP S	Server Error		Global/local	Global			
	Port2 BOOTP S Indicates that a	Server Error BOOTP server o		e occurred on the comr				
Meaning	Port2 BOOTP S Indicates that a TRUE: There w	Server Error BOOTP server of as a failure to co	nnect to the BO	e occurred on the common of th	nunications port 2.			
Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO	Server Error BOOTP server of the server of t	nnect to the BO	e occurred on the common of th				
Meaning	Port2 BOOTP S Indicates that a TRUE: There w	Server Error BOOTP server of the server of t	nnect to the BO	e occurred on the common of th	nunications port 2.			
Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server.	Server Error BOOTP server of as a failure to co DOTP is not enab	nnect to the BOoled, or BOOTP i	e occurred on the comr OTP server (timeout). s enabled and an IP ac	nunications port 2.			
Meaning Function	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server.	Server Error BOOTP server of as a failure to co DOTP is not enab	nnect to the BOoled, or BOOTP ided, or BOOTP ided	e occurred on the common the common that is enabled and an IP according for the NX701 CPU	nunications port 2. Idress was normally obtained from the J Units and NX102 CPU Units.			
Meaning Function Data type	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can	Server Error BOOTP server of as a failure to co DOTP is not enab	nnect to the BOoled, or BOOTP ided, or BOOTP ided	e occurred on the comr OTP server (timeout). s enabled and an IP ac	nunications port 2. Idress was normally obtained from the J Units and NX102 CPU Units.			
Meaning Function Data type R/W access	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can	Server Error BOOTP server of as a failure to co DOTP is not enab	nnect to the BOoled, or BOOTP i	e occurred on the common the common that is enabled and an IP acounty for the NX701 CPU Range of values	nunications port 2. Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE			
Meaning Function Data type R/W access Usage in user pro-	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be	Server Error BOOTP server of as a failure to condition of the condition of	nnect to the BOOled, or BOOTP idefined variable.	e occurred on the common the common that is enabled and an IP acounty for the NX701 CPU Range of values	nunications port 2. Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE			
Meaning Function Data type R/W access Usage in user pro-	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be	Server Error BOOTP server of as a failure to condition of the condition of	nnect to the BOOled, or BOOTP idefined variable.	e occurred on the common the common that is enabled and an IP acounty for the NX701 CPU Range of values	nunications port 2. Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE			
Meaning Function Data type R/W access Usage in user program	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be BOOL R Possible.	Server Error BOOTP server of as a failure to co DOTP is not enabuse this system-of Retained Related instructions	nnect to the BOOled, or BOOTP idefined variable.	e occurred on the common the common that is enabled and an IP acounty for the NX701 CPU Range of values	nunications port 2. Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE			
Meaning Function Data type R/W access Usage in user program Variable name	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be BOOL R Possible.	Server Error BOOTP server of as a failure to co DOTP is not enabuse this system-of Retained Related instructions	nnect to the BOOled, or BOOTP idefined variable.	e occurred on the common of th	dress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published.			
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can b BOOL R Possible. _EIP_IPRTblEr IP Route Table	Server Error BOOTP server of as a failure to coport is not enable use this system-of Retained Related instructions	nnect to the BOoled, or BOOTP idefined variable. Not retained.	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global			
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be BOOL R Possible. EIP_IPRTbIEr IP Route Table NX-series CPU	Berver Error BOOTP server of as a failure to co DOTP is not enable use this system-of the system-of	nnect to the BOoled, or BOOTP idefined variable. Not retained.	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global			
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can b BOOL R Possible. _EIP_IPRTblEr IP Route Table NX-series CPU operation failed	Server Error BOOTP server of as a failure to co OOTP is not enabuse this system-of the	nnect to the BOO pled, or BOOTP i defined variable of Not retained.	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global			
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be BOOL R Possible. EIP_IPRTblEr IP Route Table NX-series CPU operation failed TRUE: Setting	Server Error BOOTP server of as a failure to co DOTP is not enabluse this system-of the system-of th	nnect to the BOO pled, or BOOTP i defined variable of Not retained.	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global			
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can b BOOL R Possible. _EIP_IPRTblEr IP Route Table NX-series CPU operation failed	Server Error BOOTP server of as a failure to co DOTP is not enabluse this system-of the system-of th	nnect to the BOO pled, or BOOTP i defined variable of Not retained.	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global			
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be BOOL R Possible. EIP_IPRTblEr IP Route Table NX-series CPU operation failed TRUE: Setting	Server Error BOOTP server of as a failure to co DOTP is not enabluse this system-of the system-of th	nnect to the BOO pled, or BOOTP i defined variable of Not retained.	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global			
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can b BOOL R Possible. EIP_IPRTbIEr IP Route Table NX-series CPU operation failed TRUE: Setting FALSE: Normal	Berver Error BOOTP server of as a failure to co DOTP is not enabuse this system-of Retained Related instructions r Error Units: Indicates in incorrect or read	nnect to the BOoled, or BOOTP is defined variable. Not retained that the default grailed.	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global Global Duter table settings are incorrect. Or, a rea			
Meaning Function Data type R/W access Usage in user program Variable name	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be book as a book and book are book as a book are book a	Berver Error BOOTP server of as a failure to co DOTP is not enabuse this system-of Retained Related instructions r Error Units: Indicates in incorrect or read	nnect to the BOO pled, or BOOTP i defined variable of Not retained that the default g failed	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global Global Duter table settings are incorrect. Or, a rea			
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be book as a book and book are book as a book are book a	Server Error BOOTP server of as a failure to co DOTP is not enabluse this system-of sy	nnect to the BOO pled, or BOOTP i defined variable of Not retained that the default g failed	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global Global Duter table settings are incorrect. Or, a rea			
Meaning Function Data type R/W access Usage in user program Variable name Meaning Function	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be book as a book and book are book as a book are book ar	Server Error BOOTP server of as a failure to co DOTP is not enabluse this system-of sy	nnect to the BOO pled, or BOOTP i defined variable of Not retained that the default g failed	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global Outer table settings are incorrect. Or, a rea			
Meaning Function Data type R/W access Usage in user program Variable name Meaning Function Data type	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be book R Possible. EIP_IPRTblEr IP Route Table NX-series CPU operation failed TRUE: Setting in FALSE: Normal NJ-series CPU TRUE: Setting in FALSE: Normal BOOL	Retained Related instructions r Error Units: Indicates to read	nnect to the BOO pled, or BOOTP i defined variable or BOOTP i defined variable or BOOTP i not retained. that the default g failed that the IP router failed	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global Outer table settings are incorrect. Or, a read			
Meaning Function Data type R/W access Usage in user program Variable name Meaning Function	Port2 BOOTP S Indicates that a TRUE: There w FALSE: The BO BOOTP server. Note You can be BOOL R Possible. EIP_IPRTblEr IP Route Table NX-series CPU operation failed TRUE: Setting is FALSE: Normal	Server Error BOOTP server of as a failure to co DOTP is not enabluse this system-of sy	nnect to the BOO pled, or BOOTP i defined variable of Not retained that the default g failed	e occurred on the common of th	Idress was normally obtained from the J Units and NX102 CPU Units. TRUE or FALSE Published. Global Outer table settings are incorrect. Or, a read are incorrect. Or, a read operation failed. TRUE or FALSE			

Variable name	_EIP_IdentityEr	_EIP_IdentityErr					
Meaning	Identity Error	Identity Error Global/local Global					
Function	NX-series CPU Units: Indicates that the identity information for CIP communications 1 (which you cannot overwrite) is incorrect. Or, a read operation failed.						
	TRUE: Setting i	ncorrect or read	failed				
	FALSE: Normal						
	N Learies CDII	Unite: Indicates t	hat the identity in	formation (which you can	not overwrite) is incorrect. Or, a read		
	operation failed		nat the identity in	normation (which you can	iot overwitte) is incorrect. Of, a read		
	TRUE: Setting i	ncorrect or read	failed				
	FALSE: Normal						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP1_IdentityErr							
Meaning	CIP Communica	ations1 Identity E	rror	Global/local	Global			
Function	Indicates that the identity information for CIP communications 1 (which you cannot overwrite) is incorrect. Or, a read operation failed.							
	TRUE: Setting i	ncorrect or read	failed					
	FALSE: Normal							
	Note You can	use this system-d	lefined variable o	nly for NX-series CPU Un	its.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained. Network Publish Published.					
Usage in user pro-	Possible.	Related						
gram		instructions						

Variable name	_EIP2_IdentityErr						
Meaning	CIP Communic	ations2 Identity E	rror	Global/local	Global		
Function		Indicates that the identity information for CIP communications 2 (which you cannot overwrite) is incorrect. Or, a read operation failed.					
	TRUE: Setting	ncorrect or read	failed				
	FALSE: Normal						
	Note You can	use this system-c	defined variable o	only for the NX701 CPU U	nits and NX102 CPU Units.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP_TDLinkCfgErr						
Meaning	Tag Data Link S	Setting Error		Global/local	Global		
Function	NX-series CPU Units: Indicates that the tag data link settings for CIP communications 1 are incorrect. Or, a read operation failed.						
	TRUE: Setting i	ncorrect or read	failed				
	FALSE: Normal						
	NJ-series CPU	Units: Indicates t	hat the tag data I	ink settings are incorrect.	Or, a read operation failed.		
	TRUE: Setting i	ncorrect or read	failed				
	FALSE: Normal						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP1_TDLinkCfgErr						
Meaning		ations1 Tag Data	Link Setting	Global/local	Global		
	Error						
Function	Indicates that the	ne tag data link se	ettings for CIP co	mmunications 1 are incorr	ect. Or, a read operation failed.		
	TRUE: Setting i	ncorrect or read	failed				
	FALSE: Normal						
	Note You can	use this system-c	lefined variable o	nly for NX-series CPU Un	its.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related					
gram		instructions					

Variable name	_EIP2_TDLink(_EIP2_TDLinkCfgErr						
Meaning	CIP Communic Error	CIP Communications2 Tag Data Link Setting Global/local Global Error						
Function	Indicates that the	ne tag data link se	ettings for CIP co	mmunications 2 are incor	rect. Or, a read operation failed.			
	TRUE: Setting	ncorrect or read	failed					
	FALSE: Normal							
	Note You can	use this system-c	defined variable o	only for the NX701 CPU U	nits and NX102 CPU Units.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related						
gram		instructions						

Variable name	EIP TDLinkOpnErr							
Variable name	'							
Meaning	Tag Data Link C	Connection Failed		Global/local	Global			
Function	NX-series CPU	Units: Indicates th	at establishing a t	ag data link connection for	CIP communications 1 failed.			
	TRUE: Establis	ning a tag data lir	nk connection fail	ed due to one of the follow	wing causes.			
		formation registe information.	red for a target n	ode in the tag data link pa	rameters is different from the actual			
	•There	was no response	from the remote	node.				
	FALSE: Other tl	nan the above.						
	NJ-series CPU	Units: Indicates t	hat establishing a	a tag data link connection	failed.			
	TRUE: Establis	ning a tag data lir	nk connection fail	ed due to one of the follow	wing causes.			
		formation registe information.	red for a target n	ode in the tag data link pa	rameters is different from the actual			
	•There	was no response	from the remote	node.				
	FALSE: Other to	nan the above.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related						
gram		instructions						

Variable name	EIP1 TDLink	EIP1 TDLinkOpnErr								
Meaning		ations1 Tag Data	Link Connec-	Global/local	Global					
Function	Indicates that establishing a tag data link connection for CIP communications 1 failed.									
	TRUE: Establis	hing a tag data li	nk connection fa	iled due to one of the f	ollowing causes.					
		nformation registe e information.	red for a target i	node in the tag data lin	k parameters is different from the actual					
	•There	was no response	e from the remot	e node.						
	FALSE: Other t	han the above.								
	Note You can	use this system.	defined variable	only for NX-series CPU	LUnite					
Data type	BOOL	doc tillo oyotcill-c	deliried variable	Range of values	TRUE or FALSE					
R/W access	R	Retained	Not retained.	Network Publish	Published.					
Usage in user pro- gram	Possible.	Related instructions								
	•									
Variable name	_EIP2_TDLink(OpnErr								
Meaning	CIP Communic	ations2 Tag Data	Link Connec-	Global/local	Global					
	tion Failed									
Function				n for CIP communication						
				iled due to one of the f						
		•	red for a target r	node in the tag data lin	k parameters is different from the actual					
		node information.								
	•There was no response from the remote node.									
	FALSE: Other t	FALSE: Other than the above.								
	Note You can	use this system-c	defined variable	only for the NX701 CP	U Units and NX102 CPU Units.					
Data type	BOOL			Range of values	TRUE or FALSE					
R/W access	R	Retained	Not retained.	Network Publish	Published.					
Usage in user pro- gram	Possible.	Related instructions								
Variable name	_EIP_TDLinkE		_	01.1.1/1						
Meaning		Communications		Global/local	Global					
Function			iat a timeout occi	irred in a tag data link o	onnection for CIP communications 1.					
	TRUE: A timeo									
	FALSE: Other than the above.									
										
			at a timeout occu	rred in a tag data link co	onnection.					
	TRUE: A timeo									
	FALSE: Other t	han the above.								
Data type	BOOL		I	Range of values	TRUE or FALSE					
R/W access	R	Retained	Not retained.	Network Publish	Published.					
Usage in user pro- gram	Possible.	Related instructions								
Variable name	_EIP1_TDLinkl		Link C	Clabal"===1	Clobal					
Meaning	cations Error	ations1 Tag Data	Link Communi-	Global/local	Global					
	Indicates that a timeout occurred in a tag data link connection for CIP communications 1.									
Function	indicates that a	TRUE: A timeout occurred.								
Function				TRUE: A timeout occurred. FALSE: Other than the above.						
Function	TRUE: A timeo	ut occurred.								
Function	TRUE: A timeo	ut occurred. han the above.	dofined weri-ble	only for NV on-in- CDI	LUcito					
	TRUE: A timeo FALSE: Other t Note You can	ut occurred. han the above.	defined variable	only for NX-series CPU						
Data type	TRUE: A timeo FALSE: Other t Note You can BOOL	ut occurred. han the above. use this system-c		Range of values	TRUE or FALSE					
Pata type R/W access Usage in user pro-	TRUE: A timeo FALSE: Other t Note You can	ut occurred. han the above.	Not retained.							

gram

instructions

Variable name	_EIP2_TDLinkErr							
Meaning	CIP Communications2 Tag Data Link Communications Error Global/local Global							
Function	Indicates that a t	imeout occurred i	n a tag data link o	onnection for CIP commun	ications 2.			
	TRUE: A timeou	it occurred.						
	FALSE: Other th	nan the above.						
	Note You can u	use this system-d	defined variable o	nly for the NX701 CPU Ur	nits and NX102 CPU Units.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained. Network Publish Published.					
Usage in user pro-	Possible.	Related						
gram		instructions						

Variable name	_EIP_TagAdrEr	r						
Meaning	Tag Name Reso			Global/local	Global			
Function		Units: Indicates th	at tag resolution fo	or CIP communications 1 fa	ailed (i.e., the address could not be identi-			
	TRUE: Tag reso	olution failed (i.e.,	the address cou	ld not be identified from the	ne tag name). The following causes are			
	•The si	ze of the network	variable is differ	ent from the tag settings.				
		O direction that is in the CPU Unit.	set in the tag da	ta link settings does not a	agree with the I/O direction of the vari-			
	•There	is no network va	riable in the CPU	Unit that corresponds to	the tag setting.			
	FALSE: Other t	han the above.						
	NJ-series CPU Units: Indicates that tag resolution failed (i.e., the address could not be identified from the tag name).							
	TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.							
	•The size of the network variable is different from the tag settings.							
	•The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the CPU Unit.							
	•There is no network variable in the CPU Unit that corresponds to the tag setting.							
	FALSE: Other t	FALSE: Other than the above.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP1_TagAdrErr							
Meaning	CIP Communica Error	ations1 Tag Name	e Resolution	Global/local	Global			
Function	Indicates that tag resolution for CIP communications 1 failed (i.e., the address could not be identified from the tag name).							
	TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.							
	•The size of the network variable is different from the tag settings.							
	•The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the CPU Unit.							
	•There is no network variable in the CPU Unit that corresponds to the tag setting.							
	FALSE: Other than the above.							
	Note You can use this system-defined variable only for NX-series CPU Units.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP2_TagAdrErr							
Meaning	CIP Communica Error	ations2 Tag Name	e Resolution	Global/local	Global			
Function	Indicates that tag	Indicates that tag resolution for CIP communications 2 failed (i.e., the address could not be identified from the tag name).						
	TRUE: Tag resolution failed (i.e., the address could not be identified from the tag name). The following causes are possible.							
	•The size of the network variable is different from the tag settings.							
	•The I/O direction that is set in the tag data link settings does not agree with the I/O direction of the variable in the CPU Unit.							
	•There is no network variable in the CPU Unit that corresponds to the tag setting.							
	FALSE: Other than the above.							
	Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP_MultiSwONErr						
Meaning	Multiple Switches ON Error Global/local Global						
Function	NX-series CPU Units: Indicates that more than one switch turned ON at the same time in CIP communications 1.						
	TRUE: More that	TRUE: More than one data link start/stop switch changed to TRUE at the same time.					
	FALSE: Other t	han the above.					
	NJ-series CPU Units: Indicates that more than one switch turned ON at the same time.						
	TRUE: More than one data link start/stop switch changed to TRUE at the same time.						
	FALSE: Other t	FALSE: Other than the above.					
Data type	BOOL Range of values TRUE or FALSE						
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related					
gram		instructions					

Variable name	_EIP1_MultiSwONErr								
Meaning	CIP Communic Error	tions1 Multiple Switches ON Global/local Global							
Function	Indicates that n	Indicates that more than one switch turned ON at the same time in CIP communications 1.							
	TRUE: More than one data link start/stop switch changed to TRUE at the same time.								
	FALSE: Other than the above.								
	Note You can use this system-defined variable only for NX-series CPU Units.								
Data type	BOOL Range of values TRUE or FALSE								
R/W access	R Retained Not retained. Network Publish Published.								
Usage in user program	Possible.	Related instructions							

Variable name	_EIP2_MultiSw	_EIP2_MultiSwONErr							
Meaning	CIP Communications2 Multiple Switches ON Global/local Global Error								
Function	Indicates that n	Indicates that more than one switch turned ON at the same time in CIP communications 2.							
	TRUE: More th	TRUE: More than one data link start/stop switch changed to TRUE at the same time.							
	FALSE: Other t	FALSE: Other than the above.							
	Note You can	Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.							
Data type	BOOL	BOOL Range of values TRUE or FALSE							
R/W access	R Retained Not retained. Network Publish Published.								
Usage in user pro-	Possible.	Related	elated						
gram		instructions							

Variable name	_EIP_TcpAppCfgErr						
Meaning	TCP Application Setting Error			Global/local	Global		
Function	TRUE: At least one of the set values for a TCP application (FTP, NTP, SNMP) is incorrect. Or, a read operation failed.						
	FALSE: Normal.						
Data type	BOOL Range of values TRUE or FALSE						
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP_NTPSrvErr							
Meaning	NTP Server Connection Error			Global/local	Global			
Function	TRUE: The NTP client failed to connect to the server (timeout).							
	FALSE: NTP is not set or the connection was successful.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP_DNSSrvErr						
Meaning	DNS Server Co	nnection Error		Global/local	Global		
Function	TRUE: The DNS client failed to connect to the server (timeout).						
	FALSE: DNS is not enabled. Or, DNS is enabled and the connection was successful.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related					
gram		instructions					

• Functional Classification: EtherNet/IP Communications Status

Variable name	_EIP_EtnOnlineSta							
Meaning	Online			Global/local	Global			
Function	NX-series CPU Units: Indicates that the built-in EtherNet/IP port's communications can be used via the communications port 1 (that is, the link is ON, IP address is defined, and there are no errors).							
	TRUE: The buil	t-in EtherNet/IP p	ort's communica	tions can be used.				
	FALSE: The built-in EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.							
	NJ-series CPU Units: Indicates that the built-in EtherNet/IP port's communications can be used via the communications port (that is, the link is ON, IP address is defined, and there are no errors).							
	TRUE: The buil	t-in EtherNet/IP p	ort's communica	tions can be used.				
	FALSE: The built-in EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.							
Data type	BOOL Range of values TRUE or FALSE							
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP1_EtnOnlineSta						
Meaning	Port1 Online Global/local Global						
Function	Indicates that the built-in EtherNet/IP port's communications can be used via the communications port 1 (that is, the link is ON, IP address is defined, and there are no errors).						
	TRUE: The buil	t-in EtherNet/IP p	oort's communica	tions can be used.			
	FALSE: The built-in EtherNet/IP port's communications is disabled due to an error in initial processing, restart processing, or link OFF status.						
	Note You can	use this system-d	defined variable o	nly for NX-series CPU Un	its.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP2_EtnOnlineSta						
Meaning	Port2 Online	Port2 Online Global/local Global					
Function	Indicates that the built-in EtherNet/IP port's communications can be used via the communications port 2 (that is, the link is ON, IP address is defined, and there are no errors).						
	TRUE: The buil	t-in EtherNet/IP p	ort's communica	tions can be used.			
	cessing, or link	OFF status.	•		n error in initial processing, restart pro- nits and NX102 CPU Units.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP_TDLinkR	_EIP_TDLinkRunSta						
Meaning	Tag Data Link (Tag Data Link Communications Status Global/local Global						
Function	NX-series CPU Units: Indicates that at least one connection is in normal operation in CIP communications 1.							
	TRUE: Normal	operation						
	FALSE: Other t	han the above.						
	NJ-series CPU Units: Indicates that at least one connection is in normal operation.							
	TRUE: Normal	operation		·				
	FALSE: Other t	han the above.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Possible. Related						
gram		instructions						

Variable name	_EIP1_TDLinkF	_EIP1_TDLinkRunSta						
Meaning	CIP Communications1 Tag Data Link Communications Status Global/local Global							
Function	Indicates that a	t least one conne	ction is in norma	l operation in CIP commu	nications 1.			
	TRUE: Normal	TRUE: Normal operation						
	FALSE: Other t	han the above.						
	Note You can	use this system-c	lefined variable o	only for NX-series CPU Un	its.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related						
gram		instructions						

Variable name	EIP2 TDLinkRunSta							
Meaning		ations2 Tag Data	Link Communi-	Global/local	Global			
J	cations Status	cations Status						
Function	Indicates that a	Indicates that at least one connection is in normal operation in CIP communications 2.						
	TRUE: Normal operation							
	FALSE: Other than the above.							
	Note You can i	Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.						
Data type	BOOL	ase tills system-c	lelified variable c	Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related		Trottrotter dibitori	1. 32			
gram	. 555.2.51	instructions						
Variable name	_EIP_TDLinkAl	RunSta						
Meaning	All Tag Data Lin	k Communication	ns Status	Global/local	Global			
Function	NX-series CPU	Units: Indicates	that all tag data li	nks are communicating	in CIP communications 1.			
	TRUE: Tag data	links are comm	unicating in all co	nnections as the origina	tor.			
	FALSE: An erro	r occurred in at le	east one connect	ion.				
	NJ-series CPU	Units: Indicates t	hat all tag data li	nks are communicating.				
	TRUE: Tag data	links are commi	unicating in all co	nnections as the origina	tor.			
			east one connect	=				
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related			'			
gram		instructions						
Variable name	_EIP1_TDLinkA							
Meaning		ations1 All Tag Da	ata Link Com-	Global/local	Global			
Function	munications Sta			CID communications 1				
Function		-	_	n CIP communications 1.	tor			
	_		•	nnections as the origina	ioi.			
	FALSE: An erro	r occurred in at i	east one connect	ion.				
	Note You can	use this system-c	lefined variable c	nly for NX-series CPU L	Jnits.			
Data type	DOO!			•				
D/M/ access	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Range of values Network Publish				
Usage in user pro-		Related	Not retained.		TRUE or FALSE			
	R				TRUE or FALSE			
Usage in user pro-	R	Related			TRUE or FALSE			
Usage in user pro- gram	R Possible.	Related instructions			TRUE or FALSE			
Usage in user program Variable name	R Possible. _EIP2_TDLinkA	Related instructions		Network Publish	TRUE or FALSE Published.			
Usage in user pro- gram	R Possible. _EIP2_TDLinkA CIP Communication	Related instructions			TRUE or FALSE			
Usage in user program Variable name Meaning	R Possible. _EIP2_TDLinkA CIP Communications Sta	Related instructions AllRunSta ations2 All Tag Datus	ata Link Com-	Network Publish Global/local	TRUE or FALSE Published.			
Usage in user program Variable name	R Possible. _EIP2_TDLinkA CIP Communications Sta	Related instructions AllRunSta ations2 All Tag Datus tag data links are	ata Link Com-	Network Publish Global/local CIP communications 2.	TRUE or FALSE Published. Global			
Usage in user program Variable name Meaning	R Possible. _EIP2_TDLinkA CIP Communica munications Sta Indicates that all TRUE: Tag data	Related instructions AllRunSta ations2 All Tag Datus tag data links are communications.	ata Link Com- communicating in	Network Publish Global/local CIP communications 2. nnections as the origina	TRUE or FALSE Published. Global			
Usage in user program Variable name Meaning	R Possible. _EIP2_TDLinkA CIP Communica munications Sta Indicates that all TRUE: Tag data FALSE: An erro	Related instructions AllRunSta ations2 All Tag Datus tag data links are commer occurred in at let	ata Link Com- communicating in all contest one connect	Global/local CIP communications 2. nnections as the origination.	TRUE or FALSE Published. Global tor.			
Usage in user program Variable name Meaning Function	R Possible. _EIP2_TDLinkA CIP Communications Sta Indicates that all TRUE: Tag data FALSE: An erro Note You can	Related instructions AllRunSta ations2 All Tag Datus tag data links are commer occurred in at let	ata Link Com- communicating in all contest one connect	Global/local CIP communications 2. nnections as the origination. nly for the NX701 CPU L	TRUE or FALSE Published. Global tor. Jnits.			
Usage in user program Variable name Meaning Function Data type	R Possible. _EIP2_TDLinkA CIP Communica munications Sta Indicates that all TRUE: Tag data FALSE: An erro Note You can in BOOL	Related instructions AllRunSta ations2 All Tag Datus tag data links are commur occurred in at lease this system-course.	ata Link Com- communicating in unicating in all co east one connect	Global/local CIP communications 2. nnections as the origination. nly for the NX701 CPU URange of values	TRUE or FALSE Published. Global tor. Jnits. TRUE or FALSE			
Variable name Meaning Function Data type R/W access	R Possible. _EIP2_TDLinkA CIP Communica munications Sta Indicates that all TRUE: Tag data FALSE: An erro Note You can is BOOL R	Related instructions AllRunSta ations2 All Tag Datus tag data links are common roccurred in at lease this system-common Retained	ata Link Com- communicating in all corporations one connect defined variable of Not retained.	Global/local CIP communications 2. nnections as the origination. nly for the NX701 CPU L	TRUE or FALSE Published. Global tor. Jnits.			
Usage in user program Variable name Meaning Function Data type	R Possible. _EIP2_TDLinkA CIP Communica munications Sta Indicates that all TRUE: Tag data FALSE: An erro Note You can in BOOL	Related instructions AllRunSta ations2 All Tag Datus tag data links are commur occurred in at lease this system-course.	ata Link Com- communicating in unicating in all co east one connect	Global/local CIP communications 2. nnections as the origination. nly for the NX701 CPU URange of values	TRUE or FALSE Published. Global tor. Jnits. TRUE or FALSE			

Variable name	_EIP_RegTargetSta [255]						
Meaning	Registered Targ	et Node Informat	tion	Global/local	Global		
Function	NX-series CPU Units: Gives a list of nodes for which built-in EtherNet/IP connections are registered for CIP communications 1.						
	This variable is valid only when the built-in EtherNet/IP port is the originator.						
	Array[x] is TRUE: The connection to the node with a target node ID of x is registered.						
	Array[x] is FALS	SE: The connection	on to the node wi	th a target node ID of x is	not registered.		
	NJ-series CPU	Units: Gives a lis	t of nodes for wh	ich built-in EtherNet/IP co	nnections are registered.		
	This variable is	valid only when t	he built-in EtherN	Net/IP port is the originator	r.		
	Array[x] is TRU	E: The connection	n to the node with	h a target node ID of x is r	registered.		
	Array[x] is FALS	SE: The connection	on to the node wi	th a target node ID of x is	not registered.		
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP1_RegTar	_EIP1_RegTargetSta [255]						
Meaning	CIP Communications1 Registered Target Node Information Global/local Global							
Function	Gives a list of n	odes for which bu	uilt-in EtherNet/IF	connections are registere	ed for CIP communications 1.			
	This variable is	valid only when t	the built-in Ether	Net/IP port is the originator	:			
	Array[x] is TRU	Array[x] is TRUE: The connection to the node with a target node ID of x is registered.						
	Array[x] is FALS	Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.						
	Note You can	use this system-d	defined variable o	only for NX-series CPU Un	its.			
Data type	ARRAY [0255] OF BOOL		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP2_RegTargetSta [255]						
Meaning	CIP Communication	Communications2 Registered Target Node mation Global/local Global					
Function	Gives a list of n	odes for which b	uilt-in EtherNet/IF	connections are registere	ed for CIP communications 2.		
	This variable is	valid only when t	he built-in EtherN	Net/IP port is the originator	:		
	Array[x] is TRU	Array[x] is TRUE: The connection to the node with a target node ID of x is registered.					
	Array[x] is FALS	Array[x] is FALSE: The connection to the node with a target node ID of x is not registered.					
	Note You can	use this system-c	lefined variable o	only for the NX701 CPU Ur	nits and NX102 CPU Units.		
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related					
gram		instructions					

Variable name	_EIP_EstbTargetSta [255]						
Meaning	Normal Target N	Node Information		Global/local	Global		
Function	NX-series CPU Units: Gives a list of nodes that have normally established EtherNet/IP connections for CIP communications 1.						
	Array[x] is TRUE: The connection to the node with a target node ID of x was established normally.						
	Array[x] is FALSE: The connection to the node with a target node ID of x was not established, or an error occurred.						
	NJ-series CPU	Units: Gives a lis	t of nodes that ha	ave normally established E	EtherNet/IP connections.		
	Array[x] is TRU	E: The connection	n to the node witl	n a target node ID of x wa	s established normally.		
	Array[x] is FALS	E: The connection	n to the node witl	n a target node ID of x was	s not established, or an error occurred.		
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP1_EstbTar	_EIP1_EstbTargetSta [255]						
Meaning	CIP Communic Information	ations1 Normal T	arget Node	Global/local	Global			
Function	Gives a list of r	nodes that have n	ormally establish	ed EtherNet/IP connection	ns for CIP communications 1.			
	Array[x] is TRU	IE: The connectio	n to the node wit	h a target node ID of x wa	s established normally.			
	Array[x] is FAL	Array[x] is FALSE: The connection to the node with a target node ID of x was not established, or an error occurred.						
	Note You can	use this system-o	defined variable o	only for NX-series CPU Ur	nits.			
Data type	ARRAY [0255] OF BOOL		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP2_EstbTargetSta [255]						
Meaning	CIP Communications2 Normal Target Node Global/local Global G						
Function	Gives a list of n	odes that have n	ormally establish	ed EtherNet/IP connection	ns for CIP communications 2.		
	Array[x] is TRU	E: The connection	n to the node with	n a target node ID of x was	s established normally.		
	Array[x] is FALSE: The connection to the node with a target node ID of x was not established, or an error occurred.						
	Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.						
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related					
gram		instructions					

Variable name	_EIP_TargetPLCModeSta [255]							
Meaning	Target PLC Ope	t PLC Operating Mode Global/local Global						
Function	NX-series CPU Units: Shows the operating status of the target node Controllers that are connected for CIP communications 1, with the built-in EtherNet/IP port as the originator.							
	The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, the Target Node Controller Operating Information indicates the previous operating status.							
	Array[x] is TRU	E: This is the ope	erating state of th	e target Controller with a i	node address of x.			
	Array[x] is FALS	SE: Other than the	e above.					
		Units: Shows the tas the originato		of the target node Contro	llers that are connected with the built-in			
		al Target Node In	•		Node Information is TRUE. If the corre- roller Operating Information indicates			
	Array[x] is TRU	E: This is the ope	rating state of th	e target Controller with a ı	node address of x.			
	Array[x] is FALS	SE: Other than th	e above.					
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	EIP1 TargetPl	EIP1 TargetPLCModeSta [255]						
Meaning	CIP Communica Mode	ations1 Target PL	.C Operating	Global/local	Global			
Function		Shows the operating status of the target node Controllers that are connected for CIP communications 1, with the built-in EtherNet/IP port as the originator.						
	The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, the Target Node Controller Operating Information indicates the previous operating status.							
	Array[x] is TRU	E: This is the ope	rating state of the	e target Controller with a r	node address of x.			
	Array[x] is FALS	SE: Other than the	e above.					
	Note You can use this system-defined variable only for NX-series CPU Units.							
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EIP2_TargetPLCModeSta [255]					
Meaning	CIP Communica Mode	ations2 Target PL	.C Operating	Global/local	Global	
Function	Shows the operating status of the target node Controllers that are connected for CIP communications 2, with the built-in EtherNet/IP port as the originator.					
	The array elements are valid only when the corresponding Normal Target Node Information is TRUE. If the corresponding Normal Target Node Information is FALSE, the Target Node Controller Operating Information indicates the previous operating status.					
	Array[x] is TRUE	E: This is the ope	erating state of the	e target Controller with a r	node address of x.	
	Array[x] is FALS	E: Other than the	e above.			
	Note You can u	use this system-d	lefined variable o	nly for the NX701 CPU Ur	nits and NX102 CPU Units.	
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user pro- gram	Possible.	Related instructions				

Variable name	_EIP_TargetPLCErr [255]						
Meaning	Target PLC Erro	or Information		Global/local	Global		
Function	NX-series CPU Units: Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected for CIP communications 1, with the built-in EtherNet/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE.						
	Array[x] is TRU	E: A fatal or non-f	atal error occurre	ed in the target Controller	with a target node ID of x.		
	Array[x] is FALS	SE: Other than the	e above.				
	that are connec	ted with the built-	in EtherNet/IP po	orts as the originator. The	al errors) of the target node Controllers array elements are valid only when the preceding value is retained if this vari-		
	Array[x] is TRU	E: A fatal or non-f	atal error occurre	ed in the target Controller	with a target node ID of x.		
	Array[x] is FALS	SE: Other than the	e above.				
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP1_TargetPl	LCErr [255]					
Meaning		ations1 Target PL	.C Error Infor-	Global/local	Global		
	mation						
Function	Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected for CIP communications 1, with the built-in EtherNet/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE.						
	Array[x] is TRU	E: A fatal or non-f	fatal error occurre	ed in the target Controller	with a target node ID of x.		
	Array[x] is FALS	SE: Other than the	e above.				
	Note You can	use this system-d	lefined variable o	nly for NX-series CPU Un	its.		
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user pro-	Possible.	Related					
gram		instructions					

Variable name	_EIP2_TargetPLCErr [255]						
Meaning	CIP Communication	ations2 Target PL	C Error Infor-	Global/local	Global		
Function	Shows the error status (logical OR of fatal and non-fatal errors) of the target node Controllers that are connected for CIP communications 2, with the built-in EtherNet/IP ports as the originator. The array elements are valid only when the corresponding Normal Target Node Information is TRUE. The immediately preceding value is retained if this variable is FALSE. Array[x] is TRUE: A fatal or non-fatal error occurred in the target Controller with a target node ID of x. Array[x] is FALSE: Other than the above. Note You can use this system-defined variable only for the NX701 CPU Units and NX102 CPU Units.						
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EIP_TargetNodeErr [255]								
Meaning	Target Node Er	Target Node Error Information Global/local Global							
Function		NX-series CPU Units: Indicates that the connection for the Registered Target Node Information for CIP communications 1 was not established or that an error occurred in the target Controller.							
	The array elem	ents are valid onl	y when the Regis	stered Target Node Inform	ation is TRUE.				
	tered Target No	de Information is ⁻	TRUE and the No		node for a target node ID of x (the Registion is FALSE), or a connection was				
	Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE and the Normal Target Node Information is TRUE). An error occurred in the target Controller (the Target PLC Error Information is TRUE).								
		Units: Indicates the contract occurred in the tax		n for the Registered Targe	t Node Information was not established				
	The array elem	ents are valid onl	y when the Regis	stered Target Node Inform	ation is TRUE.				
	tered Target No	de Information is ⁻	TRUE and the No		node for a target node ID of x (the Registion is FALSE), or a connection was				
	Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE and the Normal Target Node Information is TRUE). An error occurred in the target Controller (the Target PLC Error Information is TRUE).								
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE				
R/W access	R	Retained	Not retained.	Network Publish	Published.				
Usage in user program	Possible.	Related instructions							

Variable name	_EIP1_TargetNodeErr [255]						
Meaning	CIP Communication	ations1 Target No	de Error Infor-	Global/local	Global		
Function	Indicates that the connection for the Registered Target Node Information for CIP communications 1 was not established or that an error occurred in the target Controller.						
	The array eleme	ents are valid only	y when the Regis	stered Target Node Inform	ation is TRUE.		
	Array[x] is TRUE: A connection was not normally established with the target node for a target node ID of x (the Registered Target Node Information is TRUE and the Normal Target Node Information is FALSE), or a connection was established with the target node but an error occurred in the target Controller.						
	Array[x] is FALSE: The target node is not registered for a target node ID of x (the Registered Target Node Information is FALSE), or a connection was normally established with the target node (the Registered Target Node Information is TRUE and the Normal Target Node Information is TRUE). An error occurred in the target Controller (the Target PLC Error Information is TRUE). Note You can use this system-defined variable only for NX-series CPU Units.						
Data type	ARRAY [0255]	OF BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	EIP2 TargetNo	_EIP2_TargetNodeErr [255]						
Meaning		ations2 Target No	ode Error Infor-	Global/local	Global			
Function		Indicates that the connection for the Registered Target Node Information for CIP communications 2 was not established or that an error occurred in the target Controller.						
	The array eleme	ents are valid on	ly when the Regi	stered Target Node Inform	ation is TRUE.			
	tered Target No	Array[x] is TRUE: A connection was not normally established with the target node for a target node ID of x (the Registered Target Node Information is TRUE and the Normal Target Node Information is FALSE), or a connection was established with the target node but an error occurred in the target Controller.						
	tion is FALSE), mation is TRUE	or a connection	was normally est Target Node Info	ablished with the target no	x (the Registered Target Node Informa- de (the Registered Target Node Infor- or occurred in the target Controller (the			
			defined variable o		nits and NX102 CPU Units.			
Data type	ARRAY [0255]			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						
Variable name	_EIP_NTPResu	ılt		Member name	.ExecTime			
Meaning	NTP Last Opera	ation Time		Global/local	Global			
Function	Gives the last ti	me that NTP pro	cessing ended n	ormally.				
	The time that w	The time that was obtained from the NTP server is stored when the time is obtained normally.						
	The time is not	stored if it is not	obtained from the	e NTP server normally.				
	Note Do not us	se this variable i	n the user progra	_	in updating it. Use this variable only to			
Data type	Structure: _sNT		minarioations iro	Range of values	Depends on data type.			
Data typo	Members: DATE	_		Traingo or valuos	Deponds on data type.			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Not possible.	Related			e with the GetNTPStatus instruction.			
gram		instructions						
Variable name	_EIP_NTPResu	lt		Member name	.ExecNormal			
Meaning	NTP Operation			Global/local	Global			
Function	This variable sh	ows if the NTP o	peration ended r	normally.				
		s an NTP norma						
	FALSE: Indicates that NTP operation ended in an error or has not been executed even once.							
				am. There may be a delay m an external device.	in updating it. Use this variable only to			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Not possible.	Related	You can read th	ne contents of this variable	with the GetNTPStatus instruction.			
gram		instructions						

• Functional Classification: EtherNet/IP Communications Switches

Variable name	_EIP_TDLinkSt	_EIP_TDLinkStartCmd							
Meaning	Tag Data Link C	Communications S	Start Switch	Global/local	Global				
Function	NX-series CPU	NX-series CPU Units: Change this variable to TRUE to start tag data links for CIP communications 1.							
	It automatically	It automatically changes back to FALSE after tag data link operation starts.							
	NJ-series CPU	Units: Change th	is variable to TRI	JE to start tag data links.					
	It automatically	changes back to	FALSE after tag	data link operation starts.					
		rce this switch to utomatically.	change to FALSE	E from the user program o	r from the Sysmac Studio. It changes to				
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	RW	Retained	Not retained.	Network Publish	Published.				
Usage in user pro-	Possible.	Related							
gram		instructions							

Variable name	_EIP1_TDLinkStartCmd								
Meaning	CIP Communic	ations1 Tag Data	Link Communi-	Global/local	Global				
	cations Start Sv	witch							
Function	Change this var	Change this variable to TRUE to start tag data links for CIP communications 1.							
	It automatically	changes back to	FALSE after tag	data link operation starts.					
	FALSE a	utomatically.	Ü	. 0	r from the Sysmac Studio. It changes to				
	Note You can	use this system-c	lefined variable c	nly for NX-series CPU Un	its.				
Data type	BOOL			Range of values	TRUE or FALSE				
R/W access	RW	Retained	Not retained.	Network Publish	Published.				
Usage in user pro-	Possible.	Related							
gram		instructions							

Variable name	_EIP2_TDLink	_EIP2_TDLinkStartCmd						
Meaning		ations2 Tag Data	Link Communi-	Global/local	Global			
	cations Start S	witch						
Function	Change this var	Change this variable to TRUE to start tag data links for CIP communications 2.						
	It automatically	changes back to	FALSE after tag	data link operation starts.				
		orce this switch to outomatically.	change to FALSI	E from the user program o	r from the Sysmac Studio. It changes to			
	Note You can	use this system-d	lefined variable o	only for the NX701 CPU U	nits and NX102 CPU Units.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	RW	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related						
gram		instructions						

Variable name	EIP TDLinkSt	copCmd						
Meaning		Tag Data Link Communications Stop Switch Global/local Global						
Function				E to stop tag data links f	for CIP communications 1.			
		It automatically changes back to FALSE after tag data link operation stops.						
	NJ-series CPU	Units: Change th	nis variable to TR	UE to stop tag data linl	ks.			
	It automatically	changes back to	FALSE after tag	data link operation sto	pps.			
		rce this switch to utomatically.	change to FALS	E from the user prograi	m or from the Sysmac Studio. It changes to			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	RW	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions			<u>'</u>			
Variable name	EIP1 TDLinks	StopCmd						
Meaning		ations1 Tag Data	Link Communi-	Global/local	Global			
	cations Stop Sv							
Function	Change this variable to TRUE to stop tag data links for CIP communications 1.							
	It automatically changes back to FALSE after tag data link operation stops.							
	Note Do not fo	Note Do not force this switch to change to FALSE from the user program or from the Sysmac Studio. It changes to						
		FALSE automatically.						
	Note You can	use this evetem	dofinad variable d	only for NV porion CDLI	Linita			
Data type	BOOL	use this system-	delined variable (only for NX-series CPU Range of values	TRUE or FALSE			
R/W access	RW	Retained	Not retained.	Network Publish	Published.			
Usage in user pro-	Possible.	Related		NCtWORK I UDIISII	i ublisticu.			
gram	T GGGIBIG.	instructions						
0								
Variable name	EIP2 TDLinks	StopCmd						
Meaning		ations2 Tag Data	Link Communi-	Global/local	Global			
Function			stop tag data links	for CIP communication	us 2.			
	It automatically changes back to FALSE after tag data link operation stops. Note Do not force this switch to change to FALSE from the user program or from the Sysmac Studio. It char							
	FALSE a	utomatically.						
	Note You can	use this system-	defined variable o	only for the NX701 CPL	J Units and NX102 CPU Units.			
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	RW	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

A-8 Attributes of CPU Unit Data

The following table shows the attributes of the CPU Unit data including the Retain/Non-retain attribute in the following cases: power interruption, power on, operating mode change, and major fault level Controller error.

	CPU Unit data		Data reten-	When	Status	changes	Writing when write	Transfer- ring data with the Sysmac Studio	Operating modes	Overwrit-
			power is interruptions power is		Change between PRO- GRAM mode and RUN mode	When a Major Fault Level Con- troller Error occurs	protection is enabled	Synchro- nized data	permitting writing	ing in RUN mode
User pro- gram		user program ID in user pro-	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM/ RUN mode (online edit- ing)	Supported. Online editing
Task Setup	Task Settii	ngs	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not supported.
	Variable tables	Device variable	Retained (with non- volatile memory).	Same as before power interruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not supported.
Variables	(but not variable values)	User-defined variables	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM/ RUN mode (online edit- ing)	Supported. Online editing
Data type		User-defined data types	Retained (with non- volatile memory).	Same as before power interruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM/ RUN mode (online edit- ing)	Supported. Online editing
Controller	namo	CPU Unit name	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM/ RUN mode	Supported.
Controller	name	Built-in Ether- Net/IP port name	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Supported	Not retained.	PRO- GRAM/ RUN mode	Supported.

	CPU Unit data		Data reten-	When	Status (changes	Writing	Transfer- ring data with the Sysmac Studio	Operating	Overwrit-
			power interrup- tions	power is turned ON	Change between PRO- GRAM mode and RUN mode	When a Major Fault Level Con- troller Error occurs	when write protection is enabled	Synchro- nized data	modes permitting writing	ing in RUN mode
	Opera- tion Set- tings	Operation Settings Error settings	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	CPU Unit name: RUN/PRO- GRAM mode, Other set- tings: PRO- GRAM mode	Not supported.
	Security Settings	Protection Settings at Startup	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not sup- ported.	Retained.	Write Protection and other settings: PROGRAM mode	Supported.
Control- ler Setup	Built-in Ether- Net/IP Port Set- tings	TCP/IP Set- tings, Built-in EtherNet/IP Port Link Set- tings, Service Settings. SNMP Set- tings, SNMP Trap Settings, NTP Settings, FTP Settings, and IP Router Tables	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not supported.
ier Setup		Tag data link settings for built-in Ether- Net/IP port	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Supported	Not retained.	PRO- GRAM/ RUN	Not sup- ported.
	FINS Set- tings	Node Address Settings, FINS/UDP Set- tings, FINS/TCP Set- tings, FINS Routing Tables, FINS Write Protec- tion	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not supported.
	Built-in I/O	Settings	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not sup- ported.	Retained.	PRO- GRAM mode	Not supported.
	Option Boa	ard Settings	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not sup- ported.	Retained.	PRO- GRAM mode	Not supported.
	Memory Se series Unit	ettings for CJ- ts	Retained (with non- volatile memory).	Same as before power interruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not supported.

				When	Status (changes	Writing when write	Transfer- ring data with the Sysmac Studio	Operating modes	Overwrit-
	CPU Unit data		power interrup- tions	power is turned ON	Change between PRO- GRAM mode and RUN mode	When a Major Fault Level Con- troller Error occurs	protection is enabled	Synchro- nized data	permitting writing	ing in RUN mode
	OPC UA Server Settings	Server Settings Network Settings End Point Settings Execution Log Settings	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not supported.
OPC UA Settings	Client Certifica- tion Set- tings	Certification Trust List Certification Trust List (Expired) Certification Reject List Root Certification /Intermediate Certification List Root Certification List Coefficiation List Certification List Certification List Certification	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Supported.	Not retained.	PRO- GRAM/ RUN mode	Supported.
	User Set- tings	List (Expired) User Authentication Definition File	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Supported.	Not retained.	PRO- GRAM/ RUN mode	Supported.
Motion Control Setup	parameter group para	nments, axis settings, axes meter settings, on parameter	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not sup- ported.
Cam Data			Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not sup- ported.	Retained.	PRO- GRAM mode	Not supported.
Event Setting Table	Event Setting Table	User-defined error mes-sages	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not sup- ported.	Retained.	RUN/PRO- GRAM mode	Not supported.
Bus con-	NX Units		Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not supported.
tion	CJ-series bus con- figura- tion	I/O table	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not supported.

	CPU Unit data		Data reten- tion at	When	Status (changes	Writing when write	Transfer- ring data with the Sysmac Studio	Operating modes	Overwrit-
			power interrup- tions	power is turned ON	Change between PRO- GRAM mode and RUN mode	When a Major Fault Level Con- troller Error occurs	protection is enabled	Synchro- nized data	permitting writing	ing in RUN mode
		Data in CJ- series Units, such as proto- col macros	Retained (in CJ- series Units).		Retained.	Retained.	Supported.	Not retained.	Depends on the Unit.	
Special I/O Unit Set- tings/CP U Bus Unit Set- tings	CJ-series Unit Set- tings	Words allo- cated to CPU Bus Units, Example: Con- troller Link Data Link Tables.	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Supported.	Not retained.	RUN/PRO- GRAM mode	Supported.
		Words allo- cated in DM Area	Retained (with Bat- tery).	Same as before power inter- ruption.	Retained.	Retained.	Supported	Retained.	RUN/PRO- GRAM mode	Supported.
Ether- CAT Con- figuratio n	Ether- CAT Net- work Configu- ration	Network configuration information.	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not sup- ported.
Ether- CAT Set-	Ether- CAT Set-	Master	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Retained.	PRO- GRAM mode	Not sup- ported.
tings	tings	Settings in Slaves	Retained (by slaves).		Retained.	Retained.	Supported.	Retained.	RUN/PRO- GRAM mode	Supported.
Operation A	Authority Ve	rification	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Not retained.	PRO- GRAM mode	Not supported.
User progr	am executio	n ID in CPU Unit	Retained (with non- volatile memory).	Same as before power inter- ruption.	Retained.	Retained.	Not supported.	Not retained.	PRO- GRAM mode	Not supported.
Present values of	Values of non- retained variables	User-defined variables and device variables	Not retained.	Initial val- ues	Initial val- ues	Initial val- ues	Supported.	Not retained.	RUN/PRO- GRAM mode	Supported.
variables	Values of retained variables	User-defined variables and device variables	Retained (with Bat- tery*1).	Same as before power inter- ruption.	Retained.	Retained.	Supported.	Not retained.	RUN/PRO- GRAM mode	Supported.
Contents of mem-	CIO/WR		Not retained.	16#0000	16#0000	16#0000	Supported.	Not retained.	RUN/PRO- GRAM mode	Supported.
ory used for CJ- series Units	HR/DM/EM		Retained (with Bat- tery*1).	Same as before power inter- ruption.*2	Retained.	Retained.	Supported.	Not retained.	RUN/PRO- GRAM mode	Supported.

		Data retention at When	Status changes		Writing when write	Transfer- ring data with the Sysmac Studio	Operating modes	Overwrit-		
	CPU Unit data		power interruptions power is		Change between PRO- GRAM mode and RUN mode	When a Major Fault Level Con- troller Error occurs	protection is enabled	Synchro- nized data	permitting writing	ing in RUN mode
Event logs	Logs	System log User event log	Retained (with Bat- tery*1).	Same as before power inter- ruption.	Retained.	Retained.	Supported.	Not retained.		Supported.
Internal clock		n the specifica- ch system- riable.	Retained (with Bat- tery).	With Bat- tery: Retained (contin- ued), With- out Battery: Not predict- able (may stop).	Retained (continued).	Retained (continued).	Supported.	Not retained.	RUN/PRO- GRAM mode	Supported.
Absolute e	ncoder hom	e offset	Retained (with Bat- tery ^{*1}).	Same as before power inter- ruption.	Retained (continued).	Retained (continued).	Supported.	Not retained.		Not supported.

^{*1} For the NX102 CPU Units and NX1P2 CPU Units, data is retained in the non-volatile memory.
*2 For the NX102 CPU Units and NX1P2 CPU Units, the value is 16#0000 if the Battery-related error detection is set to Do not use.

A-9 Contents of Memory Used for CJ-series Units

You can specify addresses in the memory used for CJ-series Units for AT specifications for variables. Details on each area are provided below.



Precautions for Correct Use

- You can use the memory used for CJ-series Units only with the NJ-series CPU Units, NX102 CPU Units, and NX1P2 CPU Units.
- Refer to the *NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual* (Cat. No. W579) for how to use memory for CJ-series Units with the NX1P2 CPU Units.

A-9-1 CIO Area

I/O Bits

Description

The bits in this area are allocated to input and output terminals on CJ-series Basic I/O Units. The number of words (16 bits each) that is required for each CJ-series Basic I/O Unit are allocated in order based on the position where the Units are connected (from left to right starting from the Unit that is closest to the CPU Unit). Data in this area is cleared when power is cycled or when the operating mode is changed between PROGRAM and RUN mode.

Addresses

Addresses	Word addresses	Bit addresses
Range	CIO 0 to CIO 159	0.00 to 159.15



Additional Information

You can access this area on NJ-series CPU Units through device variables allocated to I/O ports. We therefore recommend that you do not use AT specifications to access this area. You should use AT specifications for the CIO Area only when you specify addresses for some of the Special Units.

CPU Bus Unit Area

Description

The bits in this area are allocated to control and status information for CJ-series CPU Bus Units. Each Unit is allocated 25 words based on its unit number. Data in this area is cleared when power is cycled or when the operating mode is changed between PROGRAM and RUN mode.

Addresses

Addresses	Word addresses	Bit addresses	Words per Unit
Range	CIO 1500 to CIO 1899	CIO 1500.00 to CIO 1899.15	25 words

The words that are allocated are listed in the following table.

Word addresses	Unit Number
CIO 1500 to CIO 1524	0
CIO 1525 to CIO 1549	1
to	to
CIO 1875 to CIO 1899	F

For details on how to use the allocated words, refer to the operation manual for the CJ-series CPU Bus Unit.



Precautions for Correct Use

You can access the CPU Bus Unit Area in NJ-series CPU Units through the device variables that are allocated to I/O ports. We therefore recommend that you do not use AT specifications to access this area. You should use AT specifications for the CIO Area only when you specify addresses for some of the Special Units.

Special I/O Unit Area

Description

The bits in this area are allocated to control and status information for CJ-series Special I/O Units. Each Unit is allocated 10 words based on the unit number for up to a total of 96 Units (unit numbers 0 to 95). Data in this area is cleared when power is cycled or when the operating mode is changed between PROGRAM and RUN mode.

Addresses

Addresses	Word addresses	Bit addresses	Words per Unit
Range	CIO 2000 to CIO 2959 (10 words × 96 unit numbers)	CIO 2000.00 to CIO 2959.15	10 words

The words that are allocated are listed in the following table.

Word addresses	Unit Number
CIO 2000 to CIO 2009	0
CIO 2010 to CIO 2019	1
to	to
CIO 2950 to CIO 2959	95

For details on how to use the allocated words, refer to the operation manual for the CJ-series Special I/O Unit.



Additional Information

You can access the Special I/O Unit Area in NJ-series CPU Units through the device variables that are allocated to I/O ports. We therefore recommend that you do not use AT specifications to access this area.

DeviceNet Area

Description

The bits in this area are allocated to the slaves when the remote I/O master function of a DeviceNet Unit is used (fixed allocations only). Data in this area is cleared when power is cycled or when the operating mode is changed between PROGRAM and RUN mode.

Addresses

Addresses	Word addresses	Bit addresses
Range	CIO 3200 to CIO 3799	CIO 3200.00 to CIO 3799.15

Words in this area are allocated to slaves for fixed allocations according to fixed allocation setting 1, 2, or 3 in the software switches in the CIO Area. Select one of these fixed areas.

Addresses	Master to slave out- put area	Slave to master input area		
Fixed allocation area 1	CIO 3200 to CIO 3263	CIO 3300 to CIO 3363		
Fixed allocation area 2	CIO 3400 to CIO 3463	CIO 3500 to CIO 3563		
Fixed allocation area 3	CIO 3600 to CIO 3663	CIO 3700 to CIO 3763		

You can allocate memory in the DeviceNet Area even if you use fixed allocations to use the remote I/O slave function of a DeviceNet Unit.

Addresses	Master to slave out- put area	Slave to master input area	
Fixed allocation area 1	CIO 3370	CIO 3270	
Fixed allocation area 2	CIO 3570	CIO 3470	
Fixed allocation area 3	CIO 3770	CIO 3670	

Refer to the *CJ-series DeviceNet Units Operation Manual for NJ-series CPU Unit* (Cat. No. W497) for details.

CIO Area Work Areas

Description

You use the bits in these areas only in programming. You cannot use them to input or output data through external I/O terminals. If you need work bits, you should normally use bits in this area. Data in this area is cleared when power is cycled or when the operating mode is changed between PRO-GRAM and RUN mode.

Addresses

Addresses	Word addresses	Bit addresses
Range	CIO 1300 to CIO 1499 and CIO 3800 to CIO 6143	CIO 1300.00 to CIO 1499.15 and CIO 3800.00 to CIO 6143.15

A-9-2 Internal I/O Area

Description

You use the bits in these areas only in programming. You cannot use them to input or output data through external I/O terminals. If you need work bits, you should normally use bits in this area. Data in this area is cleared when power is cycled or when the operating mode is changed between PRO-GRAM and RUN mode.

Addresses

Addresses Word addresses		Bit addresses	
Range	W000 to W511	W000.00 to W511.15	

A-9-3 Holding Area

Description

You use the words and bits in this area only in programming. The status of the words and bits in this area are retained during power interruptions or when the operating mode is changed between PRO-GRAM and RUN mode.

Addresses

Addresses	Word addresses	Bit addresses	
Range	H0 to H511	H0.00 to H511.15	

A-9-4 DM Area

Description

This is a general-purpose data area used to read and write 16-bit words. You can also add a bit number to address specify bits. Data in this area is retained during power interruption or when the operating mode is changed between PROGRAM and RUN mode.

Addresses

Addresses	Word addresses	Bit addresses	
Range	D0 to D32767	D0.00 to D32767.15	

DM Area Words for Special Units

Description

The following words in the DM Area are allocated to initial settings for Special Units.

Addresses

Addresses	Type of CJ-series Special Unit	Word addresses	Words per Unit
Range	CJ-series Special I/O Units	D20000 to D29599 (100 words × 96 unit numbers)	100 words
Nange	CJ-series CPU Bus Units	D30000 to D31599 (100 words × 16 unit numbers)	100 words

The words that are allocated are listed in the following table. CJ-series Special I/O Units

Word addresses	Unit Number
D20000 to D20099	0
D20100 to D20199	1
to	to
D29500 to D29599	95

CJ-series CPU Bus Units

Word addresses	Unit Number
D30000 to D30099	0
D30100 to D30199	1
to	to
D31500 to D31599	F

For details on how to use the allocated words, refer to the operation manual for the Special Unit.



Additional Information

You can access the DM Area words that are allocated to Special Units in NJ-series CPU Units through the device variables that are allocated to I/O ports. We therefore recommend that you do not use AT specifications to access this area.

A-9-5 EM Area

Description

This is a general-purpose data area used to read and write 16-bit words. You can also add a bit number to address specify bits. Data in this area is retained during power interruption or when the operating mode is changed between PROGRAM and RUN mode.

Addresses

Addresses	Word addresses	Bit addresses
	NJ501-□□□: E0_0 to E18_32767	NJ501-□□□: E0_0.00 to E18_3276.15
Range	NJ301-□□□: E0_0 to E3_32767	NJ301-□□□: E0_0.00 to E3_32767.15
	NJ101-□□□□: E0_0 to E3_32767	NJ101-□□□: E0_0.00 to E3_32767.15

Note The number of banks is given in hexadecimal.

A-10 Variable Memory Allocation Methods

You must be aware of the way in which memory is allocated to variables to align the memory locations of the members of structure or union variables with variables in other devices. Adjustments are necessary mainly when structure variables are used in the following type of communications with other devices.


- When using EtherNet/IP tag data links or CIP messages to access variables between NJ/NX-series CPU Units and other CPU Units
- · When using structure variables to exchange data with devices other than CPU Units, such as ID Tags

A-10-1 Variable Memory Allocation Rules

The amount of memory and the memory locations that are allocated for a variable depend on the data type of the variable. The amount of memory and the memory locations that are allocated for array elements, structure members, and union members depend on the data types, but also on the declarations that are made for the arrays, structures, and unions.

Data Type Alignment and Memory Allocation Amounts

The data size is determined for each data type. The data size is the minimum amount of memory that is required to store the value or values of that data type. On the other hand, memory for variables is automatically structured by the Controller for the most efficient access. Therefore, the total amount of memory that is required for variables is not necessarily the total of the data sizes of the variables. For example, if WORD and DWORD variables are declared, the total of the data sizes is six bytes, but eight bytes are allocated in memory, as shown in the following figure.



Variable Table			
:	Name	Data type	
:	Α	WORD	
	В	DWORD	

This information for determining the location of a variable in memory is called the alignment. The alignment is determined for each data type. The amount of memory and the memory locations for the variables are given below.

Item	Specification
Amount of memory that is allocated	An integral multiple of the alignment. However, the minimum amount of memory is the data size.
Locations in memory	At an integral multiple of the alignment starting from the start of the variable in memory.

The alignments and the amounts of memory that are allocated for the basic data types and enumerations are given below.

Data type	Alignment [bytes]	Amount of memory that is allocated [bytes]
BOOL	2	2
BYTE, USINT, or SINT	1	1
WORD, UINT, or INT	2	2
DWORD, UDINT, or DINT	4	4
LWORD, ULINT, or LINT	8	8
REAL	4	4
LREAL	8	8
TIME, DATE, TIME_OF_DAY, or DATE_AND_TIME	8	8
STRING[N+1]*1	1	N+1
Enumerations	4	4

^{*1} N is the maximum number of characters handled. For example, if a maximum of 10 single-byte characters are handled, the NULL character is added, so memory for 11 characters must be reserved.

The elements of arrays and the members of structures and unions are located in memory for the most efficient access. The alignments and the amounts of memory that are allocated for arrays, structures, and unions are determined by the variable declarations, as described below.

Data type	Alignment	Amount of memory that is allocated	
Array	Same as alignment of the data type of the elements	(Amount of memory that is allocated for the data type of the elements) \times Number of elements *	
Structure members total amount of memory that is a bers are arranged in order at interest.		The integral multiple of the alignment that is larger than the total amount of memory that is allocated when the members are arranged in order at integral multiples of the alignment of the data types of the members	
Union	The largest alignment of all of the members	The largest amount of memory that is allocated for any of the members	


^{*} BOOL arrays are an exception. Refer to *Precautions for Correct Use*, below, for the amount of memory that is allocated for BOOL arrays.



Precautions for Correct Use

Amount of Memory That Is Allocated for BOOL Arrays

Two bytes are allocated in memory for individual BOOL variables, BOOL structure members, and BOOL union variables. However, for a BOOL array, two bytes of memory are not allocated for each element. One bit is allocated in order for each element. For the entire array, a multiple of two bytes of memory is allocated (including unused bits).



Vá	Variable Table				
	Name	Data type			
	Α	BOOL			
	В	ARRAY[15]OF BOOL			
	С	ARRAY[018]OF BOOL			

Therefore, the following formula gives the amount of memory that is allocated for a BOOL array. For 1 to 16 elements, 2 bytes are allocated. For 17 to 32 elements, 4 bytes are allocated.

Amount of memory =
$$2\left[\begin{array}{c} \text{Number of elements} - 1 \\ \hline 16 \end{array}\right] + 2$$

Truncate the decimal portion of the result of the calculation in brackets.


Specific examples of the rules for memory allocation for variables of each data type are given below.

Basic Data Types

Variables with One-Byte Alignments (e.g., BYTE)

One byte of memory is allocated for the one-byte alignment.


Example: Two consecutive BYTE variables




Variables with Two-byte Alignments (e.g., BOOL and WORD)

Two bytes of memory are allocated for the two-byte alignment.

Example: Two consecutive BOOL variables







Variables with Four-byte Alignments (e.g., DWORD)

Four bytes of memory are allocated for the four-byte alignment.

The location of the first byte of data in memory is an integer multiple of four bytes. Therefore, if a variable with a two-byte alignment, such as WORD data, is inserted, two bytes of unused memory will remain.

Example: Consecutive variables in the following order: DWORD, WORD, and DWORD






Variables with Eight-byte Alignments (e.g., LWORD)

Eight bytes of memory are allocated for the eight-byte alignment.

The location of the first byte of data in memory is an integer multiple of eight bytes. Therefore, if a variable with a two-byte alignment, such as WORD data, is inserted, six bytes of unused memory will remain. If a variable with a four-byte alignment, such as DWORD data, is inserted, four bytes of unused memory will remain.

Example: Consecutive variables in the following order: LWORD, WORD, and LWORD




Variable Table					
Name	Data type				
Α	LWORD				
В	WORD				
С	LWORD				

Arrays


A continuous section of memory is allocated for the elements of the array based on the data size of the data type of the array variable. The alignment of an array is the same as alignment of the data type of the elements.


Example: Continuous variables in the following order: two BOOL variable, one BOOL array with five elements, one BOOL array with 19 elements, and one BOOL array with four elements




Va	ariable Table				
	Name	Data type			
	Α	BOOL			
	В	BOOL			
	С	ARRAY[15]OF BOOL			
	D	ARRAY[018]OF BOOL			
	E ARRAY[58]OF BOOL				

Example: INT array with five elements






Example: BYTE array with four elements for each dimension with two-dimensional array



Va	ariable Table		-
	Name	Data type	1
:	Variable A	ARRAY[03, 03] OF BYTE	
: '			




Example: WORD array with three elements for each dimension with two-dimensional array

Structures

For a structure variable, the members are located in memory in the order that they are declared. Each member is located at an integer multiple of the alignment of the data type of the member. Therefore, there can be unused memory between members or at the end of members. The alignment of a structure is the largest alignment of all of the members. The amount of memory that is allocated is the integral multiple of the alignment that is larger than the total amount of memory that is allocated when the members are arranged in order at integral multiples of the alignment of the data types of the members.

Example: The alignments and the amounts of memory that are allocated for the four variable declarations given in the following figure are given in the following table.


Variable	Alignment [bytes]	Amount of memory that is allocated [bytes]	
Α	4	8	
В	4	8	
С	4	16	
D	4	16	



D	Data Type Definitions				
	Name		Data type		
	Structure STR_A		STRUCT		
	а		DINT		
	b		INT		
	Name		Data type		
i	Structure STR_B		STRUCT		
1	С		INT		
	d		DINT		
V	Variable Table				
i	Name	Data	type		
	Variable A Struc		tructure STR_A		
	Variable B	Struc	cture STR_B		
į	Variable C	ARR	AY[01] OF STR_A		
i	Variable D	ARR	AY[01] OF STR_B		
V	Name Variable A Variable B Variable C	Struc Struc	type eture STR_A eture STR_B AY[01] OF STR_A		

Example: The alignments and the amounts of memory that are allocated for the four variable declarations given in the following figure are given in the following table.

Variable	Alignment [bytes]	Amount of memory that is allocated [bytes]
Е	2	4
F	2	4
G	2	8
Н	2	8



	Name		Data type	
	Structure STR_C		STRUCT	
	а		ARRAY[07] OF BOOL	
	b		BYTE	
	Name		Data type	
	Structure S	TR_D	STRUCT	
	С		BYTE	
	d		ARRAY[07] OF BOOL	
۷á	ariable Table		. , ,	
Va	ariable Table Name	Data	type	
Vä				
Vä	Name	Stru	type	
Vä	Name Variable E	Struc	type	


Data Type Definitions

Unions

For a union variable, the members overlap in the same memory locations. The alignment of a union is largest alignment of all of the members. The amount of memory that is allocated is the largest amount of memory that is allocated for any of the members.

Example: The alignments and the amounts of memory that are allocated for the four variable declarations given in the following figure are given in the following table.

Variable	Alignment [bytes]	Amount of memory that is allocated [bytes]		
Α	4	4		
В	4	4		
С	4	8		
D	4	8		



	Name		Data type	
	Union UNI_	Α	UNION	
	а		DWORD	
	b		WORD	
	Name		Data type	
	Union UNI_	В	UNION	
	С		WORD	
	d		DWORD	
Variable Table				
	Name	Dat	a type	
	Variable A	Uni	on <i>UNI_A</i>	
	Variable B Uni		on <i>UNI_B</i>	
	Variable C	ARRAY[01] OF UNI_A		
	Variable D	ARRAY[01] OF UNI_B		

A-10-2 Important Case Examples

When you exchange structure variable data between an NJ/NX-series CPU Unit and a remote device, you must align the memory configuration of the structure variable members with those of the remote device. This section describes what to do in either the NJ/NX-series CPU Unit or in the remote device.




Additional Information

This is not necessary when you exchange data between NJ/NX-series CPU Units.

Aligning the Memory Configuration with a Remote Device

There are two methods that you can use to align the memory configuration with a remote device. For example, the differences in the memory configuration for structure variables between an NJ/NX-series CPU Unit and a CJ-series CPU Unit are shown below.

This section describes how to align the memory configuration for these Units.



Method 1: Changing the Memory Configuration of the Structure Variable in the NJ/NX-series CPU Unit

With an NJ/NX-series CPU Unit, you can specify member offsets to change the memory configuration of the members of a structure variable. You can change the memory configuration of the members of a structure variable in the NJ/NX-series CPU Unit so that it is the same as the memory configuration in a remote device that the CPU Unit will communicate with. Specify the member offsets for a structure variable when you register the structure data type.

To communicate with a CJ-series CPU Unit, you can set the offset type to *CJ* to automatically use the CJ-series memory structure. You can set the offset type to *User* to freely set your own offsets.



Version Information


The following table gives the unit version of the CPU Units and the Sysmac Studio version that are required to specify member offsets.

Unit version of CPU Unit	Sysmac Studio version			
Offic version of CFO Offic	1.01 or lower	1.02	1.03 or higher	
1.01 or later	Not possible.	Possible.*	Possible.	
1.00	Not possible.	Not possible.	Not possible.	

^{*} You cannot select the memory offset type. You can set member offsets.

If you change the memory configuration of a structure variable by setting offsets, you must make the same changes for the same structure variable in other NJ/NX-series CPU Units on the network. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No W504-E1-03 or later) for the procedure to change the memory configuration of a structure variable.


Example: The following example shows how the memory configuration of the structure variable in the CJ-series CPU Unit is changed to match the memory configuration of the structure variable in the NJ/NX-series CPU Unit.




To align the memory configurations in the NJ-series and CJ-series CPU Units, offsets are set in the Sysmac Studio.



Here, the following offsets are set for member c of data type Y of the structure variable NJ_X.






Method 2: Changing the Memory Configuration of the Structure Variable in the Remote Device

You can insert a member into the structure variable of the remote device to change it to match the memory configuration of the structure variable in the NJ/NX-series CPU Unit. Both the memory configuration and the data types must be the same between the two structure variables. You therefore need to create the same members in both the remote device and the NJ/NX-series CPU Unit.

Example: The following example shows how the memory configuration of the structure variable in the CJ-series CPU Unit is changed to match the memory configuration of the structure variable in the NJ/NX-series CPU Unit.



A-217

A-11 Registering a Symbol Table on the CX-Designer


When you connect the NJ/NX-series Controller to an NS-series PT, you can use variables on the CX-Designer to set addresses for the functional objects. The variables are managed in a symbol table. This section shows how to copy a table of variables from a Microsoft Excel spreadsheet to register them all at the same time in a symbol table. Refer to the *CX-Designer User's Manual* (Cat. No. V099) for detailed information on the CX-Designer.

1 Use the following format to create a table of variables in a Microsoft Excel spreadsheet.

You must use the same number and arrangement of columns as in the following format. Do not omit any columns even if they are empty, like the *Address type/address* and *I/O comment* columns that are shown below.

Host	Name	Туре	Address type/address	I/O com- ment	Tag
HOST3	_Card1BkupCmd.ExecBkup	BOOL			TRUE
HOST3	_Card1BkupCmd.CancelBkup	BOOL			TRUE
HOST3	_Card1BkupCmd.ExecVefy	BOOL			TRUE
HOST3	_Card1BkupCmd.CancelVefy	BOOL			TRUE
HOST3	_Card1BkupCmd.DirName	STRING(64)			TRUE
HOST3	_Card1BkupSta.Done	BOOL			TRUE
HOST3	_Card1BkupSta.Active	BOOL			TRUE
HOST3	_Card1BkupSta.Err	BOOL			TRUE
HOST3	_Card1VefySta.Done	BOOL			TRUE
HOST3	_Card1VefySta.Active	BOOL			TRUE
HOST3	_Card1VefySta.VefyRslt	BOOL			TRUE
HOST3	_Card1VefySta.Err	BOOL			TRUE
HOST3	_BackupBusy	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.Exec	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.DirName	STRING(64)			TRUE
HOST3	_Card1PrgTransferCmd.Password	STRING(33)			TRUE
HOST3	_Card1PrgTransferCmd.TargetUserProgram	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.TargetIPAdr	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.TargetVariable	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.TargetMemory	BOOL			TRUE
HOST3	_Card1PrgTransferSta.Done	BOOL			TRUE
HOST3	_Card1PrgTransferSta.Active	BOOL			TRUE
HOST3	_Card1PrgTransferSta.Err	BOOL			TRUE
HOST3	_Card1RestoreCmd.Exec	BOOL			TRUE
HOST3	_Card1RestoreCmd.DirName	STRING(64)			TRUE
HOST3	_Card1RestoreCmd.Password	STRING(33)			TRUE
HOST3	_Card1RestoreSta.Done	BOOL			TRUE
HOST3	_Card1RestoreSta.Active	BOOL			TRUE
HOST3	_Card1RestoreSta.Err	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetUserProgram	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetIPAdr	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetVariable	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetMemory	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetUnitConfig	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetAbsEncoder	BOOL			TRUE

2 Start the CX-Designer and open the Symbol Table Dialog Box.



3 Copy the shaded portion of the Microsoft Excel spreadsheet.


Always copy all of the columns that are shown below.

Host	Name	Туре	Address type/address	I/O com- ment	Tag
HOST3	_Card1BkupCmd.ExecBkup	BOOL			TRUE
HOST3	_Card1BkupCmd.CancelBkup	BOOL			TRUE
HOST3	_Card1BkupCmd.ExecVefy	BOOL			TRUE
HOST3	_Card1BkupCmd.CancelVefy	BOOL			TRUE
HOST3	_Card1BkupCmd.DirName	STRING(64)			TRUE
HOST3	_Card1BkupSta.Done	BOOL			TRUE
HOST3	_Card1BkupSta.Active	BOOL			TRUE
HOST3	_Card1BkupSta.Err	BOOL			TRUE
HOST3	_Card1VefySta.Done	BOOL			TRUE
HOST3	_Card1VefySta.Active	BOOL			TRUE
HOST3	_Card1VefySta.VefyRslt	BOOL			TRUE
HOST3	_Card1VefySta.Err	BOOL			TRUE
HOST3	_BackupBusy	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.Exec	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.DirName	STRING(64)			TRUE
HOST3	_Card1PrgTransferCmd.Password	STRING(33)			TRUE
HOST3	_Card1PrgTransferCmd.TargetUserProgram	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.TargetIPAdr	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.TargetVariable	BOOL			TRUE
HOST3	_Card1PrgTransferCmd.TargetMemory	BOOL			TRUE
HOST3	_Card1PrgTransferSta.Done	BOOL			TRUE
HOST3	_Card1PrgTransferSta.Active	BOOL			TRUE
HOST3	_Card1PrgTransferSta.Err	BOOL			TRUE
HOST3	_Card1RestoreCmd.Exec	BOOL			TRUE
HOST3	_Card1RestoreCmd.DirName	STRING(64)			TRUE
HOST3	_Card1RestoreCmd.Password	STRING(33)			TRUE
HOST3	_Card1RestoreSta.Done	BOOL			TRUE
HOST3	_Card1RestoreSta.Active	BOOL			TRUE
HOST3	_Card1RestoreSta.Err	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetUserProgram	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetIPAdr	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetVariable	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetMemory	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetUnitConfig	BOOL			TRUE
HOST3	_Card1RestoreCmdTargetAbsEncoder	BOOL			TRUE


4 Right-click in the Symbol Table Dialog Box in the CX-Designer and select *Paste* from the menu.



5 In the Host Selection Dialog Box on the CX-Designer, select the NJ/NX-series Controller host and then click the OK Button.



The variables are registered in the Symbol Table Dialog Box of the CX-Designer.



A-12 Enable/Disable EtherCAT Slaves and Axes

You can enable and disable EtherCAT slaves and axes using programming instructions. You can use this for the following types of applications.

- Managing more than one machine with different EtherCAT slave configurations and axis compositions with one project on the Sysmac Studio.
- Leaving one production line running while you change the EtherCAT slave configuration or axis composition of another line.

This section describes the instructions and system-defined variables that are used and provides some application examples.



Version Information

A CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher are required to use the instructions to enable and disable EtherCAT slaves and axes.

A-12-1 Project Settings When Using EtherCAT Slaves and Axes

When you turn ON the power supply or download the project, disable in advance any EtherCAT slaves that may not be installed in the EtherCAT network. Also, set any axes for those EtherCAT slaves to unused axes. If any EtherCAT slaves that are not installed on the EtherCAT network are enabled or if any of their axes are set to used axes, an error will occur when operation is started.



Additional Information

- You can also enable and disable EtherCAT slaves in the following Sysmac Studio settings:
 Configurations and Setup EtherCAT Network Configuration Enable/Disable Settings. If you use the Sysmac Studio settings, however, you would have to use the Sysmac Studio to change the settings every time or you would have to change the project file depending on the machine to handle the application that is described later in Application 1: Centralized Management of Machines with Different EtherCAT Slave Configuration and Axis Composition on page A-224.
- You can disable an EtherCAT slave to enable removing it or installing it on the EtherCAT network.

A-12-2 Using Instructions to Enable/Disable EtherCAT Slaves and Axes

You can use instructions in the user program to enable and disable EtherCAT slaves and axes. Separate instructions are used to enable and disable EtherCAT slaves and to enable and disable axes. Both instructions are given in the following table.

Item changed	Instruction
EtherCAT slaves	EC_ChangeEnableSetting (Enable/Disable EtherCAT Slave) instruction
Axes	MC_ChangeAxisUse (Change Axis Use) instruction



Version Information

A CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher are required to use the EC_ChangeEnableSetting and MC_ChangeAxisUse instructions.

EC_ChangeEnableSetting Instruction

The EC_ChangeEnableSetting (Enable/Disable EtherCAT Slave) instruction is used to enable and disable EtherCAT slaves. You can use the EC_ChangeEnableSetting instruction to enable or disable the EtherCAT slave with the specified node address. If you cycle the power supply to the Controller after this instruction is executed, the settings will return to the settings from before instruction execution. Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for the detailed specifications of the EC_ChangeEnableSetting instruction.

MC_ChangeAxisUse Instruction

The MC_ChangeAxisUse (Change Axis Use) instruction is used to enable and disable axes. The MC_ChangeAxisUse instruction changes the setting of the Axis Use axis parameter of the specified axis between *Used Axis* and *Unused Axis*. If you cycle the power supply to the Controller after this instruction is executed, the settings will return to the settings from before instruction execution. Refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for the detailed specifications of the MC_ChangeAxisUse instruction.

A-12-3 System-defined Variables That Indicate EtherCAT Slave or Axis Status

You can check the values of system-defined variables to get the current status of EtherCAT slaves and axes. The system-defined variables for these are given below.

Accessed status	System-defined variable name
EtherCAT slaves	_EC_DisableSlavTbl[] (Disabled Slave Table)
Axes	_MC_AX[].Cfg.AxEnable (Axis Use)*1

^{*1} You can also use _MC1_AX[].Cfg.AxEnable and _MC2_AX[].Cfg.AxEnable with the NX701 CPU Unit.

_EC_DisableSlavTbl[] (Disabled Slave Table)

The _EC_DisableSlavTbl[] (Disabled Slave Table) system-defined variable tells whether each Ether-CAT slave is currently disabled. The node address is specified for the array subscript. The meanings of the values in _EC_DisableSlavTbl[] (Disabled Slave Table) are given below.

Value	Meaning
TRUE	The EtherCAT slave with the specified node address is disabled.
FALSE	The EtherCAT slave with the specified node address is enabled.

_MC_AX[].Cfg.AxEnable (Axis Use)

The _MC_AX[].Cfg.AxEnable (Axis Use) system-defined variable tells whether each axis is defined and whether each axis is used. The axis number is specified for the array subscript. The meanings of the values in _MC_AX[].Cfg.AxEnable (Axis Use) are given below.

Value	Meaning
0: _mcNoneAxis	The specified axis is an undefined axis.
1: _mcUnusedAxis	The specified axis is an unused axis.
2: _mcUsedAxis	The specified axis is a used axis.

A-12-4 Enabling/Disabling Execution of Program

There are certain programs associated with the EtherCAT slaves and axes, which are enabled or disabled. These associated programs must be enabled or disabled as the EtherCAT slaves and axes are enabled or disabled. To enable or disable the program, use the following instructions in the user program.

Function	Instruction
Enable program	PrgStart instruction
Disable program	PrgStop instruction

Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502-E1-10 or later) for the detailed specifications of the PrgStart instruction and PrgStop instruction.



Precautions for Correct Use

When you want to disable the program, first disable the EtherCAT slave and axis which the program is associated with, and then disable the program.



Version Information

A CPU Unit with unit version 1.08 or later and Sysmac Studio version 1.09 or higher are required to use the PrgStart and PrgStop instructions.

A-12-5 Checking Enabled/Disabled Program

You can use the PrgStatus instruction to check the program is enabled or disabled that is associated with the EtherCAT slave and axis that are enabled and disabled.

Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502-E1-10 or later) for the detailed specifications of the PrgStatus instruction.



Version Information

A CPU Unit with unit version 1.08 or later and the Sysmac Studio version 1.09 or higher are required to use the PrgStatus instruction.

A-12-6 Settings with the Sysmac Studio

You can also enable/disable the EtherCAT slaves and axes and set to enable/disable the program at the start of operation using the Sysmac Studio. Some applications require that EtherCAT slave status, axis status and program status at the start of operation are set in advance with the Sysmac Studio.

Enabling/Disabling EtherCAT Slaves with Sysmac Studio

Use the following procedure to enable an EtherCAT slave on the Sysmac Studio.

- 1 Right-click **EtherCAT** under **Configurations and Setup** and select **Edit** from the menu. The EtherCAT Tab Page is displayed.
- 2 In the Toolbox, right-click the EtherCAT slave you want to connect and select *Insert* from the menu. The selected EtherCAT slave is displayed under the EtherCAT master on the EtherCAT Tab Page. Also, the Parameter Settings Area for the EtherCAT slave is displayed on the right side of the EtherCAT Tab Page.

3 Set the value of Enable/Disable Settings to Enabled on the Parameter Settings Area for the EtherCAT slave.

Enabling/Disabling Axis with Sysmac Studio

Use the following procedure to enable an axis on the Sysmac Studio.

- Right-click Axis Settings under Configurations and Setup Motion Control Setup and select Add Axis Settings from the menu.
 - The axis MC_Axis000(0) is added under Axis Settings.
- **2** Right-click *MC_Axis000(0)* and select *Edit* from the menu. The Axis Basic Settings Display appears.
- 3 Set Axis Use to Used Axis.

Running/Stopping Program at the Start of Operation with Sysmac Studio

Use the following procedure to execute a program at the start of operation on the Sysmac Studio.


- **1** Right-click **Task Settings** under **Configurations and Setup** and select **Edit** from the menu. The Task Settings Tab Page is displayed.
- Click the Program Assignment Settings Button.
 The Program Assignment Settings Display appears.
- **3** Set **Initial Status** of the program to *Run* on the Program Assignment Settings Display.


A-12-7 Examples of Applications of Enabling/Disabling EtherCAT Slaves and Axes

This section provides concrete examples of applications in which EtherCAT slaves and axes are enabled and disabled.

Application 1: Centralized Management of Machines with Different EtherCAT Slave Configuration and Axis Composition

Assume that the EtherCAT slaves and axis compositions for the NJ-series Controllers are different for machines 1 and 2 as shown below. These two machines are centrally managed using one Sysmac Studio project.






In the Sysmac Studio project, an EtherCAT Slave Configuration is created for all four EtherCAT slaves and axes in A, B, C, and D in the figure. Then, on the Sysmac Studio, you set the EtherCAT slave enable/disable settings, Axis Use parameter settings, and the associated program run/stop status at the start of operation according to machine 1, as shown in the following table.

EtherCAT slave	Installed in EtherCAT network	Enable/disable setting	Axis Use parameter setting	Associated programs
A, B, and C	Installed.	Enabled.	Used Axis	Run at the start of operation.
D	Not installed.	Disabled.	Unused Axis	Stop at the start of operation.

To make changes for machine 2, you use instructions to change the EtherCAT slave enable/disable settings, Axis Use parameter settings, and the associated program enable/disable settings as shown in the following table.


EtherCAT slave	Installed in EtherCAT network	Enable/disable setting	Axis Use parameter setting	Associated programs
A, B, and C	Installed.	Enabled.	Used Axis	Executed.
D	Installed.	Enabled.	Used Axis	Executed.

The user program algorithm is shown in the following figure. A signal is input to the Controller from an external device to specify whether machine 1 or machine 2 is operated.



Application 2: Changing the EtherCAT Slave Configuration and Axis Composition during Operation

In the following figure, production line 1 is left running while the EtherCAT slaves and axis composition on production line 2 are changed.



In the Sysmac Studio project, an EtherCAT slave configuration is created for all seven EtherCAT slaves and axes in A to G in the figure.

On the Sysmac Studio, set the EtherCAT slave enable/disable settings, Axis Use parameter settings, and the associated program run/stop status at the start of operation for nodes A to G as shown in the following table. These are the settings for the configuration before change.

EtherCAT slave	Installed in EtherCAT network	Enable/disable setting	Axis Use parameter setting	Associated programs
A and B	Installed.	Enabled.	Used Axis	Run at the start of operation.
C, E, and D	Installed.	Enabled.	Used Axis	Run at the start of operation.
F and G	Not installed.	Disabled.	Unused Axis	Stop at the start of operation.

The following procedure is used to change the EtherCAT slaves and axes that are used from C, D, E to F and G.

- **1** Stop production line 4.
- **2** Use the MC_ChangeAxisUse instruction to set the Axis Use parameters for C, D, and E to *Unused Axis*.
- 3 Use the EC_ChangeEnableSetting instruction to disable the settings for EtherCAT slaves C, D, and E.
- **4** Use the PrgStop instruction to disable the programs associated with C, D and E.
- **5** Remove EtherCAT slaves C, D, and E from production line 4.
- **6** Install EtherCAT slaves F and G on production line 4.
- 7 Use the EC_ChangeEnableSetting instruction to enable the settings for EtherCAT slaves F and G.
- **8** Use the MC_ChangeAxisUse instruction to set the Axis Use parameters for F and G to *Used Axis*.
- **9** Use the PrgStart instruction to enable the programs associated with F and G.
- **10** Start production line 4 again.

As the result of the above steps, the EtherCAT slave enable/disable settings, Axis Use parameter settings, and the associated programs enable/disable settings are changed as shown below.

EtherCAT slave	Installed in EtherCAT network	Enable/disable setting	Axis Use parameter setting	Associated programs
A and B	Installed.	Enabled.	Used Axis	Enabled.
C, E, and D	Not installed.	Disabled.	Unused Axis	Disabled.
F and G	Installed.	Enabled.	Used Axis	Enabled.



Precautions for Correct Use

When you want to disable the program, first disable the EtherCAT slave and axis which the program is associated with, and then disable the program.

A-13 Size Restrictions for the User Program

There are size restrictions for the user program due to the limitations of the memory capacity in the CPU Unit and other factors. If you exceed these restrictions, errors will occur during operation. This section describes each of the size restrictions of a user program that is created in a CPU Unit.

You can check the approximate sizes of the user program and variables with the memory display functions of the Sysmac Studio.

Be careful not to exceed these restrictions when you create the user program. The restrictions that are given in this section, however, are only reference values for use as guidelines. We recommend that you ensure ample leeway for the restrictions to allow for the possibility of future user program expansion as well as for other reasons.



Precautions for Correct Use

Errors can occur during online editing even if the user program size restrictions are not exceeded. This is because even if you change the user program with online editing, other data that is allocated in the memory of the CPU Unit may remain. If errors occur, change the Controller to PROGRAM mode and transfer the user program to the Controller again to reset the errors.

A-13-1 User Program Object Restrictions

This section describes the restrictions to user program objects. There are restrictions for the following objects.

- POU
- Variables
- · Data type definitions
- · Constants (literals)

POU Restrictions

There are restrictions both on POU definitions and POU instances.

POU Definition Restrictions

POU definitions are subject to the following restrictions.

			CPU Un	it model		
Restriction	NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
Maximum number of programs	1,000	1,000	500	500	500	500
Maximum value of the following: Number of function block definitions + Number of function definitions + Number of ladder diagram sections	6,000	3,000	450	3,000	750	450
Maximum total number of input, output, and in-out variables in function block and function definitions	64	64	64	64	64	64

POU Instance Restrictions

POU instances are subject to the following restrictions. The maximum number of POU instances depends on the model and unit version of the CPU Unit and the version of the Sysmac Studio.

Maximum Number of POU Instances for the NX701-□□□□

Restriction	CPU Unit model
Restriction	NX701-□□□□
Maximum number of POU instances	48,000

Maximum Number of POU Instances for the NX102-□□□□

Restriction	CPU Unit model
Restriction	NX102-□□□□
Maximum number of POU instances	9,000

Maximum Number of POU Instances for the NX1P2-□□□□

Restriction	CPU Unit model
Restriction	NX1P2-□□□□
Maximum number of POU instances	1,800

Maximum Number of POU Instances for the NJ501-□□□□

Restriction	Version	CPU Unit model		
Restriction	Sysmac Studio	NJ501-□□□□		
Maximum number of POU instances	1.05 or lower	6,000		
	1.06 or higher	9,000		

Maximum Number of POU Instances for the NJ301-□□□□

Restriction	Unit versi	CPU Unit model	
Restriction	CPU Unit	Sysmac Studio	NJ301-□□□□
Maximum number of POU instances		1.04 or lower	1,500
	1.03 or earlier	1.05 or higher	2,400
	1.04 or later		3,000

Maximum Number of POU Instances for the NJ101-□□□□

Postwistion	CPU Unit model
Restriction	NJ101-□□□□
Maximum number of POU instances	1,800

Refer to Number of POU Instances on page A-231 for information on counting POU instances.

Restrictions to Variables

There are restrictions to both variable usage and variable definitions.

Restrictions to Variable Usage

The usage of variables is subject to the following restrictions.

	CPU Unit model					
Restriction	NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
Maximum total size in Mbytes of variables without a Retain attribute*1	256	32	2* ²	4	2	2
Maximum total size*1 in Mbytes of variables with a Retain attribute	4	1.5	0.032*2	2	0.5	0.5
Maximum number of variables ^{*3} without a Retain attribute	360,000	90,000	90,000	*4	*5	22,500
Maximum number of variables ^{*6} with a Retain attribute	40,000	10,000	5,000	10,000	*7	5,000
Maximum number of network variables	40,000	40,000	27,500	40,000	27,500	27,500

^{*1} The data size of each variable depends on its data type. Refer to 6-3-5 Data Types for the sizes of the data types.

- *3 Refer to *Number of Variables without a Retain Attribute* on page A-231 for information on counting variables.
- *4 The restriction depends on the Sysmac Studio version and the unit version of the CPU Unit as follows: Sysmac Studio version 1.26 or higher and CPU Unit with unit version 1.20 or later: 180,000 Other combinations: 90,000
- *5 The restriction depends on the Sysmac Studio version and the unit version of the CPU Unit as follows: Sysmac Studio version 1.26 or higher and CPU Unit with unit version 1.20 or later: 90,000 Other combinations: 22,500
- *6 Refer to Number of Variables with a Retain Attribute on page A-231 for information on counting variables.
- *7 The restriction depends on the Sysmac Studio version and the unit version of the CPU Unit as follows: Sysmac Studio version 1.05 or higher and CPU Unit with unit version 1.04 or later: 5,000 Other combinations: 2,500

Restrictions to Variable Definitions

Variable definitions are subject to the following restrictions.

	CPU Unit model					
Restriction	NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-
Maximum number of elements per array	65,535	65,535	65,535	65,535	65,535	65,535
Maximum number of dimensions in an array	3	3	3	3	3	3
Maximum size in MB of an array	8	4	1	4	2	2
Maximum value of a subscript (element number) for an array	65,535	65,535	65,535	65,535	65,535	65,535
Maximum size in bytes ^{*1} of a string variable	1,986	1,986	1,986	1,986	1,986	1,986

^{*1} The NULL character at the end must be counted. Therefore, there are 1,985 single-byte characters in a string that has a size of 1,986 bytes.

^{*2} Memory for CJ-series Units is included.

Restrictions to Data Type Definitions

Data type definitions are subject to the following restrictions.

	CPU Unit model						
Restriction	NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-	
Maximum number*1 of data type definitions	8,000	1,000	1,000	2,000	1,000	1,000	
Maximum number of levels in a structure definition	8	8	8	8	8	8	
Maximum number of members in a structure definition	2,048	2,048	2,048	2,048	2,048	2,048	
Maximum size in MB of a structure variable	8	4	1	4	2	2	
Maximum number of members in a union definition	4	4	4	4	4	4	
Maximum number of enumerators in an enumeration definition	2,048	2,048	2,048	2,048	2,048	2,048	

^{*1} Refer to Number of Data Type Definitions on page A-232 for information on counting data types.

Restrictions to Constants (Literals)

The constants (literals) are subject to the following restrictions.

	CPU Unit model						
Restriction	NX701-	NX102-	NX1P2-	NJ501-	NJ301-	NJ101-	
Maximum size in bytes of a constant (literal)	1,985	1,985	1,985	1,985	1,985	1,985	

A-13-2 Counting User Program Objects

This section describes how to count POU instances, variables with a Retain attribute, variables without a Retain attribute, and data type definitions. The information in this section is provided only as guidelines. The methods for counting objects sometimes varies with the unit version of the CPU Unit. Always use the Sysmac Studio to confirm that user program object sizes are suitable.

Number of POU Instances

POU instances are counted as described below.

Objects Counted as POU Instances

The following objects are counted as POU instances.

- Programs
- Function block instances (both user-created instances and instructions are included)
- Functions (both user-created instances and instructions are included)

Precautions in Counting POU Instances

Observe the following precautions when you count POU instances.

- If n instances of a function block are used for the same function block definition, count them as n
 instances.
- If the same function is used more than once in the same task, count them as one instance regardless of the actual number of functions.
- If the same function is used in different tasks, count them as one instance for each task.

Number of Variables without a Retain Attribute

Variables without a Retain attribute are counted as described below.

Objects Counted as Variables without a Retain Attribute

The following objects are counted as variables without a Retain attribute.

- · Global variables without a Retain attribute
- Local variables without a Retain attribute in programs and function block instances (both user-created instances and instructions are included)

Precautions in Counting Variables without a Retain Attribute

Observe the following precautions when you count variables without a Retain attribute.

- · Count arrays as one variable each regardless of the number of elements.
- Count function block instances as one variable. Both user-created instances and instructions are included for function block instances.
- Count arrays of function block instances as one variable each regardless of the number of elements. However, count one variable for each element of the array for the number of variables without a Retain attribute that are used in the function block.

Number of Variables with a Retain Attribute

Variables with a Retain attribute are counted as described below.

Objects Counted as Variables with a Retain Attribute

The following objects are counted as variables with a Retain attribute.

- · Global variables with a Retain attribute
- Local variables with a Retain attribute in programs and function block instances (both user-created instances and instructions are included)

Precautions in Counting Variables with a Retain Attribute

Observe the following precautions when you count variables with a Retain attribute.

- Count arrays as one variable each regardless of the number of elements.
- Do not count arrays of function block instances. However, count one variable for each element of the array for the number of variables with a Retain attribute that are used in the function blocks.

Number of Data Type Definitions

Data type definitions are counted as described below.

Objects Counted as Data Type Definitions

The following objects are counted as data type definitions.

- · User-created structure definitions
- · User-created union definitions
- · User-created enumeration definitions

A-14 Replacing CPU Units with Unit Version 1.02 or Earlier

An NJ-series CPU Unit with a unit version of 1.02 or earlier does not support the SD Memory Card backup functions and Sysmac Studio Controller backup functions. Therefore, the following work is required to replace a CPU Unit when it fails or to change to a newer version.

Work	Description
Upload the data from the CPU Unit.	Upload the following three types of data from the old CPU Unit. Each of these must be uploaded separately.
	Project
	Present values of variables and memory
	Tag data link tables
Connect the new CPU Unit.	Remove the old CPU Unit from the Controller and connect the new CPU Unit.
Download the data to the CPU Unit.	Download the three types of data that you stored in the computer to the new CPU Unit.

Details on the above work is provided in the following sections.

A-14-1 Uploading the Data from the CPU Unit

Upload the following three types of data from the old CPU Unit. Each of these must be uploaded separately. Use the Sysmac Studio and the Network Configurator.

Data to upload	Contents of data	Support Software
Project	Unit Configuration and Unit Setup	Sysmac Studio
	I/O Map	
	Controller Setup (Operation Settings and Built-in Ether- Net/IP Port Settings)	
	Motion Control Setup	
	Cam Data Settings	
	Event Setup	
	Task Settings	
	• POUs	
	Data type definitions and global variable definitions	
Present values of vari-	Values of variables with a Retain attribute	Sysmac Studio
ables and memory	Values of the Holding, DM, and EM Areas in the memory for CJ-series Units	
	Absolute encoder home offsets	
Tag data link tables*1	Tag data link settings for EtherNet/IP	Sysmac Studio
		Network Configurator*2

^{*1} You need to upload tag data link tables only when tag data links are set.

^{*2} Use the Network Configurator with the Sysmac Studio version 1.09 or lower.



Precautions for Correct Use


The following data in the CPU Unit is not included in the project, present values of variables and memory, or tag data link tables. Therefore, you must set them again after you replace the CPU Unit.

- Data Trace Settings
- Controller name
- · Operation authority verification
- · Time zone setting for the built-in clock

Uploading the Project

Use the following procedure to upload the project.


- **1** Start the Sysmac Studio on the computer that is connected to the NJ-series Controller.
- **2** Click the New Project Button and create a new project.
- 3 Select the device and version of the CPU Unit to replace.



4 Click the Online Button in the toolbar.



5 Click the Synchronize Button in the toolbar.



6 Clear the Do not transfer the EtherNet/IP connection settings (built-in port and Unit) Check Box and click the Transfer From Controller Button.

The project in the Controller is uploaded to the computer.



7 Click the Recompare Button.

The uploaded project is compared to the project in the Controller.



Click the Save Button.

The project is saved in the computer.




Uploading the Present Values of Variables and Memory

Use the Sysmac Studio's variable and memory backup function to upload the present values of variables and memory. Refer to 9-8 Sysmac Studio Variable and Memory Backup Functions for details on the Sysmac Studio variable and memory backup functions.

Use the following procedure.

- 1 Select Backup Backup Variables and Memory from the Tools Menu on the Sysmac Studio.
- 2 Select the Present value of Retain attribute variable, DM, EM and Holding Memory used for CJ -series Units, and Absolute encoder home offset value Check Boxes and click the Execute Button.

The variable and memory data is uploaded to the computer.



Uploading Tag Data Link Tables


The Network Configurator is used with the Sysmac Studio version 1.09 or lower.

Use the following procedure to upload the tag data link tables.

- 1 Start the Network Configurator on the computer that is connected to the NJ-series Controller.
- **2** Select *Network Connect* from the toolbar.
- 3 Select Network Upload from the toolbar.

The following message is displayed: "Uploading all devices parameters form network will start based on the current document, OK?"

- 4 Click the Yes Button.
- 5 Select only the IP address of the connected CPU Unit as the device and click the OK Button.



6 Select File – Save As.

The tag data link tables are uploaded to the computer.

A-14-2 Connecting the New CPU Unit

Remove the old CPU Unit and connect the new CPU Unit. Refer to the *NJ-series CPU Unit Hardware User's Manual* (Cat. No. W500) for details on the connection methods.

Perform the following actions for the new CPU Unit.

- Insert the SD Memory Card that was in the old CPU Unit into the new CPU Unit.
- · Set the DIP switch to the same settings as the old CPU Unit.

A-14-3 Downloading the Data to the CPU Unit

Download the project, present values of variables and memory, and tag data link tables to the new CPU Unit.



Precautions for Safe Use

Check the operation of the downloaded project for proper execution before you use it for actual operation.

Downloading the Project

Use the following procedure to download the project.

- **7** Start the Sysmac Studio on the computer that is connected to the NJ-series Controller.
- **2** Click the Open Project Button.
- 3 From the project list, select the project that you uploaded from the old CPU Unit.

In the following example, the name of the project that you uploaded from the previous CPU Unit is *BackupData*.



4 Click the Online Button in the toolbar.



5 Click the Synchronize Button in the toolbar.



6 Clear the Do not transfer the EtherNet/IP connection settings (built-in port and Unit) Check Box and click the Transfer To Controller Button.

The project in the computer is downloaded to the Controller.




Downloading the Present Values of Variables and Memory

Use the Sysmac Studio's variable and memory backup function to download the present values of variables and memory. Refer to 9-8 Sysmac Studio Variable and Memory Backup Functions for details on the Sysmac Studio variable and memory backup functions.

Use the following procedure.

- 1 Select Backup Restore Variables and Memory from the Tools Menu on the Sysmac Studio.
- 2 Select the data file that you uploaded from the old CPU Unit and click the Execute Button.

 The variable and memory data is downloaded to the Controller.




Downloading Tag Data Link Tables

The Network Configurator is used with the Sysmac Studio version 1.09 or lower.

Use the following procedure to download the tag data link tables.

- 1 Start the Network Configurator on the computer that is connected to the NJ-series Controller.
- 2 Select Network Connect from the toolbar.
- 3 Select File Open and open the tag data link file that you uploaded from the old CPU Unit.
- 4 To download tag data link tables to a CPU Unit with unit version 1.03 or later when the tag data link tables were uploaded from a CPU Unit with unit version 1.02 or earlier, select Device Change Device and select NJDDD-1DDD Rev2 as the new device.



5 Select *Network – Download* from the toolbar.


The following message is displayed: "In order to enable new configuration, downloading parameters to all devices will start, OK?"

6 Click the Yes Button.

A list of the currently active devices is displayed.

7 Click the Download after changed to Program mode Button.

The tag data link tables are downloaded to the Controller.





Precautions for Correct Use

If *NJDDD-1DDD Rev2* is not displayed as a new device selection in step 4, above, use the newest version of the Network Configurator.

A-15 Version Information for NX-series Controllers

This section describes the relationship between the unit versions of NX-series CPU Units and the Sysmac Studio versions, and the functions that are supported for each unit version.

A-15-1 Relationship Between Unit Versions of CPU Units and Sysmac Studio Versions

This section also describes how the unit versions of NX-series CPU Units correspond to Sysmac Studio versions. Normally use the corresponding versions.

Unit Versions and Corresponding Sysmac Studio Versions

This following table gives the relationship between the unit versions of NX-series CPU Units and the corresponding Sysmac Studio versions.

Unit version of CPU Unit	Corresponding version of Sysmac Studio
Ver.1.31 ^{*1}	Ver.1.24
Ver.1.30 ^{*2}	Ver.1.23
Ver.1.18 ^{*3}	Ver.1.22
Ver.1.16 ^{*4}	Ver.1.20
Ver.1.14	Ver.1.18
Ver.1.13 ^{*5}	Ver.1.17 ^{*6}
Ver.1.12	Ver.1.16
Ver.1.11	Ver.1.15
Ver.1.10	Ver.1.13

^{*1} This is the Unit version of NX102-□□□□ CPU Units. There is no NX701-□□□□□ CPU Unit and NX1P2-□□□□□□□□□□□□□□□□□ CPU Unit with unit version 1.31.

Specifications When Not Using the Sysmac Studio Version That Corresponds to the Unit Version of the CPU Unit

The specifications when you do not use the Sysmac Studio version that corresponds to the unit version of the NX-series CPU Unit are given in this section.

Using Sysmac Studio Version 1.12 or Lower

You cannot use the NX-series CPU Unit with Sysmac Studio version 1.12 or lower.

Using a Lower Version of Sysmac Studio

If you use a lower version of the Sysmac Studio, you can use only the functions of the unit version of the CPU Unit that corresponds to the Sysmac Studio version.

^{*2} This is the Unit version of NX102- CPU Units. There is no NX102- CPU Unit with unit version 1.29 or earlier. There is no NX701- CPU Unit and NX1P2- CPU Unit with unit version 1.30.

^{*3} There is no NX701-\(\subseteq \subseteq \) CPU Unit and NX1P2-\(\subseteq \subseteq \subseteq \subseteq \) CPU Unit with unit version 1.17.

^{*4} There are no NX701- and NX1P2- CPU Units with unit version 1.15.

^{*5} There is no NX1P2-\(\sigma\) \(\sigma\) CPU Unit with unit version 1.12 or earlier.

Example: Unit version of CPU Unit: 1.11

Sysmac Studio version: 1.13

Unit version 1.10 of the CPU Unit corresponds to Sysmac Studio version 1.13. Therefore, you can use only the functions that are supported by unit version 1.10 of the CPU Unit. You cannot use functionality that was added for unit version 1.11 or later of the

CPU Unit.

Using a CPU Unit with an Earlier Unit Version

If you use an NX-series CPU Unit with an earlier version, select the unit version of the connected CPU Unit or an earlier unit version in the Select Device Area of the Project Properties Dialog Box on the Sysmac Studio. You can use only the functions that are supported by the unit version of the connected CPU Unit.

Example: Unit version of CPU Unit: 1.10

Sysmac Studio version: 1.15

Unit version 1.11 of the CPU Unit corresponds to Sysmac Studio version 1.15. However, the connected CPU Unit is unit version 1.10, so select version 1.10 as the version in the Select Device Area of the Project Properties Dialog Box.

If you select version 1.10 as the version in the Select Device Area of the Project Properties Dialog Box, you can use only the functions that are supported by unit version 1.10 of the CPU Unit. You cannot use functionality that was added for unit version 1.11 or later of the CPU Unit.



Additional Information

Unit Version Settings for Project Devices

- With Sysmac Studio version 1.02 or higher, you can select the unit version in the Select Device Area of the relevant dialog boxes.
- You can select any unit version that is the same as or earlier than the unit version of the CPU Unit. For example, if the unit version of the CPU Unit is 1.11, select either 1.10 or 1.11.
- The Sysmac Studio will treat the CPU Unit as a CPU Unit with the unit version that is selected for the project device. For example, if you set unit version 1.10 for project device, you can use only the functionality for unit version 1.10 on the Sysmac Studio.
- You can transfer a project to the Sysmac Studio if the unit version that is set for the project device is the same as or earlier than the unit version of the destination CPU Unit.
- Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504-E1-03 or later) for details on the Select Device Area of the relevant dialog boxes.

A-15-2 Functions That Were Added or Changed for Each Unit Version

This section describes the functions that were added or changed for each unit version of NX-series CPU Unit.

Additions and Changes to Functional Specifications

The following table gives the unit version of the CPU Units and the Sysmac Studio version for each addition or change to the functional specifications.

	Function			Addi- tion/cha nge	Unit ver- sion	Sysmac Studio version	Reference
Program- ming	Variables	Arrays	Variable- length array	Addition	Ver.1.18	Ver.1.22	6-3-7 Array Specifications and Range Specifications for Data Types
Communi- cations	EtherNet/ IP port	TCP/IP function	Packet Filter *1	Addition	Ver.1.30	Ver.1.23	NJ/NX-series CPU Unit Built-in Ether- Net/IP Port User's Man- ual (Cat. No. W506)
		CIP Safety routing*1		Addition	Ver.1.31	Ver.1.24	NX-series Safety Control Unit User's Manual (Cat. No. Z930-E1- 12 or later)
		OPC UA	Server func- tion*1	Addition	UA User's N	<i>lanual</i> (Cat. N s and correspo	CPU Unit OPC lo. W588) for onding Sysmac
		Others	Modbus/TCP (Client)*1	Addition	Ver.1.30	Ver.1.23	NJ/NX-series CPU Unit Built-in Ether- Net/IP Port User's Man- ual (Cat. No. W506)
			FINS com- munications service*1	Addition	Ver.1.30	Ver.1.23	NX-series CPU Unit FINS User's Manual (Cat. No. W596)
	Communicat	ions instructions	5	Change	Ver.1.11 Ver.1.30 ^{*1}	Ver.1.15 Ver.1.23	NJ/NX-series Instructions Reference Manual (Cat. No. W502)
SD Memory Cards	Application	Program trans Memory Card		Addition	Ver.1.11	Ver.1.15	9-5 Program Transfer from SD Memory Card
Backing up data	Safety unit restore*1			Addition	Ver.1.31	Ver.1.24	9-1-4 Types of Backup Func- tions

^{*1} This addition applies only to NX102-

Note Refer to the manuals for the function modules for additions and changes to function module functions for each unit version of the CPU Units.

Additions and Changes to Basic Instructions and Motion Control Instructions

The basic instructions and motion control instructions that you can use have increased or changed for the new unit version of the CPU Unit.

For details, refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) and *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Additions and Changes to Controller Events

The events that can occur have increased or changed for the new unit version of the CPU Unit. There are also changes in the recovery methods to use when some errors occur.

For details, refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503).

Additions and Changes to System-defined Variables

The system-defined variables that you can use have increased or changed for the new unit version of the CPU Unit.

Refer to A-6 System-defined Variables for details.

A-16 Version Information for NJ-series Controllers

This section describes the relationship between the unit versions of NJ-series CPU Units and the Sysmac Studio versions, and the functions that are supported for each unit version.

A-16-1 Relationship between Unit Versions of CPU Units and Sysmac Studio Versions

This section also describes how the unit versions of NJ-series CPU Units correspond to Sysmac Studio versions. Normally use the corresponding versions.

Unit Versions and Corresponding Sysmac Studio Versions

The following table gives the relationship between unit versions of NJ-series CPU Units and the corresponding Sysmac Studio versions.

Unit version of CPU Unit	Corresponding version of Sysmac Studio
Ver.1.20	Ver.1.26
Ver.1.19	Ver.1.24
Ver.1.18	Ver.1.22
Ver.1.17	Ver.1.21
Ver.1.16	Ver.1.20
Ver.1.15	Ver.1.19
Ver.1.14	Ver.1.18
Ver.1.13	Ver.1.17
Ver.1.12	Ver.1.16
Ver.1.11	Ver.1.15
Ver.1.10 ^{*1}	Ver.1.13 ^{*2}
	Ver.1.12
Ver.1.09	Ver.1.10
Ver.1.08	Ver.1.09
Ver.1.07	Ver.1.08
Ver.1.06	Ver.1.07
Ver.1.05	Ver.1.06
Ver.1.04	Ver.1.05
Ver.1.03	Ver.1.04
Ver.1.02	Ver.1.03
Ver.1.01	Ver.1.02
Ver.1.00 ^{*3}	Ver.1.01
	Ver.1.00

^{*1} There is no NJ101-□□□□ CPU Unit with unit version 1.09 or earlier.

^{*2} Use an NJ101-□□□□ CPU Unit with Sysmac Studio version 1.13 or higher. You cannot use an NJ101-□□□□ CPU Unit with Sysmac Studio version 1.12 or lower.

^{*3} There is no NJ301-□□□□ CPU Unit with unit version 1.00. Therefore, you cannot use an NJ301-□□□□ CPU Unit with Sysmac Studio version 1.01 or lower.

Specifications When Not Using the Sysmac Studio Version That Corresponds to the Unit Version of the CPU Unit

The specifications when you do not use the Sysmac Studio version that corresponds to the unit version of the NJ-series CPU Unit are given in this section.

Using a Lower Sysmac Studio Version

If you use a lower version of the Sysmac Studio, you can use only the functions of the unit version of the CPU Unit that corresponds to the Sysmac Studio version.

Example: Unit version of CPU Unit: 1.04

Sysmac Studio version: 1.04

Unit version 1.03 of the CPU Unit corresponds to Sysmac Studio version 1.04. Therefore, you can use only the functions that are supported by unit version 1.03 of the CPU Unit. You cannot use functionality that was added for unit version 1.04 or later of the

CPU Unit.

Using a CPU Unit with an Earlier Unit Version

If you use an NJ-series CPU Unit with an earlier version, select the unit version of the connected CPU Unit or an earlier unit version in the Select Device Area of the Project Properties Dialog Box on the Sysmac Studio. You can use only the functions that are supported by the unit version of the connected CPU Unit.

Example: Unit version of CPU Unit: 1.03

Sysmac Studio version: 1.05

Unit version 1.04 of the CPU Unit corresponds to Sysmac Studio version 1.05. However, the connected CPU Unit is unit version 1.03, so select version 1.03 or earlier as the version in the Select Device Area of the Project Properties Dialog Box. If you select version 1.03 as the version in the Select Device Area of the Project Properties Dialog Box, you can use only the functions that are supported by unit version 1.03 of the CPU Unit. You cannot use functionality that was added for unit version 1.04 or later of the





Precautions for Correct Use

An error will occur if you perform the following type of operation.

- Create a project on Sysmac Studio version 1.02 or higher with unit version 1.01 or later selected as the version in the Select Device Area of the Project Properties Dialog Box.
- Upload the project to Sysmac Studio version 1.01.



Additional Information

Unit Version Settings for Project Devices

- With Sysmac Studio version 1.02 or higher, you can select the unit version in the Select Device Area of the relevant dialog boxes.
- You can select any unit version that is the same as or earlier than the unit version of the CPU Unit. For example, if the unit version of the CPU Unit is 1.01, select either 1.00 or 1.01.
- The Sysmac Studio will treat the CPU Unit as a CPU Unit with the unit version that is selected for the project device. For example, if you set unit version 1.00 for project device, you can use only the functionality for unit version 1.00 on the Sysmac Studio.
- You can transfer a project to the Sysmac Studio if the unit version that is set for the project device is the same as or earlier than the unit version of the destination CPU Unit.
- Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504-E1-03 or later) for details on the Select Device Area of the relevant dialog boxes.

A-16-2 Relationship between Hardware Revisions of CPU Units and Sysmac Studio Versions

The following table shows how the hardware revisions of the NJ-series CPU Units correspond to Sysmac Studio versions. Use the corresponding version of Sysmac Studio or higher if you execute the Simulator in Execution Time Estimation Mode. You cannot select the relevant hardware revision if you use a lower version of the Sysmac Studio.

Model number	Hardware revision of CPU Unit	Corresponding version of Sysmac Studio
NJ501-□□□□	Α	Ver.1.14
	В	Ver.1.24
NJ301-□□□□	Α	Ver.1.24
NJ101-□□□□	A	Ver.1.24

A-16-3 Functions That Were Added or Changed for Each Unit Version

This section gives the functions that were added or changed for each unit version of NJ-series CPU Unit.

Additions and Changes to Functional Specifications

The following table gives the unit version of the CPU Units and the Sysmac Studio version for each addition or change to the functional specifications.

Function		Addition/ change	Unit version	Sysmac Studio version	Reference		
Tasks	Function	Conditionally ex	ecuted tasks	Addition	1.03	1.04	5-2 Overview of Tasks
Programming	Namespaces	•		Addition	1.01	1.02	6-7 Namespaces
	Data types	Structure data types	Specifying member off-sets	Addition Change	1.01	1.02	Specifying Structure Member Offsets on page 6-42
	Variables	Arrays	Variable- length array	Addition	1.18	1.22	6-3-7 Array Specifications and Range Specifications for Data Types
	Libraries			Addition	1.01	1.02	6-8 Libraries
Motion control	Single axes	Single-axis position control	Cyclic syn- chronous absolute posi- tioning	Addition	1.03	1.04	NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507)
		Auxiliary function for single- axis control	Homing with specified parameters	Addition	1.03	1.04	
			Enabling digi- tal cam switches	Addition	1.06	1.07	
			Command position compensation	Addition	1.10	1.12	
			Start velocity	Addition	1.05	1.06	1
	Axes groups	Multi-axes Axes group coordinated cyclic synchronous absolute positioning	1.02				
	tions for	Auxiliary functions for multi- axes coordi-	Reading axes group posi- tions	Addition	1.01	1.02	
		nated control Changing the axes in a group Addition 1.0	tion 1.01 1.02	1.02			
	Common items	Cams	Generating cam tables	Addition	1.08	1.09	
		Parameters	Changing axis parameters	Addition	1.08	1.09	
	Auxiliary func- tions	Input signal logi	c inversion	Addition	1.05	1.06	
Unit (I/O) management	NX Units			Addition	1.05	1.06	NX-series EtherCAT Coupler Unit User's Manual (Cat. No. W519)

	Function			Addition/ change	Unit version	Sysmac Studio version	Reference
Communications	EtherNet/ IP port	TCP/IP applications	FTP client	Addition	1.08	1.09	NJ/NX-series CPU Unit Built-in Ether- Net/IP Port User's Manual (Cat. No. W506)
		OPC UA	Server Function	Addition	User's Ma	to the NJ/NX-series CPU Unit OPC Manual (Cat. No. W588) for unit v and corresponding Sysmac Studio	
	EtherCAT port	Packet monitorii (NJ301-□□□□		Addition	1.10	1.12	NJ/NX-series CPU Unit Built-in EtherCAT Port User's Manual (Cat. No. W505)
	Communication	s instructions		Change	1.08 1.11	1.09 1.15	NJ/NX-series Instruc- tions Reference Man- ual (Cat. No. W502)
Debugging function	Differential mon	itoring		Addition	1.03	1.04	8-6-5 Differential Monitoring
Reliability functions	Self diagnosis	Controller errors	Changing lev- els	Addition	1.03	1.04	8-8 Changing Event Levels
Security	Asset protection and pre-	on and pre-	Addition	1.01	1.02	8-5-4 Data Protection	
	venting incorrect operation	Operation authority verification	Number of groups	Change	1.01	1.02	8-5-5 Operation Authority Verification
SD Memory Cards			fer from SD	Addition	1.03	1.04	9-4 Automatic Trans- fers from SD Memory Cards
		Program transfe ory Card	er from SD Mem-	Addition	1.11	1.15	9-5 Program Transfer from SD Memory Card
Backing up data	SD Memory Card backups	Operating methods	CPU Unit front-panel DIP switch	Addition	1.03	1.04	9-2 SD Memory Card Backups
			Specification with system- defined vari- ables	Addition	1.03	1.04	
			SD Memory Card Window in Sysmac Stu- dio	Addition	1.03	1.04	
			Special instruction	Addition	1.08	1.09	
		Protection	Disabling backups to SD Memory Cards	Addition	1.03	1.04	9-3 Disabling Back- ups to SD Memory Cards
	Sysmac Studio	Controller backup	os	Addition	1.03	1.04	9-6 Sysmac Studio Controller Backups

^{*1} This addition applies only to an NJ301-□□□□ CPU Unit. The NJ501-□□□□ and NJ101-□□□□ CPU Units support packet monitoring with all versions.

Note Refer to the manuals for the function modules for additions and changes to function module functions for each unit version of the CPU Units.

Addition of Mountable CJ-series Units

The CJ-series Units that can be mounted have increased for the new unit version of the CPU Unit. For details, refer to the *NJ-series CPU Unit Hardware User's Manual* (Cat. No. W500).

• Additions and Changes to Basic Instructions and Motion Control Instructions

The basic instructions and motion control instructions that you can use have increased or changed for the new unit version of the CPU Unit. For details, refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) and *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

Additions and Changes to Controller Events

The events that can occur have increased or changed for the new unit version of the CPU Unit. There are also changes in the recovery methods to use when some errors occur. For details, refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503).

Additions and Changes to System-defined Variables

The system-defined variables that you can use have increased or changed for the new unit version of the CPU Unit. Refer to *A-6 System-defined Variables* for details.

A-16-4 Performance Improvements for Unit Version Upgrades


This section introduces the functions for which performance was improved for each unit version of NJ-series CPU Unit and for each Sysmac Studio version.

	Fun	ction		Performance value	Unit version	Sysmac Stu- dio version
Program-	Program	Quantities	Number of	9,000		1.06 or higher
ming	capacity		POU instances (NJ501-	6,000		1.05 or lower
			Number of	3,000	1.04 or later	1.05 or higher
			POU instances	1,500	1	1.04 or lower
			(NJ301-	2,400	1.03 or earlier	1.05 or higher
				1,500	1	1.04 or lower
	Memory	Variables	Number of vari-	5,000	1.04 or later	1.05 or higher
	capacity for	with a	ables ^{*1} (NJ301-	2,500	1	1.04 or lower
	variables	Retain attribute		2,500	1.03 or earlier	
		Variables	Number of vari-	180,000	1.20 or later	1.26 or higher
		without a Retain	ables (NJ501- □□□□)	90,000	Other than the nation	above combi-
		attribute	Number of vari-	90,000	1.20 or later	1.26 or higher
			ables (NJ301- □□□□)	22,500	Other than the nation	above combi-
Motion	Number of	Maximum n	umber of con-	15 axes	1.06 or later	1.07 or higher
Control	controlled axes trolled axes (NJ301-		8 axes (NJ301- 1200)	Other than the above combination		
			·	4 axes (NJ301- 1100)		
			umber of axes	15 axes	1.06 or later	1.07 or higher
		for single-ax (NJ301-□□	xis control ^{*4*5} □□□)	8 axes (NJ301- 1200)	Other than the nation	above combi-
				4 axes (NJ301- 1100)		
Built-in Ether-	CIP service: Tag data links	Packet inter	rval	Can be set for each connection.	1.03 or higher	
Net/IP port	(cyclic commu- nications)			1 to 10,000 ms in 1-ms increments		
				Can be set for	1.02 or lower	
				each connection.		
				10 to 10,000 ms in		
				1-ms increments		
			communica-	3,000 pps*6	1.03 or higher	
		tions band		(including heart- beat)		
				1,000 pps (including heartbeat)	1.02 or lower	
	Number of TCP sockets		30	1.03 or higher		
				16	1.02 or lower	
Built-in EtherCAT	Communications			500, 1,000, 2,000, or 4,000 μs	1.03 or higher	
port		,		1,000, 2,000, or 4,000 μs	1.02 or lower	

^{*1} The performance improvement applies only to an NJ301-□□□□ CPU Unit. The maximum number of variables with a Retain attributes for the NJ501-□□□□ is 10,000.

^{*2} This is the total for all axis types.

*3	The performance improvement applies only to an NJ301-□□□□ CPU Unit. The maximum numbers of controlled axes for the NJ501-□□□□ are as follows: NJ501-□5□□: 64 axes, NJ501-□4□□: 32 axes, and NJ501-□3□□: 16 axes
*4	There is no change in the maximum number of used real axes.
	The performance improvement applies only to an NJ301-\(\sigma\) CPU Unit. The maximum numbers of axes for single-axis control for the NJ501-\(\sigma\) are as follows: NJ501-\(\sigma\) 64 axes, NJ501-\(\sigma\) 4\(\sigma\): 32 axes, and NJ501-\(\sigma\) 3\(\sigma\): 16 axes
*6	Here, pps means "packets per second" and indicates the number of packets that can be processed in one second.
*7	The performance improvement applies only to an NJ301- \square CPU Unit. You can use 500, 1,000, 2,000 or 4,000 μ s communications cycle with an NJ501- \square CPU Unit, and 1,000, 2,000 or 4,000 μ s communications cycle with an NJ101- \square CPU Unit.



Index

Index

Symbols	_Card1PrgTransferCmd (SD Memory Card
	Program Transfer Command)
.IsCompleteA-82	_Card1PrgTransferSta (SD Memory Card
.lsOutputA-82	Program Transfer Status)
.lsStartA-82	_Card1Protect8-30, A-70, A-129 _Card1Ready8-30, A-70, A-129
A	_Card1RestoreCmd (SD Memory Card
	Restore Command)A-135
accessing I/O with variables2-16	_Card1RestoreSta (SD Memory Card
Accessing Task4-10	Restore Status)
accessing tasks5-97	_Card1VefySta A-72, A-132, A-133
_ <i>TaskName</i> _Active5-8, A-68, A-126	Carry Flag6-8, A-76, A-139
AlarmFlagA-69, A-128	changing event levels8-84
algorithms6-10, 6-17	changing present values8-52
All Tag Data Link Communications StatusA-112	CIP Communications ErrorA-99, A-172
Always FALSE Flag	CIP Communications1 ErrorA-99
Always TRUE Flag	CIP Communications1 Identity ErrorA-104
array specification6-33, 6-50	CIP Communications1 Multiple Switches ON Error A-108
AT Specification6-59	CIP Communications1 Tag Data Link
Axes Group Error Status	Communications ErrorA-106
Axes Group Variables3-18, A-88, A-89	CIP Communications1 Tag Data Link
Axis Error Status	Connection FailedA-106
Axis Variables	CIP Communications1 Tag Data Link Setting Error A-105
7 W.O. Variables 70, 71 00, 71 00	CIP Communications1 Tag Name Resolution ErrorA-107
В	CIP Communications2 ErrorA-100
	CIP Communications2 Identity ErrorA-104
hooking up data	CIP Communications2 Multiple Switches ON Error A-108
backing up data9-3	CIP Communications2 Tag Data Link
Backup Function Busy FlagA-75, A-138	Communications ErrorA-106
_BackupBusyA-75, A-138	CIP Communications2 Tag Data Link
basic data types	Connection FailedA-106
Basic Ethernet Setting ErrorA-101	CIP Communications2 Tag Data Link Setting Error A-105
Basic I/O Unit Information	CIP Communications2 Tag Name Resolution ErrorA-108
Basic I/O Units4-15, 8-22	CIP Safety communications2-10
Basic Input Unit Input Response Times .8-23, A-83, A-150	CIP Safety routingA-243
basic settings4-4	_CJB_CBU00InitSta to _CJB_CBU15InitSta
basic system configuration1-7	8-24, A-84, A-151
basic system configurations1-5, 1-9, 1-11	_CJB_CBU00Restart to _CJB_CBU15Restart
bit strings6-31	8-24, A-84, A-152
Boolean	_CJB_ErrStaA-83, A-149
BOOTP Server ErrorA-103	
Built-in EtherCAT Error	CJB IOUnitInfo
Built-in EtherNet/IP ErrorA-96, A-170	_CJB_MaxRackNoA-83, A-149
bus bars6-90	CJB_MaxSlotNo
	CJB_MstrErrStaA-83, A-150
<u>C</u>	_CJB_SCU00P1ChgSta to _CJB_SCU00P2ChgSta
Card1Access8-30, A-70, A-129	A-84
_Card1BkupCmd A-71, A-130, A-131	_CJB_SCU00P1ChgSta, _CJB_SCU00P2ChgSta to
	_CJB_SCU15P1ChgSta, _CJB_SCU15P2ChgSta A-153
Card1Deteriorated8-30, A-70, A-130	_CJB_SCU15P1ChgSta to _CJB_SCU15P2ChgStaA-84
Card1Err8-30, A-70, A-129	_CJB_SIO00InitSta to _CJB_SIO95InitSta
_Card1PowerFail8-30, A-70, A-130	8-24, A-84, A-151
_Card1PrgRestoreCmd (SD Memory Card	_CJB_SIO00Restart to _CJB_SIO95Restart
Restore Command)A-73	8-24, A-84, A-152
2,	_CJB_UnitErrStaA-83, A-150

CJ-series Unit configuration	1-11	UDINT	6-31
Clearing All Memory	8-3	UINT	
clock	8-3	ULINT	6-31
clock data	8-4	USINT	6-31
Common Error Status A-	88, A-157	WORD	6-31
Common VariableA-	88, A-158	date and time	6-32
communications	10-6	dates	6-31
Communications Bridge Service	2-10	debug programs	7-6
Communications Controller ErrorA-91, A-1	01, A-162	derivative data types	6-33
Communications Error Slave Table A-	92, A-165	device variables	
Communications Port Error A-91, A-97, A-1	61, A-170	_DeviceOutHoldCfg	A-77, A-142
Communications Port1 Error	A-98	DeviceOutHoldStatus	A-77, A-142
Communications Port2 Error		Diagnosis/Statistics Log Busy	
Condition Flags	6-135	Diagnosis/Statistics Log Cycle	
connecting lines		Diagnosis/Statistics Log Enable	
constants		Diagnosis/Statistics Log Error	
Controller Error Status A-		differential monitoring	
Controller errors		Disabled Slave Table	
Controller events	8-70	Disconnected Slave Table	
Controller information		DNS Server Connection Error	
Controller Setup		DNS Setting Error	
CPU Bus Unit Initializing Flags8-24, A-		durations	
CPU Bus Unit Restart Bits8-24, A-			
CPU Unit	0.,70_	E	
name	8-45	_	
CPU Unit High Temperature Flag		_EC_CommErrTbl	Λ_02 Λ_165
CPU unit names		_EC_CycleExceeded	
_CurrentTimeA-		_EC_DisableSlavTbl	
CX-Designer symbol table registration		_EC_DisableSlavTbl	
57 Boolghor dymbor table region and r		_EC_DiscorniciavTbl	
D		_EC_ErrSta	
		_EC_InData1Invalid	
data formats		_EC_InData Inivalid	
bit strings	6.35	_EC_InData2filvalid	
real numbers		_EC_IndataInvalidErr	
text strings		_EC_IndatanivalidEn _EC_LanHwErr	
•		EC LinkOffErr	
data protectiondata tracing		EC LinkStatus	
continuous tracing		EC MacAdrErr	
operation		_EC_MBXSlavTbl	
-			
specifications		_EC_MsgErr	
triggered tracing		_EC_MstrErr	
data types		_EC_NetCfgCmpErr	
BOOL		_EC_NetCfgErr	
BYTE		_EC_NetTopologyErr	
converting		_EC_PDActive	
DATE		_EC_PDCommErr	
DINT		_EC_PDSendErr	·
DWORD		_EC_PDSlavTbl	
INT		_EC_PDTimeoutErr	
LINT		_EC_PktMonStop	
LREAL		_EC_PktSaving	
LWORD		_EC_PortErr	
REAL		_EC_RegSlavTbl	
SINT		_EC_SlavAdrDupErr	
specifications		_EC_SlavAppErr	
STRING		_EC_SlavEmergErr	
TIME		_EC_SlavErr	
TIME OF DAY	6-32	EC SlavErrTbl	Δ-91 Δ-162

_EC_SlavInitErr	A-92, A-164	_EIP_TDLinkOpnErr	
_EC_StatisticsLogBusy		_EIP_TDLinkRunSta	A-112
(Diagnosis/Statistics Log Busy)	A-95, A-169	Emergency Message Detected	
_EC_StatisticsLogCycleSec		EN	6-12, 6-20
(Diagnosis/Statistics Log Cycle)	A-95, A-169	enabling/disabling EtherCAT slaves and	axesA-221
_EC_StatisticsLogEnable		ENO	6-12, 6-20
(Diagnosis/Statistics Log Enable)	A-95, A-169	enumerations	6-48
_EC_StatisticsLogErr		Error	A-79, A-80
(Diagnosis/Statistics Log Error)	A-95, A-169	_ErrSta	A-69, A-128
_EIP1_BootpErr		EtherCAT Communications Cycle Excee	dedA-92
 _EIP1_CipErr		EtherCAT Master Function Module	
: EIP1 EtnCfgErr		initial settings	4-24
 _EIP1_IdentityErr		EtherCAT Message Error	
 _EIP1_IPAdrCfgErr		EtherCAT network configuration	
_EIP1_IPAdrDupErr		EtherNet/IP Function Module	,,,
EIP1 LanHwErr		initial settings	4-25
EIP1 MacAdrErr		event codes	
EIP1 MultiSwONErr		event levels	
EIP1 PortErr		event log categories	
_EIP1_TagAdrErr		Event Log Settings	
_EIP1_TDLinkCfgErr		event logs	
_EIP1_TDLinkErr		Event Setting Table	
_EIP1_TDLINKEIT _EIP1_TDLinkOpnErr		event sources	
_EIP2_BootpErr		event tasks	
_EIP2_CipErr		ActEventTask instruction	
_EIP2_EtnCfgErr		parameters	
_EIP2_IdentityErr		when condition expressions for varia	
_EIP2_IPAdrCfgErr			
_EIP2_IPAdrDupErr		events	
_EIP2_LanHwErr		_TaskName_ExceedCount	
_EIP2_MacAdrErr		_TaskName_Exceeded	5-9, A-69, A-127
_EIP2_MultiSwONErr		Exclusive Control of File Access in	
_EIP2_PortErr		SD Memory Cards	
_EIP2_TagAdrErr		_ <i>TaskName</i> _ExecCount	
_EIP2_TDLinkCfgErr		Execute Backup Flag	
_EIP2_TDLinkErr		external variables	6-12, 6-20
_EIP2_TDLinkOpnErr		_	
_EIP_BootpErr	A-103	F	
_EIP_CipErr	A-99, A-172		
_EIP_DNSCfgErr	A-103	FINS/TCP Connection Status	A-76, A-141
_EIP_DNSSrvErr	A-109	_FINSTCPConnSta	A-76, A-141
_EIP_ErrSta	A-96, A-170	First Program Period Flag	A-140
_EIP_EtnCfgErr	A-101	First RUN Period Flag	
_EIP_EtnOnlineSta	A-111	forced refreshing	
_EIP_IdentityErr	A-104	FramingErr	
_EIP_IPAdrCfgErr	A-102	FTP Client Communication Instructions	
_EIP_IPAdrDupErr	A-103	FTP server	8-29
EIP IPRTblErr	A-104	fully qualified names	
 EIP_LanHwErr		FUN instructions	
 EIP MacAdrErr		function block instructions	
 _EIP_MultiSwONErr		function blocks	
EIP NTPSrvErr		accessing variables from outside the	function block
EIP PortErr		accessing variables from outside the	
_EIP_TagAdrErr		array specifications for instances	
_EIP_TcpAppCfgErr		calling from ST	
_EIP_TcpAppErr		<u> </u>	
_EIP_TDLinkAllRunSta		creating	
_EIP_TDLinkAllKun3ta _EIP_TDLinkCfgErr		definitions and instances	
		details	
_EIP_TDLinkErr	A-100	execution conditions	6-15

instances	6-13	Lock	5-8
instruction names	6-9	ResetUnit	8-23
names	6-9	Unlock	5-8
parameters	6-10	Insufficient System Service Time Error	5-109
structure	6-9	integers	6-31
using or omitting EN and ENO	6-22	internal variables	6-11, 6-20
variable designations	6-11	IP Address Duplication Error	A-103
functions		IP Address Setting Error	A-102
details	6-17	IP Route Table Error	A-104
expressing in ST	6-18	isDetect	A-79
instruction names	6-17		
names	6-17	L	
operation for parameter errors	6-23		
operation when parameters are omitted	6-23	ladder diagram language	6-90
parameters	6-18	ladder diagrams	
structure	6-17	completion	6-91
variable designations	6-19	connecting functions and function bl	
		controlling execution	
G		order of execution	
		Largest Rack Number	A-83, A-149
global variables	6-28	Largest Slot Number	
		Largest Unit Number	
H		Last Task Execution Time	
		_ <i>TaskName</i> _LastExecTime	5-8, A-68, A-126
Hardware revision	A-141	Link OFF Error	
hardware revision		Link Status	
_HardwareRevision (Hardware Revision) A		literals	6-85
	,	local variable tables	6-10, 6-18
1		local Variables	6-28
		Low Battery Flag	A-77
I/O Bus Error Status A	.83 A.1/O	Low FAN Revolution Flag	
I/O Bus Master Error Status A	,	9	
I/O Bus Unit Error Status A	•	М	
I/O Control Task Settings	•		
I/O ports	4-9	MAC Address Error	A-91 A-100 A-162
names	3.0	master control	
I/O refresh operation		Master Error	
		_ <i>TaskName</i> _MaxExecTime	·
I/O Refreshing Timeout ErrorIdentity Error		Maximum Task Execution Time	
		MC Test Run	
implicit castsInitial Start of Operation		_MC1_AX	
- · · · · · · · · · · · · · · · · · · ·		_MC1_GRP	
Initial Status of Program		_MC2_AX	
inline ST		_MC2_AX _MC2_GRP	
in-out variables		_MC_AX_ErrSta	
Input Data Invalid		_MC_COM	
Input Data1 Invalid		_MC_ComErrSta	
Input Data2 Invalid		_MC_GrinSta	
Input Process Data Invalid Error		_MC_GRP_ErrSta	
input variables	6-11, 6-19	Memory Settings for CJ-series Units	
inputs	0.04		
program inputs		Message Communications Enabled Sla	
instance name		_ <i>TaskName</i> _MinExecTime	
instance names			
Instruction Error Flag6-8, 6-140, A		Motion Control Function Module	J-0, A-00, A-121
Instruction Errors			4 00
instruction errors		initial settings	
instruction options	6-134	Motion Control Function Module Error S	
instructions	5 0	Multiple Switches ON Error	
GetMyTaskStatus	5-8	Multiple Switches ON Error	A-108

N		ParityErr	
		P_CY Period/Execution Condition	
names		periodic tasks	
restrictions		periodic tasks that control I/O	
namespace declarations		periodic tasks that do not control I/O	
namespaces		P_First_Run	
Network Communications Instruction Enabled	•	P_First_RunMode	
		PLC Function Module	
network configuration		initial settings	4-4
Network Configuration Error		PLC Function Module Error Status	
Network Configuration Information Error		_PLC_ErrSta	
Network Configuration Verification Error		_PLC_OptBoardSta A-7	
Network Configurations		_PLC_OptSerialErrSta	
network configurations		_PLC_SFLogSta	
Network Connected Slave Table		_PLC_TraceSta[03]	
NTP Server Connection Error		_PLC_TraceSta[03].IsComplete	
Number of Used Ports		_PLC_TraceSta[03].IsStart	
NX Bus Function Module Error Status		_PLC_TraceSta[03].IsTrigger	
NX Bus Function Module Master Error Status		_PLC_TraceSta[03].ParamErr	
NX Bus Function Module Unit Error Status		P_Off	
NX Unit Configuration		P_On	
NX Unit configuration		Port1 Basic Ethernet Setting Error	
NX Unit Error Status		Port1 BOOTP Server Error	
NX Unit I/O Data Active Status		Port1 Communications Controller Error	
NX Unit Message Enabled Status		Port1 IP Address Duplication Error	
NX Unit Registration Status		Port1 IP Address Setting Error	
NXB_ErrSta		Port1 MAC Address Error	
_NXB_MaxUnitNo		Port2 Basic Ethernet Setting Error	
_NXB_MstrErrSta		Port2 BOOTP Server Error	
_NXB_UnitErrFlagTbl		Port2 Communications Controller Error	
_NXB_UnitErrStaTbl		Port2 IP Address Duplication Error	
_NXB_UnitIOActiveTbl		Port2 IP Address Setting Erro	
_NXB_UnitMsgActiveTbl		Port2 MAC Address Error	
_NXB_UnitRegTbl	A-86	_Port_isAvailable	
•		Port numUsingPort	
0		POUs	
		function blocks	6-1
offline debugging		functions	
Online		programs	
online editing		restrictions	
pperation authority verification		POUs (program organization units)	
Operation Settings		Power Interruption Count	
Operation Settings Tab Page		_PowerOnCount	
Option Board Error		_PowerOnHour	
Option Board Mounted		P_PRGER	
Option Board Normal Operation		primary periodic task	
Option Board Status		parameters	
output variables	6-11, 6-19	priority-5 periodic task	
outputs		Process Data Communicating Slave Table	
program outputs		Process Data Communicating clave rable	
overall project file protection		Process Data Communications Error	
OverRun		Process Data Reception Timeout Error	
overview of CPU Unit data	2-36	Process Data Transmission Error	
_		Program Assignment Settings	
P		Program Execution Order	
		programming languages	
Packet Monitoring Stopped	. A-94, A-167	programsprograms	
parameters for priority-16, priority-17,		execution conditions	
and priority-18 periodic tasks	5-95	evecation conditions	0-6

R Setting Change during RUN Mode 4-6 Settings for Exclusive Control of Variables in Tasks4-10, 5-97, 5-104 range specification 6-33, 6-56 Settings for Variable Access Time 5-105 real numbers 6-31 short names 6-143 refreshing tasks 5-97 simulation 7-3 Registered Slave Table A-94, A-165 restoring data9-3 simulation speed7-7 retain condition 6-72 Slave Application Error A-92, A-164 RetainFail A-75, A-139 Slave Error A-91, A-161 Retention Failure Flag A-75, A-139 return values 6-20, 6-21 Slave Initialization Error A-92, A-164 Slave Node Address Duplicated Error A-92, A-163 RUN output 8-6 software configuration2-4 software operation2-5 S Special I/O Unit Initializing Flags 8-24, A-84, A-151 Special I/O Unit Restart Bits 8-24, A-84, A-152 Safety Data Logging8-25 Special Units4-15, 8-23 Safety unit restore 9-9 initial settings4-20 Saving Packet Data File A-94, A-167 specifications SD Memory Card function A-12 exclusive control of file access 8-33 generalA-3 self-diagnosis 8-31 SD Memory Card Access Flag 8-30, A-70, A-129 specifying structure member offsets 6-42 SD Memory Card Backup Commands A-71, A-130 ST language 6-96 SD Memory Card Backup Status A-72, A-131 assignment 6-103 SD Memory Card Error Flag 8-30, A-70, A-129 CASE 6-109 SD Memory Card Life Warning Flag 8-30, A-70, A-130 EXIT 6-119 SD Memory Card Power Interruption Flag expressions 6-97 8-30, A-70, A-130 FOR 6-111 SD Memory Card Program Transfer Command function block calls 6-120 function calls 6-123 SD Memory Card Program Transfer Setting 4-5 IF with multiple conditions 6-106 SD Memory Card program transfer status IF with one condition 6-104A-73, A-135, A-136 operators 6-100 SD Memory Card Ready Flag 8-30, A-70, A-129 REPEAT 6-117 RETURN 6-104 statement keywords 6-98 SD Memory Card Restorer CommandA-73 structure 6-97 SD Memory Card Setting 4-5 syntax errors 6-139 SD Memory Card Verify Status A-72, A-132 WHILE 6-115 SD Memory Card Write Protected Flag . 8-30, A-70, A-129 starting and stopping the Simulator7-3 SD Memory Cards structures 6-40 file operations from the Sysmac Studio 8-29 Support Software 1-5, 1-6, 1-7, 1-8, 1-9, 1-10, 1-12 life expiration detection 8-29 synchronizing sequence control and motion control ... 2-35 operation instructions 8-28 System Service Monitoring Settings 4-5 operations 8-25 system services 5-82 specifications 8-26 System Time A-68, A-126 Security Setting 4-6 system-defined events 8-70 SelfTest HighTemperatureA-77 system-defined variables 6-27 SelfTest LowBatteryA-77 Auxiliary Area bits for CJ-series Units A-84, A-151 SelfTest LowFanRevolutionA-77 semi-user-defined variables 6-27 communications A-76, A-140 sequence control and motion control 2-29 debugging A-78, A-143 sequence control system 2-31 errors A-69, A-78, A-128, A-144 Serial Communications Unit 0, EtherCAT Communications Diagnosis/Statistics Log Port 1/2 Settings Changing Flags A-84, A-153A-169 Serial Communications Units 1 to 15, Port 1/2 Settings Changing Flags A-84, A-153

serial IDs8-45, 8-46

EtherNet/IP communications errors	A-170	Trace Busy Flag	8-62, A-78, A-143
I/O bus errors	A-83, A-149	Trace Completed Flag	8-62, A-78, A-143
I/O bus status	A-83, A-149	Trace Parameter Error Flag	8-62, A-78, A-144
meanings of error status bits	A-123	Trace Trigger Monitor Flag	8-62, A-78, A-143
motion control functions	A-157		
NX Bus Function Module Errors	A-155	U	
NX Bus Function Module Status	A-85, A-154		
Option Boards	A-79	unions	6-46
power supply	A-75, A-138	Unit Version	A-77
programming	A-76, A-139	UnitVersion	A-77, A-141
Safety Data Logging	A-82	Update Variable	4-10
SD Memory Cards	A-70, A-129	user program execution IDs	
tasks	A-126	user program transfer with no rest	
		User-defined Error Status	A-69, A-128
T		user-defined errors	8-77
		user-defined events	8-70
Tag Data Link Communications Error	A-106	user-defined information	8-77
Tag Data Link Communications Status	A-112	user-defined variables	6-27
Tag Data Link Connection Failed	A-105		
Tag Data Link Setting Error	A-105	V	
Tag Name Resolution Error			
Task		values of retain variables after nev	vlv creations
Specifications of the NX-series CPU Ur	nits5-32	or changes of POU names	
Task Active Flag		Variable Access Time	
task design		variable attributes	
example	5-114	AT Specification	6-59
task exclusive control instructions		Constant	
Task Execution Count	5-9, A-68, A-127	Edge	
task execution status		Initial Value	
monitoring	5-110	Network Publish	
Task Execution Status Monitor	4-11	Retain	
Task Execution Time Monitor	4-11, 5-111	Variable Name	
Task Execution Timeout	5-108	variable memory allocation	
Task Execution Timeout Time		rules	A-205
task execution times	5-114	variable names	
Task Name	4-7, 4-9	restrictions	
Task Period Exceeded	5-107	variable values	
Task Period Exceeded Count	5-9, A-69, A-128	ensuring concurrency	5-97
Task Period Exceeded Error Detection		variable values when data types o	
Task Period Exceeded Flag	5-9, A-69, A-127	retained variables are changed .	
task real processing time	5-113	variable-length array specification	6-54
Task Settings	4-7	variables	
Task Type	4-7	attributes	6-29
tasks		outline	6-27
assigning tasks to programs	5-93	types	6-27
monitoring task execution status		verifying data	
and task execution times	5-110	version information	
order of program execution	5-93		
outline	5-6	W	
POUs that you can assign to tasks	5-93		
processing of tasks and system service	es5-17, 5-56	write protection	8-44
synchronizing variable access with task	execution	,	
	5-103		
task execution priority	5-13, 5-34, 5-51		
TCP Application Communications Error	A-100		
TCP/IP Setting Error			
text strings	6-32		
time of day	6-32		

OMRON Corporation **Industrial Automation Company**

Kyoto, JAPAN

Contact: www.ia.omron.com

Regional Headquarters OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2011-2019 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. W501-E1-26