OMRON

Machine Automation Controller

NJ-series

CPU Unit Built-in EtherCAT® Port

User's Manual

NJ501-15□□

NJ501-14□□

NJ501-13□□

NJ301-12□□

NJ301-11□□

CPU Unit





W505-E1-08

© OMRON, 2011

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks -

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Windows, Windows 98, Windows XP, Windows Vista, and Windows 7 are registered trademarks of Microsoft Corporation in the USA and other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD and SDHC logos are trademarks of SD-3C, LLC.





Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Introduction

Thank you for purchasing an NJ-series CPU Unit.

This manual contains information that is necessary to use the NJ-series CPU Unit. Please read this manual and make sure you understand the functionality and performance of the NJ-series CPU Unit before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

Intended Audience

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- Personnel in charge of introducing FA systems.
- Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B3503.

Applicable Products

This manual covers the following products.

- NJ-series CPU Units
 - NJ501-15□□
 - NJ501-14□□
 - NJ501-13□□
 - NJ301-12□□
 - NJ301-11□□

Part of the specifications of the CPU Units are given in other manuals. Refer to *Relevant Manuals* on page 2 and *Related Manuals* on page 23.

Relevant Manuals

There are three manuals that provide basic information on the NJ-series CPU Units: the NJ-series CPU Unit Hardware User's Manual, the NJ-series CPU Unit Software User's Manual, and the NJ-series Instructions Reference Manual.

Most operations are performed from the Sysmac Studio Automation Software. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Sysmac Studio.

Other manuals are necessary for specific system configurations and applications.

Read all of the manuals that are relevant to your system configuration and application to make the most of the NJ-series CPU Unit.

								Manua	l						
				N	J Serie	es					N.	X Serie	es		
	Basic informa- tion														
Purpose of use	NJ-series CPU Unit Hardware User's Manual	NJ-series CPU Unit Software User's Manual	NJ-series Instructions Reference Manual	NJ-series CPU Unit Motion Control User's Manual	NJ-series CPU Unit Built-in EtherCAT Port User's Manual	NJ-series Motion Control Instructions Reference Manual	NJ-series CPU Unit Built-in EtherNet/IP Port User's Manual	NJ-series Database Connection CPU Unit User's Manual	NJ-series Troubleshooting Manual	NX-series EtherCAT Coupler Unit User's Manual	NX-series NX Units User's Manuals	NX-series Safety Control Unit User's Manual	NX-series Safety Control Unit Instructions Reference Manual	NX-series Data Reference Manual	CJ-series Special Unit Operation Manuals for NJ-series CPU Unit
Introduction to NJ-series Controllers	•														
Setting devices and hardware															
Using motion control				•							•				
Using EtherCAT					•										
Using EtherNet/IP							•								
Using the database connection service	•							•							
Using the NX Series										•	•			•	
Performing safety controls												•		•	
Using CJ-series Units															•
Software settings															
Using motion control				•							•				
Using EtherCAT					•										
Using EtherNet/IP							•								
Using the database connection service								•							
Using the NX Series										•	•			•	
Performing safety controls										•		•		•	
Writing the user program															
Using motion control				•		•					•				
Using EtherCAT					•										
Using the database connection								_							
service		•	•					•							
Using the NX Series										•	•				
Performing safety controls												•	•		
Using CJ-series Units															•
Programming error processing									•						


								Manua	ı						
				N	J Serie	es					N	X Seri	es		
	Bas	ic info	rma-												
		tion	ı					1	ı		1	1	ı	1	
Purpose of use	NJ-series CPU Unit Hardware User's Manual	NJ-series CPU Unit Software User's Manual	NJ-series Instructions Reference Manual	NJ-series CPU Unit Motion Control User's Manual	NJ-series CPU Unit Built-in EtherCAT Port User's Manual	NJ-series Motion Control Instructions Reference Manual	NJ-series CPU Unit Built-in EtherNet/IP Port User's Manual	NJ-series Database Connection CPU Unit User's Manual	NJ-series Troubleshooting Manual	NX-series EtherCAT Coupler Unit User's Manual	NX-series NX Units User's Manuals	NX-series Safety Control Unit User's Manual	NX-series Safety Control Unit Instructions Reference Manual	NX-series Data Reference Manual	CJ-series Special Unit Operation Manuals for NJ-series CPU Unit
Testing operation and debugging															
Using motion control				•							•				
Using EtherCAT					•										
Using EtherNet/IP		•					•								
Using the database connection service								•							
Using the NX Series										•	•				
Performing safety controls												•			
Learning about error management and corrections*1	•	A		A	A		A	A	•	•	A				A
Maintenance															
Using motion control				•							•				
Using EtherCAT					•										
Using EtherNet/IP	•						•								
Using the NX Series										•	•				
Performing safety controls												•			
Using CJ-series Units															•

^{*1} Refer to the *NJ-series Troubleshooting Manual* (Cat. No. W503) for the error management concepts and an overview of the error items. Refer to the manuals that are indicated with triangles for details on errors for the corresponding Units.

Manual Structure

Page Structure

The following page structure is used in this manual.



This illustration is provided only as a sample. It may not literally appear in this manual.

Special Information

Special information in this manual is classified as follows:



Precautions for Safe Use

Precautions on what to do and what not to do to ensure safe usage of the product.



Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.



Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.

Note References are provided to more detailed or related information.

Precaution on Terminology

In this manual, "download" refers to transferring data from the Sysmac Studio to the physical Controller and "upload" refers to transferring data from the physical Controller to the Sysmac Studio.

For the Sysmac Studio, synchronization is used to both upload and download data. Here, "synchronize" means to automatically compare the data for the Sysmac Studio on the computer with the data in the physical Controller and transfer the data in the direction that is specified by the user.

Manual Structure

Sections in this Manual

					1 A		
1	Introduction	Α	Appendices		2 I		
2	Part Names and	П	Index		3		
	Slave Settings			_///	4		
3	3 EtherCAT Communications						
4	EtherCAT Network Wiring 6						
5	Setting Up EtherCAT Communications with the Sysmac Studio						
6	Process Data Communications 8						
7	System-defined Variables That Are Related 9						
	to the Built-in EtherCAT Port						
8	Example of Operations	for E	therCAT Communication	ons /			
9	9 Troubleshooting						

Sections in this Manual

CONTENTS

	Intro	duction	1				
	Rele	vant Manuals	2				
	ual Structure	4					
	Sect	ions in this Manual	7				
	Tern	ns and Conditions Agreement	13				
	Safe	ty Precautions	15				
		eautions for Safe Use					
	Precautions for Correct Use						
		ulations and Standards					
	_	Versions					
		ted Manuals					
	Kevi	sion History	25				
Sectio	n 1	Introduction					
	1-1	Introduction to EtherCAT	1-2				
		1-1-1 EtherCAT Features	1-2				
	1-2	System Configuration and Configuration Devices 1-2-1 System Configuration	1-4				
	1-3	Specifications of Built-in EtherCAT Port 1-3-1 Performance Specifications	1-8				
	1-4	EtherCAT Communications Procedure	. 1-10				
Sectio	n 2	Part Names and Slave Settings					
		Part Names and Functions 2-1-1 EtherCAT Master Indicators 2-1-2 Windows Used in Sysmac Studio 2-1-3 Connecting the Sysmac Studio.	2-2 2-3				
		Setting the Node Addresses of the EtherCAT Slaves					
		Features of Sysmac Devices 2-3-1 Sysmac Devices 2-3-2 Sysmac Device Features 2-3-3 List of Sysmac Devices 2-3-4 Sysmac Device Features and EtherCAT Masters	. 2-10 . 2-10 . 2-13				

	3-1	EtherCAT Communi	ications Types and Settings	3-2
			oplication Protocol over EtherCAT)	
			nmunications	
			erCAT Variables	
			uired for EtherCAT Communications	
	3-2	Programming Ether	CAT Communications	3-7
	3-3	State Transitions fo	r EtherCAT Communications	3-8
			is at Startup	
			s for EtherCAT Communications	
		3-3-3 CPU UNII Sta	ilus in Relation to EtherCAL	3-10
Section	n 4	EtherCA7	Γ Network Wiring	
	4-1	Laving the EtherCA	T Network	4-2
	,	4-1-1 Supported Ne	etwork Topologies	4-2
			recautions	
			erCAT Communications Cables	
		9	Communications Cables	
		Studio		
	5-1		k Configuration Information	
	5-2		CAT Network Configuration	
	5-3		lave Variables and Axes	
			Device Variables for All EtherCAT Slaves	
	5-4	_	nd Slave Parameter Settings	
	•		CAT Master	
			CAT Slaves	
	5-5	Comparing and Mer	ging EtherCAT Network Configurations	5-26
		5-5-1 Comparing a	nd Merging with the Actual Network Configuration from the Sysmac Studio	5-26
			Creating the Network Configuration	
			smac Studio to Obtain Serial Numbers from the Actual Network Configuration	1 5-32
		9 ,	•	
	5-6	Downloading the Ne	etwork Configuration Information	5-34
		Downloading the No. 5-6-1 Downloading	the Network Configuration Information from the Sysmac Studio	5-34
	5-6 5-7	Downloading the Ne 5-6-1 Downloading Confirming Commu		5-34 5-34
		Downloading the Ne 5-6-1 Downloading Confirming Commu	the Network Configuration Information from the Sysmac Studio Inications after Completing EtherCAT Configuration	5-34 5-34
Sectio	5-7	Downloading the Ne 5-6-1 Downloading Confirming Commu and Settings	the Network Configuration Information from the Sysmac Studio Inications after Completing EtherCAT Configuration Data Communications and SDO	5-34 5-34
Sectio	5-7 on 6	Downloading the Ne 5-6-1 Downloading Confirming Commu and Settings	the Network Configuration Information from the Sysmac Studio Inications after Completing EtherCAT Configuration Data Communications and SDO ications	5-34 5-34
Sectio	5-7	Downloading the Ne 5-6-1 Downloading Confirming Communand Settings	the Network Configuration Information from the Sysmac Studio Inications after Completing EtherCAT Configuration Data Communications and SDO ications munications (PDO Communications)	5-34 5-36
Sectio	5-7 on 6	Downloading the Ne 5-6-1 Downloading Confirming Communand Settings	the Network Configuration Information from the Sysmac Studio Inications after Completing EtherCAT Configuration Data Communications and SDO ications	5-34 5-36 6-2
Sectio	5-7 on 6	Downloading the Ne 5-6-1 Downloading Confirming Communand Settings	the Network Configuration Information from the Sysmac Studio Inications after Completing EtherCAT Configuration Data Communications and SDO ications munications (PDO Communications)	5-34 5-36 6-2 6-4

with Specified Values6-10

6-2	SDO Communications	6-13
	6-2-1 EtherCAT Instructions	6-13
	6-2-2 Sample Programming	
	6-2-3 Execution Timing of SDO Communications	
	6-2-4 Minimum Message Response Time for SDO Communications	6-15
6-3	Instructions Used in EtherCAT Communications	
	6-3-1 EtherCAT Instructions	6-17
Section 7	System-defined Variables That Are Related to the E in EtherCAT Port	Built-
7-1	System-defined Variables That Are Related to the Built-in EtherCAT Port	7-2
	7-1-1 What Are System-defined Variables?	
	7-1-2 System-defined Variables	
	7-1-3 EtherCAT Master Function Module, Category Name: _EC	7-6
Section 8	Example of Operations for EtherCAT Communication	ons
 8-1	Example of Operations for EtherCAT Communications	8-2
•	8-1-1 System Configuration Example	
	8-1-2 Wiring and Settings	
	8-1-3 Setting the EtherCAT Network Configuration	8-3
	8-1-4 Programming	
	8-1-5 Offline Debugging	
	8-1-6 Turning the Power ON	
	8-1-7 Online Debugging	
	8-1-8 Downloading the Network Configuration Information and the User Program	
Section 9	Troubleshooting	
9-1	Overview of Errors	9-2
	9-1-1 How to Check for Errors	
	9-1-2 Errors Related to the EtherCAT Master Function Module	9-6
9-2	Troubleshooting	9-9
	9-2-1 Error Table	
	9-2-2 Error Descriptions	9-14
	9-2-3 Resetting Errors	
	9-2-4 Diagnostic and Statistical Information	
9-3	Precautions When Connecting or Disconnecting Slaves during Communications	
	 9-3-1 Procedure for Connecting and Disconnecting Slaves during Communications 9-3-2 Prohibition to Physically Disconnecting a Slave and Resetting an Error or Connecting a Slave at the Same Time 	
9-4	Replacing Slaves during Communications	
	9-4-1 Introduction	
	9-4-2 Slave Replacement Methods	
	9-4-3 Backing Up Settings	
	9-4-4 Restoring Settings	
	9-4-5 Replacement Procedure	9-48

Appendices

A-1	Ether(CAT Status in Relation to CPU Unit Status	A-2
	A-1-1	Startup	A-2
	A-1-2	CPU Unit Operating Modes	A-3
	A-1-3	Controller Errors Other Than Errors in the Built-in EtherCAT Master	A-4
	A-1-4	Others	A-5
A-2	Monite	oring Packets	A-7
		Sample Programming	
A-3	Multi-	vendor Environments	A-15
	A-3-1	EtherCAT Slave Information File (ESI Files)	
	A-3-2	Connecting Slaves from Other Manufacturers to an OMRON Master	
	A-3-3	Installing ESI Files	A-16
	A-3-4	Editing PDO Entry Tables	A-22
A-4	Gloss	ary	A-25
Δ-5	Versio	on Information	Δ-27

Index

Terms and Conditions Agreement

Read and understand this Manual

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranty, Limitations of Liability

Warranties

Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Disclaimers

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Safety Precautions

Refer to the following manuals for safety precautions.

- NJ-series CPU Unit Hardware User's Manual (Cat No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

Precautions for Safe Use

Refer to the following manuals for precautions for safe use.

- NJ-series CPU Unit Hardware User's Manual (Cat No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

Precautions for Correct Use

Refer to the following manuals for precautions for correct use.

- NJ-series CPU Unit Hardware User's Manual (Cat No. W500)
- NJ-series CPU Unit Software User's Manual (Cat. No. W501)

Regulations and Standards

Conformance to EC Directives

Applicable Directives

- EMC Directives
- · Low Voltage Directive

Concepts

EMC Directive

OMRON devices that comply with EC Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards.*

Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer. EMC-related performance of the OMRON devices that comply with EC Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

* Applicable EMC (Electromagnetic Compatibility) standards are as follows: EMS (Electromagnetic Susceptibility): EN 61131-2 and EN 61000-6-2 EMI (Electromagnetic Interference): EN 61131-2 and EN 61000-6-4 (Radiated emission: 10-m regulations)

Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 VAC and 75 to 1,500 VDC meet the required safety standards. The applicable directive is EN 61131-2.

Conformance to EC Directives

The NJ-series Controllers comply with EC Directives. To ensure that the machine or device in which the NJ-series Controller is used complies with EC Directives, the Controller must be installed as follows:

- The NJ-series Controller must be installed within a control panel.
- You must use reinforced insulation or double insulation for the DC power supplies connected to DC Power Supply Units and I/O Units.
- NJ-series Controllers that comply with EC Directives also conform to the Common Emission Standard (EN 61000-6-4). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions.

You must therefore confirm that the overall machine or equipment complies with EC Directives.

Conformance to KC Standards

Observe the following precaution if you use NX-series Units in Korea.

A급기기(업무용 방송통신기자재) 이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Class A Device (Broadcasting Communications Device for Office Use)

This device obtained EMC registration for office use (Class A), and it is intended to be used in places other than homes.

Sellers and/or users need to take note of this.

Conformance to Shipbuilding Standards

The NJ-series Controllers comply with the following shipbuilding standards. Applicability to the ship-building standards is based on certain usage conditions. It may not be possible to use the product in some locations. Contact your OMRON representative before attempting to use a Controller on a ship.

Usage Conditions for NK and LR Shipbuilding Standards

- The NJ-series Controller must be installed within a control panel.
- Gaps in the door to the control panel must be completely filled or covered with gaskets or other material.
- The following noise filter must be connected to the power supply line.

Noise Filter

Manufacturer	Model			
Cosel Co., Ltd.	TAH-06-683			

Software Licenses and Copyrights

This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj_info_e/.

Unit Versions


Unit Versions

A "unit version" has been introduced to manage CPU Units in the NJ Series according to differences in functionality accompanying Unit upgrades.

Notation of Unit Versions on Products

The unit version is given on the ID information label of the products for which unit versions are managed, as shown below.

Example for NJ-series NJ501-



Lot number and serial number MAC address

The following information is provided on the ID information label.

Item	Description				
Unit model	Gives the model of the Unit.				
Unit version	n Gives the unit version of the Unit.				
Lot number and	Gives the lot number and serial number of the Unit.				
serial number	DDMYY: Lot number, □: For use by OMRON, xxxx: Serial number				
	"M" gives the month (1 to 9: January to September, X: October, Y: November, Z: December)				
MAC address	Gives the MAC address of the built-in port on the Unit.				

Confirming Unit Versions with Sysmac Studio

You can use the Unit Production Information on the Sysmac Studio to check the unit version of the CPU Unit, CJ-series Special I/O Units, CJ-series CPU Bus Units, and EtherCAT slaves. The unit versions of CJ-series Basic I/O Units cannot be checked from the Sysmac Studio.


CPU Unit and CJ-series Units

1 Double-click CPU/Expansion Racks under Configurations and Setup in the Multiview Explorer. Or, right-click CPU/Expansion Racks under Configurations and Setup and select *Edit* from the menu.

The Unit Editor is displayed for the Controller Configurations and Setup layer.

2 Right-click any open space in the Unit Editor and select **Production Information**.

The Production Information Dialog Box is displayed.





Simple Display

Detailed Display

In this example, "Ver.1.00" is displayed next to the unit model.

The following items are displayed.

CPU Unit	CJ-series Units
Unit model	Unit model
Unit version	Unit version
Lot number	Lot number
	Rack number, slot number, and unit number


EtherCAT Slaves

1 Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit* from the menu.

The EtherCAT Configuration Tab Page is displayed for the Controller Configurations and Setup layer.

2 Right-click the master in the EtherCAT Configurations Editing Pane and select Display Production Information.

The Production Information Dialog Box is displayed.



The following items are displayed.

Node address

Type information*

Serial number

* If the model number cannot be determined (such as when there is no ESI file), the vendor ID, product code, and revision number are displayed.



Additional Information

Refer to the manual for the specific Unit for the unit versions of the CPU Units, Communications Coupler Units, NX Units, and Safety Control Units to which the database connection service and other functions were added.

Unit Version Notation

In this manual, unit versions are specified as shown in the following table.

Product nameplate Notation in this manual		Remarks			
"Ver.1.0" or later to the right of the lot number	Unit version 1.0 or later	Unless unit versions are specified, the information in this manual applies to all unit versions.			

Related Manuals


The following manuals are related to the NJ-series Controllers. Use these manuals for reference.

Manual name	Cat. No.	Model numbers	Application	Description
NJ-series CPU Unit Hardware User's Manual	W500	NJ501-□□□□ NJ301-□□□□	Learning the basic specifications of the NJ-series CPU Units, including introductory information, designing, installation, and maintenance. Mainly hardware information is provided.	An introduction to the entire NJ-series system is provided along with the following information on a Controller built with a CPU Unit. • Features and system configuration • Introduction • Part names and functions • General specifications • Installation and wiring • Maintenance and inspection Use this manual together with the NJ-series CPU Unit Software User's Manual (Cat. No. W501).
NJ-series CPU Unit Soft- ware User's Manual	W501	NJ501-□□□□ NJ301-□□□□	Learning how to program and set up an NJ-series CPU Unit. Mainly software information is provided.	The following information is provided on a Controller built with an NJ501 CPU Unit. CPU Unit operation CPU Unit features Initial settings Programming based on IEC 61131-3 language specifications Use this manual together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500).
NJ-series CPU Unit Motion Control User's Manual	W507	NJ501-□□□□ NJ301-□□□□	Learning about motion control settings and programming concepts.	The settings and operation of the CPU Unit and programming concepts for motion control are described. Use this manual together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) and NJ-series CPU Unit Software User's Manual (Cat. No. W501).
NJ-series Instructions Reference Manual	W502	NJ501-□□□□ NJ301-□□□□	Learning detailed specifi- cations on the basic instructions of an NJ-series CPU Unit.	The instructions in the instruction set (IEC 61131-3 specifications) are described. When programming, use this manual together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) and NJ-series CPU Unit Software User's Manual (Cat. No. W501).
NJ-series Motion Control Instructions Reference Manual	W508	NJ501-□□□□ NJ301-□□□□	Learning about the specifi- cations of the motion con- trol instructions that are provided by OMRON.	The motion control instructions are described. When programming, use this manual together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500), NJ-series CPU Unit Software User's Manual (Cat. No. W501) and NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507).
NJ-series CPU Unit Built- in EtherCAT® Port User's Manual	W505	NJ501-□□□□ NJ301-□□□□	Using the built-in EtherCAT port on an NJ-series CPU Unit.	Information on the built-in EtherCAT port is provided. This manual provides an introduction and provides information on the configuration, features, and setup. Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).
NJ-series CPU Unit Built- in EtherNet/IP TM Port User's Manual	W506	NJ501-□□□□ NJ301-□□□□	Using the built-in Ether- Net/IP port on an NJ-series CPU Unit.	Information on the built-in EtherNet/IP port is provided. Information is provided on the basic setup, tag data links, and other features. Use this manual together with the <i>NJ-series CPU Unit Hardware User's Manual</i> (Cat. No. W500) and <i>NJ-series CPU Unit Software User's Manual</i> (Cat. No. W501).

Manual name	Cat. No.	Model numbers	Application	Description
NJ-series Troubleshoot- ing Manual	W503	NJ501-□□□□ NJ301-□□□□	Learning about the errors that may be detected in an NJ-series Controller.	Concepts on managing errors that may be detected in an NJ-series Controller and information on individual errors are described. Use this manual together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) and NJ-series CPU Unit Software User's Manual (Cat. No. W501).
NJ-series Database Con- nection CPU Units User's Manual	W527	NJ501-1□20	Using the database con- nection service with NJ- series Controllers	Describes the database connection service.
NX-series Communica- tions Coupler Unit User's Manual	W519	NX-ECC	Leaning how to use an NX- series Communications Coupler Unit and Slave Terminals	Introduces the system, configuration methods, Unit hardware, setting methods, and functions of Slave Terminals that consist of a Communications Coupler Unit and NX Units. A manual is available for the following Unit. EtherCAT Coupler Unit
NX-series NX Units User's Manuals	W521 W522 W523 W524 W525	NX-ID	Learning how to use NX Units	Describe the hardware, setup methods, and functions of the NX Units. Manuals are available for the following Units. Digital I/O Units, Analog I/O Units, System Units, and Position Interface Units
NX-series Safety Control Unit User's Manual	W930	NX-SL	Learning how to use NX- series Safety Control Units	Describes the hardware, setup methods, and functions of the NX-series Safety Control Units.
NX-series Safety Control Unit Command Refer- ence Manual	Z931	NX-SL	Learning about the specifications of instructions for the Safety CPU Unit.	Describes the instructions for the Safety CPU Unit. When programming, use this manual together with the NX-series Safety Control Unit User's Manual (Cat. No. Z930).
CJ-series Special Unit Manuals for NJ-series CPU Unit	W490 W498 W491 Z317 W492 W494 W497 W495 W493	CJ1W-DDD	Learning how to use CJ- series Units with an NJ- series CPU Unit.	The methods and precautions for using CJseries Units with an NJ501 CPU Unit are described, including access methods and programming interfaces. Manuals are available for the following Units. Analog I/O Units, Insulated-type Analog I/O Units, Temperature Control Units, ID Sensor Units, High-speed Counter Units, Serial Communications Units, DeviceNet Units EtherNet/IP Units, and CompoNet Master Units. Use these manuals together with the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) and NJ-series CPU Unit Software User's Manual (Cat. No. W501).
Sysmac Studio Version 1 Operation Manual	W504	SYSMAC- SE2□□□	Learning about the operat- ing procedures and func- tions of the Sysmac Studio.	Describes the operating procedures of the Sysmac Studio.
CX-Integrator CS/CJ/CP/NSJ/NJ-series Network Configuration Tool Operation Manual	W464		Learning how to configure networks (data links, rout- ing tables, Communica- tions Unit settings, etc.).	Describes operating procedures for the CX-Integrator.
CX-Designer User's Manual	V099		Learning to create screen data for NS-series Programmable Terminals.	Describes operating procedures for the CX-Designer.
CX-Protocol Operation Manual	W344		Creating data transfer pro- tocols for general-purpose devices connected to CJ- series Serial Communica- tions Units.	Describes operating procedures for the CX-Protocol.

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content
01	July 2011	Original production
02	March 2012	Added information on the NJ301-□□□ and corrected mistakes.
03	May 2012	Added information on functional support for unit version 1.02 and later of the CPU Units.
		Corrected mistakes.
04	August 2012	Added information on functional support for unit version 1.03 and later of the CPU Units.
		Corrected mistakes.
05	February 2013	Added information on functional support for unit version 1.04 and later of the CPU Units.
		Corrected mistakes.
06	April 2013	Added information on functional support for unit version 1.05 and later of the CPU Units.
		Corrected mistakes.
07	June 2013	Added information on functional support for unit version 1.06 and later of the CPU Units.
		Corrected mistakes.
08	September 2013	Added information on functional support for unit version 1.07 and later of the CPU Units.
		Corrected mistakes.

Revision History



Introduction

This section provides an overview of EtherCAT communications, describes the system configuration and specifications, and provides operating procedures.

1-1	Introd	uction to EtherCAT	. 1-2
	1-1-1	EtherCAT Features	. 1-2
	1-1-2	EtherCAT Communications	. 1-2
	1-1-3	EtherCAT Features for NJ-series CPU Units	. 1-3
1-2	Syste	m Configuration and Configuration Devices	. 1-4
	1-2-1	System Configuration	. 1-4
	1-2-2	Determining the Network Configuration	. 1-7
1-3	Specif	ications of Built-in EtherCAT Port	. 1-8
	1-3-1	Performance Specifications	. 1-8
1-4	Ether(CAT Communications Procedure	1-10
	1-4-1	Overview	1-10
	1-4-2	Details	1-11

1-1 Introduction to EtherCAT

EtherCAT (Ethernet Control Automation Technology) is a high-performance industrial network system that enables faster and more efficient communications based on Ethernet. Each node achieves a short communications cycle time by transmitting Ethernet frames at high speed. Furthermore, even though EtherCAT is a unique protocol, it offers excellent general-purpose applicability. For example, you can use Ethernet cables because EtherCAT utilizes standard Ethernet technology for the physical layer. And the effectiveness of EtherCAT can be fully utilized not only in large control systems that require high processing speeds and system integrity, but also in small and medium control systems.

1-1-1 EtherCAT Features

EtherCAT provides the following features.

High-speed Communications at 100 Mbps

The I/O response time from signal input to signal output has been significantly reduced. By fully utilizing the optimized Ethernet frame bandwidth to transmit data using a high-speed repeat method, it is possible to efficiently transmit a wide variety of data.

Extremely High Compatibility with Ethernet

EtherCAT is an open network with extremely high compatibility with conventional Ethernet systems.


1-1-2 EtherCAT Communications

EtherCAT does not send data to individual slave nodes on the network, instead, it passes Ethernet frames through all of the slave nodes.

When frame passes through a slave node, the slave node reads and writes data in the areas allocated to it in the frames in a few nanoseconds.

The Ethernet frames transmitted by the EtherCAT master pass through all EtherCAT slaves without stopping. The last slave returns all of the frames, which again pass through all of the slaves before returning to the EtherCAT master.

This mechanism ensures high speed and realtime data transmission.



1-1-3 EtherCAT Features for NJ-series CPU Units

EtherCAT in the NJ-series CPU Units has the following features.

Synchronization of the CPU Unit Processing Period and the EtherCAT Communications Cycle

The period of sequence processing and motion processing in the CPU Unit matches the process data communications cycle of EtherCAT.

This enables high-precision sequence control and motion control with a stable fixed period.

Accessing Data with Device Variables without Considering Addresses

EtherCAT slaves are accessed using device variables in the same way as the Units on the NJ-series CPU Racks and Expansion Racks. Various types of data in Servo Drive and the encoder input slaves are accessed using structure-type Axis Variables prepared in advance.

This enables access to slaves on EtherCAT without regard to addresses.

Optimum Functionality and Ease of Operation Based on Unified Specifications


You can use the NJ-series Machine Automation Controllers together with Sysmac devices* and the Sysmac Studio Automation Software to achieve optimum functionality and ease of operation.

* Sysmac devices is a generic name for EtherCAT slaves and other OMRON control components that were designed with the same communications and user interface specifications.

1-2 **System Configuration and Configuration Devices**

System Configuration 1-2-1

The EtherCAT network configuration and configuration devices are shown below.



Outlines of the configuration devices are given below.

EtherCAT Master

The EtherCAT master manages the network, monitors the status of slaves, and exchanges I/O data with slaves. There is one output port.

Output Port

The output port transmits EtherCAT communications data to other devices. When you connect the output port to another device, always connect it to the input port on the other device. Normal communications will not be possible if you connect to the output port on another device.

Input Port

This port is used to input EtherCAT communications data. Always connect it to the output port on another device. Normal communications will not be possible if you connect to the input port on another device.

EtherCAT Slaves

Each EtherCAT slave outputs the output data that it received from the EtherCAT master through the EtherCAT network. It also sends input data to the EtherCAT master through the EtherCAT network. In the EtherCAT network, you can use a total of 192 slaves nodes. These can include the slaves that are listed below. The slaves are synchronized even when multiple non-synced slaves and Junction Slaves are connected. Slaves have one input port and at least one output port. Assign node addresses 1 to 192 to the slaves. You can assign any address within the node address setting range (1 to 192) regardless of the type of slave. However, each node address can be used for only one slave. There are also Junction Slaves for which more than one node address is set.

Non-synced Slaves

These slaves perform sequence control. Synchronization is not required between them. They include digital slaves, analog slaves, etc. Each non-synced slave has one input port and one output port.

Synced Slaves

The operation of these slaves is synchronized with a distributed clock (DC). They include Servo Drive and encoder input slaves. Each synced slave has one input port and one output port.

The following tables lists some of the OMRON EtherCAT slaves that are available.

Name	Туре	Model	Synced/Non- synced Slaves	Assigning an axis
Digital I/O Slaves	Slaves with screw terminals and 2-tier terminal block	GX-□D16□1/OC1601	Non-synced Slaves	Not possible
	Slaves with screw terminals and 3-tier terminal block	GX-ID16□2/OD16□2/MD16□2	Non-synced Slaves	Not possible
	Slaves with e-CON connectors	GX-□D16□8/□D32□8	Non-synced Slaves	Not possible
Analog I/O Slaves	Slaves with screw terminals and 2-tier terminal block	GX-AD0471/DA0271	Non-synced Slaves	Not possible
NX-series EtherCAT Coupler Unit*	NX Series	NX-ECC201	Synced Slaves	Not possible (Some of the connected NX Units can be assigned to an axis.)
Multifunctional, Compact Inverters	MX2 Series	3G3MX2 with EtherCAT Communications Unit 3G3AX-MX2-ECT	Non-synced Slaves	Not possible
Advanced General- purpose Inverters	RX Series	3G3RX-V1 with EtherCAT Communications Unit 3G3AX-RX-ECT	Non-synced Slaves	Not possible
AC Servo Drive	G5-series Servo Drive with EtherCAT communications	R88M-K/R88D-KN□-ECT	Synced Slaves	Possible
Linear Servo Drives	G5-series Linear Servo Drives with EtherCAT communications	R88L-EC/R88D-KN□-ECT-L	Synced Slaves	Possible
Encoder Input Slaves	Slave with 3-tier terminal block	GX-EC0211/EC0241	Synced Slaves	Possible

Name	Туре	Model	Synced/Non- synced Slaves	Assigning an axis
Specialized Vision Sensors for Position-	FQ-M-series Sensors with EtherCAT Communications	FQ-MS12□(-□)-ECT	Synced Slaves	Not possible
ing	FZM1-series Vision Sensors	FZM1-35□-ECT	Synced Slaves	Not possible
Digital Sensor Com- munications Unit	E3NW Series	E3NW-ECT	Non-synced Slaves	Not possible
Fiber Sensor Com- munications Unit	E3X Series	E3X-ECT	Non-synced Slaves	Not possible
Confocal Fiber Type Displacement Sen- sors	ZW Series	ZW-CE1□	Non-synced Slaves	Not possible

An NJ-series CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required.

EtherCAT Junction Slave

This is a special unit for branching EtherCAT network wiring. Cascade connections are possible within the range of node addresses that the EtherCAT master can handle. Set the node address in the EtherCAT Junction Slave.

Each Junction Slave has one input port and more than one output port. The output ports on each Junction Slave can be connected to another Junction Slave or other EtherCAT slaves.

The following models are examples of some of the OMRON EtherCAT slaves.

Slave type/name	Number of ports	Model
EtherCAT Junction Slave	3 ports	GX-JC03
	6 ports	GX-JC06*

^{*} Two node addresses are set for the GX-JC06.

Sysmac Studio

The Sysmac Studio runs on a personal computer and it is used to configure EtherCAT networks and slaves, and to program, monitor, and debug the Controller.

Communications Cables

Use a shielded twisted-pair cable (double shielding with aluminum tape and braiding) of Ethernet category 5 (100Base-TX) or higher, and use straight wiring.

ESI (EtherCAT Slave Information) File

The ESI files contain information unique to the EtherCAT slaves in XML format. You can load an ESI file into the Sysmac Studio, to easily allocate slave process data and make other settings.

Unit Power Supplies

This power supply is for slave communications and internal operation.

I/O Power Supply

This power supply is for slave communications and internal operation.




Additional Information

With a CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher, you can add NX-series Safety Control Units to the EtherCAT network.

You can use NX-series Safety Control Units and NX-series Safety I/O Units on EtherCAT Slave Terminals to build a safety control system on EtherCAT.

1-2-2 **Determining the Network Configuration**

Determine the type, total number, and positions of slaves in the network. Check the total number of slaves and the cable length between slaves based on the following workflow.



Precautions for Safe Use

- You cannot use standard Ethernet hubs or repeater hubs with EtherCAT communications. If you use one of these, a major fault level error or other error may occur.
- Make sure that the communications distance, number of devices connected, and method of connection for EtherCAT are within specifications.

Specifications of Built-in EtherCAT 1-3 **Port**

Performance Specifications 1-3-1

Item	Specification	
Communications protocol	EtherCAT protocol	
Supported services	CoE (Process data communications and SDO communications)*1	
Synchronization	DC (Distributed Clock)	
Physical layer	100BASE-TX	
Modulation	Baseband	
Baud rate	100 Mbit/s (100Base-TX)	
Duplex mode*2	Auto	
Topology*3	Line, daisy chain, and branching	
Transmission media	Category 5 twisted-pair cable or higher (Cable with double, aluminum tape and braided shielding, and straight wiring, are recommended.)	
Maximum transmission distance between nodes	100 m	
Transmission distance	Distance between nodes: 100 m or less (IEEE 802.3)	
Maximum number of slaves	192	
Maximum process data size	Input: 5,736 bytes Output: 5,736 bytes However, the data must not exceed 4 frames (the maximum number of pro-	
	cess data frames).	
Maximum data sizes per slave	Input: 1,434 bytes	
Maximum data 312e3 per 31ave	Output: 1,434 bytes	
Maximum message size	2,048 bytes	
Communications cycle 500 μs, 1,000 μs, 2,000 μs, or 4,000 μs *4		
Minimum communications cycle	500 μs	
Maximum communications cycle	4,000 μs	
Sync jitter	1 μs max.	

^{*1} Refer to 3-1-1 CoE (CAN Application Protocol over EtherCAT) for details on CoE.

^{*2} Connection is possible only in full duplex mode. Half-duplex connections will result in link OFF status.

^{*3} Wiring in a ring configuration is not possible.

^{*4} The communications cycle for an NJ301- $\square\square\square$ CPU Unit is 1,000, 2,000, or 4,000 μ s.

List of Supported Functions

Function name	Description		
	PDO mapping using CoE		
Process data communica-	Fail-soft operation for slave communications errors		
	Stop operation for slave communications errors		
DC (distributed clock)	Clock synchronization		
	CoE		
SDO communications	Emergency message server (receptions from slaves)		
obo communications	SDO requests and responses		
	Communications between slaves		
	Automatic setting of device variable names, etc.		
	Setting node address using hardware switches on the slaves		
Configuration	Setting node address using the Sysmac Studio		
	Network scan (collection of information on devices connected to the network)		
	Display of network configuration information (display of supported topology)		
	Slave configuration check when starting network		
RAS functions	Reading of error information (emergency error history, subscription information, etc.)		
	Packet monitoring*		
	Troubleshooting information		
Operations during arrers	When error occurs (stop communications or change to fail-soft operation)		
Operations during errors	Restoring communications when errors are cleared (Moves to operational state.)		
	Number of slaves: 192		
Slave information	Enabling/disabling slaves		
	Disconnecting/reconnecting slaves		

^{*} The NJ301- CPU Units do not support packet monitoring.

1-4 EtherCAT Communications **Procedure**

1-4-1 **Overview**

Step	Section
Mounting and Setting Devices and Hardware	2-2 Setting the Node Addresses of the EtherCAT Slaves
→	
2. Laying EtherCAT Communications Cables	Section 4 EtherCAT Network Wiring
→	
3. Creating the EtherCAT Network Configuration	5-2 Creating the EtherCAT Network Configuration
→	
4. Setting EtherCAT Slave Variables and Axes	5-3 Setting EtherCAT Slave Variables and Axes
\downarrow	
5. Setting EtherCAT Parameters	5-4 EtherCAT Master and Slave Parameter Settings
↓	
6. Programming	Section 6 Process Data Communications and SDO Communications
→	
7. Turning ON Power and Going Online from the Sysmac Studio	2-1-3 Connecting the Sysmac Studio
	3-3 State Transitions for EtherCAT Com- munications
↓	
8. Online Debugging	5-5 Comparing and Merging EtherCAT Network Configurations
→	
9. Downloading the Network Configuration Information and the User Program	5-6 Downloading the Network Configuration Information
<u>↓</u>	
10. Checking Indicators	5-7 Confirming Communications after Completing EtherCAT Configuration and Settings

1-4-2 Details

Step		Description	Sysmac Studio operation	Section
	Mounting and Setting Devices d Hardware	Use the hardware switches on all of the EtherCAT slaves in the network to set the node addresses. (The starting node address and sequence are not specified.) See the manuals for each slave for information on the procedure for setting node addresses.		2-2 Setting the Node Addresses of the EtherCAT Slaves
		Note Use the Sysmac Studio to set the node address if there are no hardware switches or the node address is beyond the range that can be set with the hardware switches.		
		Connect the EtherCAT slaves and exter- nal I/O devices.		
<u> </u>				
	Laying EtherCAT Communi- ions Cables	Connect the EtherCAT slaves to the Ether-CAT port of the NJ-series CPU Unit. If there is more than one EtherCAT slave, connect them using a daisy chain or branch wiring.		Section 4 EtherCAT Net- work Wiring
\downarrow				
	Creating the EtherCAT Net- rk Configuration	Use the Sysmac Studio to create a new project. (a) Create EtherCAT network configuration offline. or (b) Go online and create the EtherCAT	Create EtherCAT network configuration with EtherCAT under Configurations and Setup.	5-2 Creating the EtherCAT Net- work Configura- tion
		network configuration from the actual network devices. Do so after making the online connection that is described in step 7.		
<u></u>				
4	Setting EtherCAT Slave Variables and Axes			
	All EtherCAT Slaves	Allocate variables to the I/O ports. If necessary, change the names of automatically generated device variables for each I/O port to user-defined variable names.	Make the settings with I/O Map under Configurations and Setup.	5-3-1 Register- ing Device Vari- ables for All EtherCAT Slaves
	Only EtherCAT Servo Drive and encoder input slaves Set up the axes. Create axes (axes variables). Set the axis types for the Axis Variables (to a servo axis, virtual axis, etc.), and set the IDs of the Servo Drives. Axis Variables are automatically registered in the global variable table		Create and set up the axes with the Add – Axis Settings command for Configurations and Setup – Motion Control Setup – Axis Settings.	5-3-2 Axis Set- tings for Servo Drives and Encoder Input Slaves

Step		Description	Sysmac Studio operation	Section
5	Setting EtherCAT Parameters			
Setting EtherCAT Master Parameters		Set the EtherCAT master parameters. (Examples: process data communications cycle and wait all slaves startup time) The values that are set are reflected in the network configuration information.	Create an EtherCAT master with EtherCAT under Configurations and Setup.	5-4-1 Setting EtherCAT Mas- ter
	Setting EtherCAT Slave Parameters	Set the EtherCAT slave parameters. Example: Enable/disable slaves.	Create EtherCAT slaves with EtherCAT under Configurations and Setup.	5-4-2 Setting EtherCAT Slaves
↓	D	T		T
6	Programming Process Data Communications	Specify the device variables in the user program. Input conditions include system-defined variables for network error flags and normal or error flags for each slave.	Create the programs with POUs under Programming.	6-1 Process Data Communications (PDO Communications)
	SDO Communications	Read and write the following specified data for slaves: Use EC_CoESDORead and EC_CoESDOWrite instructions. • SDO data in slaves (parameters, error information, etc.)	Create the programs with POUs under Programming.	6-2 SDO Communications
\downarrow				
7. Turning ON Power and Going Online from the Sysmac Studio		slaves. 2. Turn ON the I/O power supplies to the slaves. 3. Turn ON the power supply to NJ-series Controller. 4. Use the Sysmac Studio to set communications with the NJ-series Controller and connect online.		2-1-3 Connecting the Sysmac Studio 3-3 State Transitions for EtherCAT Communications
		Go online with the Controller before you create the slave configuration from the installed network in step 3.		
\downarrow		<u> </u>		
8. Online Debugging		Compare and merge the network configuration that was set on the Sysmac Studio and the actual network configuration.		5-5 Comparing and Merging EtherCAT Net- work Configura- tions

1-12

Step	Description	Sysmac Studio operation	Section
9. Downloading the Network Configuration Information and the User Program	Download the network configuration information (EtherCAT configuration, process data information, and parameters). Note Use the synchronization operation of the Sysmac Studio to download the project.	Select Synchroniza- tion from the Controller Menu to download and verify the network configuration information.	5-6 Download- ing the Network Configuration Information
_			
10. Checking Indicators	Check the indicators on the NJ-series CPU Unit. A flashing yellow EtherCAT LINK/ACT indicator shows that data is being transmitted and received after the link is established. A solid green EtherCAT NET RUN indicator shows the device is in the operational state (normal communications state). If the EtherCAT NET ERR indicator is not lit, there is no error.		5-7 Confirming Communica- tions after Com- pleting EtherCAT Con- figuration and Settings




Part Names and Slave Settings

This section provides the part names and describes the slave settings and Sysmac device functions.

2-1	Part Na	ames and Functions	2-2
	2-1-1	EtherCAT Master Indicators	
	2-1-2	Windows Used in Sysmac Studio	2-3
	2-1-3	Connecting the Sysmac Studio	2-6
2-2	Setting	g the Node Addresses of the EtherCAT Slaves	2-8
2-3	Featur	es of Sysmac Devices	-10
	2-3-1	Sysmac Devices	2-10
	2-3-2	Sysmac Device Features	<u>2</u> -10
	2-3-3	List of Sysmac Devices	2-13
	2-3-4	Sysmac Device Features and EtherCAT Masters	<u>2</u> -14

Part Names and Functions 2-1

2-1-1 **EtherCAT Master Indicators**



Label	Name	Color	Status	Meaning
		Green	Lit	EtherCAT communications are in progress.
				I/O data is being input and output.
			Flashing	EtherCAT communications are established. Communications is in one of the following states.
EtherCAT	RUN			Only message communications is functioning.
NET RUN				Only message communications and I/O data input operations are functioning.
			Not lit	EtherCAT communications are stopped.
				Power is OFF or the Unit is being reset.
				There is a MAC address error, communications controller failure or other error.
EtherCAT	ERROR	Red	Lit	There is an unrecoverable error, such as a MAC address error, a communications controller failure or an exception.
NET ERR			Flashing	There is a recoverable error.
			Not lit	There is no error.
			Lit	The link is established.
EtherCAT LINK/ACT	Link/Activity	Yellow	Flashing	A link is established and data is being sent and received.
				The indicator flashes whenever data is sent or received.
			Not lit	The link is not established.


Refer to 3-3-2 Control States for EtherCAT Communications for details on the states.

2-1-2 Windows Used in Sysmac Studio

Use the Sysmac Studio to create the EtherCAT network configuration and to make other settings. The following windows are used.

Creating the EtherCAT Network Configuration


Use the EtherCAT Configuration Editor offline to register slaves in the EtherCAT slave configuration. Or, upload the network configuration online.



Setting EtherCAT Slave Variables and Axes


I/O Map: Used to allocate device variables.

Use the I/O Map to assign device variables to the I/O ports of the EtherCAT slaves.




Axis Settings: Used to create Axis Variables and set parameters for Servo Drive and encoder input slaves.

Use the Axis Settings to assign Axis Variables to the Servo Drive/encoder input slaves.



Setting Axis Parameters:



• EtherCAT Master Settings: Used to set the EtherCAT master.

Set the EtherCAT master and slaves from the EtherCAT master settings, and the slave settings in the EtherCAT configuration.




Refer to Section 5 Setting Up EtherCAT Communications with the Sysmac Studio for the Sysmac Studio procedures.

2-1-3 **Connecting the Sysmac Studio**

You can connect the Sysmac Studio to the NJ-series CPU Unit through the USB or EtherNet/IP port. You must set the connection method, IP address to connect to, and other parameters for communications between the computer and Controller.

Select Communications Setup from the Controller Menu. The Communications Setup Dialog Box is displayed.



Select the connection method for the connection configuration from the Connection type Area.

If you specify a Remote connection via USB or an Ethernet connection via a hub, enter the IP address of the Controller in the Remote IP Address Area. Also set the Options and Response Monitor Time parameter to the required time. Refer to Communications Setup Dialog Box Settings on the next page for information on the settings.

Click the **OK** Button.

This completes the setup.

Communications Setup Dialog Box Settings


Item		Description	
Connection type	Specify the connection method to use for online communications. The specified connection method is used when you go online.		
Remote IP Address	If you specify a USB remote or Ethernet hub connection, set the IP address of the Controller that you normally will connect to.		
	USB Communica- tions Test Button	These buttons perform a communication test with the Controller at the specified IP address. The result is displayed as follows:	
	Ethernet Communica-	Normal: "Test OK"	
	tions Test Button	Error: "The Controller was not found." or "There is more than one Controller with the specified IP address."	
Options	Confirm the serial ID when going online.	If you select this option, the names and serial IDs are compared between the project and the Controller when you go online to make sure that a connection is made to the intended Controller.	
	Check forced refreshing when going offline.	If you select this option, a check is made to see if any forced refreshing values are still in effect before going offline.	
Response Monitor Time	You can set the response monitor time for communications with the Controller. An error is displayed if a response is not received before this time expires.		
Note The time can be set to between 1 and 3,600 s.			

Setting the Node Addresses of the 2-2 **EtherCAT Slaves**

Setting Node Address Using Hardware Switches

Setting the node address is described here. An OMRON GX-series Remote I/O Terminal is used as the slave. With a GX-series Remote I/O Terminal, the node address is set on hardware switches. With a GX-series Remote I/O Terminal, these switches are used to set the node address as a slave on the EtherCAT network.

The 10s digit is set using the left rotary switch and the 1s digit is set using the right rotary switch. The setting range is from 00 to 99.



The node address setting values are described in the following table.

Switch setting	Node address setting	
00	Set with the Sysmac Studio (1 to 192).	
01 to 99	Set with the hardware switches.	


Setting the Node Address from the Sysmac Studio

Use the Sysmac Studio to set the node address if there are no hardware switches or the node address is beyond the range that can be set with the hardware switches.

- Start the Sysmac Studio and go online with the Controller.
- Double-click EtherCAT under Configurations and Setups on the Multiview Explorer. Or, rightclick EtherCAT under Configurations and Setups and select Edit.




3 Right-click the EtherCAT master that is displayed in the Edit Pane and select *Write Slave Node Address*.



The Slave Node Address Writing Dialog Box is displayed.

4 If there are slaves for which the node address is not set (i.e., for which the present value is 0) or if there is more than one slave with the same node address (indicated by "!"), change the set values of the slave addresses, and then click the **Write** Button.

(If the correct node addresses are set for all of the slaves, click the Cancel Button.)



The node addresses are written to the actual slaves.



Additional Information

- The switch setting is read only once when the power is turned ON. Even if the setting is changed after the power supply is turned ON, the new setting will not be used until the next time that power is turned ON.
- If same node address is set for more than one node, a Slave Node Address Duplicated Error occurs and the operation of the slave stops. If a duplicated node address is set, the systemdefined variable _EC_SlavAdrDupErr (Slave Node Address Duplicated Error) changes to TRUE.
- Use the Sysmac Studio to set the node address if there are no hardware switches or the node address is beyond the range that can be set with the hardware switches.

Features of Sysmac Devices 2-3

2-3-1 **Sysmac Devices**

"Sysmac devices" is a generic name for EtherCAT slaves and other OMRON control components that were designed with the same communications and user interface specifications. You can use the NJseries Machine Automation Controllers together with Sysmac devices and the Sysmac Studio Automation Software to achieve optimum functionality and ease of operation.

2-3-2 **Sysmac Device Features**

You can connect Sysmac device slaves to an NJ-series Machine Automation Controller to use the following features.

Sysmac device feature	Description
Troubleshooting	OMRON defines component error status as Sysmac errors for the entire Sysmac Series. You can use Sysmac errors to display errors that occur in slaves on the Sysmac Studio together with corrections for the errors.
Backing up and restoring parameters	An optional feature in the version-1.0.1 ESI specifications is used to enable backing up and restoring slave parameters (called backup parameters).
Saving node address settings	The node address setting for each slave is stored in non-volatile memory within the slave.
Verifying the EtherCAT network configuration using serial numbers	You can verify the EtherCAT network configuration based on serial numbers.

Troubleshooting

OMRON defines component error status as Sysmac errors for the entire Sysmac Series.

You can use Sysmac errors to display errors that occur in slaves on the Sysmac Studio together with corrections for the errors.

This allows you to detect slave errors and isolate the causes of the errors.

If a Sysmac error occurs in a slave, the values of the _EC_SlavErr system-defined variable and the element of the _EC_SlavErrTbl system-defined variable that corresponds to the slave node address change.

Refer to 9-1-1 How to Check for Errors for details on the values.



Additional Information

- This feature is not supported for OMRON slaves that are not Sysmac devices and slaves that are manufactured by other companies. Check the error detection methods for each slave.
- Before you reset an error from the NJ-series EtherCAT master, make sure you confirm the cause of the error in the slave.
- Sysmac errors are not displayed on the Troubleshooting Dialog Box when the slaves are in Init state. When a slave in Init state where a Sysmac error was detected is connected, you cannot confirm the Sysmac error that was detected by the slave until communications are restarted with that slave. Therefore, if an error that results in a slave going to Init state and a slave Sysmac error are detected at the same time, first reset the slave Init state, restart communications with the slave, and then check the Sysmac error. Then, eliminate the cause of the error and reset the error. Refer to 9-2-2 Error Descriptions for the errors that result in the Slave entering Init state.
- If you delete the assignment of the Sysmac error status from the processing data communications data, e.g., to reduce the load on the EtherCAT communications line, you will not be able to use the Sysmac error status in troubleshooting. (To delete the assignment, edit the PDO map settings in the EtherCAT master settings on the Sysmac Studio so that the map object that is mapped to object 2002 hex is not selected.) If you do so, you can detect errors that occur in the slave applications other than communications errors only through the transmission of emergency messages or status information that is mapped for other process data communications. Use emergency messages and other status information for which PDOs are mapped to detect slave errors in this case. Transmission of emergency messages is disabled by default for OMRON slaves.
- When the EtherCAT master detects an emergency message from a slave, the _EC_SlavEmergErr system-defined variable changes to TRUE. Check the contents of the emergency message from the slave on the Troubleshooting Dialog Box.
- Refer to Section 9 Troubleshooting for details on checking for errors and corrections.

Backing Up and Restoring Parameters

The Sysmac devices use an option in the version-1.0.1 ESI specifications to enable backing up and restoring the backup parameters that are specified in the ESI files in non-volatile memory in the slaves.

You can back up and restore the backup parameters that are stored from the Sysmac Studio.

This makes it easy to set slaves when they are replaced.



Additional Information

- If you use slaves from other manufacturers, obtain the slave information files that are compliant with the version-1.0.1 ESI specifications from the slave manufacturers.
- Refer to 9-4-3 Backing Up Settings for the procedure to back up slave data from the Sysmac Studio.
- Refer to 9-4-4 Restoring Settings for the procedure to restore slave data from the Sysmac Studio.
- Refer to A-3 Multi-vendor Environments for information on ESI.

Saving Node Address Settings

Each Sysmac device stores its own node address setting in non-volatile memory within the slave.

This allows the master to identify slaves on the network.

The node addresses are set as given below depending on the type of slave.

- Slaves with Hardware Switches
 - 0: The node address is set from the Sysmac Studio.
 - Not 0: The setting on the hardware switches is used.
- Slaves without Hardware Switches

The node address is set from the Sysmac Studio.



Precautions for Correct Use

- · Set a node address for every slave so that the slaves can be identified on the EtherCAT network. Do not assign the same node address more than once.
- If you connect slaves from other manufacturers to the NJ-series EtherCAT master, set the node addresses for them from the Sysmac Studio. (The NJ-series EtherCAT master recognizes the value that is stored at address 0x0012 in the EtherCAT slave controller of the slave as the node address.)
- For OMRON slaves that are not Sysmac devices, set the node addresses on the hardware switches. If the node address switches are set to 0, a Network Configuration Verification Error occurs.



Additional Information

- Refer 2-2 Setting the Node Addresses of the EtherCAT Slaves or the manuals for each slave for the procedure to set the node addresses.
- Refer to 5-4-2 Setting EtherCAT Slaves for information on setting node addresses with the Sysmac Studio.

Verifying the EtherCAT Network Configuration Using Serial Numbers

Each Sysmac device slave stores its serial number in non-volatile memory within the slave.

If serial number verification is enabled in the EtherCAT master settings, the EtherCAT network configuration is verified based on the serial numbers when the EtherCAT master is started. The following are enabled by verification of the serial numbers.

- If the EtherCAT network configuration changes, the serial numbers will not match and a Network Configuration Verification Error occurs. This helps prevent forgetting to set the parameters when a slave is replaced.
- The serial numbers of any of the slaves can be checked from the EtherCAT master.



Additional Information

Refer to 5-4-1 Setting EtherCAT Master for information on checking serial numbers.

2-3-3 List of Sysmac Devices

The following table lists the OMRON Sysmac slaves. Refer to the manual for the slave for information on OMRON slaves that are not listed in the following table.

Name	Model	Revision
AC Servo Drives	R88D-KN□□□-ECT	Revision 2.1 or higher
Multifunctional, Compact Inverter	3G3AX-MX2-ECT	Revision 1.1 or higher
Digital I/O Slaves	GX-ID	Revision 1.1 or higher
	GX-OD□□□□	
	GX-MD	
	GX-OC	
Analog I/O Slaves	GX-AD0□71	Revision 1.1 or higher
	GX-DA0□71	
Encoder Input Slaves	GX-EC02□1	Revision 1.1 or higher
Vision Sensors	FH-1□□□	Revision 1.0 or higher
	FH-3□□□	
Specialized Vision Sensors for Positioning	FQ-MS12□-ECT	Revision 1.0 or higher
	FQ-MS12□-M-ECT	
Smart Fiber Sensor Communications Unit	E3X-ECT	Revision 1.0 or higher
EtherCAT Junction Slaves	GX-JC03	Revision 1.0 or higher
	GX-JC06	
NX-series EtherCAT Coupler Unit*	NX-ECC201	Revision 1.0 or higher
Advanced General-purpose Inverters	3G3RX-V1 with EtherCAT Commu-	Revision 1.0 or higher
	nications Unit	
	3G3AX-RX-ECT	
Linear Servo Drive	R88L-EC	Revision 1.0 or higher
	R88D-KN□-ECT-L	
Digital Sensor Communications Unit	E3NW-ECT	Revision 1.0 or higher
Fiber Sensor Communications Unit	E3X-ECT	Revision 1.0 or higher
Confocal Fiber Type Displacement Sensors	ZW-CE1□	Revision 1.0 or higher

^{*} An NJ-series CPU Unit with unit version 1.05 or later is required.

Sysmac Device Features and EtherCAT Masters 2-3-4

The following table shows the relationship between Sysmac device features and EtherCAT masters.

OMRON Sysmac Device Slaves

	OMRON Eth		
Sysmac device feature	NJ301-1□□□ or NJ501-1□□□ NJ-series CPU Unit	CJ1-NC□8□ CJ-series Position Control Unit	EtherCAT master from another manufacturer
Troubleshooting	Supported.	Not supported.*1	Not supported.*1
Backing up and restor- ing parameters	Supported.	Partially supported.*2	Partially supported.*3
Saving node address settings	Supported.	Supported.	Partially supported.*4
Verifying the EtherCAT network configuration	Supported.	Not supported.	Partially supported.*5

^{*1} Error notification is provided with emergency messages.

OMRON Slaves That Do Not Support Sysmac Devices

	OMRON Eth			
Sysmac device feature	NJ301-1□□□ or NJ501-1□□□ NJ-series CPU Unit	CJ1-NC□8□ CJ-series Position Control Unit	EtherCAT master from another manufacturer	
Troubleshooting	Not supported.*1	Not supported.*1	Not supported.*1	
Backing up and restor- ing parameters	Supported.	Partially supported.*2	Partially supported.*3	
Saving node address settings	Partially supported.*4	Partially supported.*4	Partially supported.*5	
Verifying the EtherCAT network configuration	Not supported.	Not supported.	Partially supported.*6	

^{*1} Error notification is provided with emergency messages.

- *5 The ability to store node addresses depends on the ability of the EtherCAT master from another manufacturer.
- *6 The ability to verify serial numbers depends on the ability of the EtherCAT master from another manufacturer.

Slaves from Other Manufacturers

If you connect slaves from other manufacturers to an OMRON EtherCAT master, functionality is restricted as given below depending on the functionality of the slaves.

- Slaves cannot be connected if the ESI files do not comply with the most recent ESI standards.
- · The Sysmac Studio operation to set node addresses may not be supported by some slaves depending on the slave specifications.
- Verification with serial numbers is not possible for slaves that do not have the serial number in SII.

^{*2} You cannot specify the parameters that are backed up and restored.

^{*3} The ability to back up and restore parameters depends on the ability of the EtherCAT master from another manufacturer.

^{*4} The ability to store node addresses depends on the ability of the EtherCAT master from another manufacturer.

^{*5} The ability to verify serial numbers depends on the ability of the EtherCAT master from another manufacturer.

^{*2} You cannot specify the parameters that are backed up and restored.

^{*3} The ability to back up and restore parameters depends on the ability of the EtherCAT master from another manufacturer.

^{*4} Setting is possible on the node address switches. Node addresses set with the software cannot be stored in the slave.



EtherCAT Communications

This section describes the different types of EtherCAT communications, EtherCAT settings, and state transitions.

3-1	Ether	CAT Communications Types and Settings	3-2
	3-1-1	CoE (CAN Application Protocol over EtherCAT)	3-2
	3-1-2	Types of Communications	3-4
	3-1-3	Types of EtherCAT Variables	3-5
	3-1-4	Settings Required for EtherCAT Communications	3-6
3-2	Progra	amming EtherCAT Communications	3-7
3-3	State	Transitions for EtherCAT Communications	3-8
	3-3-1	Self Diagnosis at Startup	3-8
	3-3-2	Control States for EtherCAT Communications	3-8
	3-3-3	CPU Unit Status in Relation to EtherCAT	3-10

EtherCAT Communications Types and Settings

3-1-1 **CoE (CAN Application Protocol over EtherCAT)**

The EtherCAT port built into the NJ-series CPU Unit uses CoE (CAN application protocol over Ether-CAT) to exchange information with slaves over EtherCAT. CoE implements CANOpen (an industrial communications protocol developed by CiA) communications over an EtherCAT network. With CoE, the parameters and control information held by the slaves are specified according to data specifications for the object dictionary.

Process data Communications and SDO Communications


There are two communications that are used to communicate data between the master and slaves. These are described below.

1) Process Data Communications:

Communications using process data objects (PDOs) to exchange information in realtime with a fixed period.

2) SDO Communications:

Communications using service data objects (SDOs) for communicating information when required.



The EtherCAT port built into the NJ-series CPU Unit uses process data communications for commands to refresh I/O data in a fixed control period, including I/O data for EtherCAT slaves, and position control data for Servomotors. It uses SDO communications for commands to read and write data, such as for parameter transfers, at specified times.

Process data communications are executed each control cycle to refresh data continuously, and SDO communications are executed between PDO communications.




Additional Information

Object Dictionary

The object dictionary is a data table within the device that interfaces the application and communications. It describes the information handled by the device. Each piece of information is called an object. Each object is assigned a 4-digit hexadecimal index.

Each object is divided into a data type area, a CoE communications area, and a manufacturer-specific area.




Process data communications is used to read and write the process data in the CoE communications area in these objects.

SDO communications is used to read and write the parameters within the manufacturer-specific area in these objects.

Distributed Clock (DC)

This is a unique EtherCAT feature that enables precisely synchronizing time. The DC-based clock synchronization enables sharing the same time (i.e., the EtherCAT System Time) between the EtherCAT master and the slaves. This enables the timing of the operation of the EtherCAT master and slaves to be synchronized with the shared time.




All slaves that support a distributed clock (synchronized slaves) are synchronized with the reference clock. In this EtherCAT system, the closest slave on the network to the EtherCAT master of all the slaves with a reference clock provides the reference clock. The EtherCAT master and slaves automatically access this reference clock.

3-1-2 **Types of Communications**

The following two methods are used to exchange data between master and slaves in EtherCAT communications.

Communication type	Name of communication type	Timing of processing	Type of data
Cyclic communications	Process data communications (PDO communications)	Constant (process data communications cycle)	PDO data
Message communications	SDO communications	When required.	SDO data



* Device variables for EtherCAT slaves Axis Variables only for Servo Drive and encoder input slaves to which axes are allocated

Process Data Communications (PDO Communications)

PDO communications is used for constant data exchange between the master and slaves. It is called process data communications. PDO data (i.e., I/O data that is mapped to PDOs) that is allocated in advance is input and output periodically each EtherCAT process data communications cycle (i.e., the period of primary periodic task).

It is accessed from the NJ-series CPU Unit in the following ways.

- With device variables for EtherCAT slave I/O
- With Axis Variables for Servo Drive and encoder input slaves to which an axis is allocated

SDO Communications


SDO communications are used to read and write specified slave data from the master when required. This is called SDO communications.


You can read/write the following specified slave data with the EC_CoESDORead (Read CoE SDO) instruction or the EC_CoESDOWrite (Write CoE SDO) instruction.

• SDO data in slaves (parameters, error information, etc.)

3-1-3 Types of EtherCAT Variables

There are three types of EtherCAT variables as listed below.





Settings Required for EtherCAT Communications 3-1-4

For EtherCAT communications, you must set the following network configuration information from the Sysmac Studio and download it to the CPU Unit.

- Network configuration: Master and slave configuration
- · EtherCAT master settings: Parameters settings, such as the process data communications cycle
- · Process data information: Allocation information for slave PDO data



Additional Information

EtherCAT communications cannot be performed unless the correct network configuration information is downloaded to the CPU Unit.

Refer to Section 5 Setting Up EtherCAT Communications with the Sysmac Studio for details.

3-2 Programming EtherCAT Communications

The user program in the NJ-series CPU Unit reads/writes EtherCAT slave data and performs motion control for Servo Drive and encoder input slaves.

Instructions and variables are used according to slave types and target data as shown below.

Slave type	Type of data	Timing	Instructions	Variables
Slaves to which you cannot assign axes	Process data	Constantly read/written	Read/write instructions such as LD, OUT and MOV	Device variables
	SDO data	Read/written as required	EtherCAT instructions (EC_CoESDORead or EC_CoESDOWrite)	User-defined variables
Slaves to which you can assign axes	Process data	Constantly read/written	Motion control instruc- tions or read/write instructions such as LD, OUT and MOV	Axis Variables or device variables
	SDO data	Read/written as required	EtherCAT instructions (EC_CoESDORead or EC_CoESDOWrite)	User-defined variables

State Transitions for EtherCAT 3-3 **Communications**

3-3-1 **Self Diagnosis at Startup**

The EtherCAT master executes the following self-diagnosis when the power is turned ON. The results of self-diagnosis are provided in the following system-defined variables as EtherCAT master errors if errors are detected.


Diagnosis	Detected error type	System-defined variables
Diagnosis of network configuration information	Network configuration information error	_EC_NetCfgErr
Diagnosis of communications port	MAC address error	_EC_MacAdrErr
	Communications controller error	_EC_LanHwErr

Refer to 9-1 Overview of Errors for details on error types.

Control States for EtherCAT Communications 3-3-2

Control State Machine

EtherCAT communications provides four control states. Communications is controlled by moving between these states.



After the power is turned ON, the communications master and slaves go from the Init state to the Preoperational state, Safe-operational state, and then Operational state before starting EtherCAT communications. Afterwards, EtherCAT communications are performed while the state changes automatically between these states according to error occurrence and other conditions.

The current control state can be determined using the RUN indicator on the front panel.

State	Description	Process data communications	SDO communications	RUN indicator
1. Init	Communications are being initialized. Communications are not possible.	Not allowed	Not allowed	Not lit
	This state continues if the network is not configured.			
2. Pre-operational	Only SDO communications are possible in this state. Communications always enters this state after initialization, and changes to the safe-operational state after initial setting of the network is performed.	Not allowed	Possible	Flashing
3. Safe operational	In this state, SDO communications and only inputs for process data communications are possible. Communications always enters this state before going into the Operational state.	Only inputs are possible	Possible	Flashing
4. Operational	This is the normal state for communications.	Possible	Possible	Lit




Additional Information

I/O Refreshing

The procedure from startup of the EtherCAT network until process data I/O can be refreshed is shown below. There is no correlation between the startup of the EtherCAT network and the execution of the user program. Design the user program by adding the system-defined variables* for the relevant slaves to the interlock conditions of the device variables for the slaves.

*._EC_ActSlavTbl[1..192], _EC_MBXSlavTbl[1..192], _EC_PDSlavTbl[1..192], _EC_DisconnSlavTbl[1..192], and _EC_DisableSlavTbl[1..192]



3-3-3 **CPU Unit Status in Relation to EtherCAT**

Refer to A-1 EtherCAT Status in Relation to CPU Unit Status for details on the following: memory related to the EtherCAT master, the ability to download master settings and slave settings, and the status of slaves according to the CPU Unit operating mode and the status of Controller errors.



EtherCAT Network Wiring

This section describes how to connect and wire an EtherCAT network.

4-1	Laying	the EtherCAT Network	4-2
	4-1-1	Supported Network Topologies	4-2
	4-1-2	Installation Precautions	4-4
	4-1-3	Installing EtherCAT Communications Cables	4-4
	4-1-4	Connecting Communications Cables	4-7
	4-1-5	Cable Connection Procedure	4-8


Laying the EtherCAT Network 4-1

This section describes how to install EtherCAT networks.


Supported Network Topologies 4-1-1

The NJ-series CPU Unit can be connected using daisy chain connections with no branching, or with branching connections using Junction Slaves. This supports redundancy, and all topologies other than rings. Examples of topology without branching and with branching (Junction Slaves) are shown below.

No Branching



Branching





Additional Information

When you use a system configuration in which an EtherCAT Junction Slave is connected to synchronized slaves that provide a distributed clock, at least one of the following two conditions below must be met.

- A slave that provides a reference clock must be connected between the EtherCAT master and the first Junction Slave.
- The Junction Slave must provide a reference clock.

However, the above conditions do not apply when synchronization is not performed between slaves providing a distributed clock throughout the entire EtherCAT network.

You can determine whether the Junction Slave supports a reference clock from the Reference Clock setting in the Sysmac Studio slave settings. OMRON Junction Slaves support a reference clock.

4-1-2 **Installation Precautions**

Basic precautions for the installation of EtherCAT networks are provided below.

Precautions when Installing a Network

- When you install an EtherCAT network, take sufficient safety precautions and perform the installation according to standards and specifications. (Refer to JIS X5252 or to electrical facility technical refer-
 - An expert well versed in safety measures and the standards and specifications should be asked to perform the installation.
- Do not install EtherCAT network equipment near sources of noise. If the network must be installed in an area with noise, take steps to address the noise, such as placing equipment in metal cases.

Precautions when Installing Communications Cables

- · Check the following items on the communications cables that are used in the network.
 - Are there any breaks?
 - Are there any shorts?
 - Are there any connector problems?
- When you connect the cable to the communications connectors on devices, firmly insert the communications cable connector until it locks in place.
- Do not lay the communications cables together with high-voltage lines.
- Do not lay the communications cable near devices that generate noise.
- Do not lay the communications cables in locations subject to high temperatures or high humidity.
- Do not lay the communications cables in locations subject to excessive dirt and dust or to oil mist or other contaminants.
- There are limitations on the bending radius of communications cables. Check the specifications of the communications cable for the bending radius.

4-1-3 Installing EtherCAT Communications Cables

Ethernet communications cables and connectors are used to connect the built-in EtherCAT port with EtherCAT slaves.

Use a shielded twisted-pair cable (double shielding with aluminum tape and braiding) of Ethernet category 5 (100Base-TX) or higher, and use straight wiring.

Cable with Connectors

Sizes and Conductor Pairs: AWG 22 × 2 Pairs

Product name	Manufacturer	Cable length (m)*	Model	Contact information
Cable with Connec-	OMRON	0.3	XS5W-T421-AMD-K	OMRON Customer
tors on both Ends (RJ45/RJ45)	Corporation	0.5	XS5W-T421-BMD-K	Service Center
		1	XS5W-T421-CMD-K	
Cable with Connec-	OMRON	2	XS5W-T421-DMC-K	OMRON Customer
tors on both Ends (M12/RJ45)	Corporation	5	XS5W-T421-GMC-K	Service Center
		10	XS5W-T421-JMC-K	

Cables are available in the following lengths: 0.3, 0.5, 1, 2, 3, 5, 10, and 15 m. Refer to the Industrial Ethernet Connectors Catalog (Cat. No. G019)

Cables and Connectors

Sizes and Conductor Pairs: AWG 24 × 4 Pairs

Part name	Manufacturer	Model	Contact information
Cables	Tonichi Kyosan Cable, Ltd.	NETSTAR-C5E SAB 0.5 × 4P*	Planning Department, Kanetsu Co., Ltd.
	Kuramo Electric Co.	KETH-SB*	Kuramo Electric Co.
	SWCC Showa Cable Systems Co.	FAE-5004*	SWCC Showa Cable Systems Co.
RJ45 Connectors	Panduit Corporation	MPS588*	Panduit Corporation US Headquarters

^{*} We recommend that you use combinations of the above Cables and Connectors.

Sizes and Conductor Pairs: AWG 22 × 2 Pairs

Part name	Manufacturer	Model	Contact information
Cables	Kuramo Electric Co.	KETH-PSB-OMR*	Kuramo Electric Co.
RJ45 Assembly Connectors	OMRON Corporation	XS6G-T421-1*	OMRON Customer Service Center

^{*} We recommend that you use combinations of the above Cables and Connectors.



Precautions for Correct Use

- The maximum length between nodes is 100 m. However, some cables are specified for less than 100 m. Generally speaking, if the conductors are twisted wire rather than solid wire, transmission performance will be lower, and reliable communications may not be possible at 100 m. Confirm details with the cable manufacturer.
- When selecting a connector, confirm that it is applicable to the cable that will be used. Confirm the following items: Conductor size, conductor type (solid wire or twisted wire), number of twisted pairs (2 or 4), outer diameter, etc.




Additional Information

If an Ethernet cable of category 5 or higher is used, communications will be possible even if the cable is not shielded. However, we recommend a cable with double, aluminum tape and braided shielding to ensure sufficient noise immunity.

Attaching the Connectors to the Cable and Pin Assignments

Use straight wiring to attach the connectors to the communications cable.



^{*1} Connect the cable shield to the connector hood at both ends of the cable.

Connector Specifications

Specification	Description
Electrical characteristics	Conforms to IEEE 802.3 standards.
Connector structure	RJ45 8-pin modular connector (Conforms to ISO 8877.)

Pin Assignments


Pin No.	Signal name	Abbreviation	Signal direction
1	Transmission data +	TD+	Output
2	Transmission data –	TD-	Output
3	Reception data +	RD+	Input
4	Not used.		
5	Not used.		
6	Reception data –	RD-	Input
7	Not used.		
8	Not used.		
Hood	Frame ground	FG	

^{*2} There are two connection methods for Ethernet: T568A and T568B. The T568A connection method is shown above, but the T568B connection method can also be used.

4-1-4 Connecting Communications Cables

Cable connections can be made freely in EtherCAT networks. Connect the communications cable from the EtherCAT master to the input port on the first slave, and then connect the communications cable to the next slave to the output port on the first slave.

Do not connect anything to the output port of the slave at the end of the network.



The cable between any two nodes (L1, L2 ... Ln) must be 100 m or less. Use the Sysmac Studio to confirm if communications are possible for the total cable length. Firmly connect the communications cable connector until it clicks into place.



Precautions for Correct Use

Always perform one of the following operations before you disconnect the communications cable to a EtherCAT slave during operation.

- Disconnect the EtherCAT slave from the network.
- Disable the EtherCAT slaves and all slaves connected after it.

Refer to 9-4 Replacing Slaves during Communications for information on replacing slaves during operation.



Additional Information


Make sure the cable between each pair of devices connects an output port to an input port. Normal communications are not possible if an output port is connected to another output port or an input port is connected to another input port.

4-1-5 **Cable Connection Procedure**




Precautions for Correct Use

- Turn OFF the Controller's power supply before connecting or disconnecting Ethernet communications cable.
- Allow extra space for the bending radius of the communications cable. The required space depends on the communications cable and connector that are used. Consult with the manufacturer or sales agent.



- Lay the Ethernet communications cable.
- Connect the Ethernet communications cable to the built-in EtherCAT port on the NJ-series CPU Unit. Firmly insert the connector until it locks into place.





Setting Up EtherCAT Communications with the Sysmac Studio

This section describes how to set the network configuration information and how to check EtherCAT communications from the Sysmac Studio.

5-1	Overvie	ew of Network Configuration Information 5-2				
5-2	Creatin	g the EtherCAT Network Configuration 5-3				
5-3	Setting EtherCAT Slave Variables and Axes 5-6					
	5-3-1	Registering Device Variables for All EtherCAT Slaves 5-6				
	5-3-2	Axis Settings for Servo Drives and Encoder Input Slaves 5-12				
5-4	EtherC	AT Master and Slave Parameter Settings 5-17				
	5-4-1	Setting EtherCAT Master 5-17				
	5-4-2	Setting EtherCAT Slaves				
5-5	-5 Comparing and Merging EtherCAT Network Configurations					
	5-5-1	Comparing and Merging with the Actual Network Configuration from the Sysmac Studio				
	5-5-2	Automatically Creating the Network Configuration 5-29				
	5-5-3	Using the Sysmac Studio to Obtain Serial Numbers from the Actual Network Configuration				
5-6	Downloading the Network Configuration Information 5-34					
	5-6-1	Downloading the Network Configuration Information from the Sysmac Studio				
5-7		ning Communications after Completing EtherCAT Configuration and s				


Overview of Network Configuration 5-1 Information

To execute EtherCAT communications, you must create the following three types of data with the Sysmac Studio and download the data to the CPU Unit. When this data is set, the network configuration information is automatically created.

When you download the network configuration information to the CPU Unit, the EtherCAT master initializes slaves and performs process data communications based on the network configuration information. This section describes the procedures to set the network configuration information and how to check EtherCAT communications.

Network Configuration Information


Network configuration infor-	1.	EtherCAT network configuration
mation	2.	Process data information This is allocation information for PDO data in the slaves. It is also called PDO mapping data.
	3.	EtherCAT master and slave parameter settings (Examples: process data communications cycle and wait all slaves startup time)




5-2 Creating the EtherCAT Network Configuration

This section describes how to create the EtherCAT network configuration.

- **1** Start the Sysmac Studio offline.
- 2 Double-click **EtherCAT** under **Configurations and Setup** on the Multiview Explorer. Or, right-click EtherCAT under **Configurations and Setup** and select *Edit*.




EtherCAT master will be displayed in the Edit Pane.



Edit Pane


Multi-view Explorer

Select a slave in the Toolbox, drag it to the Edit Pane, and drop it under the master. The slave will be added under the master.



Drag the slaves.

Select another slave in the Toolbox, drag it to the Edit Pane, and drop it under the slave to which you want to connect it to. The slave will be added under the slave.



For detailed procedures, such as those for deleting slaves, or copying and pasting slaves, refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504).

Refer to the NX-series EtherCAT Coupler Unit User's Manual (Cat. No. W519) and the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on creating the EtherCAT Slave Terminal configuration.

Refer to A-8 MDP Settings for EtherCAT Network Slaves in the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on MDP slaves and editing the configurations of the modules that you can connect to the MDP slaves.



Additional Information

You can go online and read the actual network configuration from the Sysmac Studio to display it and to use it as the network configuration in the project.

For details, refer to 5-5-2 Automatically Creating the Network Configuration.

Setting EtherCAT Slave Variables and **5-3** Axes

Device variables are used to read and write process data for EtherCAT slaves. Axis variables are used to manipulate slaves to which axes are assigned from the Motion Control Function Module. This section describes how to register device variables and set the axes.

5-3-1 Registering Device Variables for All EtherCAT Slaves

You use the I/O Map Tab Page in the Sysmac Studio to assign device variables to the I/O ports. The device variables that you create are registered in the global variable table. Use one of the following three methods.

- Selecting variables that were previously registered in a variable table
- · Inputting new device variable names
- · Automatically creating device variable names

Selecting Variables That Were Previously Registered in a Variable Table

You can select variables that are already registered on the menu on the I/O Map Tab Page. For example, this method can be used to register device variables in the following cases.


- To write the program before the slave configuration information is created.
- To reuse programming from another project.

Use the following procedure.

- Register the variables in advance in the global variable table or the local variable table of one of the POUs.
- Program using those variables.
- **3** Create the slave configuration information.
- Double-click I/O Map under Configurations and Setup on the Multiview Explorer. Or, right-click I/O Map under Configurations and Setup and select Edit.



5 Select the variables from the pull-down list in the I/O Map Tab Page to assign them to I/O ports.



Inputting New Device Variable Names

You can input the required device variable names. For example, this method can be used to register device variables in the following case.


To give suitable names to device variables that are assigned to I/O for I/O slaves.

Use the following procedure.


1 Double-click I/O Map under Configurations and Setup on the Multiview Explorer. Or, right-click I/O Map under Configurations and Setup and select *Edit*.



2 Select the I/O port on the I/O Map Tab Page and enter the variable name in the Variable column.



Device variables are assigned to the I/O ports of the slaves.



3 To specify a variable table for the scope, specify the variable type.

Automatically Creating Device Variable Names

The device variable names will be created by combining the device name and the I/O port name. The device names are set in the slave parameters. The default device names are "E" followed by a serial number that starts from 001. For example, this method can be used to register device variables in the following case.

To eliminate the work that is involved in obtaining the device variable names.


Use the following procedure.

Double-click I/O Map under Configurations and Setup on the Multiview Explorer. Or, right-click I/O Map under Configurations and Setup select Edit.




The I/O Map Tab Page will be displayed.

Select a slave or I/O ports on the I/O Map Tab Page, right-click, and select Create Device Variable.



3 If you specify a variable table for the scope, specify the variable type afterward.



Device variables are automatically assigned to the I/O ports of the slaves and registered in the variable table that is specified by the Variable Type.



Additional Information


- We recommend that you set device names.
- To delete the mapping for the variable that is assigned to a port, delete the contents of the cell in the Variable column or right-click the cell and select Reset Assignment.
 - The mapping of the device variable is deleted. The variable is not deleted from the variable table.
 - Refer to NJ-series CPU Unit Software User's Manual (Cat. No. W501) for details on device variables.
- If you do not specify anything in the Variable type Column when you register a variable or create device variables, the variables are automatically registered in the global variable table.





Additional Information

Default allocations of process data for slaves are defined in the ESI files. Depending on the slave, you may have to change the process data assignment as required by the application. Use the following procedure.


Select the slave for which to change the allocated data. The parameters and allocated data for the slave will appear.







The Edit PDO Map Settings Window will appear. Edit the allocated data as required.




- 3 Select the output data (RxPDO) and input data (TxPDO) in the PDO Map List. You can add or delete the PDOs with Editable Flags as entries for the objects to use for the slaves. Refer to A-3-4 Editing PDO Entry Tables for details.
- 4 Click the **OK** Button.


Axis Settings for Servo Drives and Encoder Input Slaves 5-3-2

Adding Axes

Right-click Axis Settings under Configurations and Setup - Motion Control Setup on the Multiview Explorer. Select *Add* – *Axis Settings* from the menu.



The *MC_Axis000* Axis Variable is added under the **Axis Settings**.







You can confirm that the MC_Axis000 Axis Variable has been added automatically.



Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for the procedures to change, delete, or copy Axis Variables or the procedure to register axes groups.




Additional Information


Even if you change an axis name in the Global Variable Table, the axis name in the Motion Control Setup will not change. Always change the axis name in the Motion Control Setup.

Registering Slaves to Axes


Double-click the MC_Axis000 Axis Variable that was registered.




The Axis Parameter Setting View will be displayed in the Edit Pane. The Axis Basic Settings Tab Page will be displayed first.



2 To enable the use of a servo axis, set the *Axis use* Box to *Used axis* and set the *Axis type* to *Servo axis*.




3 Select the slave that is assigned to the registered servo axis for the input device.



Setting Axis Parameters

1 Click each of the icons in the Axis Parameter Settings Tab Page.
The settings for each icon are displayed on the Axis Parameter Settings Tab Page.



The parameters that are displayed for these icons are described in the following table.

Overview of Axis Parameter Settings Tab Page

Icon	Name	Description
E	Axis Basic Settings	Displays the page to enable/disable axis and to set axis types, node addresses, and channels.
+++ + +	Unit Conversion Settings	Displays the page to set the gear ratio of the electronic gear using the pulses per motor rotation and travel distance.
3	Operation Settings	Displays the page to set the velocity, acceleration rate, deceleration rate, torque warning values, and other monitor parameters.
←	Other Operation Settings	Displays the page to set the Servo Drive I/O.
3	Limit Settings	Displays the page to set software limits and following error limits.
中	Homing Settings	Displays the page to set the homing operation.
123	Position Count Settings	Displays the page to set Count Mode of the Controller.
0	Servo Drive Settings	Displays the page to set the Servo Drive parameters.



Additional Information

You can display all of the axis parameters in an Axis Setting Table. You can edit the axis parameters in this table in the same way as for the Axis Parameter Setting View.

Any parameters that are edited in the Axis Parameter Setting View are automatically updated in the Axis Setting Table.


Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for details on the Axis Setting Table.

Refer to NJ-series CPU Unit Motion Control User's Manual (Cat. No. W507) for details on axis parameters.


5-4 EtherCAT Master and Slave Parameter Settings

5-4-1 Setting EtherCAT Master

1 Double-click EtherCAT under Configurations and Setup on the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit*.



2 Select the EtherCAT master that is displayed in the Edit Pane.



The EtherCAT master settings are listed below.

Name	Editing	Remarks
Device name	OK	Displays the name of the EtherCAT master.
		Default setting: Master
Model	Not allowed.	Always "Master."
Product name	Not allowed.	Always "Master."
Number of Slaves	Not allowed.	The number of slaves is automatically calculated based on the topology. There can be up to 192 slaves. Display range: 0 to 192.
PDO Communications Cycle Time	Not allowed.	This is automatically input based on the task period of the primary periodic task. Display range: 500 to 4,000 μs^{*1}
Total Cable Length*2	ОК	This is the total cable length between the slaves. Setting range: 1 to 4,294,967,295 Default setting: 1,000 m
Fail-soft Operation Setting	OK	Select <i>Stop</i> or <i>Fail-soft</i> operation for communications with all slaves on the network when the master detects a communications error (cable disconnection, slave malfunction, etc.).
		Default setting: Fail-soft operation Refer to 9-1 Overview of Errors for details on errors.
Wait Time for Slave Startup	ОК	Set the time to wait from the detection of the link on the EtherCAT port until all slaves join the network.
		Setting range: 3 to 200 s
		Default setting: 30 s
		Process data communications start if all slaves are present within the wait time. If all of the slaves are not present after the wait time elapses, a network configuration verification error occurs. When you use a slave that takes time to start, use a longer wait time setting to prevent errors.
PDO communications timeout detection count	ОК	A Process Data Reception Timeout error occurs if process data (PDO) communications timeouts occur continuously the specified number of times. Increase the setting if process data reception timeout errors occur frequently, such as in high-noise environments. Set the value to 2 or higher for a slave that needs to be replaced.
		Setting range: 1 to 8 errors
		Default setting: 2 errors
Revision Check Method	ОК	Specify the method to use to verify the revision numbers that are stored in the network configuration information (setting) against the actual revision numbers of the slaves (actual device) at the start of communications. Verification is required to enable operation. Communications will not start if there are unverified slaves, and a network configuration verification error will occur.
		Setting values: Setting <= Actual device, Setting = Actual device, or No check*3
		Default setting: Setting <= Actual device
Serial Number Check Method*4	OK	Specify whether to verify the slave serial numbers that are stored in the network configuration information against the serial numbers that are set in the actual slaves when initiating communications. Communications will not start if there are unverified slaves, and a network configuration verification error will occur.
		Setting values: Setting = Actual device or No check
	1	Default setting: No check

- *1 The PDO communications cycle time for an NJ301-□□□□ CPU Unit is 1,000, 2,000, or 4,000 µs.
- *2 The total cable length is set because it is used for simulation of the task execution times on the Sysmac Studio. Setting the total cable length will enable taking into consideration the delay that is caused by the cable lengths when the Sysmac Studio estimates the task execution times. The operation of the Controller is not affected even if the setting of the total cable length is not correct (e.g., if you do not change the default setting). If you use the default setting, the simulation results will reflect the delay for a 1,000-meter total cable length. If this setting is different from the actual total cable length, the delay on the actual system will be different than the delay in the simulation results.
- *3 Operations for the setting values of the revision check method are described in the following table.

Setting value	Result of revision number check	Communications with slaves	
Setting <= Actual device	Setting > Actual device	Communications are not possible.	
	Setting = Actual device	Communications are possible.	
	Setting < Actual device	Communications are possible.	
Setting = Actual device	Setting > Actual device	Communications are not possible.	
	Setting = Actual device	Communications are possible.	
	Setting < Actual device	Communications are not possible.	
No check	Setting > Actual device	Communications are possible.	
	Setting = Actual device	Communications are possible.	
	Setting < Actual device	Communications are possible.	

*4 If the set value is "Setting = Actual device", communications with slaves in the network is not started if a slave is replaced. If it is necessary to replace a slave while the set value is "Setting = Actual device", you must correct the network configuration information and transfer it to the EtherCAT master again. Set this parameter to "Setting = Actual device" if strict management of the equipment configuration is required.



Precautions for Safe Use

- If the Fail-soft Operation Setting parameter is set to "Stop", process data communications will stop for all slaves when an EtherCAT communications error is detected in a slave. The Servo Drive will operate according to the Servo Drive specifications. Make sure that the Fail-soft Operation parameter setting results in safe operation when a device error occurs.
- If verifying revisions is disabled, parameters are also transferred to slaves with different Ether-CAT revisions. If an incompatible revision of a slave is connected, incorrect parameters may be set and operation may not be correct. If you disable the revision check, make sure that only compatible slaves are connected before transferring the parameters.



Additional Information

Network Configuration Verification

The network configuration information is verified against the actual network when the EtherCAT master is started. If an inconsistency is found during verification, the system-defined variable for a Network Configuration Verification Error provides notification. This setting applies to the entire system and not to individual slaves.

Verified information	Required/optional	Description
Number of slaves connected	Required	Number of slaves in the network
Vender ID	Required	Vendor ID of each slave
Product code	Required	Product code of each slave
Revision	Optional*1	Revision number of each slave
Serial number	Optional*1*2	Serial numbers of all slaves

^{*1} Options are selectable.


^{*2} Serial number verification is performed for all slaves in the EtherCAT topology. You cannot specify verification for individual slaves. The default setting is No check .

5-4-2 Setting EtherCAT Slaves

1 Double-click EtherCAT under Configurations and Setup on the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit*.



2 Select an EtherCAT slave that is displayed in the Edit Pane.



The EtherCAT slave settings are listed below.

Name	Editing	Remarks
Device name	OK	Displays the name of the slave.
		Default setting: E*** (where * is a serial number starting from 001)
		The default value is automatically generated based on the node address.
		Setting range: 1 to 192
Model	Not allowed.	Automatically displays the name of the slave model.
Product name	Not allowed.	Displays the product name of the slave.
Revision	Not allowed.	Displays the revision of the slave.

Name	Editing	Remarks
Node Address	ОК	Sets the node address.
		The default value is set automatically when a slave is added.
		Setting range: 1 to 192
Enable/Disable Settings	OK	Enables or disables the slave as a communications target.
		Enabled: The slave will operate.
		Disabled: The slave will not operate.*
		Set the following slaves as disabled slaves: slaves that are not installed on the physical EtherCAT network but are scheduled for addition at a later date or slaves that are not used due to changes in the device configuration during system operation.
		Even for disabled slaves, process data allocations can be set and used as system-defined variables and device variables in the user program.
		Default setting: Enabled
Serial Number	Not	Displays the serial number of the slave.
	allowed.	Default: 0x00000000 (when offline)
		The value is updated to the serial number of the physical slave when you select <i>Get Slave Serial Numbers</i> from the menu for the master.
		A Network Configuration Verification Error occurs if the serial number on the Sysmac Studio and the serial number of the physical slave do not agree when the Serial Number Check Method in the master settings is set to Setting = Actual device.
		Refer to 5-5-3 Using the Sysmac Studio to Obtain Serial Numbers from the Actual Network Configuration for how to access the serial number of the physical slave.
PDO Map Settings	OK	Default allocations of process data for slaves are provided by the Sysmac Studio.
		When the network configuration is created, device variables are automatically created in the initial process data allocations. You can read and write these process data allocations as device variables from the user program.
		When valid PDOs are present, a list of them is displayed. When valid PDOs are not present, "" is displayed.
		If editing the process data allocations is required, click the Edit PDO Map settings Button at the bottom of the list. Refer to 5-3-1 Registering Device Variables for All EtherCAT Slaves for details.
Enable Distributed Clock	OK	If a slave provides a distributed clock, Enabled is displayed.
		You can also disable the distributed clock.
		If a slave provides a distributed clock and you can disable it, either <i>Enabled</i> or <i>Disabled</i> is displayed.
		If the distributed clock is enabled, you can select the synchronization timing (Sync0 or Sync1) for some slaves. If Sync0 is selected, <i>Enabled (DC Sync0)</i> is displayed.
		If a slave does not provide a distributed clock, is displayed.

Name	Editing	Remarks
Reference Clock	Not allowed.	Displays whether the slave provides a reference clock. If there is more than one slave in the system with an enabled distributed clock, there must be a slave that provides a reference clock before the first Junction Slave. "Exist" is displayed if the slave provides a reference clock. "Not exist" is displayed if the slave does not provide a reference clock.
Setting Parameters	OK	If a slave has an initial parameter setting function, <i>Setting</i> is displayed.
		If a slave does not have an initial parameter setting function, "" is displayed.
		To edit the settings, click the Edit Setting Parameters Button.
Backup Parameter Settings	OK	If a slave has a backup parameter setting function, Setting is displayed.
		If a slave does not have a backup parameter setting function, "" is displayed.
		To edit the settings, click the Edit Backup Parameter Settings Button.

^{*} Network errors do not occur even if disabled slaves are not present on the EtherCAT network. You can use them to prepare for future system expansions or to operate without them for the current system. You can execute a special instruction to enable a disabled slave during system operation. You can also execute the special instruction to disable a slave during system operation. When a slave is present in the position of a disabled slave in the actual network configuration, operations occur as shown in the following table. Refer to 9-1-1 How to Check for Errors for the behavior of enabled slaves.

		I network con- ation	Operation for disabled slave				
	Node address	Vendor ID/product code	Message communica- tions	Process data communications	Error	Backup, restore, and compare operations	
1	Matches	Matches	Performed	Not performed	Normal opera- tion (no error)	Performed	
2	Matches	Different	Not performed	Not performed	Network Configuration Verification Error	Not performed	
3	Different	Matches	Not performed	Not performed	Network Con- figuration Veri- fication Error	Not performed	
4	Different	Different	Not performed	Not performed	Network Con- figuration Veri- fication Error	Not performed	



Version Information

A CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher are required to disable EtherCAT slaves with the special instruction.

EtherCAT Slave Enable/Disable Settings

Relation between Enable/Disable Settings and Instruction Settings

The following table gives the relation between the enable/disable setting of an EtherCAT slave and the results of instruction execution.

EtherCAT slave setting	Instruction setting	Result
Enabled	Enable	Enabled (normal end)
	Disable	Disabled
Disabled and slave physically	Enable	Enabled
exists*1, *2	Disable	Disabled (normal end)
Disabled with no physical slave connected to network	Enable or disable	Error (error end)

- *1 Even if a slave physically exits, it cannot be enabled or disabled if there are any of the following
 - If there is a Network Configuration Information Error or Network Configuration Error in the master.
 - If the slave does not have a current software connection to the network or if it has a Slave Initialization Error, Process Data Communications Error, or Slave Application Error.
- *2 If a slave is disabled (either with or without a physical slave), you cannot disconnect the slaves.



Precautions for Correct Use

If you use the special instruction to change the enable/disable setting of a slave, the change is lost when the power supply to the master is turned OFF. The status that was set from the Sysmac Studio is used the next time the power supply is turned ON. To change this setting, you must change the setting from the Sysmac Studio and then transfer the network configuration information to the built-in EtherCAT master in the NJ-series CPU Unit.

• Relation between Changes in the Enable/Disable Setting and I/O Operations

The I/O operations that occur for changes in the enable/disable settings of an EtherCAT slave are given in the following table.

	Inpu	uts	Outputs		
Change in status	Input refresh val- ues	Device variable values	Device variable values	Output refresh values	
Disabled slaves after turning ON the power supply or transferring the EtherCAT network configuration infor- mation	Input refreshing is performed but not applied to the device variables.	0 or FALSE	Depends on results of user program execution.	Output refreshing is not performed.	
Slaves changed from disabled to enabled	Input refreshing is performed.	Input refresh values are applied.	Depends on results of user program execution.	The values of the device variables are output.	
Slaves changed from enabled to dis- abled	Input refreshing is performed but not applied to the device variables.	The values from before the status of the slave was changed are retained.	Depends on results of user program execution.	Depends on the settings of the slave and slave models. GX-series EtherCAT Slaves output values according to the Output Hold/Clear at Setting Communications Error Setting in each slave.	




Precautions for Correct Use


For a slave that changed from enabled to disabled, the values of the device variables from before the change are retained.

Use the following processing to confirm if a slave is enabled or disabled.

(1) Confirm that the slave is enabled before you access the device variables of the input device.



(2) If the input device is disabled, always write the value of the device variable.




Comparing and Merging EtherCAT **5-5 Network Configurations**

Comparing and Merging with the Actual Network Configuration 5-5-1 from the Sysmac Studio

Use the Sysmac Studio to compare the network configuration information settings in the Sysmac Studio with the actual network configuration that is connected, including branch lines and branch locations. The following items are compared.

- Node addresses
- Vendor IDs
- Product codes
- Revisions
- Connected ports

If the settings in the Sysmac Studio and the actual network configuration match completely, it is possible to determine the locations of errors when they occur. If differences are shown in the comparison results, merge the configurations from the Sysmac Studio.




Use the following procedure to compare and merge the network configuration settings on the Sysmac Studio and the actual network configuration.

- Start the Sysmac Studio and go online with the Controller.
- Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, rightclick EtherCAT under Configurations and Setup and select Edit.




The Edit Pane is displayed.


3 Right-click the EtherCAT master that is displayed in the Edit Pane and select *Compare and Merge with Actual Network Configuration*.



The Compare and Merge with Actual Network Configuration Dialog Box is displayed. The results of comparing the settings on the Sysmac Studio with the actual network configuration are displayed in the *Comparison results* Column.




4 If there is a slave that exists only on the actual network, "Added" is displayed in the Comparison results Column. Drag the slave in the actual network configuration to the Sysmac Studio network configuration.



After you drag the missing slaves and add them to the network configuration on the Sysmac Studio, the Comparison results Column will show that everything in the configurations matches.

5 Click the **Close** Button.



The Sysmac Studio returns to the Edit Pane. This completes the operation to compare and merge with the actual network configuration.

"Removed" is displayed in the Comparison results Column for a slaves that exist only in the settings on the Sysmac Studio. The following example shows a case where a node address is different in the settings on the Sysmac Studio and in the actual network configuration. As a result, "Added" and "Removed" are displayed in the *Comparison results* Column.



Here, either correct the node address in the network configuration on the Sysmac Studio or the node address in the physical slave in the actual network configuration, and then repeat the compare and merge operation to confirm that the configurations are the same.



Additional Information

- Make sure that the communications cables between the master and slaves are connected correctly before you perform the compare and merge operation. The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if the connections are not correct.
- The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if there is a slave in the actual network configuration for which the node address is not set or if the same address is set for more than one slave in the actual network configuration. Make sure that node addresses are set correctly for the slaves in the actual network configuration before you perform the compare and merge operation.
- When the compare and merge operation is performed, the synchronization between the Sysmac Studio and the Controller is lost. Synchronize the Sysmac Studio and Controller before you perform any online operations for the slaves. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on synchronization.


5-5-2 Automatically Creating the Network Configuration

Instead of manually setting the network configuration offline, you can also automatically create the network configuration on the Sysmac Studio based on the actual network configuration. Use the following procedure to automatically duplicate the actual network configuration on the Sysmac Studio.

- Start the Sysmac Studio and go online with the Controller.
- 2 Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select Edit.




Right-click the EtherCAT master that is displayed in the Edit Pane and select Compare and Merge with Actual Network Configuration.




The Compare and Merge with Actual Network Configuration Dialog Box is displayed.

Click the Apply actual network configuration Button.



The actual network configuration is duplicated in the network configuration on Sysmac Studio, and the Comparison results Column shows that everything in the configurations matches. (The network configuration on the Sysmac Studio is created based on the actual network configuration.)

Click the Close Button.



6 Go offline, and then assign device variables, set the axis parameters, set up the tasks, and set the master and slave parameters.



Additional Information

- Make sure that the communications cables between the master and slaves are connected correctly before you perform this operation. The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if the connections are not correct.
- The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if
 there is a slave in the actual network configuration for which the node address is not set or if
 the same address is set for more than one slave in the actual network configuration. Make
 sure that node addresses are set correctly for the slaves in the actual network configuration
 before you perform this operation.
- Even if you have previously set them on the Sysmac Studio, the following configuration and settings are discarded when you automatically create the network configuration on the Sysmac Studio based on the actual network configuration: network configuration, master settings, and any slave settings (including enable settings, PDO map settings, setting parameter settings, backup parameter settings, device variable assignments in the I/O map, slave assignments to Axes Variables registered in the axis settings, and master settings to control slaves that are registered in the task setup). To merge the actual network configuration information without losing the current settings in the Sysmac Studio, use the compare and merge operation to create the network configuration. Refer to 5-5-1 Comparing and Merging with the Actual Network Configuration from the Sysmac Studio for information on the operation to compare and merge with the actual network configuration on the Sysmac Studio.
- When the compare and merge operation is performed, the synchronization between the Sysmac Studio and the Controller is lost. Synchronize the Sysmac Studio and Controller before you perform any online operations for the slaves. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on synchronization.


5-5-3 Using the Sysmac Studio to Obtain Serial Numbers from the **Actual Network Configuration**

If the Serial Number Check Method in the EtherCAT master settings is set to Setting = Actual device, you must download the network configuration information in which the slave serial numbers are set to the CPU Unit. Use the following procedure to get the serial numbers of the physical slaves and apply them as the serial numbers of the slaves in the settings on the Sysmac Studio.

- Start the Sysmac Studio and go online with the Controller.
- Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, rightclick EtherCAT under Configurations and Setup and select Edit.



Right-click the EtherCAT master that is displayed in the Edit Pane and select Get Slave Serial Numbers.



The serial numbers of the physical slaves are saved as the serial numbers in the slave settings on the Sysmac Studio.



Additional Information


- Make sure that the communications cables between the master and slaves are connected correctly before you perform this operation. You cannot get the serial numbers of the slaves unless the connections are correct.
- You cannot get the serial numbers of the slaves if there is a slave in the actual network configuration for which the node address is not set or if the same address is set for more than one slave in the actual network configuration. Make sure that node addresses are set correctly for the slaves in the actual network configuration before you perform this operation.
- You cannot get the serial numbers of the slaves unless the Compare and Merge with Actual Network Configuration Dialog Box shows that the entire slave configurations agree. Make sure that the Compare and Merge with Actual Network Configuration Dialog Box shows that the entire slave configurations agree before you perform this operation. However, you can get the serial numbers of the slaves even if the entire slave configurations do not agree if there are slaves in the Sysmac Studio settings that are disabled.
- If you get the serial numbers of the slaves when there are disabled slaves that do not exist in the actual network configuration, the serial numbers of the disabled slaves will be cleared to 0x00000000 in the settings on the Sysmac Studio. If the disabled slaves exist in the actual network configuration, the serial numbers of the slaves in the actual network configuration are saved in the settings on the Sysmac Studio.
- Any serial numbers that are set for slaves in the settings on the Sysmac Studio are overwritten
 when the serial numbers are obtained from the actual network configuration. Make sure that it
 is OK to overwrite the serial numbers on the Sysmac Studio before you perform this operation.
- When you get the serial numbers from the slaves on the actual network configuration, the synchronization between the Sysmac Studio and the Controller is lost. Synchronize the Sysmac Studio and Controller before you perform any online operations for the slaves. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on synchronization.

5-6 Downloading the Network Configuration Information

Downloading the Network Configuration Information from the 5-6-1 **Sysmac Studio**


You must download the network configuration information in the project from the Sysmac Studio to the NJ-series CPU Unit. Use the synchronize operation to download the network configuration information. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on synchronization.

Go online and select **Synchronization** from the Controller Menu.



The Synchronization Dialog Box is displayed.

Select the EtherCAT Check Box in the Synchronization Dialog Box and then click the Transfer to Controller Button.



The network configuration information is downloaded from the Sysmac Studio to the Controller.



Precautions for Safe Use

After you transfer the user program, the CPU Unit is restarted and communications with the EtherCAT slaves are cut off. During that period, the slave outputs behave according to the slave specifications.

The time that communications are cut off depends on the EtherCAT network configuration. Before you transfer the user program, confirm that the system will not be adversely affected.



Precautions for Correct Use

Use the Synchronization Menu of the Sysmac Studio to upload and download the project.



Additional Information

The backup parameters of EtherCAT slaves are out of the scope of synchronization and are not downloaded to the slaves for the default settings. To transfer the backup parameters, clear the selection of the *Do not transfer Special Unit parameters and backup parameters of EtherCAT slaves (out of synchronization scope)*. Check Box in the Synchronization Pane.

Confirming Communications after 5-7 **Completing EtherCAT Configuration** and Settings

If normal network configuration information is downloaded to the CPU Unit, EtherCAT communications start automatically regardless of the operating mode of the CPU Unit.

EtherCAT communications are in operational state (normal communications state) if the EtherCAT NET RUN indicator on the front of the NJ-series CPU Unit is lit green.

Refer to 9-2-3 Resetting Errors if the EtherCAT NET RUN indicator is not lit green.

If network configuration information is not downloaded to the CPU Unit, the EtherCAT master will not perform process data communications. Because of this, notification of errors will not occur. The Ether-CAT communications will be in the Init state (where both process data communications and SDO communications are disabled).

You can check from the user program to see if I/O refreshing is normal by checking the system-defined variable _EC_PDSlavTbl (Process Data Communicating Slave Table).



Precautions for Safe Use

- EtherCAT communications are not always established immediately after the power supply is turned ON. Use the system-defined variable in the user program to confirm that communications are established before you attempt to control device variables and Axis Variables.
- After you change any EtherCAT slave or Special Unit settings, carefully check the safety of the controlled system before you restart the Unit.



Precautions for Correct Use

When you change the EtherCAT slave configuration and reconfigure the axis allocation settings, you must download the network configuration information again.



Process Data Communications and SDO Communications

This section describes the timing of communications, response times, and special instructions for process data communications and SDO communications. It also provides sample programming.

6-1	Proces	ss Data Communications (PDO Communications) 6-2
	6-1-1	Allocated Variables for Process Data Communications 6-2
	6-1-2	Sample Programming 6-4
	6-1-3	Process Data Communications Timing 6-8
	6-1-4	System Response Time in Process Data Communications 6-9
	6-1-5	I/O Operations for Major Fault Level Controller Errors and I/O Refreshing with
		Specified Values 6-10
6-2	SDO C	communications
		• • • • • • • • • • • • • • • • • • • •
_	6-2-1	EtherCAT Instructions
-		
	6-2-1	EtherCAT Instructions 6-13
	6-2-1 6-2-2	EtherCAT Instructions
6-3	6-2-1 6-2-2 6-2-3 6-2-4	EtherCAT Instructions

Process Data Communications (PDO 6-1 **Communications)**

Process data communications cyclically exchanges data between the master and slaves in the process data communications cycle (i.e., the task period of primary periodic task).

From the user program in the NJ-series CPU Unit, slave data is accessed through allocated variables.

6-1-1 Allocated Variables for Process Data Communications


The variables that are allocated depend on the slave type as shown in the following table.

Slave type	Allocated variables	Operation in Sysmac Studio
EtherCAT slaves	Device variables	I/O Map
Only Servo Drive and encoder input slaves	Axis Variables (structures)	Axis Settings

Allocated variables are specified for instructions in the user program.

All EtherCAT Slaves

The user program in an NJ-series CPU Unit can read and write EtherCAT slave process data by reading and writing device variables. (The slave process data is I/O data that is exchanged between the master and slaves in each period.)




Only Servo Drive and Encoder Input Slaves

Servo Drive and encoder input slave on EtherCAT can be controlled by specifying Axis Variables (structures) as parameters for motion control instruction in-out variables.

Axis Variables (structures) consist of the following data.

- Parameters: Maximum acceleration rate, software limits, etc.
- I/O: Home proximity input, Servo ON, etc.
- Operating status: Accelerating, waiting for in-position state, etc.

• Error and warning status: Excessive following error, acceleration error, etc.



Sample Programming 6-1-2

Individual Interlocks

This sample programs individual interlocks to check the validity of the process data from each slave. The _EC_PDSlavTbl[1..192] (Process Data Communicating Slave Table) system-defined variables are used to see if the process data inputs and outputs are valid for the relevant slave (slave 1). LD

```
EQ
 _EC_PDSlavTbl[1] _EC_CommErrTbl[1]
                                                                                                    Slave_1_outputs_valid
                                                      ΕN
                                                      ln1
                                  _EC_SlavErrTbl[1]-
                                   WORD#16#0000-
                                                      ln2
                                                                                 _EC_InDataInvalid
                                                                                                   Slave_1_inputs_valid
Slave 1 inputs
                                                                                                    E001_Out_Bit07
 Slave_1_inputs_valid
                        E001_In_Bit00
Slave 1 outputs
                                                                                                    E001_Out_Bit00
 Slave_1_outputs_valid
```

```
IF _EC_PDSlavTbl[1]=TRUE AND _EC_CommErrTbl[1]=FALSE AND
_EC_SlavErrTbl[1]=WORD#16#0 THEN
  A:=TRUE;
 ELSE
  A:=FALSE;
 END_IF;
(* Output valid condition *)
IF A=TRUE THEN
   Slav_Out:=TRUE;
 ELSE
  Slav_Out:=FALSE;
 END_IF;
(* Input valid condition *)
IF A=TRUE AND InDataInvalid=FALSE THEN
  Slav_In:=TRUE;
 ELSE
  Slav_In:=FALSE;
 END_IF;
(* Output data valid *)
IF Slav_Out=TRUE THEN
  E001_Out_Bit00:=TRUE;
 ELSE
  E001_Out_Bit00:=FALSE;
 END_IF;
(* Input data valid *)
IF Slav_In=TRUE AND E001_In_Bit00=TRUE THEN
  E001_Out_Bit07:=TRUE;
 ELSE
  E001_Out_Bit07:=FALSE;
 END_IF;
```

ST



Precautions for Safe Use

If noise occurs or an EtherCAT slave is disconnected from the network, any current communications frames may be lost. If frames are lost, slave I/O data is not communicated, and unintended operation may occur. The slave outputs behave according to the slave specifications. For details, refer to relevant manuals for each slave. If a noise countermeasures or slave replacement is required, perform the following processing.

- Program the _EC_InDataInvalid (Input Data Disable) system-defined variable as an interlock condition in the user program.
- Set the PDO communications timeout detection count setting in the EtherCAT master to at least 2. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.



Additional Information


You can read the status of the _EC_PDSlavTbl[1..192] (Process Data Communicating Slave Table) system-defined variables from the user program to see if I/O refreshing is normal.

Overall Interlock

This sample programs an interlock to check the validity of the process data from all of the slaves that are connected to the network.

The EC PDActive (Process Data Communications Status) system-defined variable is used to see if the process data inputs and outputs are valid for all of the slaves.

LD



```
IF _EC_PDActive=TRUE AND _EC_SlavErr=WORD#16#0 THEN
  A:=TRUE;
 ELSE
  A:=FALSE;
 END IF;
(* Output valid condition *)
IF A=TRUE THEN
  AllSlav_Out:=TRUE;
 ELSE
  AllSlav_Out:=FALSE;
 END_IF;
(* Input valid condition *)
IF A=TRUE AND InDataInvalid=FALSE THEN
  AllSlav_In:=TRUE;
 ELSE
  AllSlav_In:=FALSE;
 END_IF;
(* Output data valid *)
IF ALLSlav_Out=TRUE THEN
  E002_Out_Bit00:=TRUE;
 ELSE
  E002_Out_Bit00:=FALSE;
 END_IF;
(* Input data valid *)
IF ALLSlav_In=TRUE AND E002_In_Bit00=TRUE THEN
  E002_Out_Bit07:=TRUE;
 ELSE
  E002_Out_Bit07:=FALSE;
 END_IF;
```

ST



Precautions for Safe Use


If noise occurs or an EtherCAT slave is disconnected from the network, any current communications frames may be lost. If frames are lost, slave I/O data is not communicated, and unintended operation may occur. The slave outputs behave according to the slave specifications. For details, refer to relevant manuals for each slave. If a noise countermeasures or slave replacement is required, perform the following processing.

- Program the _EC_InDataInvalid (Input Data Disable) system-defined variable as an interlock condition in the user program.
- Set the PDO communications timeout detection count setting in the EtherCAT master to at least 2. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.

6-1-3 **Process Data Communications Timing**

The EtherCAT communications cycle is the same as period of the primary periodic task for sequence control. It is also the same as the motion control period.

The relationships between sequence processing, motion control processing, and data exchange in EtherCAT communications are shown below.




Primary periodic task period = Motion control period = Process data communications cycle

6-1-4 System Response Time in Process Data Communications

Standard Synchronization Timing

Here, sequence control and motion control are performed within the task period of the primary periodic task in which EtherCAT communications were refreshed.



^{*} Process data communications cycle = Primary period

System maximum input and output response time = Primary period (i.e., the process data communications cycle) x 2 + Slave input response time + Slave output response time

- (1) Sensor and other inputs are input to the slave.
- (2) Signals are detected by the slave after the input response time.
- (3) Process data is transmitted from the slave to the EtherCAT communications line.
- (4) The EtherCAT master reads (refreshes) the data and passes it to the PLC Function Module.
- (5) Sequence processing is performed by the CPU Unit based on the input data. When a motion control instruction is executed, the Motion Control Function Module is asked to perform the processing, and the motion control processing is performed.
- (6) Output data is determined and the send frame is generated.
- (7) There is wait time during the primary period.
- (8) On the scheduled trigger, the frame is transmitted to the EtherCAT communications line.
- (9) Signals are input to the slave.
- (10) Signals are output after the output response time.



Additional Information

If there is excessive communications jitter, a Process Data Transmission Error (a Controller error in the minor fault level) occurs. This error is recorded in the event log.

- If the fail-soft operation is set to stop operation, the EtherCAT master will change to the preoperational state and process data communications will stop.
- If the fail-soft operation is set to fail-soft operation, the EtherCAT master will remain in operational state and process data communications will continue.


In either case, the _EC_PDSendErr (Process Data Send Error) system-defined variables will change to TRUE.

If this happens, increase the task period of the primary periodic task and execute communications again.


6-1-5 I/O Operations for Major Fault Level Controller Errors and I/O **Refreshing with Specified Values**

I/O Operations for Major Fault Level Controller Errors

If the NJ-series CPU Unit detects a major fault level Controller error, all slave outputs will retain the process data values from before operation stopped in Operational state. Then the slaves will gradually move to Safe-operational state and the slave settings will control the slave outputs. The process data is still acquired for the slave inputs.*




When a major fault level Controller error occurs, the values of the variables are not output to the slaves even if they are initialized. The slave settings will control the slave outputs.



* If there are 192 slaves connected, the maximum time required for all outputs to be controlled by the slave settings (i.e., the time to enter Safe-operational state) is the communications cycle multiplied by 20 plus the slave Safeoperational state transition time (10 ms max. or OMRON slaves).

Forced Refreshing

You can specify forced refreshing from the Sysmac Studio for debugging. This allows you to change process data output values to the slaves and input values from the slaves to the values that you specify in advance.



Relationship between Major Fault Level Controller Errors, Normal Operation, and Forced Refreshing

Forced refreshing functions as shown in the following table for major fault level Controller errors and for normal operation.

Condition		Major fault level controller error*	Normal operation	
Forced refreshing	Enabled	Output data: Values from before operation stopped (Operational state). Slave settings control the outputs (Safe-operational state).	Output data: Forced refreshing values Input data: Forced refreshing values	
	Disabled	Input data: Process data Output data: Values from before operation stopped (Operational state).	Output data: Process data Input data: Process data	
		Slave settings control the outputs (Safe-operational state). Input data: Process data		

^{*} If a major fault level Controller error occurs, the output values from before operation stopped are retained while the slaves are in Operational state and the slave settings control the outputs after the slaves enter Safe-operational state.



Precautions for Safe Use

- You can select whether the master continues or stops communications with all slaves when a communications error occurs. Refer to 5-4-1 Setting EtherCAT Master for details.
- · If noise occurs or an EtherCAT slave is disconnected from the network, any current communications frames may be lost. If frames are lost, slave I/O data is not communicated, and unintended operation may occur. The slave outputs behave according to the slave specifications. For details, refer to relevant manuals for each slave. If a noise countermeasures or slave replacement is required, perform the following processing.
 - Program the _EC_InDataInvalid (Input Data Disable) system-defined variable as an interlock condition in the user program. Refer to 6-1-2 Sample Programming.
 - Set the PDO communications timeout detection count setting in the EtherCAT master to at least 2. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.
- If a communications error prevents the slaves from receiving signals from the master, the slave settings will control the slave outputs. During the time that is required to change from normal operation to a communications error status, frames will be lost. The outputs for lost frames are different for synced slaves (Servo Drives and encoders) and non-synced slaves. The slave settings will control the slave outputs for synced slaves. The previous values are retained for the slave outputs for non-synced slaves.

	Normal operation	Frames lost	Communications error status
Outputs from synced slaves (Servo Drives and encoders)	Controlled by the values of device variables.	Controlled by the slave settings.	Controlled by the slave settings.
Outputs from non-synced slaves	Controlled by the values of device variables.	The previous values are output.	Controlled by the slave settings.

For details, refer to relevant manuals for each slave.



Additional Information

You can check from the user program to see if I/O refreshing is normal by checking one of the system-defined variables _EC_PDSlavTbl[1..192] (Process Data Communicating Slave Table).

6-2 SDO Communications

SDO communications are performed by using EtherCAT instructions to access SDO data in slaves when required.

6-2-1 EtherCAT Instructions

You can perform the following SDO communications with EtherCAT instructions.

· Reading and writing of SDO data

Reading and Writing SDO Data

Function	Instruction	Description
CoE messages (Read CoE SDO)	EC_CoESDORead	You set parameters to read data from the slave's object dictionary (SDO data).
CoE messages (Write CoE SDO)	EC_CoESDOWrite	You set parameters to write data to the slave's object dictionary (SDO data).

6-2-2 Sample Programming

This sample uses an EtherCAT SDO message to read the software version of an OMRON V1.02 R88D-KN01L-ECT Servo Drive. The node address of the slave is 1.

The object index for the software version is 16#100A. The subindex is 0. The read value is stored in STRING variable *VersionInfo*.




Built-in EtherCAT port

LD

Internal Variables	Variable	Data type	Initial value	Comment
	Trigger	BOOL	False	Execution condition
	SdoObject	_sSDO_ACCESS	(Index:=0, Subindex:=0,	SDO parameter
			IsCompleteAccess:=False)	
	VersionInfo	STRING[256]	ø	Read data
	EC_CoESDORead_instance	EC_CoESDORead		

External Variables	Variable	Data type	Constant	Comment
	_EC_MBXSlavTbl	ARRAY[1192] OF BOOL		Message Communications Enabled Slave Table



ST

Internal Variables	Variable	Data type	Initial value	Comment
	Trigger	BOOL	False	Execution condition
	SdoObject	_sSDO_ACCESS	(Index:=0, Subindex:=0,	SDO parameter
			IsCompleteAccess:=False)	
	DoSdoRead	BOOL	False	Processing
	VersionInfo	STRING[256]	ø	Read data
	NormalEnd	UINT	0	Normal end
	ErrorEnd	UINT	0	Error end
	EC_CoESDORead_instance	EC_CoESDORead		

External Variables	Variable	Data type	Constant	Comment
	_EC_MBXSlavTbl	ARRAY[1192] OF BOOL		Message Communications Enabled Slave Table

```
// Detect when Trigger changes to TRUE.
IF ( (Trigger=TRUE) AND (DoSdoRead=FALSE) AND (_EC_MBXSlavTbl[1]=TRUE) ) THEN
  DoSdoRead
                             :=TRUE;
   SdoObject.Index
                             :=UINT#16#100A;
  SdoObject.Subindex
                             :=USINT#0;
   SdoObject.IsCompleteAccess:=FALSE;
  EC_CoESDORead_instance(
      Execute:=FALSE,
                               // Initialize instance.
     ReadDat:=VersionInfo);
                               // Dummy
END_IF;
// Execute EC CoESDORead instruction.
IF (DoSdoRead=TRUE) THEN
  EC_CoESDORead_instance(
     Execute :=TRUE,
                               // Node address 1
     NodeAdr :=UINT#1,
                               // SDO parameter
     SdoObj :=SdoObject,
                               // Timeout time: 2.0 s
     TimeOut :=UINT#20,
                               // Read data
     ReadDat:=VersionInfo);
  IF (EC_CoESDORead_instance.Done=TRUE) THEN
     // Processing after normal end
     NormalEnd:=NormalEnd+UINT#1;
  ELSIF (EC_CoESDORead_instance.Error=TRUE) THEN
     // Processing after error end
     ErrorEnd :=ErrorEnd+UINT#1;
  END_IF;
END_IF;
```

6-2-3 Execution Timing of SDO Communications

SDO communications are executed in the system service time of the NJ-series CPU Unit. System services are executed in the period between execution of all of the tasks.

Refer to the *NJ-series CPU Unit Software User's Manual* (Cat. No. W501) for details on the execution timing of system services.

6-2-4 Minimum Message Response Time for SDO Communications

The minimum message response time for SDO communications is the time from when the SDO communications instruction is executed in the user program until execution of the instruction is completed.


When the instruction is executed in the user program, the master sends a frame to the slave in the system service. When the slave receives the frame, it processes it. When the slave completes processing, the master receives a response from the slave to complete execution of the instruction.

Calculating the Minimum Message Response Time

Minimum message Task period + (Slave SDO processing time/Task period + 1*1) x Task period + (SDO response time = response data size/256 bytes + 1*2) x Task period + Task period

- *1 If the slave SDO processing time divides evenly by the task period, then "+1" is not required.
- *2 If the SDO response data size divides evenly by 256 bytes, then "+1" is not required.

The following timing chart shows an example of the timing from execution of the instruction for SDO message communications to the completion of instruction execution (i.e., until a response is received).



Performance Model Example

Task period (ms)	1
SDO size (bytes)	512
Slave SDO processing time (ms)	2
Message response time (ms)	6



Additional Information

The miminum message response time depends on the unused time in task execution, slave SDO size, and slave SDO processing time. The above timing chart is for reference only.

6-3 Instructions Used in EtherCAT Communications

6-3-1 EtherCAT Instructions

Function	Instruction	Description
Start EtherCAT Packet Monitor	EC_StartMon	Starts packet monitoring of the EtherCAT master built into the NJ-series CPU Unit.
Stop EtherCAT Packet Monitor	EC_StopMon	Stops packet monitoring of the EtherCAT master built into the NJ-series CPU Unit.
Save Packet Data File	EC_SaveMon	Saves captured data in a file in the system of the NJ- series CPU Unit. The packet monitor is a function of the EtherCAT master built into the NJ-series CPU Unit. The captured files in the system of the NJ-series CPU Unit are not retained when the power is inter- rupted.
Copy Packet Data File to SD Memory Card	EC_CopyMon	Copies the captured data that was saved in the system of the NJ-series CPU Unit to a file on an SD Memory Card. The captured data is previously saved from EtherCAT master built into the NJ-series CPU Unit into the system of the NJ-series CPU Unit. The files saved to an SD Memory Card are retained after the power is interrupted.
Disconnect EtherCAT Slave	EC_DisconnectSlave	Temporarily disconnects a slave from the EtherCAT network for maintenance, such as replacement of the slave.
Connect EtherCAT Slave	EC_ConnectSlave	Reconnects a temporarily disconnected slave to the EtherCAT network after maintenance, such as replacement of the slave.
Enable/Disable EtherCAT Slave	EC_ChangeEnableSetting	Enables or disables an EtherCAT slave.
Get EtherCAT Error Status	GetECError	Gets the status of Controller errors (partial faults or minor faults) that occur in the EtherCAT master and the highest-level event code for the current errors.
Reset EtherCAT Controller Error	ResetECError	Resets Controller errors in the EtherCAT master. (Execute this instruction only after eliminating the cause of the error.)

Note Refer to the *NJ-series Instructions Reference Manual* (Cat. No. W502) for details on the instructions that are used with EtherCAT communications.



Additional Information

"Enable/disable," "Connected/disconnected," and "physical slave/no physical slave" are defined as follows:

Enable/Disable Setting

This setting tells whether process data communications are performed for an EtherCAT slave. You can make this setting from the Sysmac Studio and you can change the setting with the EC_ChangeEnableSetting (Enable/Disable EtherCAT Slave) instruction.

Connected/Disconnected Setting

This setting is used to temporarily disconnect a slave from the network when the slave is replaced and then to connect the slave to the network again.

However, if an EtherCAT slave in a daisy-chain connection is disconnected, all of the slaves that are connected after it are disconnected. This point is different from the enable/disable setting.

 Physical Slave/No Physical Slave This indicates whether the EtherCAT slave is physically connected.

The following table shows how these states combine.

Enable/disable setting	Connected/discon- nected setting	Physical slave/no physical slave	Combined state
Enabled	Connected	Present	Present
		Not installed	None
			(You cannot connect a non-exiting slave to the network.)
	Disconnected	Present	Present
		Not installed	
Disabled		Present	Present
	(The concept of con- nected/disconnected does not apply if a slave is disabled.)	Not installed	



System-defined Variables That Are Related to the Built-in EtherCAT Port

This section describes the system-defined variables that are related to the built-in EtherCAT port.


7-1	System	n-defined Variables That Are Related to the Built-in EtherCAT Port	7-2
	7-1-1	What Are System-defined Variables?	7-2
	7-1-2	System-defined Variables	7-2
	7-1-3	EtherCAT Master Function Module, Category Name: _EC	7-6

System-defined Variables That Are 7-1 Related to the Built-in EtherCAT Port

What Are System-defined Variables? 7-1-1

System-defined variables are variables that are defined by the system for use with EtherCAT communications. These are provided in advance in the global variable table.

The user program can input status and set parameters for the EtherCAT master and slaves by reading and writing system-defined variables.



System-defined Variables 7-1-2

Functional Classification: EtherCAT Communications Errors

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_ErrSta	Built-in EtherCAT Error	This system-defined variable provides the collective status of errors in the EtherCAT Master Function Module.	WORD	16#0000 to 16#00F0	page 7-6
		Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.			
_EC_PortErr	Communications Port Error	This system-defined variable provides the collective status of errors in the communications ports for the EtherCAT master.	WORD	16#0000 to 16#00F0	page 7-6
		Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.			
_EC_MstrErr	Master Error	This system-defined variable provides the collective status of EtherCAT master errors and slave errors detected by the EtherCAT master.	WORD	16#0000 to 16#00F0	page 7-7
		Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.			

Variable name	Meaning	Function	Data type	Range of values	Reference	
_EC_SlavErr	Slave Error	This system-defined variable provides the collective status of all the error status for Ether-CAT slaves.	WORD	16#0000 to 16#00F0	page 7-7	
		Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.				
_EC_SlavErrTbl	Slave Error Table	This system-defined variable gives the error status for each EtherCAT slave. The error status is given for each slave in the actual system configuration. This variable array indicates slaves in which there are errors. Status is provided for each EtherCAT slave node address (1 to 192). Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.	ARRAY [1192] OF WORD	16#0000 to 16#00F0	page 7-7	
_EC_MacAdrErr	MAC Address Error	TRUE if there is an illegal MAC address.	BOOL	TRUE or FALSE	page 7-7	
_EC_LanHwErr	Communications Controller Error	TRUE if there is a communications controller hardware error.	BOOL	TRUE or FALSE	page 7-8	
_EC_LinkOffErr	Link OFF Error	TRUE if the communications controller link is not established.	BOOL	TRUE or FALSE	page 7-8	
_EC_NetCfgErr	Network Configuration Information Error	TRUE if there is illegal network configuration information.	BOOL	TRUE or FALSE	page 7-8	
_EC_NetCfgCmpErr	Network Configuration Verification Error	TRUE if the network configuration information does not match the actual network configuration.	BOOL	TRUE or FALSE	page 7-8	
_EC_NetTopologyErr	Network Configuration Error	TRUE if there is a network configuration error (too many devices connected or ring connection).	BOOL	TRUE or FALSE	page 7-8	
_EC_PDCommErr	Process Data Communications Error	TRUE if there is an unexpected slave disconnection or connection or if a slave WDT error is detected during process data communications.	BOOL	TRUE or FALSE	page 7-8	
_EC_PDTimeoutErr	Process Data Reception Timeout	TRUE if a timeout occurs while receiving process data.	BOOL	TRUE or FALSE	page 7-9	
_EC_PDSendErr	Process Data Transmission Error	TRUE if there is a process data transmission error (cannot send within the process data communications cycle or transmission jitter is over the limit).	BOOL	TRUE or FALSE	page 7-9	
_EC_SlavAdrDupErr	Slave Node Address Duplicated Error	TRUE if the same node address is set for more than one slave.	BOOL	TRUE or FALSE	page 7-9	
_EC_SlavInitErr	Slave Initialization Error	TRUE if there is an error in an initialization command addressed to a slave.	BOOL	TRUE or FALSE	page 7-9	
_EC_SlavAppErr	Slave Application Error	TRUE if there is an error in the slave's application status register.	BOOL	TRUE or FALSE	page 7-9	
_EC_MsgErr	EtherCAT Message Error	TRUE when a message is sent to a slave that does not support messages or when there is an error in the format of the response to a message that was sent to a slave.	BOOL	TRUE or FALSE	page 7-9	
_EC_SlavEmergErr	Emergency Message Detected	TRUE if the master detects an emergency message that was sent by a slave.	BOOL	TRUE or FALSE	page 7-10	
_EC_CommErrTbl	Communications Error Slave Table	Slaves are given in the table in the order of slave node addresses. The corresponding slave element is TRUE if the master detected an error for the slave.	ARRAY [1192] OF BOOL	TRUE or FALSE	page 7-10	



Additional Information

Typical Relationships for the Built-in EtherCAT Error Flags

Variable Name	Meaning	Variable Name	Meaning	Variable Name	Meaning	Event level		
_EC_ErrSta	Built-in	_EC_PortErr	Communi-	_EC_MacAdrErr	MAC Address Error	Partial fault		
	EtherCAT Error		cations Port Error	_EC_LanHwErr	Communications Controller Error	level		
				_EC_LinkOffErr	Link OFF Error	Minor fault		
		_EC_MstrErr	Master Error	_EC_NetCfgErr	Network Configura- tion Information Error	level		
				_EC_NetCfgCmpErr	Network Configura- tion Verification Error			
				_EC_NetTopologyErr	Network Configura- tion Error			
				_EC_PDCommErr	Process Data Com- munications Error			
			_EC_PDTimeoutErr	Process Data Reception Timeout				
						_EC_PDSendErr	Process Data Trans- mission Error	
				_EC_SlavAdrDupErr	Slave Node Address Duplicated Error			
						_EC_SlavInitErr	Slave Initialization Error	
				_EC_SlavAppErr	Slave Application Error			
						_EC_CommErrTbl	Communications Error Slave Table	
				_EC_MsgErr	EtherCAT Message Error	Observation		
				_EC_SlavEmergErr	Emergency Message Detected			
		_EC_SlavErr	Slave Error	_EC_SlavErrTbl	Slave Error Table	Defined by the slave.		

Note The values of all system-defined variables that are related to errors in EtherCAT communications do not change until the cause of the error is removed and then the error in the Controller is reset with the troubleshooting functions of the Sysmac Studio or the ResetECError instruction.

• Functional Classification: EtherCAT Communications Status

Variable name	Meaning	Function	Data type	Range of values	Reference	
_EC_RegSlavTbl	Registered Slave Table	This table indicates the slaves that are registered in the network configuration information. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if the corresponding slave is registered.	ARRAY [1192] OF BOOL	TRUE or FALSE	page 7-10	
_EC_EntrySlavTbl	Network Connected Slave Table	This table indicates which slaves are connected to the network. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if the corresponding slave has entered the network.	ARRAY [1192] OF BOOL	TRUE or FALSE	page 7-10	
_EC_MBXSlavTbl	Message Communications Enabled Slave Table	This table indicates the slaves that can perform message communications. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if message communications are enabled for it (pre-operational, safe-operation, or operational state). Note Use this variable to confirm that message communications are possible for the relevant slave before you execute message communications with an	ARRAY [1192] OF BOOL	TRUE or FALSE	page 7-11	
		EtherCAT slave.				
_EC_PDSlavTbl	Process Data Communicating Slave Table	This table indicates the slaves that are performing process data communications. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if process data of the corresponding slave is enabled (operational) for both slave inputs and outputs. Note Use this variable to confirm that the data for the relevant slave is valid	ARRAY [1192] OF BOOL	TRUE or FALSE	page 7-11	
_EC_DisconnSlavTbl	Disconnected	before controlling an EtherCAT slave. Slaves are given in the table in the order of	ARRAY	TRUE or	page 7-11	
	Slave Table	slave node addresses. The element for a slave is TRUE if the corresponding slave was disconnected.	[1192] OF BOOL	FALSE	pago	
_EC_DisableSlavTbl	Disabled Slave Table	Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if the corresponding slave is disabled.	ARRAY [1192] OF BOOL	TRUE or FALSE	page 7-11	
_EC_PDActive	Process Data Communications Status	TRUE when process data communications are performed with all slaves*. * Disabled slaves are not included.	BOOL	TRUE or FALSE	page 7-12	
_EC_PktMonStop	Packet Monitoring Stopped	TRUE when packet monitoring is stopped.	BOOL	TRUE or FALSE	page 7-12	
_EC_LinkStatus	Link Status	TRUE if the communications controller link status is Link ON.	BOOL	TRUE or FALSE	page 7-12	
_EC_PktSaving	Saving Packet Data File	Shows whether a packet data file is being saved. TRUE: Packet data file being saved. FALSE: Packet data file not being saved.	BOOL	TRUE or FALSE	page 7-12	
_EC_InDataInvalid	Input Data Disabled	TRUE when process data communications are not normal and the input data is not valid.	BOOL	TRUE or FALSE	page 7-12	

Note All system-defined variables that are related to the status of EtherCAT communications give the current status.

Meanings of Error Status Bits

The meanings of the individual bits in the above error status variables are given below.

Bit	Name	Description	Value	Meaning
15	Master Detection*1	This bit indicates whether the master	TRUE	Error
		detected an error in the slaves that it manages.	FALSE	No error
14	Slave Summary*2	Indicates whether there is an error at	TRUE	Error
		a level below the function module.	FALSE	No error
8 to 13	Not used.			
7	Major Fault	Indicates if there is a major fault level	TRUE	Error
		error.	FALSE	No error
6	Partial Fault	Indicates if there is a partial fault level	TRUE	Error
		error.	FALSE	No error
5	Minor Fault	Indicates if there is a minor fault level	TRUE	Error
		error.	FALSE	No error
4	Observation	Indicates if there is an observation	TRUE	Error
		level error.	FALSE	No error
0 to 3	Not used.		•	

^{*1} For the EtherCAT Master Function Module, only _EC_SlavErrTbl (Slave Error Table) is used.

7-1-3 **EtherCAT Master Function Module, Category Name: _EC**

• Functional Classification: EtherCAT Communications Errors

Variable name	_EC_ErrSta	_EC_ErrSta						
Meaning	Built-in EtherCAT	Error		Global/local	Global			
Function	This system-defin	ed variable provide	s the collective state	us of errors in the E	therCAT Master Function Module.			
	Refer to Meaning	Refer to Meanings of Error Status Bits provided above for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc-	Get EtherCAT Err	or Status				
		tions	GetECError					
			Reset EtherCAT Controller Error					
			ResetECError					

Variable name	_EC_PortErr	_EC_PortErr						
Meaning	Communications	Port Error		Global/local	Global			
Function	This system-defin- master.	This system-defined variable provides the collective status of errors in the communications ports for the EtherCAT master.						
	Refer to Meanings	Refer to Meanings of Error Status Bits provided above for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc-	Get EtherCAT Err	or Status				
		tions	GetECError					
			Reset EtherCAT Controller Error					
			ResetECError					

^{*2} For the EtherCAT Master Function Module, only _EC_ErrSta (Built-in EtherCAT Error) is used.

Variable name	_EC_MstrErr					
Meaning	Master Error			Global/local	Global	
Function	This system-defin by the EtherCAT r		s the collective stat	tus of EtherCAT master errors and slave errors detecte		
	Refer to Meanings	the error status bits.				
Data type	WORD	•		Range of values	16#0000 to 16#00F0	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible. Related instructions Get EtherCAT E GetECError Reset EtherCAT ResetECError					
	I 50 01 5					
Variable name	_EC_SlavErr			Clab of the section	Olahal	
Meaning	Slave Error			Global/local	Global	
Function		•			atus for EtherCAT slaves. the error status bits.	
Data type	WORD			Range of values	16#0000 to 16#00F0	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program		tions	GetECError Reset EtherCAT (ResetECError			
Variable name	_EC_SlavErrTbl			10	Lavis	
Meaning	Slave Error Table			Global/local	Global	
Meaning	Slave Error Table This system-defin The error status is This variable array address (1 to 192	s given for each sla / indicates slaves ir).	ve in the actual sys	ach EtherCAT slave tem configuration. rrors. Status is provi).	
Meaning Function	Slave Error Table This system-defin The error status is This variable array address (1 to 192	s given for each sla indicates slaves in). s of Error Status Bi	ve in the actual sys	ach EtherCAT slave tem configuration. rrors. Status is provi	ided for each EtherCAT slave node	
Variable name Meaning Function Data type R/W access	Slave Error Table This system-defin The error status is This variable array address (1 to 192 Refer to Meanings	s given for each sla indicates slaves in). s of Error Status Bi	ve in the actual sys	ach EtherCAT slave tem configuration. rrors. Status is prov	e. ided for each EtherCAT slave node the error status bits.	
Meaning Function Data type	Slave Error Table This system-defin The error status is This variable array address (1 to 192 Refer to Meanings Array [1192] OF	s given for each slaty indicates slaves in the slaves in t	ve in the actual sys n which there are en ts provided above fo	ach EtherCAT slave tem configuration. rrors. Status is provi or the meanings of t Range of values Network Publish or Status	ided for each EtherCAT slave node the error status bits.	
Meaning Function Data type R/W access Usage in user program	Slave Error Table This system-defin The error status is This variable array address (1 to 192 Refer to Meanings Array [1192] OF R Possible.	s given for each slave indicates slaves in indicates slaves in indicates slaves in set of Error Status Bit WORD Retained Related instruc-	Not retained. Get EtherCAT Error Reset EtherCAT C	ach EtherCAT slave tem configuration. rrors. Status is provi or the meanings of t Range of values Network Publish or Status	ided for each EtherCAT slave node the error status bits.	
Meaning Function Data type R/W access Usage in user program	Slave Error Table This system-defin The error status is This variable array address (1 to 192 Refer to Meanings Array [1192] OF R Possible. _EC_MacAdrErr	s given for each slave in indicates slaves in indicates indicates in	Not retained. Get EtherCAT Error Reset EtherCAT C	ach EtherCAT slave tem configuration. rrors. Status is provi or the meanings of t Range of values Network Publish or Status Controller Error	ided for each EtherCAT slave node the error status bits. 16#0000 to 16#00F0 Published.	
Meaning Function Data type R/W access Usage in user program Variable name Meaning	Slave Error Table This system-defin The error status is This variable array address (1 to 192 Refer to Meanings Array [1192] OF R Possible. _EC_MacAdrErr MAC Address Error	s given for each slave in indicates slaves slaves in indicates slaves slaves in indicates slaves in indicates slaves in indicates slaves slaves in indicates slaves slaves in indicates slaves slave	Not retained. Get EtherCAT Error Reset EtherCAT (Reset EtherCAT (Reset EtherCAT (ach EtherCAT slave tem configuration. rrors. Status is provi or the meanings of t Range of values Network Publish or Status	ided for each EtherCAT slave node the error status bits.	
Meaning Function Data type R/W access Usage in user program Variable name Meaning Function	Slave Error Table This system-defin The error status is This variable array address (1 to 192 Refer to Meanings Array [1192] OF R Possible. _EC_MacAdrErr MAC Address Error TRUE if there is a	s given for each slave in indicates slaves in indicates indicates in	Not retained. Get EtherCAT Error Reset EtherCAT (Reset EtherCAT (Reset EtherCAT (ach EtherCAT slave tem configuration. rrors. Status is provi or the meanings of t Range of values Network Publish or Status Controller Error	ided for each EtherCAT slave node the error status bits. 16#0000 to 16#00F0 Published. Global	
Meaning Function Data type R/W access	Slave Error Table This system-defin The error status is This variable array address (1 to 192 Refer to Meanings Array [1192] OF R Possible. _EC_MacAdrErr MAC Address Error	s given for each slave in indicates slaves slaves in indicates slaves slaves in indicates slaves in indicates slaves in indicates slaves slaves in indicates slaves slaves in indicates slaves slave	Not retained. Get EtherCAT Error Reset EtherCAT (Reset EtherCAT (Reset EtherCAT (ach EtherCAT slave tem configuration. rrors. Status is provi or the meanings of t Range of values Network Publish or Status Controller Error	ided for each EtherCAT slave node the error status bits. 16#0000 to 16#00F0 Published.	

Variable name	_EC_LanHwErr					
Meaning	Communications	Controller Error		Global/local	Global	
Function	TRUE if there is a	communications c	ontroller hardware	error.		
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions	Reset EtherCAT ResetECError	Controller Error		
	1					
Variable name	_EC_LinkOffErr					
Meaning	Link OFF Error			Global/local	Global	
Function		nunications controll	er link is not establ		Γ=	
Data type	BOOL		T	Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions	Reset EtherCAT ResetECError	Controller Error		
Variable name	_EC_NetCfgErr					
Meaning	Network Configura	ation Information E	rror	Global/local	Global	
Function	TRUE if there is il	legal network confi	guration information	n.		
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions	Reset EtherCAT ResetECError	Controller Error		
Variable name	_EC_NetCfgCmp	Err				
Meaning	Network Configura	ation Verification E	ror	Global/local	Global	
Function	TRUE if the netwo	ork configuration inf	ormation does not	match the actual network configuration.		
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions	Reset EtherCAT ResetECError	Controller Error		
Variable name	_EC_NetTopology	/Err				
Meaning	Network Configura	ation Error		Global/local	Global	
Function	TRUE if there is a	network configurat	ion error (too many	devices connected	or ring connection).	
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions	Reset EtherCAT ResetECError			
Variable name	_EC_PDCommEr	r				
Meaning		nmunications Error		Global/local	Global	
Function		n unexpected slave			ave WDT error is detected during pro-	
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instructions	Reset EtherCAT ResetECError	Controller Error		
	<u> </u>		I			

Variable name	_EC_PDTimeout	Err				
Meaning	Process Data Red	ception Timeout Err	or	Global/local	Global	
Function	TRUE if a timeout	occurs while receive	ving process data.			
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Controller Error		
		tions	ResetECError			
Variable name	_EC_PDSendErr			_		
Meaning	Process Data Tra	nsmission Error		Global/local	Global	
Function		process data trans ter is over the limit)	`	not send within the p	process data communications perior	
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Controller Error		
		tions	ResetECError			
	T 50 01 4 1 5	_				
Variable name	_EC_SlavAdrDup		_	01-1-1/	Olahari	
Meaning		ess Duplicated Erro		Global/local	Global	
Function		node address is se	et for more than on		T== ==	
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Jsage in user program	Possible.	Related instruc- tions	Reset EtherCAT	Controller Error		
	1		Reselection			
Variable name	EC SlavInitErr					
Meaning	Slave Initialization	Error		Global/local	Global	
Function	TRUE if there is a	n error in an initializ	zation command a	ddressed to a slave.		
Data type	BOOL			Range of values TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Controller Error		
		tions	ResetECError			
Variable name	_EC_SlavAppErr					
Meaning	Slave Application	Error		Global/local	Global	
Function	TRUE if there is a	n error in the slave	s application status	s register.		
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Controller Error		
		tions	ResetECError			
Variable name	CC ModErr					
Variable name	_EC_MsgErr	no Error		Global/lagal	Global	
Magning	EtherCAT Message Error			Global/local	Global	
	TDUE	TRUE when a message is sent to a slave that does not of the response to a message that was sent to a slave.			or when there is an error in the formation	
Function				Range of values	TRUE or FALSE	
Function Data type	of the response to			Range of values Network Publish	TRUE or FALSE Published.	
Meaning Function Data type R/W access Usage in user program	of the response to	Retained Related instruc-	as sent to a slave.	Network Publish		
Function Data type R/W access	of the response to BOOL	Retained	Not retained.	Network Publish Read CoE SDO)		
Function Data type R/W access	of the response to BOOL	Retained Related instruc-	Not retained. CoE messages (Network Publish Read CoE SDO)		

Variable name	_EC_SlavEmergE	_EC_SlavEmergErr					
Meaning	Emergency Messa	age Detected		Global/local	Global		
Function	TRUE if the maste	er detects an emerg	ency message that	was sent by a slav	e.		
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Reset EtherCAT C	Controller Error			
		tions	ResetECError				
Variable name	_EC_CommErrTb	I					
Meaning	Communications	Error Slave Table		Global/local	Global		
Function	Slaves are given i	n the table in the or	der of slave node a	ddresses.			
	The corresponding	g slave element is 7	TRUE if the master	detected an error fo	or the slave.		
Data type	Array [1192] OF	BOOL		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Reset EtherCAT C	Γ Controller Error			
		tions	ResetECError	r			

Note The values of all system-defined variables that are related to errors in EtherCAT communications do not change until the cause of the error is removed and then the error in the Controller is reset with the troubleshooting functions of the Sysmac Studio or the ResetECError instruction.

• Functional Classification: EtherCAT Communications Status

Variable name	_EC_RegSlavTbl	_EC_RegSlavTbl						
Meaning	Registered Slave Table			Global/local	Global			
Function	This table indicate	s the slaves that ar	e registered in the	network configuration	on information.			
	Slaves are given i	Slaves are given in the table in the order of slave node addresses.						
	The element for a	The element for a slave is TRUE if the corresponding slave is registered.						
Data type	Array [1192] OF BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						
Variable name	_EC_EntrySlavTb	I						
Meaning	Network Connecte	ed Slave Table		Global/local	Global			
Function	This table indicate	es which slaves are	connected to the ne	etwork.				
	Slaves are given i	n the table in the or	der of slave node a	ddresses.				
	The element for a	slave is TRUE if the	e corresponding sla	ave has entered the	network.			
Data type	Array [1192] OF	BOOL		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EC_MBXSlavTbl							
Meaning	Message Commu	nications Enabled S	Slave Table	Global/local	Global			
Function	This table indicates the slaves that can perform message communications.							
	Slaves are given in the table in the order of slave node addresses.							
	The element for a slave is TRUE if message communications are enabled for it (pre-operational, safe-operation,							
	or operational state).							
	Note Use this variable to confirm that message communications are possible for the relevant slave before you execute message communications with an EtherCAT slave.							
Data type		Array [1192] OF BOOL			TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc-	Disconnect Ether					
		tions	EC_Disconnect					
			Connect EtherCA					
			EC_ConnectSla	ave				
Variable name	_EC_PDSlavTbl							
Meaning	Process Data Con	nmunicating Slave	Table	Global/local	Global			
Function	This is a table that	indicates the slave	es that are perform	ing process data co	ommunications.			
	Slaves are given in the table in the order of slave node addresses.							
	The element for a slave is TRUE if process data of the corresponding slave is enabled (operational) for both slave							
	inputs and outputs.							
	Note Use this var	iable to confirm tha	at the data for the re		d before controlling an EtherCAT sla			
Data type	Array [1192] OF	BOOL	_	Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible. Related instruc- Disconnect EtherCAT Slave							
	• EC_DisconnectSlave							
			AT Slave					
			EC_ConnectSlav	е				
	_							
Variable name	_EC_DisconnSlav	Tbl			_			
Meaning	Disconnected Slav	/e Table		Global/local	Global			
Function	Slaves are given in	n the table in the or	der of slave node a	addresses.				
	The element for a	slave is TRUE if the	e corresponding sl	ave was disconnec	ted.			
Data type	Array [1192] OF	BOOL		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc-	Disconnect Ether	CAT Slave				
		tions	EC_Disconnect	tSlave				
			Connect EtherCA	AT Slave				
		EC_ConnectSlave						
Variable name	_EC_DisableSlav	ГЫ						
Meaning	Disabled Slave Ta	ble		Global/local	Global			
Function	Slaves are given in	n the table in the or	der of slave node a	addresses.				
	The element for a	slave is TRUE if th	e corresponding sl	ave is disabled.				
Data type	Array [1192] OF	BOOL		Range of values	TRUE or FALSE			
D.444	R	Retained	Not retained.	Network Publish	Published.			
R/W access	N	Retairieu	Not retained.	Network Publish	Published.			

tions

_EC_PDActive					
Process Data Communications Status			Global/local	Global	
TRUE when proce	ss data communica	ations are performe	d with all slaves*.		
BOOL			Range of values	TRUE or FALSE	
R	Retained	Not retained.	Network Publish	Published.	
Possible.	Related instruc-	Disconnect EtherCAT Slave			
tions		EC_DisconnectSlave			
		Connect EtherCAT Slave			
	EC_ConnectSlave				
F	Process Data Com FRUE when proce BOOL	Process Data Communications Status FRUE when process data communications BOOL Retained Possible. Related instruc-	Process Data Communications Status FRUE when process data communications are performe BOOL Related instructions Related instructions EC_Disconnects Connect EtherCAT	Process Data Communications Status Global/local FRUE when process data communications are performed with all slaves*. BOOL Range of values Retained Not retained. Network Publish Possible. Related instructions Disconnect EtherCAT Slave • EC_DisconnectSlave Connect EtherCAT Slave	

* Disabled slaves are not included.


Variable name	_EC_PktMonStop	_EC_PktMonStop					
Meaning	Packet Monitoring	Stopped		Global/local	Global		
Function	TRUE when packe	et monitoring is stop	oped.				
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Stop Packet Monitor • EC_StopMon				
		tions					
			Start Packet Monitor				
			EC_StartMon				

Variable name	_EC_LinkStatus	_EC_LinkStatus						
Meaning	Link Status			Global/local	Global			
Function	TRUE if the communications controller link status is Link ON.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

Variable name	_EC_PktSaving						
Meaning	Saving Packet Da	ta File		Global/local	Global		
Function	Shows whether a						
	TRUE: Packet data file being saved.						
	FALSE: Packet data file not being saved.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Saving Packet Data File				
		tions	EC_SaveMon				

Variable name	_EC_InDataInvali	_EC_InDataInvalid					
Meaning	Input Data Invalid			Global/local	Global		
Function	TRUE when process data communications are not normal and the input data is not valid.						
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Note All system-defined variables that are related to the status of EtherCAT communications give the current status.




Example of Operations for EtherCAT Communications

This section provides a series of example operations for when an NJ-series CPU Unit is connected to slaves.

8-1 I	Examp	Example of Operations for EtherCAT Communications								
	8-1-1	System Configuration Example	. 8-2							
	8-1-2	Wiring and Settings	. 8-2							
	8-1-3	Setting the EtherCAT Network Configuration	. 8-3							
	8-1-4	Programming	. 8-4							
	8-1-5	Offline Debugging	. 8-5							
	8-1-6	Turning the Power ON	. 8-5							
	8-1-7	Online Debugging	. 8-5							
	8-1-8	Downloading the Network Configuration Information and the User Program	. 8-5							
	8-1-9	Confirming the Start of Communications	. 8-5							

Example of Operations for EtherCAT 8-1 **Communications**

System Configuration Example 8-1-1



There are no restrictions on the order of node addresses.

Wiring and Settings 8-1-2

Wiring

- Install the NJ-series CPU Unit and slaves.
- · Connect communications cables to the EtherCAT master and slaves.
- · Connect the power supply.

Settings


· Set the node address for each slave.

8-1-3 Setting the EtherCAT Network Configuration

Start the Sysmac Studio and make the following settings.

Creating the EtherCAT Network Configuration


Use the EtherCAT Configuration Editor to create the slave configuration.



In this example, digital I/O slaves are set to node addresses 1 and 2 and Servo Drives are set to node addresses 3 and 4.

Assigning Device Variables to Digital I/O Slaves (Node Addresses 1 and 2)


Use the I/O Map to assign device variables to the I/O ports of the slaves.



In this example, *Pwr_On* is assigned to bit 0 of slave 1 and *Hm1_On* is assigned to bit 1 of slave 1.

Axis Settings for the Servo Drives (Node Addresses 3 and 4)

Add an axis to the Motion Control Setup and then assign the Servo Drive with node address 3 to the axis to set the axis.



In the same way, add an axis and assign the Servo Drive with node address 4 to it.

Setting EtherCAT Master Parameters

Set the parameters for the EtherCAT master from the EtherCAT master settings.

Setting Slave Parameters

Set the slave parameters from the EtherCAT configuration slave settings. If a communications error prevents the slaves from receiving signals from the EtherCAT master, the slave settings will control the slave outputs.


8-1-4 **Programming**

Programming

When the operation start button is pressed, the Pwr_On variable changes to TRUE and axis control is enabled. (See rung 0.)



When the homing button is pressed, the Hm1_On variable changes to TRUE and homing is performed. (See rung 1.)



Program Assignments

The Program Assignments are used to assign the programs to tasks and set the program execution order.

8-1-5 Offline Debugging

You can use the Simulator to check the program and task execution times with offline debugging.

8-1-6 Turning the Power ON

Turn ON the following power supplies.

- Slave unit power supply (The PWR indicator on the slave will light when the power supply turns ON.)
- Slave I/O power supply
- NJ-series Controller power supply

8-1-7 Online Debugging

Compare and merge the network configuration that was set on the Sysmac Studio and the actual configuration.

8-1-8 Downloading the Network Configuration Information and the User Program

Download the network configuration information and the user program that were created on the Sysmac Studio to the NJ-series Controller.

Note Use the synchronization operation of the Sysmac Studio to download the data.

8-1-9 Confirming the Start of Communications

Check to make sure that all registered slaves are participating in the network and that communications start.

Make sure that the master indicators are in the following status.

NET RUN indicator	Lit
NET ERR indicator	Not lit
LINK/ACT indicator (physical layer LINK)	Flashing

Make sure that the status indicators on all slaves are in the following status.

PWR indicator	Lit
RUN indicator	Lit
ERR indicator	Not lit
L/A IN (physical layer LINK inputs)	Flashing
L/A OUT (physical layer LINK outputs)	Flashing (Not lit on the last slave.)



Troubleshooting


This section describes the event codes, error confirmation methods, and corrections for errors that can occur for EtherCAT communications. It also describes how to replace slaves

9-1	Overvi 9-1-1	iew of Errors	
	9-1-2	Errors Related to the EtherCAT Master Function Module	9-6
9-2	Troubl	eshooting	9-9
	9-2-1	Error Table	9-9
	9-2-2	Error Descriptions	9-14
	9-2-3	Resetting Errors	9-38
	9-2-4	Diagnostic and Statistical Information	9-39
9-3	Precau	itions When Connecting or Disconnecting Slaves during	
		unications	9-42
	9-3-1	Procedure for Connecting and Disconnecting Slaves during	
		Communications	
	9-3-2	Prohibition to Physically Disconnecting a Slave and Resetting an Error or Connecting a Slave at the Same Time	
9-4	Replac	cing Slaves during Communications	9-43
	9-4-1	Introduction	9-43
	9-4-2	Slave Replacement Methods	9-44
	9-4-3	Backing Up Settings	9-45
	9-4-4	Restoring Settings	9-46
	9-4-5	Replacement Procedure	9-48

Overview of Errors

You manage all of the errors that occur on the NJ-series Controller as events. The same methods are used for all events. This allows you to see what errors have occurred and find corrections for them with the same methods for the entire range of errors that is managed (i.e., CPU Unit, NX-series Slave Terminals, EtherCAT slaves,* and CJ-series Units).

* Only Sysmac devices are supported.



You can use the troubleshooting functions of the Sysmac Studio or the Troubleshooter on an NS-series PT to quickly check for errors that have occurred and find corrections for them.

To perform troubleshooting from an NS-series PT, connect the PT to the built-in EtherNet/IP port on the CPU Unit.

This manual describes the errors that originate in the EtherCAT Master Function Module. Refer to the NJ-series Troubleshooting Manual (Cat. No. W503) for specific corrections when errors occur and for troubleshooting information on the entire NJ-series Controller.

9-1-1 How to Check for Errors

You can check to see if an error has occurred with the following methods.

Checking method	What you can check
Checking the indicators	You can check the error status of the CPU Unit and EtherCAT Master Function Module.
Troubleshooter of the Sysmac Studio	You can check for current Controller errors, a log of past Controller errors, error sources, error causes, and corrections.
Checking with the Trouble- shooter of an NS-series PT*	You can check for current Controller errors, a log of past Controller errors, error sources, causes, and corrections.
Checking with instructions that read function module error status	You can check the highest-level status and highest-level event code in the current Controller errors.
Checking with system- defined variables	You can check the current Controller error status for each function module.

^{*} To perform troubleshooting from an NS-series PT, connect the PT to the built-in EtherNet/IP port on the CPU

This section describes the above checking methods.

Checking the Indicators

CPU Unit Operating Status

You can use the PWR indicator on the Power Supply Unit and the RUN and ERROR indicators on the CPU Unit to determine the event level for an error. The following table shows the relationship between the Controller's indicators and the event level.

Indicators			CDILLInit operating status	Error confirmation with the Sys-	
PWR	RUN	ERROR	- CPU Unit operating status	mac Studio or an NS-series PT	
Not lit	Not lit	Not lit	Power Supply Error	Not possible: Refer to the NJ-series	
Lit	Not lit	Not lit	CPU Unit Reset*1	Troubleshooting Manual (Cat. No. W503).	
Lit	Flashing	Lit	Incorrect Power Supply Unit Connected		
Lit	Not lit	Lit	CPU Unit Watchdog Timer Error*2		
Lit	Not lit	Lit	Major fault level	Possible: Connect the Sysmac Stu- dio or an NS-series PT and check the cause of and correction for the	
Lit	Lit	Flashing	Partial fault level*2		
Lit	Lit	Flashing	Minor fault level	error in the troubleshooting func-	
Lit	Lit	Not lit	Observation	tions of the Sysmac Studio or the Troubleshooter of the NS-series PT	
Lit	Lit	Not lit	Normal operation in RUN mode		
Lit	Not lit	Not lit	Normal operation in PROGRAM mode*1		
Lit	Flashing	Not lit	Normal operation in startup state		

^{*1} If you can connect communications to the CPU Unit from the Sysmac Studio with a direct connection via USB, the CPU Unit is in PROGRAM mode. If you cannot connect communications, the CPU Unit is being reset.*3

^{*2} If you can connect communications to the CPU Unit from the Sysmac Studio with a direct connection via USB, a major fault level error has occurred. If you cannot connect communications, a watchdog timer error has occurred in the CPU Unit.*3

*3 If you cannot connect communications to the CPU Unit from the Sysmac Studio, it is also possible that the USB cable is faulty or that the connection type on the Sysmac Studio is not set for a direct connection via USB. Refer to the NJ-series Troubleshooting Manual (Cat. No. W503) if you cannot connect communications to the CPU Unit.

EtherCAT Master Function Module Error Status

If the EtherCAT NET ERR indicator is also lit in addition to the PWR, RUN, and ERROR indicators, then an error that affects process data communications occurred in the EtherCAT Master Function Module. The indicator lets you check the status given in the following table.

Indicator	Indicated status	
EtherCAT NET ERR	EtherCAT Master Function Module Status	
	Lit: An error for which normal status cannot be recovered through user actions (i.e., errors for which you must replace the CPU Unit or contact your OMRON representative) has occurred.	
	Flashing: An error for which normal status can be recovered through user actions has occurred.	
	Not lit: An error that affects process data communications has not occurred.	

Checking with the Troubleshooting Function of Sysmac Studio

When an error occurs, you can connect the Sysmac Studio online to the Controller to check current Controller errors and the log of past Controller errors. You can also check the cause of the error and corrections.

Refer to the NJ-series Troubleshooting Manual (Cat. No. W503) for the procedures to check for errors with the Sysmac Studio.

Checking with the Troubleshooter of an NS-series PT

If you can connect communications between an NS-series PT and the Controller when an error occurs, you can check for current Controller errors and the log of past Controller errors. You can also check the cause of the error and corrections.

To perform troubleshooting from an NS-series PT, connect the PT to the built-in EtherNet/IP port on the CPU Unit.

Refer to the NJ-series Troubleshooting Manual (Cat. No. W503) for the procedures to check for errors with an NS-series PT.

Checking with Instructions That Read Error Status

You can use instructions in the user program to check the error status of each function module. The following instruction is used to read the error status of the EtherCAT Master Function Module.

Instruction	Name	Outline of function
GetECError	Get EtherCAT Error Status	The GetECError instruction gets the highest level status (partial fault or minor fault) and highest level event code of the current Controller errors in the EtherCAT Master Function Module.

For details on the instructions that get error status, refer to the NJ-series Instructions Reference Manual (Cat. No. W502).

Checking with System-defined Variables

You can use system-defined variables to check for errors in the EtherCAT Master Function Module.

• Error Status Variables

You can check for errors in each function module of the NJ-series Controller with error status variables. The following variables show the error status of the EtherCAT Master Function Module.

Variable name	Data type	Meaning	Function
_EC_ErrSta	WORD	Built-in EtherCAT Error	Gives the collective error status of all error status for the EtherCAT Master Function Module.
_EC_PortErr	WORD	Communications Port Error	Gives the collective error status of all error status for the EtherCAT communications port.
_EC_MstrErr	WORD	Master Error	Gives the collective error status of the EtherCAT master error status and slave error status detected by the EtherCAT master.
_EC_SlavErr	WORD	Slave Error	Gives the collective error status of the error status for all EtherCAT slaves.
_EC_SlavErrTbl	ARRAY[1192] OF WORD	Slave Error Table	Gives the error status for each EtherCAT slave.

The meanings of the individual bits in the above error status variables are given below.

Bit	Name	Description	Value	Meaning	
15	Master Detection*1	This bit indicates whether the master	TRUE	Error	
		detected an error in the slaves that it manages.	FALSE	No error	
14	Slave Summary*2	Indicates whether there is an error at	TRUE	Error	
		a level below the function module.	FALSE	No error	
8 to 13	Reserved.	Reserved.			
7	Major Fault	Indicates if there is a major fault level error.	TRUE	Error	
			FALSE	No error	
6	Partial Fault	Indicates if there is a partial fault level	TRUE	Error	
		error.	FALSE	No error	
5	Minor Fault	Indicates if there is a minor fault level	TRUE	Error	
	error.	rror.	FALSE	No error	
4	Observation	Indicates if there is an observation	TRUE	Error	
		level error.	FALSE	No error	
0 to 3	Reserved.		•	•	

^{*1} For the EtherCAT Master Function Module, only _EC_SlavErrTbl (Slave Error Table) is used.

Other System-defined Variables Related to Errors

For the EtherCAT Master Function Module, there are other system-defined variables that show error status in addition to the error status variables. Refer to 7-1-2 System-defined Variables for system-defined variables that are related to errors.


^{*2} For the EtherCAT Master Function Module, only _EC_ErrSta (Built-in EtherCAT Error) is used.

Errors Related to the EtherCAT Master Function Module 9-1-2

This section describes the errors that are related to the EtherCAT Master Function Module.

Locations of Errors in the EtherCAT Master Function Module

Errors can occur internally in the EtherCAT Master Function Module, or they can occur in the built-in EtherCAT port or in EtherCAT slaves.





Additional Information

If any one of the following errors occurs at the same time for more than one slave, only the error for the slave that is closest to the master is recorded in the event log. The same error is not recorded in the event log for slaves that are connected further from the master.

- Network Configuration Verification Error
- Process Data Communications Errors (when caused by a disconnected cable)
- Slave Node Address Duplicated
- Slave Initialization Error

Classifications

There are the following sources of errors in the EtherCAT Master Function Module.

Classification	Description
Communications port errors	If an error is detected in overall EtherCAT communications, the corresponding bit in the Communications Port Error status variable shows the error.
EtherCAT master errors	If the EtherCAT master detects an error in its own settings or processing, the corresponding bit in the Master Error status variable shows the error. If the EtherCAT master detects an error in a slave, the corresponding bit in the Master Error status variable shows the error.
EtherCAT slave errors	If the EtherCAT master detects an error in a slave, the error status for the slave will show that the master detected an error.*1*2*3

^{*1} The EtherCAT master periodically reads error status information from the slaves. It updates the system-defined variables at the same time as the I/O data.

^{*2} The EtherCAT master will set the bits for EtherCAT slaves that do not report error status to FALSE in the Slave Error Table.

*3 If the error in the slave is corrected after it occurs, you do not need to reset it. It is reset automatically. (This applies to CPU Unit with unit version 1.05 or later.)



Additional Information

Refer to the *NX-series EtherCAT Coupler Unit User's Manual* (Cat. No. W519) for the events that can occur for an EtherCAT Slave Terminal.

Event Levels

This section describes the operation of the EtherCAT Master Function Module for each event level.

Event level of the error	Operation	
Major fault	All NJ-series Controller control operations stop for errors in this event level.	
Partial fault	All control operations for one of the function modules in the NJ-series Control stop for errors in this event level. If a partial fault level error occurs in the Ethe CAT Master Function Module, all functions of the EtherCAT Master Function Module stop.	
Minor fault	Some of the control operations for one of the function modules in the NJ-series Controller stop for errors in this event level. If a minor fault level error occurs for the EtherCAT Master Function Module, EtherCAT communications are possible, but control may be affected. User action is required.	
Observation	Errors in the observation level do not affect NJ-series Controller control operations. Observations are reported in order to prevent them from developing into errors at the minor fault level or higher.	
Information	Events that are classified as information provide information that do not indicate errors.	

EtherCAT Master Function Module Errors by Source

The following tables list the errors in each event level that can occur for each source.

Source Level	Communications port	EtherCAT master	EtherCAT slaves
Major fault	• None	None	None
Partial fault	Communications Controller Error MAC Address Error Link OFF Error	EtherCAT Processing Error	None
Minor fault	• None	 Network Configuration Information Error Network Configuration Verification Error Network Configuration Error Process Data Reception Timeout Error Process Data Transmission Error Slave Node Address Duplicated Slave Initialization Error Controller Insufficient Mem- 	 Network Configuration Verification Error Process Data Communications Error Slave Node Address Duplicated Slave Initialization Error Slave Application Error
	• None	EtherCAT Message Error EtherCAT Slove Bodyup	Emergency Message Detected
Observation		EtherCAT Slave Backup Failed EtherCAT Slave Restore Operation Failed	Botoliou
Information	None	Errors Reset	Slave Disconnected Slave Connected

^{*} Slave errors that are detected by the master are listed. There will also be a master error if any of these errors occurs. For slave errors that are not detected by the master, the errors and levels are defined by the individual slaves. Refer to the manual for the slave.

Refer to the NX-series EtherCAT Coupler Unit User's Manual (Cat. No. W519) for the events that can occur for an EtherCAT Slave Terminal.

9-2 Troubleshooting

This section describes the errors that can occur and the corrections for them.

9-2-1 Error Table

The errors (i.e., events) that can occur in the Built-in EtherCAT Master Function Module are given on the following pages. Event levels are given as following in the tables:

Maj: Major fault level Prt: Partial fault level Min: Minor fault level Obs: Observation Info: Information

A version in parentheses in the *Event code* column is the unit version of the CPU Unit when the event was added.

Refer to the *NJ-series Troubleshooting Manual* (Cat. No. W503) for all of the event codes that may occur in an NJ-series Controller.

Front code	Front name	Magning	A			Leve	I		Reference
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
0440 0000 hex	Communica- tions Control- ler Failure	An error was detected in the hardware test at startup.	The CPU Unit has failed.		√				page 9-15
1440 0000 hex	MAC Address Error	The MAC address is incorrect.	The CPU Unit has failed.		V				page 9-15
44010000 hex	EtherCAT Fault	A fatal error was detected in the EtherCAT Master Function Module.	Software is corrupted.		√				page 9-16
84200000 hex	Link OFF Error	A Link OFF state occurred.	 The Ethernet cable is broken between the master and slaves. The Ethernet cable connector is disconnected. The Ethernet cable is not connected. 		√				page 9-17
24200000 hex	Slave Node Address Duplicated	The same slave address is used for two nodes.	The same node address is set for more than one slave.			1			page 9-18
34400000 hex	Network Configura- tion Informa- tion Error	There is an error in the network configuration information.	The power supply to the Controller was interrupted or communications with the Sysmac Studio were disconnected while downloading the network configuration information.			V			page 9-19

Event code	Event name	Meaning	Assumed cause			Leve			Reference
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Kererence
50010000 hex (Ver. 1.02)					V			page 9-19	
84210000 hex	Network Configura- tion Error	The EtherCAT network configuration is incorrect.	Slave output ports are connected to each other. The master and slave are connected with the slave output port. The number of connected slaves exceeded the maximum number of slaves, 192 nodes, for the EtherCAT master.			V			page 9-20
84220000 hex	Network Configura- tion Verifica- tion Error	A slave that is in the network configuration information is not connected. Or, a slave that is not in the network configuration information is connected.	 A slave that is in the network configuration information is not connected. There is a node address mismatch. A different slave from the one that is specified in the network configuration information is connected. A slave that is not in the network configuration information is connected. The hardware switches for the slave node address were changed to a value other than 0 after the Write Slave Node Address operation was performed from the Sysmac Studio. The Ethernet physical layer is broken between two slaves. 			V			page 9-21
84230000 hex	Slave Initial- ization Error	Slave initialization failed.	 An error occurred in EtherCAT master processing. An initialization error occurred in the EtherCAT slave. 			√			page 9-22
84280000 hex	Slave Application Error	An error occurred in the slave application.	An error was detected in the slave's application layer status register.			1			page 9-24
84290000 hex	Process Data Transmis- sion Error	Sending process data failed.	It was not possible to send the EtherCAT frame during the EtherCAT communications period. The frame transmission jitter exceeded the limit.			1			page 9-25

Event end-	Event ners	Magning	Accumed course			Leve	I		Poforonoo
Event code	Event name	Meaning	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
842B0000 hex	Process Data Reception Timeout	Process data reception timed out.	 The Ethernet cable is broken. The Ethernet cable for Ether-CAT is disconnected. A general-purpose Ethernet hub is connected. The master failed. The slave failed. The Ethernet cable is too long. The CPU Unit task period is too short. Noise 			V			page 9-26
842C0000 hex	Process Data Communica- tions Error	An error occurred in process data communications.	 A slave left the network even though the disconnection operation was not performed. Noise The slave failed. 			√			page 9-27
102F0000 hex (Ver. 1.03)	EtherCAT Slave Backup Failed	The backup operation for an Ether-CAT slave ended in an error.	There is no connection between the EtherCAT master and the slave (Link OFF). An error caused an incorrect EtherCAT master status. The EtherCAT network configuration information does not agree with the physical network configuration. The request to the EtherCAT slave failed. The EtherCAT master was temporarily unable to perform the processing because it was executing other processing. Initialization of the EtherCAT slave failed. It was not possible to read the backup parameters from the EtherCAT slave. Communications with an OMRON Communications Coupler Unit or NX Unit failed.				1		page 9-28

Event code	Event neme	Magning	Accumed course			Leve			Reference
Event code	Event name	Meaning	Assumed cause	Мај	Prt	Min	Obs	Info	Reference
10300000 hex (Ver. 1.03)	EtherCAT Slave Restore Operation Failed	The restore operation for an Ether-CAT slave ended in an error.	 There is no connection between the EtherCAT master and the slave (Link OFF). An error caused an incorrect EtherCAT master status. The EtherCAT network configuration information does not agree with the physical network configuration. The request to the EtherCAT slave failed. The EtherCAT master was temporarily unable to perform the processing because it was executing other processing. Initialization of the EtherCAT slave failed. It was not possible to write the backup parameters to the MX2/RX Series Inverter. It was not possible to write the backup parameters to the EtherCAT slave. Incorrect backup data was detected. The EtherCAT network configuration in the backup data does not agree with the physical network configuration. An error occurred at an OMRON Communications Coupler Unit. The following causes are possible. Reading a backup file failed at the Communications Coupler Unit (when attached information 4 is 1). Communications with the Communications Coupler Unit or NX Unit failed (when attached information 4 is 2). The Unit Configuration of the NX Units in the Communications Coupler Unit when data was backed up did not agree with the actual configuration of NX Units (when attached information 4 is 3). 						page 9-30
6420 0000 hex	Emergency Message Detected	An emergency message was detected.	An emergency message was received from a slave.				1		page 9-32
842D0000 hex	EtherCAT Message Error	An error occurred in a message communications with the slave.	Refer to the attached information to check the error.				V		page 9-33
9440 0000 hex	Slave Disconnected	A slave was discon- nected for a discon- nection command.	An operation to disconnect the slave was executed from the Sysmac Studio. The EC_DisconnectSlave instruction was executed.					1	page 9-34

Event code	Event name	Meaning	Assumed cause			Leve	I		Reference
Event code	Event name	Wearing	Assumed cause	Maj	Prt	Min	Obs	Info	Reference
9441 0000 hex	Slave Con- nected	A slave was reconnected for a reconnection command.	 An operation to reconnect the slave was executed from the Sysmac Studio. The EC_ConnectSlave instruc- tion was executed. 					V	page 9-35
9443 0000 hex	Errors Reset	A command was received to reset errors.	 An error reset operation was performed from the Sysmac Studio. The ResetECError instruction was executed. 					V	page 9-36
94440000 hex	Slave Dis- abled	The EtherCAT Slave was disabled.	The EC_ChangeEnableSetting instruction was executed.					1	page 9-37
9445 0000 hex	Slave Enabled	The EtherCAT Slave was enabled.	The EC_ChangeEnableSetting instruction was executed.					V	page 9-37

9-2-2 **Error Descriptions**

This section describes the information that is given for individual errors.

Controller Error Descriptions

The items that are used to describe individual errors (events) are described in the following copy of an error table.

Event name	Gives the name of	the error.		Event code	Gives the code of	the error.		
Meaning	Gives a short desc	cription of the error.						
Source	Gives the source of	of the error.	Source details	etails Gives details on the source of the error. Detection timing Tells will error is				
Error attributes	Level	Tells the level of influence on control.*1	Recovery	Gives the recovery method.*2	Log category	Tells which log the error is saved in.*3		
Effects	User program	Tells what will hap- pen to execution of the user pro- gram.*4	Operation	Provides special ir from the error.	formation on the op	eration that results		
Indicators		f the built-in EtherNe CAT Master Functior	•	•		us is given only for		
System-defined	Variable		Data type		Name			
variables		names, data types, a fected by the error, o				t error notification,		
Cause and cor-	Assumed cause		Correction		Prevention			
rection	Lists the possible	causes, corrections,	and preventive mea	sures for the error.				
Attached information	This is the attache	This is the attached information that is displayed by the Sysmac Studio or an NS-series PT.						
Precautions/ Remarks	Provides precaution	ons, restrictions, and	supplemental inforn	nation.				

One of the following:

Major fault: Major fault level Partial fault: Partial fault level Minor fault: Minor fault level

Observation Information

*2 One of the following:

Automatic recovery: Normal status is restored automatically when the cause of the error is removed.

Error reset: Normal status is restored when the error is reset after the cause of the error is removed.

Cycle the power supply: Normal status is restored when the power supply to the Controller is turned OFF and then back ON after the cause of the error is removed.

Controller reset: Normal status is restored when the Controller is reset after the cause of the error is removed.

Depends on cause: The recovery method depends on the cause of the error.

*3 One of the following:

System: System event log Access: Access event log

*4 One of the following:

Continues: Execution of the user program will continue.

Stops: Execution of the user program stops. Starts: Execution of the user program starts.

Error Descriptions

Event name	Communications	Controller Failure		Event code	0440 0000 hex			
Meaning	An error was dete	ected in the hardwa	re test at startup.		•			
Source	Built-in EtherCAT	port	Source details	Communications port	Detection timing	At power ON or Controller reset		
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category System			
Effects	User program	Continues.	Operation	Master: The master waits i Slave: Parameter setting cations are not po	is not possible. Pro	ocess data communi-		
Indicators	EtherCAT NET R	UN	EtherCAT NET E	RR	EtherCAT LINK/A	ACT		
			Lights.					
System-defined	Variable		Data type		Name			
variables	_EC_LanHwErr		BOOL		Communications	Controller Error		
Cause and	Assumed cause		Correction		Prevention			
correction	The CPU Unit ha	s failed.	Replace the CPU	Unit.	None			
Attached information	None		•					
Precautions/ Remarks	None	None						

Event name	MAC Address Err	or		Event code	1440 0000 hex					
Meaning	The MAC address	The MAC address is incorrect.								
Source	EtherCAT Master	Function Module	Source details	Communications port	Detection timing	At power ON or Controller reset				
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category System					
Effects	User program	Continues.	Operation	Master: The master waits i Slave: Parameter setting cations are not pos	is not possible. Proc	ess data communi-				
Indicators	EtherCAT NET R	UN	EtherCAT NET E	RR	EtherCAT LINK/AC	T				
			Lights.							
System-defined	Variable		Data type		Name					
variables	_EC_MacAdrErr		BOOL		MAC Address Erro	or				
Cause and	Assumed cause		Correction		Prevention					
correction	The CPU Unit ha	s failed.	Replace the CPU	Unit.	None					
Attached information	None		•							
Precautions/ Remarks	None									

Event name	EtherCAT Fault			Event code	4401 0000 hex				
Meaning	A fatal error was detected in the EtherCAT Master Function Module.								
Source	EtherCAT Master F	Function Module	Source details	Master	Detection timing	During communications			
Error attributes	Level	Partial fault	Recovery	Cycle the power supply or reset the Controller.	Log category	System			
Effects	User program	Continues.	Operation	cations are not pos	eess data communi- ed communications e error occurred at				
Indicators	EtherCAT NET RU	N	EtherCAT NET ER	R	EtherCAT LINK/AC	т			
			Lights.						
System-defined	Variable		Data type		Name				
variables	None								
Cause and	Assumed cause		Correction		Prevention				
correction	Software is corrupt	ed.	Replace the CPU	Unit.	None				
Attached information	Attached information Attached information	on 1: System inform on 2: System inform on 3: System inform on 4: System inform	ation 2 ation 3						
Precautions/ Remarks	None								

Event name	Link OFF Error Event code 8420 0000 hex							
Meaning	A Link OFF state occurred.							
Source	EtherCAT Master	Function Module	Source details	Communications port	Detection timing	At power ON, at Controller reset, or during commu- nications		
Error attributes	Level	Partial fault	Recovery	Error reset	Log category	System		
Effects	User program	Continues.	Operation	Master:				
				Other communicat detected.	ions errors caused	by this error are not		
				Slave:				
				cations are not pos chronized communithen the error occu	ssible. If the error or	e master and slave, he error is pro-		
Indicators	EtherCAT NET RU	JN	EtherCAT NET ERR		EtherCAT LINK/A	CT		
			Flashes at 1-s inte	ervals.				
System-defined	VariableEC_LinkOffErr		Data type		Name			
variables			BOOL		Link OFF Error			
	_EC_LinkStatus		BOOL		Link Status			
Cause and	Assumed cause		Correction		Prevention			
correction	The Ethernet cable the master and sla	e is broken between aves.	Check the Ethern the master and sla damaged or disco replace the cable	ave to see if they are innected and	Check the Etherno operating properly	et cable to see if it is		
	The Ethernet cable connected.	e connector is dis-	Reconnect the co	nnector and make orrectly.	Confirm that the E connected secure			
	The Ethernet cabl	e is not connected.	Confirm that all Et connected and co that are not connected.	nnect any cables				
Attached information	None		1					
Precautions/ Remarks	None	None						

Event name	Slave Node Addres	ss Duplicated		Event code	2420 0000 hex					
Meaning	The same slave ac	Idress is used for to	wo nodes.							
Source	EtherCAT Master F	Function Module	Source details	Slave	Detection timing	At power ON, at Controller reset, or during commu- nications				
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System				
Effects	User program	Continues.	Operation	Communications When the Fail-se error is detected Slaves that were after the new slater remain in the When the Fail-se is detected during The slaves that state. Slaves after cated address estate. Slave: No error occurred Parameters other and process data	oft operation is set to any operation: were normal enter the er the new slave that arror remain in the Initiated. That the node address communications can that caused the duplice of the	aits in the Init state. Fail-soft and the operate. Slaves duplicated address Stop and the error as Pre-operational t caused the dupli- t state. Ss cannot be set not be performed				
Indicators	EtherCAT NET RU	N	EtherCAT NET ER	RR	EtherCAT LINK/AC	т				
			Flashes at 1-s inte	ervals.						
System-defined	Variable		Data type		Name					
variables	_EC_SlavAdrDupE	- Err	BOOL		Duplicated Slave N	Node Address Error				
Cause and	Assumed cause		Correction		Prevention					
correction	The same node ad more than one slav		Check the node at node address set and change it to p duplication.	value of the slave,	Set the node addre					
Attached information	None									
Precautions/ Remarks	The slave cannot be used unless the slave node address is set.									

Event name	Network Configura	tion Information Erro	or	Event code	3440 0000 hex		
Meaning	There is an error in	work Configuration Information Error Event code 3440 0000 hex re is an error in the network configuration information.					
Source	EtherCAT Master F	Function Module	Source details	Master	Detection timing	At power ON or Controller reset	
Error attributes	Level	Minor fault	Recovery	Automatic recovery	Log category	System	
Effects	User program	Continues.	Operation	Master: The master waits i Slave: Parameter setting cations are not pos	is not possible. Prod	cess data commun	
Indicators	EtherCAT NET RU	N	EtherCAT NET EF	RR	EtherCAT LINK/A	CT	
			Flashes at 1-s into	ervals.			
System-defined	Variable		Data type		Name		
variables	_EC_NetCfgErr		BOOL		Network Configura	ation Information	
Cause and	Assumed cause		Correction		Prevention		
correction	The power supply was interrupted or with the Sysmac S nected while down work configuration	communications tudio were discon- loading the net-	Perform the Clear tion, set the netwo information, and the master again.	•	the Controller or on ications with the	the network con-	
Attached information	Attached Informati	on 1: Error Details (0	0001 hex: Illegal pa	rameter, 0014 hex: E	rror opening file)		
Precautions/ Remarks	None						
Event name	Controller Insufficie	ent Memory Warning)	Event code	5001 0000 hex*		
Meaning				network-published in ble to perform online			
Source	EtherCAT Master F EtherNet/IP Functi	Function Module or on Module	Source details	Master or CIP	Detection timing	At power ON, download, or online editing	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	Not affected.			
Indicators	EtherCAT NET RU	N	EtherCAT NET EF	RR	EtherCAT LINK/A	СТ	
System-defined	Variable		Data type		Name		
variables	None						
Cause and	Assumed cause		Correction		Prevention		
correction	The amount of dat slave configuration lished information, exceeds the value the CPU Unit.	, network-pub- or other data	used by EtherCAT Reduce the numb are used for netwo	er of data types that ork-published vari- e length of the text	None		
Attached information	None						
Precautions/ Remarks	You may not be ab	le to perform online	editing or other ope	rations.			

^{*} This event code was added for unit version 1.02 of the CPU Unit.

Event name	Network Configura	tion Error		Event code 8421 0000 hex		
Meaning	The EtherCAT net	work configuration is	s incorrect.			
Source	EtherCAT Master F	Function Module	Source details	timing Controller reset,		At power ON, at Controller reset, or during commu- nications
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	 Master: The following applies if fail-soft operation is enabled, the event was detected when the power supply was turned ON or the Controller was reset, and the error details in the attached information is 0000 hex: the slaves for the first 192 nodes will enter Operational state and continue operation. Communications will stop for all slaves for nodes 193 and higher. The following applies if fail-soft operation is enabled, the event was detected when the power supply was turned ON or the Controller was reset, and the error details in the attached information is 0001 hex. It also applies if fail-soft operation is disabled and the event was detected when the power supply was turned ON or the Controller was reset: All of the slave will enter Init state and communications will stop. When the error is detected during operation while Fail-soft operation is set to Fail-soft. The slaves that are normal continue to operate. If you are using distributed clocks to synchronize the slaves, a Synchronization Error may occur between the slaves. Slave: No error occurred. When error is detected at power ON or Controller reset All slaves are initialized. Parameter setting is not possible. Process data communications are not possible. When the Fail-soft operation is set to Fail-soft and the error is detected during operation: Process data communications are possible for the slaves that are normal. If you are using distributed clocks to synchronizatior 		tion is enabled, the supply was turned the error details in: the slaves for the state and continue for all slaves for tion is enabled, the supply was turned the error details in. It also applies if event was a turned ON or the will enter Init state the error details in the event was a turned on the will enter Init state the error details in the event was a turned on the will enter Init state the error details in the event was a turned on the sale of the slaves, a ween the slaves. The controller reset: the error details in the possible of the ing distributed in the sale of the slaves.
Indicators	EtherCAT NET RU	N	EtherCAT NET ER	RR	EtherCAT LINK/AC	T
			Flashes at 1-s inte	ervals.		
System-defined variables	Variable		Data type		Name	
	_EC_NetTopology	⊨rr	BOOL		Network Configura	tion Error
Cause and correction	Assumed cause		Correction		Prevention	
COTTCCTION	Slave output ports each other.		Correct the Ethern tions.	net cable connec-	Confirm that there Ethernet cable cor	
	The master and slawith the slave outp	ut port.				
	The number of cor exceeded the max slaves, 192 nodes, master.	imum number of	Disconnect unnect keep the number be number.	essary slaves and below the maximum	Confirm that no mo are connected to to work.	ore than 192 nodes he EtherCAT net-
Attached information	Error Details: 0000	hex: Too many sla	ves, 0001 hex: Incorr	rect connections, suc	ch as a ring connecti	on
Precautions/ Remarks	there are slaves, s	uch as Junction Sla	of slave node address ves, that use more the ction, a Too Many Sl	nan one node. Also,	if 192 nodes are con	

Event name	Network Configura	ation Verification Err	or	Event code	84220000 hex	
Meaning	A slave that is in the tion information is		ation information is r	not connected. Or, a	slave that is not in the	ne network configura-
Source	EtherCAT Master Function Module		Source details	Master/Slave	Detection timing	At power ON, at Controller reset, or during commu- nications
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	When Fail-soft C	peration Is Set to Fa	ail-soft
				Master:		
				information ente not consistent w and all subseque Slave: Depends on the When Fail-soft C Master: All slaves remain Slave:	consistent with the ner the Operational state ith the network configent slaves remain in slave communication operation is Set to Set in the Init state and	te. Slaves that are guration information lnit state. ns status.
Indicators	EtherCAT NET RU	IN .	EtherCAT NET E	Init state	EtherCAT LINK/	ACT
indicators -			Flashes at 1-s int			
System-defined	Variable		Data type		Name	
variables	_EC_NetCfgCmpI	Err	BOOL		Network Configu	ration Verification
	When Inconsisten Verification _EC_CommErrTb		Array [1192] of I	BOOL	Communications	Error Slave Table

Cause and	Assumed cause		Correction		Prevention	
correction	A slave that is in the network configuration information is not connected.			es that are in the net- information. Or, nac Studio and set work configuration ne slave deleted in	Set and save the network configuration information for the configuration actually connected in the master.	
	There is a node ad	dress mismatch.		de address settings e network configura-		
	A different slave from specified in the net information is conn	work configuration	the network config Or, connect the S			
	A slave that is not i figuration informati		network configura from the network. Sysmac Studio ar	Or, connect the nd set and save the tion information with		
	The hardware switches for the slave node address were changed to a value other than 0 after the <i>Write Slave Node Address</i> operation was performed from the Sysmac Studio.		disagreement bets switches and the sten from the Sysm Application Error occur and you mulerror again. If this error occurs disconnected or derror first and there the slave. When y Application Error is	s, reset the error. reset, there will be a ween the hardware value that was writ- nac Studio. A Slave (8428 0000 hex) will ast then reset the s when the slave is lisabled, reset the n connect or enable rou do, a Slave (8428 0000 hex) will error again and then	disagreement between switches and the water from the Sysmapplication Error (occur and you musterror again. If this error occurs disconnected or dierror first and them the slave. When you application Error (s, reset the error. eset, there will be a ween the hardware value that was writ- lac Studio. A Slave 8428 0000 hex) will st then reset the when the slave is isabled, reset the connect or enable bu do, a Slave 8428 0000 hex) will rror again and then
			from the Sysmac	ddress that was set Studio, set the hard- a node address of 0 er supply to the	To use the node address that was set from the Sysmac Studio, set the hardware switches to a node address of 0 and cycle the power supply to the slave.	
	The Ethernet physic between two slaves	•	In cases not caus causes, confirm the break in the Ether replace the cable.	ne location of the net cable and	None	
Attached information	None					
Precautions/ Remarks	If you add check ite	you add check items in the options for network configuration verification, chec			ck whether the items	s match.
Event name	Slave Initialization	Error		Event code	8423 0000 hex	
Meaning	Slave initialization			Eveni code	04230000 HeX	
Source	EtherCAT Master F		Source details	Master/Slave	Detection timing	At power ON, Controller reset, or error reset
Error attributes	Level	Minor fault	Recovery	Error reset/hard- ware replace-	Log category	System

ment

=" .		0 "	= "	
Effects	User program Continues.	Operation		eration Is Set to <i>Fail-soft</i>
			after initialization Communications the error occurre where the error continue to oper • When the maste tional state: Only the slave w The normal slav tinue to operate. Slave: This depends on t When Fail-soft Op Master: • When the maste after initialization All slaves enter t • When the maste tional state:	s stop in the Init state at the slave where ed. Slaves in topology up to the slave occurred enter Operational state and ate. In fails to enter states after Pre-operation of the error will stop state transitions. The escape enter the Operational state and content of the slave communications status. In fails to enter Pre-operational state enter the Operational state of the slave communications status.
			This depends on t	he slave communications status.
Indicators	EtherCAT NET RUN	EtherCAT NET	ERR	EtherCAT LINK/ACT
		Flashes at 1-s	intervals.	
System-defined	Variable	Data type		Name
variables	_EC_SlavInitErr	BOOL		Slave Initialization Error
	_EC_CommErrTbl	Array [1192] o	of BOOL	Communications Error Slave Table
Cause and	Assumed cause	Correction		Prevention
correction	An error occurred in EtherCAT m processing.	reconfigure and configuration in ter again. If this check that there slave synchron the PDO mapp	rsmac Studio and d save the network dormation in the masserror occurs again, e are no errors in the ization settings and ing information, and ors that are found.	Correctly set the slave synchronization settings, PDO mapping information, and configure and save network configuration information in the master.
	An initialization error occurred in EtherCAT slave.	parameter is so a slave in the E figuration on the if a send method If that occurs, send method p send and perfo again. Or, cycle the p EtherCAT slave	Infig send method Implies the CAT network con- e Sysmac Studio even and cannot be set. Set the Module config arameter to Do not rm synchronization ower supply to the e. Insists, replace the	None
		EtherCAT slave	•	
Attached	Attached information 1: System	information 1		
information	Attached information 2: System			
	Attached information 3: System			
	Attached information 4: System	information 4		
Precautions/ Remarks	None			

Event name	Slave Application I	Frror		Event code	84280000 hex	
Meaning	An error occurred	n the slave applicat	ion.			
Source	EtherCAT Master F	Function Module	Source details	Slave	Detection timing	During communi- cations
Error attributes	Level	Minor fault	Recovery Error reset		Log category	System
Effects	User program	Continues.	Operation	Master: The slave communoperation continue tion layer status er Slave: An error occurred. transition behavior When Fail-soft Ope Master: All slaves enter the tion layer status er Slave:	peration Is Set to Fail nications status is not so that status of slav ror is also not manip Operation is accord of the slave where the ration Is Set to Stope Pre-operational states	ot manipulated, but yes with an applica- bulated. ling to the state the error occurred.
Indicators	EtherCAT NET RU	N	EtherCAT NET ER	R	EtherCAT LINK/AC	т
			Flashes at 1-s inte	rvals.		
System-defined	Variable		Data type		Name	
variables	_EC_SlavAppErr		BOOL		Slave Application I	Error
	_EC_CommErrTbl		Array [1192] of B	OOL	Communications Error Slave Table	
Cause and	Assumed cause		Correction		Prevention	
correction	An error was detection application layer st		Clear the error fror slave where the ap occurred. Use the the slave documer	oplication error procedure given in	None	
Attached information	Attached Informati	on 1: AL status code	e for the slave where	the error was detec	ted.	
Precautions/ Remarks	None					

Event name	Process Data Transmission Error			Event code	84290000 hex	
Meaning	Sending process d	ata failed.				
Source	EtherCAT Master F	Function Module	Source details			During communications
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation	When Fail-soft Operation Is Set to Fail-soft Master: Operation continues. Slave: The error occurs only with synced slaves. When Fail-soft Operation Is Set to Stop Master: All slaves enter the Pre-operational state. Slave: Errors only occur in synced slaves.		
Indicators	EtherCAT NET RU	N	EtherCAT NET ER	RR EtherCAT LINK/ACT		СТ
			Flashes at 1-s intervals.			
System-defined	Variable		Data type		Name	
variables	_EC_PDSendErr		BOOL		Process Data Transmission Error	
Cause and	Assumed cause		Correction		Prevention	
correction	CAT frame during to munications period	It was not possible to send the Ether-CAT frame during the EtherCAT communications period.		Connect the Sysmac Studio, increase the task period setting of the primary periodic task, and set and save the network configuration information in		d of the primary value that provides ng time. Use the the necessary
	The frame transmis exceeded the limit.	,	the EtherCAT master.		,	
Attached information	Attached Information 1: Error Details (Frame generation was late for the transmission timing: 0000 sion jitter exceeded the limit: 0001 hex				ission timing: 0000	hex, If the transmis-
	Attached Information	on 2: System inform	ation			
Precautions/ Remarks	None					

Event name	Process Data Rece	eption Timeout		Event code	842B0000 hex	
Meaning	Process data recep	otion timed out.				
Source	EtherCAT Master F	Function Module	Source details	Master	Detection timing	During communi- cations
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System
Effects	User program	Continues.	Operation When Fail-soft Operation Is Set to Fail-s Master: Operation continues. Slave: Errors only occur in synced slaves. Ope tinues. Safe-operational state is entered tion is made at the slave. When Fail-soft Operation Is Set to Stop Master: All slaves enter the Pre-operational state Slave:		d-soft Derational state coned if the state transi-	
				Errors only occur i		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
			Flashes at 1-s intervals.			
System-defined variables	Variable		Data type		Name Pata Bassatias Tissasat	
	_EC_PDTimeoutE	rr	BOOL		Process Data Rec	ception Timeout
Cause and correction	Assumed cause	. 'a bashaa	Correction	and the left are man	Prevention	
	The Ethernet cable disconnected.		sible if the error occurrence system starts oper	n on the left are pos- occurs from when the eration or if it always opifications offer the		
	A general-purpose Ethernet hub is connected.		occurs after a specific time after the system starts operation. If the Ethernet cable between the master and slave is broken, replace it. Or, recon-		When branching an EtherCAT network, use an EtherCAT Junction Slave.	
	The master failed.		nect the connector	and make sure it is	None	
	The slave failed.		mated correctly. If a general-purpose Ethernet hub is connected, replace it with an EtherCAT Junction Slave. If the CPU Unit or an EtherCAT slave fails, replace it.		None	
	The Ethernet cable	e is too long.	sible if the error oc	on the left are pos- curs from when the	Make the Etherne possible.	t cable as short as
	The CPU Unit task	period is too short.	system starts operation. If the Ether net cable is too long, shorten it. If the error still occurs, connect the Sysma Studio, increase the task period of the primary periodic task, and reconfiguithe Controller.		too long, shorten it. If the curs, connect the Sysmac ease the task period of the iodic task, and reconfigure	
	Noise		If this error occurs ment noise counte		Implement noise of	countermeasures.
Attached information	None					
Precautions/ Remarks	None					

Event name	Process Data Com	munications Error		Event code	842C 0000 hex		
Meaning	An error occurred	in process data com	munications.				
Source	EtherCAT Master F	Function Module	Source details	Slave	Detection During community cations		
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System	
Effects	User program	Continues.	Operation	When Fail-soft Operation Is Set to Fail-soft Master: Operation continues. Slave: An error occurred. Operational state continues. If a PDI watchdog error occurs in a slave, the slave enters the Init state. Check for communications errors for each slave in system-defined variables _EC_CommErrTbl [1] to _EC_CommErrTbl [192]. When Fail-soft Operation Is Set to Stop Master: All slaves enter the Pre-operational state. Slave: An error occurred. When operation stops, all slaves enter the Pre-operational state. If a PDI watchdog error occurs in a slave, the slave enters the Init state.			
Indicators	EtherCAT NET RU	N	EtherCAT NET E	RR	EtherCAT LINK//	ACT	
			Flashes at 1-s intervals.				
System-defined	Variable		Data type		Name		
variables	_EC_PDCommErr		BOOL		Process Data Co	ommunications Erro	
	_EC_CommErrTbl		Array [1192] of BOOL		Communications Error Slave Table		
	_EC_PDActive	_EC_PDActive				Process Data Communications Status	
Cause and	Assumed cause		Correction		Prevention		
correction	A slave left the network even though the disconnection operation was not performed.		before removing	nnection operation the slave from the hernet cable is bro-		onnection operation the slave from the	
	Noise		Implement noise countermeasures if there is excessive noise.		Implement noise countermeasures if there is excessive noise.		
	Moving Slaves		If this error occur the above correct slave.	s again even after ion, replace the	None		
Attached information	Attached Informati	on 1: Error Details (0001 hex: Slave WI	OT error, 0002 hex: S	lave disconnected)	
Precautions/ Remarks	None						

Event name	EtherCAT Slave Ba	ackup Failed		Event code	102F0000 hex*	_
Meaning	The backup opera	tion for an EtherCAT	slave ended in an e	rror.	•	
Source	EtherCAT Master I	Function Module	Source details	Master	Detection timing	During backup operation
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program Continues.		Operation	Not affected.		
Indicators	EtherCAT NET RU	N	EtherCAT NET ER	R	EtherCAT LINK/A	СТ
System-defined	Variable		Data type		Name	
variables	_EC_DisconnSlav	Tbl	Array [1192] of Bo	OOL	Disconnected Sla	ve Table
Cause and	Assumed cause		Correction		Prevention	
correction	There is no connect therCAT master a OFF).		Wire the EtherCAT securely.	master and slave	Wire the EtherCA securely and mak nection is establis attempt to back up	hed before you
	An error caused an incorrect Ether-CAT master status. The EtherCAT network configuration information does not agree with the physical network configuration.			tudio or the Trou- -series PT to check nate any EtherCAT	Back up the data when there are no EtherCAT errors.	
			Make sure that network configuration information agrees with the physical network configuration.		Back up the data only when the network configuration information agrees with the physical network configuration.	
	The request to the failed.	EtherCAT slave	Connect the cable securely. Implement noise countermeasures if there is excessive ambient noise. If the situation does not improve, replace the EtherCAT slave. Try backing up the data again.		Connect the cable securely. Implement noise countermeasures if there is excessive ambient noise. None	
	The EtherCAT masily unable to perfor because it was execessing.	m the processing				
	Initialization of the EtherCAT slave failed.		Troubleshooter of a check for the follow Initialization Error,	rsmac Studio or the a NS-series PT to wing errors: Slave Slave Application be Data Communica-	slave is participati and there are no s connected from the back up the data	slaves that are dis- ne network. Also,
	It was not possible to read the backup parameters from the EtherCAT slave.		manufacturer of the	meters that are set ters. If all of the s can be read, the	None	

Cause and	Communications with an OMRON	Connect the cable securely.	Connect the cable securely.			
correction	Communications Coupler Unit or NX	Mount the NX Unit securely.	Mount the NX Unit securely.			
	Unit failed.	Implement noise countermeasures if there is excessive ambient noise.	Implement noise countermeasures if there is excessive ambient noise.			
		If the problem still exists, replace the Communications Coupler Unit or the NX Unit.				
Attached	Attached Information 1: Error Details (7	The following values are in the order of the	ne causes of the error.)			
information	0001 hex: Link OFF					
	0002 hex: Incorrect master status					
	0003 hex: Configuration informatio	n does not agree with network configura	tion.			
	0004 hex: The request to the Ether	CAT slave failed.				
	0005 hex: Master status temporaril	y prevented processing.				
	0006 hex: An error occurred in slav	e initialization or a slave is disconnected	from the network.			
	0007 hex: Reading the backup data	a failed.				
	000B hex: Error at OMRON Comm	unications Coupler Unit				
	Attached Information 2: Error Location					
	0: Master					
	1 to 192: Slave (The number is the	node address.)				
		Details (only when attached information	1 is 000B hex).			
	0: Communications Coupler Unit					
	1 to 192: Unit number of NX Unit					
	Attached Information 4: Cause of Error at OMRON Communications Coupler Unit (only when attached information 1 is 000B hex).					
	2: Communications with the Comm	unications Coupler Unit or NX Unit failed	d.			
Precautions/ Remarks	None					

^{*} This event code was added for unit version 1.03 of the CPU Unit.

Event name	EtherCAT Slave Restore Operation Failed			Event code	10300000 hex*	
Meaning	The restore operate	tion for an EtherCAT	slave ended in an e	error.		
Source	EtherCAT Master I	Function Module	Source details	Master	Detection timing	During restore operation
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherCAT NET RU	IN	EtherCAT NET ER	RR	EtherCAT LINK/	ACT
System-defined	Variable		Data type		Name	
variables	None					
Cause and	Assumed cause		Correction		Prevention	
correction	There is no conne EtherCAT master a OFF).	ction between the and the slave (Link	Wire the EtherCAT securely.	Tmaster and slave	securely, and ma	AT master and slave ake sure that a con- ished before you re the data.
	An error caused at CAT master status			Studio or the Trou- s-series PT to check inate any EtherCAT	Restore the data EtherCAT errors	when there are no
	The EtherCAT network configuration information does not agree with the physical network configuration.		Make sure that ne information agrees network configurar Always use a slave same or higher that that was used whe backed up even if for the Revision C backup. Set No ch Number Check Me up the data. If you with the Serial Nur set to Setting = Ac use the restore fur change the network configuransfer the slave node address is set.	Make sure that network configuration information agrees with the physical network configuration. Always use a slave revision that is the same or higher than the slave revision that was used when the data was backed up even if you set <i>No check</i> for the Revision Check Method for backup. Set <i>No check</i> for the Serial Number Check Method and then back up the data. If you replace a slave with the Serial Number Check Method set to Setting = Actual device, do not use the restore function. Instead, change the network configuration from the Sysmac Studio, download the network configuration, and then transfer the slave parameters. If the node address is set on the hardware switches, use the same setting as		a only when the net- on information agrees I network configura-
	The request to the EtherCAT slave failed.		Connect the cable securely. Implement noise countermeasures if there is excessive ambient noise. If the situation does not improve, replace the EtherCAT slave.		Connect the cable securely. Implement noise countermeasures if there is excessive ambient noise.	
	ily unable to perfor	The EtherCAT master was temporarily unable to perform the processing because it was executing other processing.		ata again.	None	
	Initialization of the failed.	EtherCAT slave	for the following en	s-series PT to check rrors: Slave Initial- e Application Error, Communications		a when there is no ommunications Error.
	It was not possible parameters to the Inverter.	to write the backup MX2/RX Series	Download the para Inverter using the the Sysmac Studie	"To Drive" menu of	to Inverter restrict download the pa	e "To Drive" menu of

Cause and correction	It was not possible to write the backup parameters to the EtherCAT slave.	The ESI file may be incorrect. Ask the manufacturer of the slave if you can write all of the parameters that are set as backup parameters. If all of the backup parameters can be written, the slave is faulty. Replace the slave.	None
	Incorrect backup data was detected.	Format the SD Memory Card with the Sysmac Studio and then place the backup file on it.	Do not remove the SD Memory Card or turn OFF the power supply while the SD BUSY indicator is lit. Or, replace the SD Memory Card periodically according to the write life of the SD Memory Card.
	The EtherCAT network configuration in the backup data does not agree with the physical network configuration.	Make sure that the EtherCAT network configuration in the backup data agrees with the physical network configuration.	Make sure that the EtherCAT network configuration in the backup data agrees with the physical network configuration before you try to restore the data.
	An error occurred at an OMRON Communications Coupler Unit. The following causes are possible. Reading a backup file failed at the Communications Coupler Unit (when attached information 4 is 1). Communications with the Communications Coupler Unit or NX Unit failed (when attached information 4 is 2). The Unit Configuration of the NX Units in the Communications Coupler Unit when data was backed up did not agree with the actual configuration of NX Units (when attached information 4 is 3).	 Try backing up the data again (when attached information 4 is 1). Connect the cable securely. Mount the NX Unit securely. Implement noise countermeasures if there is excessive ambient noise. If the problem still exists, replace the Communications Coupler Unit or the NX Unit (when attached information 4 is 2). Make the Unit Configuration of the NX Units in the Communications Coupler Unit when data was backed up agree with the actual configuration of NX Units (when attached information 4 is 2 or 3). Correct the hardware switches on the Communications Coupler Unit so that they are the same as when the data was backed up (when attached information 4 is 3). 	 Format an SD Memory Card with the Sysmac Studio and then place the backup file on it. Also, do not remove the SD Memory Card or turn OFF the power supply while the SD BUSY indicator is lit (when attached information 4 is 1). Connect the cable securely. Mount the NX Unit securely. Implement noise countermeasures if there is excessive ambient noise (when attached information 4 is 2). Restore the data while the Unit Configuration of the NX Units in the Communications Coupler Unit agrees with the actual configuration of NX Units (when attached information 4 is 2 or 3). Restore the data while the hardware switches on the Communications Coupler Unit are the same as when the data was backed up (when attached information 4 is 3).

Attached	Attached Information 1: Error Details (The following values are in the order of the causes of the error.)					
information	0001 hex: Link OFF					
	0002 hex: Incorrect master status					
	0003 hex: Configuration information does not agree with network configuration.					
	0004 hex: The request to the EtherCAT slave failed.					
	0005 hex: Master status temporarily prevented processing.					
	0006 hex: An error occurred in slave initialization.					
	0007 hex: Writing the backup data failed.					
	0008 hex: The backup data is not correct.					
	0009 hex: The network configuration does not agree with the network configuration in the backup data.					
	000B hex: Error at OMRON Communications Coupler Unit					
	Attached Information 2: Error Location					
	0: Master					
	1 to 192: Slave (The number is the node address.)					
	Attached Information 3: Error Location Details (only when attached information 1 is 000B hex).					
	0: Communications Coupler Unit					
	1 to 192: Unit number of NX Unit					
	Attached Information 4: Cause of Error at OMRON Communications Coupler Unit (only when attached information 1 is 000B hex).					
	1: Reading the backup file failed.					
	2: Communications with the Communications Coupler Unit or NX Unit failed.					
	3: The Unit Configuration does not agree with the Unit Configuration in the backup data.					
Precautions/ Remarks	None					

 $^{\ast}\,$ This event code was added for unit version 1.03 of the CPU Unit.

Event name	Emergency Message Detected			Event code	6420 0000 hex	
Meaning	An emergency message was detected.					
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	During communications
Error attributes	Level	Observation	Recovery		Log category	System
Effects	User program	Continues.	Operation	Slave:		
				An error occurred. Other operation is not affected.		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
System-defined variables	Variable		Data type		Name	
	_EC_SlavEmergErr		BOOL		Emergency Message Detected	
Cause and correction	Assumed cause		Correction		Prevention	
	An emergency message was received from a slave.		Clear the error from the EtherCAT slave where the application error occurred. Use the procedure given in the slave documentation.		Refer to the information given in the manual for the slave and implement countermeasures to prevent the problem.	
Attached information	Attached Information 1: Slave emergency code					
	Attached information 2: Slave error register object value					
	Attached Information 3: Slave emergency data. Only the lower five bytes are valid.					
Precautions/ Remarks	None					

Event name	EtherCAT Messag	e Error		Event code	842D0000 hex		
Meaning	An error occurred in a message communications with the slave.						
Source	EtherCAT Master	Function Module	Source details Master		Detection timing	During communications	
Error attributes	Level	Observation	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Slave: An error occurred.	Other operation is not affected.		
Indicators	EtherCAT NET RU	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
System-defined	Variable		Data type	Data type		Name	
variables	_EC_MsgErr		BOOL		EtherCAT Message Error		
Cause and	Assumed cause		Correction		Prevention		
correction	Refer to the attached information to check the error.		Send messages only to slaves that support the message protocol. Iden- tify the error message with the error details that are given in the attached information, and correct the message.		Use messages that match the slave specifications. Also check to make sure that messages are addressed to the correct node.		
Attached information	Attached Information 1: Error Details 1st byte: 00 hex: Error message reception, 02 hex: Illegal or unsupported message discarded, 04 hex: Message with illegal destination address discarded 2nd byte: For Transmission: 00 hex: Error, 01 hex: VoE (AoE), 02 hex: EoE, 03 hex: CoE, 04 hex: FoE, 05 hex: SoE, 0F hex: VoE For Reception: 80 hex: Error, 81 hex: VoE (AoE), 82 hex: EoE, 83 hex: CoE, 84 hex: FoE, 85 hex: SoE, 8F hex: VoE, Attached information 2: Source node address. If the source is the master: 0 Attached Information 3: Transmission destination node address. If the destination is the master: 0 Attached information 4: Error service data. This data is valid only when byte 2 of attached information 1 is 00 or 80 hex.						
Precautions/ Remarks	None						

Event name	Slave Disconnected			Event code	9440 0000 hex		
Meaning	A slave was disconnected for a disconnection command.						
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	When slave dis- connection is specified during communications	
Error attributes	Level	Information	Recovery		Log category	System	
Effects	User program	Continues.	Operation	and all slaves after stopped for the slatestables. Slave: The slaves will mo	ommunications are stopped for the slave after it. Monitoring of topology changes is slave and all slaves after it. move to Init state. You can transfer the eters with the Sysmac Studio. Process data is are not possible.		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT		
System-defined	Variable		Data type		Name		
variables	_EC_DisconnSlavTbl		Array [1192] of BOOL		Disconnected Slave Table		
	_EC_PDSlavTbl		Array [1192] of BOOL		Process Data Communicating Slave Table		
	_EC_MBXSlavTbl		Array [1192] of BOOL		Message Communications Enabled Slave Table		
Cause and	Assumed cause		Correction		Prevention		
correction	An operation to disconnect the slave was executed from the Sysmac Studio.						
	The EC_DisconnectSlave instruction was executed.						
Attached information	None						
Precautions/ Remarks	None						

Event name	Slave Connected			Event code	9441 0000 hex		
Meaning	A slave was recor	nected for a reconn	ection command.				
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	When slave reconnection is specified during communications	
Error attributes	Level	Information	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Master:			
					The slave enters the Operational state again, and procesdata communications restart. Slave:		
				Enters Operatio	nal state.		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK//	ACT	
System-defined	Variable		Data type	Data type			
variables	_EC_DisconnSlavTbl		Array [1192] of	BOOL	Disconnected SI	ave Table	
	_EC_PDSlavTbl		Array [1192] of BOOL		Process Data Co Table	Process Data Communicating Slave Table	
	_EC_MBXSlavTbl		Array [1192] of	Array [1192] of BOOL		Message Communications Enabled Slave Table	
Cause and	Assumed cause		Correction		Prevention		
correction	An operation to reconnect the slave was executed from the Sysmac Studio.						
	The EC_ConnectSlave instruction was executed.						
Attached information	None		•		<u>.</u>		
Precautions/ Remarks	None						

Event name	Errors Reset			Event code	94430000 hex		
Meaning	A command was received to reset errors.						
Source	EtherCAT Master Function Module		Source details	Master	Detection timing	When errors are reset	
Error attributes	Level	Information	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Master: The current errors are reset and the network is verific again. If the error is not detected again, process data communications with the slave for which communications were stopped are restarted. Slave: The slave where the error occurred enters the Operat state.		n, process data ch communications	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT		
System-defined	Variable		Data type		Name		
variables	_EC_PDSlavTbl		Array [1192] of B	Array [1192] of BOOL		Process Data Communicating Slave Table	
	_EC_MBXSlavTbl		Array [1192] of B	Array [1192] of BOOL		Message Communications Enabled Slave Table	
Cause and	Assumed cause		Correction		Prevention		
correction	An error reset operation was per- formed from the Sysmac Studio.						
	The ResetECError instruction was executed.						
Attached information	None						
Precautions/ Remarks	None						

Event name	Slave Disabled		Event code	94440000 hex*		
Meaning	The EtherCAT Slave was disabled.					
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	At execution of setting instruction
Error attributes	Level	Information	Recovery		Log category	System
Effects	User program	Continues.	Operation	Master:		
				Process data communications stop for the slave.		
				Slave:		
				Enters the Pre-operational state. It will be possible to set parameters. Process data communications are not possible.		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
System-defined	Variable		Data type		Name	
variables	_EC_PDSlavTbl		Array [1192] of BOOL		Process Data Communicating Slave Table	
	_EC_DisableSlavTbl		Array [1192] of BOOL		Disabled Slave Table	
Cause and	Assumed cause		Correction		Prevention	
correction	The EC_ChangeEnableSetting instruction was executed.					
Attached information	None				•	
Precautions/ Remarks	None					

^{*} This event code was added for unit version 1.04 of the CPU Unit.

Event name	Slave Enabled		Event code	9445 0000 hex*			
Meaning	The EtherCAT Slav	The EtherCAT Slave was enabled.					
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	At execution of setting instruction	
Error attributes	Level	Information	Recovery		Log category	System	
Effects	User program	Continues.	Operation	Master:			
				The slave enters the Operational state again, and process data communications restart.		again, and process	
				Slave:			
				Enters the Operation	onal state.		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT		
System-defined	Variable		Data type		Name		
variables	_EC_PDSlavTbl		Array [1192] of B	Array [1192] of BOOL		Process Data Communicating Slave Table	
	_EC_DisableSlavTbl		Array [1192] of BOOL		Disabled Slave Table		
Cause and	Assumed cause		Correction		Prevention		
correction	The EC_ChangeEnableSetting instruction was executed.						
Attached information	None						
Precautions/ Remarks	None						

^{*} This event code was added for unit version 1.04 of the CPU Unit.

9-2-3 **Resetting Errors**

There are three methods to reset errors.

- Sysmac Studio
- NS-series PT
- Execution of the Reset EtherCAT Controller Error (ResetECError) instruction


Refer to the NJ-series Troubleshooting Manual (Cat. No. W503) for the resetting procedures from the Sysmac Studio or an NS-series PT. Refer to the NJ-series Instructions Reference Manual (Cat. No. W502) for details on the Reset EtherCAT Controller Error (ResetECError) instruction.

Resetting Errors in the EtherCAT Master Function Module

Before you reset the following errors, always make sure that the slave with the error is participating in the network.

- Resetting a Network Configuration Verification Error or Process Data Communications Error while the power supply to the slave is ON or while the cable is connected
- Resetting a Link OFF Error while the power supply is ON to the first slave where the cable was disconnected or while the cable is connected

Use the following procedure.



* Check the _EC_EntrySlavTbl[] (Network Connected Slave Table) system-defined variable to see if a slave is participating.

Also, set the wait time in the EtherCAT master settings (EtherCAT master parameter settings) long enough to allow for the power supply startup time of all of the slaves. If you reset the error in the Ether-CAT Master Function Module without using the above procedure, the EtherCAT master may access a slave with a different node address than the specified node address, or other unexpected operations may occur. Also, the error may not be reset correctly.

Resetting Slave Errors

You can reset errors in the EtherCAT Master Function Module to reset slave errors. However, process data communications between the EtherCAT master and EtherCAT slave must be active to reset a slave error.

If process data communications with the slave are not active, check the slave after you reset errors in the EtherCAT Master Function Module to see if process data communications are active. Then, to reset the error in the slave, reset errors in the EtherCAT Master Function Module again.


9-2-4 Diagnostic and Statistical Information

The EtherCAT master provides the following diagnostic and statistical information. You can refer to these to help isolate the cause of errors and obtain the status of the network. You can access this information from the Sysmac Studio with the following procedure.

- **1** Start the Sysmac Studio and go online with the Controller.
- 2 Double-click **EtherCAT** under **Configurations and Setup** in the Multiview Explorer. Or, right-click **EtherCAT** under **Configurations and Setup** and select **Edit**.



3 Right-click in the EtherCAT Network Configuration Tab Page and select *Display Diagnosis/Statistics Information* from the menu.



The Diagnosis/Statistics Information Dialog Box is displayed.



Item	Description
Output File	Outputs the information to a CSV file.
Update	Gets the diagnosis/statistics information from the Controller and updates the display.
Clear	Clears the diagnosis/statistics information from the Controller to all zeros.

Diagnostic and statistical information is cleared to all zeros when the power supply is turned ON.

Diagnostic and Statistical Information	Description
Total frames Sent	The total number of EtherCAT frames sent by the master.
Total frames Received	The total number of EtherCAT frames received by the master. If the total number of frames received is different from the total number of frames sent, the frames cannot be received and a frame reception timeout will occur. (Refer to Frame reception timeout count, below.)
Frame reception timeout count	The number of frame reception timeouts that occurred. If the number of frame reception timeouts changes, a Process Data Reception Timeout Error may have occurred. Refer to 9-2 Troubleshooting. If the number of CRC error frames received, the number of short frames received, or the number of overlength frames received increases, the number of frame reception timeouts will also increase.
Reception buffer overflow count	The number of frames discarded due to buffer overflows when receiving data. It is possible that there are many frames that are not EtherCAT frames on the EtherCAT network. These frames will interfere with EtherCAT communications. See if there are computers or other non-EtherCAT devices connected to the EtherCAT network and remove them if there are any.
Non-EtherCAT frames received	The number of frames received other than EtherCAT frames. There are frames that are not EtherCAT frames on the EtherCAT network. These frames will interfere with EtherCAT communications. See if there are computers or other non-EtherCAT devices connected to the EtherCAT network and remove them if there are any.
Link OFF count	The number of times link OFF was detected. The number of Link OFF Errors. Refer to 9-2 <i>Troubleshooting</i> and remove the cause of the errors.

Diagnostic and Statistical Information	Description
Discarded process data receptions	The number of process data packets discarded when receiving process data. The number of discarded process data receptions increases when a slave cannot update the PDO data within the communications cycle. If this value continues to increase, consider increasing the PDO communications cycle time. The value sometimes increases when the network is started or slaves are replaced.
Discarded message receptions	The number of messages discarded in mailbox reception. The number of EtherCAT Message Errors. Refer to 9-2 Troubleshooting and remove the cause of the errors.
Network propagation delay time*1	The propagation delay time for a frame to travel from the slave connected to the master to the last slave when using two or more synchronized slaves.
Current transmission cycle*2	The present value of the process data transmission period (ns).
Maximum transmission cycle*2	The maximum value of the process data transmission period (ns).
Minimum transmission cycle*2	The minimum value of the process data transmission period (ns).
Transmission jitter*2	The jitter in the process data transmission period (ns).
CRC Error Frames Received	The number of frames received that resulted in CRC errors. It is possible that noise on the EtherCAT line is corrupting the frames. Implement noise countermeasures.
Frame reception errors	The number of frames resulting in reception errors from the Ethernet controller (EtherMAC). It is possible that noise on the EtherCAT line is corrupting the frames. Implement noise countermeasures.
Collision count	The number of delay collisions on the line after start of transmissions. A repeater hub may be connected. You cannot use repeater hubs with EtherCAT communications.
Short frames received	The number of frames received with less than 64 bytes. It is possible that noise on the EtherCAT line is corrupting the frames. Implement noise countermeasures. See if there are repeater hubs connected to the EtherCAT network and remove them if there are any.
Overlength frames received	The number of frames received with more than 1,522 bytes. It is possible that noise on the EtherCAT line is corrupting the frames or that a computer or Ethernet device is connected. Implement noise countermeasures or see if there are computers or other non-Ether-CAT devices connected to the EtherCAT network and remove them if there are any.

^{*1} This value cannot be cleared to zero from the Sysmac Studio.

^{*2} This information is valid only for slaves that support a distributed clock. If a slave does not support a distributed clock, --- is displayed.

Precautions When Connecting or 9-3 **Disconnecting Slaves during Communications**

Procedure for Connecting and Disconnecting Slaves during 9-3-1 **Communications**

If you use slaves on a branched network, always use the following procedure to turn OFF the slave power supply or connect/disconnect cables during EtherCAT master communications.*

- * This includes the pre-operational, safe-operational, and operational states.
- Step 1. Use the Sysmac Studio or an instruction to send a command to disconnect the slave.
- Step 2. Confirm that the slave was disconnected normally.
- Step 3. Turn OFF the power supply to the slave or disconnect the cable.

If you turn OFF the power supply or disconnect the cable without performing steps 1 and 2, the slaves that are operating may be adversely affected.

9-3-2 Prohibition to Physically Disconnecting a Slave and Resetting an Error or Connecting a Slave at the Same Time

If you perform the following operation a or b at the same time as operation c, a Slave Initialization Error will occur.


- a) Turn OFF the power supply to the slave or disconnect the cable.
- b) Turn ON the power supply to the slave or connect the cable.
- c) Reset an error in the EtherCAT Master Function Module or connect the slave.*
- * This can happen when the Reset EtherCAT Controller Error (ResetECError) instruction or Connect EtherCAT Slave (EC_ConnectSlave) instruction is cyclically executed in the user program.

If you perform these operations at the same time, the EtherCAT master may access a slave with a different node address than the specified node address, or other unexpected operations may occur. Therefore, never turn OFF the power supply to the slave or disconnect the cable at the same time as you reset an error or connect a slave.

9-4 Replacing Slaves during Communications

9-4-1 Introduction

You can temporarily stop and start communications with a specified slave and all subsequent slaves without stopping the entire communications system. This makes it possible to replace slaves during communications for maintenance, or for replacement when a slave malfunctions.





Precautions for Correct Use

- A Process Data Communications Error occurs if you physically disconnect a slave from the network without executing the disconnection instruction.
 - A Network Configuration Verification Error occurs if the correct node address is not set for a slave that was replaced with the disconnection instruction and a connection is made to a different port than the one that was used for the disconnection instruction.

9-4-2 **Slave Replacement Methods**

The slave to be replaced is first disconnected from the network and then reconnected after you replace it. Use one of the following methods to disconnect and reconnect the slave.


Method 1: Connecting and Reconnecting Specified Slaves from the Sysmac Studio

Method 2: Execute the Disconnect EtherCAT Slave and Connect EtherCAT Slave instructions.

Execute the following instructions in the user program. You can use a pushbutton or a PT to input the execution condition.

Function	Instruction	Description
Disconnect EtherCAT Slave	EC_DisconnectSlave	Temporarily disconnects a slave from the EtherCAT network for maintenance, such as replacement of the slave.
Connect EtherCAT Slave	EC_ConnectSlave	Reconnects a temporarily disconnected slave to the EtherCAT network after maintenance, such as replacement of the slave.

If the EtherCAT slave to replace has backup parameters, we recommend that you use the Sysmac Studio to replace the slave. (You can specify backing up the parameters in the EtherCAT slave from the Sysmac Studio.)





Additional Information

The disconnection and reconnection operations are not required for slaves that are disabled with the EtherCAT Slave Enable/Disable Settings. You therefore cannot disconnect and reconnect them from the Sysmac Studio. If you execute the disconnection and connection instructions, they will result in errors.

9-4-3 Backing Up Settings


Before you replace an EtherCAT slave that is currently performing communications, the settings of the EtherCAT slave to replace are backed up. The settings of an EtherCAT slave are divided according to the storage locations and setting methods into initial parameters and backup parameters, as shown in the following table.

Slave settings	Storage location	Slave setting method
Initial parameters	EtherCAT master	These parameters are set automatically from the EtherCAT master when EtherCAT communications start or when a slave is connected.
Backup parameters	EtherCAT slaves	You set these parameters by transferring them to the slaves from the Backup Parameter Settings Tab Page of the Sysmac Studio. The data can also be transferred from the EtherCAT Drive Tab Page.

To replace an EtherCAT slave, you first back up the backup parameters that are stored in the EtherCAT slave.

- 1 Click the Edit Backup Parameter Settings Button in the EtherCAT Slave Setting Tab Page.
 The Backup Parameter Settings Tab Page is displayed.
- Click the **Transfer from Slave** Button.

 All of the backup parameters that are stored in the EtherCAT slave and displayed in the list are transferred from the EtherCAT slave.



3 Click the Compare Button.

Check to be sure that you have correctly obtained the backup parameters in step 2.

9-45



Additional Information


- You can back up the EtherCAT slave settings for any EtherCAT slave that is connected to the network (i.e., whenever the _EC_EntrySlavTbl[1..192] (Network Connected Slave Table) system-defined variable is TRUE) either before of after the disconnection command is sent to the EtherCAT slave.
- You can also set the EtherCAT drive slaves from the EtherCAT Drive Tab Page. Back up the settings information from the EtherCAT Drive Tab Page. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the applicable EtherCAT drive slaves.
- You do not need to back up the settings to replace an EtherCAT slave that does not have backup parameters.

9-4-4 Restoring Settings

After you replace the EtherCAT slave, you restore the settings that you backed up before you replaced the slave. The backup parameters that were backed up are restored to the EtherCAT slave.

- 1 Click the Edit Backup Parameter Settings Button in the EtherCAT Slave Setting Tab Page.
 The Backup Parameter Settings Tab Page is displayed.
- **2** Click the **Transfer to Slave** Button.

All of the backup parameters that are stored in the EtherCAT slave and displayed in the list are downloaded to the EtherCAT slave.



3 Click the Compare Button.

Check to be sure that you have correctly transferred the backup parameters in step 2.



Precautions for Correct Use


Restore the settings to the EtherCAT slave before you connect the EtherCAT slave to restart process data communications. Restore the EtherCAT slave settings while the slave is connected to the network (i.e., whenever the <code>_EC_EntrySlavTbl[</code> 1..192] (Network Connected Slave Table) system-defined variable is TRUE). You must set the node address of the EtherCAT slave before it can participate in the network.



Additional Information

- You can set the EtherCAT drive slaves from the EtherCAT Drive Tab Page. Restore the settings information from the EtherCAT Drive Tab Page. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the applicable EtherCAT drive slaves.
- You do not need to restore the settings to replace an EtherCAT slave that does not have backup parameters.

Replacement Procedure 9-4-5



Note: Steps shown in dotted boxes depend on the system.




Precautions for Safe Use

- When an EtherCAT slave is disconnected from the Sysmac Studio or with an instruction, communications will stop and control of the outputs will be lost not only for the disconnected slave, but for all slaves connected after it. Always confirm system safety before you disconnect an EtherCAT slave.
- If noise occurs or an EtherCAT slave is disconnected from the network, any current communications frames may be lost. If frames are lost, slave I/O data is not communicated, and unintended operation may occur. The slave outputs behave according to the slave specifications. For details, refer to relevant manuals for each slave. If a noise countermeasures or slave replacement is required, perform the following processing.
 - Program the _EC_InDataInvalid (Input Data Disable) system-defined variable as an interlock condition in the user program. Refer to 6-1-2 Sample Programming.
 - Set the PDO communications timeout detection count setting in the EtherCAT master to at least 2. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.

Disconnecting Slaves

If a slave is disconnected, slaves connected after the designated slave (on the output side) in a daisy chain are disconnected at the same time. Slaves connected before the disconnected slave (on the input side) and slaves connected beyond Junction Slaves continue to operate. (If (1) is disconnected in the following figure, (2) and (3) are also disconnected.)



The status of the system-defined variables for disconnected slaves are listed in the following table. The status in the following table are reached immediately after disconnection. This status does not change even if a slave is physically removed from the actual network configuration or physically connected to the actual network configuration again. The corresponding element in the Network Connected Slave Table changes to FALSE when the slave is physically removed from the actual network configuration.


System-defined variable name	Description	Value
_EC_RegSlavTbl[1192] (Registered Slave Table)	This variable shows the slaves that are registered in the network configuration information.	Remains TRUE.
_EC_EntrySlavTbl[1192] (Network Connected Slave Table)	This variable shows the slaves that are registered in the network configuration information and connected to the network.	The corresponding element changes to FALSE when the slave is removed from the actual network configuration.
_EC_MBXSlavTbl[1192] (Message Communications Enabled Slave Table)	This variable shows the slaves that are registered in the network configuration information and able to perform message communications.	The corresponding element changes to FALSE after the Ether-CAT slave is disconnected from the Sysmac Studio or with an instruction.
_EC_PDSlavTbl[1192] (Process Data Communicating Slave Table)	This variable shows the slaves that are registered in the network configuration information and performing process data communications.	The corresponding element changes to FALSE after the Ether-CAT slave is disconnected from the Sysmac Studio or with an instruction.
_EC_DisconnSlavTbl[1192] (Disconnected Slave Table)	This variable shows the slaves that are registered in the network configuration information and disconnected from the network.	The corresponding element changes to TRUE after the Ether-CAT Slave is disconnected from the Sysmac Studio or with an instruction.

Reconnecting Slaves

When reconnecting disconnected slaves after replacement or inspection, make sure that the following conditions are met and then reconnect them. If they are reconnected without meeting following conditions, process data communications with the slaves will not start again, and a network configuration verification error will occur. If the conditions are met, _EC_EntrySlavTbl will be TRUE.

- Make sure that the slave's node address is set correctly.
- Make sure that there are no errors in the order that the slaves are connected.

There are no restrictions on the order when reconnecting slaves that are in a daisy chain. For example, even if slaves (1) to (3) in a configuration such as the one shown in the following figure are disconnected, there are no restriction on the reconnection order of slaves (1) to (3). (For example, the slaves can be reconnected in the order (3), (2), (1) or (1), (3), (2).)



The status of the system-defined variables for disconnected slaves that have been successfully reconnected are listed in the following table.

System-defined variable name	Description	Value
_EC_RegSlavTbl[1192] (Registered Slave Table)	This variable shows the slaves that are registered in the network configuration information.	Remains TRUE.
_EC_EntrySlavTbl[1192] (Network Connected Slave Table)	This variable shows the slaves that are registered in the network configuration information and connected to the network.	Shows actual network configuration (changes to FALSE for disconnection and to TRUE for connection).
_EC_MBXSlavTbl[1192] (Message Communications Enabled Slave Table)	This variable shows the slaves that are registered in the network configuration information and able to perform message communications.	The corresponding element changes to TRUE after the EtherCAT slave is connected from the Sysmac Studio or with an instruction
_EC_PDSlavTbl[1192] (Process Data Communicating Slave Table)	This variable shows the slaves that are registered in the network configuration information and performing process data communications.	The corresponding element changes to TRUE after the EtherCAT slave is connected from the Sysmac Studio or with an instruction
_EC_DisconnSlavTbl[1192] (Disconnected Slave Table)	This variable shows the slaves that are registered in the network configuration information and disconnected from the network.	The corresponding element changes to FALSE after the EtherCAT Slave is disconnected from the Sysmac Studio or with an instruction.

9-51



Additional Information

Synchronization correction processing is performed to reconnect synced slaves. Therefore, several seconds may be required per slave until reconnection is completed.



Appendices

The appendices describe the relation of EtherCAT communications to overall CPU Unit status, packet monitoring functions, and multi-vendor application.

A-1	EtherC	AT Status in Relation to CPU Unit Status	4-2
	A-1-1	Startup	A-2
	A-1-2	CPU Unit Operating Modes	A-3
	A-1-3	Controller Errors Other Than Errors in the Built-in EtherCAT Master	A-4
	A-1-4	Others	A-5
A-2	Monito	ring Packets	4-7
	A-2-1	Sample Programming A	-10
A-3	Multi-v	endor Environments	-15
	A-3-1	EtherCAT Slave Information File (ESI Files)	-15
	A-3-2	Connecting Slaves from Other Manufacturers to an OMRON Master A	-16
	A-3-3	Installing ESI Files	-16
	A-3-4	Editing PDO Entry Tables	-22
A-4	Glossa	ıry A-	-25
A-5	Version	n Information	-27

A-1 EtherCAT Status in Relation to CPU Unit Status

The status of EtherCAT master memory, the ability to download master and slave settings, and the slave status are given below for different CPU Unit operating modes, Controller errors, and other status.

A-1-1 Startup

Mem	ory related to E	therCAT mast	er		S	laves
Device vari- ables	Category _EC sys- tem-defined variables	Network configura- tion infor- mation	Diagnos- tic and sta- tistical informa- tion	Downloading master and slaves settings	Slave outputs	Slave communica- tions status
Devices variables that are not retained: Initial settings	Default set- tings (Default settings are set in the EtherCAT master.)		Cleared to all zeros.		The status of slave outputs before the start of EtherCAT communications depend on the slave. Slaves output values of device variables after EtherCAT communications start.	The EtherCAT master moves slaves into the operational state according to the network configuration information.

A-1-2 **CPU Unit Operating Modes**

	Memor	y related to E	therCAT mas	ter		Sla	ves
CPU Unit sta- tus	Device vari- ables	Category _EC sys- tem- defined variables	Network configura- tion infor- mation	Diagnostic and statis- tical infor- mation	Downloading master and slaves set- tings	Slave out- puts	Slave com- munica- tions status
PROGRAM mode	Normal Ether- CAT communi- cations are performed and I/O is refreshed.	Continually show Ether- CAT com- munications status.	Nothing is performed (does not depend on the operat- ing mode of the CPU Unit).	Does not depend on the operating mode of the CPU Unit. Continually show Ether-CAT communications status.	Master settings: OK Slave settings: OK (However, setting may not be possible depending on the status of the slave.)	Does not depend on the operating mode of the CPU Unit. Continually show the output data sent from the Ether-	Does not depend on the operat- ing mode of the CPU Unit.
Switching between PRO- GRAM and RUN mode	Device variables that are not retained: Default settings	Not initial- ized (Com- munications status is still updated by the Ether- CAT master regardless of the oper- ating mode of the CPU Unit).				CAT master.	
RUN mode	Normal Ether-CAT communications are performed and I/O is refreshed.	Continually show Ether- CAT com- munications status.			Master settings: Not possible. Slave settings: OK (However, setting may not be possible depending on the status of the slave.)		

A-1-3 Controller Errors Other Than Errors in the Built-in EtherCAT Master

	Memor	y related to E	therCAT mas	ter	Slaves		
CPU Unit sta- tus	Device vari- ables	Category _EC sys- tem- defined variables	Network configura- tion infor- mation	Diagnos- tic and sta- tistical informa- tion	Downloading master and slaves set- tings	Slave out- puts	Slave com- munica- tions status
A major fault level Control- ler error occurs.	Device variables that are not retained: Default settings	Does not depend on the operating mode of the CPU Unit. Continually show Ether-CAT communications status.	Nothing is performed (does not depend on the operating mode of the CPU Unit).	Does not depend on the operating mode of the CPU Unit. Continually show Ether-CAT communication s status.		In Operational state, the values from before operation stopped are output. When the slaves have entered Safe-operational state, the slave settings control all of the outputs. Inputs are enabled.	The Ether-CAT master moves the slaves into the safe-operational state.
A partial fault level Controller error occurs. A minor fault level Controller error occurs.	Normal Ether-CAT communications are performed and I/O is refreshed.					Does not depend on the operating mode of the CPU Unit. Continually show the output data sent from the Ether-CAT master.	Does not depend on the operat- ing mode of the CPU Unit.

Refer to 9-1 Overview of Errors if a Controller error occurs in the built-in EtherCAT master.

A-1-4 Others

	Memor	y related to E	therCAT mas	ter		Slave out- munica-	ves
CPU Unit status	Device vari- ables	Category _EC sys- tem- defined variables	Network configura- tion infor- mation	Diagnos- tic and sta- tistical informa- tion	Downloading master and slaves set- tings		Slave com- munica- tions status
Memory all clear	Cleared to all zeros.	Initialized to default val- ues (0).	Deleted.	Cleared to all zeros.		EtherCAT communica- tions stop. (Output val- ues depend on the slave.)	EtherCAT communications stop.

Appendices

Monitoring Packets A-2


Packet monitoring stores a certain number of the most recent packets sent and received by the Ether-CAT master along with time information.

You can use an EtherCAT communications instruction or the Sysmac Studio to save the captured packet data in packet data files in the system in the CPU Unit.

You can use any of the following methods to obtain the packet data saved in the system memory in the CPU Unit.

- Reading directly from the Sysmac Studio
- Saving to an SD Memory Card inserted in the CPU Unit

You can view the captured packet data with packet analyzer software, such as WireShark. You can also use the data for analysis applications, such as error analysis and data mining.





Additional Information

The NJ301- CPU Units do not support packet monitoring. The EC PktMonStop systemdefined variable, which shows the operating status of packet monitoring, will always be TRUE in an NJ301-DDD CPU Unit. If you execute any EtherCAT instructions for packet monitoring (EC StartMon, EC StopMon, EC SaveMon, or EC CopyMon) in the user program, an error is returned that says packet monitoring cannot be used.

Starting and Stopping Packet Monitor

You can start and stop packet monitoring either with instructions in the user program or with operations on the Sysmac Studio.

Using Instructions in the User Program


- EC_StartMon (Start EtherCAT Packet Monitor) instruction: Starts the execution of packet monitoring and continues to update a fixed number of packets.
- EC_StopMon (Stop EtherCAT Packet Monitor) instruction: Stops the execution of packet monitoring.

Operation from the Sysmac Studio

- **1** Start the Sysmac Studio and go online with the Controller.
- 2 Double-click EtherCAT under Configurations and Setups in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setups and select *Edit*.



Right-click in the EtherCAT Network Configuration Tab Page and select **Display Packet Monitor** from the menu.



The Packet Monitor Dialog Box is displayed.

4 Click the Start Button to begin monitoring packets.



5 Click the **Stop** Button to stop monitoring packets.



Saving Packet Data

Reading Data from the Sysmac Studio

After you stop packet monitoring, you can use the Sysmac Studio to read the packet data and save it in a file.

- Stop monitoring packets.
- **2** Click the **Save Packet Data** Button to save the packet data.



The Save Dialog Box is displayed.

Input a file name, and then click the Save Button.
A TCPDump packet data file with a .cap extension is saved.

Saving to an SD Memory Card from Memory in the CPU Unit

Stop monitoring packets, and then execute the EC_SaveMon (Save EtherCAT Packets) instruction to save a given quantity of collected packet data in memory in the CPU Unit. Then, execute the EC_CopyMon (Transfer EtherCAT Packets) instruction to save the packet data that was saved in the CPU Unit to a file on an SD Memory Card inserted into the CPU Unit. You can specify the name of the file that is saved in the SD Memory Card. The number of files is limited only by the space that is available on the SD Memory Card.



Additional Information

- Packet data in the CPU Unit's memory is not retained when the power is interrupted.
- · Packet data cannot be saved while packets are being monitored.
- Packet monitoring cannot be started while saving packet data.
- If an SD Memory Card is not inserted and you execute the instruction to copy the data to the SD Memory Card, then an error is returned. If there is no SD Memory Card, only the one file in the CPU Unit's memory can be read to the Sysmac Studio.
- Packet monitoring starts when the power is turned ON.

Packet Monitoring Specifications

Item	Specification
Maximum data size of one packet data file	12 MB
Maximum number of packets that can be obtained	3,904 packets
Format of packet data file	TCPDump format (cap)
Time information	Recorded (unit: μ s) The elapsed time starting when packet monitoring begins is recorded. (Packet monitoring can be started when power turns ON, for an EtherCAT instruction, or for a Sysmac Studio operation.)
Save location for packet data file	CPU Unit's system: 1 file SD Memory Card inserted in CPU Unit: Multiple files (up to capacity of SD Memory Card)

A-2-1 Sample Programming


This sample transfers EtherCAT communications packets to an SD Memory Card when an EtherCAT slave error occurs. The file name is 'PacketFile.' The processing procedure is as follows:

- **1** The system-defined variable _EC_ErrSta (EtherCAT Error) is monitored and processing is started if an error occurs.
- 2 The EC_StopMon instruction is used to stop execution of packet monitoring for EtherCAT communications.
- **3** The EC_SaveMon instruction is used to save EtherCAT communications packet data to a file in the system of the CPU Unit.
- **4** The EC_CopyMon instruction is used to copy that file to the SD Memory Card.
- **5** The EC_StartMon instruction is used to restart execution of packet monitoring for EtherCAT communications.

LD					
	Internal Variables	Variable	Data type	Initial value	Comment
		OperatingEnd	BOOL	False	Processing completed
	Operating		BOOL	False	Execution condition
		A	BOOL	False	
	В		BOOL	False	
		С	BOOL	False	
		RS_instance	RS		
		EC_StopMon_instance	EC_StopMon		
		EC_SaveMon_instance			
		EC_CopyMon_instance	EC_CopyMon		
		EC_StartMon_instance	EC_StartMon		

	External Variables	Variable	Data type	Constant	Comment
		_EC_ErrSta	WORD		Built-in EtherCAT Error
	_EC_PktMonStop _EC_PktSaving _Card1Ready		BOOL		Packet Monitoring Stopped
			BOOL	\Box	Saving Packet Data File
			BOOL	\Box	SD Memory Card Enabled Flag

Determine if instruction execution is completed.




Monitor for EtherCAT errors.

```
_EC_PktMonStop
                                                            EC_StopMon_instance.Busy
                                  Up
                ΕN
                                In
   _EC_ErrSta
               In1
WORD#16#00 -
```

```
EC_SaveMon_instance.Busy EC_CopyMon_instance.Busy
                                                   EC_StartMon_instance.Busy
                                                                                    В
```

```
RS_instance
В
          _EC_PktSaving
                                                         Operating
                                             RS
                                                   Q1
                        OperatingEnd
                                        Reset1
```



Internal Variables	Variable	Data type	Initial value	
	EC_Err	BOOL	False	Controller error in the EtherCAT Master Function Module.
	EC_Err_Trigger	BOOL	False	Detect when EC_Err changes to TRUE.
	DoEC_PktSave	BOOL	False	Processing
	Stage	INT	0	Stage change
	R_TRIG_instance	R_TRIG		
	EC_StopMon_instance	EC_StopMon		
	EC_SaveMon_instance	EC_SaveMon		
	EC_CopyMon_instance	EC_CopyMon		
	EC_StartMon_instance	EC_StartMon		

	External Variables	Variable	Data type	Constant	Comment
		_EC_ErrSta		\square	Built-in EtherCAT Error
		_EC_PktMonStop	BOOL		Packet Monitoring Stopped
	_EC_PktSavin		BOOL		Saving Packet Data File
_Card1R		_Card1Ready	BOOL	\square	SD Memory Card Enabled Flag

ST

```
// Start sequence when _EC_ErrSta changes to TRUE.
EC_Err:=(_EC_ErrSta <> WORD#16#00);
R_TRIG_instance(Clk:=EC_Err, Q=>EC_Err_Trigger);
IF ( (EC_Err_Trigger=TRUE) AND (DoEC_PktSave=FALSE) AND (_EC_PktMonStop=FALSE) AND (_EC_PktSaving=FALSE) AND (_Card1Ready=TRUE) ) THEN
   DoEC_PktSave:=TRUE;
                 :=INT#1;
   Stage
   EC_StopMon_instance(Execute:=FALSE); // Initialize instance.
   EC_SaveMon_instance(Execute:=FALSE);
   EC_CopyMon_instance(Execute:=FALSE);
   EC_StartMon_instance(Execute:=FALSE);
END_IF;
// Instruction execution
IF (DoEC_PktSave=TRUE) THEN
   CASE Stage OF
                     // Stop EtherCAT packet monitor.
      EC_StopMon_instance(
         Execute :=TRUE);
      IF (EC_StopMon_instance.Done=TRUE) THEN
                                   // Normal end
         Stage:=INT#2;
      ELSIF (EC_StopMon_instance.Error=TRUE) THEN
                                   // Error end
         Stage:=INT#10;
      END_IF;
                     // Save EtherCAT packet data to file in system.
      EC_SaveMon_instance(
        Execute :=TRUE);
      IF (EC_SaveMon_instance.Done=TRUE) THEN
         Stage:=INT#3;
                                   // Normal end
      ELSIF (EC_SaveMon_instance.Error=TRUE) THEN
         Stage:=INT#20;
                                   // Error end
      END_IF;
                     // Copy EtherCAT packet data file to the SD Memory Card.
      EC_CopyMon_instance(
         Execute :=TRUE,
        FileName:='PacketFile');
      IF (EC_CopyMon_instance.Done=TRUE) THEN
         Stage:=INT#4;
                                   // Normal end
      ELSIF (EC_CopyMon_instance.Error=TRUE) THEN
         Stage:=INT#30;
                                   // Error end
      END_IF;
```

Multi-vendor Environments

This section provides precautions and describes documentation for multi-vendor environments.


A-3-1 **EtherCAT Slave Information File (ESI Files)**

Setting information for EtherCAT is defined in EtherCAT slave information (ESI) files. These files are provided by the individual slave manufacturers. Various EtherCAT communications settings are defined based on the ESI definitions of connected slaves.

You can install the ESI files in the Sysmac Studio to use them to edit the EtherCAT configuration in the Sysmac Studio and create the network configuration information.

You can download the network configuration information to the EtherCAT master to configure the Ether-CAT network.

Contact the manufacturer or the point of purchase to obtain the most recent ESI files for slaves that are manufactured by other companies.



Communications are started according to the communications settings and the network configuration in the ESI files that are installed.



Additional Information

ESI file versions that are lower than ESI version-1.0.1 specifications are not supported. If you install an ESI file version that is not supported, a message saying that you cannot use the slave is displayed by the Sysmac Studio.

The NJ-series CPU Units do not support variables with some of the data types that are defined in ETG.1020. The NJ-series CPU Units do not support the following data types for variables. If variables with any of these data types are included in the slave information (ESI), you cannot use the slave.

Integer data types: INT24, INT40, INT48, and INT56 Unsigned integer data types: UINT24, UINT40, UINT48, and UINT56

ARRAY[0..n] OF BYTE and ARRAY[0..n] OF UINT Octet string data types:

Visible string data type: STRING(n)

Variables with the following data types are also not supported on Sysmac Studio version 1.07 or lower.

Bit data types: BIT1, BIT2, BIT3, BIT4, BIT5, BIT6, BIT7, and BIT8

Bit array data types: BITARR8, BITARR16, and BITARR32

If variables with any of these data types are included in the slave information (ESI), a message saying that you cannot use the slave is displayed in the ESI Library Dialog Box of the Sysmac Studio.

A-3-2 Connecting Slaves from Other Manufacturers to an OMRON Master

You can install the ESI file for a slave from another manufacturer in the Sysmac Studio to handle the slave in the same way as an OMRON slave. (Only the ESI files for OMRON slaves for which connectability has been confirmed are installed in the Sysmac Studio in advance.)

When connecting a slave from another manufacturer to an OMRON master, refer to the manuals for the other manufacturer's slaves, and then ask your OMRON representative if you have any questions.



Additional Information

EtherCAT setup software that is provided by other manufacturers cannot be connected to NJ-series CPU Units.

A-3-3 Installing ESI Files

Procedure

An ESI (EtherCAT slave information) file is an XML file that describes the connection information and profile of the EtherCAT slave.

To connect an EtherCAT slave that is manufactured by other company to an NJ-series master, you must install the ESI file for that slave in the Sysmac Studio to enable setting the slave.


Use the following procedure to install an ESI file.

1 Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit*.




The edit pane is displayed.

Right-click the EtherCAT master that is displayed in the edit pane and select Display ESI Library.




The ESI Library Dialog Box is displayed.

Click the this folder link in the ESI Library Dialog Box.



The contents of the EsiFiles folder are displayed.

4 Copy the ESI file for the EtherCAT slave that is manufactured by another company and paste it in the EsiFiles folder. Obtain the ESI file from the slave manufacturer. The ESI file must conform to the most recent ETG ESI specifications.




5 Restart the Sysmac Studio.

The ESI file that you installed is displayed in the ESI Library Dialog Box after you restart the Sysmac Studio.

Procedure to Confirm ESI File Installation


Use the following procedure to confirm that an ESI file was installed correctly

Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, rightclick EtherCAT under Configurations and Setup and select Edit.




The edit pane is displayed.

Right-click the EtherCAT master that is displayed in the edit pane and select Display ESI Library.




The ESI Library Dialog Box is displayed.

3 Click the + Icon to the left of the name of the ESI file that was added.




The slave definitions in the ESI file are expanded so that you can check the following items.

- Model
- Revision
- Product name



If an exclamation mark is not displayed, click the Close Button.





Additional Information

If an ESI file for a slave cannot be used in the Sysmac Studio, an exclamation mark is displayed to the left of the file name. If an exclamation mark is displayed, obtain an ESI file with the cause corrected from the slave manufacturer, and then install the ESI file again.

A-3-4 Editing PDO Entry Tables

A PDO entry table maps objects in a slave to the process data that is used for communications between the master and the slave.

You cannot necessarily edit all of the PDO mappings in a PDO entry table.

You can add and delete objects in a PDO entry table or you can change the order of the entries.

The Sysmac Studio provides the functionality to edit slave PDO entry tables.

Order of entries

	Index	Size	Data type	PDO entry name	Comment
l	0x6000:00	16[bit]	UINT	uiAAA	
l	0x6001:00	8[bit]	USINT	b2BBB	
l	0x6002:00	8[bit]	USINT	b4CCC	
l	0x6008:00	16[bit]	UINT	uiddd	
⇂	0x6010:00	32[bit]	UDINT	udEEE	

Editing a PDO Entry Table

Initially, a slave PDO entry table contains the default objects. Some slaves have objects other than these default objects.

You can add objects other than the default objects to the PDO entry table, or you can delete objects from the PDO entry table. However, the following restrictions apply:

Byte Boundaries

An OMRON master must arrange entry objects by byte boundaries. (This applies only to objects that are one byte or larger in size.)

If an entry object is bit data, padding must be entered to adjust the boundaries. Padding is meaning-less data that is added to the end of an entry so that an object ends at a boundary of the specified size. You can use the following methods to arrange objects within byte boundaries.

- Click the Align Button.
 Padding is automatically entered. Refer to the descriptions of the buttons below for details.
- · Add padding to the PDO entries manually.

In the following example, 2 bits of padding are entered to adjust the byte boundary when entering objects with BIT2 and BIT4 data types for PDO entries.


	Index	Size	Data type	PDO entry name	Comment
	0x6000:00	16[bit]	UINT	uiAAA	
	0x6001:00	2[bit]	BIT2	b2BBB	
	0x6002:00	4[bit]	BIT4	b4CCC	
4	0x0000:00	2[bit]			
/`	0x6010:00	32[bit]	UDINT	udEEE	

Because an object with 2 bits and an object with 4 bits are entered, 2 bits of padding must be added to adjust the byte boundary (8 bits).

Connecting to Slaves from Other Manufacturers

When connecting a slave from another manufacturer, refer to the manuals for the other manufacturer's slaves, and then ask your OMRON representative if you have any questions.

The following buttons are used to edit a PDO entry table. The meanings of the buttons are given below.



Add PDO Entry Button and Delete PDO Entry Button

Use these buttons to add objects to and delete objects from the PDO entry table. "0x0000:00" is for padding. The default size is 8 bits.

Edit PDO Entry Button

Use this button to change the size of padding (i.e., the number of bits) in the PDO mapping.

Move Up Button and Move Down Button

Use these buttons to change the order of the PDO entries by moving objects up and down.

Align Button

Use this button to automatically order the PDO entries and adjust byte boundaries.

The PDO entries are ordered according to the type, descending PDO entry size, ascending indices, and then ascending subindices.

For the type, data arranged by byte boundaries (INT, BYTE, STRING, etc.) comes first, followed by data arranged by bit boundaries (BIT, BIT8, etc.).



Version Information


- Sysmac Studio version 1.08 or higher is required to use the following buttons to edit PDO entry tables: Edit PDO Entry, Move Up, Move Down, and Align.
- Sysmac Studio version 1.08 or higher is required to add "0x0000:00" to a PDO entry table.

Editing Methods for PDO Entries

Adding PDO Entries


Click the **Add PDO Entry** Button. The entry table from the slave is displayed. Select the object to add with the cursor and click the **OK** Button to add it.

The selected object is added at the location of the cursor in the PDO entry table.



Editing PDO Entries

Use the cursor to select padding (0x0000:00) in the PDO entry table and click the **Edit PDO Entry** Button. Enter the size and click the **OK** Button. The size of the padding will change.



A-4 Glossary

Use the following list of EtherCAT terms for reference.

Term	Abbrevia- tion	Description
AL status (application layer status)	-	Status for indicating information on errors that occur in an application on a slave.
CAN application protocol over Ether- CAT	CoE	A CAN application protocol service implemented on EtherCAT.
CAN in Automation	CiA	CiA is the international users' and manufacturers' group that develops and supports higher-layer protocols.
device profile	_	Collection of device dependent information and functionality providing consistency between similar devices of the same device type.
device variables	_	Variables in the NJ-series CPU Unit to which process data on Ether-CAT slaves are allocated. Slave process data is accessed by directly reading and writing these device variables from user applications on the NJ-series CPU Unit.
distributed clocks	DC	Clock distribution mechanism used to synchronize EtherCAT Slave Units and the EtherCAT Master Units.
EtherCAT Master Function Module	_	One of the function modules. This module controls the EtherCAT slaves as the EtherCAT master.
EtherCAT slave controller	ESC	A controller for EtherCAT slave communication.
EtherCAT slave information	ESI	An XML file that contains setting information for an EtherCAT Slave Unit.
EtherCAT state machine	ESM	An EtherCAT communication state machine.
EtherCAT Technology Group	ETG	The ETG is a global organization in which OEM, End Users and Technology Providers join forces to support and promote the further technology development.
index	_	Address of an object within an application process.
network configuration information	_	The EtherCAT network configuration information held by the Ether-CAT master.
object	_	Abstract representation of a particular component within a device, which consists of data, parameters, and methods.
object dictionary	OD	Data structure addressed by Index and Sub-index that contains description of data type objects, communication objects and application objects.
Operational	_	A state in EtherCAT communications where SDO communications and I/O are possible.
packet monitoring	_	A function that enables the EtherCAT master to capture packets flowing over an EtherCAT line and store them in the master. You can start and stop capturing packets from the Sysmac Studio or with EtherCAT communications instructions.
PDO communications	_	An acronym for process data communications.
Pre-operational	-	A state in EtherCAT communications where only SDO communications are possible without being able to perform I/O.
process data	_	Collection of application objects designated to be downloaded cyclically or acyclically for the purpose of measurement and control.
process data communications	-	One type of EtherCAT communications that uses process data objects (PDOs) to exchange information in realtime with a fixed cycle. This is also called PDO communications.
process data object	PDO	Structure described by mapping parameters containing one or several process data entities.
receive PDO	RxPDO	A process data object received by an EtherCAT Slave Unit.

Term	Abbrevia- tion	Description
Safe operational		A state in EtherCAT communications where only SDO communications and reading input data from slaves are possible. Outputs from slaves are not performed.
SDO communications	-	One type of EtherCAT communications that uses service data objects (SDOs) for communicating information when required.
service data object	SDO	CoE asynchronous mailbox communications where all objects in the object dictionary can be read and written.
Slave Information Interface	SII	Slave information that is stored in non-volatile memory in the slave.
subindex	-	Sub-address of an object within the object dictionary.
sync jitter	-	The offset in the operation timing between slaves.
sync manager	SM	Collection of control elements to coordinate access to concurrently used objects.
system-defined variable	-	A variable in the NJ-series CPU Unit for providing information such as the EtherCAT communications status and error status. Status information about EtherCAT communications is obtained by reading system-defined variables from user applications in the NJ-series CPU Unit.
transmission jitter	-	The jitter in the process data transmission period (ns).
transmit PDO	TxPDO	A process data object sent from an EtherCAT Slave Unit.
WireShark	-	Freeware for monitoring and capturing packets.

A-5 Version Information


This appendix describes the changes in and additions to functional specifications that were made for changes in the unit version of the CPU Units.

Changes in and Additions to Functional Specifications

The following table gives the unit version of the CPU Units and the Sysmac Studio version for each addition or change to the functional specifications.

Function	Addition/change	Reference	Unit version	Sysmac Studio version
Backup and restore operations	Addition	9-43 and 9-45	1.03	1.04
Enabling/disabling	Addition	5-22 and 5-24	1.04	1.05

Appendices



Index

Index

A		_EC_MBXSlavTbl	7-5, 7-11
		_EC_MsgErr	
AL status	A-25	_EC_MstrErr	
assumed causes	9-9	_EC_NetCfgCmpErr	
Axis Settings	5-12	_EC_NetCfgErr	
Axis Variables	3-6	_EC_NetTopologyErr	
		_EC_PDActive	
В		_EC_PDCommErr	
		_EC_PDSendErr	
backing up		_EC_PDSlavTbl	
2-10, 2-12, 2-14, 5-23, 5-31, 5-35, 9-11,		_EC_PDTimeoutErr	
9-46, 9-48	,,,	_EC_PktMonStop	
Backup Parameter Settings	5-23	_EC_PktSaving	
Built-in EtherCAT Error		_EC_PortErr	
	2, 7 0, 0 0	_EC_RegSlavTbl	
C		_EC_SlavAdrDupErr	7-3, 7-9
		_EC_SlavAppErr	7-3, 7-9
CAN application protocol over EtherCAT	2 2 1 25	_EC_SlavEmergErr	7-3, 7-10
CAN in Automation		_EC_SlavErr	7-3, 7-7, 9-5
		_EC_SlavErrTbl	7-3, 7-7, 9-5
CiA		_EC_SlavInitErr	7-3, 7-9
CoE		Emergency Message Detected	7-3, 7-10
communications cables	•	Enable Distributed Clock	5-22
Communications Controller Error		Enable/Disable EtherCAT Slave	6-17
Communications Error Slave Table		enable/disable setting	6-18
Communications Port Error		Enable/Disable Settings	5-22
communications port errors		errors	
comparing and merging		checking for errors	9-3
connected/disconnected setting		sources	9-6
control states	3-8	status variables	9-5
D		ESC	A-25
D		ESI	A-25
		ESI files	1-6, A-15, A-16
DC	•	ESM	A-25
Device name	•	ETG	A-25
device profile		EtherCAT communications	3-1
device variables		EtherCAT features	1-2
diagnostic and statistical information		EtherCAT instructions	6-13, 6-17
Disabled Slave Table		EtherCAT Junction Slave	
Disconnected Slave Table		EtherCAT master	
distributed clocks	3-3, A-25	setting	5-17
_		EtherCAT master errors	
E		EtherCAT Master Function Module	
		EtherCAT Message Error	
EC_ChangeEnableSetting	6-17, 6-18	EtherCAT slave controller	
_EC_CommErrTbl	7-3, 7-10	EtherCAT Slave Enable/Disable Settings	
_EC_DisableSlavTbl	7-5, 7-11	EtherCAT slave errors	
_EC_DisconnSlavTbl	7-5, 7-11	EtherCAT slave information	
_EC_EntrySlavTbl		EtherCAT slave information file	
_EC_ErrSta		EtherCAT slaves	
_EC_InDataInvalid		setting	
_EC_LanHwErr		EtherCAT state machine	
_EC_LinkOffErr		EtherCAT Technology Group	
_EC_LinkStatus	7-5, 7-12	event codes	

_EC_MacAdrErr7-3, 7-7

events	9-2 objects
	observation event level9-7
F	ODA-25
	Operational3-9, A-25
Fail-soft Operation Setting	5-18 output ports 1-4
forced refreshing	6-11
G	P
<u>G</u>	packet monitoring A-7, A-25
Get EtherCAT Error Status instruction	
Get Ethero, it End Glatas motivation	partial fault event level
I	PDOA-25
·	PDO communications
I/O power supply	DD0.0 : :: 0 T
I/O refreshing	500
index	DDO Mar Cattings
indicators	720
information event level	and a section of the
Init	0.0.4.05
Input Data Invalid	
installation	12 .
communication cables	1.05
instructions	Process Data Communicating Slave Table 7-5, 7-11
GetECError	
Gelegenor	Process Data Communications Error
L	Process Data Communications Status7-5, 7-12
	process data objects
lavala	Process Data Reception Timeout
levels	Process Data Recention Timeout Error 7-0
events	Process Data Transmission Error 7.2.7.0
Link OFF Error7-3 Link Status7-5,	7-0 Draduat name
LINK Status7-5,	-12
M	R
	receive PDO
MAC Address Error7-3	7-1 Deference Clark
major fault event level	9-7
major fault level Controller errors	6-10 relation between changes in the enable/
Master Error7-2, 7-7	displie acting and I/O energtions
Message Communications Enabled Slave Table	rectoring 2.10.2.12.2.14.5.22.0.12.0.20.0.46.0.47
minor fault event level	Dovision F 24
Model 5-18,	5-21 Revision Check Method
	RxPDO
N	A-25
Natwork Configuration Error 7.3	S
Network Configuration Error	
network configuration information5-2, Adams and downloading	Safa aparational 2.0 A.26
downloading	Soving Docket Data File 7.5.7.12
Network Configuration Information Error	1-0
network configuration verification	9-20 SDO communications 2.2.2.5.6.42.4.26
Network Configuration Verification Error	1-0
Network Connected Slave Table	7-10
node addresses	Sarial Number 5-22
non-synced slaves	1-0 Carial Number Check Mathed 5-19
Number of Slaves	service data objectsA-26
0	Setting Parameters
0	SII
11. 4.8.6	Slave Application Error 7-3, 7-9
object dictionary3-3, A	A-25 Slave Error

Slave Error Table	7-3, 7-7, 9-5
Slave Information Interface	A-26
Slave Initialization Error	7-3, 7-9
Slave Node Address Duplicated Error	7-3, 7-9
slaves	
replacing	
SM	A-26
subindex	
sync manager	
synced slaves	
Sysmac devices	
features	
Sysmac Studio	
system configuration	
system response time	
system-defined variables3-6,	
EtherCAT communications errors	
EtherCAT communications status	7-5, 7-10
<u>T</u>	
topologies	
Total Cable Length	
transmit PDO	
Troubleshooter	
troubleshooting	
TxPDO	A-26
U	
unit power supplies	
v	
version5-2	23, 6-13, A-27
W	
Wait Time for Slave Startup	5-18
Murat harl	V 06

OMRON Corporation Industrial Automation Company

Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters OMRON EUROPE B.V.

Wegalaan 67-69-2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

One Commerce Drive Schaumburg, IL 60173-5302 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2011 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. W505-E1-08