# OMRON

## **Machine Automation Controller**

**NJ/NX-series** 

## **CPU Unit Built-in EtherCAT® Port**

## **User's Manual**

NX701-1□□□

NX102-

**NX1P2-1** 

**NX1P2-9** 

**NJ501-**□□□□

**NJ301-1**□□□

NJ101-10□□

NJ101-90□□

**CPU Unit** 





#### NOTE -

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

#### Trademarks -

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD and SDHC logos are trademarks of SD-3C, LLC.





Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

#### Copyrights

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

## Introduction

Thank you for purchasing an NJ/NX-series CPU Unit.

This manual contains information that is necessary to use the NJ/NX-series CPU Unit. Please read this manual and make sure you understand the functionality and performance of the NJ/NX-series CPU Unit before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

#### **Intended Audience**

This manual is intended for the following personnel, who must also have knowledge of electrical systems (an electrical engineer or the equivalent).

- · Personnel in charge of introducing FA systems.
- Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- · Personnel in charge of managing FA systems and facilities.

For programming, this manual is intended for personnel who understand the programming language specifications in international standard IEC 61131-3 or Japanese standard JIS B 3503.

### **Applicable Products**

This manual covers the following products	This manual	covers	the	following	products
---	-------------	--------	-----	-----------	----------

- NX-series CPU Units
   NX701-17□□
   NX701-16□□
   NX102-12□□
  - NX102-11□□NX102-10□□
  - NX102-90□□
  - NX1P2-11□□□□
  - NX1P2-11□□□□1
  - NX1P2-10□□□□
  - NX1P2-10□□□□1
  - NX1P2-90□□□□
  - NX1P2-90□□□□1
- · NJ-series CPU Units
  - NJ501-□5□□
  - NJ501-□4□□
  - NJ501-□3□□
  - NJ301-12□□
  - NJ301-11□□
  - NJ101-10□□
  - NJ101-90□□

Part of the specifications and restrictions for the CPU Units are given in other manuals. Refer to *Relevant Manuals* on page 2 and *Related Manuals* on page 23.

## **Relevant Manuals**

The following table provides the relevant manuals for the NJ/NX-series CPU Units. Read all of the manuals that are relevant to your system configuration and application before you use the NJ/NX-series CPU Unit.

Most operations are performed from the Sysmac Studio Automation Software. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on the Sysmac Studio.

												1	Mar	nual	l													—
			Bas	sic	info	rma	tion																					
Purpose of use	NX-series CPU Unit Hardware User's Manual	Hardware User's Manual	Hardware User's Manual	NX-series NX1P2 CPU Unit	Hardware User's Manual	Software User's Manual	NJ/NX-series CPU Unit	NX-series NX1P2 CPU Unit	Instructions Reference Manual	NJ/NX-series	NJ/NX-series CPU Unit Motion Control User's Manual	Motion Control Instructions Reference Manua	NJ/NX-series	Built-in EtherCAT Port User's Manual	NJ/NX-series CPU Unit	NJ/NX-series CPU Unit	OPC UA User's Manual	NJ/NX-series CPU Unit	FINS Function User's Manual	NX-series CPU Unit	User's Manual	User's Manual	NJ-series SECS/GEM CPU Units	CPU Unit User's Manual	NJ-series NJ Robotics	NJ/NY-series NC Integrated Controller User's Manual	N I/NY parisa NG Interretal Controller	NJ/NX-series
Introduction to NX701 CPU Units	•					+						F			-		-										+	—
Introduction to NX101 CPU Units	-	•	+			+	+					+			+		+										+	
Introduction to NX102 CPU Units			+.	•						_		╁			-		+			_		+		-			+	
Introduction to NJ-series Controllers			+	_	•	-	+					-			+												+	
Setting devices and hardware	•	•	+,	•	•	+																						
Using motion control	1			•		-					•	-																
Using EtherCAT	1													•	,												T	
Using EtherNet/IP	1															•	1											
Software settings			$\dagger$			(	•			1		t			$\dagger$		t		$\vdash$	7		$\dagger$		H			t	
Using motion control							ŀ				•				1												T	
Using EtherCAT						1	ľ							•	,												T	
Using EtherNet/IP							ľ									•												
Using OPC UA			T				j										1	•									T	
Using FINS							ľ												•	•								
Using the database connection service			$\dagger$			1	f														•						T	
Using the GEM Services	1					1	ŀ								$\neg$								•				t	
Using robot control						1	ľ								$\exists$									•			T	
Using numerical control			T				j										Ì									•	T	
Using the NX1P2 CPU Unit functions	İ					1	Ī	•							1							T					T	


															М	anı	ıal													
			E	3as	ic i	nfo	rm	ati	on																					
Purpose of use	Hardware User's Manual	Hardware User's Manual	NX-series NX102 CPU Unit	Hardware User's Manual	NX-series NX1P2 CPU Unit	Hardware User's Manual	N.L. Spring CPII IInit	NO/NA-Series CPO Unit	N I/NY corios CBI I linit	NX-series NX1P2 CPU Unit	Instructions Reference Manual	NJ/NX-series	Motion Control User's Manual	NJ/NX-series CPU Unit	Motion Control Instructions Reference Manual	NJ/NX-series	NJ/NX-series CPU Unit	Built-in EtherNet/IP Port User's Manual	NJ/NX-series CPU Unit	OPC UA User's Manual	NJ/NX-series CPU Unit	NA-series CFO Onit FINS Function User's Manual	User's Manual	NJ/NX-series Database Connection CPU Units	User's Manual	NJ-series SECS/GEM CPU Units	NJ-series NJ Robotics  CPU Unit User's Manual	User's Manual	NJ/NY-series NC Integrated Controller	NJ/NX-series Troubleshooting Manual
Writing the user program								•			+	•		<u> </u>	_											$\dashv$				
Using motion control								•	-			•	•	,	•	,		1			_					_			+	
Using EtherCAT													_		_		•				<b>-</b> †					_				
Using EtherNet/IP																	_		•		1									
Using OPC UA																1				•	,				<u> </u>					
Using FINS																					1	•								
Using the database connection service											-													•	-					
Using the GEM Services																					_				•	,				
Using robot control																					1				Ħ		•			
Using numerical control																												•	,	
Programming error processing																										$\neg$				•
Using the NX1P2 CPU Unit functions										•																$\neg$				
Testing operation and debugging								•													1					一				
Using motion control													•	,																
Using EtherCAT																	•													
Using EtherNet/IP																			•		j								1	
Using OPC UA									T											•	,								1	
Using FINS							1		T					T							T	•				T			T	
Using the database connection service	1				1		$\exists$		F					T		$\top$		T			$\dashv$		T	•	T	$\exists$		1	T	
Using the GEM Services	1				1		$\exists$		F					T		$\top$		T			$\dashv$		T		•	,		1	T	
Using robot control							1							T		T					T					$\dashv$	•	1	1	
Using numerical control							1		r					T				1			T					T		•	,	
Using the NX1P2 CPU Unit functions	L									•											Ţ							Ĺ		
Learning about error management and corrections *1																				Δ	,	Δ		Δ	Δ	7	Δ	Δ	7	•
Maintenance							1		1												Ţ				Г	T				
Using motion control			_	_		_			1				•	•							T					T			T	
Using EtherCAT	<b></b>	'	•	•		•			T								•				T								1	
Using EtherNet/IP	1						l		T					T					•		Ţ					7			1	

<sup>\*1</sup> Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for the error management concepts and the error items. However, refer to the manuals that are indicated with triangles(△) for details on errors corresponding to the products with the manuals that are indicated with triangles(△).

## **Manual Structure**

## **Page Structure**

The following page structure is used in this manual.



This illustration is provided only as a sample. It may not literally appear in this manual.

## **Special Information**

Special information in this manual is classified as follows:



#### **Precautions for Safe Use**

Precautions on what to do and what not to do to ensure safe usage of the product.



#### **Precautions for Correct Use**

Precautions on what to do and what not to do to ensure proper operation and performance.



#### Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.

Note References are provided to more detailed or related information.

## **Precaution on Terminology**

In this manual, "download" refers to transferring data from the Sysmac Studio to the physical Controller and "upload" refers to transferring data from the physical Controller to the Sysmac Studio.

For the Sysmac Studio, synchronization is used to both upload and download data. Here, "synchronize" means to automatically compare the data for the Sysmac Studio on the computer with the data in the physical Controller and transfer the data in the direction that is specified by the user.

Manual Structure

## **Sections in this Manual**

			1	A
1	Introduction A Appe	endices	2	ı
2	Part Names and Slave Settings Index	x		3
3	EtherCAT Communications			4 5
4	EtherCAT Network Wiring			6
5	Setting Up EtherCAT Communicati with the Sysmac Studio	ons		7
6	Process Data Communications and SDO Communications			8
7	System-defined Variables That Are to the Built-in EtherCAT Port	Related		9
8	Example of Operations for EtherCA	AT Communications		
9	Troubleshooting			

## **CONTENTS**

	Intr	Oduction Intended Audience Applicable Products	1
	Rel	evant Manuals	2
	Mar	Page Structure Special Information Precaution on Terminology	4 4
	Sec	tions in this Manual	7
	Teri	ms and Conditions Agreement  Warranty, Limitations of Liability  Application Considerations  Disclaimers	12 13
	Saf	ety Precautions	14
	Pre	cautions for Safe Use	15
	Pre	cautions for Correct Use	16
	Reg	Conformance to EU Directives Conformance to KC Standards Conformance to Shipbuilding Standards Software Licenses and Copyrights	17 18 18
	Ver	Checking Versions	19
	Rela	ated Manuals	23
Section		ision HistoryIntroduction	26
	1-1	Introduction to EtherCAT  1-1-1 EtherCAT Features  1-1-2 EtherCAT Communications  1-1-3 EtherCAT Features for NJ/NX-series CPU Units	1-2 1-2
	1-2	System Configuration and Configuration Devices.  1-2-1 System Configuration	<b>1-4</b>
	1-3	Specifications of Built-in EtherCAT Port	
	1-4	Introduction of Communications	<b>1-12</b> 1-12
	1-5	EtherCAT Communications Procedure	

	1-5-2	Details	1-15
Section	2	Part Names and Slave Settings	
2-	.1 Part	Names and Functions	2-2
2-	2-1-1	Built-in EtherCAT Port Indicators	
	2-1-2	Windows Used in Sysmac Studio	
	2-1-3	Connecting the Sysmac Studio	
2-	-2 Setti	ng the Node Addresses of the EtherCAT Slaves	2-9
2-	-3 Featu	ıres of Sysmac Devices	2-12
	2-3-1	Sysmac Devices	2-12
	2-3-2	Sysmac Device Features	
	2-3-3 2-3-4	List of Sysmac DevicesSysmac Device Features and EtherCAT Masters	
		-,	
Section	3	EtherCAT Communications	
3-	-1 Ethe	CAT Communications Types and Settings	
	3-1-1	CoE (CAN Application Protocol over EtherCAT)	
	3-1-2	Types of Communications	
	3-1-3	Types of EtherCAT Variables	
	3-1-4	Settings Required for EtherCAT Communications	
3-	_	ramming EtherCAT Communications	
3-	-3 State	Transitions for EtherCAT Communications	
	3-3-1	Self Diagnosis at Startup	3-9
	3-3-2 3-3-3	Control States for EtherCAT Communications	
Section	4	EtherCAT Network Wiring	
4-	1 Lavir	ng the EtherCAT Network	4.5
4-	∙ı ∟ayıı 4-1-1	Supported Network Topologies	
	4-1-1	Installation Precautions	
	–	Installing EtherCAT Communications Cables	
	4-1-4	Connecting Communications Cables	
	4-1-5	Cable Connection Procedure	
Section	5	Setting Up EtherCAT Communications with	
		the Sysmac Studio	
5-	-1 Over	view of Network Configuration Information	5-2
5-	-2 Crea	ting the EtherCAT Network Configuration	5-3
5-	-3 Setti	ng EtherCAT Slave Variables and Axes	5-6
	5-3-1	Registering Device Variables for All EtherCAT Slaves	
	5-3-2	Axis Settings for Servo Drives and Encoder Input Slaves	5-10
5-	4 Ethe	CAT Master and Slave Parameter Settings	
	5-4-1	Setting EtherCAT Master	5-11
	5-4-2	Setting EtherCAT Slaves	5-16
5-	-5 Com	paring and Merging EtherCAT Network Configurations	5-24
•	5-5-1	Comparing and Merging with the Actual Network Configuration from the Sysmac Studio	
	5-5-2	Automatically Creating the Network Configuration	
	5-5-3	Using the Sysmac Studio to Obtain Serial Numbers from the Actual	
		Network Configuration	5-32

5-6	Downloading the Network Configuration Information	
	5-6-1 Downloading the Network Configuration Information from the Sysmac Studio	5-34
5-7	Confirming Communications after Completing  EtherCAT Configuration and Settings	5-36
Section 6	Process Data Communications and SDO Communications	
6-1	Process Data Communications (PDO Communications)	6-2
0.	6-1-1 Allocated Variables for Process Data Communications	
	6-1-2 Process Data Communications Refresh Timing	
	6-1-3 Checking the Validity of the Process Data	
	6-1-4 System Response Time in Process Data Communications	
	Specified Values	
6-2	SDO Communications	
	6-2-1 EtherCAT Instructions	
	6-2-2 Sample Programming	
	6-2-3 Execution Timing of SDO Communications	
6-3	Instructions Used in EtherCAT Communications	
7-1	System-defined Variables That Are Related to the Built-in EtherCAT Port	7-2 7-3
Section 8		
	· · ·	
8-1	Example of Operations for EtherCAT Communications	
	8-1-1 System Configuration Example	
	8-1-3 Setting the EtherCAT Network Configuration	
	8-1-4 Programming	
	8-1-5 Offline Debugging	
	8-1-6 Turning the Power ON	
	8-1-7 Online Debugging	
	8-1-8 Downloading the Network Configuration Information and the User Program	
Section 9	Troubleshooting	
9-1	Overview of Errors	9-2
9-1	Troubleshooting	
3-2	9-2-1 Diagnostic and Statistical Information	
	9-2-2 Identifying an Error Slave and Cause of Error	
9-3	Precautions When Connecting or Disconnecting Slaves during Communications	
<b>3-3</b>	9-3-1 Procedure for Connecting and Disconnecting Slaves during Communications 9-3-2 Prohibition to Physically Disconnecting a Slave and Resetting an Error	
	or Connecting a Slave at the Same Time	9-24

9-4	Replacing Slaves during Communications	9-25
	9-4-2 Slave Replacement Methods	9-26
	9-4-5 Replacement Procedure	9-30
ndic	ces	
A-1	EtherCAT Status in Relation to CPU Unit Status	A-2
	A-1-2 CPU Unit Operating Modes	A-3
	A-1-3 Controller Errors Other Than Errors in the Built-in EtherCAT Master	A-5
	A-1-5 When the Power Supply Is Turned OFF	A-7
<b>A-2</b>	Monitoring Packets	A-8
<b>A-3</b>	Multi-vendor Environments	A-17
	A-3-1 EtherCAT Slave Information File (ESI Files)	A-17
	A-3-2 Connecting Slaves from Other Manufacturers to an OMRON Master	A-19
	A-3-5 Settings for MDP-compatible Slaves from Other Manufacturers	A-30
A-4	Glossary	A-33
A-5	Version Information	A-35
	A-2 A-3	9-4-1 Introduction 9-4-2 Slave Replacement Methods 9-4-3 Backing Up Settings 9-4-4 Restoring Settings 9-4-5 Replacement Procedure  A-1 EtherCAT Status in Relation to CPU Unit Status A-1-1 When the Power Supply Is Turned ON A-1-2 CPU Unit Operating Modes A-1-3 Controller Errors Other Than Errors in the Built-in EtherCAT Master A-1-4 Others A-1-5 When the Power Supply Is Turned OFF  A-2 Monitoring Packets A-3 Multi-vendor Environments A-3-1 EtherCAT Slave Information File (ESI Files) A-3-2 Connecting Slaves from Other Manufacturers to an OMRON Master A-3-3 Installing ESI Files A-3-4 Editing PDO Entry Tables A-3-5 Settings for MDP-compatible Slaves from Other Manufacturers  A-4 Glossary

## **Terms and Conditions Agreement**

### Warranty, Limitations of Liability

### **Warranties**

### Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

#### Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

#### Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

## Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

### **Application Considerations**

### **Suitability of Use**

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

### **Programmable Products**

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

#### **Disclaimers**

### **Performance Data**

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

## **Change in Specifications**

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

#### **Errors and Omissions**

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

## **Safety Precautions**

Refer to the following manuals for safety precautions.

- NX-series CPU Unit Hardware User's Manual (Cat No. W535)
- NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593)
- NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
- NJ-series CPU Unit Hardware User's Manual (Cat No. W500)

## **Precautions for Safe Use**

Refer to the following manuals for precautions for safe use.

- NX-series CPU Unit Hardware User's Manual (Cat No. W535)
- NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593)
- NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
- NJ-series CPU Unit Hardware User's Manual (Cat No. W500)

## **Precautions for Correct Use**

Refer to the following manuals for precautions for correct use.

- NX-series CPU Unit Hardware User's Manual (Cat No. W535)
- NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593)
- NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578)
- NJ-series CPU Unit Hardware User's Manual (Cat No. W500)

## Regulations and Standards

#### Conformance to EU Directives

### **Applicable Directives**

- EMC Directives
- · Low Voltage Directive

### Concepts

#### EMC Directive

OMRON devices that comply with EU Directives also conform to the related EMC standards so that they can be more easily built into other devices or the overall machine. The actual products have been checked for conformity to EMC standards.\*

Whether the products conform to the standards in the system used by the customer, however, must be checked by the customer. EMC-related performance of the OMRON devices that comply with EU Directives will vary depending on the configuration, wiring, and other conditions of the equipment or control panel on which the OMRON devices are installed. The customer must, therefore, perform the final check to confirm that devices and the overall machine conform to EMC standards.

\* Applicable EMC (Electromagnetic Compatibility) standards are as follows: EMS (Electromagnetic Susceptibility): EN 61131-2 EMI (Electromagnetic Interference): EN 61131-2 (Radiated emission: 10-m regulations)

#### Low Voltage Directive

Always ensure that devices operating at voltages of 50 to 1,000 VAC and 75 to 1,500 VDC meet the required safety standards. The applicable directive is EN 61010-2-201.

#### Conformance to EU Directives

The NJ/NX-series Controllers comply with EU Directives. To ensure that the machine or device in which the NJ/NX-series Controller is used complies with EU Directives, the Controller must be installed as follows:

- The NJ/NX-series Controller must be installed within a control panel.
- You must use the power supply in SELV specifications for the DC power supplies connected to DC Power Supply Units and I/O Units.
- NJ/NX-series Controllers that comply with EU Directives also conform to the Common Emission Standard (EN 61000-6-4). Radiated emission characteristics (10-m regulations) may vary depending on the configuration of the control panel used, other devices connected to the control panel, wiring, and other conditions.

You must therefore confirm that the overall machine or equipment complies with EU Directives.

#### **Conformance to KC Certification**

Observe the following precaution if you use NX-series Units in Korea.

A급 기기 (업무용 방송통신기자재) 이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Class A Device (Broadcasting Communications Device for Office Use)

This device obtained EMC registration for office use (Class A), and it is intended to be used in places other than homes.

Sellers and/or users need to take note of this.

### **Conformance to Shipbuilding Standards**

The NJ/NX-series Controllers comply with the following shipbuilding standards. Applicability to the shipbuilding standards is based on certain usage conditions. It may not be possible to use the product in some locations. Contact your OMRON representative before attempting to use a Controller on a ship.

### Usage Conditions for NK and LR Shipbuilding Standards

- The NJ/NX-series Controller must be installed within a control panel.
- Gaps in the door to the control panel must be completely filled or covered with gaskets or other material.
- The following noise filter must be connected to the power supply line.

#### **Noise Filter**

Manufacturer	Model
Cosel Co., Ltd.	TAH-06-683

### **Software Licenses and Copyrights**

This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj\_info\_e/.

## **Versions**

Hardware revisions and unit versions are used to manage the hardware and software in NJ/NX-series Units and EtherCAT slaves. The hardware revision or unit version is updated each time there is a change in hardware or software specifications. Even when two Units or EtherCAT slaves have the same model number, they will have functional or performance differences if they have different hardware revisions or unit versions.


### **Checking Versions**

You can check versions on the ID information indications or with the Sysmac Studio.

## **Checking Unit Versions on ID Information Indications**


The unit version is given on the ID information indication on the side of the product.

The ID information on an NX-series NX701-□□□□ CPU Unit is shown below.




**Note** The hardware revision is not displayed for the Unit that the hardware revision is in blank.

The ID information on an NX-series NX102- $\square\square\square$  CPU Unit is shown below.




Note The hardware revision is not displayed for the Unit that the hardware revision is in blank.

The ID information on an NX-series NX1P2
CPU Unit is shown below.



Note The hardware revision is not displayed for the Unit that the hardware revision is in blank.

The ID information on an NJ-series NJ501- CPU Unit is shown below.



Note The hardware revision is not displayed for the Unit that the hardware revision is in blank.

## **Checking Unit Versions with the Sysmac Studio**

You can use the Sysmac Studio to check unit versions. The procedure is different for Units and for EtherCAT slaves.

#### Checking the Unit Version of an NX-series CPU Unit

You can use the Production Information while the Sysmac Studio is online to check the unit version of a Unit. You can do this for the following Units.

Model	Unit for which unit version can be checked
NX701-□□□□	CPU Unit
NX102-□□□□	CPU Unit and NX Unit on CPU Rack
NX1P2-□□□	CPU Unit, NX Unit on CPU Rack, and Option Boards

1 Right-click CPU Rack under Configurations and Setup - CPU/Expansion Racks in the Multiview Explorer and select *Production Information*.

The Production Information Dialog Box is displayed.

#### Checking the Unit Version of an NJ-series CPU Unit

You can use the Production Information while the Sysmac Studio is online to check the unit version of a Unit. You can do this for the CPU Unit, CJ-series Special I/O Units, and CJ-series CPU Bus Units. You cannot check the unit versions of CJ-series Basic I/O Units with the Sysmac Studio.

Use the following procedure to check the unit version.

1 Double-click CPU/Expansion Racks under Configurations and Setup in the Multiview Explorer. Or, right-click CPU/Expansion Racks under Configurations and Setup and select Edit from the menu.


The Unit Editor is displayed.


**2** Right-click any open space in the Unit Editor and select **Production Information**. The Production Information Dialog Box is displayed.

#### Changing Information Displayed in Production Information Dialog Box

1 Click the **Show Detail** or **Show Outline** Button at the lower right of the Production Information Dialog Box.

The view will change between the production information details and outline.





Outline View

**Detail View** 

The information that is displayed is different for the Outline View and Detail View. The Detail View displays the unit version, hardware version, and software versions. The Outline View displays only the unit version.

**Note** The hardware revision is separated by "/" and displayed on the right of the hardware version. The hardware revision is not displayed for the Unit that the hardware revision is in blank.

#### Checking the Unit Version of an EtherCAT Slave


You can use the Production Information while the Sysmac Studio is online to check the unit version of an EtherCAT slave. Use the following procedure to check the unit version.


- 1 Double-click **EtherCAT** under **Configurations and Setup** in the Multiview Explorer. Or, right-click **EtherCAT** under **Configurations and Setup** and select *Edit* from the menu.
  - The EtherCAT Tab Page is displayed.
- Right-click the master on the EtherCAT Tab Page and select *Display Production Information*.
  The Production Information Dialog Box is displayed.
  The unit version is displayed after "Rev."

#### • Changing Information Displayed in Production Information Dialog Box

1 Click the **Show Detail** or **Show Outline** Button at the lower right of the Production Information Dialog Box.

The view will change between the production information details and outline.





Outline View

**Detail View** 

## **Unit Versions of CPU Units and Sysmac Studio Versions**

The functions that are supported depend on the unit version of the NJ/NX-series CPU Unit. The version of Sysmac Studio that supports the functions that were added for an upgrade is also required to use those functions.

Refer to the *NJ/NX-series CPU Unit Software User's Manual* (Cat. No. W501-E1-02 or later) for the relationship between the unit versions of the CPU Units and the Sysmac Studio versions, and for the functions that are supported by each unit version.

## **Related Manuals**

The followings are the manuals related to this manual. Use these manuals for reference.


Manual name	Cat. No.	Model numbers	Application	Description
NX-series CPU Unit Hardware User's Manual	W535	NX701-□□□□	Learning the basic specifications of the NX701 CPU Units, including introductory information, designing, installation, and maintenance.  Mainly hardware information is provided.	An introduction to the entire NX701 system is provided along with the following information on the CPU Unit.  • Features and system configuration  • Introduction  • Part names and functions  • General specifications  • Installation and wiring  • Maintenance and inspection
NX-series NX102 CPU Unit Hardware User's Manual	W593	NX102-□□□	Learning the basic specifications of the NX102 CPU Units, including introductory information, designing, installation, and maintenance.  Mainly hardware information is provided.	An introduction to the entire NX102 system is provided along with the following information on the CPU Unit.  • Features and system configuration  • Introduction  • Part names and functions  • General specifications  • Installation and wiring  • Maintenance and inspection
NX-series NX1P2 CPU Unit Hardware User's Manual	W578	NX1P2-□□□□	Learning the basic specifications of the NX1P2 CPU Units, including introductory information, designing, installation, and maintenance.  Mainly hardware information is provided.	An introduction to the entire NX1P2 system is provided along with the following information on the CPU Unit.  • Features and system configuration  • Introduction  • Part names and functions  • General specifications  • Installation and wiring  • Maintenance and inspection
NJ-series CPU Unit Hardware User's Manual	W500	NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning the basic specifications of the NJ-series CPU Units, including introductory information, designing, installation, and maintenance.  Mainly hardware information is provided.	An introduction to the entire NJ-series system is provided along with the following information on the CPU Unit.  Features and system configuration  Introduction  Part names and functions  General specifications  Installation and wiring  Maintenance and inspection
NJ/NX-series CPU Unit Software User's Manual	W501	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning how to program and set up an NJ/NX- series CPU Unit. Mainly software informa- tion is provided.	The following information is provided on a Controller built with an NJ/NX-series CPU Unit.  CPU Unit operation  CPU Unit features  Initial settings  Programming based on IEC 61131-3 language specifications
NX-series NX1P2 CPU Unit Built-in I/O and Option Board User's Manual	W579	NX1P2-□□□□	Learning about the details of functions only for an NX-series NX1P2 CPU Unit and an introduction of functions for an NJ/NX-series CPU Unit.	Of the functions for an NX1P2 CPU Unit, the following information is provided.  Built-in I/O  Serial Communications Option Boards  Analog I/O Option Boards  An introduction of following functions for an NJ/NX-series CPU Unit is also provided.  Motion control functions  EtherNet/IP communications functions  EtherCAT communications functions

Manual name	Cat. No.	Model numbers	Application	Description
NJ/NX-series Instructions Reference Manual	W502	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning detailed specifi- cations on the basic instructions of an NJ/NX- series CPU Unit.	The instructions in the instruction set (IEC 61131-3 specifications) are described.
NJ/NX-series CPU Unit Motion Control User's Manual	W507	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning about motion control settings and programming concepts.	The settings and operation of the CPU Unit and programming concepts for motion control are described.
NJ/NX-series Motion Control Instruc- tions Reference Manual	W508	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning about the specifications of the motion control instructions.	The motion control instructions are described.
NJ/NX-series CPU Unit Built-in EtherCAT® Port User's Manual	W505	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Using the built-in EtherCAT port on an NJ/NX-series CPU Unit.	Information on the built-in EtherCAT port is provided.  This manual provides an introduction and provides information on the configuration, features, and setup.
NJ/NX-series CPU Unit Built-in EtherNet/IP <sup>™</sup> Port User's Manual	W506	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Using the built-in Ether- Net/IP port on an NJ/NX- series CPU Unit.	Information on the built-in EtherNet/IP port is provided. Information is provided on the basic setup, tag data links, and other features.
NJ/NX-series CPU Unit OPC UA User's Manual	W588	NX102-□□□ NJ501-1□00	Using OPC UA.	An introduction to the OPC UA is provided.
NX-series CPU Unit FINS Function User's Manual	W596	NX701-□□20 NX102-□□□□	Using the FINS function on the NX-series CPU Unit.	An introduction to the FINS function on the NXseries CPU Unit is provided.
NJ/NX-series Database Connection CPU Units User's Manual	W527	NX701-□□20 NX102-□□20 NJ501-□□20 NJ101-□□20	Using the database connection service with NJ/NX-series Controllers.	Describes the database connection service.
NJ-series SECS/GEM CPU Units User's Manual	W528	NJ501-1340	Using the GEM Services with NJ-series Controllers.	Provides information on the GEM Services.
NJ-series NJ Robotics CPU Unit User's Manual	W539	NJ501-4□□□	Controlling robots with NJ- series CPU Units.	Describes the functionality to control robots.
NJ/NY-series NC Inte- grated Controller User's Manual	O030	NJ501-5300 NY532-5400	Performing numerical control with NJ/NY-series Controllers.	Describes the functionality to perform the numerical control. Use this manual together with the <i>NJ/NY-series G code Instructions Reference Manual</i> (Cat. No. O031) when programming.
NJ/NY-series G code Instructions Ref- erence Manual	O031	NJ501-5300 NY532-5400	Learning about the specifications of the G code/M code instructions.	The G code/M code instructions are described. Use this manual together with the <i>NJ/NY-series NC Integrated Controller User's Manual</i> (Cat. No. O030) when programming.
NJ/NX-series Troubleshooting Manual	W503	NX701-□□□□ NX102-□□□□ NX1P2-□□□□ NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning about the errors that may be detected in an NJ/NX-series Controller.	Concepts on managing errors that may be detected in an NJ/NX-series Controller and information on individual errors are described.

Manual name	Cat. No.	Model numbers	Application	Description
Sysmac Studio Version 1 Operation Manual	W504	SYSMAC -SE2□□□	Learning about the operating procedures and functions of the Sysmac Studio.	Describes the operating procedures of the Sysmac Studio.
CNC Operator Operation Manual	O032	SYSMAC -RTNC0□□□D	Learning an introduction of the CNC Operator and how to use it.	An introduction of the CNC Operator, installation procedures, basic operations, connection operations, and operating procedures for main functions are described.
NX-series EtherCAT® Coupler Unit User's Manual	W519	NX-ECC	Learning how to use an NX-series EtherCAT Coupler Unit and EtherCAT Slave Terminals.	The following items are described: the overall system and configuration methods of an Ether-CAT Slave Terminal (which consists of an NX-series EtherCAT Coupler Unit and NX Units), and information on hardware, setup, and functions to set up, control, and monitor NX Units through EtherCAT.

## **Revision History**

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Revision code	Date	Revised content		
01	July 2011	Original production		
02	March 2012	Added information on the NJ301-□□□ and corrected mistakes.		
03	May 2012	<ul> <li>Added information on functional support for unit version 1.02 of the CPU Units.</li> <li>Corrected mistakes.</li> </ul>		
04	August 2012	Added information on functional support for unit version 1.03 of the CPU Units.     Corrected mistakes.		
05	February 2013	Added information on functional support for unit version 1.04 of the CPU Units.     Corrected mistakes.		
06	April 2013	<ul> <li>Added information on functional support for unit version 1.05 of the CPU Units.</li> <li>Corrected mistakes.</li> </ul>		
07	June 2013	Added information on functional support for unit version 1.06 of the CPU Units.     Corrected mistakes.		
08	September 2013	Added information on functional support for unit version 1.07 of the CPU Units.     Corrected mistakes.		
09	December 2013			
10	July 2014	Corrected mistakes.		
11	January 2015	<ul> <li>Added information on functional support for unit version 1.10 of the CPU Units.</li> <li>Corrected mistakes.</li> </ul>		
12	April 2015	<ul> <li>Added information on the NX701-□□□.</li> <li>Added information on the NJ101-□□□.</li> <li>Corrected mistakes.</li> </ul>		
13	April 2016	<ul> <li>Added information on functional support for unit version 1.11 of the CPU Units.</li> <li>Corrected mistakes.</li> </ul>		
14	October 2016	<ul> <li>Added information on the NX1P2-□□□□□.</li> <li>Corrected mistakes.</li> </ul>		
15	April 2017	Corrected mistakes.		
16	October 2017	Corrected mistakes.		
17	April 2018	Corrected mistakes.		

18	April 2018	<ul> <li>Added information on the NX102-□□□□.</li> <li>Collected descriptions on event codes and errors to the NJ/NX-series Troubleshooting Manual.</li> <li>Corrected mistakes.</li> </ul>
19	July 2018	Corrected mistakes.
20	October 2018	Corrected mistakes.

**Revision History** 



# Introduction

This section provides an overview of EtherCAT communications, describes the system configuration and specifications, and provides operating procedures.

1-1	اممیر	vetion to EthorCAT	4.2
1-1		uction to EtherCAT	
	1-1-1	EtherCAT Features	
	1-1-2	EtherCAT Communications	1-2
	1-1-3	EtherCAT Features for NJ/NX-series CPU Units	1-3
1-2	Syster	m Configuration and Configuration Devices	1-4
	1-2-1	System Configuration	1-4
	1-2-2	Determining the Network Configuration	1-8
1-3	Specif	ications of Built-in EtherCAT Port	1-9
	1-3-1	Performance Specifications	1-9
1-4	Introd	uction of Communications	1-12
	1-4-1	Process Data Communications and SDO Communications	1-12
	1-4-2	Other Functions	1-12
1-5	Ether	CAT Communications Procedure	1-14
	1-5-1	Overview	1-14
	1-5-2	Details	1-15

## Introduction to EtherCAT

EtherCAT (Ethernet Control Automation Technology) is a high-performance industrial network system that enables faster and more efficient communications based on Ethernet. Each node achieves a short communications cycle time by transmitting Ethernet frames at high speed. Furthermore, even though EtherCAT is a unique protocol, it offers excellent general-purpose applicability. For example, you can use Ethernet cables because EtherCAT utilizes standard Ethernet technology for the physical layer. And the effectiveness of EtherCAT can be fully utilized not only in large control systems that require high processing speeds and system integrity, but also in small and medium control systems.

#### 1-1-1 **EtherCAT Features**

EtherCAT provides the following features.

### **High-speed Communications at 100 Mbps**

The I/O response time from signal input to signal output has been significantly reduced. By fully utilizing the optimized Ethernet frame bandwidth to transmit data using a high-speed repeat method, it is possible to efficiently transmit a wide variety of data.


#### 1-1-2 **EtherCAT Communications**

EtherCAT does not send data to individual slave nodes on the network, instead, it passes Ethernet frames through all of the slave nodes.

When frame passes through a slave node, the slave node reads and writes data in the areas allocated to it in the frames in a few nanoseconds.

The Ethernet frames transmitted by the EtherCAT master pass through all EtherCAT slaves without stopping. The last slave returns all of the frames, which again pass through all of the slaves before returning to the EtherCAT master.

This mechanism ensures high speed and realtime data transmission.



#### 1-1-3 EtherCAT Features for NJ/NX-series CPU Units

EtherCAT in the NJ/NX-series CPU Units has the following features.

# Synchronization of the CPU Unit Processing Period and the EtherCAT Communications Cycle

The period of sequence processing and motion processing in the CPU Unit matches the process data communications cycle of EtherCAT.

This enables high-precision sequence control and motion control with a stable fixed period.

Also, with the NX701 CPU Unit, slaves to be synchronized can be divided into two groups with different process data communications cycles. This means that slaves are separately processed in one group that needs high-speed communications and the other that needs not.

# Accessing Data with Device Variables without Considering Addresses

EtherCAT slaves are accessed using device variables that are assigned to the I/O ports of the Ether-CAT slaves. Various types of data in Servo Drive and the encoder input slaves are accessed using structure-type Axis Variables prepared in advance.

This enables access to slaves on EtherCAT without regard to addresses.

# Optimum Functionality and Ease of Operation Based on Unified Specifications


You can use the NJ/NX-series Machine Automation Controllers together with Sysmac devices\* and the Sysmac Studio Automation Software to achieve optimum functionality and ease of operation.

\* "Sysmac devices" is a generic name for EtherCAT slaves and other OMRON control components that were designed with the same communications and user interface specifications.

## 1-2 **System Configuration and Configuration Devices**

#### **System Configuration** 1-2-1

The EtherCAT network configuration and configuration devices are shown below.



Outlines of the configuration devices are given below.

#### EtherCAT Master

The EtherCAT master manages the network, monitors the status of slaves, and exchanges I/O data with slaves. There is one output port.

#### Output Port

The output port transmits EtherCAT communications data to other devices. When you connect the output port to another device, always connect it to the input port on the other device. Normal communications will not be possible if you connect to the output port on another device.

#### Input Port

This port is used to input EtherCAT communications data. Always connect it to the output port on another device. Normal communications will not be possible if you connect to the input port on another device.

#### EtherCAT Slaves

Each EtherCAT slave outputs the output data that it received from the EtherCAT master through the EtherCAT network. It also sends input data to the EtherCAT master through the EtherCAT network.

- Each slave has one input port and at least one output port.
- In the EtherCAT network, you can use the salves and Junction Slaves that are listed below in total up to the maximum number of slaves.
- Assign node addresses to the slaves and Junction Slaves. The node address can be any value
  within the settable node address range, and can be assigned without any distinction between the
  slaves and Junction Slaves. But any node address should not be used more than once.
- The EtherCAT slaves can be classified into two: whether they support synchronization based on a distributed clock (DC) or not.
  - a) Non-synced Slaves
     These slaves perform sequence control that does not require synchronization between them.
     Digital I/O Slaves and Analog I/O Slaves are among this type. They do not support a distributed clock (DC).
  - b) Synced Slaves
    These slaves are synchronized based on the distributed clock (DC). Servo Drives and encoder input slaves are among this type.
- **Note 1** Refer to 1-3-1 Performance Specifications for details on the maximum number of slaves and the settable node address range.
  - **2** The slaves are synchronized even when multiple non-synced slaves and Junction Slaves are connected.

The following tables lists some of the OMRON EtherCAT slaves that are available.

Name	Туре	Model	Synced/ Non-synced Slaves	Reference Clock*1	Assigning an axis
Digital I/O Slaves	Slaves with screw terminals and 2-tier terminal block	GX-□D16□1/OC1601	Non-synced Slaves	Exist	Not possible
	Slaves with screw terminals and 3-tier terminal block	GX-ID16□2/OD16□2/MD16□2	Non-synced Slaves	Exist	Not possible
	Slaves with e-CON connectors	GX-□D16□8/□D32□8	Non-synced Slaves	Exist	Not possible
Analog I/O Slaves	Slaves with screw terminals and 2-tier terminal block	GX-AD0471/DA0271	Non-synced Slaves	Exist	Not possible
NX-series Ether- CAT Coupler Unit	NX Series	NX-ECC201*2 NX-ECC202*3 NX-ECC203*4	Synced Slaves	Exist	Not possible (Some of the connected NX Units can be assigned to an axis.)
Multifunctional, Compact Inverters	MX2 Series	3G3MX2 with EtherCAT Communications Unit 3G3AX-MX2-ECT	Non-synced Slaves	Exist	Not possible
Advanced General- purpose Inverters	RX Series	3G3RX-V1 with EtherCAT Communications Unit 3G3AX-RX-ECT	Non-synced Slaves	Exist	Not possible

Name	Туре	Model	Synced/ Non-synced Slaves	Reference Clock*1	Assigning an axis
AC Servo Drive	G5-series Servo Drive with EtherCAT communications	R88M-K/R88D-KN□-ECT	Synced Slaves	Exist	Possible
Linear Servo Drives	G5-series Linear Servo Drives with EtherCAT communi- cations	R88L-EC/R88D-KN□-ECT-L	Synced Slaves	Exist	Possible
Encoder Input Slaves	Slave with 3-tier ter- minal block	GX-EC0211/EC0241	Synced Slaves	Exist	Possible
Vision Sensors	FH Series	FH-1□□□ FH-3□□□	Synced Slaves	Exist	Not possible
Specialized Vision Sensors for Posi- tioning	FQ-M-series Sensors with EtherCAT Com- munications	FQ-MS12□(-□)-ECT	Synced Slaves	Exist	Not possible
	FZM1-series Vision Sensors	FZM1-35□-ECT	Synced Slaves	Exist	Not possible
Digital Sensor Com- munications Unit	E3NW Series	E3NW-ECT	Synced Slaves	Exist	Not possible
Fiber Sensor Com- munications Unit	E3X Series	E3X-ECT	Synced Slaves	Exist	Not possible
Confocal Fiber Type Displacement Sen- sors	ZW Series	ZW-CE1□	Synced Slaves	Exist	Not possible

Shows whether or not the slave provides a reference clock. A slave or a master that provides a reference clock is required for a system configuration that enables synchronization between slaves based on a distributed clock (DC). When you connect a slave that supports the reference clock, you must meet some conditions. Refer to 4-1-1 Supported Network Topologies for detail on the conditions.

- \*2 A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required.
- \*3 A CPU Unit with unit version 1.07 or later and Sysmac Studio version 1.08 or higher are required.
- \*4 A CPU Unit with unit version 1.07 or later and Sysmac Studio version 1.11 or higher are required.

#### **EtherCAT Junction Slave**

This is a special Unit for branching EtherCAT network wiring. Cascade connections are possible within the range of node addresses that the EtherCAT master can handle.

Each Junction Slave has one input port and more than one output port. The output ports on each Junction Slave can be connected to another Junction Slave or other EtherCAT slaves.

The Junction Slave supports the reference clock that is required for a system configuration that enables synchronization between slaves based on a distributed clock (DC).

The following models are examples of some of the OMRON EtherCAT slaves.

Slave type/name	Number of ports	Model	
EtherCAT Junction Slave	3 ports	GX-JC03	
	6 ports	GX-JC06	



#### **Precautions for Safe Use**

You cannot use standard Ethernet hubs or repeater hubs with EtherCAT communications. If you use one of these, a major fault level error or other error may occur.




### **Precautions for Correct Use**

- GX-JC03 and GX-JC06 EtherCAT Junction Slaves do not have hardware switches for node address setting. The Sysmac Studio is required to set the node addresses for these slaves. The node addresses are set to 0 by default. If you use these slaves with the default node address, a Network Configuration Verification Error will occur.
- A GX-JC03 EtherCAT Junction Slave needs only one node address. A GX-JC06 EtherCAT Junction Slave needs two node addresses.



#### **Additional Information**

A GX-JC06 EtherCAT Junction Slave which appears to be one Unit is actually composed of two slaves. The two slaves appear as "Main device" and "Sub-device" in the Sysmac Studio, respectively, as shown in the figure below. The In port of Sub-device appears as "Internal Port" in the Sysmac Studio and it is internally connected to the Main device.



### Sysmac Studio

The Sysmac Studio runs on a personal computer and it is used to configure EtherCAT networks and slaves, and to program, monitor, and debug the Controller.

### Communications Cables

Use a straight, shielded twisted-pair cable (double shielding with aluminum tape and braiding) of Ethernet category 5 (100BASE-TX) or higher.

### ESI (EtherCAT Slave Information) File

The ESI files contain information unique to the EtherCAT slaves in XML format. You can load an ESI file into the Sysmac Studio, to easily allocate slave process data and make other settings.

### Unit Power Supplies

This power supply is for slave communications and internal operation.

### I/O Power Supply

This power supply is for I/O operations of external devices connected to the slaves.




#### **Additional Information**

With a CPU Unit with unit version 1.06 or later and Sysmac Studio version 1.07 or higher, you can add NX-series Safety Control Units to the EtherCAT network.

You can use NX-series Safety Control Units on EtherCAT Slave Terminals to build a safety control system on EtherCAT.

#### 1-2-2 **Determining the Network Configuration**

Determine the type, total number, and positions of slaves in the network. Check the total number of slaves and the cable length between slaves based on the following workflow.



**Note** Refer to 1-3-1 Performance Specifications for details on the maximum number of slaves.



### **Precautions for Safe Use**

- You cannot use standard Ethernet hubs or repeater hubs with EtherCAT communications. If you use one of these, a major fault level error or other error may occur.
- · Make sure that the communications distance, number of devices connected, and method of connection for EtherCAT are within specifications.

# 1-3 Specifications of Built-in EtherCAT Port

### 1-3-1 Performance Specifications

	Specification				
Item	NX701-□□□□	NX102- □□□□	NX1P2-	NJ501-□□□□/ NJ301-□□□□	NJ101-□□□□
Communications protocol	EtherCAT protocol				
Supported services	CoE (Process data	CoE (Process data communications and SDO communications)*1			
Synchronization	DC (Distributed Clo	DC (Distributed Clock)			
Physical layer	100BASE-TX	100BASE-TX			
Modulation	Baseband				
Baud rate	100 Mbit/s (100BAS	SE-TX)			
Duplex mode*2	Auto				
Topology	Line, daisy chain, a	nd branching			
Transmission media	Twisted-pair cable of category 5 or higher (Recommended cable: straight, double-shielded cable with aluminum tape and braiding)			ng)	
Maximum transmission distance between nodes	100 m				
Maximum number of slaves	512	64	16	192	64
Settable node address range	1 to 512	1 to 192			
Maximum process data size	Input: 11,472 bytes Output: 11,472 bytes However, the data must not exceed 8 frames (the maxi- mum number of process data frames).	Input: 5,736 bytes Output: 5,736 bytes However, the data must not exceed 4 frames (the maxi- mum number of process data frames).	Input: 1,434 bytes Output: 1,434 bytes However, the data must not exceed 1 frame (the maxi- mum number of process data frames).	Output: 5,736 bytes  However, the data must not exceed 4 frames (the maximum number of pro-	
Maximum size per slave	Input: 1,434 bytes Output: 1,434 bytes	3			
Maximum message size	2,048 bytes				

	Specification					
Item	NX701-□□□□	NX102- □□□□	NX1P2-	NJ501-□□□□/ NJ301-□□□□	NJ101-□□□□	
Communications cycle	<ul> <li>Primary periodic task</li> <li>125 μs, 250 μs</li> <li>to 8 ms   (in 250-μs increments)</li> <li>Priority-5 periodic task</li> <li>125 μs, 250 μs</li> <li>to</li> <li>100 ms (in 250-μs increments)*4</li> </ul>	1,000 to 32,000 μs (in 250-μs increments)	2,000 to 8,000 μs (in 250-μs increments)	500 μs*5, 1,000 μs, 2,000 μs, or 4,000 μs	1,000 μs, 2,000 μs, or 4,000 μs	
Sync jitter	1 μs max.		_		_	

- \*1 Refer to 3-1-1 CoE (CAN Application Protocol over EtherCAT) for details on CoE.
- \*2 Connection is possible only in full duplex mode. Half-duplex connections will result in link OFF status.
- \*3 Wiring in a ring configuration is not possible.
- \*4 Setting is available only for integer multiples of the task period of the primary periodic task.
- \*5 Unit version 1.03 or later of the CPU Unit is required to use this setting on the NJ301- $\square\square\square$ .

### **List of Supported Functions**

Function name	Description	
	PDO mapping using CoE	
Process data communica-	Fail-soft operation for slave communications errors	
	Stop operation for slave communications errors	
DC (distributed clock)	Clock synchronization	
	CoE	
SDO communications	Emergency message server (receptions from slaves)	
3DO communications	SDO requests and responses	
	Communications between slaves	
	Automatic setting of device variable names, etc.	
	Setting node address using hardware switches on the slaves	
Configuration	Setting node address using the Sysmac Studio	
	Network scan (collection of information on devices connected to the network)	
	Display of network configuration information (display of supported topology)	
	Slave configuration check when starting network	
	Reading of error information (emergency error history, subscription information, etc.)	
RAS functions	Packet monitoring*1	
	Troubleshooting information	
	Diagnosis/statistics log*2	
Operations during errors	When error occurs (stop communications or change to fail-soft operation)	
Operations during errors	Restoring communications when errors are cleared (Moves to operational state.)	
Slave information	Enabling/disabling slaves	
Siave information	Disconnecting/reconnecting slaves	

<sup>\*1</sup> For the NJ301- and NJ101- CPU Units, unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use the packet monitoring function.

<sup>\*2</sup> A CPU Unit with unit version 1.11 is required to use the diagnosis/statistics log.

### 1-4 Introduction of Communications

This section provides an introduction of the communications functions of the built-in EtherCAT port.

### 1-4-1 Process Data Communications and SDO Communications

The built-in EtherCAT port performs the following communications method to exchange information with EtherCAT slaves.

- · Process data communications
- SDO communications

### **Process Data Communications**

"Process data communications" is a cyclic communications method in which control information is exchanged in a fixed cycle between the EtherCAT master and slaves.

The fixed cycle is called a process data communications cycle. The EtherCAT master can exchange information with EtherCAT slaves in realtime in this process data communications cycle.

The same control period is also used for the process data communications cycle for EtherCAT. This enables precise sequence and motion control in a fixed period with very little deviation.

Refer to 6-1 Process Data Communications (PDO Communications) for details on the specifications of process data communications.

### **SDO Communications**

"SDO communications" is a communications method in which control information is exchanged in noncyclic event communications between the EtherCAT master and slaves.

You can use EtherCAT communications instructions to read and write the SDO data in EtherCAT slaves.

Refer to 6-2 SDO Communications for details on the specifications of SDO communications.

### 1-4-2 Other Functions

In addition to process data communications and SDO communications, the built-in EtherCAT port also provides functions related to EtherCAT network configurations and setup, as well as communications control and maintenance during operation or at error occurrence.

### **Network Configurations and Setup**

### Enable/Disable Setting for Slaves

Use this function to select the EtherCAT slaves for communications from among those registered in the network configuration information.

- You can design a network with future addition of EtherCAT slaves in mind, by setting EtherCAT slaves that you plan to add at a later time to *Disabled* and then registering them in the network configuration information on the EtherCAT master.
- You can change the EtherCAT slaves for communications based on the device configuration during system operation.

You can enable/disable each slave in the Sysmac Studio. Refer to 5-4-2 Setting EtherCAT Slaves for the setting procedure.

To enable/disable slaves during system operation, use the Enable/Disable EtherCAT Slave instruction. Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for details on this instruction.

### **Communications Control during Operation**

### Wait Time Setting for Slave Startup

Use this function to set the wait time until all of the EtherCAT slaves are connected to the network.

When you use a slave that takes time to start, use a longer wait time setting to prevent errors.

Set the wait time for slave startup in the Sysmac Studio. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.

### **Communications Control at Error Occurrence**

### Fail-soft Operation

Use this function to continue or stop the communications with EtherCAT slaves that are operating normally, if a communications error occurs.

"Fail-soft operation" refers an operation that only normally operating EtherCAT slaves are allowed to operate continuously.

The EtherCAT master can continue the communications with the EtherCAT slaves until the operation is stopped safely through the user program or user operation.

You can enable/disable the fail-soft operation in Sysmac Studio. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.

### **Maintenance**

### Disconnecting/Reconnecting Slaves

Use this function to temporarily stop and start communications with a specified slave.

It is useful because, during system operation, you can replace an erroneous EtherCAT slave without interrupting the communications with EtherCAT slaves that are operating normally.

Refer to 9-4 Replacing Slaves during Communications for details on how to use this function.

### Diagnosis/Statistics Log

The diagnostic and statistical information provides statistics on the number of communications frames sent and received by the EtherCAT master and EtherCAT slaves as well as the number of frames for which errors were detected.

This function acquires the diagnostic and statistical information at the specified cycle and saves the information as a log file in an SD Memory Card that is mounted on the CPU Unit.

You can use it to diagnose the EtherCAT network line quality based on the diagnostic and statistical information.

Use this function for the following applications.

- Checking the EtherCAT network line quality for predictive monitoring and preventive maintenance
- Finding locations of errors when they occur

Refer to *Diagnosis/Statistics Log of CPU Unit* for details on how to use this function.

## 1-5 EtherCAT Communications **Procedure**

#### 1-5-1 **Overview**

Step	Section
Mounting and Setting Devices and Hardware	2-2 Setting the Node Addresses of the EtherCAT Slaves
<b>→</b>	
2. Laying EtherCAT Communications Cables	Section 4 EtherCAT Network Wiring
<b>→</b>	
3. Creating the EtherCAT Network Configuration	5-2 Creating the EtherCAT Network Configuration
<b>→</b>	
4. Setting EtherCAT Slave Variables and Axes	5-3 Setting EtherCAT Slave Variables and Axes
$\downarrow$	
5. Setting EtherCAT Parameters	5-4 EtherCAT Master and Slave Parameter Settings
<b>↓</b>	
6. Programming	Section 6 Process Data Communications and SDO Communications
<b>→</b>	
7. Turning ON Power and Going Online from the Sysmac Studio	2-1-3 Connecting the Sysmac Studio
	3-3 State Transitions for EtherCAT Com- munications
<b>↓</b>	
8. Online Debugging	5-5 Comparing and Merging EtherCAT Network Configurations
<b>↓</b>	
9. Downloading the Network Configuration Information and the User Program	5-6 Downloading the Network Configuration Information
<u>↓</u>	
10. Checking the EtherCAT Process Data Communications Status	5-7 Confirming Communications after Completing EtherCAT Configuration and Settings

### 1-5-2 Details

Step		Description	Sysmac Studio operation	Section
	Mounting and Setting Devices d Hardware	Use the hardware switches on all of the EtherCAT slaves in the network to set the node addresses. (The starting node address and sequence are not specified.) See the manuals for each slave for infor- mation on the procedure for setting node addresses.		2-2 Setting the Node Addresses of the EtherCAT Slaves
		Note Use the Sysmac Studio to set the node address if there are no hardware switches or the node address is beyond the range that can be set with the hardware switches.		
		<ul> <li>Connect the EtherCAT slaves and exter- nal I/O devices.</li> </ul>		
<u></u>				T
	Laying EtherCAT Communi- ions Cables	Connect the EtherCAT slaves to the Ether-CAT port of the NJ/NX-series CPU Unit. If there is more than one EtherCAT slave, connect them using a daisy chain or branch wiring.		Section 4 Eth- erCAT Network Wiring
$\downarrow$				
3. Creating the EtherCAT Network Configuration		Use the Sysmac Studio to create a new project.      (a) Create EtherCAT network configuration offline.     or      (b) Go online and create the EtherCAT network configuration from the actual network devices. Do so after making the online connection that is described in step 7.	Create EtherCAT network configuration with EtherCAT under Configurations and Setup.	5-2 Creating the EtherCAT Net- work Configura- tion
<u> </u>			<del>,</del>	<del>,</del>
4	Setting EtherCAT Slave Variables and Axes			
	All EtherCAT Slaves	Allocate variables to the I/O ports.     If necessary, change the names of automatically generated device variables for each I/O port to user-defined variable names.	Make the settings with I/O Map under Configurations and Setup.	5-3-1 Register- ing Device Vari- ables for All EtherCAT Slaves
	Only EtherCAT Servo Drive and encoder input slaves	<ul> <li>Set up the axes.</li> <li>Create axes (axes variables).</li> <li>Set the axis types for the Axis Variables (to a servo axis, virtual axis, etc.), and set the IDs of the Servo Drives.</li> <li>Axis Variables are automatically registered in the global variable table</li> </ul>	Create and set up the axes from Axis Settings under Configuration and Setup – Motion Control Setup – Axis Settings – Add.	5-3-2 Axis Set- tings for Servo Drives and Encoder Input Slaves

Ste	p q	Description	Sysmac Studio operation	Section
5	Setting EtherCAT Parameters			
	Setting EtherCAT Master Parameters	Set the EtherCAT master parameters. (Examples: Fail-soft Operation Setting and Wait Time for Slave Startup) The values that are set are reflected in the network configuration information.	Create an EtherCAT master with EtherCAT under Configurations and Setup.	5-4-1 Setting EtherCAT Mas- ter
	Setting EtherCAT Slave Parameters	Set the EtherCAT slave parameters. Example: Enable/disable slaves.	Create EtherCAT slaves with EtherCAT under Configurations and Setup.	5-4-2 Setting EtherCAT Slaves
$\downarrow$				
6	Programming			
	Process Data Communications	Specify the device variables in the user program.  Input conditions include system-defined variables for network error flags and normal or error flags for each slave.	Create the programs with <b>POUs</b> under <b>Programming</b> .	6-1 Process Data Communications (PDO Communications)
		Assign to the task that refreshes I/O for each EtherCAT slave.	Set it for each slave from I/O Control Task Settings under Config- urations and Setup - Task Settings.	
	SDO Communications	Read and write the following specified data for slaves:  Use EC_CoESDORead and EC_CoESDOWrite instructions.  • SDO data in slaves (parameters, error information, etc.)	Create the programs with <b>POUs</b> under <b>Programming</b> .	6-2 SDO Com- munications
$\downarrow$				
	Furning ON Power and Going line from the Sysmac Studio	<ul> <li>Turn ON the power supply to EtherCAT slaves.</li> <li>Turn ON the I/O power supplies to the slaves.</li> <li>Turn ON the power supply to NJ/NX-series Controller.</li> <li>Use the Sysmac Studio to set communications with the NJ/NX-series Controller and go online.</li> </ul>	Select <i>Communications Setup</i> from the Controller Menu and make the settings to go online.	2-1-3 Connecting the Sysmac Studio 3-3 State Transitions for EtherCAT Communications
<u></u>				T
8. 0	Online Debugging	Compare and merge the network configuration that was set on the Sysmac Studio and the actual network configuration.	Right-click the Ether-CAT master under Configurations and Setup – EtherCAT and select Actual network configuration.	5-5 Comparing and Merging EtherCAT Net- work Configura- tions
$\downarrow$				

1-16

Step	Description	Sysmac Studio operation	Section
9. Downloading the Network Configuration Information and the User Program	Download the network configuration information (EtherCAT configuration, process data information, and parameters).  Note Use the synchronization operation of the Sysmac Studio to download the project.	Select <b>Synchroniza- tion</b> from the Controller Menu to download and verify the network configuration information.	5-6 Download- ing the Network Configuration Information

<u> </u>			
10. Checking the EtherCAT Process Data Communications Status	<ul> <li>In the Sysmac Studio, check that process data communications with all EtherCAT slaves are performed normally.</li> <li>Check the indicators on the NJ/NX-series CPU Unit.         <ul> <li>a) A flashing yellow EtherCAT LINK/ACT indicator shows that data is being transmitted and received after the link is established.</li> </ul> </li> </ul>	Display the Controller Status Pane and switch to the detailed view.	5-7 Confirming Communica- tions after Com- pleting EtherCAT Con- figuration and Settings
	<ul><li>b) A solid green EtherCAT NET RUN indicator shows the device is in the operational state (normal communications state).</li><li>c) If the EtherCAT NET ERR indicator is not lit, there is no error.</li></ul>		



# **Part Names and Slave Settings**

This section provides the part names and describes the slave settings and Sysmac device functions.

2-1	Part N	lames and Functions	2-2
	2-1-1	Built-in EtherCAT Port Indicators	. 2-2
	2-1-2	Windows Used in Sysmac Studio	. 2-4
	2-1-3	Connecting the Sysmac Studio	. 2-7
2-2	Settin	g the Node Addresses of the EtherCAT Slaves	2-9
2-3	Featu	res of Sysmac Devices	2-12
	2-3-1	Sysmac Devices	2-12
	2-3-2	Sysmac Device Features	2-12
	2-3-3	List of Sysmac Devices	2-15
	2-3-4	Sysmac Device Features and EtherCAT Masters	2-16

### **Part Names and Functions** 2-1


#### 2-1-1 **Built-in EtherCAT Port Indicators**

The indicators show the operating status of the built-in EtherCAT port on an NJ/NX-series CPU Unit.


The locations of indicators of the built-in EtherCAT port on the CPU Unit as well as the colors and statuses of indicators associated with corresponding operating status are shown below.

The locations of the built-in EtherCAT port indicators are shown below.


### NJ-series CPU Units



### NX701 CPU Units




### • NX102 CPU Unit



Operation indicators for the Built-in EtherCAT port

### NX1P2 CPU Unit



The operating status corresponding to colors and status of the built-in EtherCAT port indicators are shown below.

Label	Color	Status	Meaning
		Lit	EtherCAT communications are in progress.
			Inputs and outputs for I/O data are in operation.
		Flashing	EtherCAT communications are being established.
			This indicator shows either of the following conditions.
NET RUN	Green		Only message communications are in operation.
	Green		Only message communications and I/O data inputs are in operation.
		Not lit	EtherCAT communications are stopped.
			The power supply is OFF or the CPU Unit was reset.
			A MAC Address Error, Communications Controller Error, or other error occurred.
		Lit	A hardware error or unrecoverable error occurred, such as for exception processing.
NET ERR	Red	Flashing	A recoverable error occurred.
		Not lit	There are no errors.
		Lit	A link was established.
LINK/ACT		Flashing	Data communications are in progress after establishing link.
or L/A	Yellow		Flashes every time data is sent or received.
		Not lit	The link was not established.


Refer to 3-3-2 Control States for EtherCAT Communications for details on the states.

#### 2-1-2 Windows Used in Sysmac Studio

Use the Sysmac Studio to create the EtherCAT network configuration and to make other settings. The following windows are used.

### Creating the EtherCAT Network Configuration


Use the EtherCAT Configuration Editor offline to register slaves in the EtherCAT slave configuration. Or, upload the network configuration online.



### Setting EtherCAT Slave Variables and Axes


### I/O Map: Used to allocate device variables.

Use the I/O Map to assign device variables to the I/O ports of the EtherCAT slaves.




# Axis Basic Settings: Used to create Axis Variables and set parameters for Servo Drive and encoder input slaves.

Use the Axis Basic Settings to assign Axis Variables to the Servo Drive/encoder input slaves.



Setting Axis Parameters:


Use the Axis Setting Table to set axis parameters.




### EtherCAT Master and Slave Parameters Settings

Set the EtherCAT master and slave parameters after selecting a master or slave on the EtherCAT network configuration.

· Parameter Setting for the EtherCAT Master



· Parameter Setting for the EtherCAT Slaves



Refer to Section 5 Setting Up EtherCAT Communications with the Sysmac Studio for the Sysmac Studio procedures.

### 2-1-3 Connecting the Sysmac Studio


You can connect the Sysmac Studio to the NJ/NX-series CPU Unit through the USB or EtherNet/IP port. You must set the connection method, IP address to connect to, and other parameters for communications between the computer and Controller.



#### **Precautions for Correct Use**

You cannot connect a computer and an NX102 or an NX1P2 CPU Unit because it does not provide a peripheral USB port.

**1** Select *Communications Setup* from the Controller Menu. The Communications Setup Dialog Box is displayed.



2 Select the connection method for the connection configuration from the Connection type Area.

If you specify a Remote connection via USB or an Ethernet connection via a hub, enter the IP address of the Controller in the Remote IP Address Area. Also set the Options and Response Monitor Time parameter to the required time. Refer to Communications Setup Dialog Box Settings on the next page for information on the settings.

3 Click the **OK** Button.

This completes the setup.

### Communications Setup Dialog Box Settings


Item		Description	
Connection type	Specify the connection method to use for online communications. The specified connection method is used when you go online.		
Remote IP Address	•	onnection via USB or Ethernet connection via a hub, set the IP er that you normally will connect to.	
	USB Communica- tions Test Button	These buttons perform a communication test with the Controller at the specified IP address. The result is displayed as follows:	
	Ethernet Communica-	Normal: "Test OK"	
	tions Test Button	Error: "The Controller was not found." or "There is more than one Controller with the specified IP address."	
Options	Confirm the serial ID when going online.	If you select this option, the names and serial IDs are compared between the project and the Controller when you go online to make sure that a connection is made to the intended Controller.	
	Check forced refreshing when going offline.	If you select this option, a check is made to see if any forced refreshing values are still in effect before going offline.	
Response Monitor Time  You can set the response monitor time for communications with An error is displayed if a response is not received before this to			
	Note The time can be set to between 1 and 3,600 s.		

## 2-2 Setting the Node Addresses of the EtherCAT Slaves

### Setting Node Address Using Hardware Switches

Setting the node address is described here. An OMRON GX-series Remote I/O Terminal is used as the slave. With a GX-series Remote I/O Terminal, the node address is set on hardware switches. With a GX-series Remote I/O Terminal, these switches are used to set the node address as a slave on the EtherCAT network.

The 10s digit is set using the left rotary switch and the 1s digit is set using the right rotary switch. The setting range is from 00 to 99.



The node address setting values are described in the following table.

Switch setting	Node address setting
00	Set with the Sysmac Studio*.
01 to 99	Set with the hardware switches.

<sup>\*</sup> Refer to 1-3-1 Performance Specifications for details on the settable node address range.

### Setting the Node Address from the Sysmac Studio


Use the Sysmac Studio to set the node address if there are no hardware switches or the node address is beyond the range that can be set with the hardware switches.

**1** Start the Sysmac Studio and go online with the Controller.

Double-click EtherCAT under Configurations and Setups on the Multiview Explorer. Or, rightclick EtherCAT under Configurations and Setups and select Edit.




Right-click the EtherCAT master that is displayed in the Edit Pane and select Write Slave Node Address.



The Slave Node Address Writing Dialog Box is displayed.

4 If there are slaves for which the node address is not set (i.e., for which the **present value** is 0) or if there is more than one slave with the same node address (indicated by "!"), change the **set values** of the slave addresses, and then click the **Write** Button.

(If the correct node addresses are set for all of the slaves, click the Cancel Button.)



The node addresses are written to the actual slaves.

- **5** Cycle the power supply to the slave for which **Set value** of the node address is changed. The set node address becomes valid.
- 6 Click the Update With Latest Actual Network Configuration Button.

The present values of each slave node address are read and Present value of node addresses are updated.

Check that **Present value** and **Set value** of the slave node address for which Set value was changed show the same values.



#### **Version Information**

Sysmac Studio version 1.22 or higher is required to use the **Update With Latest Actual Network Configuration** Button.



### **Additional Information**

- The switch setting is read only once when the power is turned ON. Even if the setting is changed after the power supply is turned ON, the new setting will not be used until the next time that power is turned ON.
- If same node address is set for more than one node, a Slave Node Address Duplicated Error occurs and the operation of the slave stops. If a duplicated node address is set, the system-defined variable \_EC\_SlavAdrDupErr (Slave Node Address Duplicated Error) changes to TRUE.
- Use the Sysmac Studio to set the node address if there are no hardware switches or the node address is beyond the range that can be set with the hardware switches.

### **Features of Sysmac Devices** 2-3

#### 2-3-1 **Sysmac Devices**

"Sysmac devices" is a generic name for EtherCAT slaves and other OMRON control components that were designed with the same communications and user interface specifications. You can use the NJ/NX-series Machine Automation Controllers together with Sysmac devices and the Sysmac Studio Automation Software to achieve optimum functionality and ease of operation.

#### 2-3-2 **Sysmac Device Features**

You can connect Sysmac device slaves to an NJ/NX-series Machine Automation Controller to use the following features.

Sysmac device feature	Description
Troubleshooting	OMRON defines component error status as Sysmac errors for the entire Sysmac Series. You can use Sysmac errors to display errors that occur in slaves on the Sysmac Studio together with corrections for the errors.
Backing up and restoring parameters	An optional feature in the version-1.0.1 ESI specifications is used to enable backing up and restoring slave parameters (called backup parameters).
Saving node address settings	The node address setting for each slave is stored in non-volatile memory within the slave.
Verifying the EtherCAT network configuration using serial numbers	You can verify the EtherCAT network configuration based on serial numbers.

### **Troubleshooting**

OMRON defines component error status as Sysmac errors for the entire Sysmac Series.

You can use Sysmac errors to display errors that occur in slaves on the Sysmac Studio together with corrections for the errors.

This allows you to detect slave errors and isolate the causes of the errors.

If a Sysmac error occurs in a slave, the values of the *\_EC\_SlavErr* system-defined variable and the element of the *\_EC\_SlavErrTbl* system-defined variable that corresponds to the slave node address change.

Refer to 7-1-3 EtherCAT Master Function Module, Category Name: \_EC for details on the values.



#### **Additional Information**

- This feature is not supported for OMRON slaves that are not Sysmac devices and slaves that are manufactured by other companies. Check the error detection methods for each slave.
- Before you reset an error from the NJ/NX-series EtherCAT master, make sure you confirm the cause of the error in the slave.
- Sysmac errors are not displayed on the Troubleshooting Dialog Box when the slaves are in Init state. When a slave in Init state where a Sysmac error was detected is connected, you cannot confirm the Sysmac error that was detected by the slave until communications are restarted with that slave. Therefore, if an error that results in a slave going to Init state and a slave Sysmac error are detected at the same time, first reset the slave Init state, restart communications with the slave, and then check the Sysmac error. Then, eliminate the cause of the error and reset the error. Refer to Error Descriptions in Errors in the EtherCAT Master Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for the errors that result in the Slave entering Init state.
- If you delete the assignment of the Sysmac error status from the processing data communications data, e.g., to reduce the load on the EtherCAT communications line, you will not be able to use the Sysmac error status in troubleshooting. (To delete the assignment, edit the PDO map settings in the EtherCAT master settings on the Sysmac Studio so that the map object that is mapped to object 2002 hex is not selected.) If you do so, you can detect errors that occur in the slave applications other than communications errors only through the transmission of emergency messages or status information that is mapped for other process data communications. Use emergency messages and other status information for which PDOs are mapped to detect slave errors in this case. Transmission of emergency messages is disabled by default for OMRON slaves.
- When the EtherCAT master detects an emergency message from a slave, the \_EC\_SlavEmergErr system-defined variable changes to TRUE. Check the contents of the emergency message from the slave on the Troubleshooting Dialog Box.
- Refer to Section 9 Troubleshooting for details on checking for errors and corrections.

### **Backing Up and Restoring Parameters**

The Sysmac devices use an option in the version-1.0.1 ESI specifications to enable backing up and restoring the backup parameters that are specified in the ESI files in non-volatile memory in the slaves.

You can back up and restore the backup parameters that are stored from the Sysmac Studio.

This makes it easy to set slaves when they are replaced.



#### **Additional Information**

- If you use slaves from other manufacturers, obtain the slave information files that are compliant with the version-1.0.1 ESI specifications from the slave manufacturers.
- Refer to 9-4-3 Backing Up Settings for the procedure to back up slave data from the Sysmac Studio.
- Refer to 9-4-4 Restoring Settings for the procedure to restore slave data from the Sysmac Studio.
- Refer to A-3 Multi-vendor Environments for information on ESI.

### **Saving Node Address Settings**

Each Sysmac device stores its own node address setting in non-volatile memory within the slave.

This allows the master to identify slaves on the network.

The node addresses are set as given below depending on the type of slave.

- Slaves with Hardware Switches
  - 0: The node address is set from the Sysmac Studio.
  - Not 0: The setting on the hardware switches is used.
- Slaves without Hardware Switches

The node address is set from the Sysmac Studio.



### **Precautions for Correct Use**

- · Set a node address for every slave so that the slaves can be identified on the EtherCAT network. Do not assign the same node address more than once.
- If you connect slaves from other manufacturers to the NJ/NX-series EtherCAT master, set the node addresses for them from the Sysmac Studio. (The NJ/NX-series EtherCAT master recognizes the value that is stored at address 0x0012 in the EtherCAT slave controller of the slave as the node address.)
- For OMRON slaves that are not Sysmac devices, set the node addresses on the hardware switches. If the node address switches are set to 0, a Network Configuration Verification Error occurs.



### **Additional Information**

- Refer to 2-2 Setting the Node Addresses of the EtherCAT Slaves or the manuals for each slave for the procedure to set the node addresses.
- · Refer to 5-4-2 Setting EtherCAT Slaves for information on setting node addresses with the Sysmac Studio.

### Verifying the EtherCAT Network Configuration Using Serial Numbers

Each Sysmac device slave stores its serial number in non-volatile memory within the slave.

If serial number verification is enabled in the EtherCAT master settings, the EtherCAT network configuration is verified based on the serial numbers when the EtherCAT master is started. The following are enabled by verification of the serial numbers.

- If the EtherCAT network configuration changes, the serial numbers will not match and a Network Configuration Verification Error occurs. This helps prevent forgetting to set the parameters when a slave is replaced.
- The serial numbers of any of the slaves can be checked from the EtherCAT master.



### **Additional Information**

Refer to 5-4-1 Setting EtherCAT Master for information on checking serial numbers.

### 2-3-3 List of Sysmac Devices

The following table lists the OMRON Sysmac slaves. Refer to the manual for the slave for information on OMRON slaves that are not listed in the following table.

Name	Model	Revision
AC Servo Drives	R88D-KN□□□-ECT	Revision 2.1 or later
Multifunctional, Compact Inverter	3G3AX-MX2-ECT	Revision 1.1 or later
Digital I/O Slaves	GX-ID□□□□ GX-OD□□□□ GX-MD□□□□ GX-OC□□□□	Revision 1.1 or later
Analog I/O Slaves	GX-AD0□71 GX-DA0□71	Revision 1.1 or later
Encoder Input Slaves	GX-EC02□1	Revision 1.1 or later
Vision Sensors	FH-1□□□ FH-3□□□	Revision 1.0 or later
Specialized Vision Sensors for Positioning	FQ-MS12□-ECT	Revision 1.0 or later
	FQ-MS12□-M-ECT	
Smart Fiber Sensor Communications Unit	E3X-ECT	Revision 1.0 or later
EtherCAT Junction Slaves	GX-JC03	Revision 1.0 or later
	GX-JC06	
NX-series EtherCAT Coupler Unit*	NX-ECC201*1	Revision 1.0 or later
	NX-ECC202*2	Revision 1.2 or later
	NX-ECC203*3	Revision 1.3 or later
Advanced General-purpose Inverters	3G3RX-V1 with EtherCAT Communications Unit 3G3AX-RX-ECT	Revision 1.0 or later
Linear Servo Drive	R88L-EC	Revision 1.0 or later
	R88D-KN□-ECT-L	
Digital Sensor Communications Unit	E3NW-ECT	Revision 1.0 or later
Fiber Sensor Communications Unit	E3X-ECT	Revision 1.0 or later
Confocal Fiber Type Displacement Sensors	ZW-CE1□	Revision 1.0 or later

<sup>\*1</sup> A CPU Unit with unit version 1.05 or later and Sysmac Studio version 1.06 or higher are required.

<sup>\*2</sup> A CPU Unit with unit version 1.07 or later and Sysmac Studio version 1.08 or higher are required.

<sup>\*3</sup> A CPU Unit with unit version 1.07 or later and Sysmac Studio version 1.11 or higher are required.

#### 2-3-4 Sysmac Device Features and EtherCAT Masters

The following table shows the relationship between Sysmac device features and EtherCAT masters.

### **OMRON Sysmac Device Slaves**

	OMRON EtherCAT master			
Sysmac device feature	NJ/NX-series CPU Unit  NX701-□□□□  NX102-□□□□  NX1P2-□□□□□□□  NJ501-□□□□  NJ301-□□□□  NJ101-□□□□	CJ1W-NC⊟8⊟ CJ-series Position Control Unit	EtherCAT master from another manufacturer	
Troubleshooting	Supported.	Not supported.*1	Not supported.*1	
Backing up and restor- ing parameters	Supported.*2	Partially supported.*3	Partially supported.*4	
Saving node address settings	Supported.	Supported.	Partially supported.*5	
Verifying the EtherCAT network configuration	Supported.	Not supported.	Partially supported.*6	

<sup>\*1</sup> Error notification is provided with emergency messages.

### **OMRON Slaves That Do Not Support Sysmac Devices**

	OMRON Eth			
Sysmac device feature	NJ/NX-series CPU Unit  NX701-□□□□  NX102-□□□□□  NX1P2-□□□□□□□  NJ501-□□□□  NJ301-□□□□  NJ101-□□□□	CJ1W-NC⊟8⊟ CJ-series Position Control Unit	EtherCAT master from another manufacturer	
Troubleshooting	Not supported.*1	Not supported.*1	Not supported.*1	
Backing up and restor- ing parameters	Supported.*2	Partially supported.*3	Partially supported.*4	
Saving node address settings	Partially supported.*5	Partially supported.*5	Partially supported.*6	
Verifying the EtherCAT network configuration	Not supported.	Not supported.	Partially supported.*7	

<sup>\*1</sup> Error notification is provided with emergency messages.

<sup>\*2</sup> EtherCAT slaves for which data can be backed up have specific precautions. Refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details on the precautions.

<sup>\*3</sup> You cannot specify data to back up and restore.

<sup>\*4</sup> The ability to back up and restore data depends on the ability of the EtherCAT master from another manufac-

<sup>\*5</sup> The ability to store node addresses depends on the ability of the EtherCAT master from another manufacturer.

<sup>\*6</sup> The ability to verify serial numbers depends on the ability of the EtherCAT master from another manufacturer.

<sup>\*2</sup> EtherCAT slaves for which data can be backed up have specific precautions. Refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details on the precautions.

<sup>\*3</sup> You cannot specify the data that is backed up and restored.

The ability to back up and restore data depends on the ability of the EtherCAT master from another manufacturer.

Setting is possible on the node address switches. Node addresses set with the software cannot be stored in the slave.

<sup>\*6</sup> The ability to store node addresses depends on the ability of the EtherCAT master from another manufacturer.

\*7 The ability to verify serial numbers depends on the ability of the EtherCAT master from another manufacturer.

### **Slaves from Other Manufacturers**

If you connect slaves from other manufacturers to an OMRON EtherCAT master, some slave functions are not supported or restricted as follows.

- When you use an ESI file that is not supported by the Sysmac Studio, some slave functions may be restricted or not settable, or the slave may not operate properly.
- The node address setting from the Sysmac Studio may not be supported by some slave specifications.
- Verification with serial numbers is not possible for slaves that do not have the serial number in SII.



# **EtherCAT Communications**

This section describes the different types of EtherCAT communications, EtherCAT settings, and state transitions.

3-1	EtherC	CAT Communications Types and Settings	3-2
	3-1-1	CoE (CAN Application Protocol over EtherCAT)	. 3-2
	3-1-2	Types of Communications	. 3-5
	3-1-3	Types of EtherCAT Variables	. 3-6
	3-1-4	Settings Required for EtherCAT Communications	. 3-7
3-2	Progra	amming EtherCAT Communications	3-8
3-3	State 7	Transitions for EtherCAT Communications	3-9
	3-3-1	Self Diagnosis at Startup	. 3-9
	3-3-2	Control States for EtherCAT Communications	. 3-9
	3-3-3	CPU Unit Status in Relation to EtherCAT	.3-11

# **EtherCAT Communications Types** and Settings

#### 3-1-1 **CoE (CAN Application Protocol over EtherCAT)**

The EtherCAT port built into the NJ/NX-series CPU Unit uses CoE (CAN application protocol over EtherCAT) to exchange information with slaves over EtherCAT. CoE implements message communications of CAN application over an EtherCAT network. With CoE, the parameters and control information held by the slaves are specified according to data specifications for the object dictionary.

### **Process data Communications and SDO Communications**


There are two communications that are used to communicate data between the master and slaves. These are described below.

### Process Data Communications:

Communications using process data objects (PDOs) to exchange information in realtime with a fixed period.

#### SDO Communications:

Communications using service data objects (SDOs) for communicating information when required.



The EtherCAT port built into the NJ/NX-series CPU Unit uses process data communications for commands to refresh I/O data in a fixed control period, including I/O data for EtherCAT slaves, and position control data for Servomotors. It uses SDO communications for commands to read and write data, such as for parameter transfers, at specified times.

Process data communications are executed each control cycle to refresh data continuously, and SDO communications are executed between PDO communications.




### **Additional Information**

### **Object Dictionary**

The object dictionary is a data table within the device that interfaces the application and communications. It describes the information handled by the device. Each piece of information is called an object. Each object is assigned a 4-digit hexadecimal index.

Each object is divided into a data type area, a CoE communications area, and a manufacturer-specific area.



Process data communications is used to read and write the process data in the CoE communications area in these objects.


SDO communications is used to read and write the parameters within the manufacturer-specific area in these objects.



### **Additional Information**

### **Distributed Clock (DC)**

This is a unique EtherCAT feature that enables precise clock synchronization. The DC-based clock synchronization enables sharing the same time between the EtherCAT master and the slaves. This enables the timing of the operation of the EtherCAT master and slaves to be synchronized with the shared time.



The clock that gives the standard network time is called a "reference clock". The reference clock is provided either by the master or a slave that supports the function to provide a reference clock, to the other slaves. As described in the table below, whether the master or slave provides a reference clock depends on the used CPU Unit.

When NX-series CPU Units Is Used	When NJ-series CPU Units Is Used
The EtherCAT master of the NX-series CPU Unit	Of the slaves that provide a reference clock, the slave that is the closest to the EtherCAT master on the wiring. In the above figure. the left most slave of the slaves with the DC functionality.*


<sup>\*</sup> Slaves with the DC functionality can provide a reference clock.

The EtherCAT master uses this reference clock to send frames so that the EtherCAT master and slaves remain synchronized. The slaves that support a distributed clock (i.e., synchronized slaves) perform advanced time synchronization by performing input and outputs based on the reference clock.

### 3-1-2 Types of Communications

The following two methods are used to exchange data between master and slaves in EtherCAT communications.

Communication type	Name of communication type	Timing of processing	Type of data
Cyclic communications	Process data communications (PDO communications)	Constant (process data communications cycle)	PDO data
Message communications	SDO communications	When required.	SDO data



\* Device variables for EtherCAT slaves

Axis Variables only for Servo Drive and encoder input slaves to which axes are allocated

### **Process Data Communications (PDO Communications)**

PDO communications is used for constant data exchange between the master and slaves. It is called process data communications. PDO data (i.e., I/O data that is mapped to PDOs) that is allocated in advance is input and output periodically each EtherCAT process data communications cycle (i.e., the task period of primary periodic task or priority-5 periodic task).

It is accessed from the NJ/NX-series CPU Unit in the following ways.

- With device variables for EtherCAT slave I/O
- · With Axis Variables for Servo Drive and encoder input slaves to which an axis is allocated



#### **Additional Information**

You can use the priority-5 periodic task only with NX701 CPU Units.

### **SDO Communications**


SDO communications are used to read and write specified slave data from the master when required. This is called SDO communications.

You can read/write the following specified slave data with the EC CoESDORead (Read CoE SDO) instruction or the EC\_CoESDOWrite (Write CoE SDO) instruction.

• SDO data in slaves (parameters, error information, etc.)

#### 3-1-3 **Types of EtherCAT Variables**

There are three types of EtherCAT variables as listed below.



Variable type		Description		
Allocated variables	Axis Variables	These are structure variables for I/O and parameters for Servo Drive and encoder input slaves.  You can change the names of these variables.  CPU Unit  Axis Variable A  Axis Variable B  Allocated.  EtherCAT  Servo Drive  Servo Drive		
System- defined vari- ables	System-defined variables for EtherCAT master	These variables are defined by the system for communications parameters, communication status, and other functions. You cannot change the names of these variables.		

#### 3-1-4 Settings Required for EtherCAT Communications

For EtherCAT communications, you must set the following network configuration information from the Sysmac Studio and download it to the CPU Unit.

- Network configuration:
   Master and slave configuration
- EtherCAT master settings: Parameters settings, such as the Fail-soft Operation Setting or Wait Time

for Slave Startup

• Process data information: Allocation information for slave PDO data



#### **Additional Information**

EtherCAT communications cannot be performed unless the correct network configuration information is downloaded to the CPU Unit.

Refer to Section 5 Setting Up EtherCAT Communications with the Sysmac Studio for details.

#### **Programming EtherCAT** 3-2 **Communications**

The user program in the NJ/NX-series CPU Unit reads/writes EtherCAT slave data and performs motion control for Servo Drive and encoder input slaves.

Instructions and variables are used according to slave types and target data as shown below.

Slave type	Type of data	Timing	Instructions	Variables
Slaves to which you cannot assign axes	Process data	Constantly read/written	Read/write instructions such as LD, OUT and MOV	Device variables
	SDO data	Read/written as required	EtherCAT instructions (EC_CoESDORead or EC_CoESDOWrite)	User-defined variables
Slaves to which you can assign axes	Process data	Constantly read/written	Motion control instruc- tions or read/write instructions such as LD, OUT and MOV	Axis Variables or device variables
	SDO data	Read/written as required	EtherCAT instructions (EC_CoESDORead or EC_CoESDOWrite)	User-defined variables

## 3-3 State Transitions for EtherCAT Communications

#### 3-3-1 Self Diagnosis at Startup

The EtherCAT master executes the following self-diagnosis when the power is turned ON. The results of self-diagnosis are provided in the following system-defined variables as EtherCAT master errors if errors are detected.


Diagnosis	Detected error type	System-defined variables
Diagnosis of network configuration information	Network configuration information error	_EC_NetCfgErr
Diagnosis of communications port	MAC address error	_EC_MacAdrErr
	Communications controller error	_EC_LanHwErr

Refer to *Error Descriptions* in *Errors in the EtherCAT Master Function Module* in the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503-E1-19 or later) for details on error types.

#### 3-3-2 Control States for EtherCAT Communications

#### **Control State Machine**

EtherCAT communications provides four control states. Communications is controlled by moving between these states.



After the power is turned ON, the communications master and slaves go from the Init state to the Preoperational state, Safe-operational state, and then Operational state before starting EtherCAT communications. Afterwards, EtherCAT communications are performed while the state changes automatically between these states according to error occurrence and other conditions. The current control state can be determined using the RUN indicator on the front panel.

State	Description	Process data communications	SDO communications	RUN indicator
1. Init	Communications are being initialized. Communications are not possible.	Not allowed	Not allowed	Not lit
	This state continues if the network is not configured.			
2. Pre-operational	Only SDO communications are possible in this state. Communications always enters this state after initialization, and changes to the safe-operational state after initial setting of the network is performed.	Not allowed	Possible	Flashing
3. Safe operational	In this state, SDO communications and only inputs for process data communications are possible. Communications always enters this state before going into the Operational state.	Only inputs are possible	Possible	Flashing
4. Operational	This is the normal state for communications.	Possible	Possible	Lit




#### **Additional Information**

#### I/O Refreshing

The procedure from startup of the EtherCAT network until process data I/O can be refreshed is shown below. There is no correlation between the startup of the EtherCAT network and the execution of the user program. Design the user program by adding the system-defined variables\* for the relevant slaves to the interlock conditions of the device variables for the slaves.

\* \_EC\_ActSlavTbl[1..n], \_EC\_MBXSlavTbl[1..n], \_EC\_PDSlavTbl[1..n], \_EC\_DisconnSlavTbl[1..n], and EC\_DisableSlavTbl[1..n]

Here, *n* is the maximum value of the settable node address. Refer to *1-3-1 Performance Specifications* for the maximum value of the settable node address.



#### 3-3-3 CPU Unit Status in Relation to EtherCAT

Refer to A-1 EtherCAT Status in Relation to CPU Unit Status for details on the following: memory related to the EtherCAT master, the ability to download master settings and slave settings, and the status of slaves according to the CPU Unit operating mode and the status of Controller errors.



### **EtherCAT Network Wiring**

This section describes how to connect and wire an EtherCAT network.

4-1	Laying	the EtherCAT Network	4-2
	4-1-1	Supported Network Topologies	4-2
	4-1-2	Installation Precautions	4-4
	4-1-3	Installing EtherCAT Communications Cables	4-4
	4-1-4	Connecting Communications Cables	4-8
	4-1-5	Cable Connection Procedure	4-9


#### **Laying the EtherCAT Network** 4-1

This section describes how to install EtherCAT networks.


#### **Supported Network Topologies** 4-1-1

The NJ/NX-series CPU Unit can be connected using daisy chain connections with no branching, or with branching connections using Junction Slaves. This supports redundancy, and all topologies other than rings. Examples of topology without branching and with branching (Junction Slaves) are shown below.

#### No Branching



#### Branching





#### **Precautions for Safe Use**

You cannot use standard Ethernet hubs or repeater hubs with EtherCAT communications. If you use one of these, a major fault level error or other error may occur.



#### **Precautions for Correct Use**

When you use a system configuration in which an EtherCAT Junction Slave is connected to synchronized slaves that support distributed clocks, you need a master or slave that can provide a reference clock.

With the NX-series CPU Unit, the EtherCAT master provides a reference clock.

With the NJ-series CPU Unit, at least one of the following two conditions must be met because the EtherCAT master does not provide a reference clock.

- A slave that provides a reference clock must be connected between the EtherCAT master and the first EtherCAT Junction Slave.
- The EtherCAT Junction Slave must provide a reference clock.

However, the above conditions do not apply when synchronization is not performed between slaves that support providing a distributed clock in the entire EtherCAT network.

You can determine whether the EtherCAT Junction Slave supports a reference clock from the Reference Clock setting in the Sysmac Studio slave settings. OMRON EtherCAT Junction Slaves support a reference clock.



#### **Additional Information**

If you use EtherCAT Junction Slaves, the EtherCAT Junction Slave ports that are actually connected to slaves will communicate normally even if they do not agree with the Sysmac Studio network configuration.

If you need to make the Sysmac Studio network configuration consistent with the ports that are actually connected to slaves, use the compare and merge function of the Sysmac Studio to check the actual configuration.

#### 4-1-2 **Installation Precautions**

Basic precautions for the installation of EtherCAT networks are provided below.

#### **Precautions when Installing a Network**

- When you install an EtherCAT network, take sufficient safety precautions and perform the installation according to standards and specifications. (Refer to JIS X5252 or to electrical facility technical refer-
  - An expert well versed in safety measures and the standards and specifications should be asked to perform the installation.
- Do not install EtherCAT network equipment near sources of noise. If the network must be installed in an area with noise, take steps to address the noise, such as placing equipment in metal cases.
- · When using a shielded cable with the shields on both ends of the cable connected to connector hoods, ground loops induced by improper earthing methods may decrease noise immunity and cause device damage. To prevent ground loops caused by differences in potential between device earthing points, the reference potential between the devices must be stabilized. Design earthing appropriately so that noise current does not flow to ground lines between the devices. For earthing methods, refer to the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500), the NX-series CPU Unit Hardware User's Manual (Cat. No. W535), the NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593) and the NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578).

#### **Precautions when Installing Communications Cables**

- Check the following items on the communications cables that are used in the network.
  - · Are there any breaks?
  - Are there any shorts?
  - Are there any connector problems?
- When you connect the cable to the communications connectors on devices, firmly insert the communications cable connector until it locks in place.
- Do not lay the communications cables together with high-voltage lines.
- Do not lay the communications cable near devices that generate noise.
- Do not lay the communications cables in locations subject to high temperatures or high humidity.
- Do not lay the communications cables in locations subject to excessive dirt and dust or to oil mist or other contaminants.
- There are limitations on the bending radius of communications cables. Check the specifications of the communications cable for the bending radius.

#### 4-1-3 Installing EtherCAT Communications Cables

Ethernet communications cables and connectors are used to connect the built-in EtherCAT port with EtherCAT slaves.

Use a straight, shielded twisted-pair cable (double shielding with aluminum tape and braiding) of Ethernet category 5 (100BASE-TX) or higher.

#### Cable with Connectors

#### • Sizes and Conductor Pairs: AWG 27 × 4 Pairs

Product name	Manufacturer	Cable length [m]	Model	Contact information
Standard type *1	OMRON Corporation	0.3	XS6W- 6LSZH8SS30CM-Y	OMRON Customer Service Center
Cable with Connectors on Both Ends		0.5	XS6W- 6LSZH8SS50CM-Y	
(RJ45/RJ45) Cable Sheath mate-		1	XS6W- 6LSZH8SS100CM-Y	
rial: LSZH *2 Cable color: Yellow*3		2	XS6W- 6LSZH8SS200CM-Y	
8		3	XS6W- 6LSZH8SS300CM-Y	
•		5	XS6W- 6LSZH8SS500CM-Y	

<sup>\*1</sup> Cables are available in the following lengths: 0.2, 0.3, 0.5, 1, 1.5, 2, 3, 5, 7.5, 10, 15, and 20 m. Refer to the *Industrial Ethernet Connectors Catalog* (Cat. No. G019) for details.

#### ■ Sizes and Conductor Pairs: AWG 22 × 2 Pairs

Product name	Manu- facturer	Cable length [m]	Model	Contact infor- mation
Rugged type *1	OMRON	0.3	XS5W-T421-AMD-K	OMRON Cus-
Cable with Connectors on	Corpora- tion	0.5	XS5W-T421-BMD-K	tomer Service Center
Both Ends (RJ45/RJ45) Cable color: Light blue	tion	1	XS5W-T421-CMD-K	Center
Cubic Color: Light Blue		2	XS5W-T421-DMD-K	
		5	XS5W-T421-GMD-K	
		10	XS5W-T421-JMD-K	
Rugged type *2	OMRON	0.5	XS5W-T421-BM2-SS	
Cable with Connectors on	Corpora-	1	XS5W-T421-CM2-SS	
Both Ends (M12 Straight/M12 Straight)	tion	2	XS5W-T421-DM2-SS	
Shield Strengthening cable		3	XS5W-T421-EM2-SS	
Cable color: Black		5	XS5W-T421-GM2-SS	
0		10	XS5W-T421-JM2-SS	
Rugged type *2	OMRON	0.5	XS5W-T421-BMC-SS	
Cable with Connectors on	Corpora-	1	XS5W-T421-CMC-SS	
Both Ends (M12 Straight/RJ45)	tion	2	XS5W-T421-DMC-SS	
Shield Strengthening cable		3	XS5W-T421-EMC-SS	<u>-</u>
Cable color: Black		5	XS5W-T421-GMC-SS	
000		10	XS5W-T421-JMC-SS	

<sup>\*2</sup> The lineup features Low Smoke Zero Halogen cables for in-cabinet use and PUR cables for out-of-cabinet use. Although the LSZH cable is single shielded, its communications and noise characteristics meet the standards.

<sup>\*3</sup> Cables colors are available in blue, yellow, or green.

- \*1 Cables are available in the following lengths: 0.3, 0.5, 1, 2, 3, 5, 10, and 15 m. Refer to the Industrial Ethernet Connectors Catalog (Cat. No. G019) for details.
- \*2 For details, contact your OMRON representative.

#### Cables and Connectors

#### Sizes and Conductor Pairs: AWG 24 × 4 Pairs

Part name	Manufacturer	Model	Contact information
Cables	Hitachi Metals, Ltd.	NETSTAR-C5E SAB 0.5 × 4P*	Planning Department, Kanetsu Co., Ltd.
	Kuramo Electric Co.	KETH-SB*	Kuramo Electric Co.
	SWCC Showa Cable Systems Co.	FAE-5004*	SWCC Showa Cable Systems Co.
RJ45 Connectors	Panduit Corporation	MPS588*	Panduit Corporation US Headquarters

<sup>\*</sup> We recommend that you use combinations of the above Cables and Connectors.

#### Sizes and Conductor Pairs: AWG 22 × 2 Pairs

Part name	Manufacturer	Model	Contact information
Cables	Kuramo Electric Co.	KETH-PSB-OMR*	Kuramo Electric Co.
	JMACS Japan Co., Ltd.	PNET/B*	JMACS Japan Co., Ltd.
RJ45 Assembly Connectors	OMRON Corporation	XS6G-T421-1*	OMRON Customer Ser- vice Center

<sup>\*</sup> We recommend that you use combinations of the above Cables and Connectors.



#### **Precautions for Correct Use**

- · The maximum length between nodes is 100 m. However, some cables are specified for less than 100 m. Generally speaking, if the conductors are twisted wire rather than solid wire, transmission performance will be lower, and reliable communications may not be possible at 100 m. Confirm details with the cable manufacturer.
- · When selecting a connector, confirm that it is applicable to the cable that will be used. Confirm the following items: Conductor size, conductor type (solid wire or twisted wire), number of twisted pairs (2 or 4), outer diameter, etc.




#### **Additional Information**

If an Ethernet cable of category 5 or higher is used, communications will be possible even if the cable is not shielded. However, we recommend a cable with double, aluminum tape and braided shielding to ensure sufficient noise immunity.

#### **Attaching the Connectors to the Cable and Pin Assignments**

Use straight wiring to attach the connectors to the communications cable.



<sup>\*1</sup> Connect the cable shield to the connector hood at both ends of the cable.

#### **Connector Specifications**

Specification	Description
Electrical characteristics	Conforms to IEEE 802.3 standards.
Connector structure	RJ45 8-pin modular connector (Conforms to ISO 8877.)

#### **Pin Assignments**


Pin No.	Signal name	Abbreviation	Signal direction
1	Transmission data +	TD+	Output
2	Transmission data –	TD-	Output
3	Reception data +	RD+	Input
4	Not used.		
5	Not used.		
6	Reception data –	RD-	Input
7	Not used.		
8	Not used.		
Hood	Frame ground	FG	

<sup>\*2</sup> There are two connection methods for Ethernet: T568A and T568B. The T568A connection method is shown above, but the T568B connection method can also be used.

#### 4-1-4 **Connecting Communications Cables**

Cable connections can be made freely in EtherCAT networks. Connect the communications cable from the EtherCAT master to the input port on the first slave, and then connect the communications cable to the next slave to the output port on the first slave.

Do not connect anything to the output port of the slave at the end of the network.



The cable between any two nodes (L1, L2 ... Ln) must be 100 m or less. Use the Sysmac Studio to confirm if communications are possible for the total cable length. Firmly connect the communications cable connector until it clicks into place.



#### **Precautions for Correct Use**

Always perform one of the following operations before you disconnect the communications cable to a EtherCAT slave during operation.

- · Disconnect the EtherCAT slave from the network.
- Disable the EtherCAT slaves and all slaves connected after it.

Refer to 9-4 Replacing Slaves during Communications for information on replacing slaves during operation.



#### **Additional Information**

Make sure the cable between each pair of devices connects an output port to an input port. Normal communications are not possible if an output port is connected to another output port or an input port is connected to another input port.

#### 4-1-5 Cable Connection Procedure



#### **Precautions for Correct Use**

- Turn OFF the Controller's power supply before connecting or disconnecting Ethernet communications cable.
- Allow extra space for the bending radius of the communications cable. The required space depends on the communications cable, connector, and CPU Unit that are used.


Refer to the *NJ-series CPU Unit Hardware User's Manual* (Cat. No. W500) for details on the NJ-series CPU Unit.

Refer to the *NX-series CPU Unit Hardware User's Manual* (Cat. No. W535) for details on the NX701 CPU Unit.

Refer to the *NX-series NX102 CPU Unit Hardware User's Manual* (Cat. No. W593) for details on the NX102 CPU Unit.

Refer to the *NX-series NX1P2 CPU Unit Hardware User's Manual* (Cat. No. W578) for details on the NX1P2 CPU Unit.

- **1** Lay the Ethernet communications cable.
- Connect the Ethernet communications cable to the built-in EtherCAT port on the NJ/NX-series CPU Unit. Firmly insert the connector until it locks into place.





# Setting Up EtherCAT Communications with the Sysmac Studio

This section describes how to set the network configuration information and how to check EtherCAT communications from the Sysmac Studio.


5-1	Overvi	ew of Network Configuration Information	5-2
5-2	Creatin	ng the EtherCAT Network Configuration	5-3
5-3	Setting	g EtherCAT Slave Variables and Axes	5-6
	5-3-1	Registering Device Variables for All EtherCAT Slaves	5-6
	5-3-2	Axis Settings for Servo Drives and Encoder Input Slaves	5-10
5-4	EtherC	AT Master and Slave Parameter Settings	5-11
	5-4-1	Setting EtherCAT Master	5-11
	5-4-2	Setting EtherCAT Slaves	5-16
5-5	Compa	aring and Merging EtherCAT Network Configurations	5-24
	5-5-1	Comparing and Merging with the Actual Network Configuration from the Sysmac Studio	5-24
	5-5-2	Automatically Creating the Network Configuration	
	5-5-3	Using the Sysmac Studio to Obtain Serial Numbers	
		from the Actual Network Configuration	5-32
5-6	Downl	oading the Network Configuration Information	5-34
	5-6-1	Downloading the Network Configuration Information from	
		the Sysmac Studio	5-34
5-7	Confir	ming Communications after Completing EtherCAT	
	Config	uration and Settings	5-36


#### **Overview of Network Configuration** Information

To execute EtherCAT communications, you must create the following three types of data with the Sysmac Studio and download the data to the CPU Unit. When this data is set, the network configuration information is automatically created.

When you download the network configuration information to the CPU Unit, the EtherCAT master initializes slaves and performs process data communications based on the network configuration information. This section describes the procedures to set the network configuration information and how to check EtherCAT communications.

#### **Network Configuration Information**






## 5-2 Creating the EtherCAT Network Configuration


This section describes how to create the EtherCAT network configuration.

- **1** Start the Sysmac Studio offline.
- 2 Double-click EtherCAT under Configurations and Setup on the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select Edit.




EtherCAT master will be displayed in the Edit Pane.

Multi-view Explorer




Edit Pane

Select a slave in the Toolbox, drag it to the Edit Pane, and drop it under the master. The slave will be added under the master.



Drag the slaves.

Select another slave in the Toolbox, drag it to the Edit Pane, and drop it under the slave to which you want to connect it to. The slave will be added under the slave.



For detailed procedures, such as those for deleting slaves, or copying and pasting slaves, refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504).

Refer to the NX-series EtherCAT Coupler Unit User's Manual (Cat. No. W519) and the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on creating the EtherCAT Slave Terminal configuration.

Refer to A-8 MDP Settings for EtherCAT Network Slaves in the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on MDP slaves and editing the configurations of the modules that you can connect to the MDP slaves.



#### **Additional Information**

You can go online and read the actual network configuration from the Sysmac Studio to display it and to use it as the network configuration in the project.

For details, refer to 5-5-2 Automatically Creating the Network Configuration.

#### Setting EtherCAT Slave Variables and **5-3** Axes

Device variables are used to read and write process data for EtherCAT slaves. Axis variables are used to manipulate slaves to which axes are assigned from the Motion Control Function Module. This section describes how to register device variables and set the axes.

#### 5-3-1 Registering Device Variables for All EtherCAT Slaves

You use the I/O Map Tab Page in the Sysmac Studio to assign device variables to the I/O ports. The device variables that you create are registered in the global variable table. Use one of the following three methods.

- Selecting variables that were previously registered in a variable table
- · Inputting new device variable names
- Automatically creating device variable names

#### Selecting Variables That Were Previously Registered in a Variable Table

You can select variables that are already registered on the menu on the I/O Map Tab Page. For example, this method can be used to register device variables in the following cases.


- To write the program before the slave configuration information is created.
- To reuse programming from another project.

Use the following procedure.

- Register the variables in advance in the global variable table or the local variable table of one of the POUs.
- Program using those variables.
- **3** Create the slave configuration information.
- Double-click I/O Map under Configurations and Setup on the Multiview Explorer. Or, rightclick I/O Map under Configurations and Setup and select Edit.



**5** Select the variables from the pull-down list in the I/O Map Tab Page to assign them to I/O ports.



#### **Inputting New Device Variable Names**

You can input the required device variable names. For example, this method can be used to register device variables in the following case.


To give suitable names to device variables that are assigned to I/O for I/O slaves.

Use the following procedure.


1 Double-click I/O Map under Configurations and Setup on the Multiview Explorer. Or, right-click I/O Map under Configurations and Setup and select *Edit*.



2 Select the I/O port on the I/O Map Tab Page and enter the variable name in the *Variable* Column.



Device variables are assigned to the I/O ports of the slaves.



To specify a variable table for the scope, specify the Variable Type.


#### **Automatically Creating Device Variable Names**

The device variable names will be created by combining the device name and the I/O port name. The device names are set in the slave parameters. The default device names are "E" followed by a serial number that starts from 001. For example, this method can be used to register device variables in the following case.

To eliminate the work that is involved in obtaining the device variable names.


Use the following procedure.

Double-click I/O Map under Configurations and Setup on the Multiview Explorer. Or, rightclick I/O Map under Configurations and Setup and select Edit.




The I/O Map Tab Page will be displayed.

2 Select a slave or I/O ports on the I/O Map Tab Page, right-click, and select *Create Device Variable*.



**3** If you specify a variable table for the scope, specify the *Variable Type* afterward.



Device variables are automatically assigned to the I/O ports of the slaves and registered in the variable table that is specified by the variable type.



#### **Additional Information**

- · We recommend that you set device names.
- To delete the mapping for the variable that is assigned to a port, delete the contents of the cell in the Variable Column or right-click the cell and select Reset Assignment.
  - The mapping of the device variable is deleted. The variable is not deleted from the variable table.
  - Refer to NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details on device variables.
- If you do not specify anything in the Variable Type Column when you register a variable or create device variables, the variables are automatically registered in the global variable table.

#### 5-3-2 **Axis Settings for Servo Drives and Encoder Input Slaves**

To operate slaves that can be assigned to axes in the Motion Control Function Module, you have to make axes settings. For details on the items and procedures of the axes setting, refer to the NJ/NXseries CPU Unit Motion Control User's Manual (Cat. No. W507).


## 5-4 EtherCAT Master and Slave Parameter Settings


#### 5-4-1 Setting EtherCAT Master


1 Double-click EtherCAT under Configurations and Setup on the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit*.



- **2** Select the EtherCAT master that is displayed in the Edit Pane.
  - · Screen for NJ-series CPU Unit







The EtherCAT master settings are listed below.

Name	Editing	Remarks
Device name	OK	Displays the name of the EtherCAT master.
		Default setting: Master
Model name	Not allowed.	Always "Master."
Product name	Not allowed.	Always "Master."
Number of Slaves	Not allowed.	The number of slaves is automatically calculated based on the topology.
		Display range: 0 to the maximum number of slaves.*1
PDO Communications Cycle*2	Not	Displays the time of Process Data Communications Cycle.
	allowed.	This is automatically input based on the task period of the primary periodic task.
		Display range: 500 to 4,000 μs.
		Default setting: 1,000 μs
PDO Communications Cycle 1*3	Not allowed.	Displays the time of Process Data Communications Cycle 1.
1 DO COMMUNICATIONS GYOLE 1		This is automatically input based on the task period of the primary periodic task.
		Display range: 125, 250 to 32,000 μs.
		Default setting: 1,000 μs*4
PDO Communications Cycle 2*3	Not allowed.	Displays the time of Process Data Communications Cycle 2.  This is automatically input based on the task period of the priority-5 periodic task.*5
		Display range: 125, 250 to 100,000 μs.
Reference Clock	Not	Default setting: 2,000 μs
Reference Clock	allowed.	Displays whether the master provides a reference clock.*6
		Exist: The master provides a reference clock.
T. 1.0.1.1.4.*7	OK	Not Exist: The master does not provides a reference clock.
Total Cable Length*7	UK	This is the total cable length between the slaves.
		Default setting: 1,000 m

Name	Editing	Remarks
Fail-soft Operation Setting	OK	Select Stop or Fail-soft operation for communications with all slaves on the network when the master detects a communications error (cable disconnection, slave malfunction, etc.).
		Default setting: Fail-soft operation  Refer to 9-1 Overview of Errors for details on errors.
Wait Time for Slave Startup	OK	Set the time to wait from the detection of the link on the Ether-
Walt Time for Glave Glarap		CAT port until all slaves join the network.
		Setting range: 3 to 200 s Default setting: 30 s
		Process data communications start if all slaves are present within the wait time. If all of the slaves are not present after the wait time elapses, a Network Configuration Verification Error occurs.
		When you use a slave that takes time to start, use a longer wait time setting to prevent errors.
PDO Communications Timeout Detection Count	ОК	A Process Data Reception Timeout error occurs if process data (PDO) communications timeouts occur continuously more often than the specified number of times.
		Increase the setting if Process Data Reception Timeout errors occur frequently, such as in high-noise environments.
		Set the value to 2 or higher for a slave that needs to be replaced.
		Setting range: 1 to 8 errors
		Default setting: 2 errors
Revision Check Method	OK	Specify the method to use to verify the revision numbers that are stored in the network configuration information (setting) against the actual revision numbers of the slaves (actual device) at the start of communications.
		Communications will not start if there are unverified slaves, and a Network Configuration Verification Error will occur.
		Setting values: Setting <= Actual device, Setting = Actual
		device, or No check*8
	014	Default setting: Setting <= Actual device
Serial Number Check Method*9	OK	Specify whether to verify the slave serial numbers that are stored in the network configuration information against the serial numbers that are set in the actual slaves when initiating communications.
		Communications will not start if there are unverified slaves, and a network configuration verification error will occur.
		Setting values: Setting = Actual device or No check
		Default setting: No check
DC Synchronous Correction*10	OK	Specify whether to use the slave monitoring option during DC Synchronous Correction which ensures sync jitter accuracy of the DC time.
		If <i>Enable slave monitoring option</i> is selected, the master executes DC Synchronous Correction while monitoring the DC time of the slave.
		Use this setting if a Slave Application Error occurs when the slaves are started. The error can be prevented if you select <i>Enable slave monitoring option</i> and reconnect the slave. If the error does not occur any more, that means a longer time is required for the startup of all slaves and slave reconnection.
		Setting range: Enable, or Disable slave monitoring option
		Default setting: Disable slave monitoring option

<sup>\*1</sup> Refer to 1-3-1 Performance Specifications for the maximum number of slaves.

- \*2 Displayed only with the NJ-series CPU Unit.
- \*3 Displayed only with the NX-series CPU Unit.
- \*4 For the NX102 and NX1P2 CPU Units, the default setting is 2,000  $\mu$ s.
- \*5 When the priority-5 periodic task is not used, "---" is displayed.
- \*6 Exist is displayed with the NX-series CPU Unit, Not Exist is displayed with the NJ-series.
- \*7 If the total cable length exceeds the default setting (1,000 m), set an appropriate value for the total cable length.
- \*8 Refer to the following table, Communications with Slaves Based on the Result of Revision Number Check, for the operation of communications with slaves that are determined by the result of revision number check.
- \*9 If the set value is Setting = Actual device, communications are not started with a slave, in a network, that is replaced. If it is necessary to replace a slave while the set value is Setting = Actual device, you must correct the network configuration information and transfer it to the EtherCAT master again. Set this parameter to Setting = Actual device only when strict management of the equipment configuration is required.
- \*10 A CPU Unit with unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use this function

#### Communications with Slaves Based on the Result of Revision Number Check

Setting value of Revision Check Method	Result of revision number check	Communications with slaves
Setting <= Actual device	Setting > Actual device	Communications are not possible.
	Setting = Actual device	Communications are possible.
	Setting < Actual device	Communications are possible.
Setting = Actual device	Setting > Actual device	Communications are not possible.
	Setting = Actual device	Communications are possible.
	Setting < Actual device	Communications are not possible.
No check	Setting > Actual device	Communications are possible.
	Setting = Actual device	Communications are possible.
	Setting < Actual device	Communications are possible.



#### **Precautions for Safe Use**

- If the Fail-soft Operation Setting parameter is set to Stop, process data communications will stop for all slaves when an EtherCAT communications error is detected in a slave. The Servo Drive will operate according to the Servo Drive specifications. Make sure that the Fail-soft Operation parameter setting results in safe operation when a device error occurs.
- If verifying revisions is disabled, parameters are also transferred to slaves with different Ether-CAT revisions. If an incompatible revision of a slave is connected, incorrect parameters may be set and operation may not be correct. If you disable the revision check, make sure that only compatible slaves are connected before transferring the parameters.



#### Additional Information

#### **Network Configuration Verification**

The network configuration information is verified against the actual network when the EtherCAT master is started. If an inconsistency is found during verification, the system-defined variable for a Network Configuration Verification Error provides notification.

This setting applies to the entire system and cannot be changed for individual slaves.

Verified information	Required/optional	Description
Number of slaves connected	Required	Number of slaves in the network
Vendor ID	Required	Vendor ID of each slave
Product code	Required	Product code of each slave
Revision	Optional*1	Revision number of each slave
Serial number	Optional*1*2	Serial numbers of all slaves

<sup>\*1</sup> Options are available.


<sup>\*2</sup> Serial number verification is performed for all slaves in the EtherCAT topology. You cannot specify different verification methods for individual slaves. The default setting is *No check*.

#### **Setting EtherCAT Slaves** 5-4-2


Double-click EtherCAT under Configurations and Setup on the Multiview Explorer. Or, rightclick EtherCAT under Configurations and Setup and select Edit.



- Select an EtherCAT slave that is displayed in the Edit Pane.
  - · Screen for NJ-series CPU Unit



#### • Screen for NX-series CPU Unit



The EtherCAT slave settings are listed as below.

Name	Editing	Remarks
Device name	OK	Displays the name of the slave.
		Default setting: E*** (where * is a serial number starting from 001)
		The default value is automatically generated based on the node address.
Model name	Not allowed.	Automatically displays the name of the slave model.
Product name	Not allowed.	Displays the product name of the slave.
Revision	Not allowed.	Displays the revision of the slave.
PDO Communications Cycle*1	Not allowed.	Displays the process data communications cycle assigned for the slave.
		Either of the following values is displayed.
		PDO Communications Cycle 1
		Communications cycle is the task period of the primary periodic task.
		PDO Communications Cycle 2
		Communications cycle is the task period of the priority-5 periodic task.
Node Address	OK	Sets the node address.
		The default value is set automatically when a slave is added.
		Setting range: Settable node address range*2

Name	Editing	Remarks
Enable/Disable Settings	OK	Enables or disables the slave as a communications tar-
		get.
		• Enabled: The slave will pet energte *3
		Disabled: The slave will not operate.*3  Set the following aloves as disabled slaves; slaves that
		Set the following slaves as disabled slaves: slaves that are not installed on the physical EtherCAT network but are scheduled for addition at a later date or slaves that not used due to changes in the device configuration during system operation.
		Even for disabled slaves, process data allocations can be set and used as system-defined variables and device variables in the user program.
		Default setting: Enabled
Serial Number	Not	Displays the serial number of the slave.
	allowed.	Default: 0x00000000 (when offline)
		The value is updated to the serial number of the physical slave when you select <b>Get Slave Serial Numbers</b> from the menu for the master.
		A Network Configuration Verification Error occurs if the serial number on the Sysmac Studio and the serial number of the physical slave do not agree when the Serial Number Check Method in the master settings is set to Setting = Actual device.
		Refer to 5-5-3 Using the Sysmac Studio to Obtain Serial Numbers from the Actual Network Configuration for how to access the serial number of the physical slave.
PDO Map Settings OK	OK	Default allocations of process data for slaves are provided by the Sysmac Studio.
		When the network configuration is created, device variables are automatically created in the initial process data allocations. You can read and write these process data allocations as device variables from the user program.
		When valid PDOs are present, a list of them is displayed.
		When valid PDOs are not present, "" is displayed.
		If editing the process data allocations is required, click the <b>Edit PDO Map Settings</b> Button at the bottom of the list. Refer to <i>Changing the PDO Map Settings</i> for details.
Enable Distributed Clock	ОК	If a slave provides a distributed clock, <i>Enabled</i> is displayed.  If a slave provides a distribute clock which allows disable setting, either <i>Enabled</i> or <i>Disabled</i> is displayed. You can select enabling or disabling the clock.
		If the distributed clock is enabled, you can select the synchronization timing (Sync0 or Sync1) for some slaves. If Sync0 is selected, <i>Enabled (DC Sync0)</i> is displayed.
		If a slave does not provide a distributed clock, "" is displayed.

Name	Editing	Remarks
	Not	Displays whether the slave provides a reference clock.*4
	allowed.	Exist is displayed if the slave provides a reference clock.
		Not exist is displayed if the slave does not provide a reference clock.
Setting Parameters	Setting Parameters OK	If a slave has an initial parameter setting function, Setting is displayed.
		If a slave does not have an initial parameter setting function, "" is displayed.
		To edit the settings, click the <b>Edit Setting Parameters</b> Button.
Backup Parameter Settings OK	ОК	If a slave has a backup parameter setting function, Setting is displayed.  If a slave does not have a backup parameter setting func-
		tion, "" is displayed.
		To edit the settings, click the <b>Edit Backup Parameter Settings</b> Button.

<sup>\*1</sup> Displayed only with the NX-series CPU Unit.

- \*2 Refer to 1-3-1 Performance Specifications for the settable node address range.
- \*3 Network errors do not occur even if disabled slaves are not present on the EtherCAT network. You can use them to prepare for future system expansions or to operate without them for the current system. You can execute a special instruction to enable a disabled slave during system operation. You can also execute the special instruction to disable a slave during system operation.
- \*4 With the NJ-series CPU Unit, if you configure the system to connect the EtherCAT Junction Slave and to synchronize the slaves that have an enabled distributed clock, there must be a slave that provides a reference clock between the Master and the first EtherCAT Junction Slave. Or, the first EtherCAT Junction Slave must provide a reference clock.



#### **Version Information**

A CPU Unit with unit version 1.04 or later and Sysmac Studio version 1.05 or higher are required to disable EtherCAT slaves with the special instruction.


#### Changing the PDO Map Settings

Default allocations of process data for slaves are defined in the ESI files.


Depending on the slave, you may have to change the process data assignment as required by the application.


The operations on the Sysmac Studio is shown as follows.

Select the slave for which to change the allocated data. The parameters and allocated data for the slave will appear.



Click the **Edit PDO Map Settings** Button at the lower right of the allocated data in the pane.





The Edit PDO Map Settings Window will appear. Edit the allocated data as required.

- 3 Select the output data (RxPDO) and input data (TxPDO) in the PDO Map. You can add or delete the PDOs with Editable Flags as entries for the objects to use for the slaves. Refer to A-3-4 Editing PDO Entry Tables for details.
- **4** Click the OK Button.

# **EtherCAT Slave Enable/Disable Settings**

# Relation between Enable/Disable Settings and Instruction Settings

The following table gives the relation between the enable/disable setting of an EtherCAT slave and the results of instruction execution.

EtherCAT slave setting	Instruction setting	Result
Enable	Enable	Enabled (normal end)
	Disable	Disabled
Disabled with physical slaves*1, *2	Enable	Enabled
	Disable	Disabled (normal end)
Disabled with no physical slave, or disconnected	Enable or disable	Error (error end)

- \*1 Even if a slave physically exits, it cannot be enabled or disabled if there are any of the following errors.
  - · If there is a Network Configuration Information Error or Network Configuration Error in the master.
  - If the slave is disconnected from the network or if it has a Slave Initialization Error, Process Data Communications Error, Slave Application Error, or EtherCAT Frame Not Received error.
- \*2 If a slave is disabled (either with or without a physical slave), you cannot disconnect the slaves.



# **Precautions for Correct Use**

If you use the special instruction to change the enable/disable setting of a slave, turning OFF the power supply to the master will discard the change and revert the setting to those set from Sysmac Studio. To retain the changed setting, you must change the setting from the Sysmac Studio and then transfer the network configuration information to the CPU Unit.

# Relation between Changes in the Enable/Disable Setting and I/O Operations

The I/O operations that occur for changes in the enable/disable settings of an EtherCAT slave are given in the following table.

	Inputs		Outputs	
Change in status	Input refresh values	Device variable values	Device variable values	Output refresh values
Disabled slaves after turning ON the power supply or transferring the EtherCAT network configuration infor- mation	Input refreshing is performed but not applied to the device variables.	0 or FALSE	Depends on results of user program execution.	Output refreshing is not performed.
Slaves changed from disabled to enabled	Input refreshing is performed.	Input refresh values are applied.	Depends on results of user program execution.	The values of the device variables are output.
Slaves changed from enabled to disabled	Input refreshing is performed but not applied to the device variables.	The values from before the status of the slave was changed are retained.	Depends on results of user program execution.	Depends on the set- tings of the slave and on slave mod- els. With GX-series EtherCAT Slaves, a value is output according to the Error Mode Output setting on each slave.




# **Precautions for Correct Use**


For a slave that changed from enabled to disabled, the values of the device variables from before the change are retained.

Use the following processing to confirm if a slave is enabled or disabled.

# (1) Confirm that the slave is enabled before you access the device variables of the input device.



# (2) If the input device is disabled, always write the value of the device variable.



# • Relation between Operation and the Slave Information at a Disabled Slave

If the actual network configuration has a slave in a position of a slave set to disable (or disabled slave), the slave operation depends on the slave information. The operation differs by the result of comparison between the slave information of the disabled slave and the slave information of the slave on the actual network configuration.

The table below gives the operation of the disabled slave.

Slave inf	Slave information		Operation for disabled slave		
Node address	Vendor ID/ Product code	Message com- munications	Process data communications	Error	Back up/ Restore/verify
Same	Same	Performed	Not performed	Normal opera- tion (no error)	Performed
Same	Different	Not performed	Not performed	Network Configuration Verification Error	Not performed
Different	Same	Not performed	Not performed	Network Configuration Verification Error	Not performed
Different	Different	Not performed	Not performed	Network Configuration Verification Error	Not performed


# **Comparing and Merging EtherCAT 5-5 Network Configurations**

### **Comparing and Merging with the Actual Network Configuration** 5-5-1 from the Sysmac Studio

Use the Sysmac Studio to compare the network configuration information settings in the Sysmac Studio with the actual network configuration that is connected, including branch lines and branch locations. The following items are compared.

- · Node addresses
- · Vendor IDs
- · Product codes
- Revisions
- · Connected ports

If the settings in the Sysmac Studio and the actual network configuration match completely, it is possible to determine the locations of errors when they occur. If differences are shown in the comparison results, merge the configurations from the Sysmac Studio.



slaves. In this example, the settings on the Sysmac Studio and the slaves connected to Out1 and Out3 on node #09 in the actual network configuration do not match.



Input port



"#" indicates a node address.


Use the following procedure to compare and merge the network configuration settings on the Sysmac Studio and the actual network configuration.

- **1** Start the Sysmac Studio and go online with the Controller.
- 2 Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select Edit.




The Edit Pane is displayed.


3 Right-click the EtherCAT master that is displayed in the Edit Pane and select **Compare and Merge with Actual Network Configuration**.



The Compare and Merge with Actual Network Configuration Dialog Box is displayed. The results of comparing the settings on the Sysmac Studio with the actual network configuration are displayed in the Comparison results Column.




If there is a slave that exists only on the actual network, "Added" is displayed in the Comparison results Column. Drag the slave in the actual network configuration to the Sysmac Studio network configuration.




After you drag the missing slaves and add them to the network configuration on the Sysmac Studio, the *Comparison results* Column will show that everything in the configurations matches.

# **5** Click the **Close** Button.



The Sysmac Studio returns to the Edit Pane. This completes the operation to compare and merge with the actual network configuration.

"Removed" is displayed in the *Comparison results* Column for a slaves that exist only in the settings on the Sysmac Studio. The following example shows a case where a node address is different in the settings on the Sysmac Studio and in the actual network configuration. As a result, "Added" and "Removed" are displayed in the *Comparison results* Column.



Here, either correct the node address in the network configuration on the Sysmac Studio or the node address in the physical slave in the actual network configuration, and then repeat the compare and merge operation to confirm that the configurations are the same.



### Additional Information

- · Make sure that the communications cables between the master and slaves are connected correctly before you perform the compare and merge operation. The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if the connections are not correct.
- The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if the slave on the actual network configuration has a problem. Refer to When Compare and Merge with Actual Network Configuration Dialog Box is Not Displayed for actions for such case.
- The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if an EtherCAT Frame Not Received error occurs. Remove the cause of the error and perform the compare and merge operation. Refer to Error Tables in Errors in the EtherCAT Master Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for the cause of the error.
- When the compare and merge operation is performed, the synchronization between the Sysmac Studio and the Controller is lost. Synchronize the Sysmac Studio and Controller before you perform any online operations for the slaves. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on synchronization.


# When Compare and Merge with Actual Network Configuration **Dialog Box is Not Displayed**

An error message is displayed in the following case and the network configuration settings on the Sysmac Studio and the actual network configuration cannot be compared. Take appropriate measures following the messages displayed before comparing the network configuration settings on the Sysmac Studio and the actual network configuration.

The slave node address settings are not correct.

# When Slave Node Address Settings are not correct.

The error message below is shown if comparing the network configuration settings on the Sysmac Studio and the actual network configuration is commanded when the slave node address settings are not correct. Correct the errors of slave node address settings indicated in the message, then compare the network configuration settings on the Sysmac Studio and the actual network configuration.






### **Version Information**

Sysmac Studio version 1.22 or higher is required to show the list of the incorrect settings of slave node address.


# 5-5-2 Automatically Creating the Network Configuration

Instead of manually setting the network configuration offline, you can also automatically create the network configuration on the Sysmac Studio based on the actual network configuration. Use the following procedure to automatically duplicate the actual network configuration on the Sysmac Studio.


- **1** Start the Sysmac Studio and go online with the Controller.
- 2 Double-click **EtherCAT** under **Configurations and Setup** in the Multiview Explorer. Or, right-click **EtherCAT** under **Configurations and Setup** and select **Edit**.



3 Right-click the EtherCAT master that is displayed in the Edit Pane and select Compare and Merge with Actual Network Configuration.




The Compare and Merge with Actual Network Configuration Dialog Box is displayed.



Click the Apply actual network configuration Button.

The actual network configuration is duplicated in the network configuration on Sysmac Studio, and the Comparison results Column shows that everything in the configurations matches. (The network configuration on the Sysmac Studio is created based on the actual network configuration.)

Click the Close Button.



Go offline, and then assign device variables, set the axis parameters, set up the tasks, and set the master and slave parameters.



### **Additional Information**

- Make sure that the communications cables between the master and slaves are connected correctly before you perform this operation. The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if the connections are not correct.
- The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if
  the slave on the actual network configuration has a problem. Refer to When Compare and
  Merge with Actual Network Configuration Dialog Box is Not Displayed for actions for such
  case.
- The Compare and Merge with Actual Network Configuration Dialog Box is not displayed if an EtherCAT Frame Not Received error occurs. Remove the cause of the error and perform the compare and merge operation. Refer to *Error Tables* in *Errors in the EtherCAT Master Func*tion Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for the cause of the error.
- Even if you have previously set them on the Sysmac Studio, the following configuration and settings are discarded when you automatically create the network configuration on the Sysmac Studio based on the actual network configuration: network configuration, master settings, and any slave settings (including enable settings, PDO map settings, setting parameter settings, backup parameter settings, device variable assignments in the I/O map, slave assignments to Axes Variables registered in the axis settings, and master settings to control slaves that are registered in the task setup). To merge the actual network configuration information without losing the current settings in the Sysmac Studio, use the compare and merge operation to create the network configuration. Refer to 5-5-1 Comparing and Merging with the Actual Network Configuration from the Sysmac Studio for information on the operation to compare and merge with the actual network configuration on the Sysmac Studio.
- When the compare and merge operation is performed, the synchronization between the Sysmac Studio and the Controller is lost. Synchronize the Sysmac Studio and Controller before you perform any online operations for the slaves. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on synchronization.


### 5-5-3 Using the Sysmac Studio to Obtain Serial Numbers from the **Actual Network Configuration**

If the Serial Number Check Method in the EtherCAT master settings is set to Setting = Actual device, you must download the network configuration information in which the slave serial numbers are set to the CPU Unit. Use the following procedure to get the serial numbers of the physical slaves and apply them as the serial numbers of the slaves in the settings on the Sysmac Studio.

- Start the Sysmac Studio and go online with the Controller.
- Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, rightclick EtherCAT under Configurations and Setup and select Edit.



Right-click the EtherCAT master that is displayed in the Edit Pane and select Get Slave Serial Numbers.



The serial numbers of the physical slaves are saved as the serial numbers in the slave settings on the Sysmac Studio.



### **Additional Information**

- Make sure that the communications cables between the master and slaves are connected correctly before you perform this operation. You cannot get the serial numbers of the slaves unless the connections are correct.
- You cannot get the serial numbers of the slaves if there is a slave in the actual network configuration for which the node address is not set or if the same address is set for more than one slave in the actual network configuration. Make sure that node addresses are set correctly for the slaves in the actual network configuration before you perform this operation.
- You cannot get the serial numbers of the slaves unless the Compare and Merge with Actual Network Configuration Dialog Box shows that the entire slave configurations agree. Make sure that the Compare and Merge with Actual Network Configuration Dialog Box shows that the entire slave configurations agree before you perform this operation. However, you can get the serial numbers of the slaves even if the entire slave configurations do not agree if there are slaves in the Sysmac Studio settings that are disabled.
- If you get the serial numbers of the slaves when there are disabled slaves that do not exist in the actual network configuration, the serial numbers of the disabled slaves will be cleared to 0x00000000 in the settings on the Sysmac Studio. If the disabled slaves exist in the actual network configuration, the serial numbers of the slaves in the actual network configuration are saved in the settings on the Sysmac Studio.
- Any serial numbers that are set for slaves in the settings on the Sysmac Studio are overwritten
  when the serial numbers are obtained from the actual network configuration. Make sure that it
  is OK to overwrite the serial numbers on the Sysmac Studio before you perform this operation.
- When you get the serial numbers from the slaves on the actual network configuration, the synchronization between the Sysmac Studio and the Controller is lost. Synchronize the Sysmac Studio and Controller before you perform any online operations for the slaves. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on synchronization.

# **Downloading the Network 5-6 Configuration Information**

### 5-6-1 **Downloading the Network Configuration Information from the** Sysmac Studio

You must download the network configuration information in the project from the Sysmac Studio to the NJ/NX-series CPU Unit. Use the synchronize operation to download the network configuration information. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for information on synchronization.



### **Precautions for Safe Use**

After you transfer the user program, the CPU Unit is restarted and communications with the EtherCAT slaves are cut off. During that period, the slave outputs behave according to the slave specifications.


The time that communications are cut off depends on the EtherCAT network configuration. Before you transfer the user program, confirm that the system will not be adversely affected.



### **Precautions for Correct Use**

If a Link OFF Error occurs, remove the cause of the error and retry downloading the network configuration information after the error is reset.





The Synchronization Dialog Box is displayed.

# **2** Click the **Transfer to Controller** Button.



The network configuration information is downloaded from the Sysmac Studio to the Controller.



# **Additional Information**

The backup parameters of EtherCAT slaves are out of the scope of synchronization and are not downloaded to the slaves for the default settings. To transfer the backup parameters, clear the selection of the *Do not transfer Special Unit parameters and backup parameters of EtherCAT slaves (out of synchronization scope)*. Check Box in the Synchronization Pane.

# **Confirming Communications after 5-7 Completing EtherCAT Configuration** and Settings

If normal network configuration information is downloaded to the CPU Unit, EtherCAT communications start automatically regardless of the operating mode of the CPU Unit.

After the start of EtherCAT communications, check the process data communications status to ensure that process data communications are performed normally between the EtherCAT master and all EtherCAT slaves.

# Checking the Process Data Communications Status

Use one of the following methods to check the process data communications status.

- Controller status monitor of the Sysmac Studio
- · System-defined variable
- LED

The content of checking the process data communications status using these methods is given below.

# Controller Status Monitor of the Sysmac Studio

On the detailed view of the Controller status monitor, check the item EtherCAT Process Data Communications.

If the item EtherCAT Process Data Communications is Communicating, process data communications are performed normally. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the procedure to display the Controller status monitor of the Sysmac Studio.

# System-defined Variable

Check the \_EC\_PDActive (Process Data Communications Status) system-defined variable in the user program. If EC PDActive is TRUE, process data communications are performed normally.

### Indicator

EtherCAT communications are in operational state (process data communications are performed normally) if the EtherCAT NET RUN indicator on the front of the NJ/NX-series CPU Unit is lit green.

If process data communications are not performed normally, check the event log in the Sysmac Studio and take suitable measures. Refer to Error Tables in Errors in the EtherCAT Master Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for event logs.



# **Precautions for Safe Use**

- EtherCAT communications are not always established immediately after the power supply is turned ON. Use the system-defined variable in the user program to confirm that communications are established before you attempt to control device variables and axis variables
- · After you change any EtherCAT slave or Special Unit settings, carefully check the safety of the controlled system before you restart the Unit.




### **Precautions for Correct Use**

- When you change the EtherCAT slave configuration and reconfigure the axis allocation settings, you must download the network configuration information again.
- If network configuration information is not downloaded to the Controller, the EtherCAT master will not perform process data communications. Because of this, notification of errors will not occur. The EtherCAT communications will be in the Init state (where both process data communications and SDO communications are disabled).

# **Checking the EtherCAT Network Line Quality**

If you need to confirm that the network was correctly installed after configuring an EtherCAT network, diagnose the EtherCAT network line quality. For how to diagnose the EtherCAT network line quality, refer to 9-2-4 Diagnostic and Statistical Information.



# **Process Data Communications and SDO Communications**

This section describes the timing of communications, response times, and special instructions for process data communications and SDO communications. It also provides sample programming.

6-1	Proce	ss Data Communications (PDO Communications)	6-2
	6-1-1	Allocated Variables for Process Data Communications	6-2
	6-1-2	Process Data Communications Refresh Timing	6-4
	6-1-3	Checking the Validity of the Process Data	6-7
	6-1-4	System Response Time in Process Data Communications	6-12
	6-1-5	I/O Operations for Major Fault Level Controller Errors and	
		I/O Refreshing with Specified Values	6-16
6-2	SDO 0	Communications	6-20
	6-2-1	EtherCAT Instructions	6-20
	6-2-2	Sample Programming	6-21
	6-2-3	Execution Timing of SDO Communications	6-22
	0-2-0	Excedition finning of ODO Communications	0 22
	6-2-4	Minimum Message Response Time for SDO Communications	
6-3	6-2-4	3	6-23

# **Process Data Communications (PDO** 6-1 **Communications**)

Process data communications cyclically exchanges data between the master and slaves in the process data communications cycle (i.e., the task period of primary periodic task or priority-5 periodic task).

From the user program in the NJ/NX-series CPU Unit, slave data is accessed through allocated variables.



### **Additional Information**

You can use the priority-5 periodic task only with the NX701 CPU Units.

#### 6-1-1 **Allocated Variables for Process Data Communications**


The variables that are allocated depend on the slave type as shown in the following table.

Slave type	Allocated variables	Operation screen in Sysmac Studio
EtherCAT slaves which are not assigned to axes	Device Variables	I/O Map
EtherCAT slaves which are assigned to axes	Axis Variables	Axis Settings

Allocated variables are specified for parameters of instructions in the user program.

# **Device Variables**

The user program in an NJ/NX-series CPU Unit can read and write EtherCAT slave process data that is not assigned to axes through device variables. (The slave process data is I/O data that is exchanged between the master and slaves in each period.)




# **Axis Variables**

Servo Drives and encoder input slaves that are assigned to axes on EtherCAT can be controlled by specifying Axis Variables (structures) as parameters for motion control instruction in-out variables.

Axis Variables (structures) consist of the following data.


- Parameters: Maximum acceleration rate, software limits, etc.
- I/O: Home proximity input, Servo ON, etc.
- Operating status: Accelerating, waiting for in-position state, etc.
- Error and warning status: Excessive following error, acceleration error, etc.



#### 6-1-2 **Process Data Communications Refresh Timing**

The process data communications cycle is the same as the task period of the primary periodic task or the priority-5 periodic task for sequence control. It is also the same as the motion control period.

The control periods between each function module and between the function module and the slave are shown as follows.



Task period of primary periodic task or priority-5 periodic task = Motion control period = Process data communications cycle



### **Precautions for Correct Use**

- You can use the priority-5 periodic task only with the NX701 CPU Units.
- With an NX701 CPU Unit, you can perform process data communications separately in each task period of the primary periodic task and the priority-5 periodic task. If these two process data communications cycles must be distinguished, the cycle for the primary periodic task is called process data communications cycle 1 and the cycle for the priority-5 periodic task is called process data communications cycle 2.
- With an NX701 CPU Unit, you can execute motion control in the primary periodic task and in the priority-5 periodic task. If these two motion controls must be distinguished, the one executed by the primary periodic task is called motion control 1 and the other executed by the priority-5 periodic task is called motion control 2.
- The NX102 and NX1P2 CPU Units and NJ-series CPU Units perform process data communications only in the primary periodic task.

# Relationship Between Process Data Communications Cycle and Task Setting

The process data communications cycles of the primary periodic task and priority-5 periodic task are synchronized with the task period of the task to which I/O refreshing is assigned for each EtherCAT slave.

Assigning I/O refreshing to tasks, setting procedure on Sysmac Studio, and I/O refreshing timing are shown as follows.

# Assigning I/O Refreshing to Tasks

I/O refreshing of the EtherCAT slaves is assigned to the tasks.

Tasks to which assignment is possible and unit of assignment are different depending on the I/O refreshing target. Unit of assignment refers to a target or a group of targets for I/O refreshing that can be assigned to one I/O controlling task. For example, when the unit of assignment is Slave Terminal, you can assign I/O refreshing to only one task even if more than one NX Unit is connected to a Communications Coupler Unit.

The following table shows the relationship among the I/O refreshing target, the assignable task, and the unit of assignment.

I/O refreshing target	Assignable task	Unit of assignment
Communications Coupler Unit	Primary periodic task or priority-5	Slave Terminal
with an NX Unit assigned to an axis on the Slave Terminal	periodic task*	
Communications Coupler Unit	Primary periodic task or priority-5	
without an NX Unit assigned to an axis on the Slave Terminal	and priority-16 periodic tasks*	
EtherCAT slaves to which axes are assigned	Primary periodic task or priority-5 periodic task*	Slave
Other EtherCAT slaves	Primary periodic task or priority-5 and priority-16 periodic tasks*	

You can use the priority-5 periodic task only with the NX701 CPU Units.

# Sysmac Studio Setting Procedure

For each slave and Unit without axis assignments, set the tasks to perform I/O refreshing in the I/O Control Task Settings on the Task Settings Tab Page of the Sysmac Studio.

For details, refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501).

For each slave and Unit with axis assignments, select the motion control instruction to use in the **Motion Control Setup** of the Sysmac Studio. This sets the tasks to perform I/O refreshing.

For details, refer to the NJ/NX-series CPU Unit Motion Control User's Manual (Cat. No. W507).

# Timing of I/O Refreshing

The table below shows when I/O is refreshed for each type of EtherCAT slaves.

Task that controls I/O	Execution period of I/O refreshing
Primary periodic task	Task period of the primary periodic task*1
Priority-5 periodic task*2	Task period of the priority-5 periodic task*1
Priority-16 periodic task	Task period of the primary periodic task*1*3

- \*1 Refer to the manual for the specific slave to check if the I/O refreshing period agrees with the communications cycle supported with the slave. An error occurs if you use the Sysmac Studio to set the I/O refreshing timing to a communications cycle that is not supported with the slave. The error occurs only with the OMRON slaves that is set for synchronization.
- \*2 You can use the priority-5 periodic task only with the NX701 CPU Units.
- \*3 EtherCAT communications take place in the I/O refreshing timing for the primary periodic task. If the priority-16 periodic task is used to control EtherCAT slaves, data will be refreshed by I/O refreshing in the task period of the priority-16 periodic task.

Relationship between tasks to execute I/O refreshing, process data communications cycle, and motion control is shown as follows.

NX701 CPU Units

Task to execute I/O refreshing	Process data communications cycle	Motion control
Primary periodic task	Process data communications cycle 1	Motion control 1
Priority-5 periodic task	Process data communications cycle 2	Motion control 2

NX102 and NX1P2 CPU Units and NJ-series CPU Units

Task to execute I/O refreshing	Process data communications cycle	Motion control
Primary periodic task	Process data communications cycle	Motion control

# Restrictions for Multiple Communications Cycles

With the NX701 CPU Unit, you can perform process data communications at each task period specific to the primary periodic task and the priority-5 periodic task. On the other hand, there is only one EtherCAT network line. Therefore, some restrictions are placed on the process data communications in multiple communications cycles, as shown below.

- When the number of slaves controlled by the master increases, the process data communications cycles of both primary periodic task and priority-5 periodic task will get longer. Consider the following countermeasures if the process data communications cycle for each task exceeds the task period.
  - If you want to maintain the number of the slaves, increase the task period of the task whose process data communications cycle exceeds the task period.
  - If you want to maintain the task period, decrease the number of the slaves.
- The process data communications for the primary periodic task is processed in priority over the process data communications for the priority-5 periodic task. Therefore, the size of process data for the priority-5 periodic task that can be processed becomes smaller than that for the primary periodic task even if both tasks have the same task period.
  - Consider the following countermeasures if the process data communications cycle for the priority-5 periodic task exceeds the task period.
    - If you want to maintain the process data size of priority-5 periodic task, increase the period of the priority-5 periodic task.
    - If you want to maintain the period of priority-5 periodic task, decrease the process data size of the priority-5 periodic tasks that are assigned for the entire slaves.

# 6-1-3 Checking the Validity of the Process Data

When reading and writing the device variables and axes variables that input and output process data with slaves, the validity of the process data must be checked.

When EtherCAT communications are not established, such as immediately after the power supply to the CPU Unit is turned ON, the process data is invalid. Thus values become invalid for the device variables and axes variables that input and output the process data. If EtherCAT communications were established previously, the device variables and axes variables retain the values updated while EtherCAT commutations were established then.

Once the EtherCAT communications are established, the process data becomes valid, therefore values of the device variables and axes variables which input and output the process data become also valid. Be sure to read and write the device variables and axes variables that input and output the process data, after confirming that the process data is valid.

Use the following system-defined variables to check the validity of the process data.

- Checking the validity of the process data for each slave.
  - \_EC\_PDSlavTbl (Process Data Communicating Slave Table)
- Checking the validity of the process data for the entire slaves.
  - EC PDActive (Process Data Communications Status)



### **Precautions for Correct Use**

If noise occurs or an EtherCAT slave is disconnected from the network, any current communications frames may be lost. If frames are lost, slave I/O data is not communicated, and unintended operation may occur. The slave outputs depend on the slave specifications. For details, refer to relevant manuals for each slave. If a noise countermeasures or slave replacement is required, perform the following processing.

- Program the \_EC\_InDataInvalid (Input Data Invalid), \_ECIndata1Invalid (Input Data1 Invalid), or \_EC\_InData2Invalid (Input Data2 Invalid) system-defined variable as an interlock condition in the user program.
- Set the PDO communications timeout detection count setting in the EtherCAT master to 2 or higher. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.

A sample programming to check the validity of the process data is shown in the next section.

# Sample Programming to Check the Validity of the Process Data for **Each Slave**


With this sample program, validity of the process data is checked individually for each slave, and the data inputs and outputs with the salve are controlled.

The slave with which the process data is input and output is given the node address 1 and named "slave 1".

The \_EC\_PDSlavTbl (Process Data Communicating Slave Table) system-defined variable is used to see if the process data inputs and outputs are valid for the slave 1.

If the process data inputs and outputs with the slave 1 are valid, E001 Out Bit07 changes to TRUE when E001 In Bit00 changes to TRUE. Also, when the process data outputs with the slave 1 are valid, E001\_Out\_Bit00 changes to TRUE.

### LD



# • ST

```
IF _EC_PDSlavTbl[1]=TRUE AND _EC_CommErrTbl[1]=FALSE AND
_EC_SlavErrTbl[1]=WORD#16#0 THEN
  A:=TRUE;
 ELSE
  A:=FALSE;
 END IF;
(* Output valid condition *)
IF A=TRUE THEN
  Slav_Out:=TRUE;
 ELSE
  Slav_Out:=FALSE;
 END_IF;
```

```
(* Input valid condition *)
IF A=TRUE AND InDataInvalid=FALSE THEN
  Slav_In:=TRUE;
 ELSE
  Slav_In:=FALSE;
 END IF;
(* Output data valid *)
IF Slav Out=TRUE THEN
  E001_Out_Bit00:=TRUE;
 ELSE
  E001_Out_Bit00:=FALSE;
 END_IF;
(* Input data valid *)
IF Slav_In=TRUE AND E001_In_Bit00=TRUE THEN
  E001_Out_Bit07:=TRUE;
 ELSE
  E001_Out_Bit07:=FALSE;
 END_IF;
```

### **Additional Information**

You can read the status of the *\_EC\_PDSlavTbl* (Process Data Communicating Slave Table) system-defined variables from the user program to see if I/O refreshing is normal.

# Sample Programming to Check the Validity of the Process Data for Entire Slaves

With this sample program, validity of process data is checked collectively for all slaves that are connected to the network, and the process data inputs and outputs with the slaves are controlled. The slave with which the process data is input and output is given the node address 1.

The \_EC\_PDActive (Process Data Communications Status) system-defined variable is used to see if the process data inputs and outputs are valid for all of the slaves.

If the process data inputs and outputs with all slaves are valid, *E001\_Out\_Bit07* changes to TRUE when *E001\_In\_Bit00* changes to TRUE. Also, when the process data outputs with all slaves are valid, *E001\_Out\_Bit00* changes to TRUE.

### LD

```
EQ
   _EC_PDActive
                                                                                                     All_slave_outputs_valid
                                                        ΕN
                                                       In1
                                        _EC_SlavErr
                                    WORD#16#0000
                                                        ln2
                                                                                  _EC_InDataInvalid All_slave_inputs_valid
All slave inputs
All_slave_inputs_valid E001_In_Bit00
                                                                                                       E001_Out_Bit07
All slave outputs
All_slave_outputs_valid
                                                                                                       E001_Out_Bit00
```

# • ST

```
IF _EC_PDActive=TRUE AND _EC_SlavErr=WORD#16#0 THEN
  A:=TRUE;
 ELSE
  A:=FALSE;
 END_IF;
(* Output valid condition *)
IF A=TRUE THEN
  AllSlav_Out:=TRUE;
 ELSE
  AllSlav_Out:=FALSE;
 END_IF;
(* Input valid condition *)
IF A=TRUE AND InDataInvalid=FALSE THEN
  AllSlav_In:=TRUE;
 ELSE
  AllSlav_In:=FALSE;
 END_IF;
(* Output data valid *)
IF ALLSlav_Out=TRUE THEN
  E002_Out_Bit00:=TRUE;
 ELSE
  E002_Out_Bit00:=FALSE;
 END_IF;
```

```
(* Input data valid *)

IF ALLSlav_In=TRUE AND E002_In_Bit00=TRUE THEN

E002_Out_Bit07:=TRUE;

ELSE

E002_Out_Bit07:=FALSE;


END_IF;
```

# 6-1-4 System Response Time in Process Data Communications

This section defines the maximum I/O response time of process data communications in the system.

# **Standard Synchronization Timing**

The following timing chart shows when sequence control and motion control are performed within the task period of the primary periodic task in which EtherCAT communications were refreshed.



- (1) The slave generates process data send frames with I/O information from sensors and other devices.
- (2) The EtherCAT receives the process data frames that was sent from the slave through I/O refreshing for the CPU Unit, and reads it as input data in the CPU Unit.
- (3) Based on the input data, the CPU Unit processes user program execution and motion control to determine the output data.
- (4) The EtherCAT master generates a send frame of the process data with the output data produced in (3), and sends the frame to the slave before the slave performs reception processing.
- (5) The slave receives the send frame of the process data from the EtherCAT master in the periodic trigger timing, and outputs data to relays and other output devices.

# **Calculation Formula for Maximum I/O Response Time**

The maximum I/O response time is calculated for each periodic task of the CPU Unit in which I/O is refreshed for EtherCAT slaves.

The formula for calculating the maximum I/O response time is as follows:

Maximum I/O response	Task period of periodic task (= process data communications cycle) $\times$ 2
time =	+ Slave input response time + Slave output response time
	+ Transmission delay + Transmission jitter



### **Precautions for Correct Use**

The values that are found in the above formula are guidelines instead of guaranteed values. You must use a physical device to check the performance before the actual operation.

The following describes how to find each element value in the formula.

### Task Period of Periodic Task

This indicates the task period of the primary periodic task or the priority-5 periodic task. The priority-5 periodic task is applicable only when you use an NX701 CPU Unit.

# Transmission Delay

The following methods are provided to calculate the transmission delay times for the CPU Unit and the periodic tasks in which I/O is refreshed.

CPU Unit	Periodic task of the CPU Unit in which I/O is refreshed	Calculation method
NX701	Primary periodic task	Calculation with Sysmac Studio
		Calculation by a formula
	Priority-5 periodic task	Calculation with Sysmac Studio
		Calculation by a formula
NX102 and NX1P2	Primary periodic task	Calculation by a formula
NJ-series		

# (1) Calculation with the Sysmac Studio

You can use the Sysmac Studio to display the transmission delay time for the EtherCAT master. For details on this display method, refer to *Displaying the Transmission Delay Time for the EtherCAT Master with the Sysmac Studio* on page 6-14.

# (2) Calculation by a formula

You can use the following formula for the calculation by a formula. The vale that is found in the formula is a roughly-estimated value.

Transmission delay ( $\mu$ s) = 1.24 ( $\mu$ s) × Number of EtherCAT slaves + 0.082 ( $\mu$ s) × EtherCAT frame length (bytes)

The parameters necessary for the calculation are described below.

Parameter	Description
Number of EtherCAT Slaves	This is the number of all of the EtherCAT slaves in the same EtherCAT network. An EtherCAT Slave Terminal is counted as one EtherCAT slave.
EtherCAT Frame Length in Bytes	The EtherCAT frame length is the data byte size that is calculated under the following conditions for the EtherCAT slaves in the same EtherCAT network and for which I/O is refreshed in the primary periodic task.
	• If the total data size is less than 64 bytes, use 64 bytes in the calculation.
	For EtherCAT slaves that have both input and output data, use the larger of the input data size and output data size.
	For example, the EtherCAT frame length in bytes for the following configuration is as given below.
	Configuration Example
	Two OMRON GX-series EtherCAT slaves: Data size of 20 bytes/slave
	One EtherCAT Slave Terminal: Input data size of 50 bytes and output data size of 30 bytes
	EtherCAT frame length = 20 bytes + 20 bytes + 50 bytes = 90 bytes

### Transmission Jitter

The value of transmission jitter depends on the CPU Unit.

CPU Unit	Transmission jitter
NX701	10 μs
NX102	
NX1P2	
NJ-series	100 μs

# Slave Input Response Time

This is the time from a slave reads input information from output devices until the slave transmits a frame as a process data on the EtherCAT communications. This is the time required for internal processing that is specific to each slave. Refer to the manuals for the relevant slaves.


# Slave Output Response Time

This is the time from a slave receives a frame as a process data on the EtherCAT communications until the slave outputs the frame as output data to external output devices. This is the time required for internal processing that is specific to each slave. Refer to the manuals for the relevant slaves.


# Displaying the Transmission Delay Time for the EtherCAT Master with the Sysmac Studio

You can use the Sysmac Studio to display the transmission delay time for the built-in EtherCAT port of the NX-series CPU Unit. Use the following procedure to display the transmission delay time with the Sysmac Studio.

Right-click the EtherCAT master or EtherCAT slave in the EtherCAT Tab Page and select Calculate Transmission Delay Time of the Master.



2 The transmission delay times for PDO communications cycle 1 and PDO communications cycle 2 are displayed in the Output Tab Page.



The transmission delay times of the EtherCAT master depend on the periodic tasks of the CPU Units that refresh I/O with the EtherCAT slaves, as shown below.

Periodic task of the CPU Unit in which I/O is refreshed	Applicable transmission delay time of the EtherCAT master
Primary periodic task	Transmission delay time for PDO communications cycle 1
Priority-5 periodic task	Transmission delay time for PDO communications cycle 2



# **Precautions for Correct Use**

- Sysmac Studio does not support the transmission delay time display function for the built-in EtherCAT ports of the NJ-series CPU Units.
- You can use the Sysmac Studio to calculate and display the transmission delay times of the EtherCAT master according to the configuration information such as the number of EtherCAT slaves and the EtherCAT frame lengths. When you changed the EtherCAT configurations or setup, you must perform this function again.




# **Version Information**

Sysmac Studio version 1.13 or higher is required to use the transmission delay time display function for the EtherCAT master.


### 6-1-5 I/O Operations for Major Fault Level Controller Errors and I/O Refreshing with Specified Values

# I/O Operations for Major Fault Level Controller Errors

If the NJ/NX-series CPU Unit detects a major fault level Controller error, all slave outputs will retain the process data values from before operation stopped in Operational state. Then the slaves will move to Safe-Operational state and the slave settings will control the slave outputs. The inputs from the slaves will retain the process data values from before operation stopped. Message communications are continued.\*



When a major fault level Controller error occurs, the values of the variables are not output to the slaves even if they are initialized. The slave settings will control the slave outputs.



- \* The following errors may occur when the slave enters to the Safe-Operational state.
  - · Slave Application Error
  - · Slave Initialization Error

The formula and the maximum time required for all the slaves to enter Safe-Operational state and for the output to reach to the value set from the slave settings are shown below. This formula applies to only OMRON slaves.

CPU Unit	Formula	Maximum time	
NX-series	PDO communications timeout detection count × Task period of the task assigned to slave*1 + 10 ms	The result given from the left formula. The maximum time is 100 to 110 ms if the calculation result is 110 ms or less.	
NJ-series	Slave Sync Manager WDT error detection time (100 ms)*2 + Communications cycle (4 ms max.) + Margin	110 ms	

<sup>\*1</sup> If multiple tasks are assigned, the longest task period is used for calculation.

<sup>\*2</sup> The Slave Sync Manager WDT error detection time is the time from when the last process data is received until a reception error is detected.



# **Precautions for Correct Use**

You cannot obtain current errors from slaves after a major fault occurs except for those in Ether-CAT Slave Terminals.




# **Additional Information**

When a major fault level Controller error occurs, the related system-defined variables have the following values.

- For NX701 CPU Units
  - EC InData1Invalid = TRUE
  - \_EC\_InData2Invalid = TRUE
  - \_EC\_PDSlavTbl[] = FALSE
  - \_EC\_MBXSlavTbl[] = Values before operation stopped
  - For NX102 and NX1P2 CPU Units and NJ-series CPU Units
    - \_EC\_InDataInvalid = TRUE
    - \_EC\_PDSlavTbl[] = FALSE
    - \_EC\_MBXSlavTbl[] = Values before operation stopped

# **Forced Refreshing**

You can specify forced refreshing from the Sysmac Studio for debugging. This allows you to change process data output values to the slaves and input values from the slaves to the values that you specify in advance.



# Relationship between Major Fault Level Controller Errors, Normal Operation, and Forced Refreshing

Forced refreshing functions as shown in the following table for major fault level Controller errors and for normal operation.

Condition	1	Major fault level controller error*	Normal operation
Forced refreshing		Output data: Values from before operation stopped (Operational state).	Output data: Forced refreshing values Input data: Forced refreshing values
	Slave settings control the outputs (Safe-operational state).		
		Input data: Values from before operation stopped (Operational state).	
	Disabled	Output data: Values from before	Output data: Process data
operation stopped state).	operation stopped (Operational state).	Input data: Process data	
		Slave settings control the outputs (Safe-operational state).	
		Input data: Values from before operation stopped (Operational state).	

If a major fault level Controller error occurs, the output values from before operation stopped are retained while the slaves are in Operational state and the slave settings control the outputs after the slaves enter Safe-operational state.



#### **Precautions for Safe Use**

- You can select whether the master continues or stops communications with all slaves when a communications error occurs. Refer to 5-4-1 Setting EtherCAT Master for details.
- If noise occurs or an EtherCAT slave is disconnected from the network, any current communications frames may be lost. If frames are lost, slave I/O data is not communicated, and unintended operation may occur. The slave outputs behave according to the slave specifications. For details, refer to relevant manuals for each slave. If a noise countermeasures or slave replacement is required, perform the following processing.
  - Program the \_EC\_InDataInvalid (Input Data Invalid), \_EC\_InData1Invalid (Input Data 1 Invalid), \_EC\_InData2Invalid (Input Data 2 Invalid) system-defined variables as an interlock condition in the user program. Refer to 6-1-3 Checking the Validity of the Process Data.
  - Set the PDO communications timeout detection count setting in the EtherCAT master to at least 2. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.
- If a communications error prevents the slaves from receiving signals from the master, the slave settings will control the slave outputs. During the time that is required to change from normal operation to a communications error status, frames will be lost. The outputs for lost frames are different for synced slaves (Servo Drives and encoders) and non-synced slaves. The slave settings will control the slave outputs for synced slaves. The previous values are retained for the slave outputs for non-synced slaves.

	Normal operation	Frames lost	Communications error status
Outputs from synced slaves (Servo Drives and encoders)	Controlled by the values of device variables.	Controlled by the slave settings.	Controlled by the slave settings.
Outputs from non-synced slaves	Controlled by the values of device variables.	The previous values are output.	Controlled by the slave settings.

For details, refer to relevant manuals for each slave.



#### Additional Information

You can check from the user program to see if I/O refreshing is normal by checking one of the system-defined variables \_EC\_PDSlavTbl (Process Data Communicating Slave Table).

#### **SDO Communications** 6-2

SDO communications are performed by using EtherCAT instructions to access SDO data in slaves when required.

#### 6-2-1 **EtherCAT Instructions**

You can perform the following SDO communications with EtherCAT instructions.

· Reading and writing of SDO data


#### **Reading and Writing SDO Data**

Function	Instruction	Description
CoE messages (Read CoE SDO)	EC_CoESDORead	You set parameters to read data from the slave's object dictionary (SDO data).
CoE messages (Write CoE SDO)	EC_CoESDOWrite	You set parameters to write data to the slave's object dictionary (SDO data).

#### 6-2-2 Sample Programming

This sample uses an EtherCAT communications instruction to read the software version of an OMRON R88D-KN01L-ECT Servo Drive. The node address of the slave is 1.


The object index for the software version is 16#100A. The subindex is 0. The read value is stored in STRING variable *VersionInfo*.



LD

Internal Variables	Variable	Data type	Initial value	Comment
	Trigger	BOOL	False	Execution condition
	SdoObject	_sSDO_ACCESS	(Index:=0, Subindex:=0,	SDO parameter
			IsCompleteAccess:=False)	
	VersionInfo	STRING[256]	i)	Read data
	EC_CoESDORead_instance	EC_CoESDORead		

External Variables	Variable	Data type	Constant	Comment
	_EC_MBXSlavTbl	ARRAY[1192] OF BOOL	$\square$	Message Communications Enabled Slave Table



ST

Internal Variables	Variable	Data type	Initial value	Comment
	Trigger	BOOL	False	Execution condition
	SdoObject	_sSDO_ACCESS		SDO parameter
			IsCompleteAccess:=False)	
	DoSdoRead	BOOL	False	Processing
	VersionInfo	STRING[256]	13	Read data
	NormalEnd	UINT	0	Normal end
	ErrorEnd	UINT	0	Error end
	EC_CoESDORead_instance	EC_CoESDORead		

External Variables	Variable	Data type	Constant	Comment
	_EC_MBXSlavTbl	ARRAY[1192] OF BOOL		Message Communications Enabled Slave Table

```
// Detect when Trigger changes to TRUE.
IF ( (Trigger=TRUE) AND (DoSdoRead=FALSE) AND (_EC_MBXSlavTbl[1]=TRUE) ) THEN
   DoSdoRead
                             :=TRUE;
   SdoObject.Index
                             :=UINT#16#100A;
   SdoObject.Subindex
                             :=USINT#0;
   SdoObject.IsCompleteAccess:=FALSE;
   EC_CoESDORead_instance(
     Execute:=FALSE,
                               // Initialize instance.
     ReadDat:=VersionInfo);
                               // Dummv
END_IF;
// Execute EC_CoESDORead instruction.
IF (DoSdoRead=TRUE) THEN
   EC_CoESDORead_instance(
     Execute :=TRUE,
                               // Node address 1
     NodeAdr :=UINT#1,
                               // SDO parameter
     SdoObj :=SdoObject,
                               // Timeout time: 2.0 s
     TimeOut :=UINT#20,
                               // Read data
     ReadDat:=VersionInfo);
   IF (EC_CoESDORead_instance.Done=TRUE) THEN
     // Processing after normal end
     NormalEnd:=NormalEnd+UINT#1;
   ELSIF (EC_CoESDORead_instance.Error=TRUE) THEN
     // Processing after error end
     ErrorEnd :=ErrorEnd+UINT#1;
   END_IF;
END IF;
```

#### 6-2-3 **Execution Timing of SDO Communications**

SDO communications are executed in the system service time of the NJ/NX-series CPU Unit. System services are executed in the period between execution of all of the tasks.

Refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for details on the execution timing of system services.

#### 6-2-4 Minimum Message Response Time for SDO Communications

The minimum message response time for SDO communications is the time from when the SDO communications instruction is executed in the user program until execution of the instruction is completed.

When the instruction is executed in the user program, the master sends a frame to the slave in the system service. When the slave receives the frame, it processes it. When the slave completes processing, the master receives a response from the slave to complete execution of the instruction.



#### **Additional Information**

The minimum message response time depends on the unused time in task execution, slave SDO size, and slave SDO processing time. In the timing chart below, the time from when the SDO communications instruction is executed until execution of the instruction is completed should be used for reference only.

#### **NX-series CPU Units**

The calculation formula for the minimum message response time differs between when the task period of primary periodic task is smaller than 4 ms and when the task period is 4 ms or longer.

#### When the Task Period of the Primary Periodic Task Is Smaller than 4 ms

Minimum message response time (ms) = Task period of the task that executes the SDO communications instruction

- + (Slave SDO processing time\* $^{*1}$ /Task period of primary periodic task)\* $^{*2}$  × Task period of primary periodic task
- $+ \, (\text{SDO response data size/Transmission size})^{*2} \times \text{Task period of primary periodic task}$
- \*1 The slave SDO processing time depends on the slaves. Refer to the manual for the slave.
- \*2 Round up the calculation result in parentheses to make an integer.

The transmission size is determined by the task period of primary periodic task as shown below.


Task period of primary periodic task	Transmission size
125 μs	64 bytes
250 μs	128 bytes
500 μs or longer	256 bytes

The following timing chart shows an example of the timing from an execution of the SDO communications instruction to the completion of the instruction execution, based on the performance model below.

Here, it is assumed that the program that executes the SDO communications instructions is assigned to the primary periodic task.

#### Performance Model Example

Task period of primary periodic task [ms]	1
SDO response data size [byte]	512
Slave SDO processing time [ms]	1.2
Message response time [ms]	5



#### When the Task Period of the Primary Periodic Task is 4 ms or Longer

Minimum message response time (ms) = Task period of the task that executes SDO communications instruction


- + (Slave SDO processing time\*1/Divided period\*2)\*3 × Divided period
- + (SDO response data size/256 bytes)\*3 × Divided period
- \*1 The slave SDO processing time depends on the slaves. Refer to the manual for the slave.
- \*2 The divided period is obtained by dividing the task period of primary periodic task. If the task period of primary periodic task is equal to or more than 4 ms, the EtherCAT master sends a message communications frame to a slave and receives a message response data from the slave, according to the divided period. Assign 1 ms to the divided period for this calculation.
- \*3 Round up the calculation result in parentheses to make an integer.

The following timing chart shows an example of the timing from an execution of the SDO communications instruction to the completion of the instruction execution, based on the performance model below.

Here, it is assumed that the program that executes the SDO communications instructions is assigned to the primary periodic task.

#### Performance Model Example

Task period of primary periodic task [ms]	4
Divided period [ms]	1
SDO response data size [byte]	512
Slave SDO processing time [ms]	1.2
Message response time [ms]	8



#### **NJ-series CPU Units**

The calculation formula for the minimum message response time is given below.

Task period of the task that executes SDO communications Minimum message response time (ms) = instruction


- + (Slave SDO processing time\*1/Task period of primary periodic task)\*2 × Task period of primary periodic task
- + (SDO response data size/256 bytes)\*2 × Task period of primary periodic task
- The slave SDO processing time depends on the slaves. Refer to the manual for the slave.
- Round up the calculation result in parentheses to make an integer.

The following timing chart shows an example of the timing from an execution of the SDO communications instruction to the completion of the instruction execution, based on the performance model below.

Here, it is assumed that the program that executes the SDO communications instructions is assigned to the primary periodic task.

#### Performance Model Example

Task period of primary periodic task [ms]	1
SDO response data size [byte]	512
Slave SDO processing time [ms]	1.2
Message response time [ms]	5



## 6-3 Instructions Used in EtherCAT Communications

#### 6-3-1 EtherCAT Instructions

Function	Instruction	Description
Start EtherCAT Packet Monitor	EC_StartMon	Starts packet monitoring of the EtherCAT master built into the NJ/NX-series CPU Unit.
Stop EtherCAT Packet Monitor	EC_StopMon	Stops packet monitoring of the EtherCAT master built into the NJ/NX-series CPU Unit.
Save Packet Data File	EC_SaveMon	Saves captured data in a file in the system of the NJ/NX-series CPU Unit. The packet monitor is a function of the EtherCAT master built into the NJ/NX-series CPU Unit. The captured files in the system of the NJ/NX-series CPU Unit are not retained when the power is interrupted.
Copy Packet Data File to SD Memory Card	EC_CopyMon	Copies the captured data that was saved in the system of the NJ/NX-series CPU Unit to a file on an SD Memory Card. The captured data is previously saved from EtherCAT master built into the NJ-series CPU Unit into the system of the NJ/NX-series CPU Unit. The files saved to an SD Memory Card are retained after the power is interrupted.
Disconnect EtherCAT Slave	EC_DisconnectSlave	Temporarily disconnects a slave from the EtherCAT network for maintenance, such as replacement of the slave.
Connect EtherCAT Slave	EC_ConnectSlave	Reconnects a temporarily disconnected slave to the EtherCAT network after maintenance, such as replacement of the slave.
Enable/Disable EtherCAT Slave	EC_ChangeEnableSetting	Enables or disables an EtherCAT slave.
Get EtherCAT Error Status	GetECError	Gets the status of Controller errors (partial faults or minor faults) that occur in the EtherCAT master and the highest-level event code for the current errors.
Reset EtherCAT Error	ResetECError	Resets Controller errors in the EtherCAT master. (Execute this instruction only after eliminating the cause of the error.)

**Note** Refer to the *NJ/NX-series Instructions Reference Manual* (Cat. No. W502) for details on the instructions that are used with EtherCAT communications.



#### **Additional Information**

"Enable/disable," "Connected/disconnected," and "physical slave/no physical slave" are defined as follows:

Enable/Disable Setting

This setting tells whether process data communications are performed for an EtherCAT slave. You can make this setting from the Sysmac Studio and you can change the setting with the EC\_ChangeEnableSetting (Enable/Disable EtherCAT Slave) instruction.

· Connected/Disconnected Setting


This setting is used to temporarily disconnect a slave from the network when the slave is replaced and then to connect the slave to the network again.

However, if an EtherCAT slave in a daisy-chain connection is disconnected, all of the slaves that are connected after it are disconnected. This point is different from the enable/disable setting.

· Physical Slave/No Physical Slave This indicates whether the EtherCAT slave is physically connected.

The following table shows how these states combine.

Enable/disable setting	Connected/discon- nected setting	Physical slave/no physical slave	Combined state
Enabled	Enabled Connected Pre		Present
		Not installed	None
			(You cannot connect a non-exiting slave to the network.)
	Disconnected	Present	Present
		Not installed	
Disabled		Present	Present
	(The concept of con- nected/disconnected does not apply if a slave is disabled.)	Not installed	



# System-defined Variables That Are Related to the Built-in EtherCAT Port

This section describes the system-defined variables that are related to the built-in EtherCAT port.


7-1	System	n-defined Variables That Are Related to the Built-in EtherCAT Port	.7-2
	7-1-1	What Are System-defined Variables?	7-2
	7-1-2	System-defined Variables	7-3
	7-1-3	EtherCAT Master Function Module, Category Name: _EC	7-9

#### 7-1 **System-defined Variables That Are** Related to the Built-in EtherCAT Port

#### What Are System-defined Variables? 7-1-1

System-defined variables are variables that are defined by the system for use with EtherCAT communications. These are provided in advance in the global variable table.

The user program can input status and set parameters for the EtherCAT master and slaves by reading and writing system-defined variables.



#### 7-1-2 System-defined Variables

#### • Functional Classification: EtherCAT Communications Errors

Variable name	Meaning	Function	Data type	Range of values	Reference	
_EC_ErrSta	Built-in EtherCAT Error	This system-defined variable provides the collective status of errors in the EtherCAT Master Function Module.	WORD	16#0000 to 16#00F0	page 7-9	
		Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.				
_EC_PortErr	Communications Port Error	This system-defined variable provides the collective status of errors in the communications ports for the EtherCAT master.	WORD	16#0000 to 16#00F0	page 7-9	
		Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.				
_EC_MstrErr	Master Error	This system-defined variable provides the collective status of EtherCAT master errors and slave errors detected by the EtherCAT master.  Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.	WORD	16#0000 to 16#00F0	page 7-9	
_EC_SlavErr	Slave Error	This system-defined variable provides the collective status of all the error status for Ether-CAT slaves.  Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.	WORD	16#0000 to 16#00F0	page 7-9	
_EC_SlavErrTbl	Slave Error Table	This system-defined variable gives the error status for each EtherCAT slave. The error status is given for each slave in the actual system configuration. This variable array indicates slaves in which there are errors. Status is provided for each EtherCAT slave node address (1 to 512).*1 Refer to <i>Meanings of Error Status Bits</i> given later for the meaning of individual bits.	ARRAY [1512] OF WORD*1	16#0000 to 16#00F0	page 7-10	
_EC_MacAdrErr	MAC Address Error	TRUE if there is an illegal MAC address.	BOOL	TRUE or FALSE	page 7-10	
_EC_LanHwErr	Communications Controller Error	TRUE if there is a communications controller hardware error.	BOOL	TRUE or FALSE	page 7-10	
_EC_LinkOffErr	Link OFF Error	TRUE if the communications controller link is not established.	BOOL	TRUE or FALSE	page 7-10	
_EC_NetCfgErr	Network Configuration Information Error	TRUE if there is illegal network configuration information.	BOOL	TRUE or FALSE	page 7-10	
_EC_NetCfgCmpErr	Network Configuration Verification Error	TRUE if the network configuration information does not match the actual network configuration.	BOOL	TRUE or FALSE	page 7-11	
_EC_NetTopologyErr	Network Configuration Error	TRUE if there is a network configuration error (too many devices connected or ring connection).	BOOL	TRUE or FALSE	page 7-11	
_EC_PDCommErr	Process Data Communications Error	TRUE if there is an unexpected slave disconnection or connection or if a slave WDT error is detected during process data communications.	BOOL	TRUE or FALSE	page 7-11	
_EC_PDTimeoutErr	Process Data Reception Time- out Error	TRUE if a timeout occurs while receiving process data.	BOOL	TRUE or FALSE	page 7-11	
_EC_PDSendErr			BOOL	TRUE or FALSE	page 7-11	

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_SlavAdrDupErr	Slave Node Address Duplicated Error	TRUE if the same node address is set for more than one slave.	BOOL	TRUE or FALSE	page 7-11
_EC_SlavInitErr	Slave Initialization Error	TRUE if there is an error in an initialization command addressed to a slave.	BOOL	TRUE or FALSE	page 7-12
_EC_SlavAppErr	Slave Application Error	TRUE if there is an error in the slave's application status register.	BOOL	TRUE or FALSE	page 7-12
_EC_MsgErr	EtherCAT Message Error	TRUE when a message is sent to a slave that does not support messages or when there is an error in the format of the response to a message that was sent to a slave.	BOOL	TRUE or FALSE	page 7-12
_EC_SlavEmergErr	Emergency Mes- sage Detected	TRUE if the master detects an emergency message that was sent by a slave.	BOOL	TRUE or FALSE	page 7-12
_EC_IndataInvalidErr	Input Process Data Invalid Error	TRUE if the Input Data Invalid state continued for the following period because the EtherCAT master could not perform process data communications normally when it was in the Operational state.  • When the task period is 10 ms or shorter:	BOOL	TRUE or FALSE	page 7-12
		100 ms • When the task period is longer than 10 ms: 10 periods o the task			
_EC_CommErrTbl	Communications Error Slave Table	Slaves are given in the table in the order of slave node addresses. The corresponding slave element is TRUE if the master detected an error for the slave.	ARRAY [1512] OF BOOL*2	TRUE or FALSE	page 7-13
_EC_CycleExceeded	EtherCAT Com- munications Cycle Exceeded	TRUE if the CPU unit cannot establish communications within the set communications period at startup.	BOOL	TRUE or FALSE	page 7-13
		Note You can use this system-defined variable only for NX-series CPU Units.			

<sup>\*1</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the node address is 1 to 192 and the data type is Array [1..192] OF WORD.

<sup>\*2</sup> For NJ-series CPU Units, the data type is Array [1..192] OF BOOL.



#### **Additional Information**

#### Typical Relationships for the Built-in EtherCAT Error Flags

Variable Name	Meaning	Variable Name	Meaning	Variable Name	Meaning	Event level
_EC_ErrSta	Built-in	_EC_PortErr	Communi-	_EC_MacAdrErr	MAC Address Error	Partial fault
	EtherCAT Error		cations Port Error	I EC Landwerr I Communications I		level
				_EC_LinkOffErr	Link OFF Error	Minor fault
		_EC_MstrErr	Master Error	_EC_NetCfgErr	Network Configura- tion Information Error	level
				_EC_NetCfgCmpErr	Network Configura- tion Verification Error	
				_EC_NetTopologyErr	Network Configura- tion Error	
				_EC_PDCommErr	Process Data Com- munications Error	
				_EC_PDTimeoutErr	Process Data Reception Timeout Error	
				_EC_PDSendErr	Process Data Trans- mission Error	
				_EC_SlavAdrDupErr	Slave Node Address Duplicated Error	
				_EC_SlavInitErr	Slave Initialization Error	
				_EC_SlavAppErr	Slave Application Error	
				_EC_CommErrTbl	Communications Error Slave Table	
				_EC_CycleExceeded	EtherCAT Communications Cycle Exceeded	
				_EC_MsgErr	EtherCAT Message Error	Observation
				_EC_SlavEmergErr	Emergency Message Detected	
		_EC_SlavErr	Slave Error	_EC_SlavErrTbl	Slave Error Table	Defined by the slave.

**Note** The values of all system-defined variables that are related to errors in EtherCAT communications do not change until the cause of the error is removed and then the error in the Controller is reset with the trouble-shooting functions of the Sysmac Studio or the ResetECError instruction.

#### • Functional Classification: EtherCAT Communications Status

Variable name	Meaning	Function	Data type	Range of values	Reference	
_EC_RegSlavTbl	Registered Slave Table	This table indicates the slaves that are registered in the network configuration information. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if the corresponding slave is registered.	ARRAY [1512] OF BOOL*	TRUE or FALSE	page 7-13	
_EC_EntrySlavTbl	Network Connected Slave Table	This table indicates which slaves are connected to the network. Slaves are given in the table in the order of slave node addresses. The element for a slave is TRUE if the corresponding slave has entered the network.	ARRAY [1512] OF BOOL*	TRUE or FALSE	page 7-13	
_EC_MBXSlavTbl	Message Communications Enabled Slave Table	This table indicates the slaves that can perform message communications. Slaves are given in the table in the order of slave node addresses.  The element for a slave is TRUE if message communications are enabled for it (pre-operational, safe-operation, or operational state).  Note Use this variable to confirm that message communications are possible for the relevant slave before you execute message communications with an EtherCAT slave.	ARRAY [1512] OF BOOL*	TRUE or FALSE	page 7-14	
_EC_PDSlavTbl	Process Data Communicating Slave Table	This table indicates the slaves that are performing process data communications. Slaves are given in the table in the order of slave node addresses.  The element for a slave is TRUE if process data of the corresponding slave is enabled (operational) for both slave inputs and outputs.  Note Use this variable to confirm that the data for the relevant slave is valid before controlling an EtherCAT slave.	ARRAY [1512] OF BOOL*	TRUE or FALSE	page 7-14	
_EC_DisconnSlavTbl	Disconnected Slave Table	Slaves are given in the table in the order of slave node addresses.  The element for a slave is TRUE if the corresponding slave was disconnected.	ARRAY [1512] OF BOOL*	TRUE or FALSE	page 7-14	
_EC_DisableSlavTbl	Disabled Slave Table	Slaves are given in the table in the order of slave node addresses.  The element for a slave is TRUE if the corresponding slave is disabled.	ARRAY [1512] OF BOOL*	TRUE or FALSE	page 7-15	
_EC_PDActive	Process Data Communications Status	TRUE when process data communications are performed with all slaves*.  *Disabled slaves are not included.	BOOL	TRUE or FALSE	page 7-15	
_EC_PktMonStop	Packet Monitoring Stopped	TRUE when packet monitoring is stopped.	BOOL	TRUE or FALSE	page 7-15	
_EC_LinkStatus	Link Status	TRUE if the communications controller link status is Link ON.	BOOL	TRUE or FALSE	page 7-15	
_EC_PktSaving	Saving Packet Data File	Shows whether a packet data file is being saved.  TRUE: Packet data file being saved.  FALSE: Packet data file not being saved.	BOOL	TRUE or FALSE	page 7-15	

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_InDataInvalid	Input Data Invalid	TRUE when process data communications in the primary periodic task are not normal and the input data is not valid.	BOOL	TRUE or FALSE	page 7-16
_EC_InData1Invalid	Input Data1 Invalid	TRUE when process data communications established in the primary periodic task are not normal and the input data is not valid.  Note You can use this system-defined variable only for NX-series CPU Units.	BOOL	TRUE or FALSE	page 7-16
_EC_InData2Invalid	Input Data2 Invalid	TRUE when process data communications established in the priority-5 periodic task are not normal and the input data is not valid.  Note You can use this system-defined variable only for NX-series CPU Units.  Note This variable is always TRUE for NX102 and NX1P2 CPU Units.	BOOL	TRUE or FALSE	page 7-16

<sup>\*</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the data type is Array [1..192] OF BOOL.

**Note** All system-defined variables that are related to the status of EtherCAT communications give the current status.

### Functional Classification: EtherCAT Communications Diagnosis/Statistics Log

Variable name	Meaning	Function	Data type	Range of values	Reference
_EC_StatisticsLogEn- able	Diagnosis/Statis- tics Log Enable	Changes to TRUE when the diagnosis/statistics log is started.	BOOL	TRUE or FALSE	page 7-16
(Ver.1.11)		Changes to FALSE when the diagnosis/statistics log is ended.			
_EC_StatisticsLogCy-cleSec (Ver.1.11)	Diagnosis/Statis- tics Log Cycle	Specifies the interval to write the diagnostic and statistical information of the diagnosis/statistics log in units of seconds.	UINT	0, or 30 to 1800	page 7-17
,		When 0 is specified, the diagnostic and statistical information is written only once when the diagnosis/statistics log is ended.			
		Note The write interval does not change even if you change the value of this system-defined variable while the diagnosis/statistics log operation is in progress.			
_EC_StatisticsLog- Busy	Diagnosis/Statis- tics Log Busy	TRUE while the diagnosis/statistics log operation is in progress.	BOOL	TRUE or FALSE	page 7-17
(Ver.1.11)					
_EC_StatisticsLogErr	Diagnosis/Statis- tics Log Error	TRUE when the diagnosis/statistics log failed to start or it is impossible to write into the log.	BOOL	TRUE or FALSE	page 7-17
(Ver.1.11)	ites Log Entit	The value of this flag is determined when _EC_StatisticsLogBusy (Diagnosis/Statistics Log Busy) changes to FALSE after the diagnosis/statistics log operation is started.		TALSE	
		The error end is caused by the following.			
		Another records cannot be added in the log file because the capacity of the SD Memory Card is fully used.			
		The SD Memory Card is write protected.			
		There is no SD Memory Card.			
		The function cannot be started because the value specified for _EC_StatisticsLogCy- cleSec (Diagnosis/Statistics Log Cycle) is invalid.			

#### Meanings of Error Status Bits

The meanings of the individual bits in the above error status variables are given below.

Bit	Name	Description	Value	Meaning
15	Master Detection	This bit indicates whether the master	TRUE	Error
		detected an error in the slaves that it manages.	FALSE	No error
14	Slave Summary*1	Indicates whether there is an error at	TRUE	Error
		a level below the function module.	FALSE	No error
8 to 13	Not used.			
7	Major Fault	Indicates if there is a major fault level	TRUE	Error
		error.	FALSE	No error
6	Partial Fault	Indicates if there is a partial fault level		Error
		error.	FALSE	No error
5	Minor Fault	Indicates if there is a minor fault level	TRUE	Error
	error.		FALSE	No error
4	Observation	Indicates if there is an observation	TRUE	Error
	level error.		FALSE	No error
0 to 3	Not used.		•	

<sup>\*1</sup> For the EtherCAT Master Function Module, only \_EC\_ErrSta (Built-in EtherCAT Error) is used.

#### 7-1-3 EtherCAT Master Function Module, Category Name: \_EC

#### • Functional Classification: EtherCAT Communications Errors

Variable name	_EC_ErrSta	EC_ErrSta						
Meaning	Built-in EtherCAT	Error		Global/local	Global			
Function	This system-defin	ed variable provide	s the collective state	tus of errors in the EtherCAT Master Function Module.				
	Refer to Meanings	Refer to Meanings of Error Status Bits provided above for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc-	Get EtherCAT Erro	or Status				
		tions	GetECError					
			Reset EtherCAT Error					
			ResetECError					

Variable name	_EC_PortErr	EC_PortErr						
Meaning	Communications I	Port Error		Global/local	Global			
Function	This system-defined variable provides the collective status of errors in the communications ports for the EtherCAT master.							
	Refer to Meanings	Refer to Meanings of Error Status Bits provided above for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc-	Get EtherCAT Erro	or Status	_			
		tions	GetECError					
			Reset EtherCAT Error					
			ResetECError					

Variable name	_EC_MstrErr	EC_MstrErr							
Meaning	Master Error			Global/local	Global				
Function	This system-defined variable provides the collective status of EtherCAT master errors and slave errors detected by the EtherCAT master.  Refer to <i>Meanings of Error Status Bits</i> provided above for the meanings of the error status bits.								
	Refer to Meanings	s of Error Status Bit	s provided above for	or the meanings of t	the error status bits.				
Data type	WORD			Range of values	16#0000 to 16#00F0				
R/W access	R	Retained	Not retained.	Network Publish	Published.				
Usage in user program	Possible.	Related instruc-	Get EtherCAT Err	or Status					
		tions	GetECError						
			Reset EtherCAT Error						
			ResetECError						

Variable name	_EC_SlavErr	EC_SlavErr						
Meaning	Slave Error			Global/local	Global			
Function	This system-define	ed variable provide	us of all the error status for EtherCAT slaves.					
	Refer to Meanings	Refer to Meanings of Error Status Bits provided above for the meanings of the error status bits.						
Data type	WORD			Range of values	16#0000 to 16#00F0			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc- tions	Get EtherCAT Err  GetECError	or Status				
			Reset EtherCAT Error					
			ResetECError					

Variable name	_EC_SlavErrTbl						
Meaning	Slave Error Table			Global/local	Global		
Function	This system-defin	ed variable gives th	e error status for ea	ach EtherCAT slave	÷.		
	The error status is	given for each sla	ve in the actual sys	tem configuration.			
	This variable array indicates slaves in which there are errors. Status is provided for each EtherCAT slave node address (1 to 512).*						
	Refer to Meanings of Error Status Bits provided above for the meanings of the error status bits.						
Data type	Array [1512] OF	WORD*		Range of values	16#0000 to 16#00F0		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Get EtherCAT Err	or Status			
		tions	GetECError				
			Reset EtherCAT Error				
			ResetECError				

\* For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the node address is 1 to 192 and the data type is Array [1..192] OF WORD.

Variable name	_EC_MacAdrErr					
Meaning	MAC Address Error			Global/local	Global	
Function	TRUE if there is a	TRUE if there is an illegal MAC address.				
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT Error			
		tions	ResetECError			

Variable name	_EC_LanHwErr						
Meaning	Communications Controller Error			Global/local	Global		
Function	TRUE if there is a	TRUE if there is a communications controller hardware error.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-					
		tions	ResetECError				

Variable name	_EC_LinkOffErr					
Meaning	Link OFF Error			Global/local	Global	
Function	TRUE if the comn	TRUE if the communications controller link is not established.				
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	ssible. Related instruc- Reset EtherCAT Error				
		tions	ResetECError			

Variable name	_EC_NetCfgErr					
Meaning	Network Configuration Information Error			Global/local	Global	
Function	TRUE if there is ill	TRUE if there is illegal network configuration information.				
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT E	Error		
		tions	ResetECError			

Variable name	_EC_NetCfgCmpl	Err				
Meaning	Network Configura	ation Verification Er	ror	Global/local	Global	
Function	TRUE if the netwo	ork configuration inf	formation does not	match the actual ne	twork configuration.	
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	CAT Error		
		tions	ResetECError			
Variable name	_EC_NetTopology	Ærr				
Meaning	Network Configura	ation Error		Global/local	Global	
Function	TRUE if there is a	network configurat	tion error (too man	y devices connected	or ring connection).	
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Error		
		tions	ResetECError			
Variable name	_EC_PDCommEr	r				
Meaning	Process Data Cor	nmunications Error		Global/local	Global	
Function	TRUE if there is a	n unexpected slave	e disconnection or	connection or if a sla	ave WDT error is detected during p	
	cess data commu	nications.				
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	d instruc- Reset EtherCAT Error			
		tions	ResetECError			
Variable name	_EC_PDTimeoutE	rr				
Meaning	Process Data Rec	eption Timeout Err	or	Global/local	Global	
Function	TRUE if a timeout	occurs while recei	ving process data.			
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT	Error		
		tions	ResetECError			
Variable name	FO DD0					
	_EC_PDSendErr					
Meaning	Process Data Trai	nsmission Error		Global/local	Global	
-	Process Data Trai		smission error (can			
-	Process Data Trai		`			
Function	Process Data Trai	process data trans	`			
Function  Data type	Process Data Trai TRUE if there is a or transmission jitt	process data trans	`	nnot send within the p	process data communications perio	
Function  Data type  R/W access	Process Data Trai TRUE if there is a or transmission jitt BOOL	process data trans ter is over the limit)		Range of values  Network Publish	orocess data communications period	
Function  Data type  R/W access	Process Data Train TRUE if there is a or transmission jitt BOOL	process data transter is over the limit)	Not retained.	Range of values  Network Publish	orocess data communications period	
Function  Data type  R/W access	Process Data Train TRUE if there is a or transmission jitt BOOL	process data transter is over the limit)  Retained  Related instruc-	Not retained. Reset EtherCAT	Range of values  Network Publish	orocess data communications period	
Function  Data type  R/W access  Usage in user program	Process Data Train TRUE if there is a or transmission jitt BOOL	process data transter is over the limit)  Retained  Related instructions	Not retained. Reset EtherCAT	Range of values  Network Publish	orocess data communications perio	
Function  Data type  R/W access  Usage in user program  Variable name	Process Data Trail TRUE if there is a or transmission jittle BOOL R Possible.  _EC_SlavAdrDup	process data transter is over the limit)  Retained  Related instructions	Not retained.  Reset EtherCAT  ResetECError	Range of values  Network Publish	orocess data communications perions	
Function  Data type  R/W access  Usage in user program  Variable name  Meaning	Process Data Train TRUE if there is a or transmission jittle BOOL R Possible.  _EC_SlavAdrDup Slave Node Addresses Data Train	process data transter is over the limit)  Retained  Related instructions	Not retained.  Reset EtherCAT  ResetECError	Range of values Network Publish Error Global/local	TRUE or FALSE Published.	
Function  Data type  R/W access  Usage in user program  Variable name  Meaning  Function	Process Data Train TRUE if there is a or transmission jittle BOOL R Possible.  _EC_SlavAdrDup Slave Node Addresses Data Train	process data transter is over the limit)  Retained  Related instructions  Err	Not retained.  Reset EtherCAT  ResetECError	Range of values Network Publish Error Global/local ne slave.	TRUE or FALSE Published.	
Meaning Function  Data type R/W access Usage in user program  Variable name Meaning Function Data type R/W access	Process Data Train TRUE if there is a or transmission jittle BOOL R Possible.  _EC_SlavAdrDup Slave Node Addres TRUE if the same	process data transter is over the limit)  Retained  Related instructions  Err	Not retained.  Reset EtherCAT  ResetECError	Range of values Network Publish Error Global/local	TRUE or FALSE Published.  Global	
Function  Data type  R/W access  Usage in user program  Variable name  Meaning  Function  Data type	Process Data Train TRUE if there is a or transmission jittle BOOL R Possible.  _EC_SlavAdrDup Slave Node Addrest TRUE if the same BOOL	process data transter is over the limit)  Retained  Related instructions  Err  ess Duplicated Erro  node address is se	Not retained. Reset EtherCAT ResetECError	Range of values Network Publish Error Global/local ne slave. Range of values Network Publish	TRUE or FALSE Published.  Global  TRUE or FALSE	

Variable name	_EC_SlavInitErr					
Meaning	Slave Initialization	Error		Global/local	Global	
Function	TRUE if there is a	n error in an initializ	zation command ad	dressed to a slave.		
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT E	Error		
		tions	ResetECError			
Variable name	_EC_SlavAppErr	_EC_SlavAppErr				
Meaning	Slave Application	Error		Global/local	Global	
Function	TRUE if there is a	n error in the slave	's application status	register.		
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	Reset EtherCAT E	Error		
		tions	ResetECError			
Variable name	_EC_MsgErr					
Meaning	EtherCAT Messag	ge Error		Global/local	Global	
Function	TRUE when a message is sent to a slave that does not support messages or when there is an error in the of the response to a message that was sent to a slave.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-	CoE messages (F	Read CoE SDO)		
	• EC_CoESDORead CoE messages (Write CoE SDO)					
			EC_CoESDOW	/rite		
	T					
Variable name	_EC_SlavEmergE				T	
Meaning	Emergency Mess			Global/local	Global	
Function		er detects an emero	gency message that	t was sent by a slav	1	
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions	Reset EtherCAT E	Error		
		tions	ResetECError			
Variable name	_EC_IndataInvalid	dErr				
Meaning	Input Process Dat	ta Invalid Error		Global/local	Global	
Function					use the EtherCAT master could not	
	perform process data communications normally when it was in the Operational state.					
	<ul> <li>When the task period is 10 ms or shorter: 100 ms</li> <li>When the task period is longer than 10 ms: 10 periods o the task</li> </ul>					
Data type	BOOL	ochou is longer that	i to ilis. To perious	Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
	Possible.		Reset EtherCAT E		i ubilotieu.	
Usage in user program	FUSSIDIE.	Related instruc- tions	Reset EtherCAT E	_1101		
			- KeselECEITOF			

<sup>\*</sup> This system-defined variable was added for unit version 1.13 of the CPU Unit.

Variable name	_EC_CommErrTbl						
Meaning	Communications Error Slave Table			Global/local	Global		
Function	Slaves are given i	Slaves are given in the table in the order of slave node addresses.					
	The corresponding slave element is TRUE if the master detected an error for the slave.						
Data type	Array [1512] OF	BOOL*		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Reset EtherCAT Error				
		tions	ResetECError				

<sup>\*</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the data type is Array [1..192] OF BOOL.

**Note** The values of all system-defined variables that are related to errors in EtherCAT communications do not change until the cause of the error is removed and then the error in the Controller is reset with the troubleshooting functions of the Sysmac Studio or the ResetECError instruction.

Variable name	_EC_CycleExceeded				
Meaning	EtherCAT Communications Cycle Exceeded			Global/local	Global
Function	TRUE if the CPU unit cannot establish communications within the set communications period at startup.  Note You can use this system-defined variable only for NX-series CPU Units.				
Data types	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

#### • Functional Classification: EtherCAT Communications Status

Variable name	_EC_RegSlavTbl						
Meaning	Registered Slave Table			Global/local	Global		
Function	This table indicate	This table indicates the slaves that are registered in the network configuration information.					
	Slaves are given i	Slaves are given in the table in the order of slave node addresses.					
	The element for a	The element for a slave is TRUE if the corresponding slave is registered.					
Data type	Array [1512] OF	BOOL*		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

<sup>\*</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the data type is Array [1..192] OF BOOL.

Variable name	_EC_EntrySlavTb	_EC_EntrySlavTbl					
Meaning	Network Connected Slave Table			Global/local	Global		
Function	This table indicates which slaves are connected to the network.						
	Slaves are given i	Slaves are given in the table in the order of slave node addresses.					
	The element for a	The element for a slave is TRUE if the corresponding slave has entered the network.					
Data type	Array [1512] OF	BOOL*		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

<sup>\*</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the data type is Array [1..192] OF BOOL.

Variable name	_EC_MBXSlavTbl						
Meaning	Message Communications Enabled Slave Table Global/local Global						
Function	This table indicate	This table indicates the slaves that can perform message communications.					
	Slaves are given i	n the table in the o	rder of slave node a	nddresses.			
	The element for a slave is TRUE if message communications are enabled for it (pre-operational, safe-operation, or operational state).						
	<b>Note</b> Use this variable to confirm that message communications are possible for the relevant slave before you execute message communications with an EtherCAT slave.						
Data type	Array [1512] OF	BOOL*		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Disconnect Ether	CAT Slave			
		tions	EC_DisconnectSlave				
			Connect EtherCA	T Slave			
			EC_ConnectSla	ive			

<sup>\*</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the data type is Array [1..192] OF BOOL.

Variable name	_EC_PDSlavTbl							
Meaning	Process Data Communicating Slave Table Global/local Global							
Function	This is a table tha	This is a table that indicates the slaves that are performing process data communications.						
	Slaves are given i	n the table in the or	rder of slave node a	ddresses.				
		The element for a slave is TRUE if process data of the corresponding slave is enabled (operational) for both slave inputs and outputs.						
	Note Use this variable to confirm that the data for the relevant slave is valid before controlling an EtherCAT slave.							
Data type	Array [1512] OF	BOOL*		Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc-	Disconnect Ether(	CAT Slave				
		tions	EC_DisconnectSlave					
			Connect EtherCA	T Slave				
			EC_ConnectSlave	•				

<sup>\*</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the data type is Array [1..192] OF BOOL.

Variable name	_EC_DisconnSlavTbl						
Meaning	Disconnected Slave Table			Global/local	Global		
Function	Slaves are given i	Slaves are given in the table in the order of slave node addresses.					
	The element for a	The element for a slave is TRUE if the corresponding slave was disconnected.					
Data type	Array [1512] OF	BOOL*		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Disconnect Ether	CAT Slave			
		tions	EC_DisconnectSlave				
			Connect EtherCAT Slave				
			EC_ConnectSla	ive			

<sup>\*</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the data type is Array [1..192] OF BOOL.

Variable name	_EC_DisableSlavTbl						
Meaning	Disabled Slave Table			Global/local	Global		
Function	Slaves are given i	Slaves are given in the table in the order of slave node addresses.					
	The element for a	The element for a slave is TRUE if the corresponding slave is disabled.					
Data type	Array [1512] OF	BOOL*		Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

<sup>\*</sup> For NX102 and NX1P2 CPU Units and NJ-series CPU Units, the data type is Array [1..192] OF BOOL.

Variable name	_EC_PDActive						
Meaning	Process Data Communications Status			Global/local	Global		
Function	TRUE when proce	ess data communica	ations are performe	d with all slaves*.			
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Disconnect Ether	CAT Slave			
		tions	EC_Disconnect	Slave			
			Connect EtherCAT Slave				
			EC_ConnectSla	ive			

<sup>\*</sup> Disabled slaves are not included.

Variable name	_EC_PktMonStop						
Meaning	Packet Monitoring Stopped			Global/local	Global		
Function	TRUE when pack	TRUE when packet monitoring is stopped.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Stop Packet Moni	itor			
		tions	EC_StopMon				
			Start Packet Monitor				
			EC_StartMon				

Variable name	_EC_LinkStatus						
Meaning	Link Status			Global/local	Global		
Function	TRUE if the comm	TRUE if the communications controller link status is Link ON.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

Variable name	_EC_PktSaving						
Meaning	Saving Packet Data File			Global/local	Global		
Function	Shows whether a	Shows whether a packet data file is being saved.					
	TRUE: Packet dat	a file being saved.					
	FALSE: Packet da	FALSE: Packet data file not being saved.					
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instruc-	Related instruc- Saving Packet Data File				
		tions	EC_SaveMon				

Variable name	_EC_InDataInvali	_EC_InDataInvalid						
Meaning	Input Data Invalid			Global/local	Global			
Function	TRUE when proce	TRUE when process data communications are not normal and the input data is not valid.						
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instructions						

**Note** All system-defined variables that are related to the status of EtherCAT communications give the current status.

Variable name	_EC_InData1Invalid						
Meaning	Input Data1 Invalid			Global/local	Global		
Function	TRUE when process data communications established in the primary periodic period are not normal and the input data is not valid.						
	You can use this s	system-defined vari	able only for NX-se	ries CPU Units.			
Data type	BOOL			Range of values	TRUE or FALSE		
R/W access	R	Retained	Not retained.	Network Publish	Published.		
Usage in user program	Possible.	Related instructions					

**Note** All system-defined variables that are related to the status of EtherCAT communications give the current status.

Variable name	_EC_InData2Inva	_EC_InData2Invalid						
Meaning	Input Data2 Invalid			Global/local	Global			
Function	TRUE when process data communications established in the priority-5 periodic period are not normal and the input data is not valid.  Note You can use this system-defined variable only for NX-series CPU Units.  Note This variable is always TRUE for NX102 and NX1P2 CPU Units.							
Data type	BOOL			Range of values	TRUE or FALSE			
R/W access	R	Retained	Not retained.	Network Publish	Published.			
Usage in user program	Possible.	Related instruc- tions						

Note All system-defined variables that are related to the status of EtherCAT communications give the current status.

#### Functional Classification: EtherCAT Communications Diagnosis/Statistics Log

Variable name	_EC_StatisticsLogEnable*					
Meaning	Diagnosis/Statistics Log Enable			Global/local	Global	
Function	Changes to TRUE	Changes to TRUE when the diagnosis/statistics log is started.				
	Changes to FALSE when the diagnosis/statistics log is ended.					
Data type	BOOL	300L		Range of values	TRUE or FALSE	
R/W access	R/W	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc-				
		tions				

<sup>\*</sup> This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_EC_StatisticsLogCycleSec*				
Meaning	Diagnosis/Statistics Log Cycle			Global/local	Global
Function	Specifies the interval to write the diagnostic and statistical information of the diagnosis/statistics log in units of seconds.  When 0 is specified, the diagnostic and statistical information is written only once when the diagnosis/statistics log is ended.  Note The write interval does not change even if you change the value of this system-defined variable while the diagnosis/statistics log operation is in progress.				
Data type	UINT			Range of values	0, or 30 to 1800
R/W access	R/W	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

<sup>\*</sup> This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_EC_StatisticsLogBusy*				
Meaning	Diagnosis/Statistics Log Busy			Global/local	Global
Function	TRUE while the diagnosis/statistics log operation is in progress.				
Data type	BOOL			Range of values	TRUE or FALSE
R/W access	R	Retained	Not retained.	Network Publish	Published.
Usage in user program	Possible.	Related instruc- tions			

<sup>\*</sup> This system-defined variable was added for unit version 1.11 of the CPU Unit.

Variable name	_EC_StatisticsLogErr*					
Meaning	Diagnosis/Statistic	s Log Error		Global/local	Global	
Function	TRUE when the diagnosis/statistics log failed to start or it is impossible to write into the log.					
	The value of this flag is determined when _EC_StatisticsLogBusy (Diagnosis/Statistics Log Busy) changes to FALSE after the diagnosis/statistics log operation is started.					
	The error end is caused by the following.					
	Another records cannot be added in the log file because the capacity of the SD Memory Card is fully used.					
	The SD Memory Card is write protected.					
	There is no SD Memory Card.					
	The function cannot be started because the value specified for _EC_StatisticsLogCycleSec (Diagnosis/Statics Log Cycle) is invalid.					
Data type	BOOL			Range of values	TRUE or FALSE	
R/W access	R	Retained	Not retained.	Network Publish	Published.	
Usage in user program	Possible.	Related instruc- tions				

<sup>\*</sup> This system-defined variable was added for unit version 1.11 of the CPU Unit.




# **Example of Operations for EtherCAT Communications**

This section provides a series of example operations for when an NJ/NX-series CPU Unit is connected to slaves.

8-1	Examp	le of Operations for EtherCAT Communications	8-2
	8-1-1	System Configuration Example	. 8-2
	8-1-2	Wiring and Settings	. 8-2
	8-1-3	Setting the EtherCAT Network Configuration	. 8-3
	8-1-4	Programming	. 8-5
	8-1-5	Offline Debugging	. 8-5
	8-1-6	Turning the Power ON	. 8-5
	8-1-7	Online Debugging	. 8-5
	8-1-8	Downloading the Network Configuration Information and the User Program	8-5
	8-1-9	Confirming the Start of Communications	. 8-6

#### **Example of Operations for EtherCAT** 8-1 Communications

#### **System Configuration Example** 8-1-1



There are no restrictions on the order of node addresses.

#### Wiring and Settings 8-1-2

#### Wiring

- · Install the Controller and slaves.
- · Connect communications cables to the EtherCAT master and slaves.
- · Connect the power supply.

#### **Settings**


· Set the node address for each slave.

#### 8-1-3 Setting the EtherCAT Network Configuration

Start the Sysmac Studio and make the following settings.

#### Creating the EtherCAT Network Configuration


Use the EtherCAT Configuration Editor to create the slave configuration.



In this example, digital I/O slaves are set to node addresses 1 and 2 and Servo Drives are set to node addresses 3 and 4.

● Assigning Device Variables to Digital I/O Slaves (Node Addresses 1 and 2)


Use the I/O Map to assign device variables to the I/O ports of the slaves.



In this example,  $Pwr\_On$  is assigned to bit 0 of slave 1 and  $Hm1\_On$  is assigned to bit 1 of slave 1.

#### Axis Settings for the Servo Drives (Node Addresses 3 and 4)

Add an axis to the Motion Control Setup and then assign the Servo Drive with node address 3 to the axis to set the axis.



In the same way, add an axis and assign the Servo Drive with node address 4 to it.

#### Setting EtherCAT Master Parameters

Set the parameters for the EtherCAT master from the EtherCAT master settings.

#### Setting Slave Parameters

Set the slave parameters from the EtherCAT configuration slave settings. If a communications error prevents the slaves from receiving signals from the EtherCAT master, the slave settings will control the slave outputs.

#### Assigning Tasks to Slaves

Use **Task Settings** to assign tasks to slaves.

- Set Period/Execution Conditions for each task from Task Settings.
- Set names of the tasks that are assigned to the slaves from I/O Control Task Settings.

#### 8-1-4 Programming


#### Programming

When the operation start button is pressed, the *Pwr\_On* variable changes to TRUE and axis control is enabled. (See rung 0.)

```
PWR1

Pwr_On _EC_PDSlavTbl[MC_Axis000.Cfg.NodeAddress] MC_Axis000— Axis — Axis— MC_Power Axis— MC_Axis000 Pwr1_Status
Enable Status
Busyr— Enter Variable
Error — Enter Variable
Error D— Enter Variable
```

When the homing button is pressed, the *Hm1\_On* variable changes to TRUE and homing is performed. (See rung 1.)



#### Assigning Programs to Tasks

Use Task Settings to assign programs to tasks and set the program execution order.

 Assign programs to tasks and set the program execution order from Program Assignment Settings.

#### 8-1-5 Offline Debugging

You can use the Simulator to check the program and task execution times with offline debugging.

#### 8-1-6 Turning the Power ON

Turn ON the following power supplies.

- Slave unit power supply (The PWR indicator on the slave will light when the power supply turns ON.)
- Slave I/O power supply
- Controller power supply

#### 8-1-7 Online Debugging

Compare and merge the network configuration that was set on the Sysmac Studio and the actual configuration.

#### 8-1-8 Downloading the Network Configuration Information and the User Program

Download the network configuration information and the user program that were created on the Sysmac Studio to the Controller.

Note Use the synchronization operation of the Sysmac Studio to download the data.

#### 8-1-9 **Confirming the Start of Communications**

Check to make sure that all registered slaves are participating in the network and that communications start.

Make sure that the master indicators are in the following status.

NET RUN indicator	Lit
NET ERR indicator	Not lit
LINK/ACT indicator (physical layer LINK)	Flashing

Make sure that the status indicators on all slaves are in the following status.

PWR indicator	Lit
RUN indicator	Lit
ERR indicator	Not lit
L/A IN (physical layer LINK inputs)	Flashing
L/A OUT (physical layer LINK outputs)	Flashing (Not lit on the last slave.)



## **Troubleshooting**


This section describes overview of troubleshooting, network diagnosis procedure using diagnostic and statistical information, functions of the Sysmac Studio and the CPU Unit for acquiring diagnostic and statistical information, functions of the Sysmac Studio for identifying error slaves and error causes, and precautions and methods of replacing slaves during communications.

9-1	Overvi	ew of Errors	9-2		
	9-1-1	How to Check for Errors	9-3		
	9-1-2	Errors Related to the EtherCAT Master Function Module	9-3		
9-2	Troubleshooting				
	9-2-1	Error Table			
	9-2-2	Error Descriptions	9-4		
	9-2-3	Resetting Errors	9-4		
	9-2-4	Diagnostic and Statistical Information	9-4		
	9-2-5	Identifying an Error Slave and Cause of Error	. 9-22		
9-3	Precau	itions When Connecting or Disconnecting Slaves during			
		unications	. 9-26		
	9-3-1	Procedure for Connecting and Disconnecting Slaves during			
		Communications	. 9-26		
	9-3-2	Prohibition to Physically Disconnecting a Slave and Resetting an Error or			
		Connecting a Slave at the Same Time	. 9-26		
9-4	Replacing Slaves during Communications				
	9-4-1	Introduction			
	9-4-2	Slave Replacement Methods	. 9-28		
	9-4-3	Backing Up Settings	. 9-29		
	9-4-4	Restoring Settings	. 9-30		
	9-4-5	Replacement Procedure			

#### **Overview of Errors**

You manage all of the errors that occur on the NJ/NX-series Controller as events. This allows you to see what errors have occurred and find corrections for them with the same methods for the entire range of errors that is managed (i.e., CPU Unit, NX Units, NX-series Slave Terminals, EtherCAT slaves, \*1 and CJ-series Units).

\*1 Only Sysmac devices are supported.



You can use the troubleshooting functions of the Sysmac Studio or the Troubleshooter on an HMI to quickly check for errors that have occurred and find corrections for them.

Refer to the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for error types and details, specific corrections when errors occur, and troubleshooting information on the entire NJ/NXseries Controllers.

## 9-1-1 How to Check for Errors

Refer to *Checking for Non-fatal Errors* in the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503-E1-19 or later) for checking for errors.

## 9-1-2 Errors Related to the EtherCAT Master Function Module

Refer to *Errors Related to the EtherCAT Master Function Module* in the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503-E1-19 or later) for errors related to the EtherCAT Master Function Module.

# 9-2 Troubleshooting

This section describes errors (events) that can occur and the corrections for them, network diagnosis procedure using diagnostic and statistical information, functions of the Sysmac Studio and the CPU Unit for acquiring diagnostic and statistical information, and functions of the Sysmac Studio for identifying error slaves and error causes.

#### 9-2-1 **Error Table**

Refer to Error Tables in Errors in the EtherCAT Master Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for tables of errors (events) that occur in the EtherCAT Master Function Module.

#### 9-2-2 **Error Descriptions**

Refer to Error Descriptions in Errors in the EtherCAT Master Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for description of errors (events) that occur in the EtherCAT Master Function Module.

#### 9-2-3 **Resetting Errors**

Refer to Resetting Errors in the EtherCAT Master Function Module in Errors Related to the EtherCAT Master Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) for how to reset errors.

#### 9-2-4 **Diagnostic and Statistical Information**

The diagnostic and statistical information provides statistics on the number of communications frames sent and received by the EtherCAT master and EtherCAT slaves as well as the number of frames for which errors were detected.

You can use it to diagnosis the EtherCAT network line qualify for the following:

- Confirming that the EtherCAT network was correctly installed during a test run
- Finding the causes of communications errors that occur during normal operation
- Checking the EtherCAT network line quality during normal operation

# **EtherCAT Network Diagnostic Procedure**

You can diagnose the EtherCAT network with the diagnostic and statistical information for the master and slaves. The procedure to diagnose the EtherCAT network is given below.

If the diagnostic results show that the EtherCAT network is not operating normally, you can find the location of the error.

An outline procedure from EtherCAT network diagnosis through correction is given below.

- Acquire the diagnostic and statistical information for the master and slaves.
- Check for errors in the trends shown in the master diagnostic and statistical information.
- Find the locations of the errors with trends in the slave diagnostic and statistical information.



Implement corrections for the error locations that you found.

**5** Confirm status after implementation of the correction.

## Step 1: Acquiring Diagnostic and Statistical Information for Master and Slaves

There are two methods to acquire the diagnostic and statistical information for the master and slaves. The following table describes each method. Use either of the methods to acquire the diagnostic and statistical information for the master and slaves.

Acquisition method	Description	
Using the diagnostic and statistical information display of Sysmac Studio	Use the Sysmac Studio to acquire the diagnostic and statistical information. You can save the acquired diagnostic and statistical information as a CSV file on the computer.	page 9- 12
Using the diagnosis/statistics log of CPU Unit	The CPU Unit acquires the diagnostic and statistical information periodically. The acquired diagnostic and statistical information is saved in an SD Memory Card that is mounted on the CPU Unit.	page 9- 18




### **Precautions for Correct Use**

When the Sysmac Studio's diagnostic and statistical information display is used, the maximum number of error frames recorded for the slave diagnostic and statistical information is 255. If the number of error frames exceeds 255, increasing trends of the number of error frames cannot be recognized. If the number of error frames for the slave diagnostic and statistical information is assumed to exceed 255, execute the clear operation for the slave diagnostic and statistical information before acquiring the slave diagnostic and statistical information.

## Step 2: Checking for Errors in Trends in Master Diagnostic and Statistical Information

Check for trends in the items in the acquired master diagnostic and statistical information to diagnose errors in the EtherCAT network.

Example of the Master Diagnosis/Statistics Tab Page of Sysmac Studio



If the value of the frame reception timeout count or number of CRC error frames received increases, then the EtherCAT network is not operating normally.

If a certain number of the frame reception timeout count or a certain number of CRC error frames received is detected, the EtherCAT network may not be operating normally.

If there is an error or possibility of an error in the EtherCAT network, find the error location by performing Step 3: Finding Locations of Errors with Trends in Slave Diagnostic and Statistical Information on page 9-7.




#### **Additional Information**

A certain number of the frame reception timeout count or a certain number of CRC error frames received is also detected if a power OFF or disconnection occurs in an EtherCAT slave.

## Step 3: Finding Locations of Errors with Trends in Slave Diagnostic and Statistical Information

You can check for trends of values in the slave diagnostic and statistical information to find the locations of the errors.

Example of the Slave Diagnosis/Statistics Tab Page of Sysmac Studio



The following are the points to check to find error locations based on the number of error frames.

- · A certain number of error frames is detected.
- The number of error frames is increased compared to the value acquired last time.
- Failed is displayed for the number of error frames.

If a certain number of error frames is detected for more than one port, start finding error locations from the port with the highest number of error frames.


The error locations that you find will change depending on the configuration of EtherCAT slave connection. Refer to the network configuration diagram to find error locations.

This section explains how to find error locations with two examples of EtherCAT network configurations in which the EtherCAT slave connection configurations are different.


## **Examples of Finding Error Locations**

Example 1: Network Configuration Where an EtherCAT Junction Slave Is Not Used

#### Network configuration



#### Slave Diagnosis/Statistics Tab Page



The number of error frames for the input port (PortA) for node address 4 is 31, so you can see that error frames were received on the input port for node address 4.


Therefore, you can assume that there is a problem between the output port (PortB) for node address 3 and the input port for node address 4.

This corresponds to location (A), (B) or (C) in the network configuration diagram.


Concretely, you can assume the following possible error locations.

- The device at node address 3
- The cable between the output port at node address 3 and the input port at node address 4 or the connectors at those ports
- · The device at node address 4

Example 2: Network Configuration Where an EtherCAT Junction Slave Is Used



Slave Diagnosis/Statistics Tab Page



The number of error frames for the input port (PortA) for node address 4 is 123, so you can see that error frames were received on the input port for node address 4.

Therefore, you can assume that there is a problem between the output port (X3) for node address 64 and the input port for node address 4.

This corresponds to location (A), (B) or (C) in the network configuration diagram.


Concretely, you can assume the following possible error locations.

- The device at node address 64
- The cable between the output port at node address 64 and the input port at node address 4 or the connectors at those ports
- · The device at node address 4

This is the procedure to find error locations when Failed is displayed for the number of error frames.

In the EtherCAT network configuration, Failed is sometimes displayed for more than one Ether-CAT slave.

In the network configuration for example 2, assume that Failed is displayed for the number of error frames for node addresses 4 and 5.



If Failed is displayed for the number of error frames, the EtherCAT slave currently cannot communicate. If an EtherCAT slave cannot communicate, all of the EtherCAT slaves connected after it may not be able to communicate. In the network configuration diagram of example 2, node address 5 is connected after node address 4.

Therefore, you can assume that there is an error in node address 4 that prevents communica-

Concretely, you can assume the following possible error locations.

- The device at node address 64
- The cable between the output port at node address 64 and the input port at node address 4 or the connectors at those ports
- · The device at node address 4

9-11

## Step 4: Implementing Corrections for Error Locations

Implement corrections for the error locations that you found.

To check the position of the EtherCAT slave with an error in the network configuration, refer to the Node Address|Network configuration display under Slave Diagnosis/Statistics.

The following table provides corrections for the causes as assumed from the diagnostic and statistical information.

statistical i	gnosis and information end	Slave diagnosis and statistical information trend	Assumed error cause	Possible correction
The frame reception		Failed is displayed for the number of error frames for	The power is not supplied to the EtherCAT slave.	Supply the power to the EtherCAT slave.
timeout count is increasing. error frames received is not increasing.	some slaves.	A connector on the Ethernet cable is disconnected, the contact is faulty, or parts are faulty.	Make sure the connector is mated correctly, or reconnect the connector.	
			The Ethernet cable is broken or the specified cable was not used.	Replace the Ethernet cable.
		A general-purpose Ethernet hub is connected.	Replace the general-pur- pose Ethernet hub with an EtherCAT Junction Slave.	
			The EtherCAT slave failed.	Replace the EtherCAT slave.
		The number of error frames is not increasing.	The EtherCAT master communications cycle is too short.	Go online with the Sysmac Studio, lengthen the task period (communications cycle), and set it in the CPU Unit again.
	The number of CRC error frames received is	Failed is displayed for the number of error frames and the number of error frames is increasing.	A connector on the Ethernet cable is disconnected, the contact is faulty, or parts are faulty.	Make sure the connector is mated correctly, or reconnect the connector.
increasing.		The EtherCAT slave failed.	Replace the EtherCAT slave.	
		Failed is displayed for the number of error frames or the number of error frames is increasing.	There is noise.	Implement noise counter- measures.

The following is a description of the case which does not correspond to any of above conditions.

If a certain number of the frame reception timeout count and CRC error frames received for the master diagnostic and statistical information, as well as a certain number of error frames for the slave diagnostic and statistical information are detected but are not increasing, these numbers were detected temporarily due to any of the following error causes.

- · A connector on the Ethernet cable is disconnected, the contact is faulty, or parts are faulty.
- · There is noise.
- · The Ethernet cable is broken or the specified cable was not used.

Implement corrections for the error locations that you found. Refer to the table above for what to do for corrections.

## Step 5: Confirming After Implementing Corrections

To confirm that the error locations were corrected, perform Step 2: Checking for Errors in Trends in Master Diagnostic and Statistical Information on page 9-5 again to make sure the network is operating normally.

## Diagnostic and Statistical Information Display of Sysmac Studio

This section describes how to activate the diagnostic and statistical information display of Sysmac Studio. The functions of the operation buttons and displayed items are also explained.


#### Activation


Activate the diagnostic and statistical information display of Sysmac Studio as follows.

- Start the Sysmac Studio and go online with the Controller.
- Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, rightclick EtherCAT under Configurations and Setup and select Edit.



Right-click the EtherCAT master on the EtherCAT Tab Page and select Display Diagnosis/Statistics Information from the menu.





The diagnostic and statistical information for the master and slaves are displayed.

## Operation Button Functions


The following table describes the buttons to operate the diagnostic and statistical information.

Button	Function
Get	Acquires the diagnostic and statistical information from the EtherCAT master and EtherCAT slaves*1 and updates the display.
	You can retain a maximum of 100 diagnostic and statistical data that you acquired.
	When the Display Diagnosis/Statistics Information Tab Page is closed, the diagnostic and statistical information that you acquired are discarded.
Clear Master Diagnosis/Statistics Information	Clears all values of the master diagnostic and statistical information to zeros.
Clear Slave Diagnosis/Statistics Information *2	Clears all values of the slave diagnostic and statistical information to zeros.
Output File	Outputs the diagnostic and statistical information to a CSV file in a specified folder. The following data are output.
	Master diagnostic and statistical information
	Slave diagnostic and statistical information *3

- \*1 Only for the EtherCAT slaves that are registered in the network configuration information of the project.
- \*2 This appears only when the unit version set in the Sysmac Studio project is 1.11 or later.
- \*3 If the number of error frames exceeds 255, 255 is output.

## Master Diagnostic and Statistical Information

The following are the items displayed for the master diagnostic and statistical information.



The last two master diagnostic and statistical data acquired from the EtherCAT master are displayed. If the master diagnostic and statistical data is not acquired, "---" is displayed.



#### **Precautions for Correct Use**

- All values of the master diagnostic and statistical information are cleared to zeros when the power supply to the Controller is turned ON.
- The network propagation delay time is not cleared to zero when the master diagnostic and statistical information is cleared.
- Values of the network propagation delay time and transmission cycle are valid only if an Ether-CAT slave that supports a distributed clock is assigned to the primary periodic task. If an EtherCAT slave that supports a distributed clock is not assigned to the primary periodic task,
- The items for PDO communications cycle 2 are valid only if an EtherCAT slave that supports a distributed clock is assigned to the priority-5 periodic task. If the CPU Unit does not have a priority-5 periodic task or if an EtherCAT slave that supports a distributed clock is not assigned to the priority-5 periodic task, "---" is displayed.

The values of the following items may increase if there is an EtherCAT network error.

The following table gives the description of each item, assumed cause of increase, and correction.

Item	Displayed information	Assumed cause of increase	Possible correction
Frame reception timeout count	The number of frame reception timeouts that occurred.	A cause to a Process Data reception Timeout occurred, which increases the Frame reception timeout count. The Frame reception timeout count will increase also when the count in the CRC Error Frames Received, Short frames received, or Overlength frames received increases.	Refer to EtherCAT Network Diagnostic Procedure on page 9-4.
Reception buf- fer overflow count	The number of frames discarded due to buffer overflows when receiving data.	There are too many frames on the EtherCAT network that are not Ether-CAT frames.	See if there are computers or other non-EtherCAT devices connected to the EtherCAT network and remove them if there are any.
Non-Ether- CAT frames received	The number of frames received other than EtherCAT frames.	There are frames on the EtherCAT network that are not EtherCAT frames.	See if there are computers or other non-EtherCAT devices connected to the EtherCAT network and remove them if there are any.
Link OFF count	The number of times link OFF was detected.	A cause to a Link OFF Error occurred.	Refer to Error Tables in Errors in the EtherCAT Master Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) and remove the cause of the error.
Discarded process data receptions	The number of process data packets discarded when receiving process data.	Operations for which multi-execution is prohibited in <i>Prohibition to Physically Disconnecting a Slave and Resetting an Error or Connecting a Slave at the Same Time</i> on page 9-26 were executed.  The value sometimes increases when	Refer to Prohibition to Physically Disconnecting a Slave and Resetting an Error or Connecting a Slave at the Same Time on page 9-26.
		the network is started or communicating EtherCAT slaves are replaced.	
Discarded message receptions	The number of messages discarded in mailbox reception.	A cause to an EtherCAT Message Error occurred.	Refer to Error Tables in Errors in the EtherCAT Master Function Module in the NJ/NX-series Troubleshooting Manual (Cat. No. W503-E1-19 or later) and remove the cause of the error.
CRC Error Frames Received	The number of frames received that resulted in CRC errors.	The frames on the EtherCAT network are corrupted.	Refer to EtherCAT Network Diagnostic Procedure on page 9-4.
Frame reception errors	The number of frames resulting in reception errors from the Ethernet controller (EtherMAC).	The frames on the EtherCAT network are corrupted due to noise.	Implement noise countermeasures.
Collision count	The total number of delay collisions on the line after start of transmissions.	A repeater hub is connected.	You cannot use repeater hubs with EtherCAT communications. See if there are repeater hubs connected to the EtherCAT network and remove them if there are any.
Short frames received	The number of frames received with less than 64 bytes.	The frames on the EtherCAT network are corrupted due to noise. Computers or other non-EtherCAT devices are connected.	Refer to EtherCAT Network Diagnostic Procedure on page 9-4.
Overlength frames received	The number of frames received with more than 1,522 bytes.	The frames on the EtherCAT network are corrupted due to noise. Computers or other non-EtherCAT devices are connected.	Refer to EtherCAT Network Diagnostic Procedure on page 9-4.

9-15




## **Precautions for Correct Use**

Even if communications are normal, values other than 0 may occur for the frame reception timeout count and the number of CRC error frames received. Refer to EtherCAT Network Diagnostic Procedure on page 9-4 to determine if the EtherCAT network is operating normally.

## Slave Diagnostic and Statistical Information

The following are the items displayed for the slave diagnostic and statistical information.



Item	Displayed information
Node Address Network configuration	EtherCAT network configuration of the project
Node Address	Node addresses of the EtherCAT slaves
Port Name	Port names of the EtherCAT slave input or output ports
	Port names that are defined in the EtherCAT slave's ESI file
	• If no name is defined, Port A, Port B, Port C, or Port D is displayed. If there are two ports, an input and an output port, i.e., Port A and Port B is displayed. The input port which is the only input port is displayed first followed by the output ports (some EtherCAT slaves have more than one output port).
Error Frames	Number of error frames received on the EtherCAT slave's input and output ports
	Range: 0 to 254
	255 or more is displayed if 255 or more error frames were received.
	When the diagnostic and statistical information is acquired twice or more, the increase from the previous acquisition is displayed in parentheses on the right of the number of error frames.  Example: When the number acquired at the previous acquisition was 6 and
	increased 4: 10 (+4)
	• Failed is displayed when the number of error frames cannot be acquired from EtherCAT slaves for reasons such as absence of the relevant EtherCAT slave.
	You cannot acquire the slave diagnostic and statistical information when the diagnosis/statistics log of the CPU Unit is in progress. If you click the <b>Get</b> Button, <i>Auto logging</i> is displayed for the number of error frames. Note that if the result of the previous acquisition was <i>Failed</i> , <i>Failed</i> will be displayed again.



## **Precautions for Correct Use**

When you display the slave diagnostic and statistical information, first open a Sysmac Studio project where the network configuration agrees with the actual network. If the network configuration in the project does not agree with the actual network, the slave diagnostic and statistical information is not displayed correctly. If a project where the network configuration agrees with the actual network is not available, create a new project, make the network configuration in the project agree with the actual network, and then display the slave diagnostic and statistical information. Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on building the network configuration.

## Diagnosis/Statistics Log of CPU Unit

The periodic auto-acquisition of the diagnostic and statistical information is allowed for the following purposes during a test run or normal operation of equipment.

- Checking the EtherCAT network line quality for predictive monitoring and preventive maintenance
- Finding locations of errors when they occur



#### Version Information

A CPU Unit with unit version 1.11 or later is required to use this function.

#### Overview

This function acquires the diagnostic and statistical information that the EtherCAT master and slaves have. The information is acquired at the specified cycle and saved as a log file in an SD Memory Card that is mounted on the CPU Unit.

Use system-defined variables to set the execution command for this function and the cycle at which the diagnostic and statistical information is saved.



#### **Precautions for Correct Use**

- An SD Memory Card is required to use this function. Refer to the NJ-series CPU Unit Hardware User's Manual (Cat. No. W500), the NX-series NX102 CPU Unit Hardware User's Manual (Cat. No. W593), the NX-series NX1P2 CPU Unit Hardware User's Manual (Cat. No. W578) or the NX-series CPU Unit Hardware User's Manual (Cat. No. W535) for the SD Memory Card models supported by the CPU Unit.
- · When the diagnosis/statistics log is in progress, you cannot acquire or clear the slave diagnostic and statistical information from the diagnostic and statistical information display of the Sysmac Studio. Try it again after the diagnosis/statistics log is completed.
- When the diagnosis/statistics log is in progress, the response time in message communications with EtherCAT slaves may be extended.

## Diagnostic and Statistical Information to Acquire

The following table shows the information to acquire and describes the information.

Information to acquire	Description
Master diagnostic and statistical information	Same as the master diagnostic and statistical information displayed by the diagnostic and statistical information display of Sysmac Studio. Refer to <i>Master Diagnostic and Statistical Information</i> on page 9-14 for details.
Slave diagnostic and statistical information*1	Same as the number of error frames for the slave diagnostic and statistical information displayed by the diagnostic and statistical information display of Sysmac Studio. Refer to <i>Slave Diagnostic and Statistical Information</i> on page 9-16 for details.

<sup>\*1</sup> Only for the EtherCAT slaves that are registered in the EtherCAT master network configuration information of the project.



## **Precautions for Correct Use**

If this function is executed when the EtherCAT master network configuration information is in the following status, only the master diagnostic and statistical information is saved in a log file. The slave diagnostic and statistical information and system-defined variables are not saved.

- The network configuration information is cleared for the Clear All Memory operation.
- No EtherCAT slave is registered in the network configuration information.

## Setting Cycle to Save Diagnostic and Statistical Information in a Log File

You can specify the cycle to save the acquired diagnostic and statistical information in a log file within the range from 30 seconds to 30 minutes in units of seconds. You can also specify the cycle so that the diagnostic and statistical information is saved only once into a log file when the execution of this function is completed.

## Specifications of Log File

The acquired diagnostic and statistical information is saved as a CSV log file in the SD Memory Card. You can save a maximum of 1,000 diagnostic and statistical data in a log file.

The file name, file type and save location of the log file saved in the SD Memory Card are given below.

Item	Specifications	
File name	ECAT_STATISTICS.csv	
File format	CSV	
Save location	Root folder	



#### **Additional Information**

The following available space is required in an SD Memory Card to save the diagnostic and statistical information.

Size of a data = 273 bytes + 51 bytes × Number of EtherCAT slaves

If the number of EtherCAT slaves is 512 and you want to save 1,000 diagnostic and statistical data, an available space of approximately 26 MB is required.

The specification of data saved in a log file is given below.

- For the first row, data are output in the following order: the CPU Unit model, software version, package version, hardware version, and serial ID. For the following rows, the date and time of acquisition and the diagnostic and statistical data are output.
- The number of error frames for the slave diagnostic and statistical information is left blank if the number of error frames cannot be acquired from the relevant EtherCAT slave.



#### **Additional Information**

The items of information such as the master diagnostic and statistical information output to a CSV file by this function are arranged in the same order as the diagnostic and statistical information display of Sysmac Studio. You can make the same file format by exchanging the places of the row and column of each item.

## Related System-defined Variables

The following system-defined variables are used to control execution of the diagnosis/statistics log. Refer to 7-1-2 System-defined Variables for details on system-defined variables.

Variable name	Meaning
_EC_StatisticsLogEnable	Diagnosis/Statistics Log Enable
_EC_StatisticsLogCycleSec	Diagnosis/Statistics Log Cycle
_EC_StatisticsLogBusy	Diagnosis/Statistics Log Busy
_EC_StatisticsLogErr	Diagnosis/Statistics Log Error

#### Procedures

The procedure to use the diagnosis/statistics log is as follows.

Set a value for \_EC\_StatisticsLogCycleSec (Diagnosis/Statistics Log Cycle).

The cycle to save the diagnostic and statistical information in a log file is set.

Set the value in units of seconds. (Example: set 30 for 30 seconds, set 1,800 for 30 minutes).

If 0 is set, the diagnostic and statistical information is saved only once when execution of this function is completed.

**2** Change *EC\_StatisticsLogEnable* (Diagnosis/Statistics Log Enable) from FALSE to TRUE.

The execution of the diagnosis/statistics log is started.

- EC\_StatisticsLogErr (Diagnosis/Statistics Log Error) changes to FALSE.
- \_EC\_StatisticsLogBusy (Diagnosis/Statistics Log Busy) changes to TRUE.

During execution of the diagnosis/statistics log, the diagnostic and statistical information is acquired and saved in a log file at the cycle specified in step 1.


If one of the following (a) to (f) is detected during the diagnosis/statistics log, the diagnosis/statistics log is automatically terminated.

- (a) The maximum number of diagnostic and statistical data are saved in a log file.
- (b) The SD Memory Card does not have sufficient available space.
- (c) The SD Memory Card is write protected.
- (d) There is no SD Memory Card.
- (e) A synchronization (or downloading) is executed on the Sysmac Studio.
- (f) The value set for \_EC\_StatisticsLogCycleSec is out of range.
- An EtherCAT Diagnosis/Statistics Log Started error is recorded in the event log.
- EC StatisticsLogBusy changes to FALSE.
- If (b), (c), (d) or (f) occurs, \_EC\_StatisticsLogErr changes to TRUE.
- An EtherCAT Diagnosis/Statistics Log Ended error is recorded in the event log.
- **3** Change \_*EC\_StatisticsLogEnable* (Diagnosis/Statistics Log Enable) from TRUE to FALSE.

Execution of the diagnosis/statistics log is terminated. The diagnostic and statistical information is saved in a log file when this variable changes to FALSE, regardless of the write cycle setting.

- EC StatisticsLogBusy changes to FALSE.
- An EtherCAT Diagnosis/Statistics Log Ended error is recorded in the event log.

The following figure shows the timing chart.





#### **Precautions for Correct Use**

- To retain the log file saved in the SD Memory Card, rename the log file or save it in another memory before you execute the diagnosis/statistics log. Once the diagnosis/statistics log is started, the log file in the SD Memory Card is deleted and a new log file is created.
- During the diagnosis/statistics log, you cannot re-execute the diagnosis/statistics log. Check that \_*EC\_StatisticsLogBusy* is FALSE before you execute the diagnosis/statistics log.
- Even if you change the value of \_EC\_StatisticsLogCycleSec during the diagnosis/statistics
  log, the change is not reflected to the saving cycle of the diagnostic and statistical information.
  The changed saving cycle is used during the next execution of the diagnosis/statistics log. To
  use the changed saving cycle, you need to terminate the diagnosis/statistics log that is currently executed.
- Access \_EC\_StatisticsLogErr after \_EC\_StatisticsLogBusy changes from TRUE to FALSE.
   The value of \_EC\_StatisticsLogErr varies while \_EC\_StatisticsLogBusy is TRUE.



#### **Additional Information**

The following are the examples of methods to retain the log file saved in the SD Memory Card.

- Use the SD Memory Card instruction such as FileRename or FileCopy to change the file name.
- Use the FTP server function for the built-in EtherNet/IP to take the log file out.
- Eject the SD Memory Card and save the file in another medium.

#### 9-2-5 Identifying an Error Slave and Cause of Error

Sysmac Studio provides the following functions to identify the slave in which an error occurred and the cause of the error.

- EtherCAT configuration information view of the event log
- · EtherCAT configuration view of the current error

# EtherCAT Configuration View of the Current Error

The following information is displayed on the EtherCAT configuration view in the slave diagnosis/statistics information display.

- · Slave state
- · Whether a slave with error exist or not
- Location where communications stopped




#### **Version Information**

Sysmac Studio version 1.22 or higher is required to use the EtherCAT configuration view of the current error.

### Display Method

Right-click the master on the EtherCAT Tab Page and select Display Diagnosis/Statistics Information from the menu.

The network configuration information is displayed in topology diagram on the EtherCAT configuration view in the slave diagnosis/statistics information display.




## Displayed Information

The following information is displayed on the EtherCAT configuration view in the slave diagnosis/statistics information display.

#### a) Slave state


Slaves in Disabled, Disconnected and Not Matched states are shown by icons with marks.

See below for an example of the pane showing slaves in Not Matched state.



b) Whether a slave with error exist or not


Slaves in which an error occurred are displayed with an error mark for emphasis.



The event name of the current error on the relevant slave is displayed in the tooltip of the error mark.

c) Location where communications stopped

The connecting line between the ports at which communications are stopped are highlighted.



## **EtherCAT Configuration Information View of the Event Log**

The following information is displayed on the EtherCAT configuration information (Event log) view.

· Event in the event log whose event source is the EtherCAT Master Function Module




#### **Version Information**

Sysmac Studio version 1.22 or higher is required to use the EtherCAT configuration information view of the event log.

## Display Procedure

Right-click in the Controller Event Log Tab Page and select Display EtherCAT Configuration **Information (Event Log)** from the menu.






## **Additional Information**

You can narrow down the range to display the event log using time information in which events occurred.


Right-click on the event log to select the condition to display from the menu.

The network configuration information is displayed on the EtherCAT configuration information (Event log) view in topology diagram.



## Display Information

Slaves are shown with error icons in the display when they have an error whose source is EtherCAT Master Function Module and whose level is higher than the minor fault level.



# **Precautions When Connecting or** 9-3 **Disconnecting Slaves during Communications**

#### **Procedure for Connecting and Disconnecting Slaves during** 9-3-1 **Communications**

Always use the following procedure to turn OFF the slave power supply or connect/disconnect cables during EtherCAT master communications.\*

- \* This includes the pre-operational, safe-operational, and operational states.
- Step 1. Use the Sysmac Studio or an instruction to send a command to disconnect the slave.
- Step 2. Confirm that the slave was disconnected normally.
- Step 3. Turn OFF the power supply to the slave or disconnect the cable.

If you turn OFF the power supply or disconnect the cable without performing steps 1 and 2, the slaves that are operating may be adversely affected.

#### 9-3-2 Prohibition to Physically Disconnecting a Slave and Resetting an Error or Connecting a Slave at the Same Time

If you perform the following operation a or b at the same time as operation c, a Slave Initialization Error will occur.


- a) Turn OFF the power supply to the slave or disconnect the cable.
- b) Turn ON the power supply to the slave or connect the cable.
- c) Reset an error in the EtherCAT Master Function Module or connect the slave.\*
- \* This can happen when the Reset EtherCAT Error (ResetECError) instruction or Connect EtherCAT Slave (EC -ConnectSlave) instruction is cyclically executed in the user program.

If you perform these operations at the same time, the EtherCAT master may access a slave with a different node address than the specified node address, or other unexpected operations may occur. Therefore, never turn OFF the power supply to the slave or disconnect the cable at the same time as you reset an error or connect a slave.

# 9-4 Replacing Slaves during Communications

## 9-4-1 Introduction

You can temporarily stop and start communications with a specified slave and all subsequent slaves without stopping the entire communications system. This makes it possible to replace slaves during communications for maintenance, or for replacement when a slave malfunctions.





## **Precautions for Correct Use**

- A Process Data Communications Error occurs if you physically disconnect a slave from the network without executing the disconnection instruction.
- A Network Configuration Verification Error occurs if the correct node address is not set for a slave that was replaced with the disconnection instruction and a connection is made to a different port than the one that was used for the disconnection instruction.

#### 9-4-2 **Slave Replacement Methods**

The slave to be replaced is first disconnected from the network and then reconnected after you replace it. Use one of the following methods to disconnect and reconnect the slave.

Method 1: Connecting and Reconnecting Specified Slaves from the Sysmac Studio

Method 2: Execute the Disconnect EtherCAT Slave and Connect EtherCAT Slave instructions.

Execute the following instructions in the user program. You can use a pushbutton or an HMI to input the execution condition.

Function	Instruction	Description
Disconnect EtherCAT Slave	EC_DisconnectSlave	Temporarily disconnects a slave from the EtherCAT network for maintenance, such as replacement of the slave.
Connect EtherCAT Slave	EC_ConnectSlave	Reconnects a temporarily disconnected slave to the EtherCAT network after maintenance, such as replacement of the slave.

If the EtherCAT slave to replace has backup parameters, we recommend that you use the Sysmac Studio to replace the slave. (You can specify backing up the parameters in the EtherCAT slave from the Sysmac Studio.)





#### **Additional Information**

The disconnection and reconnection operations are not required for slaves that are disabled with the EtherCAT Slave Enable/Disable Settings. You therefore cannot disconnect and reconnect them from the Sysmac Studio. If you execute the disconnection and connection instructions, they will result in errors.

## 9-4-3 Backing Up Settings


Before you replace an EtherCAT slave that is currently performing communications, the settings of the EtherCAT slave to replace are backed up. The settings of an EtherCAT slave are divided according to the storage locations and setting methods into initial parameters and backup parameters, as shown in the following table.

Slave settings	Storage location	Slave setting method
Initial parameters	EtherCAT master	These parameters are set automatically from the EtherCAT master when EtherCAT communications start or when a slave is connected.
Backup parameters	EtherCAT slaves	You set these parameters by transferring them to the slaves from the Backup Parameter Settings Tab Page of the Sysmac Studio.  The data can also be transferred from the EtherCAT Drive Tab Page.

To replace an EtherCAT slave, you first back up the backup parameters that are stored in the EtherCAT slave.

- 1 Click the **Edit Backup Parameter Settings** Button in the EtherCAT Slave Setting Tab Page. The Backup Parameter Settings Tab Page is displayed.
- Click the **Transfer from Slave** Button.

  All of the backup parameters that are stored in the EtherCAT slave and displayed in the list are transferred from the EtherCAT slave.



3 Click the Compare Button.

Check to be sure that you have correctly obtained the backup parameters in step 2.



#### Additional Information


- · You can back up the EtherCAT slave settings for any EtherCAT slave that is connected to the network (i.e., whenever the EC EntrySlavTbl/] (Network Connected Slave Table) systemdefined variable is TRUE) either before of after the disconnection command is sent to the EtherCAT slave.
- You can also set the EtherCAT drive slaves from the EtherCAT Drive Tab Page. Back up the settings information from the EtherCAT Drive Tab Page. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the applicable EtherCAT drive slaves.
- · You do not need to back up the settings to replace an EtherCAT slave that does not have backup parameters.

#### 9-4-4 **Restoring Settings**

After you replace the EtherCAT slave, you restore the settings that you backed up before you replaced the slave. The backup parameters that were backed up are restored to the EtherCAT slave.

- Click the Edit Backup Parameter Settings Button in the EtherCAT Slave Setting Tab Page. The Backup Parameter Settings Tab Page is displayed.
- **2** Click the **Transfer to Slave** Button.

All of the backup parameters that are stored in the EtherCAT slave and displayed in the list are downloaded to the EtherCAT slave.



Click the **Compare** Button.

Check to be sure that you have correctly transferred the backup parameters in step 2.



### **Precautions for Correct Use**


Restore the settings to the EtherCAT slave before you connect the EtherCAT slave to restart process data communications. Restore the EtherCAT slave settings while the slave is connected to the network (i.e., whenever the <code>\_EC\_EntrySlavTbl[]</code> (Network Connected Slave Table) system-defined variable is TRUE). You must set the node address of the EtherCAT slave before it can participate in the network.



#### **Additional Information**

- You can set the EtherCAT drive slaves from the EtherCAT Drive Tab Page. Restore the settings information from the EtherCAT Drive Tab Page. Refer to the Sysmac Studio Version 1 Operation Manual (Cat. No. W504) for the applicable EtherCAT drive slaves.
- You do not need to restore the settings to replace an EtherCAT slave that does not have backup parameters.

#### **Replacement Procedure** 9-4-5



Note: Steps shown in dotted boxes depend on the system.




#### **Precautions for Safe Use**

- When an EtherCAT slave is disconnected from the Sysmac Studio or with an instruction, communications will stop and control of the outputs will be lost not only for the disconnected slave, but for all slaves connected after it. Always confirm system safety before you disconnect an EtherCAT slave.
- If noise occurs or an EtherCAT slave is disconnected from the network, any current communications frames may be lost. If frames are lost, slave I/O data is not communicated, and unintended operation may occur. The slave outputs behave according to the slave specifications. For details, refer to relevant manuals for each slave. If a noise countermeasures or slave replacement is required, perform the following processing.
  - Program the \_EC\_InDataInvalid (Input Data Invalid) system-defined variable as an interlock condition in the user program. Refer to 6-1-3 Checking the Validity of the Process Data.
  - Set the PDO communications timeout detection count setting in the EtherCAT master to at least 2. Refer to 5-4-1 Setting EtherCAT Master for the setting procedure.

## **Disconnecting Slaves**

If a slave is disconnected, slaves connected after the designated slave (on the output side) in a daisy chain are disconnected at the same time. Slaves connected before the disconnected slave (on the input side) and slaves connected beyond Junction Slaves continue to operate. (If (1) is disconnected in the following figure, (2) and (3) are also disconnected.)



The status of the system-defined variables for disconnected slaves are listed in the following table. The status in the following table are reached immediately after disconnection. This status does not change even if a slave is physically removed from the actual network configuration or physically connected to the actual network configuration again. The corresponding element in the Network Connected Slave Table changes to FALSE when the slave is physically removed from the actual network configuration.


System-defined variable name	Description	Value
_EC_RegSlavTbl[] (Registered Slave Table)	This variable shows the slaves that are registered in the network configuration information.	Remains TRUE.
_EC_EntrySlavTbl[] (Network Connected Slave Table)	This variable shows the slaves that are registered in the network configuration information and connected to the network.	The corresponding element changes to FALSE when the slave is removed from the actual network configuration.
_EC_MBXSlavTbl[] (Message Communications Enabled Slave Table)	This variable shows the slaves that are registered in the network configuration information and able to perform message communications.	The corresponding element changes to FALSE after the Ether-CAT slave is disconnected from the Sysmac Studio or with an instruction.
_EC_PDSlavTbl[] (Process Data Communicating Slave Table)	This variable shows the slaves that are registered in the network configuration information and performing process data communications.	The corresponding element changes to FALSE after the Ether-CAT slave is disconnected from the Sysmac Studio or with an instruction.
_EC_DisconnSlavTbl[] (Disconnected Slave Table)	This variable shows the slaves that are registered in the network configuration information and disconnected from the network.	The corresponding element changes to TRUE after the Ether-CAT Slave is disconnected from the Sysmac Studio or with an instruction.

## **Reconnecting Slaves**

When reconnecting disconnected slaves after replacement or inspection, make sure that the following conditions are met and then reconnect them. If they are reconnected without meeting following conditions, process data communications with the slaves will not start again, and a network configuration verification error will occur. If the conditions are met, \_EC\_EntrySlavTbl will be TRUE.

- · Make sure that the slave's node address is set correctly.
- Make sure that there are no errors in the order that the slaves are connected.

There are no restrictions on the order when reconnecting slaves that are in a daisy chain. For example, even if slaves (1) to (3) in a configuration such as the one shown in the following figure are disconnected, there are no restriction on the reconnection order of slaves (1) to (3). (For example, the slaves can be reconnected in the order (3), (2), (1) or (1), (3), (2).)



The status of the system-defined variables for disconnected slaves that have been successfully reconnected are listed in the following table.

System-defined variable name	Description	Value
_EC_RegSlavTbl[] (Registered Slave Table)	This variable shows the slaves that are registered in the network configuration information.	Remains TRUE.
_EC_EntrySlavTbl[] (Network Connected Slave Table)	This variable shows the slaves that are registered in the network configuration information and connected to the network.	Shows actual network configuration (changes to FALSE for disconnection and to TRUE for connection).
_EC_MBXSlavTbl[] (Message Communications Enabled Slave Table)	This variable shows the slaves that are registered in the network configuration information and able to perform message communications.	The corresponding element changes to TRUE after the EtherCAT slave is connected from the Sysmac Studio or with an instruction
_EC_PDSlavTbl[] (Process Data Communicating Slave Table)	This variable shows the slaves that are registered in the network configuration information and performing process data communications.	The corresponding element changes to TRUE after the EtherCAT slave is connected from the Sysmac Studio or with an instruction
_EC_DisconnSlavTbl[] (Disconnected Slave Table)	This variable shows the slaves that are registered in the network configuration information and disconnected from the network.	The corresponding element changes to FALSE after the EtherCAT Slave is disconnected from the Sysmac Studio or with an instruction.



## **Additional Information**

Synchronization correction processing is performed to reconnect synced slaves. Therefore, several seconds may be required per slave until reconnection is completed.



# **Appendices**

The appendices describe the relation of EtherCAT communications to overall CPU Unit status, packet monitoring functions, and multi-vendor application.

A-1	EtherCAT Status in Relation to CPU Unit Status						
	A-1-1 When the Power Supply Is Turned ON						
	A-1-2	CPU Unit Operating Modes	A-3				
	A-1-3	Controller Errors Other Than Errors in the Built-in EtherCAT Master	A-5				
	A-1-4	Others	A-6				
	A-1-5	When the Power Supply Is Turned OFF	A-7				
A-2	Monito	ring Packets	<b>A-</b> 8				
A-3	Multi-vendor Environments						
	A-3-1	EtherCAT Slave Information File (ESI Files)	A-17				
	A-3-2	Connecting Slaves from Other Manufacturers to an OMRON Master	A-19				
	A-3-3	Installing ESI Files	A-19				
	A-3-4	Editing PDO Entry Tables	A-25				
	A-3-5	Settings for MDP-compatible Slaves from Other Manufacturers	A-30				
A-4	Glossa	ry	. A-33				
A-5	Version Information						

# A-1 EtherCAT Status in Relation to CPU Unit Status

The status of EtherCAT master memory, the ability to download master and slave settings, and the slave status are given below for different CPU Unit operating modes, Controller errors, and other status.

# A-1-1 When the Power Supply Is Turned ON

Mem	ory related to E	therCAT mast	er		Slaves	
Device vari- ables	Category _EC sys- tem-defined variables	Network configura- tion infor- mation	Diagnos- tic and sta- tistical informa- tion/Proto- col monitor	Downloading master and slaves settings	Slave outputs	Slave communica- tions status
Devices variables that are not retained: Initial values  Axes variables: Initial values	Initial values		Cleared to all zeros.		The status of slave outputs before the start of EtherCAT communications depend on the slave. Slaves output values of device variables after EtherCAT communications start.	Enters the Operational state.

## A-1-2 CPU Unit Operating Modes

		Memory rel	ated to Ether	CAT master			Sla	ves
CPU Unit status	Device variables	Category _EC sys- tem- defined variables	Network configura- tion infor- mation	Diagnos- tic and statistical informa- tion/Proto- col monitor	Current errors	Down- loading master and slaves settings	Slave out- puts	Slave communi- cations status
PROGRAM mode	Shows the I/O data exchanged on the EtherCAT communications.	Continually shows EtherCAT communications status. (Does not depend on the operating mode of the CPU Unit.)	Does not change. (Does not depend on the operat- ing mode of the CPU Unit.)	Continually shows EtherCAT communications status. (Does not depend on the operating mode of the CPU Unit.)	Retained (Do not depend on the operat- ing mode of the CPU Unit.)	Master settings: OK     Slave settings: OK (How-ever, setting may not be possible depending on the status of the slave.)	Continually shows the output data sent from the EtherCAT master. (Does not depend on the operating mode of the CPU Unit.)	Does not change. (Does not depend on the operat- ing mode of the CPU Unit.)
Switching between PROGRAM and RUN mode and Device Out- put Hold Configura- tion*1 dis- abled	Device variables that are not retained: Initial val- ues  Axis vari- ables: Retained							
Switching between PROGRAM and RUN mode and Device Out- put Hold Configura- tion enabled	Device variables that are not retained: Retained Axis vari- ables: Retained							

		Memory rel	ated to Ether	CAT master			Sla	ves
CPU Unit status	Device variables	Category _EC sys- tem- defined variables	Network configura- tion infor- mation	Diagnos- tic and statistical informa- tion/Proto- col monitor	Current errors	Down- loading master and slaves settings	Slave out- puts	Slave communi- cations status
RUN mode	Shows the I/O data exchanged on the EtherCAT communications.					Master settings: Not possible.     Slave settings: OK (However, setting may not be possible depending on the status of the slave.)		

<sup>\*1</sup> Refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for the Device Output Hold Configuration.

# A-1-3 Controller Errors Other Than Errors in the Built-in EtherCAT Master

		Memory rel	ated to Ether	CAT master			Sla	ves
CPU Unit status	Device variables	Category _EC sys- tem- defined variables	Network configura- tion infor- mation	Diagnos- tic and statistical informa- tion/Proto- col monitor	Current errors	Down- loading master and slaves settings	Slave out- puts	Slave communi- cations status
A major fault level Control- ler error occurs.	Device variables that are not retained: Initial val- ues Axis vari- ables: Retained	Continually shows EtherCAT communications status. (Does not depend on the operating mode of the CPU Unit.)	Does not change. (Does not depend on the operat- ing mode of the CPU Unit.)	Continually shows EtherCAT communications status. (Does not depend on the operating mode of the CPU Unit.)	Retained (Do not depend on the operat- ing mode of the CPU Unit.)		In Operational state, the values from before operation stopped are output. When the slaves have entered Safe-operational state, the outputs depend on the slave settings. Inputs are enabled.	EtherCAT communications stop. Enters the Safe-Operational state.
A partial fault level Controller error occurs.  A minor fault level Controller error occurs.	Shows the I/O data exchanged on the EtherCAT communications.						Continually shows the output data sent from the EtherCAT master. (Does not depend on the operating mode of the CPU Unit.)	Does not change. (Does not depend on the operat- ing mode of the CPU Unit.)

Refer to 9-1 Overview of Errors if a Controller error occurs in the built-in EtherCAT master.

### A-1-4 Others

		Memory rel	ated to Ether	CAT master			Sla	ves
CPU Unit status	Device variables	Category _EC sys- tem- defined variables	Network configura- tion infor- mation	Diagnos- tic and statistical informa- tion/Proto- col monitor	Current errors	Down- loading master and slaves settings	Slave out- puts	Slave communi- cations status
Memory all clear	Cleared to all zeros.	Entirely initialized (0).	Deleted.	Cleared to all zeros.	Cleared to all zeros.		Depends on the slave set-	Enters the Initialized state.
Download- ing data and Device Out- put Hold Configura- tion*1 dis- abled	Device variables that are not retained: Initial val- ues Axis vari- ables: Ini- tial values	Continually shows EtherCAT communications status. (Does not depend on the operating mode of the CPU Unit.)	Does not change. (Does not depend on the operating mode of the CPU Unit.)	Cleared to all zeros.	Cleared to all zeros. (However, after downloading data, the EtherCAT master restarts, and records any event as a current error if the cause of the error has not been removed.)		tings.	Enters the Initialized state when parameters are transferred to the master.     Enters the Preoperational state when backup parameters are downloaded to slaves.
Download- ing data and Device Out- put Hold Configura- tion enabled	Device variables that are not retained: Retained Axis vari- ables: Retained			Continually shows EtherCAT communications status. (Does not depend on the operating mode of the CPU Unit.)	Retained (Do not depend on the operat- ing mode of the CPU Unit.)		Continually shows the output data sent from the EtherCAT master. (Does not depend on the operating mode of the CPU Unit.)	Does not change. (Does not depend on the operat- ing mode of the CPU Unit.)

<sup>\*1</sup> Refer to the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501) for the Device Output Hold Configuration.

## A-1-5 When the Power Supply Is Turned OFF

Me	Memory related to EtherCAT master					Sla	ves
Device vari- ables	Category _EC system- defined vari- ables	Network configura- tion infor- mation	Diagnostic and statisti- cal informa- tion/Protoco I monitor	Current errors	Download- ing master and slaves settings	Slave out- puts	Slave com- munica- tions status
Does not change.	Does not change.	Does not change.	Updating the protocol monitor stops.	Cleared to all zeros.		Depends on the slave set- tings.	Depends on the behavior of slaves when Ether- CAT commu- nications stop.

# A-2 Monitoring Packets


Packet monitoring stores a certain number of the most recent packets sent and received by the Ether-CAT master along with time information.

You can use an EtherCAT communications instruction or the Sysmac Studio to save the captured packet data in packet data files in the system in the CPU Unit.

You can use any of the following methods to obtain the packet data saved in the system memory in the CPU Unit.

- · Reading directly from the Sysmac Studio
- · Saving to an SD Memory Card inserted in the CPU Unit

You can view the captured packet data with packet analyzer software, such as WireShark. You can also use the data for analysis applications, such as error analysis and data mining.





#### **Additional Information**

For the NJ301- $\square\square\square\square$  and NJ101- $\square\square\square\square$  CPU Units, unit version 1.10 or later and Sysmac Studio version 1.12 or higher are required to use the packet monitoring function.

The \_EC\_PktMonStop system-defined variable, which shows the operating status of packet monitoring, will always be TRUE in an NJ301- $\square\square\square\square$  CPU Unit with unit version 1.09 or earlier.

If you execute any EtherCAT instructions for packet monitoring (EC\_StartMon, EC\_StopMon, EC\_SaveMon, or EC\_CopyMon) in the user program, an error is returned that says packet monitoring cannot be used.

## **Starting and Stopping Packet Monitor**


You can start and stop packet monitoring either with instructions in the user program or with operations on the Sysmac Studio.

#### Using Instructions in the User Program


- EC\_StartMon (Start EtherCAT Packet Monitor) instruction: Starts the execution of packet monitoring and continues to update a fixed number of packets.
- EC\_StopMon (Stop EtherCAT Packet Monitor) instruction: Stops the execution of packet monitoring.

#### Operation from the Sysmac Studio

- **1** Start the Sysmac Studio and go online with the Controller.
- 2 Double-click EtherCAT under Configurations and Setups in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setups and select *Edit*.



**3** Right-click in the EtherCAT Network Configuration Tab Page and select **Display Packet Monitor** from the menu.



The Packet Monitor Dialog Box is displayed.

**4** Click the **Start** Button to begin monitoring packets.



**5** Click the **Stop** Button to stop monitoring packets.



### **Saving Packet Data**

#### Reading Data from the Sysmac Studio

After you stop packet monitoring, you can use the Sysmac Studio to read the packet data and save it in a file.

- **1** Stop monitoring packets.
- **2** Click the **Save Packet Data** Button to save the packet data.



The Save Dialog Box is displayed.

Input a file name, and then click the **Save** Button.

A TCPDump packet data file with a .cap extension is saved.

### • Saving to an SD Memory Card from Memory in the CPU Unit

Stop monitoring packets, and then execute the EC\_SaveMon (Save EtherCAT Packets) instruction to save a given quantity of collected packet data in memory in the CPU Unit. Then, execute the EC\_CopyMon (Transfer EtherCAT Packets) instruction to save the packet data that was saved in the CPU Unit to a file on an SD Memory Card inserted into the CPU Unit. You can specify the name of the file that is saved in the SD Memory Card. The number of files is limited only by the space that is available on the SD Memory Card.



#### **Additional Information**

- Packet data in the CPU Unit's memory is not retained when the power is interrupted.
- Packet data cannot be saved while packets are being monitored.
- Packet monitoring cannot be started while saving packet data.
- If an SD Memory Card is not inserted and you execute the instruction to copy the data to the SD Memory Card, then an error is returned. If there is no SD Memory Card, only the one file in the CPU Unit's memory can be read to the Sysmac Studio.
- Packet monitoring starts when the power is turned ON.

# Packet Monitoring Specifications

Item	Specification
Maximum data size of one packet data file	12 MB
Maximum number of packets that can be obtained	3,904 packets
Format of packet data file	TCPDump format (cap)
Time information	Recorded (unit: $\mu$ s) The elapsed time starting when packet monitoring begins is recorded. (Packet monitoring can be started when power turns ON, for an EtherCAT instruction, or for a Sysmac Studio operation.)
Save location for packet data file	CPU Unit's system: 1 file SD Memory Card inserted in CPU Unit: Multiple files (up to capacity of SD Memory Card)

## **Sample Programming**


This sample transfers EtherCAT communications packets to an SD Memory Card when an EtherCAT slave error occurs. The file name is 'PacketFile.' The processing procedure is as follows:

- **1** The system-defined variable \_EC\_ErrSta (EtherCAT Error) is monitored and processing is started if an error occurs.
- **2** The EC\_StopMon instruction is used to stop execution of packet monitoring for EtherCAT communications.
- **3** The EC\_SaveMon instruction is used to save EtherCAT communications packet data to a file in the system of the CPU Unit.
- **4** The EC\_CopyMon instruction is used to copy that file to the SD Memory Card.
- **5** The EC\_StartMon instruction is used to restart execution of packet monitoring for EtherCAT communications.

LD					
	Internal Variables	Variable	Data type	Initial value	Comment
		OperatingEnd	BOOL	False	Processing completed
		Operating	BOOL	False	Execution condition
		A	BOOL	False	
		В	BOOL	False	
		С	BOOL	False	
		RS_instance	RS		
		EC_StopMon_instance	EC_StopMon		
		EC_SaveMon_instance	EC_SaveMon		
		EC_CopyMon_instance	EC_CopyMon		
		EC_StartMon_instance	EC_StartMon		

External Variables	Variable	Data type	Constant	Comment
	_EC_ErrSta	WORD	X	Built-in EtherCAT Error
	_EC_PktMonStop	BOOL	N	Packet Monitoring Stopped
	_EC_PktSaving	BOOL		Saving Packet Data File
	_Card1Ready	BOOL	$\square$	SD Memory Card Enabled Flag

Determine if instruction execution is completed. EC\_StartMon\_instance.Done OperatingEnd EC\_StopMon\_instance.Error EC\_SaveMon\_instance.Error EC\_CopyMon\_instance.Error EC\_StartMon\_instance.Error Monitor for EtherCAT errors. \_EC\_PktMonStop EC\_StopMon\_instance.Busy ΕN In \_EC\_ErrSta ln1 WORD#16#00 ln2 EC\_SaveMon\_instance.Busy EC\_CopyMon\_instance.Busy EC\_StartMon\_instance.Busy В RS\_instance \_EC\_PktSaving В Operating RS Q1 OperatingEnd Reset1



Internal Variables	Variable	Data type	Initial value	Comment
	EC_Err	BOOL	False	Controller error in the EtherCAT Master Function Module.
	EC_Err_Trigger	BOOL	False	Detect when EC_Err changes to TRUE.
	DoEC_PktSave	BOOL	False	Processing
	Stage	INT	0	Stage change
	R_TRIG_instance	R_TRIG		
	EC_StopMon_instance	EC_StopMon		
	EC_SaveMon_instance	EC_SaveMon		
	EC_CopyMon_instance	EC_CopyMon		
	EC_StartMon_instance	EC_StartMon		

External Variables	Variable	Data type	Constant	Comment
	_EC_ErrSta	WORD	$\square$	Built-in EtherCAT Error
	_EC_PktMonStop	BOOL	$\square$	Packet Monitoring Stopped
	_EC_PktSaving	BOOL		Saving Packet Data File
	_Card1Ready	BOOL	$\square$	SD Memory Card Enabled Flag

ST

```
// Start sequence when _EC_ErrSta changes to TRUE.
EC_Err:=(_EC_ErrSta <> WORD#16#00);
R_TRIG_instance(Clk:=EC_Err, Q=>EC_Err_Trigger);
IF ( (EC_Err_Trigger=TRUE) AND (DoEC_PktSave=FALSE) AND (_EC_PktMonStop=FALSE) AND (_EC_PktSaving=FALSE) AND (_Card1Ready=TRUE) ) THEN
   DoEC_PktSave:=TRUE;
                 :=INT#1;
   Stage
   EC_StopMon_instance(Execute:=FALSE); // Initialize instance.
   EC_SaveMon_instance(Execute:=FALSE);
   EC_CopyMon_instance(Execute:=FALSE);
   EC_StartMon_instance(Execute:=FALSE);
END_IF;
// Instruction execution
IF (DoEC_PktSave=TRUE) THEN
   CASE Stage OF
                     // Stop EtherCAT packet monitor.
      EC_StopMon_instance(
         Execute :=TRUE);
      IF (EC_StopMon_instance.Done=TRUE) THEN
                                   // Normal end
         Stage:=INT#2;
      ELSIF (EC_StopMon_instance.Error=TRUE) THEN
                                   // Error end
         Stage:=INT#10;
      END_IF;
                     // Save EtherCAT packet data to file in system.
      EC_SaveMon_instance(
        Execute :=TRUE);
      IF (EC_SaveMon_instance.Done=TRUE) THEN
         Stage:=INT#3;
                                   // Normal end
      ELSIF (EC_SaveMon_instance.Error=TRUE) THEN
         Stage:=INT#20;
                                   // Error end
      END_IF;
                     // Copy EtherCAT packet data file to the SD Memory Card.
      EC_CopyMon_instance(
         Execute :=TRUE,
        FileName:='PacketFile');
      IF (EC_CopyMon_instance.Done=TRUE) THEN
         Stage:=INT#4;
                                  // Normal end
      ELSIF (EC_CopyMon_instance.Error=TRUE) THEN
         Stage:=INT#30;
                                   // Error end
      END_IF;
```

# A-3 Multi-vendor Environments

This section provides precautions and describes documentation for multi-vendor environments.


## A-3-1 EtherCAT Slave Information File (ESI Files)

Setting information for EtherCAT is defined in EtherCAT slave information (ESI) files. These files are provided by the individual slave manufacturers. Various EtherCAT communications settings are defined based on the ESI definitions of connected slaves.

You can install the ESI files in the Sysmac Studio to use them to edit the EtherCAT configuration in the Sysmac Studio and create the network configuration information.

You can download the network configuration information to the EtherCAT master to configure the EtherCAT network.

Contact the manufacturer or the point of purchase to obtain the most recent ESI files for slaves that are manufactured by other companies.



Communications are started according to the communications settings and the network configuration in the ESI files that are installed.



#### **Additional Information**

ESI file versions that are lower than ESI version-1.0.1 specifications are not supported. If you install an ESI file version that is not supported, a message saying that you cannot use the slave is displayed by the Sysmac Studio.

The NJ/NX-series CPU Units do not support variables with some of the data types that are defined in ETG.1020. If variables with any unsupported data types are included in the slave information (ESI), you cannot use the slave.

The following tables gives the data types that are supported by different Sysmac Studio versions.

Data Type		Sysmac Studio Ver.					
Data Type	1.09 or higher	1.08	1.07 or lower				
BIT1, BIT2, BIT3, BIT4, BIT5, BIT6, BIT7, and BIT8	Supported.	Supported.	Not supported.				
BITARR8, BITARR16, and BITARR32	Supported.	Supported.	Not supported.				
ARRAY[0n] OF BYTE	Supported.	Not supported.*	Not supported.*				
ARRAY[0n] OF UINT	Supported.	Not supported.*	Not supported.*				
INT24, INT40, INT48, and INT56	Not supported.	Not supported.	Not supported.				
UINT24, UINT40, UINT48, and UINT56	Not supported.	Not supported.	Not supported.				
STRING(n)	Not supported.	Not supported.	Not supported.				

<sup>\*</sup> With Sysmac Studio version 1.06, 1.07, or 1.08, you can read ESI files and assign device variables. However, you cannot monitor them in the I/O Map.

If variables with any of these data types are included in the slave information (ESI), a message saying that you cannot use the slave is displayed in the ESI Library Dialog Box of the Sysmac Studio.

# A-3-2 Connecting Slaves from Other Manufacturers to an OMRON Master

You can install the ESI file for a slave from another manufacturer in the Sysmac Studio to handle the slave in the same way as an OMRON slave. (Only the ESI files for OMRON slaves for which connectability has been confirmed are installed in the Sysmac Studio in advance.)

When connecting a slave from another manufacturer to an OMRON master, refer to the manuals for the other manufacturer's slaves, and then ask your OMRON representative if you have any questions.



#### **Additional Information**

EtherCAT setup software that is provided by other manufacturers cannot be connected to NJ/NX-series CPU Units.

## A-3-3 Installing ESI Files


#### Procedure

An ESI (EtherCAT slave information) file is an XML file that describes the connection information and profile of the EtherCAT slave.

To connect an EtherCAT slave that is manufactured by other company to an NJ/NX-series master, you must install the ESI file for that slave in the Sysmac Studio to enable setting the slave.


Use the following procedure to install an ESI file.

1 Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit*.




The edit pane is displayed.

2 Right-click the EtherCAT master that is displayed in the edit pane and select **Display ESI Library**.




The ESI Library Dialog Box is displayed.

**3** Click the **this folder** link in the ESI Library Dialog Box.



The contents of the EsiFiles folder are displayed.

4 Copy the ESI file for the EtherCAT slave that is manufactured by another company and paste it in the EsiFiles folder. Obtain the ESI file from the slave manufacturer. The ESI file must conform to the most recent ETG ESI specifications.




**5** Restart the Sysmac Studio.

The ESI file that you installed is displayed in the ESI Library Dialog Box after you restart the Sysmac Studio.

#### Procedure to Confirm ESI File Installation


Use the following procedure to confirm that an ESI file was installed correctly

1 Double-click EtherCAT under Configurations and Setup in the Multiview Explorer. Or, right-click EtherCAT under Configurations and Setup and select *Edit*.




The edit pane is displayed.

2 Right-click the EtherCAT master that is displayed in the edit pane and select **Display ESI Library**.




The ESI Library Dialog Box is displayed.

**3** Click the + Icon to the left of the name of the ESI file that was added.




The slave definitions in the ESI file are expanded so that you can check the following items.

- Model
- Revision
- · Product name



4

If an exclamation mark is not displayed, click the **Close** Button.





#### **Additional Information**

If an ESI file for a slave cannot be used in the Sysmac Studio, an exclamation mark is displayed to the left of the file name. If an exclamation mark is displayed, obtain an ESI file with the cause corrected from the slave manufacturer, and then install the ESI file again.

## A-3-4 Editing PDO Entry Tables

A PDO entry table maps objects in a slave to the process data that is used for communications between the master and the slave.

You cannot necessarily edit all of the PDO mappings in a PDO entry table.

You can add and delete objects in a PDO entry table or you can change the order of the entries.

The Sysmac Studio provides the functionality to edit slave PDO entry tables.

Order of entries

	Index	Size	Data type	PDO entry name	Comment
	0x6000:00	16[bit]	UINT	uiAAA	
Ш	0x6001:00	8[bit]	USINT	b2BBB	
	0x6002:00	8[bit]	USINT	b4CCC	
	0x6008:00	16[bit]	UINT	uiddd	
$\forall$	0x6010:00	32[bit]	UDINT	udEEE	

## **Editing a PDO Entry Table**

Initially, a slave PDO entry table contains the default objects. Some slaves have objects other than these default objects.

You can add objects other than the default objects to the PDO entry table, or you can delete objects from the PDO entry table. However, the following restrictions apply:

#### Byte Boundaries

An OMRON master must arrange entry objects by byte boundaries. (This applies only to objects that are one byte or larger in size.)

If an entry object is bit data, padding must be entered to adjust the boundaries. Padding is meaningless data that is added to the end of an entry so that an object ends at a boundary of the specified size. You can use the following methods to arrange objects within byte boundaries.

- Click the Align Button.
   Padding is automatically entered. Refer to the descriptions of the buttons below for details.
- · Add padding to the PDO entries manually.

In the following example, 2 bits of padding are entered to adjust the byte boundary when entering objects with BIT2 and BIT4 data types for PDO entries.

	Index	Size	Data type	PDO entry name	Comment
	0x6000:00	16[bit]	UINT	uiAAA	
	0x6001:00	2[bit]	BIT2	b2BBB	
	0x6002:00	4[bit]	BIT4	b4CCC	
<b>4</b>	0x0000:00	2[bit]			
/`	0x6010:00	32[bit]	UDINT	udEEE	


Because an object with 2 bits and an object with 4 bits are entered, 2 bits of padding must be added to adjust the byte boundary (8 bits).

#### Connecting to Slaves from Other Manufacturers

When connecting a slave from another manufacturer, refer to the manuals for the other manufacturer's slaves, and then ask your OMRON representative if you have any questions.

#### Specifications of Edit PDO Entry Tables Window

The following buttons are used to edit a PDO entry table. The meanings of the buttons are given below.



Button	Description
Add PDO Entry Button	Use these buttons to add objects to and delete objects from the PDO entry table.
Delete PDO Entry Button	"0x0000:00" is for padding. The default size is 8 bits.
Edit PDO Entry Button	Use this button to change the size of padding (i.e., the number of bits) in the PDO mapping.
Move Up Button	Use these buttons to change the order of the PDO entries by moving objects up and down.
Move Down Button	
Align Button	Use this button to automatically order the PDO entries and adjust byte boundaries.
	The PDO entries are ordered according to the type, descending PDO entry size, ascending indices, and then ascending subindices.
	For the type, data arranged by byte boundaries (INT, BYTE, STRING, etc.) comes first, followed by data arranged by bit boundaries (BIT, BIT8, etc.).
Compare*1*2	Use this button to compare the PDO map settings of the project and that of the actual slave.
Apply Actual Device *1*2	Use this button to upload the PDO map settings from the actual slave and update only the PDO mapping data in the PDO Map Settings Window.

<sup>1</sup> These buttons are displayed only when Sysmac Studio is connected online with the CPU Unit.

<sup>\*2</sup> This button is not displayed in MDP-compatible slave setting.



#### **Version Information**


- Sysmac Studio version 1.08 or higher is required to use the following buttons to edit PDO entry tables: Edit PDO Entry, Move Up, Move Down, and Align.
- Sysmac Studio version 1.08 or higher is required to add "0x0000:00" to a PDO entry table.
- Sysmac Studio version 1.22 or higher is required to use the following buttons to edit PDO entry tables: **Compare** and **Apply Actual Device**.

## **Editing Methods for PDO Entries**

#### Adding PDO Entries


Click the **Add PDO Entry** Button. The entry table from the slave is displayed. Select the object to add with the cursor and click the **OK** Button to add it.

The selected object is added at the location of the cursor in the PDO entry table.



#### Editing PDO Entries

Use the cursor to select padding (0x0000:00) in the PDO entry table and click the **Edit PDO Entry** Button. Enter the size and click the **OK** Button. The size of the padding will change.



## **PDO Mapping Comparison and Uploading**

You can upload the PDO map settings from the actual slave or compare with the PDO map settings of the actual slave. See below for the procedure to compare and upload the PDO map settings.



#### **Version Information**

Sysmac Studio version 1.22 or higher is required to use the PDO map compare and upload function.



#### **Precautions for Correct Use**

When the Sysmac Studio is online, you cannot change PDO mapping selection or edit PDO entries.




#### **Additional Information**

- You can display the PDO Map Settings Window even when the Sysmac Studio is online.
- You can execute the Compare and Upload functions even when the slave is in the Init state.

Use the following procedure to compare and upload the PDO map settings.

1 In the *PDO Map Settings* of EtherCAT slave settings, click the **Edit PDO Map Settings** Button. The PDO map settings edit window is displayed.



#### Compare


Click the **Compare** Button to read the PDO mapping list and PDO entry list from the actual slave and compare them with the PDO map settings in the project.

a) When no inconsistencies are found

The following dialog box is displayed.



b) When inconsistencies are found The following dialog box is displayed.



When inconsistencies are found by comparison, you can update the information in Edit PDO Map Settings Window to match the PDO Map and PDO entry list of the actual slave by clicking **Yes** Button.

Click the **OK** Button or **Apply** Button in the Edit PDO Map Settings Window to update the project with the PDO mapping list and PDO entry list of the actual slave.

#### Upload

Click the **Apply Actual Device** Button to read the PDO mapping list and PDO entry list from the actual slave and update the information in the Edit PDO Map Settings Window to match the PDO mapping list and the entry list of the actual slave.


Click the **OK** Button or **Apply** Button in the Edit PDO Map Settings Window to update the project with the PDO mapping list and PDO entry list of the actual slave.

### A-3-5 Settings for MDP-compatible Slaves from Other Manufacturers

The MDP (Modular Device Profile) defines the data structure for the settings in EtherCAT slaves. It is an EtherCAT specification. You can use slaves that support MDPs from other manufacturers on the EtherCAT Tab Page.

There are two sets of settings, slave and module, for MDP-compatible slaves.


**1** Right-click the slave in the EtherCAT Tab Page and select **Edit Module Configuration**. An Edit Pane for the module configuration is displayed.



	Index	Size	Data type	PDO entry name	Comment
	0x6000:00	16[bit]	UINT	uiAAA	
	0x6001:00	2[bit]	BIT2	b2BBB	
	0x6002:00	4[bit]	BIT4	b4CCC	
<b>4</b>	0x0000:00	2[bit]			
/`	0x6010:00	32[bit]	UDINT	udEEE	

Because an object with 2 bits and an object with 4 bits are entered, 2 bits of padding must be added to adjust the byte boundary (8 bits).

**2** Select a slave on the Edit Pane for the module configuration. A list of the slave settings is displayed.



Some items in the slave settings only display the current setting. The other items in the slave settings are changeable. The set values and their meanings are given below for the settings that are only displayed.

Name	Meaning of setting
Device name	The device name that is set in the EtherCAT configuration
Model	The model number of the slave
Product name	The product name of the slave
Revision	The revision of the slave
Number of modules	The number of modules that are connected

You can edit the *PDO Map Settings* and *Module config send method*. The meanings of these settings are given below.

#### **PDO Map Settings**

- The PDO Map Settings displays the settings for the process data assigned for the slave.
- When valid PDOs are present, a list of them is displayed.
- When valid PDOs are not present, "---" is displayed.
- Process data is assigned for each slave in default by the Sysmac Studio. To change the process data assignments, click the Edit PDO Map Settings Button. For details, refer to A-3-4 Editing PDO Entry Tables.

#### Module config send method

- This is the area to select whether to send the module configuration information to the device or not.
- When you select *Send*, module configuration information commands are created for the devices. However, the slaves must support this function.
- When you select *Do not send*, module configuration information commands are not created for the devices.
- · The default is Do not send.

3 Select the location at which to register a module and double-click the module to register in the Toolbox. Or, drag the module from the Toolbox to the location to register it on the Edit Pane for the module configuration.

The module is registered and a list of module settings is displayed.



Some items in the module settings only display the current setting. The other items in the module settings are changeable. The set values and their meanings are given below for the settings that are only displayed.

Name	Set value that is displayed
Model	The model name of the device is displayed.
Product name	The product name of the device is displayed.
Connected position	The connected position of the device is displayed.

You can edit the *Device name* and the *PDO Map Settings*. The meanings of these settings are given below.

#### **Device Name**

- The name of the module is displayed.
- The default is M#. "#" is a serial number that starts from 1.

#### **PDO Map Settings**

- The PDO Map Settings displays the settings for the process data assigned for the module.
- When valid PDOs are present, a list of them is displayed.
- When valid PDOs are not present, "---" is displayed.
- Process data is assigned for each module in default by the Sysmac Studio. To change the
  process data assignments, click the Edit PDO Map Settings Button. For details, refer to A-34 Editing PDO Entry Tables.

# A-4 Glossary

Use the following list of EtherCAT terms for reference.

Term	Abbrevia- tion	Description
AL status (application layer status)	-	Status for indicating information on errors that occur in an application on a slave.
CAN application protocol over Ether-CAT	CoE	A CAN application protocol service implemented on EtherCAT.
CAN in Automation	CiA	CiA is the international users' and manufacturers' group that develops and supports higher-layer protocols.
device profile	_	Collection of device dependent information and functionality providing consistency between similar devices of the same device type.
device variables	_	Variables in the NJ/NX-series CPU Unit to which process data on EtherCAT slaves are allocated. Slave process data is accessed by directly reading and writing these device variables from user applications on the NJ/NX-series CPU Unit.
distributed clocks	DC	Clock distribution mechanism used to synchronize EtherCAT Slave Units and the EtherCAT Master Units.
EtherCAT Master Function Module	_	One of the function modules. This module controls the EtherCAT slaves as the EtherCAT master.
EtherCAT slave controller	ESC	A controller for EtherCAT slave communication.
EtherCAT slave information	ESI	An XML file that contains setting information for an EtherCAT Slave Unit.
EtherCAT state machine	ESM	An EtherCAT communication state machine.
EtherCAT Technology Group	ETG	The ETG is a global organization in which OEM, End Users and Technology Providers join forces to support and promote the further technology development.
index	_	Address of an object within an application process.
network configuration information	-	The EtherCAT network configuration information held by the Ether-CAT master.
object	_	Abstract representation of a particular component within a device, which consists of data, parameters, and methods.
object dictionary	OD	Data structure addressed by Index and Sub-index that contains description of data type objects, communication objects and application objects.
Operational	_	A state in EtherCAT communications where SDO communications and I/O are possible.
packet monitoring	-	A function that enables the EtherCAT master to capture packets flowing over an EtherCAT line and store them in the master. You can start and stop capturing packets from the Sysmac Studio or with EtherCAT communications instructions.
PDO communications	_	An acronym for process data communications.
Pre-operational	-	A state in EtherCAT communications where only SDO communications are possible without being able to perform I/O.
process data	_	Collection of application objects designated to be downloaded cyclically or acyclically for the purpose of measurement and control.
process data communications	-	One type of EtherCAT communications that uses process data objects (PDOs) to exchange information in realtime with a fixed cycle. This is also called PDO communications.
process data object	PDO	Structure described by mapping parameters containing one or several process data entities.
receive PDO	RxPDO	A process data object received by an EtherCAT Slave Unit.

Term	Abbrevia- tion	Description
Safe operational	_	A state in EtherCAT communications where only SDO communications and reading input data from slaves are possible. Outputs from slaves are not performed.
SDO communications	-	One type of EtherCAT communications that uses service data objects (SDOs) for communicating information when required.
service data object	SDO	CoE asynchronous mailbox communications where all objects in the object dictionary can be read and written.
Slave Information Interface	SII	Slave information that is stored in non-volatile memory in the slave.
subindex	-	Sub-address of an object within the object dictionary.
sync jitter	-	The offset in the operation timing between slaves.
sync manager	SM	Collection of control elements to coordinate access to concurrently used objects.
such as the EtherCAT communities information about EtherCAT		A variable in the NJ/NX-series CPU Unit for providing information such as the EtherCAT communications status and error status. Status information about EtherCAT communications is obtained by reading system-defined variables from user applications in the NJ/NX-series CPU Unit.
transmission jitter	-	The jitter in the process data transmission period (ns).
transmit PDO	TxPDO	A process data object sent from an EtherCAT Slave Unit.
WireShark	_	Freeware for monitoring and capturing packets.

## A-5 Version Information

This appendix describes the changes in and additions to functional specifications that were made for changes in the unit version of the CPU Units.

#### Changes in and Additions to Functional Specifications

The following table gives the unit version of the CPU Units and the Sysmac Studio version for each addition or change to the functional specifications.

Function	Addition/change	Reference	Unit version	Sysmac Studio version
Backup and restore operations	Addition	page 9-29 and 9-30	1.03	1.04
Enabling/disabling	Addition	page 5-18 and 5-21	1.04	1.05
Packet monitoring*1	Addition	page 6-27 and A-8	1.10	1.12
Diagnosis/statistics log	Addition	page 9-18	1.11	_


<sup>\*1</sup> This function was added to the NJ301- and NJ101- CPU Units. The function is supported with all other CPU Unit models regardless of their versions.

#### Adding the EtherCAT Slaves That You Can Use

If you use a newer unit version of the CPU Unit, you can increase the OMRON EtherCAT Slaves that you can use. Refer to 1-2-1 System Configuration for details.

For information on the most recent lineup of the OMRON EtherCAT slaves, NX-series EtherCAT Communications Coupler Units and NX Units, refer to catalogs or OMRON websites, or ask your OMRON representative.

Appendices



# Index

# Index

Α		_EC_LinkStatus	7-6, 7-15
		_EC_MacAdrErr	7-3, 7-10
AL status	A-33	_EC_MBXSlavTbl	7-6, 7-14
Axis Variables		_EC_MsgErr	7-4, 7-12
		_EC_MstrErr	7-3, 7-9
В		_EC_NetCfgCmpErr	7-3, 7-11
		_EC_NetCfgErr	
Back up function	5-23	_EC_NetTopologyErr	
backing up	= =0	_EC_PDActive	
2-12, 2-14, 2-16, 5-31, 5-35, 9-28, 9-	29. 9-30. 9-32	_EC_PDCommErr	
Backup Parameter Settings		_EC_PDSendErr	7-3, 7-11
Built-in EtherCAT Error		_EC_PDSlavTbl	
		_EC_PDTimeoutErr	
C		_EC_PktMonStop	7-6, 7-15
		_EC_PktSaving	7-6, 7-15
CAN application protocol over EtherCAT	2 2 1 22	_EC_PortErr	7-3, 7-9
CAN in Automation		_EC_RegSlavTbl	7-6, 7-13
CiA		_EC_SlavAdrDupErr	7-4, 7-11
CoE		_EC_SlavAppErr	7-4, 7-12
		_EC_SlavEmergErr	7-4, 7-12
communications cables		_EC_SlavErr	7-3, 7-9
Communications Controller Error		_EC_SlavErrTbl	7-3, 7-10
Communications Error Slave Table		_EC_SlavInitErr	7-4, 7-12
Communications Port Error		_EC_StatisticsLogBusy	
comparing and merging		(Diagnosis/Statistics Log Busy)	7-7, 7-17
connected/disconnected setting		_EC_StatisticsLogCycleSec	
control states	3-9	(Diagnosis/Statistics Log Cycle)	7-7, 7-17
D		_EC_StatisticsLogEnable	
D		(Diagnosis/Statistics Log Enable)	7-7, 7-16
		_EC_StatisticsLogErr	
DC		(Diagnosis/Statistics Log Error)	7-7, 7-17
DC Synchronous Correction		Emergency Message Detected	7-4, 7-12
Device name		Enable Distributed Clock	5-18
device profile		Enable/Disable EtherCAT Slave	6-27
device variables		enable/disable setting	6-28
Diagnosis/Statistics Log Busy		Enable/Disable Settings	5-18
Diagnosis/Statistics Log Cycle		ESC	A-33
Diagnosis/Statistics Log Enable		ESI	A-33
Diagnosis/Statistics Log Error		ESI files	1-7, A-17, A-19
Disabled Slave Table		ESM	A-33
Disconnected Slave Table	•	ETG	A-33
distributed clocks	3-4, A-33	EtherCAT communications	3-1
_		EtherCAT features	1-2
E		EtherCAT instructions	6-20, 6-27
		EtherCAT Junction Slave	1-6
EC_ChangeEnableSetting		EtherCAT master	1-4
_EC_CommErrTbl	·	EtherCAT Master Function Module	A-33
_EC_DisableSlavTbl	·	EtherCAT master setting	5-11
_EC_DisconnSlavTbl		EtherCAT Message Error	
_EC_EntrySlavTbl		EtherCAT slave controller	
_EC_ErrSta		EtherCAT Slave Enable/Disable Settings	9-28
_EC_InDataInvalid		EtherCAT slave information	
_EC_IndataInvalidErr		EtherCAT slave information file	
_EC_LanHwErr	7-3, 7-10	EtherCAT slave setting	5-16

\_EC\_LinkOffErr ......7-3, 7-10

EtherCAT state machine ......A-33

EtherCAT Technology Group	A-33	PDO communications timeout detection	on count 5-13
		PDO Map Settings	5-18
F		PDOs	3-2
		performance specifications	1-9
Fail-soft Operation Setting	5-13	Pre-operational	3-10, A-33
forced refreshing		procedures	
3		overall procedure	1-14
1		process data	
		Process Data Communicating Slave T	
I/O nower aupply	17	process data communications	
I/O power supply		Process Data Communications Error	
I/O refreshing		Process Data Communications Status	
index		process data objects	·
Init		Process Data Reception Timeout Erro	
Input Data Invalid		Process Data Transmission Error	
Input Process Data Invalid Error		Product name	
installation		Floduct name	5-12, 5-17
communication cables	4-4	R	
1			
L		roccivo PDO	۸ ۵۵
		receive PDO	
Link OFF Error		Reference Clock	
Link Status	7-6, 7-15	Registered Slave Table	
		Relation between changes in the enal	
M		setting and I/O operations	
		Restore function	
MAC Address Error	7-3, 7-10	restoring2-12, 2	
major fault level Controller errors		Revision	
Master Error		Revision Check Method	5-13
Message Communications Enabled Slave		RxPDO	A-33
Model			
	5, 5	S	
N			
		Safe operational	
Network Configuration Error	7-3, 7-11	Saving Packet Data File	
network configuration information	5-2, A-33	SDO	
downloading		SDO communications	3-2, 3-6, 6-20, A-34
Network Configuration Information Error		SDOs	
network configuration verification		self diagnosis	
Network Configuration Verification Error		Serial Number	
Network Connected Slave Table		Serial Number Check Method	5-13
node addresses	•	service data objects	A-34
Number of Slaves		Setting Parameters	5-19
TValliber of Glaves	0-12	SII	A-34
0		Slave Application Error	7-4, 7-12
0		Slave Error	
		Slave Error Table	•
object dictionary		Slave Information Interface	
objects		Slave Initialization Error	
OD	A-33	Slave Node Address Duplicated Error	
Operational	3-10, A-33	slaves	7 7, 7 11
output ports	1-4	replacing	0_27
_		SM	
P			
		subindex	
packet monitoring	A-8. A-33	sync manager	
Packet Monitoring Stopped		Sysmac devices	
PDO		features	
PDO communications		Sysmac Studio	
PDO Communications Cycle Time		system configuration	
1 DO OUTITIONIONIONIS CYCLE TITLE	5-12	system-defined variables	3-7. 5-21. 7-2. A-34

EtherCAT communications errors	7-9
EtherCAT communications status	7-6, 7-13
Т	
topologies	4-2
Total Cable Length	
transmit PDO	A-34
TxPDO	A-34
U	
unit power supplies	1-7
W	
Wait Time for Slave Startup	5-13
AAC - Ole - I	A 0.4

**OMRON** Corporation **Industrial Automation Company** 

Kyoto, JAPAN

Contact: www.ia.omron.com

Regional Headquarters
OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2),
Alexandra Technopark,
Singapore 119967
Tel: (65) 6835-3011/Fax: (65) 6835-2711

**OMRON ELECTRONICS LLC** 

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

**Authorized Distributor:** 

© OMRON Corporation 2011-2018 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. W505-E1-20